

ABB INDUSTRIAL DRIVES

# ACS880 primary control program (AINLX) Firmware manual





# ACS880 primary control program (AINLX)

## Firmware manual

Table of contents





# Table of contents

---

## 1 Introduction to the manual

What this chapter contains .....	15
Applicability .....	15
Safety instructions .....	15
Target audience .....	15
Related manuals .....	16
Terms and abbreviations .....	18
Cyber security disclaimer .....	20

## 2 Using the control panel

## 3 Control locations and operating modes

What this chapter contains .....	23
Local control vs. external control .....	23
Local control .....	24
External control .....	25
Using the control panel as an external control source .....	25
Operating modes of the drive .....	26
Speed control mode .....	26
Torque control mode .....	27
Frequency control mode .....	27
DC voltage control mode .....	27
Special control modes .....	27

## 4 Program features

What this chapter contains .....	29
Drive configuration and programming .....	30
Programming via parameters .....	30
Adaptive programming .....	31
Settings and diagnostics .....	31
Application programming .....	31
Control interfaces .....	32
Programmable analog inputs .....	32
Settings and diagnostics .....	32
Programmable analog outputs .....	32
Settings and diagnostics .....	32
Programmable digital inputs and outputs .....	32
Settings and diagnostics .....	33

---



## 6 Table of contents

Programmable relay outputs .....	33
Settings and diagnostics .....	33
Programmable I/O extensions .....	33
Settings and diagnostics .....	34
Fieldbus control .....	34
Settings and diagnostics .....	34
Master/follower functionality .....	34
General .....	34
Load share function with a speed-controlled follower .....	36
Communication .....	36
Construction of the master/follower link .....	38
Example parameter settings .....	40
Specifications of the fiber optic master/follower link .....	41
Settings and diagnostics .....	41
External controller interface .....	42
General .....	42
Topology .....	42
Communication .....	43
Control of a supply unit (LSU) .....	44
General .....	44
Communication .....	44
Settings and diagnostics .....	45
Motor control .....	45
Direct torque control (DTC) .....	45
Settings and diagnostics .....	45
Reference ramping .....	46
Special acceleration/deceleration ramps .....	46
Settings and diagnostics .....	46
Constant speeds/frequencies .....	47
Settings and diagnostics .....	47
Critical speeds/frequencies .....	47
Example .....	47
Settings and diagnostics .....	48
Speed controller autotune .....	48
Before activating the autotune routine .....	49
Autotune modes .....	50
Autotune results .....	50
Warning indications .....	51
Settings and diagnostics .....	51
Oscillation damping .....	51
Tuning procedure for oscillation damping .....	52
Settings and diagnostics .....	52
Resonance frequency elimination .....	52
Settings and diagnostics .....	53



Rush control .....	53
Settings and diagnostics .....	53
Encoder support .....	53
Encoder echo and emulation .....	54
Load and motor feedback .....	54
Position counter .....	55
Encoder error handling .....	56
Reading/writing position counter values through fieldbus .....	57
Configuration of HTL encoder motor feedback .....	57
Example 1: Using the same encoder for both load and motor feedback .....	58
Example 2: Using two encoders .....	58
Example 3: ACS 600 / ACS800 compatibility .....	59
Settings and diagnostics .....	60
Jogging .....	60
Settings and diagnostics .....	62
Scalar motor control .....	62
IR compensation for scalar motor control .....	63
Settings and diagnostics .....	63
Autophasing .....	63
Autophasing modes .....	65
Settings and diagnostics .....	66
Flux braking .....	66
Settings and diagnostics .....	67
DC magnetization .....	67
Pre-heating .....	67
Pre-magnetization .....	67
DC hold .....	67
Post-magnetization .....	68
Continuous magnetization .....	68
Settings and diagnostics .....	69
Motor temperature estimation .....	69
Settings and diagnostics .....	69
Hexagonal motor flux pattern .....	69
Settings and diagnostics .....	70
Application control .....	71
Application macros .....	71
Process PID control .....	71
Quick configuration of the process PID controller .....	71
Sleep function for process PID control .....	72
Tracking .....	73
Settings and diagnostics .....	73
Motor potentiometer .....	73
Settings and diagnostics .....	74



## 8 Table of contents

Mechanical brake control .....	75
Inputs of the brake control logic .....	75
Outputs of the brake control logic .....	75
Brake state diagram .....	76
Timing diagram .....	78
Wiring example .....	79
Settings and diagnostics .....	80
DC voltage control .....	80
Overvoltage control .....	80
Undervoltage control (power loss ride-through) .....	80
Automatic restart .....	81
Settings and diagnostics .....	82
Voltage control and trip limits .....	83
Settings and diagnostics .....	83
Brake chopper .....	84
Settings and diagnostics .....	84
DC voltage boost .....	84
Description of the DC voltage boost function .....	84
Use case examples .....	85
Limits .....	86
DC voltage control mode .....	88
Settings and diagnostics .....	88
Safety and protections .....	89
Emergency stop .....	89
Settings and diagnostics .....	89
Motor thermal protection .....	90
Motor thermal protection model .....	90
Temperature monitoring using PTC sensors .....	91
Temperature monitoring using Pt100 or Pt1000 sensors .....	93
Temperature monitoring using KTY84 sensors .....	93
Motor fan control logic (parameters <i>35.100...35.106</i> ) .....	94
Ex motor support (parameter <i>95.15</i> , bit 0) .....	94
PTC/Pt100 relay (parameter <i>95.20</i> , bit 8) .....	94
Settings and diagnostics .....	95
Motor overload protection .....	95
Settings and diagnostics .....	96
Thermal protection of motor cable .....	96
Settings and diagnostics .....	96
User load curve .....	96
Settings and diagnostics .....	97
Automatic fault resets .....	97
Settings and diagnostics .....	98
Other programmable protection functions .....	98
External events (parameters <i>31.01...31.10</i> ) .....	98
Motor phase loss detection (parameter <i>31.19</i> ) .....	98





Earth (Ground) fault detection (parameter 31.20) .....	98
Safe torque off detection (parameter 31.22) .....	98
Swapped supply and motor cabling (parameter 31.23) .....	98
Stall protection (parameters 31.24...31.28) .....	99
Overspeed protection (parameter 31.30) .....	99
Ramp stop supervision (parameters 31.32, 31.33, 31.37 and 31.38) .....	99
Main cooling fan supervision (parameter 31.35) .....	99
Custom motor current fault limit (parameter 31.42) .....	99
Local control loss detection (parameter 49.05) .....	99
Diagnostics .....	100
Fault and warning messages, data logging .....	100
Signal supervision .....	100
Settings and diagnostics .....	100
Maintenance timers and counters .....	100
Settings and diagnostics .....	100
Energy saving calculators .....	101
Settings and diagnostics .....	101
Load analyzer .....	101
Peak value logger .....	101
Amplitude loggers .....	102
Miscellaneous .....	103
User parameter sets .....	103
Settings and diagnostics .....	103
Parameter checksum calculation .....	103
Settings and diagnostics .....	104
User lock .....	105
Settings and diagnostics .....	105
Data storage parameters .....	106
Settings and diagnostics .....	106
Reduced run function .....	106
Activation of the reduced run function .....	107
du/dt filter support .....	108
Settings and diagnostics .....	108
Sine filter support .....	108
Settings and diagnostics .....	108
Router mode for BCU control unit .....	109
Settings and diagnostics .....	110
Parameter ranges with option +N8200 (High speed license) .....	110

## 5 Application macros

What this chapter contains .....	113
General .....	113
Factory macro .....	114
Default parameter settings for the Factory macro .....	114



Default control connections for the Factory macro .....	114
Hand/Auto macro .....	117
Default parameter settings for the Hand/Auto macro .....	117
Default control connections for the Hand/Auto macro .....	118
PID control macro .....	120
Default parameter settings for the PID control macro .....	120
Default control connections for the PID control macro .....	122
Sensor connection examples for the PID control macro .....	124
Torque control macro .....	125
Default parameter settings for the Torque control macro .....	125
Default control connections for the Torque control macro .....	126
Sequential control macro .....	128
Operation diagram .....	128
Selection of constant speeds .....	129
Default parameter settings for the Sequential control macro .....	129
Default control connections for the Sequential control macro .....	130
Fieldbus control macro .....	132



## 6 Parameters

What this chapter contains .....	133
Terms and abbreviations .....	134
Parameter group summary .....	135
Parameter listing .....	138
1 Actual values .....	138
3 Input references .....	144
4 Warnings and faults .....	146
5 Diagnostics .....	159
6 Control and status words .....	161
7 System info .....	178
10 Standard DI, RO .....	182
11 Standard DIO, FI, FO .....	191
12 Standard AI .....	199
13 Standard AO .....	205
14 I/O extension module 1 .....	211
15 I/O extension module 2 .....	239
16 I/O extension module 3 .....	245
19 Operation mode .....	251
20 Start/stop/direction .....	254
21 Start/stop mode .....	267
22 Speed reference selection .....	278
23 Speed reference ramp .....	288
24 Speed reference conditioning .....	295
25 Speed control .....	302
26 Torque reference chain .....	314
28 Frequency reference chain .....	323

29 Voltage reference chain .....	333
30 Limits .....	338
31 Fault functions .....	349
32 Supervision .....	362
33 Generic timer & counter .....	366
35 Motor thermal protection .....	375
36 Load analyzer .....	390
37 User load curve .....	395
40 Process PID set 1 .....	399
41 Process PID set 2 .....	414
43 Brake chopper .....	417
44 Mechanical brake control .....	420
45 Energy efficiency .....	426
46 Monitoring/scaling settings .....	430
47 Data storage .....	435
49 Panel port communication .....	438
50 Fieldbus adapter (FBA) .....	442
51 FBA A settings .....	452
52 FBA A data in .....	454
53 FBA A data out .....	455
54 FBA B settings .....	456
55 FBA B data in .....	458
56 FBA B data out .....	459
58 Embedded fieldbus .....	460
60 DDCS communication .....	470
61 D2D and DDCS transmit data .....	488
62 D2D and DDCS receive data .....	494
90 Feedback selection .....	505
91 Encoder module settings .....	516
92 Encoder 1 configuration .....	520
93 Encoder 2 configuration .....	527
94 LSU control .....	529
95 HW configuration .....	533
96 System .....	543
97 Motor control .....	555
98 User motor parameters .....	561
99 Motor data .....	564
200 Safety .....	572
206 I/O bus configuration .....	572
207 I/O bus service .....	573
208 I/O bus diagnostics .....	573
209 I/O bus fan identification .....	573

## 7 Fault tracing

What this chapter contains .....	575
----------------------------------	-----



Safety .....	575
Indications .....	576
Warnings and faults .....	576
Pure events .....	576
Editable messages .....	576
Warning/fault history and analysis .....	577
Event logs .....	577
Auxiliary codes .....	577
Factory data logger .....	577
Other data loggers .....	577
User data logger .....	577
PSL2 data logger .....	578
Parameters that contain warning/fault information .....	578
Event word (parameters <i>04.40...04.72</i> ) .....	578
QR Code generation for mobile service application .....	578
Warning, fault and pure event messages .....	579
Auxiliary codes for line-side converter warnings .....	622
Auxiliary codes for line-side converter faults .....	625



**8 Fieldbus control through the embedded fieldbus interface (EFB)**

What this chapter contains .....	629
System overview .....	630
Connecting the fieldbus to the drive .....	630
Setting up the embedded fieldbus interface .....	631
Setting the drive control parameters .....	633
Basics of the embedded fieldbus interface .....	634
Control word and Status word .....	635
References .....	636
Actual values .....	636
Data input/outputs .....	636
Control of drive outputs through EFB .....	636
Sending process PID feedback and setpoint values through EFB .....	637
Register addressing .....	637
About the control profiles .....	637
The ABB Drives profile .....	638
Control Word .....	638
Status Word .....	640
State transition diagram .....	641
References .....	643
Actual values .....	644
Modbus holding register addresses .....	645
The Transparent profile .....	645
Modbus function codes .....	646
Exception codes .....	647

Coils (0xxxx reference set) .....	648
Discrete inputs (1xxxx reference set) .....	649
Error code registers (holding registers 400090...400100) .....	651

## 9 Fieldbus control through a fieldbus adapter

What this chapter contains .....	653
System overview .....	653
Basics of the fieldbus control interface .....	655
Control word and Status word .....	656
Debugging the network words .....	656
References .....	657
Debugging the network words .....	657
Scaling of references .....	657
Actual values .....	658
Debugging the network words .....	658
Scaling of actual values .....	658
Contents of the fieldbus Control word (ABB Drives profile) .....	659
Contents of the fieldbus Status word (ABB Drives profile) .....	661
The state diagram (ABB Drives profile) .....	662
Setting up the drive for fieldbus control .....	663
Parameter setting example: FPBA (PROFIBUS DP) .....	664

## 10 Control chain diagrams

What this chapter contains .....	667
Drive control diagrams .....	668
Speed reference source selection I .....	668
Speed reference source selection II .....	669
Speed reference ramping and shaping .....	670
Motor feedback configuration .....	671
Load feedback and position counter configuration .....	672
Speed error calculation .....	673
Speed controller .....	674
Torque reference source selection and modification .....	675
Operating mode selection .....	676
Reference selection for torque controller .....	677
Torque limitation .....	678
Torque controller .....	679
Frequency reference selection .....	680
Frequency reference modification .....	681
DC voltage reference selection .....	682
DC voltage reference modification .....	683
Process PID setpoint and feedback source selection .....	684
Process PID controller .....	685
Master/Follower communication I (Master) .....	686



14 Table of contents

Master/Follower communication II (Follower) ..... 687

**Further information**



A large, bold, black number '1' is centered within a light grey rounded square. This graphic serves as a chapter indicator for the first section of the manual.

# Introduction to the manual

---

## What this chapter contains

This chapter describes the contents of the manual. It also contains information on the compatibility, safety and intended audience.

## Applicability

This manual applies to ACS880 primary control program version 3.4x or later.

The firmware version of the control program is visible in parameter [7.5 Firmware version \(page 178\)](#), or the System info in the main menu on the drive control panel.

## Safety instructions

Follow all safety instructions delivered with the drive.

- Read the **complete safety instructions** before you install, commission, or use the drive. The complete safety instructions are delivered with the drive as either part of the *Hardware manual*, or, in the case of ACS880 multidrives, as a separate document.
- Read the **firmware function-specific warnings and notes** before changing parameter values. These warnings and notes are included in the parameter descriptions presented in chapter Parameters.

## Target audience

This manual is intended for people who design, commission, or operate the drive system.

---

## Related manuals

**Note:** A quick start-up sequence for a speed control application is provided by *ACS880 drives with primary control program, Quick start-up guide* (3AUA0000098062), delivered with the drive.

Name	Code
<b>Lists of hyperlinks to product manuals <sup>1)</sup></b>	
ACS880-01 drives	<a href="#">9AKK105408A7004</a>
ACS880-04 drive modules (200 to 710 kW, 300 to 700 hp)	<a href="#">9AKK105713A4819</a>
ACS880-07 drives (45 to 710 kW, 50 to 700 hp)	<a href="#">9AKK105408A8149</a>
ACS880-07 drives (560 to 2800 kW)	<a href="#">9AKK105713A6663</a>
ACS880-07CLC drives hardware manual	<a href="#">9AKK107046A0239</a>
ACS880-07LC drives hardware manual	<a href="#">9AKK107680A9275</a>
ACS880-11 drives	<a href="#">9AKK106930A9565</a>
ACS880-14 drive modules (132 to 400 kW, 200 to 450 hp)	<a href="#">9AKK107045A8023</a>
ACS880-17 drives (45 to 400 kW, 60 to 450 hp)	<a href="#">9AKK106930A3466</a>
ACS880-17 drives (160 to 3200 kW)	<a href="#">9AKK106354A1499</a>
ACS880-17LC drives	<a href="#">9AKK107492A4721</a>
ACS880-31 drives	<a href="#">9AKK106930A9564</a>
ACS880-34 drive modules (132 to 400 kW, 200 to 450 hp)	<a href="#">9AKK107045A8025</a>
ACS880-37 drives (45 to 400 kW, 60 to 450 hp)	<a href="#">9AKK106930A3467</a>
ACS880-37 drives (160 to 3200 kW)	<a href="#">9AKK106354A1500</a>
ACS880-37LC drives	<a href="#">9AKK107492A4722</a>
<b>Other drive hardware manuals</b>	
ACS880-04XT drive module packages (500 to 1200 kW) hardware manual	<a href="#">3AXD50000025169</a>
ACS880-04 single drive module packages hardware manual	<a href="#">3AUA0000138495</a>
ACS880-14 and -34 single drive packages hardware manual	<a href="#">3AXD50000022021</a>
ACS880-104 inverter modules hardware manual	<a href="#">3AUA0000104271</a>
ACS880-104LC inverter modules hardware manual	<a href="#">3AXD50000045610</a>
ACS880-107 inverter units hardware manual	<a href="#">3AUA0000102519</a>
ACS880-107LC inverter units hardware manual	<a href="#">3AXD50000196111</a>
<b>Drive firmware manuals and guides</b>	
ACS880 primary control program firmware manual	<a href="#">3AUA0000085967</a>



Name	Code
ACS880 drives with primary control program, quick startup guide	<a href="#">3AUA0000098062</a>
Adaptive programming application guide	<a href="#">3AXD50000028574</a>
Drive application programming manual (IEC 61131-3)	<a href="#">3AUA0000127808</a>
ACS880 diode supply control program firmware manual	<a href="#">3AUA0000103295</a>
ACS880 IGBT supply control program firmware manual	<a href="#">3AUA0000131562</a>
CIO-01 I/O module for distributed I/O bus control user's manual	<a href="#">3AXD50000126880</a>
<b>Option manuals and guides</b>	
ACS-AP-I, -S, -W and ACH-AP-H, -W Assistant control panels User's manual	<a href="#">3AUA0000085685</a>
Drive Composer start-up and maintenance PC tool user's manual	<a href="#">3AUA0000094606</a>
Manuals and quick guides for I/O extension modules, fieldbus adapters, encoder interfaces, etc.	

1) Available in the Document library.

You can find manuals and other product documents in PDF format on the Internet. See section *Document library on the Internet* on the inside of the back cover. For manuals not available in the Document library, contact your local ABB representative.

## Terms and abbreviations

Term	Description
ACS-AP-I	Industrial assistant non-Bluetooth control panel
ACS-AP-W	Industrial assistant control panel with Bluetooth interface
AI	Analog input
AO	Analog output
BCU	Type of control unit
CIO	I/O module for controlling cooling fans
DC link	DC circuit between rectifier and inverter
DDCS	Distributed drives communication system protocol
DI	Digital input
DO	Digital output
Drive	Frequency converter for controlling AC motors
DTC	Direct torque control, a motor control method
EFB	Embedded fieldbus
FAIO-01	Analog I/O extension module
FBA	Fieldbus adapter
FCAN	Optional CANopen® adapter module
FCNA-01	Optional ControlNet™ adapter module
FDCO-01	DDCS communication module with two pairs of 10 Mbit/s DDCS channels
FDIO-01	Optional digital I/O extension module
FDNA-01	Optional DeviceNet™ adapter module
FEA-03	Optional I/O extension adapter
FECA-01	Optional EtherCAT® adapter module
FEN-01	Optional TTL incremental encoder interface module
FEN-11	Optional absolute encoder interface module
FEN-21	Optional resolver interface module
FEN-31	Optional HTL incremental encoder interface module
FENA-11	Optional Ethernet adapter module for EtherNet/IP™, Modbus TCP® and PROFINET IO® protocols
FENA-21	Optional Ethernet adapter module for EtherNet/IP™, Modbus TCP and PROFINET IO protocols, 2-port
FEPL-02	Optional Ethernet POWERLINK adapter module
FIO-01	Optional digital I/O extension module
FIO-11	Optional analog I/O extension module
FPBA-01	Optional PROFIBUS DP® adapter module
FPTC-01	Optional thermistor protection module
FPTC-02	Optional ATEX-certified thermistor protection module for potentially explosive atmospheres
FSCA-01	Optional RS-485 (Modbus/RTU) adapter

<b>Term</b>	<b>Description</b>
FSO-12, FSO-21	Optional functional safety modules
HTL	High-threshold logic
ID run	Motor identification run. During the identification run, the drive will identify the characteristics of the motor for optimum motor control.
IGBT	Insulated gate bipolar transistor
INU	Inverter unit
Inverter unit	Inverter module(s) under control of one control unit, and related components. One inverter unit typically controls one motor.
ISU	IGBT supply unit
Line-side converter	Converts alternating voltage to direct voltage for the intermediate DC link of the drive
ModuleBus	A communication link used by, for example, ABB controllers. ACS880 drives can be connected to the optical ModuleBus link of the controller.
Motor-side converter	Converts intermediate DC link current to AC current for the motor
Network control	With fieldbus protocols based on the Common Industrial Protocol (CIP™), such as DeviceNet and Ethernet/IP, denotes the control of the drive using the Control Supervisor and AC/DC drive objects of the ODVA AC/DC Drive Profile. For more information, see <a href="http://www.odva.org">www.odva.org</a> .
Parameter	In the drive control program, user-adjustable operation instruction to the drive, or signal measured or calculated by the drive. In some (for example fieldbus) contexts, a value that can be accessed as an object. For example, variable, constant, or signal.
PLC	Programmable logic controller
Power unit	Contains the power electronics and power connections of the drive module. The control unit is connected to the power unit.
PSL2	Protocol used in communication inside ABB inverters
PTC	Positive temperature coefficient
RDCO	Optical DDCS communication module
RO	Relay output
STO	Safe torque off (IEC/EN 61800-5-2)
Supply unit	Supply module(s) under control of one control unit, and related components.
TTL	Transistor-transistor logic
UPS	Uninterruptible power supply
ZCU	Type of control unit

## **Cyber security disclaimer**

This product is designed to be connected to and to communicate information and data via a network interface. It is Customer's sole responsibility to provide and continuously ensure a secure connection between the product and Customer network or any other network (as the case may be). Customer shall establish and maintain any appropriate measures (such as but not limited to the installation of firewalls, application of authentication measures, encryption of data, installation of anti-virus programs, etc.) to protect the product, the network, its system and the interface against any kind of security breaches, unauthorized access, interference, intrusion, leakage and/or theft of data or information.

ABB and its affiliates are not liable for damages and/or losses related to such security breaches, any unauthorized access, interference, intrusion, leakage and/or theft of data or information.

---



# Using the control panel

---

Refer to *ACS-AP-I, -S, -W and ACH-AP-H, -W Assistant control panels user's manual* ([3AUA0000085685](#) [English]).



## 3


# Control locations and operating modes

## What this chapter contains

This chapter describes the control locations and operating modes supported by the control program.

## Local control vs. external control

The ACS880 has two main control locations: external and local. The control location is selected with the Loc/Rem key on the control panel or in the PC tool.



## 24 Control locations and operating modes

<sup>1)</sup> Extra inputs/outputs can be added by installing optional I/O extension modules (FIO-xx) in drive slots.

<sup>2)</sup> Encoder or resolver interface module(s) (FEN-xx) installed in drive slots.

### ■ Local control

The control commands are given from the control panel keypad or from a PC equipped with Drive Composer when the drive is set to local control. Speed and torque control modes are available for local control; frequency mode is available when scalar motor control mode is used (see parameter [19.16](#)).

Local control is mainly used during commissioning and maintenance. The control panel always overrides the external control signal sources when used in local control. Changing the control location to local can be prevented by parameter [19.17](#).

The user can select by a parameter ([49.5](#)) how the drive reacts to a control panel or PC tool communication break. (The parameter has no effect in external control.)

---



## ■ External control

When the drive is in external control, control commands are given through

- the I/O terminals (digital and analog inputs), or optional I/O extension modules
- the embedded fieldbus interface or an optional fieldbus adapter module
- the external (DDCS) controller interface
- the master/follower link, and/or
- the control panel.

Two external control locations, EXT1 and EXT2, are available. The user can select the sources of the start and stop commands separately for each location by parameters 20.1...20.10. The operating mode can be selected separately for each location (in parameter group 19) which enables quick switching between different operating modes, for example speed and torque control. Selection between EXT1 and EXT2 is done via any binary source such as a digital input or fieldbus control word (see parameter 19.11). The source of reference is selectable for each operating mode separately.

The control location selection is checked on a 2 ms time level.

### Using the control panel as an external control source

The control panel can also be used as a source of start/stop commands and/or reference in external control. Selections for the control panel are available in the start/stop command source and reference source selection parameters.

Reference source selection parameters (except PID setpoint selectors) have two selections for the control panel. The difference between the two selections is in the initial reference value after the reference source switches to the control panel.

The panel reference is saved whenever another reference source is selected. If the reference source selection parameter is set to **Control panel (ref saved)**, the saved value is used as the initial reference when control switches back to the panel. Note that only one type of reference can be saved at a time: for example, attempting to use the same saved reference with different operating modes (speed, torque, etc.) causes the drive to trip on 7083. The panel reference can be separately limited by parameters in group 49.

With the reference source selection parameter set to **Control panel (ref copied)**, the initial panel reference value depends on whether the operating mode changes with the reference source. If the source switches to the panel and the operating mode does not change, the last reference from the previous source is adopted. If the operating mode changes, the drive actual value corresponding to the new mode is adopted as the initial value.


---

The process PID setpoint selectors in parameter groups 40 and 41 only have one setting for the control panel. Whenever the control panel is selected as the setpoint source, operation resumes using the previous setpoint.

## Operating modes of the drive

The drive can operate in several operating modes with different types of reference. The mode is selectable for each control location (Local, EXT1 and EXT2) in parameter group 19.

The following is a general representation of the reference types and control chains. For detailed diagrams, see chapter Control chain diagrams.



### ■ Speed control mode

The motor follows a speed reference given to the drive. This mode can be used either with estimated speed as feedback, or with an encoder or resolver for better speed control accuracy.

Speed control mode is available in both local and external control. It is also available both in DTC (Direct Torque Control) and scalar motor control modes.

### ■ Torque control mode

Motor torque follows a torque reference given to the drive. Torque control is possible without feedback, but is much more dynamic and accurate when used in conjunction with a feedback device such as an encoder or a resolver. It is recommended that a feedback device is used in crane, winch or lift control situations.

Torque control mode is available in DTC motor control mode for both local and external control locations.

### ■ Frequency control mode

The motor follows a frequency reference given to the drive. Frequency control is only available in scalar motor control mode.

### ■ DC voltage control mode

This mode is intended especially for off-grid applications where the inverter unit is connected to a generator and the supply unit creates an AC supply network.

The inverter unit adjusts the DC voltage by controlling generator torque. Based on the DC circuit capacitance either from an internal database or user input parameter, and measured DC voltage, the PI controller outputs a power reference. The power reference is then converted to a torque reference.

The settings of the DC voltage control chain are available in parameter group [29 Voltage reference chain \(page 333\)](#).

DC voltage control mode is only available with drives with a BCU control unit.

### ■ Special control modes

In addition to the control modes mentioned above, the following special control modes are available:

- Process PID control. For more information, see section [Process PID control \(page 71\)](#).
  - Emergency stop modes Off1 and Off3: Drive stops along the defined deceleration ramp and drive modulation stops.
  - Jogging mode: Drive starts and accelerates to the defined speed when the jogging signal is activated. For more information, see section [Jogging \(page 60\)](#).
-





# Program features

---

## What this chapter contains


This chapter contain description of program features and functions.

---

## Drive configuration and programming

The drive control program is divided into two parts:

- firmware program
- application program



The firmware program performs the main control functions, including speed and torque control, drive logic (start/stop), I/O, feedback, communication and protection functions. Firmware functions are configured and programmed with parameters, and can be extended by application programming.

### ■ Programming via parameters

Parameters configure all of the standard drive operations and can be set through

- the control panel, as described in chapter Using the control panel
- the Drive Composer PC tool, as described in *Drive Composer start-up and maintenance PC tool user's manual* (3AUA0000094606 [English]), or
- the fieldbus interface, as described in chapters Fieldbus control through the embedded fieldbus interface (EFB) and Fieldbus control through a fieldbus adapter.

All parameter settings are stored automatically to the permanent memory of the drive. However, if an external +24 V DC power supply is used for the drive control unit, it is highly recommended to force a save by using parameter 96.7 before powering down the control unit after any parameter changes have been made.

If necessary, the default parameter values can be restored by parameter 96.6.

## ■ Adaptive programming

Conventionally, the user can control the operation of the drive by parameters. However, the standard parameters have a fixed set of choices or a setting range. To further customize the operation of the drive, an adaptive program can be constructed out of a set of function blocks.

The Drive Composer PC tool has an Adaptive programming feature with a graphical user interface for building the custom program. The function blocks include the usual arithmetic and logical functions, as well as eg. selection, comparison and timer blocks. The program can contain a maximum of 20 blocks. The adaptive program is executed on a 10 ms time level.

For selecting input to the program, the user interface has pre-selections for the physical inputs, common actual values, and other status information of the drive. Parameter values as well as constants can also be defined as inputs. The output of the program can be used eg. as a start signal, external event or reference, or connected to the drive outputs. Note that connecting the output of the adaptive program to a selection parameter will write-protect the parameter.

The status of the adaptive program is shown by parameter [7.30](#). The adaptive program can be disabled by [96.70](#).

Please note that sequential programming is not supported.

For more information, see the *Adaptive programming application guide* (3AXD50000028574 [English]).

## Settings and diagnostics

Parameters: [7.30 Adaptive program status](#) (page 180) and [96.70 Disable adaptive program](#) (page 553).

Events: [64A6 Adaptive program](#) (page 590).

## ■ Application programming

The functions of the firmware program can be extended with application programming. Application programmability is available as option +N8010.

Application programs can be built out of function blocks based on the IEC 61131-3 standard using a PC tool available separately.

For more information, see *Programming manual: Drive application programming (IEC 61131-3)* (3AUA0000127808 [English]).

---

## Control interfaces

### ■ Programmable analog inputs

The control unit has two programmable analog inputs. Each of the inputs can be independently set as a voltage (0/2...10 V or -10...10 V) or current (0/4...20 mA) input by a jumper or switch on the control unit. Each input can be filtered, inverted and scaled.

The analog inputs on the control unit are read on a 0.5 ms time level.

The number of analog inputs can be increased by installing FIO-11 or FAIO-01 I/O extensions (see [Programmable I/O extensions](#) below). The analog inputs on extension modules are read on a 2 ms time level.

The drive can be set to perform an action (for example, to generate a warning or fault) if the value of an analog input moves out of a predefined range.

### Settings and diagnostics

Parameter group: [12 Standard AI \(page 199\)](#).

Events: [80A0 AI Supervision \(page 597\)](#) and [8BA0 AI Supervised Warning \(page 614\)](#).

### ■ Programmable analog outputs

The control unit has two current (0...20 mA) analog outputs. Each output can be filtered, inverted and scaled.

The analog outputs on the control unit are updated on a 0.5 ms time level.

The number of analog outputs can be increased by installing FIO-11 or FAIO-01 I/O extensions (see [Programmable I/O extensions](#) below). The analog outputs on extension modules are updated on a 2 ms time level.

### Settings and diagnostics

Parameter group: [13 Standard AO \(page 205\)](#).

### ■ Programmable digital inputs and outputs

The control unit has six digital inputs, a digital start interlock input, and two digital input/outputs (I/O that can be set as either an input or an output). The digital inputs on the control unit are read on a 0.5 ms time level.

One digital input (DI6) doubles as a PTC thermistor input. See section [Motor thermal protection \(page 90\)](#).

Digital input/output DIO1 can be used as a frequency input, DIO2 as a frequency output.

---



The number of digital inputs/outputs can be increased by installing FIO-01, FIO-11 or FDIO-01 I/O extensions (see [Programmable I/O extensions](#) below). The digital inputs on extension modules are read on a 2 ms time level.

### Settings and diagnostics

Parameter groups: [10 Standard DI, RO \(page 182\)](#) and [11 Standard DIO, FI, FO \(page 191\)](#).

#### ■ Programmable relay outputs

The control unit has three relay outputs. The signal to be indicated by the outputs can be selected by parameters.

The relay outputs on the control unit are updated on a 0.5 ms time level.

Relay outputs can be added by installing FIO-01 or FDIO-01 I/O extensions. The relay outputs on extension modules are updated on a 2 ms time level.

### Settings and diagnostics

Parameter groups: [10 Standard DI, RO \(page 182\)](#).

#### ■ Programmable I/O extensions

Inputs and outputs can be added by using I/O extension modules. One to three modules can be mounted on the slots of the control unit. Slots can be added by connecting an FEA-03 I/O extension adapter.

The table below shows the number of I/O on the control unit as well as optional I/O extension modules.

Location	Digital inputs (DI)	Digital I/Os (DIO)	Analog inputs (AI)	Analog outputs (AO)	Relay outputs (RO)
Control unit	6 + DIIL	2	2	2	3
FIO-01	-	4	-	-	2
FIO-11	-	2	3	1	-
FAIO-01	-	-	2	2	-
FDIO-01	3	-	-	-	2

Three I/O extension modules can be activated and configured using parameter groups 14...16.

**Note:** Each configuration parameter group contains parameters that display the values of the inputs on that particular extension module. These parameters are the only way of utilizing the inputs on I/O extension modules as signal sources. To connect to an input, choose the setting *Other* in the source selector parameter, then specify the appropriate value parameter (and bit, for digital signals) in group 14, 15 or 16.

### Settings and diagnostics

Parameter groups: 14 I/O extension module 1 (page 211), 15 I/O extension module 2 (page 239) and 16 I/O extension module 3 (page 245).

Parameter: 60.41 Extension adapter com port (page 481).

Events: 7082 Ext I/O comm loss (page 592) and A799 ExtIO comm loss (page 608).

### ■ Fieldbus control

The drive can be connected to several different automation systems through its fieldbus interfaces. See chapters Fieldbus control through the embedded fieldbus interface (EFB) and Fieldbus control through a fieldbus adapter.

### Settings and diagnostics

Parameter groups: 50 Fieldbus adapter (FBA) (page 442), 51 FBA A settings (page 452), 52 FBA A data in (page 454), 53 FBA A data out (page 455), 54 FBA B settings (page 456), 55 FBA B data in (page 458), 56 FBA B data out (page 459) and 58 Embedded fieldbus (page 460).

Events: 7510 FBA A communication (page 595), 7520 FBA B communication (page 596), A7C1 FBA A communication (page 611), A7C2 FBA B communication (page 611) and A7CE EFB comm loss (page 612).


### ■ Master/follower functionality

#### General

The master/follower functionality can be used to link several drives together so that the load can be evenly distributed between the drives. This is ideal in applications where the motors are coupled to each other via gearing, chain, belt, etc.

The external control signals are typically connected to one drive only which acts as the master. The master controls up to 10 followers by sending broadcast messages over an electrical cable or fiber optic link. The master can read feedback signals from up to 3 selected followers.

---



The master drive is typically speed-controlled and the other drives follow its torque or speed reference. In general, a follower should be

- torque-controlled when the motor shafts of the master and the follower are rigidly coupled by gearing, chain etc. so that no speed difference between the drives is possible.
- speed-controlled when the motor shafts of the master and the follower are flexibly coupled so that a slight speed difference is possible. When both the master and the follower are speed-controlled, drooping is also typically used (see parameter 25.8). The distribution of load between the master and follower can alternatively be adjusted as described under [Load share function with a speed-controlled follower](#) below.

**Note:** With a speed-controlled follower (without load sharing), pay attention to the acceleration and deceleration ramp times of the follower. If the ramp times are set longer than in the master, the follower will follow its own acceleration/deceleration ramp times rather than those from the master. In general, it is recommended to set identical ramp times in both the master and the follower(s). Any ramp shape settings (see parameters 23.16...23.19) should only be applied in the master.

In some applications, both speed control and torque control of the follower are required. In those cases, the operating mode can be switched by parameter (19.12 or 19.14). Another method is to set one external control location to speed control mode, the other to torque control mode. Then, a digital input of the follower can be used to switch between the control locations. See chapter Control locations and operating modes.

With torque control, follower parameter 26.15 can be used to scale the incoming torque reference for optimal load sharing between the master and the follower. Some torque-controlled follower applications, eg. where the torque is very low, or very low speed operation is required, may require encoder feedback.

If a drive needs to quickly switch between master and follower statuses, one user parameter set (see page 103) can be saved with the master settings, another with the follower settings. The suitable settings can then be activated using for example, digital inputs.

### Load share function with a speed-controlled follower

Load sharing between the master and a speed-controlled follower can be used in various applications. The load share function is implemented by fine-tuning the follower speed reference with an additional trim signal based on a torque reference. The torque reference is selected by parameter 23.42 (by default, reference 2 received from the master). Load share is adjusted by parameter 26.15 and activated by the source selected by 23.40. Parameter 23.41 provides a gain adjustment for the speed correction. The final correction signal added to the speed reference is shown by 23.39. See the block diagram on page 673.

#### Note:

- The function can be enabled only when the drive is a speed-controlled follower in remote control mode.
- Drooping (25.8) is ignored when the load share function is active.
- The master and follower should have the same speed control tuning values.
- The speed correction term is limited by the speed error window parameters 24.44 and 24.43. An active limitation is indicated by 6.19.
- For a reliable ramp stop of a follower,
  - both parameters 24.43 and 24.44 must be set smaller than parameter 21.6 (or speed error window control disabled altogether by 24.41), and
  - parameter 24.11 must be set smaller than parameter 21.6.

### Communication

A master/follower link can be built by connecting the drives together with fiber optic cables (may require additional equipment depending on existing drive hardware), or by wiring together the XD2D connectors of the drives. The medium is selected by parameter 60.1.

---

Parameter 60.3 defines whether the drive is the master or a follower on the communication link. Typically, the speed-controlled process master drive is also configured as the master in the communication.

The communication on the master/follower link is based on the DDCS protocol, which employs data sets (specifically, data set 41). One data set contains three 16-bit words. The contents of the data set are freely configurable using parameters 61.1...61.3. The data set broadcast by the master typically contains the control word, speed reference and torque reference, while the followers return a status word with two actual values.

The default setting of parameter 61.1 is **Follower CW**. With this setting in the master, a word consisting of bits 0...11 of 6.1 and four bits selected by parameters 6.45...6.48 is broadcast to the followers. However, bit 3 of the follower control word is modified so that it remains on as long as the master is modulating, and its switching to 0 causes the follower to coast to a stop. This is to synchronize the stopping of both master and follower.

**Note:** When the master is ramping down to a stop, the follower observes the decreasing reference but receives no stop command until the master stops modulating and clears bit 3 of the follower control word. Because of this, the maximum and minimum speed limits on the follower drive should not have the same sign – otherwise the follower would be pushing against the limit until the master finally stops.

Three words of additional data can optionally be read from each follower. The followers from which data is read are selected by parameter 60.14 in the master. In each follower drive, the data to be sent is selected by parameters 61.1...61.3. The data is transferred in integer format over the link, and displayed by parameters 62.28...62.36 in the master. The data can then be forwarded to other parameters using 62.4...62.12.

To indicate faults in the followers, each follower must be configured to transmit its status word as one of the above-mentioned data words. In the master, the corresponding target parameter must be set to **Follower SW**. The action to be taken when a follower is faulted is selected by parameter 60.17. External events (see parameter group 31 **Fault functions**) can be used to indicate the status of other bits of the status word.

For block diagrams of the master/follower communication are presented on pages 686 and 687.

---

**Construction of the master/follower link**


The master/follower link is formed by connecting the drives together using either

- shielded twisted-pair cable between the XD2D terminals of the drives\*, or
- fiber optic cables. Drives with a ZCU control unit require an additional FDCO DDCS communication module; drives with a BCU control unit require an RDCO module.

\*This connection cannot co-exist with, and is not to be confused with, drive-to-drive (D2D) communication implemented by application programming (detailed in *Drive application programming manual (IEC 61131-3)*, 3AUA0000127808 [English]).


Connection examples are shown below. Note that a star configuration using fiber optic cables requires an NDBU-95C DDCS branching unit.

Master/follower wiring with electrical cable




See the hardware manual of the drive for wiring and termination details.

Ring configuration with fiber optic cables




Where, T = Transmitter; R = Receiver

Star configuration with fiber optic cables (1)



Where, T = Transmitter; R = Receiver

Star configuration with fiber optic cables (2)



Where, T = Transmitter; R = Receiver

**Example parameter settings**

The following is a checklist of parameters that need to be set when configuring the master/follower link. In this example, the master broadcasts the Follower control word, a speed reference and a torque reference. The follower returns a status word and two actual values (this is not compulsory but is shown for clarity).

Master settings

- **Master/follower link activation**
  - 60.1 M/F communication port (fiber optic channel or XD2D selection)
  - (60.2 M/F node address = 1)
  - 60.3 M/F mode = *DDCS master* (for both fiber optic and wire connection)
  - 60.5 M/F HW connection (*Ring* or *Star* for fiber optic, *Star* for wire)
- **Data to be broadcast to the followers**
  - 61.1 M/F data 1 selection = *Follower CW* (Follower control word)
  - 61.2 M/F data 2 selection = *Used speed reference*
  - 61.3 M/F data 3 selection = *Torque reference act 5*
- **Data to be read from the followers (optional)**
  - 60.14 M/F follower selection (selection of followers that data is read from)



- [62.4 Follower node 2 data 1 sel ...](#) [62.12 Follower node 4 data 3 sel](#) (mapping of data received from followers)

### Follower settings

- **Master/follower link activation**
  - [60.1 M/F communication port](#) (fiber optic channel or XD2D selection)
  - [60.2 M/F node address](#) = 2...60
  - [60.3 M/F mode](#) = *DDCS master* (for both fiber optic and wire connection)
  - [60.5 M/F HW connection](#) (*Ring* or *Star* for fiber optic, *Star* for wire)
- **Mapping of data received from master**
  - [62.1 M/F data 1 selection](#) = *CW 16bit*
  - [62.2 M/F data 2 selection](#) = *Ref1 16bit*
  - [62.3 M/F data 3 selection](#) = *Ref2 16bit*
- **Selection of operating mode and control location**
  - [19.12 Ext1 control mode](#) = *Speed* or *Torque*
  - [20.1 Ext1 commands](#) = *M/F link*
  - [20.2 Ext1 start trigger type](#) = *Level*
- **Selection of reference sources**
  - [22.11 Speed ref1 source](#) = *M/F reference 1*
  - [26.11 Torque ref1 source](#) = *M/F reference 2*
- **Selection of data to be sent to master (optional)**
  - [61.1 M/F data 1 selection](#) = *SW 16bit*
  - [61.2 M/F data 2 selection](#) = *Act1 16bit*
  - [61.3 M/F data 3 selection](#) = *Act2 16bit*

### **Specifications of the fiber optic master/follower link**

- Maximum fiber optic cable length:
  - FDCO-01/02 or RDCO-04 with POF (Plastic Optic Fiber): 30 m
  - For distances up to 1000 m, use two NOCR-01 optical converter/repeaters with glass optic cable (GOF, 62.5 micrometers, Multi-Mode)
- Maximum shielded twisted-pair cable length: 50 m
- Transmission rate: 4 Mbit/s
- Total performance of the link: < 5 ms to transfer references between the master and followers.
- Protocol: DDCS (Distributed Drives Communication System)

### **Settings and diagnostics**

Parameter groups: [60 DDCS communication](#) (page 470), [61 D2D and DDCS transmit data](#) (page 488) and [62 D2D and DDCS receive data](#) (page 494).

Events: [7582 M/F comm loss](#) (page 596) and [A7CB M/F comm loss](#) (page 612).

---

## ■ External controller interface


### General

The drive can be connected to an external controller (such as the ABB AC 800M) using either fiber optic or twisted-pair cable. The ACS880 is compatible with both the ModuleBus and DriveBus connections. Note that some features of DriveBus (such as BusManager) are not supported.

### Topology

An example connection with either a ZCU-based or BCU-based drive using fiber optic cables is shown below.

Drives with a ZCU control unit require an additional FDCO DDCS communication module; drives with a BCU control unit require an RDCO or FDCO module. The BCU has a dedicated slot for the RDCO – an FDCO module can also be used with a BCU control unit but it will reserve one of the three universal option module slots. Ring and star configurations are also possible much in the same way as with the master/follower link (see section [Master/follower functionality \(page 34\)](#)); the notable difference is that the external controller connects to channel CH0 on the RDCO module instead of CH2. The channel on the FDCO communication module can be freely selected.



T = Transmitter, R = Receiver

The external controller can also be wired to the D2D (RS-485) connector using shielded, twisted-pair cable. The selection of the connection is made by parameter [60.51](#).

The transfer rate can be selected by parameter [60.56](#).


## Communication

The communication between the controller and the drive consists of data sets of three 16-bit words each. The controller sends a data set to the drive, which returns the next data set to the controller.

The communication uses data sets 10...33. The contents of the data sets are freely configurable, but data set 10 typically contains the control word and one or two references, while data set 11 returns the status word and selected actual values. For ModuleBus communication, the ACS880 can be set up as a “standard drive” or an “engineered drive” by parameter 60.50. ModuleBus communication uses data sets 1...4 with a “standard drive” and data sets 10...33 with an “engineered drive”.

The word that is defined as the control word is internally connected to the drive logic; the coding of the bits is as presented in section [Contents of the fieldbus Control word \(ABB Drives profile\) \(page 659\)](#). Likewise, the coding of the status word is as shown in section [Contents of the fieldbus Status word \(ABB Drives profile\) \(page 661\)](#).

By default, data sets 32 and 33 are dedicated for the mailbox service, which enables the setting or inquiry of parameter values as follows:



\*19.01 → 13h.01h → 1301h = 4865

\*\*24.03 → 18h.03h → 1803h = 6147

## 44 Program features

By parameter [60.64](#), data sets 24 and 25 can be selected instead of data sets 32 and 33.

The update intervals of the data sets are as follows:

- Data sets 10...11: 2 ms
- Data sets 12...13: 4 ms
- Data sets 14...17: 10 ms
- Data sets 18...25, 32, 33: 100 ms.

### Settings and diagnostics

Parameter groups: [60 DDCS communication](#) (page 470), [61 D2D and DDCS transmit data](#) (page 488) and [62 D2D and DDCS receive data](#) (page 494).

Events: [7581 DDCS controller comm loss](#) (page 596) and [A7CA DDCS controller comm loss](#) (page 612).

## ■ Control of a supply unit (LSU)

### General

If the drive has separately-controlled supply and inverter units (also known as lineside and motor-side converters), the supply unit can be controlled through the inverter unit. For example, the inverter unit can send a control word and references to the supply unit, enabling the control of both units from the interfaces of one control program.

With ACS880 single drives, the two control units are connected at the factory. In ACS880 multidrives (drive systems with one supply unit and multiple inverter units), the feature is not typically used.

### Communication

The communication between the converters and the drive consists of data sets of three 16-bit words each. The inverter unit sends a data set to the supply unit, which returns the next data set to the inverter unit.

The communication uses data sets 10 and 11, updated at 2 ms intervals. Data set 10 is sent by the inverter unit to the supply unit, while data set 11 is sent by the supply unit to the inverter unit. The contents of the data sets are freely configurable, but data set 10 typically contains the control word, while data set 11 returns the status word.

The basic communication is initialized by parameter [95.20](#). This will make several parameters visible (see below).

If the supply unit is regenerative (such as an IGBT supply unit), it is possible to send a DC voltage and/or reactive power reference to it from inverter parameter

---

group [94 LSU control](#). A regenerative supply unit will also send actual signals to the inverter unit which are visible in parameter group [1 Actual values](#).

### Settings and diagnostics

Parameters: [1.102 Line current \(page 142\)](#)...[1.164 LSU nominal power](#), [5.111 Line converter temperature](#)...[5.121 MCB closing counter](#), [6.36 LSU Status Word](#)...[6.43 LSU CW user bit 3 selection](#), [6.116 LSU drive status word 1](#)...[6.118 LSU start inhibit status word](#), [7.106 LSU loading package name](#)...[7.107 LSU loading package version](#), [30.101 LSU limit word 1](#)...[30.149 LSU maximum power limit](#), [31.120 LSU earth fault](#)...[31.121 LSU supply phase loss](#), [95.20 HW options word 1 \(page 540\)](#) and [96.108 LSU control board boot \(page 554\)](#).

Parameter groups: [60 DDCS communication \(page 470\)](#), [61 D2D and DDCS transmit data \(page 488\)](#), [62 D2D and DDCS receive data \(page 494\)](#) and [94 LSU control \(page 529\)](#).

Events: [7580 INU-LSU comm loss \(page 596\)](#), [7584 LSU charge failed \(page 596\)](#), [AF80 INU-LSU comm loss \(page 616\)](#) and [AF85 Line side unit warning \(page 616\)](#).

## Motor control

### ■ Direct torque control (DTC)

The motor control of the ACS880 is based on direct torque control (DTC), the ABB premium motor control platform. The switching of the output semiconductors is controlled to achieve the required stator flux and motor torque. The reference value for the torque controller comes from the speed controller, DC voltage controller or directly from an external torque reference source.

Motor control requires measurement of the DC voltage and two motor phase currents. Stator flux is calculated by integrating the motor voltage in vector space. Motor torque is calculated as a cross product of the stator flux and the rotor current. By utilizing the identified motor model, the stator flux estimate is improved. Actual motor shaft speed is not needed for the motor control.

The main difference between traditional control and DTC is that torque control operates on the same time level as the power switch control. There is no separate voltage and frequency controlled PWM modulator; the output stage switching is wholly based on the electromagnetic state of the motor.

The best motor control accuracy is achieved by activating a separate motor identification run (ID run).

See also section [Scalar motor control \(page 62\)](#).

### Settings and diagnostics

Parameters: [99.4 Motor control mode \(page 564\)](#) and [99.13 ID run requested \(page 567\)](#).

### ■ Reference ramping

Acceleration and deceleration ramping times can be set individually for speed, frequency and torque reference.

With a speed or frequency reference, the ramps are defined as the time it takes for the drive to accelerate or decelerate between zero speed or frequency and the value defined by parameter [46.1](#) or [46.2](#). The user can switch between two preset ramp sets using a binary source such as a digital input. For speed reference, also the shape of the ramp can be controlled.

With a torque reference, the ramps are defined as the time it takes for the reference to change between zero and nominal motor torque (parameter [1.30](#)).

### Special acceleration/deceleration ramps

The acceleration/deceleration times for the jogging function can be defined separately; see section [Jogging \(page 60\)](#).

The change rate of the motor potentiometer function (page [73](#)) is adjustable. The same rate applies in both directions.

A deceleration ramp can be defined for emergency stop (“Off3” mode).

### Settings and diagnostics

Parameters:

- Speed reference ramping: [23.11 Ramp set selection...](#)[23.19 Shape time dec 2](#) and [46.1 Speed scaling \(page 430\)](#).
  - Torque reference ramping: [1.30 Nominal torque scale \(page 140\)](#), [26.18 Torque ramp up time \(page 316\)](#) and [26.19 Torque ramp down time \(page 316\)](#).
  - Frequency reference ramping: [28.71 Freq ramp set selection...](#)[28.75 Freq deceleration time 2](#) and [46.2 Frequency scaling \(page 430\)](#).
  - Jogging: [23.20 Acc time jogging \(page 291\)](#) and [23.21 Dec time jogging \(page 291\)](#).
  - Motor potentiometer: [22.75 Motor potentiometer ramp time \(page 285\)](#).
  - Emergency stop (“Off3” mode): [23.23 Emergency stop time \(page 291\)](#).
-

## ■ Constant speeds/frequencies

Constant speeds and frequencies are predefined references that can be quickly activated, for example, through digital inputs. It is possible to define up to 7 constant speeds for speed control and 7 constant frequencies for frequency control.



### **WARNING!**

Constant speeds and frequencies override the normal reference irrespective of where the reference is coming from.

---

The constant speeds/frequencies function operates on a 2 ms time level.

### **Settings and diagnostics**

Parameter groups: [22 Speed reference selection \(page 278\)](#) and [28 Frequency reference chain \(page 323\)](#).

## ■ Critical speeds/frequencies

Critical speeds (sometimes called “skip speeds”) can be predefined for applications where it is necessary to avoid certain motor speeds or speed ranges because of, for example, mechanical resonance problems.


The critical speeds function prevents the reference from dwelling within a critical band for extended times. When a changing reference ([22.87](#)) enters a critical range, the output of the function ([22.1](#)) freezes until the reference exits the range. Any instant change in the output is smoothed out by the ramping function further in the reference chain.

The function is also available for scalar motor control with a frequency reference. The input of the function is shown by parameter [28.96 Frequency ref act 7](#), the output by parameter [28.97 Frequency ref unlimited](#).

### **Example**

A fan has vibrations in the range of 540 to 690 rpm and 1380 to 1560 rpm. To make the drive avoid these speed ranges,

- enable the critical speeds function by turning on bit 0 of parameter [22.51](#), and
  - set the critical speed ranges as in the figure below.
-



**Settings and diagnostics**

Parameters:

- Critical speeds: [22.51 Critical speed function...](#)[22.57 Critical speed 3 high \(page 284\)](#)
- Critical frequencies: [28.51 Critical frequency function...](#)[28.57 Critical frequency 3 high.](#)

■ **Speed controller autotune**


The speed controller of the drive can be automatically adjusted using the autotune function. Autotuning is based on an estimation of the mechanical time constant (inertia) of the motor and machine.

The autotune routine will run the motor through a series of acceleration/deceleration cycles, the number of which can be adjusted by parameter 25.40. Higher values will produce more accurate results, especially if the difference between initial and maximum speeds is small.

The maximum torque reference used during autotuning will be the initial torque (ie. torque when the routine is activated) plus 25.38, unless limited by the maximum torque limit (parameter group 30 Limits) or the nominal motor torque (parameter group 99 Motor data). The calculated maximum speed during the routine is the initial speed (ie. speed when the routine is activated) + 25.39, unless limited by parameter 30.12 or 99.9.



The diagram below shows the behavior of speed and torque during the autotune routine. In this example, 25.40 is set to 2.



**Note:**

- If the drive cannot produce the requested braking power during the routine, the results will be based on the acceleration stages only, and not as accurate as with full braking power.
- The motor will exceed the calculated maximum speed slightly at the end of each acceleration stage.

**Before activating the autotune routine**

The prerequisites for performing the autotune routine are:

- The motor identification run (ID run) has been successfully completed
- Speed and torque limits (parameter group 30 Limits) have been set
- The speed feedback has been monitored for noise, vibrations and other disturbances caused by the mechanics of the system, and
  - speed feedback filtering (parameter group 90 Feedback selection)
  - speed error filtering (parameter group 24 Speed reference conditioning)
 and


## 50 Program features

- zero speed (parameters [21.6](#) and [21.7](#)) have been set to eliminate these disturbances.
- The drive has been started and is running in speed control mode.

After these conditions have been fulfilled, autotuning can be activated by parameter [25.33](#) (or the signal source selected by it).

### Autotune modes

Autotuning can be performed in three different ways depending on the setting of parameter [25.34](#). The selections [Smooth](#), [Normal](#) and [Tight](#) define how the drive torque reference should react to a speed reference step after tuning. The selection [Smooth](#) will produce a slow but robust response; [Tight](#) will produce a fast response but possibly too high gain values for some applications. The figure below shows speed responses at a speed reference step (typically 1...20%).



- A Undercompensated
- B Normally tuned (autotuning)
- C Normally tuned (manually). Better dynamic performance than with B
- D Overcompensated speed controller

### Autotune results


At the end of a successful autotune routine, its results are automatically transferred into parameters

- [25.2](#) (proportional gain of the speed controller)
  - [25.3](#) (integration time of the speed controller)
-

- [25.37](#) (mechanical time constant of the motor and machine).

Nevertheless, it is still possible to manually adjust the controller gain, integration time and derivation time.

The figure below is a simplified block diagram of the speed controller. The controller output is the reference for the torque controller.



### Warning indications

A warning message, [AF90](#) will be generated if the autotune routine does not complete successfully.

For further information, see chapter [Fault tracing](#).

### Settings and diagnostics

Parameters: [25.33 Speed controller autotune](#) (page 310)...[25.40 Autotune repeat times](#) (page 311).


Events: [AF90 Speed controller autotuning](#) (page 616).

### ■ Oscillation damping

The oscillation damping function can be used to cancel out oscillations caused by mechanics or an oscillating DC voltage. The input – a signal reflecting the oscillation – is selected by parameter [26.53](#). The oscillation damping function outputs a sine wave ([26.58](#)) which can be summed with the torque reference with a suitable gain ([26.57](#)) and phase shift ([26.56](#)).

The oscillation damping algorithm can be activated without connecting the output to the reference chain, which makes it possible to compare the input and output of the function and make further adjustments before applying the result.

**Tuning procedure for oscillation damping**



<sup>1)</sup>If the phasing of a DC oscillation cannot be determined by measuring, the value of 0 degrees is usually a suitable initial value.

**Note:** Changing the speed error low-pass filter time constant or the integration time of the speed controller can affect the tuning of the oscillation damping algorithm. It is recommended to tune the speed controller before the oscillation damping algorithm. (The speed controller gain can be adjusted after the tuning of this algorithm.)

**Settings and diagnostics**

Parameters: [26.51 Oscillation damping \(page 319\)](#)...[26.58 Oscillation damping output \(page 321\)](#).

■ **Resonance frequency elimination**


The control program contains a notch filter function for removing the resonance frequencies from the speed error signal.

## Settings and diagnostics

Parameters: [24.13 RFE speed filter](#) (page 296)...[24.17 Damping of pole](#) (page 298).

### ■ Rush control

In torque control, the motor could potentially rush if the load were suddenly lost. The control program has a rush control function that decreases the torque reference whenever the motor speed (90.1) exceeds parameter 30.11 or 30.12.



The function is based on a PI controller. The proportional gain and integration time can be defined by parameters. Setting these to zero disables rush control.

## Settings and diagnostics

Parameter groups: [30 Limits](#) (page 338), [31 Fault functions](#) (page 349) and [90 Feedback selection](#) (page 505).

Parameters: [26.81 Rush control gain](#) (page 322) and [26.82 Rush control integration time](#) (page 322).

### ■ Encoder support

The program supports two single-turn or multturn encoders (or resolvers). The following optional interface modules are available:

- TTL encoder interface FEN-01: two TTL inputs, TTL output (for encoder emulation and echo) and two digital inputs

## 54 Program features

- Absolute encoder interface FEN-11: absolute encoder input, TTL input, TTL output (for encoder emulation and echo) and two digital inputs
- Resolver interface FEN-21: resolver input, TTL input, TTL output (for encoder emulation and echo) and two digital inputs
- HTL encoder interface FEN-31: HTL encoder input, TTL output (for encoder emulation and echo) and two digital inputs
- HTL/TTL encoder interface FSE-31 (for use with an FSO-xx safety functions module): Two HTL/TTL encoder inputs (one HTL input supported at the time of publication).

The interface module is to be installed onto one of the option slots on the drive control unit. The module (except the FSE-31) can also be installed onto an FEA-03 extension adapter.

### Encoder echo and emulation

Both encoder echo and emulation are supported by the above-mentioned FEN-xx interfaces.

Encoder echo is available with TTL, TTL+ and HTL encoders. The signal received from the encoder is relayed to the TTL output unchanged. This enables the connection of one encoder to several drives.

Encoder emulation also relays the encoder signal to the output, but the signal is either scaled, or position data converted to pulses. Emulation can be used when absolute encoder or resolver position needs to be converted to TTL pulses, or when the signal must be converted to a different pulse number than the original.


### Load and motor feedback

Three different sources can be used as speed and position feedback: encoder 1, encoder 2, or motor position estimate. Any of these can be used for load position calculation or motor control. The load position calculation makes it possible, for example, to determine the position of a conveyor belt or the height of the load on a crane. The feedback sources are selected by parameters [90.41](#) and [90.51](#).

For detailed parameter connections of the motor and load feedback functions, see the block diagrams on pages [671](#) and [672](#). For more information on load position calculation, see section [Position counter \(page 55\)](#).

Any mechanical gear ratios between the components (motor, motor encoder, load, load encoder) are specified using the gear parameters shown in the diagram below.

---



Any gear ratio between the load encoder and the load is defined by [90.53](#) and [90.54](#). Similarly, any gear ratio between the motor encoder and the motor is defined by [90.43](#) and [90.44](#). In case the internal estimated position is chosen as load feedback, the gear ratio between the motor and load can be defined by [90.61](#) and [90.62](#). By default, all of the ratios mentioned above are 1:1. The ratios can only be changed with the drive stopped; new settings require validation by [91.10](#).


### Position counter

The control program contains a position counter feature that can be used to indicate the position of the load. The output of the counter function, parameter [90.7](#), indicates the scaled number of revolutions read from the selected source (see section [Load and motor feedback \(page 54\)](#)).

The relation between revolutions of the motor shaft and the translatory movement of the load (in any given unit of distance) is defined by parameters [90.63](#) and [90.64](#). This gear function can be changed without the need of a parameter refresh or position counter reinitialization – however, the counter output is only updated after new position input data is received.

For detailed parameter connections of the load feedback function, see the block diagram on page [672](#).

## 56 Program features



The position counter is initialized by setting a known physical position of the load into the control program. The initial position (for example, the home/zero position, or the distance from it) can be entered manually in a parameter (90.58), or taken from another parameter. This position is set as the value of the position counter (90.7) when the source selected by 90.67, such as a proximity switch connected to a digital input, is activated. A successful initialization is indicated by bit 4 of 90.35.

Any subsequent initialization of the counter must first be enabled by 90.69. To define a time window for initializations, 90.68 can be used to inhibit the signal from the proximity switch. An active fault in the drive will also prevent counter initialization.

### Encoder error handling

When an encoder is used for load feedback, the action taken in case of an encoder error is specified by 90.55. If the parameter is set to **Warning**, the calculation will continue smoothly using estimated motor position. If the encoder recovers from the error, the calculation will smoothly switch back to encoder feedback. The load position signals (90.4, 90.5 and 90.7) will continue to be updated all the time, but bit 6 of 90.35 will be set to indicate potentially inaccurate position data. In addition, bit 4 of 90.35 will be cleared upon the next stop as a recommendation to reinitialize the position counter.

Parameter 90.60 defines whether position calculation resumes from the previous value over an encoder error or control unit reboot. By default, bit 4 of 90.35 is cleared after an error, indicating that reinitialization is needed. With 90.60 set to



[Continue from previous value](#), the position values are retained over an error or reboot; bit 6 of [90.35](#) is set however to indicate that an error occurred.

**Note:** With a multiturn absolute encoder, bit 6 of [90.35](#) is cleared at the next stop of the drive if the encoder has recovered from the error; bit 4 is not cleared. The status of the position counter is retained over a control unit reboot, after which position calculation resumes from the absolute position given by the encoder, taking into account the initial position specified by [90.58](#).



#### **WARNING!**

If the drive is in stopped state when an encoder error occurs, or if the drive is not powered, parameters [90.4](#), [90.5](#), [90.7](#) and [90.35](#) are not updated because no movement of the load can be detected. When using previous position values ([90.60](#) is set to [Continue from previous value](#)), be aware that the position data is unreliable if the load is able to move.

---

### **Reading/writing position counter values through fieldbus**

The parameters of the position counter function, such as [90.7](#) and [90.58](#), can be accessed from an upper-level control system in the following formats:

- 16-bit integer (if 16 bits are sufficient for the application)
- 32-bit integer (can be accessed as two consequent 16-bit words).

For example, to read parameter [90.7](#) through fieldbus, set the selection parameter of the desired dataset (in group [52](#)) to Other – [90.7](#), and select the format. If you select a 32-bit format, the subsequent data word is also automatically reserved.

### **Configuration of HTL encoder motor feedback**

1. Specify the type of the encoder interface module (parameter [91.11](#) = [FEN-31](#)) and the slot the module is installed into ([91.12](#)).
  2. Specify the type of the encoder ([92.1](#) = [HTL](#)). The parameter listing will be re-read from the drive after the value is changed.
  3. Specify the interface module that the encoder is connected to ([92.2](#) = [Module 1](#)).
  4. Set the number of pulses according to encoder nameplate ([92.10](#)).
  5. If the encoder rotates at a different speed to the motor (ie. is not mounted directly on the motor shaft), enter the gear ratio in [90.43](#) and [90.44](#).
  6. Set parameter [91.10](#) to [Refresh](#) to apply the new parameter settings. The parameter will automatically revert to [Done](#).
  7. Check that [91.2](#) is showing the correct interface module type ([FEN-31](#)). Also check the status of the module; both LEDs should be glowing green.
  8. Start the motor with a reference of eg. 400 rpm.
-

## 58 Program features

9. Compare the estimated speed (1.2) with the measured speed (1.4). If the values are the same, set the encoder as the feedback source (90.41 = Encoder 1).
10. Specify the action taken in case the feedback signal is lost (90.45).

### Example 1: Using the same encoder for both load and motor feedback

The drive controls a motor used for lifting a load in a crane. An encoder attached to the motor shaft is used as feedback for motor control. The same encoder is also used for calculating the height of the load in the desired unit. A gear exists between the motor shaft and the cable drum. The encoder is configured as Encoder 1 as shown in [Configuration of HTL encoder motor feedback](#) above. In addition, the following settings are made:

- 90.43 = 1
- 90.44 = 1  
(No gear is needed as the encoder is mounted directly on the motor shaft.)
- 90.51 = Encoder 1
- 90.53 = 1
- 90.54 = 50  
The cable drum turns one revolution per 50 revolutions of the motor shaft.
- 90.61 = 1
- 90.62 = 1  
(These parameters need not be changed as position estimate is not being used for feedback.)
- 90.63 = 7
- 90.64 = 10  
The load moves 70 centimeters, ie. 7/10 of a meter, per one revolution of the cable drum.

The load height in meters can be read from 90.7, while 90.3 displays the rotational speed of the cable drum.

### Example 2: Using two encoders

One encoder (encoder 1) is used for motor feedback. The encoder is connected to the motor shaft through a gear. Another encoder (encoder 2) measures the line speed elsewhere in the machine. Each encoder is configured as shown in [Configuration of HTL encoder motor feedback](#) above. In addition, the following settings are made:

- 90.41 = Encoder 1
  - 90.43 = 1
  - 90.44 = 3
-

The encoder turns three revolutions per one revolution of the motor shaft.

- [90.51](#) = Encoder 2

The line speed measured by encoder 2 can be read from [90.3](#). This value is given in rpm which can be converted into another unit by using [90.53](#) and [90.54](#). Note that the feed constant gear cannot be used in this conversion because it does not affect [90.3](#).

### Example 3: ACS 600 / ACS800 compatibility

With ACS 600 and ACS800 drives, both the rising and falling edges from encoder channels A and B are typically counted to achieve best possible accuracy. Thus the received pulse number per revolution equals four times the nominal pulse number of the encoder.

In this example, an HTL-type 2048-pulse encoder is fitted directly on the motor shaft. The desired initial position to correspond the proximity switch is 66770.

In the ACS880, the following settings are made:

- [92.1](#) = HTL
- [92.2](#) = Module 1
- [92.10](#) = 2048
- [92.13](#) = Enable
- [90.51](#) = Encoder 1
- [90.63](#) = 8192 (ie. 4 × value of [92.10](#), as the received number of pulses is 4 times nominal. See also parameter [92.12](#))
- The desired “data out” parameter is set to Other – [90.58](#) (32-bit format). Only the high word needs to be specified – the subsequent data word is reserved for the low word automatically.
- The desired sources (such as digital inputs or user bits of the control word) are selected in [90.67](#) and [90.69](#).

In the PLC, if the initial value is set in 32-bit format using low and high words (corresponding to ACS800 parameters POS COUNT INIT LO and POS COUNT INIT HI), enter the value 66770 into these words as follows:

- **Eg. PROFIBUS:**
  - FBA data out x = POS COUNT INIT HI = 1 (as bit 16 equals 65536)
  - FBA data out (x + 1) = POS COUNT INIT LO = 1234.
- ABB Automation using DDCS communication, eg.:
  - Data set 12.1 = POS COUNT INIT HI
  - Data set 12.2 = POS COUNT INIT LO

To test the configuration of the PLC, initialize the position counter with the encoder connected. The initial value sent from the PLC should immediately be reflected by

---

90.7 in the drive. The same value should then appear in the PLC after having been read from the drive.

**Settings and diagnostics**

Parameter groups [90 Feedback selection \(page 505\)](#), [91 Encoder module settings \(page 516\)](#), [92 Encoder 1 configuration \(page 520\)](#) and [93 Encoder 2 configuration \(page 527\)](#).


■ **Jogging**

The jogging function enables the use of a momentary switch to briefly rotate the motor. The jogging function is typically used during servicing or commissioning to control the machinery locally.

Two jogging functions (1 and 2) are available, each with their own activation sources and references. The signal sources are selected by parameters [20.26](#) and [20.27](#). When jogging is activated, the drive starts and accelerates to the defined jogging speed ([22.42](#) or [22.43](#)) along the defined jogging acceleration ramp ([23.20](#)). After the activation signal switches off, the drive decelerates to a stop along the defined jogging deceleration ramp ([23.21](#)).

The figure and table below provide an example of how the drive operates during jogging. In the example, the ramp stop mode is used (see parameter [21.3](#)).

- Jog cmd = State of source set by parameter [20.26](#) or [20.27](#)
- Jog enable = State of source set by parameter [20.25](#)
- Start cmd = State of drive start command.



1-2	1	1	0	Drive accelerates to the jogging speed along the acceleration ramp of the jogging function.
2-3	1	1	0	Drive follows the jog reference.
3-4	0	1	0	Drive decelerates to zero speed along the deceleration ramp of the jogging function.
4-5	0	1	0	Drive is stopped.
5-6	1	1	0	Drive accelerates to the jogging speed along the acceleration ramp of the jogging function.
6-7	1	1	0	Drive follows the jog reference.
7-8	0	1	0	Drive decelerates to zero speed along the deceleration ramp of the jogging function.
8-9	0	1→0	0	Drive is stopped. As long as the jog enable signal is on, start commands are ignored. After jog enable switches off, a fresh start command is required.
9-10	x	0	1	Drive accelerates to the speed reference along the selected acceleration ramp (parameters 23.11...23.19).
10-11	x	0	1	Drive follows the speed reference.
11-12	x	0	0	Drive decelerates to zero speed along the selected deceleration ramp (parameters 23.11...23.19).
12-13	x	0	0	Drive is stopped.
13-14	x	0	1	Drive accelerates to the speed reference along the selected acceleration ramp (parameters 23.11...23.19).
14-15	x	0→1	1	Drive follows the speed reference. As long as the start command is on, the jog enable signal is ignored. If the jog enable signal is on when the start command switches off, jogging is enabled immediately.
15-16	0→1	1	0	Start command switches off. The drive starts to decelerate along the selected deceleration ramp (parameters 23.11...23.19). When the jog command switches on, the decelerating drive adopts the deceleration ramp of the jogging function.
16-17	1	1	0	Drive follows the jog reference.
17-18	0	1→0	0	Drive decelerates along the deceleration ramp of the jogging function.
18-19	0	0	0	Drive decelerates to zero speed along the selected deceleration ramp (parameters 23.11

See also the block diagram on page 670.

The jogging function operates on a 2 ms time level.

### Note:

- Jogging is not available when the drive is in local control.
- Jogging cannot be enabled when the drive start command is on, or the drive started when jogging is enabled. Starting the drive after the jog enable switches off requires a fresh start command.



### WARNING!

If jogging is enabled and activated while the start command is on, jogging will activate as soon as the start command switches off.

---

- If both jogging functions are activated, the one that was activated first has priority.
- Jogging uses the speed control mode.
- Ramp shape times (parameters [23.16...23.19](#)) do not apply to jogging acceleration/deceleration ramps.
- The inching functions activated through fieldbus (see parameter [6.1](#), bits 8...9) use the references and ramp times defined for jogging, but do not require the jog enable signal.

### Settings and diagnostics

Parameters: [20.25 Jogging enable \(page 265\)](#), [20.26 Jogging 1 start source \(page 265\)](#), [20.27 Jogging 2 start source \(page 266\)](#), [22.42 Jogging 1 ref \(page 283\)](#), [22.43 Jogging 2 ref \(page 283\)](#), [23.20 Acc time jogging \(page 291\)](#) and [23.21 Dec time jogging \(page 291\)](#).

#### ■ Scalar motor control

It is possible to select scalar control as the motor control method instead of DTC (Direct Torque Control). In scalar control mode, the drive is controlled with a speed or frequency reference. However, the outstanding performance of DTC is not achieved in scalar control.

It is recommended to activate scalar motor control mode

- if the nominal current of the motor is less than 1/6 of the nominal output current of the drive
  - if the drive is used without a motor connected (for example, for test purposes)
  - if the drive runs a medium-voltage motor through a step-up transformer, or
  - in multimotor drives, if
    - the load is not equally shared between the motors,
    - the motors are of different sizes, or
    - the motors are going to be changed after motor identification (ID run)
-


In scalar control, some standard features are not available.

See also section [Operating modes of the drive \(page 26\)](#).

### IR compensation for scalar motor control

IR compensation (also known as voltage boost) is available only when the motor control mode is scalar. When IR compensation is activated, the drive gives an extra voltage boost to the motor at low speeds. IR compensation is useful in applications that require a high breakaway torque. In step-up applications, voltage cannot be fed through the transformer at 0 Hz, so an additional breakpoint is available for defining the compensation near zero frequency.

In Direct Torque Control (DTC), no IR compensation is possible or needed as it is applied automatically.



### Settings and diagnostics

Parameters: [19.20 Scalar control reference unit \(page 253\)](#), [97.12 IR comp step-up frequency \(page 558\)](#), [97.13 IR compensation \(page 559\)](#) and [99.4 Motor control mode \(page 564\)](#).

Parameter group: [28 Frequency reference chain \(page 323\)](#).

#### ■ Autophasing

Autophasing is an automatic measurement routine to determine the angular position of the magnetic flux of a permanent magnet synchronous motor or the magnetic axis of a synchronous reluctance motor. The motor control requires the absolute position of the rotor flux in order to control motor torque accurately.


Sensors like absolute encoders and resolvers indicate the rotor position at all times after the offset between the zero angle of rotor and that of the sensor has been established. On the other hand, a standard pulse encoder determines the rotor position when it rotates but the initial position is not known. However, a pulse encoder can be used as an absolute encoder if it is equipped with Hall sensors, albeit with coarse initial position accuracy. Hall sensors generate so-called

## 64 Program features

commutation pulses that change their state six times during one revolution, so it is only known within which 60° sector of a complete revolution the initial position is.

Many encoders give a zero pulse (also called Z-pulse) once during each rotation. The position of the zero pulse is fixed. If this position is known with respect to zero position used by motor control, the rotor position at the instant of the zero pulse is also known.

Using the zero pulse improves the robustness of the rotor position measurement. The rotor position must be determined during starting because the initial value given by the encoder is zero. The autophasing routine determines the position, but there is a risk of some position error. If the zero pulse position is known in advance, the position found by autophasing can be corrected as soon as the zero pulse is detected for the first time after starting.



The autophasing routine is performed with permanent magnet synchronous motors and synchronous reluctance motors in the following cases:

1. One-time measurement of the rotor and encoder position difference when an absolute encoder, a resolver, or an encoder with commutation signals is used
2. At every power-up when an incremental encoder is used
3. With open-loop motor control, repetitive measurement of the rotor position at every start
4. When the position of the zero pulse must be measured before the first start after power-up.

**Note:** In closed-loop control, autophasing is performed automatically after the motor identification run (ID run). Autophasing is also performed automatically before starting when necessary.



In open-loop control, the zero angle of the rotor is determined before starting. In closed-loop control, the actual angle of the rotor is determined with autophasing when the sensor indicates zero angle. The offset of the angle must be determined because the actual zero angles of the sensor and the rotor do not usually match. The autophasing mode determines how this operation is done both in open-loop and closed-loop control.

The rotor position offset used in motor control can also be given by the user – see parameter [98.15](#). Note that the autophasing routine also writes its result into this parameter. The results are updated even if user settings are not enabled by [98.1](#).

**Note:** In open-loop control, the motor always turns when it is started as the shaft is turned towards the remanence flux.

Bit 4 of [6.21](#) indicates if the rotor position has already been determined

### Autophasing modes

Several autophasing modes are available (see parameter [21.13](#)).

The turning mode ([Turning](#)) is recommended especially with case 1 (see the list above) as it is the most robust and accurate method. In turning mode, the motor shaft is turned back and forward ( $\pm 360/\text{polepairs}$ )° in order to determine the rotor position. In case 3 (open-loop control), the shaft is turned only in one direction and the angle is smaller.

Another turning mode, [Turning with Z-pulse](#), can be used if there is difficulty using the normal turning mode, for example, because of significant friction. With this mode, the rotor is turned slowly until a zero pulse is detected from the encoder. When the zero pulse is detected for the first time, its position is stored into parameter [98.15](#), which can be edited for fine-tuning. Note that it is not mandatory to use this mode with a zero pulse encoder. In open-loop control, the two turning modes are identical.

The standstill modes ([Standstill 1](#), [Standstill 2](#)) can be used if the motor cannot be turned (for example, when the load is connected). As the characteristics of motors and loads differ, testing must be done to find out the most suitable standstill mode.

The drive is capable of determining the rotor position when started into a running motor in open-loop or closed-loop control. In this situation, the setting of [21.13](#) has no effect.

The autophasing routine can fail and therefore it is recommended to perform the routine several times and check the value of parameter [98.15](#).

An autophasing fault ([3385](#)) can occur with a running motor if the estimated angle of the motor differs too much from the measured angle. This could be caused by, for example, the following:

- The encoder is slipping on the motor shaft


- An incorrect value has been entered into [98.15](#)
- The motor is already turning before the autophasing routine is started
- **Turning** mode is selected in [21.13](#) but the motor shaft is locked
- **Turning with Z-pulse** mode is selected in [21.13](#) but no zero pulse is detected within a revolution of the motor
- The wrong motor type is selected in [99.3](#)
- Motor ID run has failed.

### Settings and diagnostics

Parameters: [6.21 Drive status word 3](#) (page 166), [21.13 Autophasing mode](#) (page 273), [98.15 Position offset user](#) (page 563) and [99.13 ID run requested](#) (page 567).


#### ■ Flux braking

---

 **WARNING!** The motor needs to be rated to absorb the thermal energy generated by flux braking.

---

The drive can provide greater deceleration by raising the level of magnetization in the motor. By increasing the motor flux, the energy generated by the motor during braking can be converted to motor thermal energy.



The drive monitors the motor status continuously, also during flux braking. Therefore, flux braking can be used both for stopping the motor and for changing the speed. The other benefits of flux braking are:

- The braking starts immediately after a stop command is given. The function does not need to wait for the flux reduction before it can start the braking.
  - The cooling of the induction motor is efficient. The stator current of the motor increases during flux braking, not the rotor current. The stator cools much more efficiently than the rotor.
-

- Flux braking can be used with induction motors and permanent magnet synchronous motors.

Two braking power levels are available:

- Moderate braking provides faster deceleration compared to a situation where flux braking is disabled. The flux level of the motor is limited to prevent excessive heating of the motor.
- Full braking exploits almost all available current to convert the mechanical braking energy to motor thermal energy. Braking time is shorter compared to moderate braking. In cyclic use, motor heating may be significant.

### Settings and diagnostics

Parameter: [97.5 Flux braking \(page 556\)](#).

#### ■ DC magnetization

DC magnetization can be applied to the motor to

- heat the motor to remove or prevent condensation, or
- to lock the rotor at, or near, zero speed.

#### Pre-heating

A motor pre-heating function is available to prevent condensation in a stopped motor, or to remove condensation from the motor before start. Pre-heating involves feeding a DC current into the motor to heat up the windings.

Pre-heating is deactivated at start, or when one of the other DC magnetization functions is activated. With the drive stopped, pre-heating is disabled by the safe torque off function, a drive fault state, or the process PID sleep function. Pre-heating can only start after one minute has elapsed from stopping the drive.

A digital source to control pre-heating is selected by parameter [21.14](#). The heating current is set by [21.16](#).

#### Pre-magnetization

Pre-magnetization refers to DC magnetization of the motor before start. Depending on the selected start mode ([21.1](#) or [21.19](#)), premagnetization can be applied to guarantee the highest possible breakaway torque, up to 200% of the nominal torque of the motor. By adjusting the pre-magnetization time ([21.2](#)), it is possible to synchronize the motor start and, for example, the release of a mechanical brake.


#### DC hold

The function makes it possible to lock the rotor at (near) zero speed in the middle of normal operation. DC hold is activated by parameter [21.8](#). When both the reference and motor speed drop below a certain level (parameter [21.9](#)), the drive will stop generating sinusoidal current and start to inject DC into the motor. The

---

## 68 Program features

current is set by parameter 21.10. When the reference exceeds parameter 21.9, normal drive operation continues.



### Note:

- DC hold is only available in speed control in DTC motor control mode (see page 26).
- The function applies the DC current to one phase only, depending on the position of the rotor. The return current will be shared between the other phases.

### Post-magnetization

This feature keeps the motor magnetized for a certain period (parameter 21.11) after stopping. This is to prevent the machinery from moving under load, for example before a mechanical brake can be applied. Postmagnetization is activated by parameter 21.8. The magnetization current and time are set by parameters 21.10 and 21.11.

**Note:** Post-magnetization is only available when ramping is the selected stop mode (see parameter 21.3).

### Continuous magnetization

A digital signal, such as a user bit in the fieldbus control word, can be selected to activate continuous magnetization. This can be especially useful in processes

requiring motors to be stopped (for example, to stand by until new material is processed), then quickly started without magnetizing them first.

**Note:**

- Continuous magnetization is only available in DTC motor control mode (see page 26). If parameter 21.12 is on, the motor will be kept magnetized after a ramp stop. To enable continuous magnetization after a coast stop, the command (21.12) must be cycled (on, off, on). Furthermore, if the Run enable signal has been off, a new rising edge is required before continuous magnetization starts.
- Continuous magnetization should not be enabled while the motor is rotating.



**WARNING!**

The motor must be designed to absorb or dissipate the thermal energy generated by continuous magnetization, for example by forced ventilation.

---

**Settings and diagnostics**

Parameters: 6.21 Drive status word 3 (page 166), 21.1 Start mode (page 267), 21.2 Magnetization time (page 268), 21.8 DC current control...21.12 Continuous magnetization command (page 273), 21.14 Pre-heating input source (page 274) and 21.16 Pre-heating current (page 274).

■ **Motor temperature estimation**

The Motor temperature estimation function identifies the stator resistance and estimates the initial temperature of the motor. The estimated temperature of the motor can be used when the ambient temperature drops below zero celsius.

The temperature is estimated by feeding a DC current (25% of the motor nominal current) into the motor for a time period of 4 seconds (default). The function uses the resistance value at room temperature obtained during an ID run.

The function can be activated with parameter 21.37. The estimation time can be defined with parameter 21.38. The function can be activated using either of the two ways: With Drive start command or at Drive power-up (after control board boot).

**Settings and diagnostics**

Parameters: 21.37 Motor temperature estimation (page 276) and 21.38 Motor temperature estimation time (page 277).

■ **Hexagonal motor flux pattern**

**Note:** This feature is only available in scalar motor control mode (see page 26).

---

## 70 Program features

Typically, the drive controls the motor flux so that the rotating flux vector follows a circular pattern. This is ideal for most applications. However, when operating above the field weakening point (FWP), it is not possible to reach 100% of the output voltage. This reduces the peak load capacity of the drive.

Using a hexagonal motor flux vector pattern, the maximum output voltage can be reached above the field weakening point. This increases the peak load capacity compared to the circular pattern, but the continuous load capacity in the range of FWP ...  $1.6 \times$  FWP is reduced because of increasing losses. With hexagonal motor flux active, the pattern changes from circular to hexagonal gradually as the frequency rises from 100% to 120% of the FWP.

### **Settings and diagnostics**

Parameters: [97.18 Hexagonal field weakening \(page 559\)](#) and [97.19 Hexagonal field weakening point \(page 560\)](#).

---

## Application control

### ■ Application macros

Application macros are predefined application parameter edits and I/O configurations. See chapter Application macros.


### ■ Process PID control

There is a built-in process PID controller in the drive. The controller can be used to control process variables such as pressure, flow or fluid level.

In process PID control, a process reference (setpoint) is connected to the drive instead of a speed reference. An actual value (process feedback) is also brought back to the drive. The process PID control adjusts the drive speed in order to keep the measured process quantity (actual value) at the desired level (setpoint).

Process PID control operates on a 2 ms time level.

The simplified block diagram below illustrates the process PID control. For a more detailed block diagram, see page 684.



The control program contains two complete sets of process PID controller settings that can be alternated whenever necessary; see parameter 40.57.

**Note:** Process PID control is only available in external control; see section [Local control vs. external control](#) (page 23).

### Quick configuration of the process PID controller

1. Activate the process PID controller (parameter 40.7).
2. Select a feedback source (parameters 40.8...40.11).
3. Select a setpoint source (parameters 40.16...40.25).

4. Set the gain, integration time, derivation time, and the PID output levels (40.32, 40.33, 40.34, 40.36 and 40.37).
5. The PID controller output is shown by parameter 40.1. Select it as the source of, for example, 22.11.


### Sleep function for process PID control

The sleep function can be used in PID control applications that involve relatively long periods of low demand (for example, a tank is at level). During such periods, the sleep function saves energy by stopping the motor completely, instead of running the motor slowly below the efficient operating range of the system. When the feedback changes, the PID controller wakes the drive up.

**Note:** The sleep function is disabled when mechanical brake control (see page 75) is active.

**Example:** The drive controls a pressure boost pump. The water consumption falls at night. As a consequence, the process PID controller decreases the motor speed. However, due to natural losses in the pipes and the low efficiency of the centrifugal pump at low speeds, the motor would never stop rotating. The sleep function detects the slow rotation and stops unnecessary pumping after the sleep delay has passed. The drive shifts into sleep mode, still monitoring the pressure. The pumping resumes when the pressure falls under the wake-up level (setpoint - wake-up deviation) and the wake-up delay has passed.





## Tracking

In tracking mode, the PID block output is set directly to the value of parameter [40.50](#) (or [41.50](#)). The internal I term of the PID controller is set so that no transient is allowed to pass on to the output, so when the tracking mode is left, normal process control operation can be resumed without a significant bump.

## Settings and diagnostics

Parameter [96.4 Macro select](#) (page 545) (macro selection).

Parameter groups [40 Process PID set 1](#) (page 399) and [41 Process PID set 2](#) (page 414).

### ■ Motor potentiometer

The motor potentiometer is, in effect, a counter whose value can be adjusted up and down using two digital signals selected by parameters [22.73](#) and [22.74](#). Note that these signals have no effect when the drive is stopped.


## 74 Program features

When enabled by [22.71](#), the motor potentiometer assumes the value set by [22.72](#). Depending on the mode selected in [22.71](#), the motor potentiometer value is either retained or reset over a stop or a power cycle.

The change rate is defined in [22.75](#) as the time it would take for the value to change from the minimum ([22.76](#)) to the maximum ([22.77](#)) or vice versa. If the up and down signals are simultaneously on, the motor potentiometer value does not change.

The output of the function is shown by [22.80](#), which can directly be set as the source of any selector parameter such as [22.11](#).

The following example shows the behavior of the motor potentiometer value.



### Settings and diagnostics

Parameters [22.71](#) Motor potentiometer function (page 284)...[22.80](#) Motor potentiometer ref act (page 286).

## ■ Mechanical brake control

A mechanical brake can be used for holding the motor and driven machinery at zero speed when the drive is stopped, or not powered. The brake control logic observes the settings of parameter group [44 Mechanical brake control](#) as well as several external signals, and moves between the states presented in the Brake state diagram on page [76](#). The tables below the state diagram detail the states and transitions. The timing diagram on page [78](#) shows an example of a close-open-close sequence.

The mechanical brake control logic operates on a 10 ms time level.

### Inputs of the brake control logic

The start command of the drive (bit 5 of [6.16](#)) is the main control source of the brake control logic. An optional external open/close signal can be selected by [44.12](#). The two signals interact as follows:

- Start command = 1 **AND** signal selected by parameter [44.12](#) = 0 → Request brake to **open**
- Start command = 0 **OR** signal selected by parameter [44.12](#) = 1 → Request brake to **close**

Another external signal – for example, from a higher-level control system – can be connected via parameter [44.11](#) to prevent the brake from opening.

Other signals that affect the state of the control logic are


- brake status acknowledgement (optional, defined by [44.7](#)),
- bit 2 of [6.11](#) (indicates whether the drive is ready to follow the given reference or not),
- bit 6 of [6.16](#) (indicates whether the drive is modulating or not),
- optional FSO-xx safety functions module.

### Outputs of the brake control logic

The mechanical brake is to be controlled by bit 0 of parameter [44.1](#). This bit should be selected as the source of a relay output (or a digital input/output in output mode) which is then wired to the brake actuator through a relay. See the wiring example on page [79](#).

The brake control logic, in various states, will request the drive control logic to hold the motor, increase the torque, or ramp down the speed. These requests are visible in parameter [44.1](#).

**Brake state diagram**



BRAKE DISABLED	Brake control is disabled (parameter 44.6 = 0, and 44.1 b4 = 0). The brake is closed (44.1 b0 = 0).
BRAKE OPENING:	
BRAKE OPENING WAIT	Brake has been requested to open. The drive logic is requested to increase the torque up to opening torque to hold the load in place (44.1 b1 = 1 and b2 = 1). The state of 44.11 is checked; if it is not 0 within a reasonable time, the drive trips on a 71A5 fault <sup>1)</sup> .
BRAKE OPENING DELAY	Opening conditions have been met and open signal activated (44.1 b0 is set). The opening torque request is removed (44.1 b1 → 0). The load is held in place by the speed control of the drive until 44.8 elapses.  At this point, if 44.7 is set to <b>No acknowledge</b> , the logic proceeds to BRAKE OPEN state. If an acknowledgement signal source has been selected, its state is checked; if the state is not “brake open”, the drive trips on a 71A3 fault <sup>1)</sup> .
BRAKE OPEN	The brake is open (44.1 b0 = 1). Hold request is removed (44.1 b2 = 0), and the drive is allowed to follow the reference.
BRAKE CLOSING:	

BRAKE CLOSING WAIT	Brake has been requested to close. The drive logic is requested to ramp down the speed to a stop (44.1 b3 = 1). The open signal is kept active (44.1, b0 = 1). The brake logic will remain in this state until the motor speed has remained below 44.14 for the time defined by 44.15.
BRAKE CLOSING DELAY	Closing conditions have been met. The open signal is deactivated (44.1 b0 → 0) and the closing torque written into 44.2. The ramp-down request is maintained (44.1 b3 = 1). The brake logic will remain in this state until 44.13 has elapsed.  At this point, if 44.7 is set to <b>No acknowledge</b> , the logic proceeds to BRAKE CLOSED state. If an acknowledgement signal source has been selected, its state is checked; if the state is not “brake closed”, the drive generates an A7A1 warning. If 44.17 = <b>Fault</b> , the drive will trip on a 71A2 fault after 44.18.
BRAKE CLOSED	The brake is closed (44.1, b0 = 0). The drive is not necessarily modulating.  <b>Note concerning open-loop (encoderless) applications:</b> If the brake is kept closed by a brake close request (either from parameter 44.12 or an FSO-xx safety functions module) against a modulating drive for longer than 5 seconds, the brake is forced to closed state and the drive trips on a fault, 71A5.


1) A warning can alternatively be selected by 44.17; if so, the drive will keep modulating and remain in this state.

**State change conditions:**

1	Brake control disabled (parameter 44.6 → 0).
2	6.11, bit 2 = 0 or brake is forced to close by optional FSO-xx safety functions module.
3	Brake has been requested to open and 44.16 has expired.
4	Brake open conditions (such as 44.10) fulfilled and 44.11 = 0.
5	44.8 has elapsed and brake open acknowledgement (if chosen by 44.7) has been received.
6	Brake has been requested to close.
7	Motor speed has remained below closing speed 44.14 for the duration of 44.15.
8	44.13 has elapsed and brake close acknowledgement (if chosen by 44.7) has been received.
9	Brake has been requested to open.
10	Brake control enabled (parameter 44.6 → 1).

### Timing diagram

The simplified timing diagram below illustrates the operation of the brake control function. Refer to the state diagram above.



$T_s$	Start torque at brake open (parameter 44.3)
$T_{mem}$	Stored torque value at brake close (44.2)
$t_{md}$	Motor magnetization delay
$t_{od}$	Brake open delay (parameter 44.8)
$n_{cs}$	Brake close speed (parameter 44.14)
$t_{ccd}$	Brake close command delay (parameter 44.15)
$t_{cd}$	Brake close delay (parameter 44.13)
$t_{cfd}$	Brake close fault delay (parameter 44.18)
$t_{rod}$	Brake reopen delay (parameter 44.16)
BOW	BRAKE OPENING WAIT
BOD	BRAKE OPENING DELAY
BCW	BRAKE CLOSING WAIT
BCD	BRAKE CLOSING DELAY

## Wiring example




### WARNING!

Make sure that the machinery into which the drive with brake control function is integrated fulfils the personnel safety regulations. Note that the frequency converter (a Complete Drive Module or a Basic Drive Module, as defined in IEC 61800-2), is not considered as a safety device mentioned in the European Machinery Directive and related harmonised standards. Thus, the personnel safety of the complete machinery must not be based on a specific frequency converter feature (such as the brake control function), but it has to be implemented as defined in the application specific regulations.

The figure below shows a brake control wiring example. The brake control hardware and wiring is to be sourced and installed by the customer.

The brake is controlled by bit 0 of parameter 44.1. The source of brake acknowledge (status supervision) is selected by parameter 44.7. In this example,

- parameter 10.24 is set to Open brake command (ie. bit 0 of 44.1), and
- parameter 44.7 is set to DI5.



## Settings and diagnostics

Parameter group: [44 Mechanical brake control \(page 420\)](#).

Events: [71A2 Mech brake closing failed \(page 593\)](#), [71A3 Mech brake opening failed \(page 593\)](#), [71A5 Mech brk opening not allowed \(page 594\)](#) and [A7A1 Mechanical brake closing failed \(page 609\)](#).

## DC voltage control

### ■ Overvoltage control

Overvoltage control of the intermediate DC link is typically needed when the motor is in generating mode. The motor can generate when it decelerates or when the load overhauls the motor shaft, causing the shaft to turn faster than the applied speed or frequency. To prevent the DC voltage from exceeding the overvoltage control limit, the overvoltage controller automatically decreases the generating torque when the limit is reached. The overvoltage controller also increases any programmed deceleration times if the limit is reached; to achieve shorter deceleration times, a brake chopper and resistor may be required.


### ■ Undervoltage control (power loss ride-through)

If the incoming supply voltage is cut off, the drive will continue to operate by utilizing the kinetic energy of the rotating motor. The drive will be fully operational as long as the motor rotates and generates energy to the drive. The drive can continue operation after the break if the main contactor (if present) remained closed.

**Note:** Units equipped with a main contactor must be equipped with a hold circuit (e.g. UPS) to keep the contactor control circuit closed during a short supply break.

---





$U_{DC}$  = intermediate circuit voltage of the drive,  $f_{out}$  = output frequency of the drive,  $T_M$  = motor torque Loss of supply voltage at nominal load ( $f_{out} = 40$  Hz). The intermediate circuit DC voltage drops to the minimum limit. The controller keeps the voltage steady as long as the mains is switched off. The drive runs the motor in generator mode. The motor speed falls but the drive is operational as long as the motor has enough kinetic energy.

### Automatic restart



#### WARNING!

Before you activate the function, make sure that no dangerous situations can occur. The function restarts the drive automatically and continues operation after a supply break.

It is possible to restart the drive automatically after a short power supply failure by using the Automatic restart function provided that the drive is allowed to run for a time defined by parameter 21.18 to restart time without the cooling fans operating.

When enabled, the function takes the following actions upon a supply failure to enable a successful restart:

- The undervoltage fault is suppressed (but a warning is generated)
- Modulation and cooling is stopped to conserve any remaining energy
- DC circuit pre-charging is enabled.

## 82 Program features

If the DC voltage is restored before the expiration of the period defined by parameter [21.18](#) and the start signal is still on, normal operation will continue. However, if the DC voltage remains too low at that point, the drive trips on a fault, [3280](#).

### **Settings and diagnostics**

Parameter: [21.18 Auto restart time](#) (page 275).

Event: [3280 Standby timeout](#) (page 582).

---

## ■ Voltage control and trip limits

The control and trip limits of the intermediate DC voltage regulator are relative to the supply voltage as well as drive/inverter type. The DC voltage is approximately 1.35 times the line-to-line supply voltage, and is displayed by parameter **1.11**.

All levels are relative to the supply voltage range selected in parameter **95.1**. The following table shows the values of selected DC voltage levels in volts and in percent of  $U_{DCmax}$  (the DC voltage at the upper bound of the supply voltage range).

	Supply voltage range [V AC] (see <b>95.1</b> )					
Level [V DC (% of $U_{DCmax}$ )]	208...240	380...415	440...480	500	525...600	660...690
Overvoltage fault limit	489/440 <sup>1)</sup>	800	878	880	1113	1218
Overvoltage control limit	405 (125)	700 (125)	810 (125)	810 (120)	1013 (125)	1167 (125)
Internal brake chopper at 100% pulse width	403 (124)	697 (124)	806 (124)	806 (119)	1008 (124)	1159 (124)
Internal brake chopper at 0% pulse width	375 (116)	648 (116)	749 (116)	780 (116)	936 (116)	1077 (116)
Overvoltage warning limit	373 (115)	644 (115)	745 (115)	776 (115)	932 (115)	1071 (115)
$U_{DCmax}$ = DC voltage at upper bound of supply voltage range	324 (100)	560 (100)	648 (100)	675 (100)	810 (100)	932 (100)
DC voltage at lower bound of supply voltage range	281	513	594	675	709	891
Undervoltage control and warning limit	239 (85)	436 (85)	505 (85)	574 (85)	602 (85)	757 (85)
Charging activation/standby limit	225 (80)	410 (80)	475 (80)	540 (80)	567 (80)	713 (80)
Undervoltage fault limit	168 (60)	308 (60)	356 (60)	405 (60)	425 (60)	535 (60)

<sup>1)</sup> 489 V with frames R1...R3, 440 V with frames R4...R8.

## Settings and diagnostics

Parameters: **1.11 DC voltage** (page 139), **30.30 Overvoltage control** (page 346), **30.31 Undervoltage control** (page 346), **95.1 Supply voltage** (page 533), and **95.2 Adaptive voltage limits** (page 533).

### ■ Brake chopper

A brake chopper can be used to handle the energy generated by a decelerating motor. When the DC voltage rises high enough, the chopper connects the DC circuit to an external brake resistor. The chopper operates on the pulse width modulation principle.

The brake chopper (43.6) can be enabled with the overvoltage controller (30.30) still active. In such case, make sure the overvoltage controller limits are set high enough not to limit before the full braking power is reached. This function in certain applications avoids unnecessary overvoltage trip and implements a simpler control logic if the resistor cannot absorb enough energy or when the resistor breaks during braking.

Some ACS880 drives have an internal brake chopper as standard, some have a brake chopper available as an internal or external option. See the appropriate hardware manual or sales catalog.

The internal brake choppers of ACS880 drives start conducting when the DC link voltage reaches  $1.156 \times U_{DCmax}$ . 100% pulse width is reached at approximately  $1.2 \times U_{DCmax}$ , depending on supply voltage range – see table under [Voltage control and trip limits](#) above. ( $U_{DCmax}$  is the DC voltage corresponding to the maximum of the AC supply voltage range.) For information on external brake choppers, refer to their documentation.

**Note:** For runtime braking, overvoltage control (parameter 30.30) needs to be disabled for the chopper to operate.

### Settings and diagnostics

Parameters: [1.11 DC voltage](#) (page 139) and [30.30 Overvoltage control](#) (page 346).

Parameter group: [43 Brake chopper](#) (page 417).

### ■ DC voltage boost

This section describes the use of the DC voltage boost function for the drives which has separate IGBT supply unit control.

The DC voltage boost require drive derating. See hardware manual of the drive for derating factors.

### Description of the DC voltage boost function

The regenerative and ultra low harmonic drives can boost their DC link voltage. In other words, they can increase the operating voltage of the DC link from its default value.

The user can take the DC voltage boost function in use by:

1. Adjusting the user-defined DC voltage reference value ([94.22](#)) and
-

2. Selecting the user-defined reference (94.22) as the source for the drive DC voltage reference (94.21).

Benefits of the DC voltage boost function are:

- Possibility to supply nominal voltage to the motor even when the supply voltage of the drive is below the motor nominal voltage. Example: A drive that is connected to 415 V can supply 460 V to a 460 V motor.
- Compensation of a voltage drop due to an output filter, motor cable or input supply cables.
- Increased motor torque in the field weakening area (that is, when the drive operates the motor in the speed range above the motor nominal speed).

### Use case examples

#### Example 1: Full motor voltage regardless of supply voltage fluctuations

Supply voltage is 380 V, motor nominal voltage is 400 V. To get motor nominal voltage at nominal speed regardless of the supply voltage fluctuations:

1. Calculate the required user DC voltage reference:  $400\text{ V} \times \sqrt{2} = 567\text{ V DC}$ .
2. Set the value of parameter 94.22 to 567 V.
3. Make sure that the value of parameter 99.7 is set to 400 V.

#### Example 2: Sine filter at the output of the drive

The drive is equipped with a sine filter at the output. Motor cable length is 300 m (984 ft). Estimated voltage loss across the filter and cable is 40 V. Motor nominal voltage is 400 V.

To compensate for the 40 V voltage loss at the nominal speed:

1. Calculate the required voltage at the drive output before the sine filter to compensate for the voltage drop:  $400\text{ V} + 40\text{ V} = 440\text{ V}$ .
2. Calculate the required user DC voltage reference:  $440\text{ V} \times \sqrt{2} = 622\text{ V}$ .
3. Set the value of parameter 94.22 to 622 V.

If the drive is configured to operate in DTC motor control mode and the ID run is performed with the output filter and motor cable connected, no other configuration is needed. The DTC motor control will take care of the estimated losses and boost drive output voltage without getting limited by parameter 99.7.

If the drive is configured to operate in the scalar motor control mode, change the value of parameter 99.7 to 440 V to allow the motor control to go up to 440 V at the drive output at nominal speed.

**Note:** In scalar motor control mode, the output voltage can alternatively be increased by adjusting the  $U/f$  curve: by setting parameter 97.7. The value of 97.7, can be calculated as the ratio of the desired voltage and the nominal voltage. In this example, the ratio is  $440\text{ V} / 400\text{ V} = 110\%$ . Set the value of 97.7 to 110% and leave motor nominal voltage as 400 V.

**Limits**

There are two types of limitations that you must take into account when you use the DC voltage boost function: limitations to the DC voltage reference and the limitation to the drive output voltage.

The drive calculates the minimum and maximum limits for the User DC voltage reference (94.22). The calculation is based on the actual supply voltage and the upper limit of the largest supply voltage range selection available for the drive (95.1). Limits are:

1. Minimum limit: Internal DC voltage reference ( $U_{dc,int}$ ).
2. Maximum limit: Maximum DC voltage reference ( $U_{dc,max}$ ).

For more information, see the table below and sections [Internal DC voltage reference \( \$U\_{dc,int}\$ \)](#) and [Maximum DC voltage reference \( \$U\_{dc,max}\$ \)](#).

This table summarizes the limits to the user-defined DC voltage reference and to the drive output voltage.

Drive type	95.1 selection	Internal DC voltage reference ( $U_{dc,int}$ ) <sup>1)</sup>	Maximum DC voltage reference ( $U_{dc,max}$ )	Maximum drive output voltage with parameter 97.4 default value
xxxA-3	380...415 V	553 V	663 V	479 V
xxxA-5	380...415 V	553 V	799 V	576 V
	440...480 V	641 V		
	500 V	728 V		
xxxA-7	525...600 V	764 V	1102 V	795 V
	660...690 V	981 V		

<sup>1)</sup> See section [Internal DC voltage reference \( \$U\_{dc,int}\$ \)](#).

Internal DC voltage reference ( $U_{dc,int}$ )

$$U_{dc,int} = U_{ac,rms} \times \sqrt{2} \times 1.03$$

where

$U_{dc,int}$  Internal DC voltage reference

$U_{ac,rms}$  Actual input supply voltage.

If the user-defined reference (94.22) is less than the internal reference value ( $U_{dc,int}$ ), the control program uses the internal reference as the drive DC voltage reference.

Maximum DC voltage reference ( $U_{dc,max}$ )

$$U_{dc,max} = U_{cat,hi} \times \sqrt{2} \times 1.13$$

where

$U_{dc,max}$  Maximum DC voltage reference

$U_{cat,hi}$  Upper limit of the largest supply voltage range selection available for the drive (95.1)

If the user-defined reference (94.22) is more than the maximum DC voltage reference ( $U_{dc,max}$ ), the control program uses the maximum value as the drive DC voltage reference.

Maximum drive output voltage

$$U_{ac,out} = (U_{dc} / \sqrt{2}) \times (1 - U_{res})$$

where

$U_{ac,out}$  Maximum output voltage of the drive

$U_{dc}$  Actual DC voltage

$U_{res}$  Value of parameter 97.4

The voltage reserve setting (97.4) limits the maximum drive output voltage.

Limit calculation examples

**Example 1:** Calculating the internal DC voltage reference and maximum DC voltage reference

The voltage category is 380 ... 415 V and the power line voltage is 400 V.

## 88 Program features

Internal DC voltage reference  $U_{dc,int} = 400 \text{ V} \times \sqrt{2} \times 1.03 = 583 \text{ V}$ .

Maximum DC voltage reference  $U_{dc,max} = 415 \text{ V} \times \sqrt{2} \times 1.13 = 663 \text{ V}$ .

*Example 2: Calculating the maximum output voltage of the drive*

DC voltage is 650 V DC, and the voltage reserve setting (97.04) is -2%.

The maximum output voltage of the drive is  $U_{ac,out} = (650 / \sqrt{2}) \times (1 + 0.02) = 469 \text{ V}$ .

### Settings and diagnostics

Parameters: [97.7 User flux reference](#), [94.20 DC voltage reference \(page 530\)](#), [94.21 DC voltage ref source \(page 530\)](#), [94.22 User DC voltage reference \(page 531\)](#) and [99.7 Motor nominal voltage](#).

#### ■ DC voltage control mode

A special mode for controlling the voltage of a common DC bus is available especially for off-grid applications where the inverter unit is connected to a generator and the supply unit creates an AC supply network. See section [DC voltage control mode](#).

### Settings and diagnostics

Parameter group: [29 Voltage reference chain \(page 333\)](#).

---



## Safety and protections

### ■ Emergency stop

The emergency stop signal is connected to the input selected by parameter [21.5](#). An emergency stop can also be generated through fieldbus (parameter [6.1](#), bits 0...2).

The mode of the emergency stop is selected by parameter [21.4](#). The following modes are available:

- Off1: Stop along the standard deceleration ramp defined for the particular reference type in use
- Off2: Stop by coasting
- Off3: Stop by the emergency stop ramp defined by parameter [23.23](#).

With Off1 or Off3 emergency stop modes, the ramp-down of the motor speed can be supervised by parameters [31.32](#) and [31.33](#).

#### Note:

- For SIL 3 / PL e-level emergency stop functions, the drive can be fitted with a TÜV-certified FSO-xx safety options module. The module can then be incorporated into certified safety systems.
- The installer of the equipment is responsible for installing the emergency stop devices and all additional devices needed for the emergency stop function to fulfill the required emergency stop categories. For more information, contact your local ABB representative.
- After an emergency stop signal is detected, the emergency stop function cannot be canceled even though the signal is canceled.
- If the minimum (or maximum) torque limit is set to 0%, the emergency stop function may not be able to stop the drive.
- Speed and torque reference additives (parameters [22.15](#), [22.17](#), [26.16](#), [26.25](#) and [26.41](#)) and reference ramp shapes ([23.16](#)...[23.19](#)) are ignored in case of emergency ramp stops.

### Settings and diagnostics

Parameters: [6.17 Drive status word 2](#) (page 163), [6.18 Start inhibit status word](#) (page 164), [21.4 Emergency stop mode](#) (page 268), [21.5 Emergency stop source](#) (page 269), [23.23 Emergency stop time](#) (page 291), [25.13 Min torq sp ctrl em stop](#) (page 307), [25.14 Max torq sp ctrl em stop](#) (page 307), [25.15 Proportional gain em stop](#) (page 307), [31.32 Emergency ramp supervision](#) (page 358) and [31.33 Emergency ramp supervision delay](#) (page 358).

---

### ■ Motor thermal protection

The control program features two separate motor temperature monitoring functions. The temperature data sources and warning/trip limits can be set up independently for each function.

The motor temperature can be monitored using

- the motor thermal protection model (estimated temperature derived internally inside the drive), or
- Sensors connected through optional modules that provide reinforced/double insulation.

In addition to temperature monitoring, a protection function is available for 'Ex' motors installed in a potentially explosive atmosphere.

#### **Motor thermal protection model**

The drive calculates the temperature of the motor on the basis of the following assumptions:

1. When power is applied to the drive for the first time, the motor is assumed to be at ambient temperature (defined by parameter [35.50](#)). After this, when power is applied to the drive, the motor is assumed to be at the estimated temperature.
2. Motor temperature is calculated using the user-adjustable motor thermal time and motor load curve. The load curve should be adjusted in case the ambient temperature exceeds 30 °C.

The motor thermal protection model fulfills standard IEC/EN 61800-5-1 ed. 2.1 requirements for thermal memory retention and speed sensitivity. The estimated temperature is retained over power down. Speed dependency is set by parameters [35.51](#), [35.52](#) and [35.53](#).

**Note:** The motor thermal model can be used when only one motor is connected to the drive.

---


## Temperature monitoring using PTC sensors



### WARNING!

Double or reinforced insulation is required between the live parts of the motor and the drive control unit. Sensors without reinforced or double insulation must be connected to option module FPTC-xx or FAIO-01. With basic-insulated motor temperature sensors, FAIO-01 forms double insulation. FPTC-xx forms itself a double insulation. See the hardware manual for more information.

One PTC sensor can be connected to digital input DI6.




The resistance of the PTC sensor increases when its temperature rises. The increasing resistance of the sensor decreases the voltage at the input, and eventually its state switches from 1 to 0, indicating overtemperature.

1...3 PTC sensors can also be connected in series to an analog input and an analog output. The analog output feeds a constant excitation current of 1.6 mA through the sensor. The sensor resistance increases as the motor temperature rises, as does the voltage over the sensor. The temperature measurement function calculates the resistance of the sensor and generates an indication if overtemperature is detected.

For wiring of the sensor, refer to the *Hardware Manual* of the drive.

The figure below shows typical PTC sensor resistance values as a function of temperature.

## 92 Program features



In addition to the above, optional FEN-xx encoder interfaces, and FPTC-xx modules have connections for PTC sensors. Refer to the module-specific documentation for more information.

---

## Temperature monitoring using Pt100 or Pt1000 sensors

---



### WARNING!

Double or reinforced insulation is required between the live parts of the motor and the drive control unit. Sensors without reinforced or double insulation must be connected to option module FAIO-01. With basic-insulated motor temperature sensors, FAIO-01 forms double insulation. See the hardware manual for more information.

---

1...3 Pt100 or Pt1000 sensors can be connected in series to an analog input and an analog output.

The analog output feeds a constant excitation current of 9.1 mA (Pt100) or 1 mA (Pt1000) through the sensor. The sensor resistance increases as the motor temperature rises, as does the voltage over the sensor. The temperature measurement function reads the voltage through the analog input and converts it into degrees Celsius.

The warning and fault limits can be adjusted by parameters.

For the wiring of the sensor, refer to the *Hardware Manual* of the drive.

**Note:** If excitation current is too high for the sensor, use some other means to measure the temperature.

## Temperature monitoring using KTY84 sensors

---



### WARNING!

Double or reinforced insulation is required between the live parts of the motor and the drive control unit. Sensors without reinforced or double insulation must be connected to option module FAIO-01. With basic-insulated motor temperature sensors, FAIO-01 forms double insulation. See the hardware manual for more information.

---


One KTY84 sensor can be connected to an analog input and an analog output on the control unit.

The analog output feeds a constant excitation current of 2.0 mA through the sensor. The sensor resistance increases as the motor temperature rises, as does the voltage over the sensor. The temperature measurement function reads the voltage through the analog input and converts it into degrees Celsius.

FEN-xx encoder interfaces (optional) also have a connection for one KTY84 sensor.

The figure and table below show typical KTY84 sensor resistance values as a function of the motor operating temperature.

---



The warning and fault limits can be adjusted by parameters.

For the wiring of the sensor, refer to the *Hardware Manual* of the drive.

**Motor fan control logic (parameters 35.100...35.106)**

If the motor has an external cooling fan, it is possible to use a drive signal (for example, running/stopped) to control the starter of the fan via a relay or digital output. A digital input can be selected for fan feedback. A loss of the feedback signal will optionally cause a warning or a fault.

Start and stop delays can be defined for the fan. In addition, a feedback delay can be set to define the time within which feedback must be received after the fan starts.

**Ex motor support (parameter 95.15, bit 0)**

The control program has a temperature protection function for Ex motors located in a potentially explosive atmosphere. The protection is enabled by setting bit 0 of parameter 95.15.

**PTC/Pt100 relay (parameter 95.20, bit 8)**

Activating parameter 95.20, bit 8 changes the source of external event 1 to DI6. It also changes the external event 1 type to a fault.

## Settings and diagnostics

Parameter groups: [35 Motor thermal protection \(page 375\)](#) and [91 Encoder module settings \(page 516\)](#).

Parameters: [95.15 Special HW settings \(page 538\)](#) and [95.20 HW options word 1 \(page 540\)](#).

### ■ Motor overload protection

This section describes motor overload protection without using motor thermal protection model, either with estimated or measured temperature. For protection with the motor thermal protection model, see section [Motor thermal protection \(page 90\)](#).

Motor overload protection is required and specified by multiple standards including the US National Electric Code (NEC), UL 508C and the common UL\IEC 61800-5-1 standard in conjunction with IEC 60947-4-1. The standards allow for motor overload protection without external temperature sensors.

The Motor overload protection fulfills standard IEC/EN 61800-5-1 ed. 2.1 requirements for thermal memory retention and speed sensitivity. The estimated temperature is retained over power down. Speed dependency is set by parameters.

The protection feature allows the user to specify the class of operation in the same manner as the overload relays are specified in standards IEC 60947-4-1 and NEMA ICS 2.

Motor overload protection requires that you specify a motor current tripping level. This is defined by a curve using parameters [35.51](#), [35.52](#) and [35.53](#). The tripping level is the motor current at which the overload protection will ultimately trip if the motor current remains at this level continuously.

The motor overload class (class of operation), parameter [35.57](#), is given as the time required for the overload relay to trip when operating at 7.2 times the tripping level in the case of IEC 60947-4-1 and 6 times the tripping level in the case of NEMA ICS 2. The standards also specify the time to trip for current levels between the tripping level and the 6 times tripping level. The drive satisfies the IEC standard and NEMA standard trip times.

Using class 20 satisfies the UL 508C requirements.

The motor overload algorithm monitors the squared ratio (motor current / tripping level)<sup>2</sup> and accumulates this over time. This is sometimes referred to as I<sup>2</sup>t protection. The accumulated value is shown in parameter [35.5](#).

You can define with parameter [35.56](#) that when [35.5](#) reaches 88%, a motor overload warning will be generated, and when it reaches 100%, the drive will trip on the motor overload fault. The rate at which this internal value is increased depends on the actual current, tripping level current and overload class selected.

Parameters [35.51](#), [35.52](#) and [35.53](#) serve a dual purpose. They determine the load curve for temperature estimate as well as specify the overload tripping level.

### Settings and diagnostics

Parameters common to motor thermal protection and motor overload protection: [35.51 Motor load curve ... 35.53 Break point \(page 384\)](#).

Parameters specific to motor overload protection: [35.5 Motor overload level \(page 376\)](#), [35.56 Motor overload action ... 35.57 Motor overload class \(page 386\)](#).

#### ■ Thermal protection of motor cable

The control program contains a thermal protection function for the motor cable. This function should be used, for example, when the nominal current of the drive exceeds the current-carrying capacity of the motor cable.

The program calculates the temperature of the cable on the basis of the following data:

- Measured output current (parameter [1.7](#))
- Nominal continuous current rating of the cable, specified by [35.61](#), and
- Thermal time constant of the cable, specified by [35.62](#).

When the calculated temperature of the cable reaches 102% of the rated maximum, a warning ([A480](#)) is given. The drive trips on a fault ([4000](#)) when 106% is reached.

### Settings and diagnostics

Parameters: [35.60 Cable temperature...35.62 Cable thermal rise time \(page 387\)](#).

Events: [A480 Motor cable overload \(page 598\)](#) and [4000 Motor cable overload \(page 583\)](#).

#### ■ User load curve


The user load curve provides a function that monitors an input signal (eg. motor torque or motor current) as a function of drive output speed or frequency. The function includes both high limit (overload) and low limit (underload) monitoring. Overload monitoring can, for example, be used to detect a pump becoming clogged or a saw blade hitting a knot. Underload monitoring can detect the load being lost, for example because of the snapping of a transmission belt.

The monitoring is effective within a motor speed and/or frequency range. The frequency range is used with a frequency reference in scalar motor control mode; otherwise, the speed range is used. The range is defined by five speed (parameters [37.11...37.15](#)) or frequency ([37.16...37.20](#)) values. The values are positive, but the monitoring is symmetrically active in the negative direction as the sign of the monitored signal is ignored. Outside the speed/frequency range, the monitoring is disabled.

---



An underload (37.21...37.25) and overload (37.31...37.35) limit is set for each of the five speed or frequency points. Between these points, the limits are interpolated linearly to form overload and underload curves.



The action (none, warning or fault) taken when the signal exits the allowed operation area can be selected separately for overload and underload conditions (parameters 37.3 and 37.4 respectively). Each condition also has an optional timer to delay the selected action (37.41 and 37.42).

### Settings and diagnostics

Parameter group: [37 User load curve \(page 395\)](#).

Events: [A6E6 ULC configuration \(page 606\)](#), [A8BE ULC overload \(page 615\)](#), [A8BF ULC underload \(page 615\)](#), [8001 ULC underload \(page 596\)](#) and [8002 ULC overload \(page 597\)](#).

### ■ Automatic fault resets



#### **WARNING!**

Before you activate the function, make sure that no dangerous situations can occur. The function resets the drive automatically and continues operation after a fault.

## 98 Program features

The drive can automatically reset itself after overcurrent, overvoltage, undervoltage and external faults. The user can also specify a fault (excluding Safe torque off related faults) to be reset automatically.

By default, automatic resets are off and must be specifically activated by the user.

### Settings and diagnostics

Parameters: [31.12 Autoreset selection](#)...[31.16 Delay time](#) (page 352).

#### ■ Other programmable protection functions

##### External events (parameters [31.01](#)...[31.10](#))

Five different event signals from the process can be connected to selectable inputs to generate trips and warnings for the driven equipment. When the signal is lost, an external event (fault, warning, or a mere log entry) is generated. The contents of the messages can be edited on the control panel by selecting **Menu - Settings - Edit texts**.

##### Motor phase loss detection (parameter [31.19](#))

The parameter selects how the drive reacts whenever a motor phase loss is detected.

##### Earth (Ground) fault detection (parameter [31.20](#))

The earth fault detection function is based on sum current measurement. Note that

- an earth fault in the supply cable does not activate the protection
- in a grounded supply, the protection activates within 2 milliseconds
- in an ungrounded supply, the supply capacitance must be 1 microfarad or more
- the capacitive currents caused by shielded motor cables up to 300 meters will not activate the protection
- the protection is deactivated when the drive is stopped.

##### Safe torque off detection (parameter [31.22](#))

The drive monitors the status of the Safe torque off input, and this parameter selects which indications are given when the signals are lost. (The parameter does not affect the operation of the Safe torque off function itself). For more information on the Safe torque off function, see the *Hardware manual*.

##### Swapped supply and motor cabling (parameter [31.23](#))

The drive can detect if the supply and motor cables have accidentally been swapped (for example, if the supply is connected to the motor connection of the drive). The

---

parameter selects if a fault is generated or not. Note that the protection should be disabled in drive/inverter hardware supplied from a common DC bus.

### **Stall protection (parameters 31.24...31.28)**

The drive protects the motor in a stall situation. It is possible to adjust the supervision limits (current, frequency and time) and choose how the drive reacts to a motor stall condition.

### **Overspeed protection (parameter 31.30)**

The user can set overspeed limits by specifying a margin that is added to the currently-used maximum and minimum speed limits.

### **Ramp stop supervision (parameters 31.32, 31.33, 31.37 and 31.38)**

The control program has a supervision function for both the normal and emergency stop ramps. The user can either define a maximum time for stopping, or a maximum deviation from the expected deceleration rate. If the drive fails to stop in the expected manner, a fault is generated and the drive coasts to a stop.

### **Main cooling fan supervision (parameter 31.35)**

The parameter selects how the drive reacts to a loss of the main cooling fan.

With an inverter unit consisting of frame R8i inverter modules, it may be possible to continue operation even if a cooling fan of an inverter module stops. See the description of the parameter.

### **Custom motor current fault limit (parameter 31.42)**

The control program sets a motor current limit based on drive hardware. In most cases, the default value is appropriate. However, a lower limit can be manually set by the user, for example, to protect a permanent magnet motor from demagnetization.

### **Local control loss detection (parameter 49.05)**

The parameter selects how the drive reacts to a control panel or PC tool communication break.

---

## Diagnostics

### ■ Fault and warning messages, data logging

See chapter Fault tracing.

### ■ Signal supervision

Three signals can be selected to be supervised by this function. Whenever a supervised signal exceeds or falls below predefined limits, a bit in [32.1](#) is activated, and a warning or fault generated. The contents of the message can be edited on the control panel by selecting **Menu - Settings - Edit texts**.

The supervised signal is low-pass filtered. The supervision operates on a 2 ms time level. The configuration parameters are scanned for changes on a 10 ms time level.

### Settings and diagnostics

Parameter group: [32 Supervision \(page 362\)](#).

Events: [A8B0 Signal supervision \(page 615\)](#), [A8B1 Signal supervision 2 \(page 615\)](#), [A8B2 Signal supervision 3 \(page 615\)](#), [80B0 Signal supervision \(page 597\)](#), [80B1 Signal supervision 2 \(page 597\)](#) and [80B2 Signal supervision 3 \(page 597\)](#).

### ■ Maintenance timers and counters

The program has six different maintenance timers or counters that can be configured to generate a warning when a pre-defined limit is reached. The contents of the message can be edited on the control panel by selecting **Menu - Settings - Edit texts**.

The timer/counter can be set to monitor any parameter. This feature is especially useful as a service reminder.

There are three types of counters:

- On-time timers. Measures the time a binary source (for example, a bit in a status word) is on.
- Signal edge counters. The counter is incremented whenever the monitored binary source changes state.
- Value counters. The counter measures, by integration, the monitored parameter. A warning is given when the calculated area below the signal peak exceeds a user-defined limit.

### Settings and diagnostics

Parameter group: [33 Generic timer & counter \(page 366\)](#).

---

## ■ Energy saving calculators

This feature consists of the following functionalities:

- An energy optimizer that adjusts the motor flux in such a way that the total system efficiency is maximized
- A counter that monitors used and saved energy by the motor and displays them in kWh, currency or volume of CO<sub>2</sub> emissions, and
- A load analyzer showing the load profile of the drive (see separate section on page [101](#)).

**Note:** The accuracy of the energy savings calculation is directly dependent on the accuracy of the reference motor power given in parameter [45.19 Comparison power](#).

## Settings and diagnostics

Parameter group: [45 Energy efficiency \(page 426\)](#).

## ■ Load analyzer

### Peak value logger


The user can select a signal to be monitored by a peak value logger. The logger records the peak value of the signal along with the time the peak occurred, as well as motor current, DC voltage and motor speed at the time of the peak. The peak value is sampled at 2 ms intervals.

---

### Amplitude loggers

The control program has two amplitude loggers. Depending on the setting of parameter 36.8, the loggers are active continuously or only when the drive is modulating.

For amplitude logger 2, the user can select a signal to be sampled at 200 ms intervals, and specify a value that corresponds to 100%. The collected samples are sorted into 10 read-only parameters according to their amplitude. Each parameter represents an amplitude range 10 percentage points wide, and displays the percentage of the collected samples that have fallen within that range. Note that the lowest range also contains the negative values (if any), while the highest range also contains the values above 100%.



Amplitude logger 1 is fixed to monitor motor current, and cannot be reset. With amplitude logger 1, 100% corresponds to the maximum output current of the drive ( $I_{max}$ , as given in the hardware manual). The distribution of collected samples is shown by parameters 36.20...36.29.

### Settings and diagnostics

Parameter group: [36 Load analyzer \(page 390\)](#).

## Miscellaneous

### ■ User parameter sets

The drive supports four user parameter sets that can be saved to the permanent memory and recalled using drive parameters. It is also possible to use digital inputs to switch between user parameter sets.

A user parameter set contains all editable values in parameter groups 10...99 except

- forced I/O values such as parameters [10.3](#) and [10.4](#)
- I/O extension module settings (groups 14...16)
- fieldbus communication enable parameters ([50.1](#) and [50.31](#))
- other fieldbus communication settings (groups 51...56 and 58)
- encoder configuration settings (groups 92...93),
- some hardware settings in parameter group [95](#), and
- user set selection parameters [96.11...96.13](#)

As the motor settings are included in the user parameter sets, make sure the settings correspond to the motor used in the application before recalling a user set. In an application where different motors are used with the drive, the motor ID run needs to be performed with each motor and the results saved to different user sets. The appropriate set can then be recalled when the motor is switched.

If no parameter sets have been saved, attempting to load a set will create all sets from the currently active parameter settings.

Switching between user parameter sets is only possible with the drive stopped.

### Settings and diagnostics

Parameters: [10.3 DI force selection \(page 182\)](#), [10.4 DI force data \(page 182\)](#), [50.1 FBA A enable \(page 442\)](#), [50.31 FBA B enable \(page 447\)](#), and [96.10 User set status \(page 547\)](#)...[96.13 User set I/O mode in2 \(page 548\)](#).

Parameter group: [95 HW configuration \(page 533\)](#).

Events: [64B2 User set fault \(page 591\)](#).

### ■ Parameter checksum calculation

A parameter checksum can be calculated from a user-definable set of parameters to monitor changes in the drive configuration. The calculated checksum is compared to 1...4 reference checksums; in case of a mismatch, an event (a pure event, warning or fault) is generated.

---

By default, the set of parameters included in the calculation contain most parameters with the exception of

- actual signals
- parameter group [47](#)
- parameters that are activated to validate new settings (such as [51.27](#) and [96.7](#))
- parameters that are not saved to the flash memory (such as [96.24...96.26](#))
- parameters that are internally calculated from others (such as [98.9...98.14](#)).
- dynamic parameters (eg. parameters that vary according to hardware), and
- application program parameters.

The default set can be edited using the Drive customizer PC tool.

### **Settings and diagnostics**

Parameters: [96.53 Actual checksum \(page 551\)...96.59 Approved checksum 4 \(page 552\)](#).

Events: [6200 Checksum mismatch \(page 588\)](#) and [A686 Checksum mismatch \(page 603\)](#).

---



## ■ User lock

---



### **WARNING!**

ABB will not be liable for damages or losses caused by the failure to activate the user lock using a new pass code. See [Cyber security disclaimer \(page 20\)](#).

---

For improved cybersecurity, it is highly recommended that you set a master pass code to prevent, for example, the changing of parameter values and/or the loading of firmware and other files.

With several drives, set a unique pass code for each drive.

To activate the user lock for the first time,

- Enter the default pass code, 10000000, into [96.2](#). This will make parameters [96.100...96.102](#) visible.
  - Enter a new pass code into [96.100](#). Always use eight digits; if using Drive Composer, finish with Enter.
  - Confirm the new pass code in [96.101](#).
- 



### **WARNING!**

Store the pass code in a safe place – the user lock cannot be opened even by ABB if the pass code is lost.

---

- In [96.102](#), define the actions that you want to prevent (we recommend you select all the actions unless otherwise required by the application).
- Enter an invalid (random) pass code into [96.2](#).
- Activate [96.8](#), or cycle the power to the control unit.
- Check that parameters [96.100...96.102](#) are hidden. If they are not, enter another random pass code into [96.2](#).

To reopen the lock, enter your pass code into [96.2](#). This will again make parameters [96.100...96.102](#) visible.

## **Settings and diagnostics**

Parameters: [96.2 Pass code \(page 544\)](#) and [96.100 Change user pass code...96.102 User lock functionality \(page 553\)](#).

Events: [A6B0 User lock open \(page 605\)](#).

---

## ■ Data storage parameters

Twenty-four (sixteen 32-bit, eight 16-bit) parameters are reserved for data storage. These parameters are unconnected by default and can be used for eg. linking, testing and commissioning purposes. They can be written to and read from using other parameters' source or target selections.

Note that only 32-bit floating point (type *real32*) parameters can be selected as the source of another parameter value. In other words, parameters 47.1...47.8 can be used as value sources of other parameters while 47.11...47.28 cannot.

To use a 16-bit integer (received in DDCS data sets) as the source of another parameter, write the value into one of the *real32* type storage parameters (47.1...47.8). Select the storage parameter as the source, and define a suitable scaling method between the 16-bit and 32-bit values in parameters 47.31...47.38.

## Settings and diagnostics

Parameter group: [47 Data storage \(page 435\)](#).

## ■ Reduced run function

A “reduced run” function is available for inverter units consisting of parallel-connected inverter modules. The function makes it possible to continue operation with limited current even if one (or more) module is out of service, for example, because of maintenance work. In principle, reduced run is possible with only one module, but the physical requirements of operating the motor still apply; for example, the modules remaining in use must be able to provide the motor with enough magnetizing current.

The reduced run mask can be used instead of the reduced run mode in case there is no need to remove the power module physically from the system. Masking a module or several modules stops BCU from sending control commands to selected PSL2 channel or channels.

### Note:

- STO circuit must remain as it has been.
  - Do not use mask to bypass STO circuit faults.
  - Do not remove fiber optic cables from the system.
  - Module must be disconnected from AC side to avoid current flow through the freewheeling diodes.
-

## Activation of the reduced run function

**Note:** For cabinet-built drives, the wiring accessories and the air baffle needed during the procedure are available from ABB, and are included in the delivery.



### **WARNING!**

Follow the safety instructions provided for the drive or inverter unit in question.

---

1. Disconnect the supply voltage and all auxiliary voltages from the drive/inverter unit.
2. If the inverter control unit is powered from the faulty module, install an extension to the wiring and connect it to one of the remaining modules.
3. Remove the module to be serviced from its bay. See the appropriate hardware manual for instructions.
4. If the Safe torque off (STO) function is in use, install jumpering in the STO wiring in place of the missing module (unless the module was the last on the chain).
5. Install an air baffle to the top module guide to block the airflow through the empty module bay.
6. In case the inverter unit has a DC switch with a charging circuit, disable the appropriate channel on the xSFC-xx charging controller.
7. Switch on the power to the drive/inverter unit.
8. Set parameter [95.12](#) to define which modules have been removed.
9. Enter the number of inverter modules present into parameter [95.13](#).
10. Reset all faults and start the drive/inverter unit. The maximum current is now automatically limited according to the new inverter configuration. A mismatch between the number of detected modules ([95.14](#)) and the value set in [95.13](#) will generate a fault.

After all modules have been reinstalled, parameters [95.12](#) and [95.13](#) must be reset to 0 to disable the reduced run function. In case the inverter is equipped with a charging circuit, the charging monitoring must be reactivated for all modules. If the Safe torque off (STO) function is in use, an acceptance test must be performed (see the hardware manual of the drive/inverter unit for instructions).

### Settings and diagnostics

Parameters: [6.17 Drive status word 2 \(page 163\)](#) and [95.13 Reduced run mode...95.14 Connected modules \(page 537\)](#).

Events: [5695 Reduced run \(page 587\)](#).

---

### ■ **du/dt filter support**

With an external du/dt filter connected to the output of the drive, bit 13 of [95.20](#) must be switched on. The setting limits the output switching frequency. With frame size R5i...R7i inverter modules, the setting also forces the drive/inverter module fan to full speed. Note that the setting is not to be activated with inverter modules with internal du/dt filters.

#### **Settings and diagnostics**

Parameter: [95.20 HW options word 1 \(page 540\)](#).

### ■ **Sine filter support**

The control program has a setting that enables the use of sine filters (available separately from ABB and others).

With an ABB sine filter connected to the output of the drive, bit 1 of [95.15](#) must be switched on. The setting limits the switching and output frequencies to

- prevent the drive from operating at filter resonance frequencies, and
- protect the filter from overheating.

With a custom sine filter, bit 3 of [95.15](#) must be switched on. (The setting does not limit the output frequency.) Additional parameters must be set according to the properties of the filter as listed below.

#### **Settings and diagnostics**

Parameters: [95.15 Special HW settings \(page 538\)](#), [97.1 Switching frequency reference \(page 555\)](#), [97.2 Minimum switching frequency \(page 555\)](#), [99.18 Sine filter inductance \(page 571\)](#) and [99.19 Sine filter capacitance \(page 572\)](#).

---

## ■ Router mode for BCU control unit


The BCU control unit of an inverter unit can be set to a “router mode” to allow the control of locally-connected power units (for example, inverter modules) by another BCU. Using the router mode and some hardware switching, it is possible to have the same modules alternate between inverter and, for example, IGBT supply use.

The router mode involves connecting the two BCUs together by their PSL2 channels. When router mode is active, the channels coming from the other BCU are forwarded to the local modules.


The diagrams below show how the control of four converter modules can be switched between two BCUs.

**Note:** For an example of how to switch converter modules between inverter and IGBT supply use, see the *ACS880 IGBT supply control program firmware manual* (3AUA0000131562 [English]).

*BCU 1 controlling all modules, BCU 2 in router mode*



*BCU 2 controlling all modules, BCU 1 in router mode*



**Note:**

- The local modules must be connected to successive channels starting from CH1. The immediately following channels are connected to the other BCU and routed to the local modules. There must be at least as many local modules as there are routed channels.
- In PLC control, any switch-overs must be done in stopped state, and so that at least one BCU is in router mode at any given time.
- Additional rules or restrictions may apply when using the router mode with other control programs. See the appropriate firmware manual.

**Settings and diagnostics**

Parameters: [95.16 Router mode \(page 538\)](#) and [95.17 Router channel config \(page 539\)](#).

■ **Parameter ranges with option +N8200 (High speed license)**

With option +N8200 (High speed license), the following speed and frequency parameters have an extended range:

Range	Parameters
-90000 ... 90000 rpm	1.2 22.1 22.26...22.32 22.41...22.43 22.52...22.57 22.81...22.87 23.1 23.2 23.27 23.39 24.1...24.4 30.11 30.12 36.15 49.15 49.16 90.1
0...90000 rpm	1.61 21.6 25.18 25.19 29.70 29.72 29.74 29.76 29.78 37.11...37.15 46.1 46.6 46.21 46.31 99.9

## 112 Program features

Range	Parameters
-1500 ... 1500 Hz	1.6 28.1 28.2 28.26...28.32 28.52...28.57 28.78 28.90...28.92 28.96 28.97 30.13 30.14 49.17 49.18
0...1500 Hz	1.63 46.2 99.8



A large, bold, black number '5' is centered within a light grey square with rounded corners.

# Application macros

---

## What this chapter contains

This chapter describes the intended use, operation and default control connections of the application macros.

More information on the connectivity of the control unit is given in the *Hardware manual* of the drive.

## General

Application macros are sets of default parameter values suitable for the application in question. When starting up the drive, the user typically selects the best-suited application macro as a starting point, then makes any necessary changes to tailor the settings to the application. This usually results in a much lower number of user edits compared to the traditional way of programming a drive.

Application macros can be selected by parameter [96.4 Macro select](#). User parameter sets are managed by the parameters in group [96 System \(page 543\)](#).

**Note:** The default control connections described in this chapter are based on the ZCU control unit.

---

## Factory macro

The Factory macro is suited to relatively straightforward speed control applications such as conveyors, pumps and fans, and test benches.

The drive is speed-controlled with the reference signal connected to analog input AI1. The start/stop commands are given through digital input DI1; running direction is determined by DI2. This macro uses control location EXT1.

Faults are reset through digital input DI3.




DI4 switches between acceleration/deceleration time sets 1 and 2. The acceleration and deceleration times, as well as ramp shapes, are defined by parameters [23.12...23.19](#).

DI5 activates constant speed 1.

### ■ Default parameter settings for the Factory macro

The default parameter settings for the Factory macro are listed in chapter Parameter listing.

### ■ Default control connections for the Factory macro

Connection	Term	Description
<b>XPOW</b> External power input		
	+24VI	24 V DC, 2 A
	GND	
<b>XAI</b> Reference voltage and analog inputs		
	+VREF	10 V DC, $R_L$ 1...10 kohm
	-VREF	-10 V DC, $R_L$ 1...10 kohm
	AGND	Ground
	AI1+	<b>Speed reference</b>
	AI1-	0(2)...10 V, $R_{in} > 200$ kohm
	AI2+	By default not in use.
	AI2-	0(4)...20 mA, $R_{in} = 100$ ohm
<b>XAO</b> Analog outputs		
	AO1	<b>Motor speed rpm</b>
	AGND	0...20 mA, $R_L < 500$ ohm
	AO2	<b>Motor current</b>
	AGND	0...20 mA, $R_L < 500$ ohm

Connection	Term	Description						
<b>XD2D Drive-to-drive link</b>								
<table border="1"> <tr><td>1</td><td>B</td></tr> <tr><td>2</td><td>A</td></tr> <tr><td>3</td><td>BGND</td></tr> </table>	1	B	2	A	3	BGND	B	Master/follower, drive-to-drive or embedded fieldbus interface connection
	1	B						
	2	A						
3	BGND							
A								
BGND								
<b>XRO1, XRO2, XRO3 Relay outputs</b>								
	NC	<b>Ready run</b>						
	COM	250 V AC / 30 V DC						
	NO	2 A						
	NC	<b>Running</b>						
	COM	250 V AC / 30 V DC						
	NO	2 A						
	NC	<b>Fault (-1)</b>						
	COM	250 V AC / 30 V DC						
	NO	2 A						
	<b>XD24 Digital interlock</b>							
		DIIL	Run enable					
		+24VD	+24 V DC 200 mA					
DICOM		Digital input ground						
+24VD		+24 V DC 200 mA						
DIOGND		Digital input/output ground						
<b>XDIO Digital input/outputs</b>								
<table border="1"> <tr><td>1</td><td>DIO1</td></tr> <tr><td>2</td><td>DIO2</td></tr> </table>	1	DIO1	2	DIO2	DIO1	Output: Ready run		
	1	DIO1						
2	DIO2							
DIO2	Output: Running							

116 Application macros

Connection	Term	Description
<b>XDI Digital inputs</b>		
	DI1	Stop (0) / Start (1)
	DI2	Forward (0) / Reverse (1)
	DI3	Reset
	DI4	Acc/Dec time set 1 (0) / set 2 (1)
	DI5	Constant speed 1 (1 = On)
	DI6	By default, not in use.
<span style="background-color: yellow; border: 1px solid black; padding: 2px;">XSTO</span>		Safe torque off circuits must be closed for the drive to start. See <i>Hardware manual</i> of drive.
<b>X12</b>		Safety options connection
<b>X13</b>		Control panel connection
<b>X205</b>		Memory unit connection

## Hand/Auto macro

The Hand/Auto macro is suited to speed control applications where two external control devices are used.

The drive is speed-controlled from the external control locations EXT1 (Hand control) and EXT2 (Auto control). The selection between the control locations is done through digital input DI3.

The start/stop signal for EXT1 is connected to DI1 while running direction is determined by DI2. For EXT2, start/stop commands are given through DI6, the direction through DI5.

The reference signals for EXT1 and EXT2 are connected to analog inputs AI1 and AI2 respectively.





A constant speed (by default, 300 rpm) can be activated through DI4.

### ■ Default parameter settings for the Hand/Auto macro

Below is a listing of default parameter values that differ from those listed for the Factory macro in [Parameter listing \(page 138\)](#).

Parameter	Hand/Auto macro default
12.30 AI2 scaled at AI2 max	1500.000
19.11 Ext1/Ext2 selection	DI3
20.6 Ext2 commands	In1 Start; In2 Dir
20.8 Ext2 in1 source	DI6
20.9 Ext2 in2 source	DI5
20.12 Run enable 1 source	DIIL
22.12 Speed ref2 source	AI2 scaled
22.14 Speed ref1/2 selection	Follow Ext1/Ext2 selection
22.22 Constant speed sel1	DI4
23.11 Ramp set selection	Acc/Dec time 1
31.11 Fault reset selection	Not selected

■ **Default control connections for the Hand/Auto macro**

Connection	Term	Description
<b>XPOW</b> External power input		
	+24VI	24 V DC, 2 A
	GND	
<b>XAI</b> Reference voltage and analog inputs		
	+VREF	10 V DC, $R_L$ 1...10 kohm
	-VREF	-10 V DC, $R_L$ 1...10 kohm
	AGND	Ground
	AI1+	<b>Speed reference (Hand)</b>
	AI1-	0(2)...10 V, $R_{in} > 200$ kohm
	AI2+	<b>Speed reference (Auto)</b>
	AI2-	0(4)...20 mA, $R_{in} = 100$ ohm
<b>XAO</b> Analog outputs		
	AO1	<b>Motor speed rpm</b>
	AGND	0...20 mA, $R_L < 500$ ohm
	AO2	<b>Motor current</b>
	AGND	0...20 mA, $R_L < 500$ ohm
<b>XD2D</b> Drive-to-drive link		
	B	Master/follower, drive-to-drive or embedded fieldbus interface connection
	A	
	BGND	
<b>XRO1, XRO2, XRO3</b> Relay outputs		

Connection	Term	Description
	NC	<b>Ready run</b>
	COM	250 V AC / 30 V DC
	NO	2 A
	NC	<b>Running</b>
	COM	250 V AC / 30 V DC
	NO	2 A
	NC	<b>Fault (-1)</b>
	COM	250 V AC / 30 V DC
	NO	2 A
<b>XD24 Digital interlock</b>		
	DIIL	Run enable
	+24VD	+24 V DC 200 mA
	DICOM	Digital input ground
	+24VD	+24 V DC 200 mA
	DIOGND	Digital input/output ground
<b>XDIO Digital input/outputs</b>		
	DIO1	Output: Ready run
	DIO2	Output: Running
<b>XDI Digital inputs</b>		
	DI1	Stop (0) / Start (1) – Hand
	DI2	Forward (0) / Reverse (1) – Hand
	DI3	Hand (0) / Auto (1)
	DI4	Constant speed 1 (1 = On)
	DI5	Forward (0) / Reverse (1) – Auto
	DI6	Stop (0) / Start (1) – Auto
XSTO	Safe torque off circuits must be closed for the drive to start. See <i>Hardware manual</i> of drive.	
X12	Safety options connection	
X13	Control panel connection	
X205	Memory unit connection	

## PID control macro

The PID control macro is suitable for process control applications, for example closed-loop pressure, level or flow control systems such as

- pressure boost pumps of municipal water supply systems
- level-controlling pumps of water reservoirs
- pressure boost pumps of district heating systems
- material flow control on a conveyor line.

The process reference signal is connected to analog input AI1 and the process feedback signal to AI2. Alternatively, a direct speed reference can be given to the drive through AI1. Then the PID controller is bypassed and the drive no longer controls the process variable.

Selection between direct speed control (control location EXT1) and process variable control (EXT2) is done through digital input DI3.

The stop/start signals for EXT1 and EXT2 are connected to DI1 and DI6 respectively.

A constant speed (by default, 300 rpm) can be activated through DI4.

**Note:** When commissioning the PID loop, it is useful to run the motor in speed control first using EXT1; this allows testing of the PID feedback polarity and scaling. Once the feedback has been proven, the PID loop can be “closed” by switching to EXT2.

### ■ Default parameter settings for the PID control macro

Below is a listing of default parameter values that differ from those listed for the Factory macro in [Parameter listing \(page 138\)](#).

Parameter	Hand/Auto macro default
12.27 AI2 min	4.000
19.11 Ext1/Ext2 selection	DI3
20.1 Ext1 commands	In1 Start
20.4 Ext1 in2 source	Not selected
20.6 Ext2 commands	In1 Start
20.8 Ext2 in1 source	DI6
20.12 Run enable 1 source	DI5
22.12 Speed ref2 source	PID
22.22 Constant speed sel1	DI4
23.11 Ramp set selection	Acc/Dec time 1







Parameter	Hand/Auto macro default
31.11 Fault reset selection	Not selected
40.7 Set 1 PID operation mode	On when drive running
40.8 Set 1 feedback 1 source	AI2 scaled
40.11 Set 1 feedback filter time	0.040 s
40.35 Set 1 derivation filter time	1.0 s
40.60 Set 1 PID activation source	Follow Ext1/Ext2 selection

**Note:** The macro selection does not affect parameter group 41 Process PID set 2.

---

■ **Default control connections for the PID control macro**


Connection	Term	Description
<b>XPOW</b> External power input		
	+24VI	24 V DC, 2 A
	GND	
<b>XAI</b> Reference voltage and analog inputs		
	+VREF	10 V DC, $R_L$ 1...10 kohm
	-VREF	-10 V DC, $R_L$ 1...10 kohm
	AGND	Ground
	AI1+	<b>Speed reference</b>
	AI1-	0(2)...10 V, $R_{in} > 200$ kohm
	AI2+	<b>Process feedback <sup>1)</sup></b>
	AI2-	0(4)...20 mA, $R_{in} = 100$ ohm
<b>XAO</b> Analog outputs		
	AO1	<b>Motor speed rpm</b>
	AGND	0...20 mA, $R_L < 500$ ohm
	AO2	<b>Motor current</b>
	AGND	0...20 mA, $R_L < 500$ ohm
<b>XD2D</b> Drive-to-drive link		
	B	Master/follower, drive-to-drive or embedded fieldbus interface connection
	A	
	BGND	
<b>XRO1, XRO2, XRO3</b> Relay outputs		

Connection	Term	Description										
	NC	<b>Ready run</b>										
	COM	250 V AC / 30 V DC										
	NO	2 A										
	NC	<b>Running</b>										
	COM	250 V AC / 30 V DC										
	NO	2 A										
	NC	<b>Fault (-1)</b>										
	COM	250 V AC / 30 V DC										
	NO	2 A										
<b>XD24 Digital interlock</b>												
<table border="1" data-bbox="344 603 483 730"> <tr><td>1</td><td>DIIL</td></tr> <tr><td>2</td><td>+24VD</td></tr> <tr><td>3</td><td>DICOM</td></tr> <tr><td>4</td><td>+24VD</td></tr> <tr><td>5</td><td>DIOGND</td></tr> </table>	1	DIIL	2	+24VD	3	DICOM	4	+24VD	5	DIOGND	DIIL	Digital interlock. By default, not in use.
	1	DIIL										
	2	+24VD										
	3	DICOM										
	4	+24VD										
5	DIOGND											
+24VD	+24 V DC 200 mA											
DICOM	Digital input ground											
+24VD	+24 V DC 200 mA											
DIOGND	Digital input/output ground											
<b>XDIO Digital input/outputs</b>												
<table border="1" data-bbox="361 850 478 898"> <tr><td>1</td><td>DIO1</td></tr> <tr><td>2</td><td>DIO2</td></tr> </table>	1	DIO1	2	DIO2	DIO1	Output: Ready run						
	1	DIO1										
2	DIO2											
DIO2	Output: Running											
<b>XDI Digital inputs</b>												
	DI1	Stop (0) / Start (1) – Speed control										
	DI2	By default, not in use.										
	DI3	Speed control (0) / Process control (1)										
	DI4	Constant speed 1 (1 = On)										
	DI5	Run enable (1 = On)										
	DI6	Stop (0) / Start (1) – Process control										
<table border="1" data-bbox="423 1281 483 1313"> <tr><td>XSTO</td></tr> </table>	XSTO	Safe torque off circuits must be closed for the drive to start. See <i>Hardware manual</i> of drive.										
XSTO												
<table border="1" data-bbox="445 1337 483 1361"> <tr><td>X12</td></tr> </table>	X12	Safety options connection										
X12												
<table border="1" data-bbox="445 1377 483 1401"> <tr><td>X13</td></tr> </table>	X13	Control panel connection										
X13												




Connection	Term	Description
<b>X205</b> Memory unit connection		

1) For sensor connection examples, see page 124.

■ **Sensor connection examples for the PID control macro**



**Note:** The sensor must be powered externally.



## Torque control macro

This macro is used in applications in which torque control of the motor is required. These are typically tension applications, where a particular tension needs to be maintained in the mechanical system.

Torque reference is given through analog input AI2, typically as a current signal in the range of 0...20 mA (corresponding to 0...100% of rated motor torque).

The start/stop signal is connected to digital input DI1. The direction is determined by DI2. Through digital input DI3, it is possible to select speed control (EXT1) instead of torque control (EXT2). As with the PID control macro, speed control can be used for commissioning the system and checking the motor direction.

It is also possible to change the control to local (control panel or PC tool) by pressing the Loc/Rem key. By default, the local reference is speed; if a torque reference is required, the value of parameter [19.16 Local control mode](#) should be changed to [Torque](#).





A constant speed (by default, 300 rpm) can be activated through DI4. DI5 switches between acceleration/deceleration time sets 1 and 2. The acceleration and deceleration times, as well as ramp shapes, are defined by parameters [23.12...23.19](#).

### ■ Default parameter settings for the Torque control macro

Below is a listing of default parameter values that differ from those listed for the Factory macro in [Parameter listing \(page 138\)](#).

Parameter	Torque control macro default
<a href="#">19.11 Ext1/Ext2 selection</a>	DI3
<a href="#">19.14 Ext2 control mode</a>	Torque
<a href="#">20.2 Ext1 start trigger type</a>	Level
<a href="#">20.6 Ext2 commands</a>	In1 Start; In2 Dir
<a href="#">20.7 Ext2 start trigger type</a>	Level
<a href="#">20.8 Ext2 in1 source</a>	DI1
<a href="#">20.9 Ext2 in2 source</a>	DI2
<a href="#">20.12 Run enable 1 source</a>	DI6
<a href="#">22.22 Constant speed sel1</a>	DI4
<a href="#">23.11 Ramp set selection</a>	DI5
<a href="#">26.11 Torque ref1 source</a>	AI2 scaled
<a href="#">31.11 Fault reset selection</a>	Not selected

■ **Default control connections for the Torque control macro**

Connection	Term	Description
<b>XPOW</b> External power input		
	+24VI	24 V DC, 2 A
	GND	
<b>XAI</b> Reference voltage and analog inputs		
	+VREF	10 V DC, $R_L$ 1...10 kohm
	-VREF	-10 V DC, $R_L$ 1...10 kohm
	AGND	Ground
	AI1+	<b>Speed reference</b>
	AI1-	0(2)...10 V, $R_{in} > 200$ kohm
	AI2+	<b>Torque reference</b>
	AI2-	0(4)...20 mA, $R_{in} = 100$ ohm
<b>XAO</b> Analog outputs		
	AO1	<b>Motor speed rpm</b>
	AGND	0...20 mA, $R_L < 500$ ohm
	AO2	<b>Motor current</b>
	AGND	0...20 mA, $R_L < 500$ ohm
<b>XD2D</b> Drive-to-drive link		
	B	Master/follower, drive-to-drive or embedded fieldbus interface connection
	A	
	BGND	
<b>XRO1, XRO2, XRO3</b> Relay outputs		

Connection	Term	Description										
	NC	<b>Ready run</b>										
	COM	250 V AC / 30 V DC										
	NO	2 A										
	NC	<b>Running</b>										
	COM	250 V AC / 30 V DC										
	NO	2 A										
	NC	<b>Fault (-1)</b>										
	COM	250 V AC / 30 V DC										
	NO	2 A										
	<b>XD24 Digital interlock</b>											
<table border="1"> <tr><td>1</td><td>DIIL</td></tr> <tr><td>2</td><td>+24VD</td></tr> <tr><td>3</td><td>DICOM</td></tr> <tr><td>4</td><td>+24VD</td></tr> <tr><td>5</td><td>DIOGND</td></tr> </table>	1	DIIL	2	+24VD	3	DICOM	4	+24VD	5	DIOGND	DIIL	Digital interlock. By default, not in use.
	1	DIIL										
	2	+24VD										
	3	DICOM										
	4	+24VD										
5	DIOGND											
+24VD	+24 V DC 200 mA											
DICOM	Digital input ground											
+24VD	+24 V DC 200 mA											
DIOGND	Digital input/output ground											
<b>XDIO Digital input/outputs</b>												
<table border="1"> <tr><td>1</td><td>DIO1</td></tr> <tr><td>2</td><td>DIO2</td></tr> </table>	1	DIO1	2	DIO2	DIO1	Output: Ready run						
	1	DIO1										
2	DIO2											
DIO2	Output: Running											
<b>XDI Digital inputs</b>												
	DI1	Stop (0) / Start (1)										
	DI2	Forward (0) / Reverse (1)										
	DI3	Speed control (0) / Torque control (1)										
	DI4	Constant speed 1 (1 = On)										
	DI5	Acc/Dec time set 1 (0) / set 2 (1)										
	DI6	Run enable (1 = On)										
	XSTO	Safe torque off circuits must be closed for the drive to start. See <i>Hardware manual</i> of drive.										
X12	Safety options connection											
X13	Control panel connection											
X205	Memory unit connection											

## Sequential control macro

The Sequential control macro is suited for speed control applications in which a speed reference, multiple constant speeds, and two acceleration and deceleration ramps can be used.

Only EXT1 is used in this macro.


The macro offers seven preset constant speeds which can be activated by digital inputs DI4...DI6 (see parameter [22.21 Constant speed function](#)). An external speed reference can be given through analog input AI1. The reference is active only when no constant speed is activated (digital inputs DI4...DI6 are all off). Operational commands can also be given from the control panel.

The start/stop commands are given through digital input DI1; running direction is determined by DI2.

Two acceleration/deceleration ramps are selectable through DI3. The acceleration and deceleration times, as well as ramp shapes, are defined by parameters [23.12...23.19](#).

### ■ Operation diagram

The figure below shows an example of the use of the macro.





## ■ Selection of constant speeds

By default, constant speeds 1...7 are selected using digital inputs DI4...DI6 as follows:





DI4	DI5	DI6	Constant speed active
0	0	0	None (External speed reference used)
1	0	0	Constant speed 1
0	1	0	Constant speed 2
1	1	0	Constant speed 3
0	0	1	Constant speed 4
1	0	1	Constant speed 5
0	1	1	Constant speed 6
1	1	1	Constant speed 7

## ■ Default parameter settings for the Sequential control macro

Below is a listing of default parameter values that differ from those listed for the Factory macro in [Parameter listing \(page 138\)](#).

Parameter	Sequential control macro default
20.12 Run enable 1 source	DIIL
21.3 Stop mode	Ramp
22.21 Constant speed function	01b (Bit 0 = Packed)
22.22 Constant speed sel1	DI4
22.23 Constant speed sel2	DI5
22.24 Constant speed sel3	DI6
22.27 Constant speed 2	600.00 rpm
22.28 Constant speed 3	900.00 rpm
22.29 Constant speed 4	1200.00 rpm
22.30 Constant speed 5	1500.00 rpm
22.31 Constant speed 6	2400.00 rpm
22.32 Constant speed 7	3000.00 rpm
23.11 Ramp set selection	DI3
25.6 Acc comp derivation time	0.12 s
31.11 Fault reset selection	Not selected

■ **Default control connections for the Sequential control macro**

Connection	Term	Description
<b>XPOW</b> External power input		
	+24VI	24 V DC, 2 A
	GND	
<b>XAI</b> Reference voltage and analog inputs		
	+VREF	10 V DC, $R_L$ 1...10 kohm
	-VREF	-10 V DC, $R_L$ 1...10 kohm
	AGND	Ground
	AI1+	<b>Speed reference</b>
	AI1-	0(2)...10 V, $R_{in} > 200$ kohm
	AI2+	By default, not in use.
	AI2-	0(4)...20 mA, $R_{in} = 100$ ohm
<b>XAO</b> Analog outputs		
	AO1	<b>Motor speed rpm</b>
	AGND	0...20 mA, $R_L < 500$ ohm
	AO2	<b>Motor current</b>
	AGND	0...20 mA, $R_L < 500$ ohm
<b>XD2D</b> Drive-to-drive link		
	B	Master/follower, drive-to-drive or embedded fieldbus interface connection
	A	
	BGND	
<b>XRO1, XRO2, XRO3</b> Relay outputs		

Connection	Term	Description
	NC	<b>Ready run</b>
	COM	250 V AC / 30 V DC
	NO	2 A
	NC	<b>Running</b>
	COM	250 V AC / 30 V DC
	NO	2 A
	NC	<b>Fault (-1)</b>
	COM	250 V AC / 30 V DC
	NO	2 A
<b>XD24 Digital interlock</b>		
	DIIL	Run enable
	+24VD	+24 V DC 200 mA
	DICOM	Digital input ground
	+24VD	+24 V DC 200 mA
	DIOGND	Digital input/output ground
<b>XDIO Digital input/outputs</b>		
	DIO1	Output: Ready run
	DIO2	Output: Running
<b>XDI Digital inputs</b>		
	DI1	Stop (0) / Start (1)
	DI2	Forward (0) / Reverse (1)
	DI3	Acc/Dec time set 1 (0) / set 2 (1)
	DI4	Constant speed selection (see page 129)
	DI5	
	DI6	
<b>XSTO</b>	Safe torque off circuits must be closed for the drive to start. See <i>Hardware manual</i> of drive.	
<b>X12</b>	Safety options connection	
<b>X13</b>	Control panel connection	
<b>X205</b>	Memory unit connection	

## **Fieldbus control macro**

This application macro is not supported by the current firmware version.



# Parameters

---

## What this chapter contains

The chapter describes the parameters, including actual signals, of the control program.

---

## Terms and abbreviations

Term	Definition
Actual signal	Type of parameter that is the result of a measurement or calculation by the drive, or contains status information. Most actual signals are read-only, but some (especially counter-type actual signals) can be reset.
Def	<p>(In the following table, shown on the same row as the parameter name) The default value of a parameter when used in the Factory macro. For information on other macro-specific parameter values, see chapter Application macros.</p> <p><b>Note:</b> Certain configurations or optional equipment may require specific default values.</p> <p>These are labelled as follows:            (95.20 bx) = Default changed or write-protected by parameter 95.20, bit x.</p>
FbEq 16b / 32b	<p>(In the following table, shown on the same row as the parameter range, or for each selection)</p> <p>The scaling between the integer used in communication and the value shown on the panel when a 16-bit value is selected for transmission to an external system. The scaling is indicated for both 16-bit and 32-bit values.</p>
Other	<p>The value is taken from another parameter.</p> <p>Choosing “Other” displays a parameter list in which the user can specify the source parameter.</p> <p><b>Note:</b> The source parameter must be of the real32 (32-bit floating point) type. To use a 16-bit integer (for example, received from an external device in data sets) as the source, data storage parameters 47.01...47.08 can be used.</p>
Other [bit]	<p>The value is taken from a specific bit in another parameter.</p> <p>Choosing “Other” displays a parameter list in which the user can specify the source parameter and bit.</p>
Parameter	Either a user-adjustable operating instruction for the drive, or an actual signal.
p.u.	Per unit
[parameter number in square brackets]	The value of the parameter.

## Parameter group summary

Group	Contents	Page
1 Actual values	Basic signals for monitoring the drive.	138
3 Input references	Values of references received from various sources.	144
4 Warnings and faults	Information on warnings and faults that occurred last.	146
5 Diagnostics	Various run-time-type counters and measurements related to drive maintenance.	159
6 Control and status words	Drive control and status words.	161
7 System info	Information on drive hardware, firmware and application program.	178
10 Standard DI, RO	Configuration of digital inputs and relay outputs.	182
11 Standard DIO, FI, FO	Configuration of digital input/outputs and frequency inputs/outputs.	191
12 Standard AI	Configuration of standard analog inputs.	199
13 Standard AO	Configuration of standard analog outputs.	205
14 I/O extension module 1	Configuration of I/O extension module 1.	211
15 I/O extension module 2	Configuration of I/O extension module 2.	239
16 I/O extension module 3	Configuration of I/O extension module 3.	245
19 Operation mode	Selection of local and external control location sources and operating modes.	251
20 Start/stop/direction	Start/stop/direction and run/start/jog enable signal source selection; positive/negative reference enable signal source selection.	254
21 Start/stop mode	Start and stop modes; emergency stop mode and signal source selection; DC magnetization settings; autophasing mode selection.	267
22 Speed reference selection	Speed reference selection; motor potentiometer settings.	278
23 Speed reference ramp	Speed reference ramp settings (programming of the acceleration and deceleration rates for the drive).	288
24 Speed reference conditioning	Speed error calculation; speed error window control configuration; speed error step.	295
25 Speed control	Speed controller settings.	302
26 Torque reference chain	Settings for the torque reference chain.	314
28 Frequency reference chain	Settings for the frequency reference chain.	323
29 Voltage reference chain	Settings for the DC voltage reference chain.	333

## 136 Parameters

<b>Group</b>	<b>Contents</b>	<b>Page</b>
30 Limits	Drive operation limits.	338
31 Fault functions	Configuration of external events; selection of behavior of the drive upon fault situations.	349
32 Supervision	Configuration of signal supervision functions 1...3.	362
33 Generic timer & counter	Configuration of maintenance timers/counters.	366
35 Motor thermal protection	Motor thermal protection settings such as temperature measurement configuration, load curve definition and motor fan control configuration.	375
36 Load analyzer	Peak value and amplitude logger settings.	390
37 User load curve	Settings for user load curve.	395
40 Process PID set 1	Parameter values for process PID control.	399
41 Process PID set 2	A second set of parameter values for process PID control.	414
43 Brake chopper	Settings for the internal brake chopper.	417
44 Mechanical brake control	Configuration of mechanical brake control.	420
45 Energy efficiency	Settings for the energy saving calculators.	426
46 Monitoring/scaling settings	Speed supervision settings; actual signal filtering; general scaling settings.	430
47 Data storage	Data storage parameters that can be written to and read from using other parameters' source and target settings.	435
49 Panel port communication	Communication settings for the control panel port on the drive.	438
50 Fieldbus adapter (FBA)	Fieldbus communication configuration.	442
51 FBA A settings	Fieldbus adapter A configuration.	452
52 FBA A data in	Selection of data to be transferred from drive to fieldbus controller through fieldbus adapter A.	454
53 FBA A data out	Selection of data to be transferred from fieldbus controller to drive through fieldbus adapter A.	455
54 FBA B settings	Fieldbus adapter B configuration.	456
55 FBA B data in	Selection of data to be transferred from drive to fieldbus controller through fieldbus adapter B.	458
56 FBA B data out	Selection of data to be transferred from fieldbus controller to drive through fieldbus adapter B.	459
58 Embedded fieldbus	Configuration of the embedded fieldbus (EFB) interface.	460
60 DDCS communication	DDCS communication configuration.	470



<b>Group</b>	<b>Contents</b>	<b>Page</b>
61 D2D and DDCS transmit data	Defines the data sent to the DDCS link.	488
62 D2D and DDCS receive data	Mapping of data received through the DDCS link.	494
90 Feedback selection	Motor and load feedback configuration.	505
91 Encoder module settings	Configuration of encoder interface modules.	516
92 Encoder 1 configuration	Settings for encoder 1.	520
93 Encoder 2 configuration	Settings for encoder 2.	527
94 LSU control	Control of the supply unit of the drive, such as DC voltage and reactive power reference.	529
95 HW configuration	Various hardware-related settings.	533
96 System	Language selection; access levels; macro selection; parameter save and restore; control unit reboot; user parameter sets; unit selection; data logger triggering; parameter checksum calculation; user lock.	543
97 Motor control	Motor model settings.	555
98 User motor parameters	Motor values supplied by the user that are used in the motor model.	561
99 Motor data	Motor configuration settings.	564
200 Safety	FSO-xx settings.	572
206 I/O bus configuration	Distributed I/O bus settings.	572
207 I/O bus service	Distributed I/O bus settings.	573
208 I/O bus diagnostics	Distributed I/O bus settings.	573
209 I/O bus fan identification	Distributed I/O bus settings.	573

## Parameter listing

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
<b>1</b>	Actual values	Basic signals for monitoring the drive. All parameters in this group are read-only unless otherwise noted.	
1.1	Motor speed used	Measured or estimated motor speed depending on which type of feedback is used (see parameter <a href="#">90.41 Motor feedback selection</a> ). A filter time constant for this signal can be defined by parameter <a href="#">46.11 Filter time motor speed</a> .	- / real32
	-30000.00 ... 30000.00 rpm	Measured or estimated motor speed. For 16-bit scaling, see parameter <a href="#">46.1</a> .	- / 100 = 1 rpm
1.2	Motor speed estimated	Estimated motor speed in rpm. A filter time constant for signal can be defined by parameter <a href="#">46.11 Filter time motor speed</a> .	- / real32
	-30000.00 ... 30000.00 rpm	Estimated motor speed. For 16-bit scaling, see parameter <a href="#">46.1</a> .	- / 100 = 1 rpm
1.3	Motor speed %	Shows the value of <a href="#">1.1 Motor speed used</a> in percent of the synchronous speed of the motor.	- / real32
	-1000.00 ... 1000.00 %	Measured or estimated motor speed. For 16-bit scaling, see parameter <a href="#">46.1</a> .	- / 100 = 1 %
1.4	Encoder 1 speed filtered	Speed of encoder 1 in rpm. A filter time constant for this signal can be defined by parameter <a href="#">46.11 Filter time motor speed</a> .	- / real32
	-30000.00 ... 30000.00 rpm	Encoder 1 speed. For 16-bit scaling, see parameter <a href="#">46.1</a> .	- / 100 = 1 rpm
1.5	Encoder 2 speed filtered	Speed of encoder 2 in rpm. A filter time constant for this signal can be defined by parameter <a href="#">46.11 Filter time motor speed</a> .	- / real32
	-30000.00 ... 30000.00 rpm	Encoder 2 speed. For 16-bit scaling, see parameter <a href="#">46.1</a> .	- / 100 = 1 rpm
1.6	Output frequency	Estimated drive output frequency in Hz. A filter time constant for this signal can be defined by parameter <a href="#">46.12 Filter time output frequency</a> .	- / real32
	-600.00 ... 600.00 Hz	Estimated output frequency. For 16-bit scaling, see parameter <a href="#">46.2</a> .	- / 100 = 1 Hz
1.7	Motor current	Measured (absolute) motor current in A.	- / real32
	0.00 ... 30000.00 A	Motor current. For 16-bit scaling, see parameter <a href="#">46.5</a> .	- / 100 = 1 A
1.8	Motor current % of motor nom	Motor current (drive output current) in percent of the nominal motor current.	- / real32
	0.0 ... 1000.0 %	Motor current.	1 = 1 % / 10 = 1 %
1.10	Motor torque	Motor torque in percent of the nominal motor torque. See also parameter <a href="#">1.30 Nominal torque scale</a> . A filter time constant for this signal can be defined by parameter <a href="#">46.13 Filter time motor torque</a> .	- / real32

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	-1600.0 ... 1600.0 %	Motor torque. For 16-bit scaling, see parameter 46.3.	- / 10 = 1 %
1.11	DC voltage	Measured DC link voltage.	- / real32
	0.00 ... 2000.00 V	DC link voltage.	10 = 1 V / 100 = 1 V
1.13	Output voltage	Calculated motor voltage in V AC.	- / real32
	0...2000 V	Motor voltage.	1 = 1 V / 1 = 1 V
1.14	Output power	Drive output power. The unit is selected by parameter 96.16 Unit selection. A filter time constant for this signal can be defined by parameter 46.14 Filter time power out.	- / real32
	-32768.00 ... 32767.00 kW	Output power. For 16-bit scaling, see parameter 46.4.	- / 100 = 1 kW
1.15	Output power % of motor nom	Shows the value of 1.14 Output power in percent of the nominal power of the motor.	- / real32
	-300.00 ... 300.00 %	Output power.	10 = 1 % / 100 = 1 %
1.17	Motor shaft power	Estimated mechanical power at motor shaft. The unit is selected by parameter 96.16 Unit selection. A filter time constant for this signal can be defined by parameter 46.14 Filter time power out.	- / real32
	-32768.00 ... 32767.00 kW or hp	Motor shaft power.	1 = 1 kW or hp / 100 = 1 kW or hp
1.18	Inverter GWh motoring	Amount of energy that has passed through the drive (towards the motor) in full gigawatt-hours. The minimum value is zero.	- / int16
	0...32767 GWh	Motoring energy in GWh.	1 = 1 GWh / 1 = 1 GWh
1.19	Inverter MWh motoring	Amount of energy that has passed through the drive (towards the motor) in full megawatt-hours. Whenever the counter rolls over, 1.18 Inverter GWh motoring is incremented. The minimum value is zero.	- / int16
	0...1000 MWh	Motoring energy in MWh.	1 = 1 MWh / 1 = 1 MWh
1.20	Inverter kWh motoring	Amount of energy that has passed through the drive (towards the motor) in full kilowatt-hours. Whenever the counter rolls over, 1.19 Inverter MWh motoring is incremented. The minimum value is zero.	- / real32
	0...1000 kWh	Motoring energy in kWh.	10 = 1 kWh / 1 = 1 kWh
1.21	U-phase current	Measured U-phase current.	- / real32
	-30000.00 ... 30000.00 A	U-phase current. For 16-bit scaling, see parameter 46.5.	- / 100 = 1 A
1.22	V-phase current	Measured V-phase current.	- / real32
	-30000.00 ... 30000.00 A	V-phase current. For 16-bit scaling, see parameter 46.5.	- / 100 = 1 A
1.23	W-phase current	Measured W-phase current.	- / real32

# 140 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	-30000.00 ... 30000.00 A	W-phase current. For 16-bit scaling, see parameter <a href="#">46.5</a> .	- / 100 = 1 A
1.24	Flux actual %	Used flux reference in percent of nominal flux of motor.	- / real32
	0...200 %	Flux reference.	1 = 1 % / 1 = 1 %
1.25	INU momentary cos φ	Momentary cosphi of the drive.	0.00 / real32
	-1.00 ... 1.00	Cosphi.	100 = 1 / 100 = 1
1.29	Speed change rate	Rate of actual speed change. Positive values indicate acceleration, negative values indicate deceleration.  See also parameters <a href="#">31.32 Emergency ramp supervision</a> , <a href="#">31.33 Emergency ramp supervision delay</a> , <a href="#">31.37 Ramp stop supervision</a> and <a href="#">31.38 Ramp stop supervision delay</a> .	- / real32
	-15000...15000 rpm/s	Rate of speed change.	1 = 1 rpm/s / 1 = 1 rpm/s
1.30	Nominal torque scale	Torque that corresponds to 100% of nominal motor torque. The unit is selected by parameter <a href="#">96.16 Unit selection</a> .  <b>Note:</b> This value is copied from parameter <a href="#">99.12 Motor nominal torque</a> if entered. Otherwise the value is calculated from other motor data.	0.000 Nm or lb-ft / uint32
	0.000 ... 4000000.000 Nm or lb-ft	Nominal torque.	1 = 1 Nm or lb-ft / 1000 = 1 Nm or lb-ft
1.31	Ambient temperature	Measured temperature of incoming cooling air. The unit (°C or °F) is selected by parameter <a href="#">96.16 Unit selection</a> .	- / real32
	-40.0 ... 200.0 °	Cooling air temperature.	1 = 1 ° / 10 = 1 °
1.32	Inverter GWh regenerating	Amount of energy that has passed through the drive (towards the supply) in full gigawatt-hours. The minimum value is zero.	- / int16
	0...32767 GWh	Regenerative energy in GWh.	1 = 1 GWh / 1 = 1 GWh
1.33	Inverter MWh regenerating	Amount of energy that has passed through the drive (towards the supply) in full megawatt-hours. Whenever the counter rolls over, <a href="#">1.32 Inverter GWh regenerating</a> is incremented. The minimum value is zero.	- / int16
	0...1000 MWh	Regenerative energy in MWh.	1 = 1 MWh / 1 = 1 MWh
1.34	Inverter kWh regenerating	Amount of energy that has passed through the drive (towards the supply) in full kilowatt-hours. Whenever the counter rolls over, <a href="#">1.33 Inverter MWh regenerating</a> is incremented. The minimum value is zero.	- / real32
	0...1000 kWh	Regenerative energy in kWh.	10 = 1 kWh / 1 = 1 kWh

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
1.35	Mot - regen energy GWh (resettable)	Amount of net energy (motoring energy - regenerating energy) that has passed through the drive in full gigawatt hours.  You can reset the value by setting it to zero. Resetting any of the parameters 1.35 to 1.37 resets all.	0 GWh / int16
	-32768...32767 GWh	Energy balance in GWh.	1 = 1 GWh / 1 = 1 GWh
1.36	Mot - regen energy MWh (resettable)	Amount of net energy (motoring energy - regenerating energy) that has passed through the drive in full megawatt hours. Whenever the counter rolls over, 1.35 Mot - regen energy GWh (resettable) is incremented or decremented.  You can reset the value by setting it to zero. Resetting any of the parameters 1.35 to 1.37 resets all.	0 MWh / int16
	-1000...1000 MWh	Energy balance in MWh.	1 = 1 MWh / 1 = 1 MWh
1.37	Mot - regen energy kWh (resettable)	Amount of energy (motoring energy - regenerating energy) that has passed through the drive in full kilowatt-hours.  Whenever the counter rolls over, 1.36 Mot - regen energy MWh (resettable) is incremented or decremented.  You can reset the value by setting it to zero. Resetting any of the parameters 1.35 to 1.37 resets all.	0 kWh / real32
	-1000...1000 kWh	Energy balance in kWh.	10 = 1 kWh / 1 = 1 kWh
1.61	Abs motor speed used	Absolute value of 1.1 Motor speed used.	- / real32
	0.00 ... 30000.00 rpm	Measured or estimated motor speed. For 16-bit scaling, see parameter 46.1.	- / 100 = 1 rpm
1.62	Abs motor speed %	Absolute value of 1.3 Motor speed %.	- / real32
	0.00 ... 1000.00 %	Measured or estimated motor speed.	10 = 1 % / 100 = 1 %
1.63	Abs output frequency	Absolute value of 1.6 Output frequency.	- / real32
	0.00 ... 600.00 Hz	Estimated output frequency. For 16-bit scaling, see parameter 46.2.	- / 100 = 1 Hz
1.64	Abs motor torque	Absolute value of 1.10 Motor torque.	- / real32
	0.0 ... 1600.0 %	Motor torque. For 16-bit scaling, see parameter 46.3.	- / 10 = 1 %
1.65	Abs output power	Absolute value of 1.14 Output power.	- / real32
	0.00 ... 32767.00 kW or hp	Output power.	1 = 1 kW or hp / 100 = 1 kW or hp
1.66	Abs output power % motor nom	Absolute value of 1.15 Output power % of motor nom.	- / real32
	0.00 ... 300.00 %	Output power.	10 = 1 % / 100 = 1 %
1.68	Abs motor shaft power	Absolute value of 1.17 Motor shaft power.	- / real32

## 142 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	0.00 ... 32767.00 kW or hp	Motor shaft power.	1 = 1 kW or hp / 100 = 1 kW or hp
1.70	Ambient temperature %	Measured temperature of incoming cooling air.  The amplitude range of 0...100 % corresponds to 0...60 °C or 32...140 °F.  See also <a href="#">1.31 Ambient temperature</a> .	0.00 % / real32
	-200.00 ... 200.00 %	Cooling air temperature.	1 = 1 % / 100 = 1 %
1.71	Step-up motor current	Estimated motor current in A when a step-up transformer is in use. The value is calculated from parameter <a href="#">1.7</a> using the step-up transformer ratio ( <a href="#">95.40</a> ) and sine filter values <a href="#">99.18</a> and <a href="#">99.19</a> .	- / real32
	0.00 ... 30000.00 A	Estimated motor current. For 16-bit scaling, see parameter <a href="#">46.5</a> .	- / 100 = 1 A
1.72	U-phase RMS current	U-phase rms current.	- / real32
	0.00 ... 30000.00 A	U-phase rms current. For 16-bit scaling, see parameter <a href="#">46.5</a> .	- / 100 = 1 A
1.73	V-phase RMS current	V-phase rms current.	- / real32
	0.00 ... 30000.00 A	V-phase rms current. For 16-bit scaling, see parameter <a href="#">46.5</a> .	- / 100 = 1 A
1.74	W-phase RMS current	W-phase rms current.	- / real32
	0.00 ... 30000.00 A	W-phase rms current. For 16-bit scaling, see parameter <a href="#">46.5</a> .	- / 100 = 1 A
1.102	Line current	<i>(Only visible when IGBT supply unit control activated by <a href="#">95.20</a>)</i>  Estimated line current flowing through the supply unit.	- / real32
	0.00 ... 30000.00 A	Estimated line current. For 16-bit scaling, see parameter <a href="#">46.5</a> .	- / 100 = 1 A
1.104	Active current	<i>(Only visible when IGBT supply unit control activated by <a href="#">95.20</a>)</i>  Estimated active current flowing through the supply unit.	- / real32
	-30000.00 ... 30000.00 A	Estimated active current. For 16-bit scaling, see parameter <a href="#">46.5</a> .	- / 100 = 1 A
1.106	Reactive current	<i>(Only visible when IGBT supply unit control activated by <a href="#">95.20</a>)</i>  Estimated reactive current flowing through the supply unit.	- / real32
	-30000.00 ... 30000.00 A	Estimated reactive current. For 16-bit scaling, see parameter <a href="#">46.5</a> .	- / 100 = 1 A

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
1.108	Grid frequency	<i>(Only visible when IGBT supply unit control activated by 95.20)</i> Estimated frequency of the power supply network.	- / real32
	0.00 ... 100.00 Hz	Estimated supply frequency. For 16-bit scaling, see parameter 46.2.	- / 100 =1 Hz
1.109	Grid voltage	<i>(Only visible when IGBT supply unit control activated by 95.20)</i> Estimated voltage of the power supply network.	- / real32
	0.00 ... 2000.00 V	Estimated supply voltage.	10 = 1 V / 100 = 1 V
1.110	Grid apparent power	<i>(Only visible when IGBT supply unit control activated by 95.20)</i> Estimated apparent power being transferred through the supply unit.	- / real32
	-30000.00 ... 30000.00 kVA	Estimated apparent power. For 16-bit scaling, see parameter 46.4.	- / 100 = 1 kVA
1.112	Grid power	<i>(Only visible when IGBT supply unit control activated by 95.20)</i> Estimated power being transferred through the supply unit.	- / real32
	-30000.00 ... 30000.00 kW	Estimated supply power. For 16-bit scaling, see parameter 46.4.	- / 100 =1 kW
1.114	Grid reactive power	<i>(Only visible when IGBT supply unit control activated by 95.20)</i> Estimated reactive power being transferred through the supply unit.	- / real32
	-30000.00 ... 30000.00 kVAr	Estimated reactive power.	10 = 1 kVAr / 100 = 1 kVAr
1.116	LSU cos $\phi$	<i>(Only visible when IGBT supply unit control activated by 95.20)</i> Power factor of the supply unit.	- / real32
	-1.00 ... 1.00	Power factor.	100 = 1 / 100 = 1
1.164	LSU nominal power	<i>(Only visible when IGBT supply unit control activated by 95.20)</i> Nominal power of the supply unit.	- / real32
	0...30000 kW	Nominal power.	1 = 1 kW / 1 = 1 kW

## 144 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
<b>3</b>	Input references	Values of references received from various sources. All parameters in this group are read-only unless otherwise noted.	
3.1	Panel reference	Local reference given from the control panel or PC tool.	0.00 / real32
	-100000.00 ... 100000.00	Local control panel or PC tool reference.	10 = 1 / 100 = 1
3.2	Panel reference 2	Remote reference given from the control panel or PC tool.	- / real32
	-30000.00 ... 30000.00	Remote control panel or PC tool reference.	10 = 1 / 100 = 1
3.5	FB A reference 1	Reference 1 received through fieldbus adapter A. See also chapter Fieldbus control through a fieldbus adapter.	0.00 / real32
	-100000.00 ... 100000.00	Reference 1 from fieldbus adapter A.	10 = 1 / 100 = 1
3.6	FB A reference 2	Reference 2 received through fieldbus adapter A.	0.00 / real32
	-100000.00 ... 100000.00	Reference 2 from fieldbus adapter A.	10 = 1 / 100 = 1
3.7	FB B reference 1	Reference 1 received through fieldbus adapter B.	0.00 / real32
	-100000.00 ... 100000.00	Reference 1 from fieldbus adapter B.	10 = 1 / 100 = 1
3.8	FB B reference 2	Reference 2 received through fieldbus adapter B.	0.00 / real32
	-100000.00 ... 100000.00	Reference 2 from fieldbus adapter B.	10 = 1 / 100 = 1
3.9	EFB reference 1	Scaled reference 1 received through the embedded fieldbus interface. The scaling is defined by <a href="#">58.26 EFB ref1 type</a> .	- / real32
	-30000.00 ... 30000.00	Reference 1 received through the embedded fieldbus interface.	10 = 1 / 100 = 1
3.10	EFB reference 2	Scaled reference 2 received through the embedded fieldbus interface. The scaling is defined by <a href="#">58.27 EFB ref2 type</a> .	- / real32
	-30000.00 ... 30000.00	Reference 2 received through the embedded fieldbus interface.	10 = 1 / 100 = 1
3.11	DDCS controller ref 1	Reference 1 received from the external (DDCS) controller. The value has been scaled according to parameter <a href="#">60.60 DDCS controller ref1 type</a> . See also section <a href="#">External controller interface</a> .	- / real32
	-30000.00 ... 30000.00	Scaled reference 1 received from external controller.	10 = 1 / 100 = 1



No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
3.12	DDCS controller ref 2	Reference 2 received from the external (DDCS) controller.  The value has been scaled according to parameter <a href="#">60.61 DDCS controller ref2 type</a> .	- / real32
	-30000.00 ... 30000.00	Scaled reference 2 received from external controller.	10 = 1 / 100 = 1
3.13	M/F or D2D ref1	Master/follower reference 1 received from the master. The value has been scaled according to parameter <a href="#">60.10 M/F ref1 type</a> .  See also section <a href="#">Master/follower functionality</a> .	- / real32
	-30000.00 ... 30000.00	Scaled reference 1 received from master.	10 = 1 / 100 = 1
3.14	M/F or D2D ref2	Master/follower reference 2 received from the master. The value has been scaled according to parameter <a href="#">60.11 M/F ref2 type</a> .	- / real32
	-30000.00 ... 30000.00	Scaled reference 2 received from master.	10 = 1 / 100 = 1
3.30	FB A reference 1 int32	Reference 1 received through fieldbus adapter A as a 32-bit integer.	- / int32
		Reference 1 from fieldbus adapter A.	- / -
3.31	FB A reference 2 int32	Reference 2 received through fieldbus adapter A as a 32-bit integer.	- / int32
		Reference 2 from fieldbus adapter A.	- / -
3.51	IEC application panel reference	Panel reference defined in the application program.	0 / real32
	-100000...100000	Panel reference in the application program.	1 = 1 / 1 = 1

# 146 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
4	Warnings and faults	Information on warnings and faults that occurred last. For explanations of individual warning and fault codes, see chapter Fault tracing. All parameters in this group are read-only unless otherwise noted.	
4.1	Tripping fault	Code of the 1st active fault (the fault that caused the current trip).	0 / uint16
	0000...FFFFh	1st active fault.	1 = 1
4.2	Active fault 2	Code of the 2nd active fault.	0 / uint16
	0000...FFFFh	2nd active fault.	1 = 1
4.3	Active fault 3	Code of the 3rd active fault.	0 / uint16
	0000...FFFFh	3rd active fault.	1 = 1
4.4	Active fault 4	Code of the 4th active fault.	0 / uint16
	0000...FFFFh	4th active fault.	1 = 1
4.5	Active fault 5	Code of the 5th active fault.	0 / uint16
	0000...FFFFh	5th active fault.	1 = 1
4.6	Active warning 1	Code of the 1st active warning.	0 / uint16
	0000...FFFFh	1st active warning.	1 = 1
4.7	Active warning 2	Code of the 2nd active warning.	0 / uint16
	0000...FFFFh	2nd active warning.	1 = 1
4.8	Active warning 3	Code of the 3rd active warning.	0 / uint16
	0000...FFFFh	3rd active warning.	1 = 1
4.9	Active warning 4	Code of the 4th active warning.	0 / uint16
	0000...FFFFh	4th active warning.	1 = 1
4.10	Active warning 5	Code of the 5th active warning.	0 / uint16
	0000...FFFFh	5th active warning.	1 = 1
4.11	Latest fault	Code of the 1st stored (non-active) fault.	0 / uint16
	0000...FFFFh	1st stored fault.	1 = 1
4.12	2nd latest fault	Code of the 2nd stored (non-active) fault.	0 / uint16
	0000...FFFFh	2nd stored fault.	1 = 1
4.13	3rd latest fault	Code of the 3rd stored (non-active) fault.	0 / uint16
	0000...FFFFh	3rd stored fault.	1 = 1
4.14	4th latest fault	Code of the 4th stored (non-active) fault.	0 / uint16
	0000...FFFFh	4th stored fault.	1 = 1
4.15	5th latest fault	Code of the 5th stored (non-active) fault.	0 / uint16

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	0000...FFFFh	5th stored fault.	1 = 1
4.16	Latest warning	Code of the 1st stored (non-active) warning.	0 / uint16
	0000...FFFFh	1st stored warning.	1 = 1
4.17	2nd latest warning	Code of the 2nd stored (non-active) warning.	0 / uint16
	0000...FFFFh	2nd stored warning.	1 = 1
4.18	3rd latest warning	Code of the 3rd stored (non-active) warning.	0 / uint16
	0000...FFFFh	3rd stored warning.	1 = 1
4.19	4th latest warning	Code of the 4th stored (non-active) warning.	0 / uint16
	0000...FFFFh	4th stored warning.	1 = 1
4.20	5th latest warning	Code of the 5th stored (non-active) warning.	0 / uint16
	0000...FFFFh	5th stored warning.	1 = 1

# 148 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
4.21	Fault word 1	<p>ACS800-compatible fault word 1.</p> <p>The bit assignments of this word correspond to FAULT WORD 1 in the ACS800. Parameter <a href="#">4.120 Fault/Warning word compatibility</a> determines whether the bit assignments are according to the ACS800 Standard or ACS800 System control program.</p> <p>Each bit can indicate several ACS880 events as listed below.</p> <p>This parameter is read-only.</p>	- / uint16

No.	Name / Range / Selection	Description			Def / Type FbEq 16b / 32b
		Bit	ACS800 fault name		ACS880 events indicated by this bit see Fault tracing(page575).
			(4.120 = ACS800 Standard ctrl program)	(4.120 = ACS800 System ctrl program)	
		0	SHORT CIRC	SHORT CIRC	2340
		1	OVERCURRENT	OVERCURRENT	2310
		2	DC OVERVOLT	DC OVERVOLT	3210
		3	ACS800 TEMP	ACS800 TEMP	2381, 4210, 4290, 42F1, 4310, 4380
		4	EARTH FAULT	EARTH FAULT	2330, 2392, 3181
		5	THERMISTOR	MOTOR TEMP M	4981, 4991, 4992, 4993
		6	MOTOR TEMP	MOTOR TEMP	4982
		7	SYSTEM_FAULT	SYSTEM_FAULT	6481, 6487, 64A1, 64A2, 64A3, 64B1, 64E1, 6881, 6882, 6883, 6885
		8	UNDERLOAD	UNDERLOAD	-
		9	OVERFREQ	OVERFREQ	7310
		10	Reserved	MPROT SWITCH	9081
		11	Reserved	CH2 COMM LOSS	7582
		12	Reserved	SC (INU1)	2340 (XXYY YY01)
		13	Reserved	SC (INU2)	2340 (XXYY YY02)
		14	Reserved	SC (INU3)	2340 (XXYY YY03)
		15	Reserved	SC (INU4)	2340 (XXYY YY04)

## 150 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
4.22	Fault word 2	<p>ACS800-compatible fault word 2.</p> <p>The bit assignments of this word correspond to FAULT WORD 2 in the ACS800. Parameter <a href="#">4.120 Fault/Warning word compatibility</a> determines whether the bit assignments are according to the ACS800 Standard or ACS800 System control program.</p> <p>Each bit can indicate several ACS880 events as listed below.</p> <p>This parameter is read-only.</p>	- / uint16

No.	Name / Range / Selection	Description			Def / Type FbEq 16b / 32b
		Bit	ACS800 fault name		ACS880 events indicated by this bit (see Fault tracing(page575))
			(4.120 = ACS800 Standard ctrl program)	(4.120 = ACS800 System ctrl program)	
		0	SUPPLY PHASE	SUPPLY PHASE	3130
		1	NO MOT DATA	NO MOTOR DATA	-
		2	DC UNDER-VOLT	DC UNDER-VOLT	3220
		3	Reserved	CABLE TEMP	4000
		4	RUN EN-ABLE	RUN DIS-ABLE	AFEB
		5	ENCODER ERR	ENCODER ERR	7301, 7380, 7381, 73A0, 73A1
		6	I/O COMM	IO COMM ERR	7080, 7082
		7	CTRL B TEMP	CTRL B TEMP	-
		8	EXTERNAL FLT	SELECT-ABLE	9082
		9	OVER SW-FREQ	OVER SW-FREQ	-
		10	AI < MIN FUNC	AI<MIN FUNC	80A0
		11	PPCC LINK	PPCC LINK	5681, 5682, 5690, 5691, 5692, 5693, 5694, 5695
		12	COMM MODULE	COMM MODULE	6681, 7510, 7520, 7581
		13	PANEL LOSS	PANEL LOSS	7081
		14	MOTOR STALL	MOTOR STALL	7121
		15	MOTOR PHASE	MOTOR PHASE	3381

## 152 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
4.25	Faulted modules	<p><i>(Only visible with a BCU control unit)</i></p> <p>Indicates which parallel-connected modules have faulted.</p> <p>The bits of this word are cleared when all faults have been reset.</p> <p>This parameter is read-only.</p>	0000h / uint16
b0	Module 1	1 = Module 1 faulted	
b1	Module 2	1 = Module 2 faulted	
b2	Module 3	1 = Module 3 faulted.	
b3	Module 4	1 = Module 4 faulted.	
b4	Module 5	1 = Module 5 faulted.	
b5	Module 6	1 = Module 6 faulted.	
b6	Module 7	1 = Module 7 faulted.	
b7	Module 8	1 = Module 8 faulted.	
b8	Module 9	1 = Module 9 faulted.	
b9	Module 10	1 = Module 10 faulted.	
b10	Module 11	1 = Module 11 faulted.	
b11	Module 12	1 = Module 12 faulted.	
b12...15	Reserved		
	0000h...FFFFh		1 = 1 / 1 = 1



No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
4.31	Warning word 1	<p>ACS800-compatible warning (alarm) word 1.</p> <p>The bit assignments of this word correspond to ALARM WORD 1 in the ACS800. Parameter <a href="#">4.120 Fault/Warning word compatibility</a> determines whether the assignments are according to the ACS800 Standard or ACS800 System control program.</p> <p>Each may indicate several ACS880 warnings as listed below.</p> <p>This parameter is read-only.</p>	- / uint16

154 Parameters

No.	Name / Range / Selection	Description			Def / Type FbEq 16b / 32b
		Bit	ACS800 alarm name (4.120 = ACS800 Standard ctrl program)	(4.120 = ACS800 System ctrl program)	ACS880 events indicated by this bit (see Fault tracing(page575))
		0	STARTINHIBIT	STARTINHIBIT	A5A0
		1	Reserved	EM STOP	AFE1, AFE2
		2	THERMISTOR	MOTOR TEMP M	A491, A497, A498, A499
		3	MOTOR TEMP	MOTOR TEMP	A492
		4	ACS800 TEMP	ACS800 TEMP	A2BA, A4A9, A4B0, A4B1, A4F6
		5	ENCODER ERR	ENCODER ERR	A797, A7B0, A7B1, A7E1
		6	T MEAS ALM	T MEAS CIRC	A490, A5EA, A782, A8A0
		7	Reserved	DIGITAL IO	-
		8	Reserved	ANALOG IO	-
		9	Reserved	EXT DIGITAL IO	-
		10	Reserved	EXT ANALOG IO	A6E5, A7AA, A7AB
		11	Reserved	CH2 COMM LOSS	A7CB, AF80
		12	COMM MODULE	MPROT SWITCH	A981
		13	Reserved	EM STOP DEC	-
		14	EARTH FAULT	EARTH FAULT	A2B3
		15	Reserved	SAFETY SWITC	A983
0000h...FFFFh					1 = 1 / 1 = 1

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
4.32	Warning word 2	<p>ACS800-compatible warning (alarm) word 2.</p> <p>The bit assignments of this word correspond to ALARM WORD 2 in the ACS800. Parameter <a href="#">4.120 Fault/Warning word compatibility</a> determines whether the bit assignments are according to the ACS800 Standard or ACS800 System control program.</p> <p>Each may indicate several ACS880 warnings as listed below.</p> <p>This parameter is read-only.</p>	- / uint16

156 Parameters

No.	Name / Range / Selection	Description				Def / Type FbEq 16b / 32b
		Bit	ACS800 alarm name		ACS880 events indicated by this bit (see Fault tracing(page575))	
			(4.120 = ACS800 Standard ctrl program)	(4.120 = ACS800 System ctrl program)		
		0	Reserved	MOTORFAN	A781	
		1	UNDER-LOAD	UNDER-LOAD	-	
		2	Reserved	INV OVER-LOAD	-	
		3	Reserved	CABLE TEMP	A480	
		4	ENCODER	ENCODER A<>B	-	
		5	Reserved	FAN OVER-TEMP	A984	
		6	Reserved	Reserved	-	
		7	POWFAIL FILE	POWFAIL FILE	-	
		8	ALM (OS_17)	POWDOWN FILE	-	
		9	MOTOR STALL	MOTOR STALL	A780	
		10	AI < MIN FUNC	AI<MIN FUNC	A8A0	
		11	Reserved	COMM MODULE	A6D1, A6D2, A7C1, A7C2, A7CA, A7CE	
		12	Reserved	BATT FAILURE	-	
		13	PANEL LOSS	PANEL LOSS	A7EE	
		14	Reserved	DC UNDER-VOLT	A3A2	
		15	Reserved	RESTARTED	-	
	0000h...FFFFh					1 = 1 / 1 = 1

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
4.40	Event word 1	User-defined event word. This word collects the status of the events (warnings, faults or pure events) selected by parameters 4.41...4.72.  For each event, an auxiliary code can optionally be specified for filtering.  This parameter is read-only.	- / uint16
b0	User bit 0	1 = Event selected by parameters 4.41 Event word 1 bit 0 code (and 4.42 Event word 1 bit 0 aux code) is active is active	
b1	User bit 1	1 = Event selected by parameters 4.43 Event word 1 bit 1 code (and 4.44 Event word 1 bit 1 aux code) is active	
b15	User bit 15	1 = Event selected by parameters 4.71 (and 4.72) is active	
	0000h...FFFFh		1 = 1 / 1 = 1
4.41	Event word 1 bit 0 code	Selects the hexadecimal code of an event (warning, fault or pure event) whose status is shown as bit 0 of 4.40 Event word 1.	0 / uint16
	0000...FFFFh	Code of event.	1 = 1
4.42	Event word 1 bit 0 aux code	Specifies an auxiliary code for the event selected by the previous parameter. The selected event is indicated by the event word only if its auxiliary code matches the value of this parameter.  With a value of 0000 0000h, the event word will indicate the event regardless of the auxiliary code.	0000 0000h / uint32
	0000 0000h...FFFF FFFFh	Code of warning, fault or pure event.	1 = 1
4.43	Event word 1 bit 1 code	Selects the hexadecimal code of an event (warning, fault or pure event) whose status is shown as bit 1 of 4.40 Event word 1.	0000h / uint16
	0000...FFFFh	Code of event.	1 = 1
4.44	Event word 1 bit 1 aux code	Specifies an auxiliary code for the event selected by the previous parameter. The selected event is indicated by the event word only if its auxiliary code matches the value of this parameter.  With a value of 0000 0000h, the event word will indicate the event regardless of the auxiliary code.	0000 0000h / uint32
	0000 0000h...FFFF FFFFh	Code of warning, fault or pure event.	1 = 1
...	...	...	...
4.71	Event word 1 bit 15 code	Selects the hexadecimal code of an event (warning, fault or pure event) whose status is shown as bit 15 of 4.40 Event word 1.  The event codes are listed in chapter Fault tracing.	0000h / uint16
	0000...FFFFh	Code of event.	1 = 1

# 158 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
4.72	Event word 1 bit 15 aux code	<p>Specifies an auxiliary code for the event selected by the previous parameter. The selected event is indicated by the event word only if its auxiliary code matches the value of this parameter.</p> <p>With a value of 0000 0000h, the event word will indicate the event regardless of the auxiliary code.</p>	0000 0000h / uint32
	0000 0000h...FFFF FFFFh	Code of warning, fault or pure event.	1 = 1
4.120	Fault/Warning word compatibility	Selects whether the bit assignments of parameters <a href="#">4.21...</a> <a href="#">4.32</a> correspond to the ACS800 Standard control program or the ACS800 System control program.	ACS800 Standard ctrl program / uint16
	ACS800 Standard ctrl program	<p>The bit assignments of parameters <a href="#">4.21...</a><a href="#">4.32</a> correspond to the ACS800 Standard control program as follows:</p> <ul style="list-style-type: none"> <li>• <a href="#">4.21</a>: 03.05 FAULT WORD 1</li> <li>• <a href="#">4.22</a>: 03.06 FAULT WORD 2</li> <li>• <a href="#">4.31</a>: 03.08 ALARM WORD 1</li> <li>• <a href="#">4.32</a>: 03.09 ALARM WORD 2</li> </ul>	0
	ACS800 System ctrl program	<p>The bit assignments of parameters <a href="#">4.21...</a><a href="#">4.32</a> correspond to the ACS800 System control program as follows:</p> <ul style="list-style-type: none"> <li>• <a href="#">4.21</a>: 09.01 FAULT WORD 1</li> <li>• <a href="#">4.22</a>: 09.02 FAULT WORD 2</li> <li>• <a href="#">4.31</a>: 09.04 ALARM WORD 1</li> <li>• <a href="#">4.32</a>: 09.04 ALARM WORD 2</li> </ul>	1

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
5	Diagnostics	Various run-time-type counters and measurements related to drive maintenance.  All parameters in this group are read-only unless otherwise noted.	
5.1	On-time counter	On-time counter. The counter runs when the drive is powered.	0 d / uint16
	0...65535 d	On-time counter.	1 = 1 d / 1 = 1 d
5.2	Run-time counter	Motor run-time counter. The counter runs when the inverter modulates.	0 d / uint16
	0...65535 d	Motor run-time counter.	1 = 1 d / 1 = 1 d
5.4	Main fan on-time counter	Running time of the drive cooling fan. Can be reset from the control panel by keeping Reset depressed for over 3 seconds.	0 d / uint16
	0...65535 d	Cooling fan run-time counter.	1 = 1 d / 1 = 1 d
5.9	Time from power-up	500-microsecond ticks elapsed since the last boot of the control unit.	- / uint32
	0...4294967295	500-microsecond ticks since last boot.	1 = 1 / 1 = 1
5.10	Control board temperature	Displays the actual temperature on the control board surface.	- / real32
	-50...150°C	Board temperature in degrees Celsius.	1 = 1 °C / 1 = 1 °C
5.11	Inverter temperature	Estimated drive temperature in percent of fault limit. The actual trip temperature varies according to the type of the drive.  0.0 % = 0 °C (32 °F)  94 % approx. = Warning limit  100.0 % = Fault limit	- / real32
	-40.0 ... 160.0 %	Drive temperature in percent.	1 = 1 % / 10 = 1 %
5.22	Diagnostic word 3	Diagnostic word 3.	- / uint16
b0...10	Reserved		
	b11 Fan command	1 = Drive fan is rotating above idle speed	
	b12 Fan service counter	1 = Drive fan service counter has reached its limit	
b13...15	Reserved		
	0000h...FFFFh		1 = 1 / 1 = 1
5.41	Main fan service counter	Displays the age of the main cooling fan as a percentage of its estimated lifetime. The estimate is based on the duty, operating conditions and other operating parameters of the fan. When the counter reaches 100%, a warning ( <a href="#">A8C0 Fan service counter</a> ) is generated.  Can be reset from the control panel by keeping Reset depressed for over 3 seconds.	0 % / real32
	0...150 %	Main cooling fan age.	1 = 1 % / 1 = 1 %

## 160 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
5.42	Aux. fan service counter	Displays the age of the auxiliary cooling fan as a percentage of its estimated lifetime. The estimate is based on the duty, operating conditions and other operating parameters of the fan. When the counter reaches 100%, a warning (A8C0 Fan service counter) is generated.  Can be reset from the control panel by keeping Reset depressed for over 3 seconds.	0 % / real32
	0...150 %	Auxiliary cooling fan age.	1 = 1 % / 1 = 1 %
5.111	Line converter temperature	<i>(Only visible when IGBT supply unit control activated by 95.20)</i>  Estimated supply unit temperature in percent of fault limit.  0.0 % = 0 °C (32 °F)  94 % approx. = Warning limit  100.0 % = Fault limit	- / real32
	-40.0 ... 160.0 %	Supply unit temperature in percent.	1 = 1 % / 10 = 1 %
5.121	MCB closing counter	<i>(Only visible when IGBT supply unit control activated by 95.20)</i>  Counts the closures of the main circuit breaker of the supply unit.	- / uint32
	0...4294967295	Count of closures of main circuit breaker.	1 = 1 / 1 = 1



No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
6	Control and status words	Drive control and status words.	
6.1	Main control word	<p>The main control word of the drive. This parameter shows the control signals as received from the selected sources (such as digital inputs, the fieldbus interfaces and the application program).</p> <p>The bit assignments of the word are as described on page 659. The related status word and state diagram are presented on pages 661 and 662 respectively.</p> <p><b>Note:</b> This parameter is read-only.</p> <ul style="list-style-type: none"> <li>• Bits 12...15 can be used to carry additional control data, and used as a signal source by any binary-source selector parameter. Bit 10 must be active for bits 12...15 to update.</li> <li>• In fieldbus control, this parameter value is not exactly the same as the control word that the drive receives from the PLC. See parameter 50.12 FBA A debug mode.</li> </ul>	- / uint16
6.2	Application control word	<p>The drive control word received from the application program (if any). The bit assignments are described on page 659.</p> <p>This parameter is read-only.</p>	- / uint16
6.3	FBA A transparent control word	<p>Displays the unaltered control word received from the PLC through fieldbus adapter A when a transparent communication profile is selected eg. by parameter group 51 FBA A settings. See section Control word and Status word (page 656).</p> <p>This parameter is read-only.</p>	0 / uint32
	00000000..FFFFFFFFh	Control word received through fieldbus adapter A.	1 = 1
6.4	FBA B transparent control word	<p>Displays the unaltered control word received from the PLC through fieldbus adapter B when a transparent communication profile is selected eg. by parameter group 54 FBA B settings. See section Control word and Status word (page 656).</p> <p>This parameter is read-only.</p>	0 / uint32
	00000000..FFFFFFFFh	Control word received through fieldbus adapter B.	1 = 1
6.5	EFB transparent control word	<p>Displays the unaltered control word received from the PLC through the embedded fieldbus interface when a transparent communication profile is selected in parameter 58.25 Control profile. See section The Transparent profile (page 645).</p> <p>This parameter is read-only.</p>	0 / uint32
	00000000..FFFFFFFFh	Control word received through the embedded fieldbus interface.	1 = 1

## 162 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
6.11	Main status word	<p>Main status word of the drive.</p> <p>The bit assignments are described on page 661. The related control word and state diagram are presented on pages 659 and 662.</p> <p><b>Note:</b> In fieldbus control, this parameter value is not exactly the same as the status word that the drive sends to the PLC. See parameter 50.12 FBA A debug mode.</p> <p>This parameter is read-only.</p>	- / uint16
6.16	Drive status word 1	<p>Drive status word 1.</p> <p>This parameter is read-only.</p>	- / uint16
b0	Enabled	<p>1 = Both run enable (see par. 20.12) and start enable (20.19) signals are present, and Safe torque off has not been activated.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>In I/O or local control, clearing this bit makes the drive enter the SWITCH-ON INHIBITED state. For further information, see 661.</li> <li>This bit is not affected by the presence of a fault.</li> </ul>	
b1	Inhibited	1 = Start inhibited. See parameters 6.18 and 6.25 for the source of the inhibiting signal.	
b2	DC charged	<p>1 = DC circuit has been charged. If present, the DC switch is closed, and charging switch is open.</p> <p>0 = Charging not complete. If the inverter unit is not equipped with a DC switch (option +F286), check setting of 95.9.</p>	
b3	Ready to start	1 = Drive is ready to receive a start command	
b4	Following reference	1 = Drive is ready to follow given reference	
b5	Started	1 = Drive has been started	
b6	Modulating	1 = Drive is modulating (output stage is being controlled)	
b7	Limiting	1 = Any operating limit (speed, torque, etc.) is active	
b8	Local control	1 = Drive is in local control	
b9	Network control	1 = Drive is in network control. See <a href="#">Terms and abbreviations (page 18)</a> .	
b10	Ext1 active	1 = Control location EXT1 active	
b11	Ext2 active	1 = Control location EXT2 active	
b12	Reserved		
b13	Start request	<p>1 = Start requested</p> <p><b>Note:</b> At the time of publishing, a start request from the control panel does not activate this bit if any start-inhibiting condition (see bit 1) is present.</p>	

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
b14...15	Reserved		
	0000h...FFFFh		1 = 1 / 1 = 1
6.17	Drive status word 2	Drive status word 2. This parameter is read-only.	- / uint16
b0	Identification run done	1 = Motor identification (ID) run has been performed	
b1	Magnetized	1 = The motor has been magnetized	
b2	Torque control	1 = Torque control mode active	
b3	Speed control	1 = Speed control mode active	
b4	Voltage control	Reserved	
b5	Safe reference active	1 = A "safe" reference is being applied by functions such as parameters <a href="#">49.5</a> and <a href="#">50.2</a> .	
b6	Last speed active	1 = A "last speed" reference is being applied by functions such as parameters <a href="#">49.5</a> and <a href="#">50.2</a> .	
b7	Loss of reference	1 = Reference signal lost	
b8	Emergency stop failed	1 = Emergency stop failed (see parameters <a href="#">31.32</a> and <a href="#">31.33</a> ).	
b9	Jogging active	1 = Jogging enable signal is on	
b10	Above limit	1 = Actual speed, frequency or torque equals or exceeds limit (defined by parameters <a href="#">46.31</a> ... <a href="#">46.33</a> ). Valid in both directions of rotation.	
b11	Emergency stop active	1 = An emergency stop command signal is active, or the drive is stopping after receiving an emergency stop command.	
b12	Reduced run	1 = Reduced run active (see section <a href="#">Reduced run function (page 106)</a> ).	
b13	Reserved		
b14	Stop failed	1 = Stopping failed (see parameters <a href="#">31.37</a> and <a href="#">31.38</a> )	
b15	Reserved		
	0000h...FFFFh		1 = 1 / 1 = 1

## 164 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
6.18	Start inhibit status word	<p>Start inhibit status word. This word specifies the source of the inhibiting condition that is preventing the drive from starting.</p> <p>After the condition is removed, the start command must be cycled. See bit-specific notes.</p> <p>See also parameter <a href="#">6.25 Drive inhibit status word 2</a>, and <a href="#">6.16 Drive status word 1</a>, bit 1.</p> <p>This parameter is read-only.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>If bit 1 of <a href="#">6.16 Drive status word 1</a> is still set after the removal of the inhibiting condition, and edge triggering is selected for the active external control location, a fresh rising-edge start signal is required. See parameters <a href="#">20.2</a>, <a href="#">20.7</a> and <a href="#">20.19</a>.</li> <li>If bit 1 of <a href="#">6.16 Drive status word 1</a> is still set after the removal of the inhibiting condition, a fresh rising-edge start signal is required.</li> <li>Informative bit. The inhibiting condition need not be removed by the user.</li> </ul>	- / uint16
b0	Not ready run	1 = DC voltage is missing or drive has not been parameterized correctly. Check the parameters in groups <a href="#">95</a> and <a href="#">99</a> .	
b1	Ctrl location changed	1 = Control location has changed	
b2	SSW inhibit	1 = Control program is keeping itself in inhibited state	
b3	Fault	1 = A fault is active	
b4	Lost start enable	1 = Start enable signal missing	
b5	Lost run enable	1 = Run enable signal missing	
b6	FSO inhibit	1 = Operation prevented by FSO-xx safety functions module	
b7	STO	1 = Safe torque off active	
b8	Current calibration ended	1 = Current calibration routine has finished	
b9	ID run ended	1 = Motor identification run has finished	
b10	Auto phase ended	1 = Autophasing routine has finished	
b11	Off1	1 = Emergency stop signal (mode Off1)	
b12	Em Off2	1 = Emergency stop signal (mode Off2)	
b13	Em Off3	1 = Emergency stop signal (mode Off3)	
b14	Auto reset inhibit	1 = The autoreset function is inhibiting operation	
b15	Jogging active	1 = The jogging enable signal is inhibiting operation	
	0000h...FFFFh		1 = 1 / 1 = 1

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
6.19	Speed control status word	Speed control status word. This parameter is read-only.	- / uint16
b0	Zero speed	1 = Drive is running at zero speed, ie. the absolute value of par. <a href="#">90.1 Motor speed for control</a> has remained below <a href="#">21.6 Zero speed limit</a> for longer than <a href="#">21.7 Zero speed delay</a> .  <b>Note:</b> <ul style="list-style-type: none"> <li>This bit is not updated when mechanical brake control is enabled by par. <a href="#">44.6</a> and the drive is modulating.</li> <li>During a ramp stop when the drive is running forward, the delay count runs whenever <math>[90.1] &lt; [21.6]</math>. From the reverse direction, the delay count runs whenever <math>90.1 &gt; -[21.6]</math>.</li> </ul>	
b1	Forward	1 = Drive is running in forward direction above zero speed limit, ie. $[90.1] > +[21.6]$ .	
b2	Reverse	1 = Drive is running in reverse direction above zero speed limit, ie. $[90.1] < -[21.6]$ .	
b3	Out of window	1 = Speed error window control active (see par. <a href="#">24.41</a> )	
b4	Internal speed feedback	1 = Estimated speed feedback used in motor control, ie. estimated speed is selected by par. <a href="#">90.41</a> or <a href="#">90.46</a> , or selected encoder has faulted (par. <a href="#">90.45</a> ) 0 = Encoder 1 or 2 used for speed feedback	
b5	Encoder 1 feedback	1 = Encoder 1 used for speed feedback in motor control 0 = Encoder 1 faulted or not selected as source of speed feedback (see par. <a href="#">90.41</a> and <a href="#">90.46</a> )	
b6	Encoder 2 feedback	1 = Encoder 2 used for speed feedback in motor control 0 = Encoder 2 faulted or not selected as source of speed feedback (see par. <a href="#">90.41</a> and <a href="#">90.46</a> )	
b7	Constant speed req	1 = A constant speed or frequency has been selected; see par. <a href="#">6.20</a> .	
b8	MF speed corr min	1 = Minimum limit of speed correction (in a speed-controlled follower) has been reached (see par. <a href="#">23.39...23.41</a> ).	
b9	MF speed corr max	1 = Maximum limit of speed correction (in a speed-controlled follower) has been reached (see par. <a href="#">23.39...23.41</a> ).	
b10...15	Reserved		
	0000h...FFFFh		1 = 1 / 1 = 1

## 166 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
6.20	Constant speed status word	Constant speed/frequency status word. Indicates which constant speed or frequency is active (if any). See also parameter <a href="#">6.19 Speed control status word</a> , bit 7, and section <a href="#">Constant speeds/frequencies</a> .  This parameter is read-only.	- / uint16
b0	Constant speed 1	1 = Constant speed or frequency 1 selected	
b1	Constant speed 2	1 = Constant speed or frequency 2 selected	
b2	Constant speed 3	1 = Constant speed or frequency 3 selected	
b3	Constant speed 4	1 = Constant speed or frequency 4 selected	
b4	Constant speed 5	1 = Constant speed or frequency 5 selected	
b5	Constant speed 6	1 = Constant speed or frequency 6 selected	
b6	Constant speed 7	1 = Constant speed or frequency 7 selected	
b7...15	Reserved		
	0000h...FFFFh		1 = 1 / 1 = 1
6.21	Drive status word 3	Drive status word 3.  This parameter is read-only.	- / uint16
b0	DC hold active	1 = DC hold is active (see par. <a href="#">21.8</a> )	
b1	Post-magnetizing active	1 = Post-magnetizing is active (see par. <a href="#">21.8</a> )	
b2	Motor pre-heating active	1 = Motor pre-heating is active (see par. <a href="#">21.14</a> )	
b3	Smooth start active	Reserved	
b4	Rotor position known	1 = Rotor position has been determined (autophasing not needed). See section <a href="#">Autophasing (page 63)</a> .	
b5	Brake chopper active	Brake chopper active. See section <a href="#">Brake chopper (page 84)</a> .	
b6	Motor temperature estimation active		
b7...15	Reserved		
	0000h...FFFFh		1 = 1 / 1 = 1

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
6.25	Drive inhibit status word 2	<p>Drive inhibit status word 2. This word specifies the source of the inhibiting condition that is preventing the drive from starting. After the condition is removed, the start command must be cycled. See bit-specific notes.</p> <p>See also parameter <a href="#">6.18 Start inhibit status word</a>, and <a href="#">6.16 Drive status word 1</a>, bit 1.</p> <p>This parameter is read-only.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>If bit 1 of <a href="#">6.16 Drive status word 1</a> is still set after the removal of the inhibiting condition, and edge triggering is selected for the active external control location, a fresh rising-edge start signal is required. See parameters <a href="#">20.2</a>, <a href="#">20.7</a> and <a href="#">20.19</a>.</li> <li>If bit 1 of <a href="#">6.16 Drive status word 1</a> is still set after the removal of the inhibiting condition, a fresh rising-edge start signal is required.</li> </ul>	- / uint16
b0	Follower drive	1 = A follower is preventing the master from starting.	
b1	Application	1 = The application program is preventing the drive from starting.	
b2	Reserved		
b3	Encoder feedback	1 = The encoder feedback configuration is preventing the drive from starting.	
b4	Ref source parametrization	1 = A reference source parametrization conflict is preventing the drive from starting. See warning <a href="#">A6DA Reference source parametrization</a> .	
b5...15	Reserved		
	0000h...FFFFh		1 = 1 / 1 = 1
6.29	MSW bit 10 sel	Selects a binary source whose status is transmitted as bit 10 of <a href="#">6.11 Main status word</a> .	Above limit / uint32
	False	0	0
	True	1	1
	Above limit	Bit 10 of <a href="#">6.17 Drive status word 2</a> (page 163).	2
	Other [bit]	See <a href="#">Terms and abbreviations</a> (page 134).	-
6.30	MSW bit 11 sel	Selects a binary source whose status is transmitted as bit 11 of <a href="#">6.11 Main status word</a> .	Ext ctrl loc / uint32
	False	0	0
	True	1	1
	Ext ctrl loc	Bit 11 of <a href="#">6.1 Main control word</a> (page 161).	2
	Other [bit]	See <a href="#">Terms and abbreviations</a> (page 134).	-
6.31	MSW bit 12 sel	Selects a binary source whose status is transmitted as bit 12 of <a href="#">6.11 Main status word</a> .	Ext run enable / uint32
	False	0	0

# 168 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	True	1	1
	Ext run enable	Inverted bit 5 of <a href="#">6.18 Start inhibit status word (page 164)</a> .	2
	Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-
6.32	MSW bit 13 sel	Selects a binary source whose status is transmitted as bit 13 of <a href="#">6.11 Main status word</a> .	False / uint32
	False	0	0
	True	1	1
	Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-
6.33	MSW bit 14 sel	Selects a binary source whose status is transmitted as bit 14 of <a href="#">6.11 Main status word</a> .	False / uint32
	False	0	0
	True	1	1
	Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-
6.36	LSU Status Word	<i>(Only visible when supply unit control activated by <a href="#">95.20</a>)</i> Shows the status of the supply unit. See also section <a href="#">Control of a supply unit (LSU) (page 44)</a> . Parameter group <a href="#">60 DDCS communication</a> . This parameter is read-only.	0000h / uint16
	b0 Ready on	1 = Ready to switch on	
	b1 Ready run	1 = Ready to operate, DC link charged	
	b2 Ready ref	1 = Operation enabled	
	b3 Tripped	1 = A fault is active	
	b4 Not In Use	Reserved	
	b5 Not In Use	Reserved	
	b6 Not In Use	Reserved	
	b7 Warning	1 = A warning is active	
	b8 Modulating	1 = The supply unit is modulating	
	b9 Remote	1 = Remote control (EXT1 or EXT2) 0 = Local control	
	b10 Net ok	1 = Supply network voltage OK	
	b11 Not In Use	Selectable in supply control program	
	b12 Not In Use	Selectable in supply control program	
	b13 Not in use	Selectable in supply control program	
	b14 Charging	1 = Charging circuit active 0 = Charging circuit inactive	



No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
b15	Not In Use	Selectable in supply control program	
	0000h...FFFFh		1 = 1 / 1 = 1
6.39	Internal state machine LSU CW	<i>(Only visible when supply unit control activated by 95.20)</i> Shows the control word sent to the supply unit from the INU-LSU (inverter unit/supply unit) state machine. This parameter is read-only.	0000h / uint16
b0	ON/OFF	1 = Start charging 0 = Open main contactor (switch power off)	
b1	OFF 2	0 = Emergency stop (Off2)	
b2	OFF 3	0 = Emergency stop (Off3)	
b3	START	1 = Start modulating 0 = Stop modulating	
b4	Not In Use	Reserved	
b5	Not In Use	Reserved	
b6	Not In Use	Reserved	
b7	RESET	0→1 = Reset an active fault. A fresh start command is required after reset.	
b8	Not In Use	Reserved	
b9	Not In Use	Reserved	
b10	Not In Use	Reserved	
b11	Not In Use	Reserved	
b12	USER BIT 0	See parameter 6.40 LSU CW user bit 0 selection.	
b13	USER BIT 1	See parameter 6.41 LSU CW user bit 1 selection.	
b14	USER BIT 2	See parameter 6.42 LSU CW user bit 2 selection.	
b15	USER BIT 3	See parameter 6.43 LSU CW user bit 3 selection.	
	0000h...FFFFh		1 = 1 / 1 = 1
6.40	LSU CW user bit 0 selection	<i>(Only visible when supply unit control activated by 95.20)</i> Selects a binary source whose status is transmitted as bit 12 of 6.39 Internal state machine LSU CW to the supply unit.	MCW user bit 0 / uint32
	FALSE	0	0
	TRUE	1	1
	MCW user bit 0	Bit 12 of 6.1 Main control word (page 161).	2
	MCW user bit 1	Bit 13 of 6.1 Main control word (page 161).	3
	MCW user bit 2	Bit 14 of 6.1 Main control word (page 161).	4
	MCW user bit 3	Bit 15 of 6.1 Main control word (page 161).	5

170 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-
6.41	LSU CW user bit 1 selection	<i>(Only visible when supply unit control activated by 95.20)</i> Selects a binary source whose status is transmitted as bit 13 of <a href="#">6.39 Internal state machine LSU CW</a> to the supply unit.	MCW user bit 1 / uint32
	FALSE	0	0
	TRUE	1	1
	MCW user bit 0	Bit 12 of <a href="#">6.1 Main control word (page 161)</a> .	2
	MCW user bit 1	Bit 13 of <a href="#">6.1 Main control word (page 161)</a> .	3
	MCW user bit 2	Bit 14 of <a href="#">6.1 Main control word (page 161)</a> .	4
	MCW user bit 3	Bit 15 of <a href="#">6.1 Main control word (page 161)</a> .	5
	Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-
6.42	LSU CW user bit 2 selection	<i>(Only visible when supply unit control activated by 95.20)</i> Selects a binary source whose status is transmitted as bit 14 of <a href="#">6.39 Internal state machine LSU CW</a> to the supply unit.	MCW user bit 2 / uint32
	FALSE	0	0
	TRUE	1	1
	MCW user bit 0	Bit 12 of <a href="#">6.1 Main control word (page 161)</a> .	2
	MCW user bit 1	Bit 13 of <a href="#">6.1 Main control word (page 161)</a> .	3
	MCW user bit 2	Bit 14 of <a href="#">6.1 Main control word (page 161)</a> .	4
	MCW user bit 3	Bit 15 of <a href="#">6.1 Main control word (page 161)</a> .	5
	Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-
6.43	LSU CW user bit 3 selection	<i>(Only visible when supply unit control activated by 95.20)</i> Selects a binary source whose status is transmitted as bit 15 of <a href="#">6.39 Internal state machine LSU CW</a> to the supply unit.	MCW user bit 3 / uint32
	FALSE	0	0
	TRUE	1	1
	MCW user bit 0	Bit 12 of <a href="#">6.1 Main control word (page 161)</a> .	2
	MCW user bit 1	Bit 13 of <a href="#">6.1 Main control word (page 161)</a> .	3
	MCW user bit 2	Bit 14 of <a href="#">6.1 Main control word (page 161)</a> .	4
	MCW user bit 3	Bit 15 of <a href="#">6.1 Main control word (page 161)</a> .	5
	Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
6.45	Follower CW user bit 0 selection	Selects a binary source whose status is transmitted as bit 12 of the Follower control word to follower drives. (Bits 0...11 of the Follower control word are taken from 6.1 Main control word.)  See also section <a href="#">Master/follower functionality</a> .	MCW user bit 0 / uint32
	FALSE	0	0
	TRUE	1	1
	MCW user bit 0	Bit 12 of <a href="#">6.1 Main control word (page 161)</a> .	2
	MCW user bit 1	Bit 13 of <a href="#">6.1 Main control word (page 161)</a> .	3
	MCW user bit 2	Bit 14 of <a href="#">6.1 Main control word (page 161)</a> .	4
	MCW user bit 3	Bit 15 of <a href="#">6.1 Main control word (page 161)</a> .	5
Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-	
6.46	Follower CW user bit 1 selection	Selects a binary source whose status is transmitted as bit 13 of the Follower control word to follower drives. (Bits 0...11 of the Follower control word are taken from 6.1 Main control word.)	MCW user bit 1 / uint32
	FALSE	0	0
	TRUE	1	1
	MCW user bit 0	Bit 12 of <a href="#">6.1 Main control word (page 161)</a> .	2
	MCW user bit 1	Bit 13 of <a href="#">6.1 Main control word (page 161)</a> .	3
	MCW user bit 2	Bit 14 of <a href="#">6.1 Main control word (page 161)</a> .	4
	MCW user bit 3	Bit 15 of <a href="#">6.1 Main control word (page 161)</a> .	5
Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-	
6.47	Follower CW user bit 2 selection	Selects a binary source whose status is transmitted as bit 14 of the Follower control word to follower drives. (Bits 0...11 of the Follower control word are taken from 6.1 Main control word.)	MCW user bit 2 / uint32
	FALSE	0	0
	TRUE	1	1
	MCW user bit 0	Bit 12 of <a href="#">6.1 Main control word (page 161)</a> .	2
	MCW user bit 1	Bit 13 of <a href="#">6.1 Main control word (page 161)</a> .	3
	MCW user bit 2	Bit 14 of <a href="#">6.1 Main control word (page 161)</a> .	4
	MCW user bit 3	Bit 15 of <a href="#">6.1 Main control word (page 161)</a> .	5
Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-	
6.48	Follower CW user bit 3 selection	Selects a binary source whose status is transmitted as bit 15 of the Follower control word to follower drives. (Bits 0...11 of the Follower control word are taken from 6.1 Main control word.)	MCW user bit 3 / uint32
	FALSE	0	0
	TRUE	1	1
	MCW user bit 0	Bit 12 of <a href="#">6.1 Main control word (page 161)</a> .	2

## 172 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	MCW user bit 1	Bit 13 of <a href="#">6.1 Main control word (page 161)</a> .	3
	MCW user bit 2	Bit 14 of <a href="#">6.1 Main control word (page 161)</a> .	4
	MCW user bit 3	Bit 15 of <a href="#">6.1 Main control word (page 161)</a> .	5
	Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-
6.50	User status word 1	User-defined status word. This word shows the status of the binary sources selected by parameters <a href="#">6.60...6.75</a> .  This parameter is read-only.	- / uint16
	b0 User status bit 0	Status of source selected by parameter <a href="#">6.60</a> .	
	b1 User status bit 1	Status of source selected by parameter <a href="#">6.61</a> .	
	b2 User status bit 2	Status of source selected by parameter <a href="#">6.62</a> .	
	b3 User status bit 3	Status of source selected by parameter <a href="#">6.63</a> .	
	b4 User status bit 4	Status of source selected by parameter <a href="#">6.64</a> .	
	b5 User status bit 5	Status of source selected by parameter <a href="#">6.65</a> .	
	b6 User status bit 6	Status of source selected by parameter <a href="#">6.66</a> .	
	b7 User status bit 7	Status of source selected by parameter <a href="#">6.67</a> .	
	b8 User status bit 8	Status of source selected by parameter <a href="#">6.68</a> .	
	b9 User status bit 9	Status of source selected by parameter <a href="#">6.69</a> .	
	b10 User status bit 10	Status of source selected by parameter <a href="#">6.70</a> .	
	b11 User status bit 11	Status of source selected by parameter <a href="#">6.71</a> .	
	b12 User status bit 12	Status of source selected by parameter <a href="#">6.72</a> .	
	b13 User status bit 13	Status of source selected by parameter <a href="#">6.73</a> .	
	b14 User status bit 14	Status of source selected by parameter <a href="#">6.74</a> .	
	b15 User status bit 15	Status of source selected by parameter <a href="#">6.75</a> .	
	0000h...FFFFh		1 = 1 / 1 = 1
6.60	User status word 1 bit 0 sel	Selects a binary source whose status is shown as bit 0 of <a href="#">6.50 User status word 1</a> .	FALSE / uint32
	FALSE	0	0
	TRUE	1	1
	Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-
6.61	User status word 1 bit 1 sel	Selects a binary source whose status is shown as bit 1 of <a href="#">6.50 User status word 1</a> .	Out of window / uint32
	False	0	0
	True	1	1
	Out of window	Bit 3 of <a href="#">6.19 Speed control status word (page 165)</a> .	2
	Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
6.62	User status word 1 bit 2 sel	Selects a binary source whose status is shown as bit 2 of 6.50 User status word 1.	Emergency stop failed / uint32
	False	0	0
	True	1	1
	Emergency stop failed	Bit 8 of 6.17 Drive status word 2 (page 163).	2
	Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-
6.63	User status word 1 bit 3 sel	Selects a binary source whose status is shown as bit 3 of 6.50 User status word 1.	Magnetized / uint32
	False	0	0
	True	1	1
	Magnetized	Bit 1 of 6.17 Drive status word 2 (page 163).	2
	Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-
6.64	User status word 1 bit 4 sel	Selects a binary source whose status is shown as bit 4 of 6.50 User status word 1.	Run disable / uint32
	False	0	0
	True	1	1
	Run disable	Bit 5 of 6.18 Start inhibit status word.	2
	Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-
6.65	User status word 1 bit 5 sel	Selects a binary source whose status is shown as bit 5 of 6.50 User status word 1.	FALSE / uint32
	FALSE	0	0
	TRUE	1	1
	Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-
6.66	User status word 1 bit 6 sel	Selects a binary source whose status is shown as bit 6 of 6.50 User status word 1.	FALSE / uint32
	FALSE	0	0
	TRUE	1	1
	Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-
6.67	User status word 1 bit 7 sel	Selects a binary source whose status is shown as bit 7 of 6.50 User status word 1.	Identification run done / uint32
	False	0	0
	True	1	1
	Identification run done	Bit 0 of 6.17 Drive status word 2 (page 163).	2
	Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-
6.68	User status word 1 bit 8 sel	Selects a binary source whose status is shown as bit 8 of 6.50 User status word 1.	Start inhibition / uint32
	False	0	0
	True	1.	1

## 174 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	Start inhibition	Bit 7 of <a href="#">6.18 Start inhibit status word (page 164)</a> .	2
	Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-
6.69	User status word 1 bit 9 sel	Selects a binary source whose status is shown as bit 9 of <a href="#">6.50 User status word 1</a> .	Limiting / uint32
	False	0	0
	True	1	1
	Limiting	Bit 7 of <a href="#">6.16 Drive status word 1 (page 162)</a> .	2
	Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-
6.70	User status word 1 bit 10 sel	Selects a binary source whose status is shown as bit 10 of <a href="#">6.50 User status word 1</a> .	Torque control / uint32
	False	0	0
	True	1	1
	Torque control	Bit 2 of <a href="#">6.17 Drive status word 2 (page 163)</a> .	2
	Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-
6.71	User status word 1 bit 11 sel	Selects a binary source whose status is shown as bit 11 of <a href="#">6.50 User status word 1</a> .	Zero speed / uint32
	False	0	0
	True	1	1
	Zero speed	Bit 0 of <a href="#">6.19 Speed control status word (page 165)</a> .	2
	Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-
6.72	User status word 1 bit 12 sel	Selects a binary source whose status is shown as bit 12 of <a href="#">6.50 User status word 1</a> .	Internal speed feedback / uint32
	False	0	0
	True	1	1
	Internal speed feedback	Bit 4 of <a href="#">6.19 Speed control status word (page 165)</a> .	2
	Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-
6.73	User status word 1 bit 13 sel	Selects a binary source whose status is shown as bit 13 of <a href="#">6.50 User status word 1</a> .	FALSE / uint32
	FALSE	0	0
	TRUE	1	1
	Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-
6.74	User status word 1 bit 14 sel	Selects a binary source whose status is shown as bit 14 of <a href="#">6.50 User status word 1</a> .	FALSE / uint32
	FALSE	0	0
	TRUE	1	1
	Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-
6.75	User status word 1 bit 15 sel	Selects a binary source whose status is shown as bit 15 of <a href="#">6.50 User status word 1</a> .	FALSE / uint32

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	FALSE	0	0
	TRUE	1	1
	Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-
6.100	User control word 1	User-defined control word 1.	0000h / uint16
	b0 User control word 1 bit 0 sel	User-defined bit.	
	b1 User control word 1 bit 1 sel	User-defined bit.	
	b2 User control word 1 bit 2 sel	User-defined bit.	
	b3 User control word 1 bit 3 sel	User-defined bit.	
	b4 User control word 1 bit 4 sel	User-defined bit.	
	b5 User control word 1 bit 5 sel	User-defined bit.	
	b6 User control word 1 bit 6 sel	User-defined bit.	
	b7 User control word 1 bit 7 sel	User-defined bit.	
	b8 User control word 1 bit 8 sel	User-defined bit.	
	b9 User control word 1 bit 9 sel	User-defined bit.	
	b10 User control word 1 bit 10 sel	User-defined bit.	
	b11 User control word 1 bit 11 sel	User-defined bit.	
	b12 User control word 1 bit 12 sel	User-defined bit.	
	b13 User control word 1 bit 13 sel	User-defined bit.	
	b14 User control word 1 bit 14 sel	User-defined bit.	
	b15 User control word 1 bit 15 sel	User-defined bit.	
	0000h...FFFFh		1 = 1 / 1 = 1
6.101	User control word 2	User-defined control word 2.	0000h / uint16
	b0 User control word 2 bit 0 sel	User-defined bit.	
	b1 User control word 2 bit 1 sel	User-defined bit.	

## 176 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
b2	User control word 2 bit 2 sel	User-defined bit.	
b3	User control word 2 bit 3 sel	User-defined bit.	
b4	User control word 2 bit 4 sel	User-defined bit.	
b5	User control word 2 bit 5 sel	User-defined bit.	
b6	User control word 2 bit 6 sel	User-defined bit.	
b7	User control word 2 bit 7 sel	User-defined bit.	
b8	User control word 2 bit 8 sel	User-defined bit.	
b9	User control word 2 bit 9 sel	User-defined bit.	
b10	User control word 2 bit 10 sel	User-defined bit.	
b11	User control word 2 bit 11 sel	User-defined bit.	
b12	User control word 2 bit 12 sel	User-defined bit.	
b13	User control word 2 bit 13 sel	User-defined bit.	
b14	User control word 2 bit 14 sel	User-defined bit.	
b15	User control word 2 bit 15 sel	User-defined bit.	
	0000h...FFFFh		1 = 1 / 1 = 1
6.116	LSU drive status word 1	<p><i>(Only visible when IGBT supply unit control activated by 95.20)</i></p> <p>Drive status word 1 received from the supply unit.</p> <p>See also section <a href="#">Control of a supply unit (LSU)</a> (page 44).</p> <p>Parameter group <b>60 DDCS communication</b>. This parameter is read-only.</p>	- / uint16
b0	Enabled	1 = Run enable and start enable signals are present	
b1	Inhibited	1 = Start inhibited	
b2	Operation allowed	1 = Drive is ready to operate	
b3	Ready to start	1 = Drive is ready to receive a start command	
b4	Running	1 = Drive is ready to follow given reference	
b5	Started	1 = Drive has been started	



No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
b6	Modulating	1 = Drive is modulating (output stage is being controlled)	
b7	Limiting	1 = Any operating limit is active	
b8	Local control	1 = Drive is in local control	
b9	Network control	1 = Drive is in network control	
b10	Ext1 active	1 = Control location Ext1 active	
b11	Ext2 active	1 = Control location Ext2 active	
b12	Charging relay	1 = Charging contactor is energized. The actual state depends on the hardware topology (NO or NC).	
b13	MCB relay	1 = MCB relay is closed	
b14...15	Reserved		
	0000h...FFFFh		1 = 1 / 1 = 1
6.118	LSU start inhibit status word	<i>(Only visible when IGBT supply unit control activated by 95.20)</i>  This word specifies the source of the inhibiting condition that is preventing the supply unit from starting.  See also section <a href="#">Control of a supply unit (LSU)</a> (page 44).  Parameter group <b>60 DDCS communication</b> . This parameter is read-only.	- / uint16
b0	Not ready run		
b1	Ctrl location changed		
b2	SSW inhibit		
b3	Fault reset		
b4	Lost start enable		
b5	Lost run enable		
b6...8	Reserved		
b9	Charging overload		
b10...11	Reserved		
b12	Em Off2		
b13	Em Off3		
b14	Auto reset inhibit		
b15	Reserved		
	0000h...FFFFh		1 = 1 / 1 = 1

# 178 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
7	System info	Information on drive hardware, firmware and application program. All parameters in this group are read-only.	
7.3	Drive rating id	Type of the drive/inverter unit.	- / uint16
7.4	Firmware name	Firmware identification. The format is AINFX, where X denotes the control unit type (2 or B = BCU-x2, 6 or C = ZCU-12/14).	- / uint32
7.5	Firmware version	Version number of the firmware. The format is A.BB.C.D, where A = major version, B = minor version, C = patch (ie. firmware variant code), D = 0.	- / uint32
7.6	Loading package name	Name of the firmware loading package. The format is AINLX, where X denotes the control unit type (2 or B = BCU-x2, 6 or C = ZCU-12/14).	- / uint32
7.7	Loading package version	Version number of the firmware loading package. See parameter 7.5.	- / uint32
7.8	Bootloader version	Version number of the firmware bootloader.	- / uint32
7.11	Cpu usage	Microprocessor load in percent.	- / uint32
	0...100 %	Microprocessor load.	1 = 1 % / 1 = 1 %
7.13	PU logic version number	Version number of the power unit logic. The value of FFFF indicates that the version numbers of parallel-connected power units are different. See the drive information on the control panel.	- / uint16
7.14	FPGA logic version name	Version name of the FPGA logic of the control unit.	- / uint32
7.15	FPGA logic version number	Version number of the FPGA logic of the control unit.	- / uint16
7.21	Application environment status 1	<i>(Only visible with option +N8010 [application programmability])</i> Shows which tasks of the application program are running.  See the <i>Drive (IEC 61131-3) application programming manual (3AUA0000127808 [English])</i> .	- / uint16
	b0 Pre task	1 = Pre-task running.	
	b1 Appl task1	1 = Task 1 running.	
	b2 Appl task2	1 = Task 2 running.	
	b3 Appl task3	1 = Task 3 running.	
	b4...14 Reserved		
	b15 Task monitoring	1 = Task monitoring enabled.	
	0000h...FFFFh		1 = 1 / 1 = 1

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
7.22	Application environment status 2	<p><i>(Only visible with option +N8010 [application programmability])</i></p> <p>Shows the status of the openings in the application program.</p> <p>See the <i>Drive (IEC 61131-3) application programming manual (3AUA0000127808 [English])</i>.</p>	- / uint16
b0	Opening1	Status of opening 1 in the application program.	
b1	Opening2	Status of opening 2 in the application program.	
b2	Opening3	Status of opening 3 in the application program.	
b3	Opening4	Status of opening 4 in the application program.	
b4	Opening5	Status of opening 5 in the application program.	
b5	Opening6	Status of opening 6 in the application program.	
b6	Opening7	Status of opening 7 in the application program.	
b7	Opening8	Status of opening 8 in the application program.	
b8	Opening9	Status of opening 9 in the application program.	
b9	Opening10	Status of opening 10 in the application program.	
b10	Opening11	Status of opening 11 in the application program.	
b11	Opening12	Status of opening 12 in the application program.	
b12	Opening13	Status of opening 13 in the application program.	
b13	Opening14	Status of opening 14 in the application program.	
b14	Opening15	Status of opening 15 in the application program.	
b15	Opening16	Status of opening 16 in the application program.	
	0000h...FFFFh		1 = 1 / 1 = 1
7.23	Application name	<p><i>(Only visible with option +N8010 [application programmability])</i></p> <p>First five ASCII letters of the name given to the application program in the programming tool. The full name is visible under System info on the control panel or the Drive Composer PC tool.</p> <p>_N/A_ = None.</p>	- / uint32
7.24	Application version	<p><i>(Only visible with option +N8010 [application programmability])</i></p> <p>Application program version number given to the application program in the programming tool. Also visible under System info on the control panel or the Drive Composer PC tool.</p>	- / uint32
7.25	Customization package name	<p>First five ASCII letters of the name given to the customization package. The full name is visible under System info on the control panel or the Drive Composer PC tool.</p> <p>_N/A_ = None.</p>	- / uint32



# 180 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
7.26	Customization package version	Customization package version number. Also visible under System info on the control panel or the Drive Composer PC tool.	- / uint32
7.30	Adaptive program status	Shows the status of the adaptive program. See section <a href="#">Adaptive programming (page 31)</a> .	0000h / uint16
b0	Initialized	1 = Adaptive program initialized	
b1	Editing	1 = Adaptive program is being edited	
b2	Edit done	1 = Editing of adaptive program finished	
b3	Running	1 = Adaptive program running	
b4...13	Reserved		
b14	State changing	Reserved	
b15	Faulted	1 = Error in adaptive program	
	0000h...FFFFh		1 = 1 / 1 = 1
7.40	IEC application Cpu usage peak	<i>(Only visible with option +N8010 [application program-mability])</i> Displays the peak loading of the microprocessor caused by the application program. This parameter can, for example, be used to check the effect of a given application program functionality on the CPU load. The value is in percent of an internal quota. Can be reset from the control panel by keeping Reset depressed for over 3 seconds.	- / real32
	0.0 ... 100.0 %	Peak microprocessor loading caused by application program.	10 = 1 % / 10 = 1 %
7.41	IEC application Cpu load average	<i>(Only visible with option +N8010 [application program-mability])</i> Displays the average loading of the microprocessor caused by the application program. The value is in percent of an internal quota.	- / real32
	0.0 ... 100.0 %	Average microprocessor loading caused by application program.	10 = 1 % / 10 = 1 %
7.51	Slot 1 option module	Displays the type of module detected in slot 1 of the drive control unit.	- / uint16
7.52	Slot 2 option module	Displays the type of module detected in slot 2 of the drive control unit.	- / uint16
7.53	Slot 3 option module	Displays the type of module detected in slot 3 of the drive control unit.	- / uint16
7.54	Slot 1 module logic version	Displays the FPGA logic version of module detected in slot 1 of the drive control unit. The logic version is detected for DDCS option modules, for example, FEN encoder modules (FEN-01, FEN-11, FEN-21, FEN-31) and I/O modules (FIO-11, FDIO-01, FAIO-01).	0 / uint16



No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	0000...FFFFh	Logic version of module detected in slot 1.	1 = 1
7.55	Slot 1 module software version	Displays the software version of module detected in slot 1 of the drive control unit.	- / uint16
7.56	Slot 2 module logic version	Displays the FPGA logic version of module detected in slot 2 of the drive control unit.  The logic version is detected for DDCS option modules, for example, FEN encoder modules (FEN-01, FEN-11, FEN-21, FEN-31) and I/O modules (FIO-11, FDIO-01, FAIO-01).	0 / uint16
	0000...FFFFh	Logic version of module detected in slot 2.	1 = 1
7.57	Slot 2 module software version	Displays the software version of module detected in slot 2 of the drive control unit.	- / uint16
7.58	Slot 3 module logic version	Displays the FPGA logic version of module detected in slot 3 of the drive control unit.  The logic version is detected for DDCS option modules, for example, FEN encoder modules (FEN-01, FEN-11, FEN-21, FEN-31) and I/O modules (FIO-11, FDIO-01, FAIO-01).	0 / uint16
	0000...FFFFh	Logic version of module detected in slot 3.	1 = 1
7.59	Slot 3 module software version	Displays the software version of module detected in slot 3 of the drive control unit.	- / uint16
7.106	LSU loading package name	<i>(Only visible when IGBT supply unit control activated by 95.20)</i> Name of the loading package of the supply unit firmware.	- / uint32
7.107	LSU loading package version	<i>(Only visible when IGBT supply unit control activated by 95.20)</i> Version number of the loading package of the supply unit firmware.	- / uint32

## 182 Parameters



No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
10	Standard DI, RO	Configuration of digital inputs and relay outputs.	
10.1	DI status	Displays the electrical status of digital inputs DIIL and DI6...DI1. The activation/deactivation delays of the inputs (if any are specified) are ignored. A filtering time can be defined by parameter <a href="#">10.51 DI filter time</a> .  Bits 0...5 reflect the status of DI1...DI6; bit 15 reflects the status of the DIIL input. <b>Example:</b> 1000000000010011b = DIIL, DI5, DI2 and DI1 are on, DI3, DI4 and DI6 are off.  This parameter is read-only.	- / uint16
10.2	DI delayed status	Displays the status of digital inputs DIIL and DI6...DI1. This word is updated only after activation/deactivation delays (if any are specified). A filtering time can be defined by parameter <a href="#">10.51 DI filter time</a> .  Bits 0...5 reflect the delayed status of DI1...DI6; bit 15 reflects the delayed status of the DIIL input.  This parameter is read-only.	- / uint16
10.3	DI force selection	The electrical statuses of the digital inputs can be overridden for eg. testing purposes. A bit in parameter <a href="#">10.4 DI force data</a> is provided for each digital input, and its value is applied whenever the corresponding bit in this parameter is 1.	0000h / uint16
b0	DI1	1 = Force DI1 to value of bit 0 of parameter <a href="#">10.4 DI force data</a> .	
b1	DI2	1 = Force DI2 to value of bit 1 of parameter <a href="#">10.4 DI force data</a> .	
b2	DI3	1 = Force DI3 to value of bit 2 of parameter <a href="#">10.4 DI force data</a> .	
b3	DI4	1 = Force DI4 to value of bit 3 of parameter <a href="#">10.4 DI force data</a> .	
b4	DI5	1 = Force DI5 to value of bit 4 of parameter <a href="#">10.4 DI force data</a> .	
b5	DI6	1 = Force DI6 to value of bit 5 of parameter <a href="#">10.4 DI force data</a> .	
b6...14	Reserved		
b15	DIIL	1 = Force DIIL to value of bit 15 of parameter <a href="#">10.4 DI force data</a> .	
	0000h...FFFFh		1 = 1 / 1 = 1
10.4	DI force data	Contains the values that the digital inputs are forced to when selected by <a href="#">10.3 DI force selection</a> .  Bit 0 is the forced value for DI1; bit 15 is the forced value for the DIIL input.	- / uint16

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
10.5	DI1 ON delay	Defines the activation delay for digital input DI1.   $t_{On} = 10.5$ DI1 ON delay $t_{Off} = 10.6$ DI1 OFF delay *Electrical status of digital input. Indicated by <a href="#">10.1 DI status</a> . **Indicated by <a href="#">10.2 DI delayed status</a> .	0.0 s / uint32
	0.0 ... 3000.0 s	Activation delay for DI1.	$10 = 1 \text{ s} / 10 = 1 \text{ s}$
10.6	DI1 OFF delay	Defines the deactivation delay for digital input DI1. See parameter <a href="#">10.5 DI1 ON delay</a> .	0.0 s / uint32
	0.0 ... 3000.0 s	Deactivation delay for DI1.	$10 = 1 \text{ s} / 10 = 1 \text{ s}$
10.7	DI2 ON delay	Defines the activation delay for digital input DI2.   $t_{On} = 10.7$ DI2 ON delay $t_{Off} = 10.8$ DI2 OFF delay *Electrical status of digital input. Indicated by <a href="#">10.1 DI status</a> . **Indicated by <a href="#">10.2 DI delayed status</a> .	0.0 s / uint32
	0.0 ... 3000.0 s	Activation delay for DI2.	$10 = 1 \text{ s} / 10 = 1 \text{ s}$
10.8	DI2 OFF delay	Defines the deactivation delay for digital input DI2. See parameter <a href="#">10.7 DI2 ON delay</a> .	0.0 s / uint32
	0.0 ... 3000.0 s	Deactivation delay for DI2.	$10 = 1 \text{ s} / 10 = 1 \text{ s}$

184 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
10.9	DI3 ON delay	<p>Defines the activation delay for digital input DI3.</p>  <p><math>t_{On} = 10.9</math> DI3 ON delay  <math>t_{Off} = 10.10</math> DI3 OFF delay</p> <p>*Electrical status of digital input. Indicated by <a href="#">10.1 DI status</a>.            **Indicated by <a href="#">10.2 DI delayed status</a>.</p>	0.0 s / uint32
	0.0 ... 3000.0 s	Activation delay for DI3.	10 = 1 s / 10 = 1 s
10.10	DI3 OFF delay	<p>Defines the deactivation delay for digital input DI3.            See parameter <a href="#">10.9 DI3 ON delay</a>.</p>	0.0 s / uint32
	0.0 ... 3000.0 s	Deactivation delay for DI3.	10 = 1 s / 10 = 1 s
10.11	DI4 ON delay	<p>Defines the activation delay for digital input DI4.</p>  <p><math>t_{On} = 10.11</math> DI4 ON delay  <math>t_{Off} = 10.12</math> DI4 OFF delay</p> <p>*Electrical status of digital input. Indicated by <a href="#">10.1 DI status</a>.            **Indicated by <a href="#">10.2 DI delayed status</a>.</p>	0.0 s / uint32
	0.0 ... 3000.0 s	Activation delay for DI4.	10 = 1 s / 10 = 1 s
10.12	DI4 OFF delay	<p>Defines the deactivation delay for digital input DI4.            See parameter <a href="#">10.11 DI4 ON delay</a>.</p>	0.0 s / uint32
	0.0 ... 3000.0 s	Deactivation delay for DI4.	10 = 1 s / 10 = 1 s




No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
10.13	DI5 ON delay	Defines the activation delay for digital input DI5.    $t_{On} = 10.13$ DI5 ON delay $t_{Off} = 10.14$ DI5 OFF delay *Electrical status of digital input. Indicated by 10.1 DI status. **Indicated by 10.2 DI delayed status.	0.0 s / uint32
	0.0 ... 3000.0 s	Activation delay for DI5.	$10 = 1$ s / $10 = 1$ s
10.14	DI5 OFF delay	Defines the deactivation delay for digital input DI5. See parameter 10.13 DI5 ON delay.	0.0 s / uint32
	0.0 ... 3000.0 s	Deactivation delay for DI5.	$10 = 1$ s / $10 = 1$ s
10.15	DI6 ON delay	Defines the activation delay for digital input DI6.    $t_{On} = 10.15$ DI6 ON delay $t_{Off} = 10.16$ DI6 OFF delay *Electrical status of digital input. Indicated by 10.1 DI status. **Indicated by 10.2 DI delayed status.	0.0 s / uint32
	0.0 ... 3000.0 s	Activation delay for DI6.	$10 = 1$ s / $10 = 1$ s
10.16	DI6 OFF delay	Defines the deactivation delay for digital input DI6. See parameter 10.15 DI6 ON delay.	0.0 s / uint32
	0.0 ... 3000.0 s	Deactivation delay for DI6.	$10 = 1$ s / $10 = 1$ s
10.21	RO status	Status of relay outputs RO8...RO1. <b>Example:</b> 00000001b = RO1 is energized, RO2...RO8 are de-energized.	- / uint16
10.24	RO1 source	Selects a drive signal to be connected to relay output RO1.	Ready run; 10.01 b3 (-1) (95.20 b2); 35.105 b1 (95.20 b6); 06.16 b6 (95.20 b9) / uint32
	Not energized	Output is not energized.	0
	Energized	Output is energized.	1
	Ready run	Bit 1 of 6.11 Main status word (page 162).	2

# 186 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	Enabled	Bit 0 of 6.16 Drive status word 1 (page 162).	4
	Started	Bit 5 of 6.16 Drive status word 1 (page 162).	5
	Magnetized	Bit 1 of 6.17 Drive status word 2 (page 163).	6
	Running	Bit 6 of 6.16 Drive status word 1 (page 162).	7
	Ready ref	Bit 2 of 6.11 Main status word (page 162).	8
	At setpoint	Bit 8 of 6.11 Main status word (page 162).	9
	Reverse	Bit 2 of 6.19 Speed control status word (page 165).	10
	Zero speed	Bit 0 of 6.19 Speed control status word (page 165).	11
	Above limit	Bit 10 of 6.17 Drive status word 2 (page 163).	12
	Warning	Bit 7 of 6.11 Main status word (page 162).	13
	Fault	Bit 3 of 6.11 Main status word (page 162).	14
	Fault (-1)	Inverted bit 3 of 6.11 Main status word (page 162).	15
	Start request	Bit 13 of 6.16 Drive status word 1 (page 162).	16
	Open brake command	Bit 0 of 44.1 Brake control status (page 420).	22
	Ext2 active	Bit 11 of 6.16 Drive status word 1 (page 162).	23
	Remote control	Bit 9 of 6.11 Main status word (page 162).	24
	Supervision 1	Bit 0 of 32.1 Supervision status (page 362).	33
	Supervision 2	Bit 1 of 32.1 Supervision status (page 362).	34
	Supervision 3	Bit 2 of 32.1 Supervision status (page 362).	35
	RO/DIO control word bit0	Bit 0 of 10.99 RO/DIO control word (page 189).	40
	RO/DIO control word bit1	Bit 1 of 10.99 RO/DIO control word (page 189).	41
	RO/DIO control word bit2	Bit 2 of 10.99 RO/DIO control word (page 189).	42
	RO/DIO control word bit8	Bit 8 of 10.99 RO/DIO control word (page 189).	43
	RO/DIO control word bit9	Bit 9 of 10.99 RO/DIO control word (page 189).	44
	Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-
10.25	RO1 ON delay	<p>Defines the activation delay for relay output RO1.</p> <p><math>t_{On}</math> = 10.25 RO1 ON delay  <math>t_{Off}</math> = 10.26 RO1 OFF delay</p>	0.0 s / uint32
	0.0 ... 3000.0 s	Activation delay for RO1.	10 = 1 s / 10 = 1 s

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
10.26	RO1 OFF delay	Defines the deactivation delay for relay output RO1. See parameter 10.25 RO1 ON delay.	0.0 s / uint32
	0.0 ... 3000.0 s	Deactivation delay for RO1.	10 = 1 s / 10 = 1 s
10.27	RO2 source	Selects a drive signal to be connected to relay output RO2.	Running (95.20 b3) / uint32
	Not energized	Output is not energized.	0
	Energized	Output is energized.	1
	Ready run	Bit 1 of 6.11 Main status word (page 162).	2
	Enabled	Bit 0 of 6.16 Drive status word 1 (page 162).	4
	Started	Bit 5 of 6.16 Drive status word 1 (page 162).	5
	Magnetized	Bit 1 of 6.17 Drive status word 2 (page 163).	6
	Running	Bit 6 of 6.16 Drive status word 1 (page 162).	7
	Ready ref	Bit 2 of 6.11 Main status word (page 162).	8
	At setpoint	Bit 8 of 6.11 Main status word (page 162).	9
	Reverse	Bit 2 of 6.19 Speed control status word (page 165).	10
	Zero speed	Bit 0 of 6.19 Speed control status word (page 165).	11
	Above limit	Bit 10 of 6.17 Drive status word 2 (page 163).	12
	Warning	Bit 7 of 6.11 Main status word (page 162).	13
	Fault	Bit 3 of 6.11 Main status word (page 162).	14
	Fault (-1)	Inverted bit 3 of 6.11 Main status word (page 162).	15
	Start request	Bit 13 of 6.16 Drive status word 1 (page 162).	16
	Open brake command	Bit 0 of 44.1 Brake control status (page 420).	22
	Ext2 active	Bit 11 of 6.16 Drive status word 1 (page 162).	23
	Remote control	Bit 9 of 6.11 Main status word (page 162).	24
	Supervision 1	Bit 0 of 32.1 Supervision status (page 362).	33
	Supervision 2	Bit 1 of 32.1 Supervision status (page 362).	34
	Supervision 3	Bit 2 of 32.1 Supervision status (page 362).	35
	RO/DIO control word bit0	Bit 0 of 10.99 RO/DIO control word (page 189).	40
	RO/DIO control word bit1	Bit 1 of 10.99 RO/DIO control word (page 189).	41
	RO/DIO control word bit2	Bit 2 of 10.99 RO/DIO control word (page 189).	42
	RO/DIO control word bit8	Bit 8 of 10.99 RO/DIO control word (page 189).	43
RO/DIO control word bit9	Bit 9 of 10.99 RO/DIO control word (page 189).	44	
Other [bit]	See Terms and abbreviations (page 134).	-	

# 188 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
10.28	RO2 ON delay	<p>Defines the activation delay for relay output RO2.</p>  <p><math>t_{On}</math> = 10.28 RO2 ON delay  <math>t_{Off}</math> = 10.29 RO2 OFF delay</p>	0.0 (95.20 b3) s / uint32
	0.0 ... 3000.0 s	Activation delay for RO2.	$10 = 1 \text{ s} / 10 = 1 \text{ s}$
10.29	RO2 OFF delay	<p>Defines the deactivation delay for relay output RO2.            See parameter 10.28 RO2 ON delay.</p>	0.0 (95.20 b3) s / uint32
	0.0 ... 3000.0 s	Deactivation delay for RO2.	$10 = 1 \text{ s} / 10 = 1 \text{ s}$
10.30	RO3 source	Selects a drive signal to be connected to relay output RO3.	Fault (-1) / uint32
	Not energized	Output is not energized.	0
	Energized	Output is energized.	1
	Ready run	Bit 1 of 6.11 Main status word (page 162).	2
	Enabled	Bit 0 of 6.16 Drive status word 1 (page 162).	4
	Started	Bit 5 of 6.16 Drive status word 1 (page 162).	5
	Magnetized	Bit 1 of 6.17 Drive status word 2 (page 163).	6
	Running	Bit 6 of 6.16 Drive status word 1 (page 162).	7
	Ready ref	Bit 2 of 6.11 Main status word (page 162).	8
	At setpoint	Bit 8 of 6.11 Main status word (page 162).	9
	Reverse	Bit 2 of 6.19 Speed control status word (page 165).	10
	Zero speed	Bit 0 of 6.19 Speed control status word (page 165).	11
	Above limit	Bit 10 of 6.17 Drive status word 2 (page 163).	12
	Warning	Bit 7 of 6.11 Main status word (page 162).	13
	Fault	Bit 3 of 6.11 Main status word (page 162).	14
	Fault (-1)	Inverted bit 3 of 6.11 Main status word (page 162).	15
	Start request	Bit 13 of 6.16 Drive status word 1 (page 162).	16
	Open brake command	Bit 0 of 44.1 Brake control status (page 420).	22
	Ext2 active	Bit 11 of 6.16 Drive status word 1 (page 162).	23
	Remote control	Bit 9 of 6.11 Main status word (page 162).	24
	Supervision 1	Bit 0 of 32.1 Supervision status (page 362).	33
	Supervision 2	Bit 1 of 32.1 Supervision status (page 362).	34
	Supervision 3	Bit 2 of 32.1 Supervision status (page 362).	35
	RO/DIO control word bit0	Bit 0 of 10.99 RO/DIO control word (page 189).	40

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	RO/DIO control word bit1	Bit 1 of <a href="#">10.99 RO/DIO control word</a> (page 189).	41
	RO/DIO control word bit2	Bit 2 of <a href="#">10.99 RO/DIO control word</a> (page 189).	42
	RO/DIO control word bit8	Bit 8 of <a href="#">10.99 RO/DIO control word</a> (page 189).	43
	RO/DIO control word bit9	Bit 9 of <a href="#">10.99 RO/DIO control word</a> (page 189).	44
	Other [bit]	See <a href="#">Terms and abbreviations</a> (page 134).	-
10.31	RO3 ON delay	<p>Defines the activation delay for relay output RO3.</p> <p><math>t_{On}</math> = <a href="#">10.31 RO3 ON delay</a>  <math>t_{Off}</math> = <a href="#">10.32 RO3 OFF delay</a></p>	0.0 s / uint32
	0.0 ... 3000.0 s	Activation delay for RO3.	10 = 1 s / 10 = 1 s
10.32	RO3 OFF delay	<p>Defines the deactivation delay for relay output RO3.  See parameter <a href="#">10.31 RO3 ON delay</a>.</p>	0.0 s / uint32
	0.0 ... 3000.0 s	Deactivation delay for RO3.	10 = 1 s / 10 = 1 s
10.51	DI filter time	<p>Defines a filtering time for parameters <a href="#">10.1 DI status</a> and <a href="#">10.2 DI delayed status</a>.</p> <p>Note that this parameter has no effect on forced DI values defined by parameters <a href="#">10.3</a> and <a href="#">10.4</a>.</p>	10.0 ms / uint32
	0.3 ... 100.0 ms	Filtering time for <a href="#">10.1</a> and <a href="#">10.2</a> .	10 = 1 ms / 10 = 1 ms
10.90	I/O time level selection	Selects the standard I/O communication time level.	Fast / uint16
	Fast	Standard I/O time level 500 us.	500
	Normal	Standard I/O time level 2 ms.	2000
10.99	RO/DIO control word	<p>Storage parameter for controlling the relay outputs and digital input/outputs eg. through the embedded fieldbus interface.</p> <p>To control the relay outputs (RO) and the digital input/outputs (DIO) of the drive, send a control word with the bit assignments shown below as Modbus I/O data. Set the target selection parameter of that particular data (<a href="#">58.101</a>...<a href="#">58.124</a>) to <a href="#">RO/DIO control word</a>. In the source selection parameter of the desired output, select the appropriate bit of this word.</p>	- / uint16
	b0 RO1	Source bit for relay output RO1. See parameter <a href="#">10.24</a> .	
	b1 RO2	Source bit for relay output RO2. See parameter <a href="#">10.27</a> .	
	b2 RO3	Source bit for relay output RO3. See parameter <a href="#">10.30</a> .	

## 190 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
b3...7	Reserved		
b8	DIO1	Source bit for digital input/output DIO1 (see parameter <a href="#">11.6</a> ).	
b9	DIO2	Source bit for digital input/output DIO2 (see parameter <a href="#">11.10</a> ).	
b10...15	Reserved		
	0000h...FFFFh		1 = 1 / 1 = 1

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
<b>11</b>	Standard DIO, FI, FO	Configuration of digital input/outputs and frequency inputs/outputs.	
11.1	DIO status	Displays the status of digital input/outputs DIO2 and DIO1.  The activation/deactivation delays (if any are specified) are ignored. A filtering time (for input mode) can be defined by parameter <a href="#">11.81 DIO filter time</a> . <b>Example:</b> 0010 = DIO2 is on, DIO1 is off.  This parameter is read-only.	- / uint16
11.2	DIO delayed status	Displays the delayed status of digital input/outputs DIO2 and DIO1. This word is updated only after activation/deactivation delays (if any are specified). A filtering time (for input mode) can be defined by parameter <a href="#">11.81 DIO filter time</a> . <b>Example:</b> 0010 = DIO2 is on, DIO1 is off.  This parameter is read-only.	- / uint16
11.5	DIO1 function	Selects whether DIO1 is used as a digital output or input, or a frequency input.	Output / uint16
	Output	DIO1 is used as a digital output.	0
	Input	DIO1 is used as a digital input.	1
	Frequency	DIO1 is used as a frequency input.	2
11.6	DIO1 output source	Selects a drive signal to be connected to digital input/output DIO1 when parameter <a href="#">11.5 DIO1 function</a> is set to <a href="#">Output</a> .	Ready run / uint32
	Not energized	Output is not energized.	0
	Energized	Output is energized.	1
	Ready run	Bit 1 of <a href="#">6.11 Main status word (page 162)</a> .	2
	Enabled	Bit 0 of <a href="#">6.16 Drive status word 1 (page 162)</a> .	4
	Started	Bit 5 of <a href="#">6.16 Drive status word 1 (page 162)</a> .	5
	Magnetized	Bit 1 of <a href="#">6.17 Drive status word 2 (page 163)</a> .	6
	Running	Bit 6 of <a href="#">6.16 Drive status word 1 (page 162)</a> .	7
	Ready ref	Bit 2 of <a href="#">6.11 Main status word (page 162)</a> .	8
	At setpoint	Bit 8 of <a href="#">6.11 Main status word (page 162)</a> .	9
	Reverse	Bit 2 of <a href="#">6.19 Speed control status word (page 165)</a> .	10
	Zero speed	Bit 0 of <a href="#">6.19 Speed control status word (page 165)</a> .	11
	Above limit	Bit 10 of <a href="#">6.17 Drive status word 2 (page 163)</a> .	12
	Warning	Bit 7 of <a href="#">6.11 Main status word (page 162)</a> .	13
	Fault	Bit 3 of <a href="#">6.11 Main status word (page 162)</a> .	14
	Fault (-1)	Inverted bit 3 of <a href="#">6.11 Main status word (page 162)</a> .	15
	Start request	Bit 13 of <a href="#">6.16 Drive status word 1 (page 162)</a> .	16


192 Parameters


No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	Open brake command	Bit 0 of 44.1 Brake control status (page 420).	22
	Ext2 active	Bit 11 of 6.16 Drive status word 1 (page 162).	23
	Remote control	Bit 9 of 6.11 Main status word (page 162).	24
	Supervision 1	Bit 0 of 32.1 Supervision status (page 362).	33
	Supervision 2	Bit 1 of 32.1 Supervision status (page 362).	34
	Supervision 3	Bit 2 of 32.1 Supervision status (page 362).	35
	RO/DIO control word bit0	Bit 0 of 10.99 RO/DIO control word (page 189).	40
	RO/DIO control word bit1	Bit 1 of 10.99 RO/DIO control word (page 189).	41
	RO/DIO control word bit2	Bit 2 of 10.99 RO/DIO control word (page 189).	42
	RO/DIO control word bit8	Bit 8 of 10.99 RO/DIO control word (page 189).	43
	RO/DIO control word bit9	Bit 9 of 10.99 RO/DIO control word (page 189).	44
	Other [bit]	See Terms and abbreviations (page 134).	-
11.7	DIO1 ON delay	<p>Defines the activation delay for digital input/output DIO1 (when used as a digital output or digital input).</p> <p><math>t_{On}</math> = 11.7 DIO1 ON delay  <math>t_{Off}</math> = 11.8 DIO1 OFF delay</p> <p>*Electrical status of DIO (in input mode) or status of selected source (in output mode). Indicated by 11.1 DIO status.</p> <p>**Indicated by 11.2 DIO delayed status.</p>	0.0 s / uint32
	0.0 ... 3000.0 s	Activation delay for DIO1.	10 = 1 s / 10 = 1 s
11.8	DIO1 OFF delay	<p>Defines the deactivation delay for digital input/output DIO1 (when used as a digital output or digital input). See parameter 11.7 DIO1 ON delay.</p>	0.0 s / uint32
	0.0 ... 3000.0 s	Deactivation delay for DIO1.	10 = 1 s / 10 = 1 s
11.9	DIO2 function	Selects whether DIO2 is used as a digital output or input, or a frequency output.	Output / uint16
	Output	DIO2 is used as a digital output.	0
	Input	DIO2 is used as a digital input.	1
	Frequency	DIO2 is used as a frequency output.	2



No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
11.10	DIO2 output source	Selects a drive signal to be connected to digital input/output DIO2 when parameter 11.9 DIO2 function is set to <a href="#">Output</a> .	Running / uint32
	Not energized	Output is not energized.	0
	Energized	Output is energized.	1
	Ready run	Bit 1 of <a href="#">6.11 Main status word (page 162)</a> .	2
	Enabled	Bit 0 of <a href="#">6.16 Drive status word 1 (page 162)</a> .	4
	Started	Bit 5 of <a href="#">6.16 Drive status word 1 (page 162)</a> .	5
	Magnetized	Bit 1 of <a href="#">6.17 Drive status word 2 (page 163)</a> .	6
	Running	Bit 6 of <a href="#">6.16 Drive status word 1 (page 162)</a> .	7
	Ready ref	Bit 2 of <a href="#">6.11 Main status word (page 162)</a> .	8
	At setpoint	Bit 8 of <a href="#">6.11 Main status word (page 162)</a> .	9
	Reverse	Bit 2 of <a href="#">6.19 Speed control status word (page 165)</a> .	10
	Zero speed	Bit 0 of <a href="#">6.19 Speed control status word (page 165)</a> .	11
	Above limit	Bit 10 of <a href="#">6.17 Drive status word 2 (page 163)</a> .	12
	Warning	Bit 7 of <a href="#">6.11 Main status word (page 162)</a> .	13
	Fault	Bit 3 of <a href="#">6.11 Main status word (page 162)</a> .	14
	Fault (-1)	Inverted bit 3 of <a href="#">6.11 Main status word (page 162)</a> .	15
	Start request	Bit 13 of <a href="#">6.16 Drive status word 1 (page 162)</a> .	16
	Open brake command	Bit 0 of <a href="#">44.1 Brake control status (page 420)</a> .	22
	Ext2 active	Bit 11 of <a href="#">6.16 Drive status word 1 (page 162)</a> .	23
	Remote control	Bit 9 of <a href="#">6.11 Main status word (page 162)</a> .	24
	Supervision 1	Bit 0 of <a href="#">32.1 Supervision status (page 362)</a> .	33
	Supervision 2	Bit 1 of <a href="#">32.1 Supervision status (page 362)</a> .	34
	Supervision 3	Bit 2 of <a href="#">32.1 Supervision status (page 362)</a> .	35
	RO/DIO control word bit0	Bit 0 of <a href="#">10.99 RO/DIO control word (page 189)</a> .	40
	RO/DIO control word bit1	Bit 1 of <a href="#">10.99 RO/DIO control word (page 189)</a> .	41
	RO/DIO control word bit2	Bit 2 of <a href="#">10.99 RO/DIO control word (page 189)</a> .	42
	RO/DIO control word bit8	Bit 8 of <a href="#">10.99 RO/DIO control word (page 189)</a> .	43
	RO/DIO control word bit9	Bit 9 of <a href="#">10.99 RO/DIO control word (page 189)</a> .	44
	Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-


194 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
11.11	DIO2 ON delay	<p>Defines the activation delay for digital input/output DIO2 (when used as a digital output or digital input).</p>  <p><math>t_{On}</math> = 11.11 DIO2 ON delay  <math>t_{Off}</math> = 11.12 DIO2 OFF delay</p> <p>*Electrical status of DIO (in input mode) or status of selected source (in output mode). Indicated by <a href="#">11.1 DIO status</a>.</p> <p>**Indicated by <a href="#">11.2 DIO delayed status</a>.</p>	0.0 s / uint32
	0.0 ... 3000.0 s	Activation delay for DIO2.	10 = 1 s / 10 = 1 s
11.12	DIO2 OFF delay	<p>Defines the deactivation delay for digital input/output DIO2 (when used as a digital output or digital input). See parameter <a href="#">11.11 DIO2 ON delay</a>.</p>	0.0 s / uint32
	0.0 ... 3000.0 s	Deactivation delay for DIO2.	10 = 1 s / 10 = 1 s
11.38	Freq in 1 actual value	<p>Displays the value of frequency input 1 (via DIO1 when it is used as a frequency input) before scaling. See parameter <a href="#">11.42 Freq in 1 min</a>.</p> <p>This parameter is read-only.</p>	- / real32
	0...16000 Hz	Unscaled value of frequency input 1.	1 = 1 Hz / 1 = 1 Hz
11.39	Freq in 1 scaled	<p>Displays the value of frequency input 1 (via DIO1 when it is used as a frequency input) after scaling. See parameter <a href="#">11.42 Freq in 1 min</a>.</p> <p>This parameter is read-only.</p>	- / real32
	-32768.000 ... 32767.000	Scaled value of frequency input 1.	1 = 1 / 1000 = 1

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
11.42	Freq in 1 min	<p>Defines the minimum for the frequency actually arriving at frequency input 1 (DIO1 when it is used as a frequency input).</p> <p>The incoming frequency signal (11.38 Freq in 1 actual value) is scaled into an internal signal (11.39 Freq in 1 scaled) by parameters 11.42...11.45 as follows:</p> 	0 Hz / real32
	0...16000 Hz	Minimum frequency of frequency input 1 (DIO1).	1 = 1 Hz / 1 = 1 Hz
11.43	Freq in 1 max	<p>Defines the maximum for the frequency actually arriving at frequency input 1 (DIO1 when it is used as a frequency input).</p> <p>See parameter 11.42 Freq in 1 min.</p>	16000 Hz / real32
	0...16000 Hz	Maximum frequency for frequency input 1 (DIO1).	1 = 1 Hz / 1 = 1 Hz
11.44	Freq in 1 at scaled min	Defines the value that is required to correspond internally to the minimum input frequency defined by parameter 11.42 Freq in 1 min. See diagram at parameter 11.42 Freq in 1 min.	0.000 / real32
	-32768.000 ... 32767.000	Value corresponding to minimum of frequency input 1.	1 = 1 / 1000 = 1
11.45	Freq in 1 at scaled max	Defines the value that is required to correspond internally to the maximum input frequency defined by parameter 11.43 Freq in 1 max. See diagram at parameter 11.42 Freq in 1 min.	1500.000; 1800.000 (95.20 b0) / real32
	-32768.000 ... 32767.000	Value corresponding to maximum of frequency input 1.	1 = 1 / 1000 = 1
11.54	Freq out 1 actual value	<p>Displays the value of frequency output 1 after scaling.</p> <p>See parameter 11.58 Freq out 1 src min.</p> <p>This parameter is read-only.</p>	- / real32
	0...16000 Hz	Value of frequency output 1.	1 = 1 Hz / 1 = 1 Hz
11.55	Freq out 1 source	Selects a signal to be connected to frequency output 1.	Motor speed used / uint32
	Zero	None	0

# 196 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	Motor speed used	<a href="#">1.1 Motor speed used (page 138).</a>	1
	Output frequency	<a href="#">1.6 Output frequency (page 138).</a>	3
	Motor current	<a href="#">1.7 Motor current (page 138).</a>	4
	Motor torque	<a href="#">1.10 Motor torque (page 138).</a>	6
	DC voltage	<a href="#">1.11 DC voltage (page 139).</a>	7
	Power inu out	<a href="#">1.14 Output power (page 139).</a>	8
	Speed ref ramp in	<a href="#">23.1 Speed ref ramp input (page 288).</a>	10
	Speed ref ramp out	<a href="#">23.2 Speed ref ramp output (page 288).</a>	11
	Speed ref used	<a href="#">24.1 Used speed reference (page 295).</a>	12
	Torq ref used	<a href="#">26.2 Torque reference used (page 314).</a>	13
	Freq ref used	<a href="#">28.2 Frequency ref ramp output (page 323).</a>	14
	Process PID out	<a href="#">40.1 Process PID output actual (page 399).</a>	16
	Process PID fbk	<a href="#">40.2 Process PID feedback actual (page 399).</a>	17
	Process PID act	<a href="#">40.3 Process PID setpoint actual (page 399).</a>	18
	Process PID dev	<a href="#">40.4 Process PID deviation actual (page 399).</a>	19
	Other [bit]	Source selection (see <a href="#">Terms and abbreviations (page 134)</a> ).	-



No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
11.58	Freq out 1 src min	<p>Defines the real value of the signal (selected by parameter <a href="#">11.55 Freq out 1 source</a> and shown by parameter <a href="#">11.54 Freq out 1 actual value</a>) that corresponds to the minimum value of frequency output 1 (defined by parameter <a href="#">11.60 Freq out 1 at src min</a>).</p>  <p>The top graph shows a signal value (x-axis) increasing from 11.60 to 11.59. The frequency output <math>f_{out}(11.54)</math> (y-axis) is constant at 11.60 for signal values up to 11.58, then increases linearly to 11.61 at signal value 11.59, and remains constant thereafter.</p> <p>The bottom graph shows a signal value (x-axis) decreasing from 11.59 to 11.58. The frequency output <math>f_{out}(11.54)</math> (y-axis) is constant at 11.61 for signal values up to 11.59, then decreases linearly to 11.60 at signal value 11.58, and remains constant thereafter.</p>	0.000 / real32
	-32768.000 ... 32767.000	Real signal value corresponding to minimum value of frequency output 1.	1 = 1 / 1000 = 1
11.59	Freq out 1 src max	<p>Defines the real value of the signal (selected by parameter <a href="#">11.55 Freq out 1 source</a> and shown by parameter <a href="#">11.54 Freq out 1 actual value</a>) that corresponds to the maximum value of frequency output 1 (defined by parameter <a href="#">11.61 Freq out 1 at src max</a>). See parameter <a href="#">11.58 Freq out 1 src min</a>.</p>	1500.000; 1800.000 (95.20 b0) / real32
	-32768.000 ... 32767.000	Real signal value corresponding to maximum value of frequency output 1.	1 = 1 / 1000 = 1
11.60	Freq out 1 at src min	Defines the minimum value of frequency output 1. See diagrams at parameter <a href="#">11.58 Freq out 1 src min</a> .	0 Hz / real32
	0...16000 Hz	Minimum value of frequency output 1.	1 = 1 Hz / 1 = 1 Hz
11.61	Freq out 1 at src max	Defines the maximum value of frequency output 1. See diagrams at parameter <a href="#">11.58 Freq out 1 src min</a> .	16000 Hz / real32
	0...16000 Hz	Maximum value of frequency output 1.	1 = 1 Hz / 1 = 1 Hz

## 198 Parameters


No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
11.81	DIO filter time	Defines a filtering time for parameter <a href="#">11.1 DIO status</a> and <a href="#">11.2 DIO delayed status</a> . The filtering time will only affect the DIOs that are in input mode.	10.0 ms / uint32
	0.3 ... 100.0 ms	Filtering time for <a href="#">11.1</a> .	10 = 1 ms / 10 = 1 ms

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
<b>12</b>	Standard AI	Configuration of standard analog inputs.	
12.1	AI tune	Triggers the analog input tuning function. Connect the signal to the input and select the appropriate tuning function.	No action / uint16
	No action	AI tune is not activated.	0
	AI1 min tune	Current analog input AI1 signal value is set as minimum value of AI1 into parameter <a href="#">12.17 AI1 min</a> . The value reverts back to <a href="#">No action</a> automatically.	1
	AI1 max tune	Current analog input AI1 signal value is set as maximum value of AI1 into parameter <a href="#">12.18 AI1 max</a> . The value reverts back to <a href="#">No action</a> automatically.	2
	AI2 min tune	Current analog input AI2 signal value is set as minimum value of AI2 into parameter <a href="#">12.27 AI2 min</a> . The value reverts back to <a href="#">No action</a> automatically.	3
	AI2 max tune	Current analog input AI2 signal value is set as maximum value of AI2 into parameter <a href="#">12.28 AI2 max</a> . The value reverts back to <a href="#">No action</a> automatically.	4
12.3	AI supervision function	Selects how the drive reacts when an analog input signal moves out of the minimum and/or maximum limits specified for the input.  The supervision applies a margin of 0.5 V or 1.0 mA to the limits. For example, if the maximum limit for the input is 7.000 V, the maximum limit supervision activates at 7.500 V.  The inputs and the limits to be observed are selected by parameter <a href="#">12.4 AI supervision selection</a> .  <b>Note:</b> Analog input signal supervision is only active when <ul style="list-style-type: none"> <li>the analog input is set as the source (using the AI1 scaled or AI2 scaled selection) in parameter <a href="#">22.11</a>, <a href="#">22.12</a>, <a href="#">22.15</a>, <a href="#">22.17</a>, <a href="#">23.42</a>, <a href="#">26.11</a>, <a href="#">26.12</a>, <a href="#">26.16</a>, <a href="#">26.25</a>, <a href="#">28.11</a>, <a href="#">28.12</a>, <a href="#">30.21</a>, <a href="#">30.22</a>, <a href="#">40.16</a>, <a href="#">40.17</a>, <a href="#">40.50</a>, <a href="#">41.16</a>, <a href="#">41.17</a>, <a href="#">41.50</a> or <a href="#">44.9</a>, and is being used as the active source, or</li> <li>supervision is forced using parameter <a href="#">12.5 AI supervision force</a>.</li> </ul>	No action / uint16
	No action	No action taken.	0
	Fault	Drive trips on <a href="#">80A0 AI Supervision</a> .	1
	Warning	Drive generates an <a href="#">A8A0 AI Supervised Warning</a> warning.	2


200 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	Last speed	Drive generates a warning ( <a href="#">A8A0 AI Supervised Warning</a> ) and freezes the speed (or frequency) to the level the drive was operating at. The speed/frequency is determined on the basis of actual speed using 850 ms low-pass filtering.   <b>WARNING!</b> Make sure that it is safe to continue operation in case of a communication break.	3
	Speed ref safe	Drive generates a warning ( <a href="#">A8A0 AI Supervised Warning</a> ) and sets the speed to the speed defined by parameter <a href="#">22.41 Speed ref safe</a> (or <a href="#">28.41 Frequency ref safe</a> when frequency reference is being used).   <b>WARNING!</b> Make sure that it is safe to continue operation in case of a communication break.	4
12.4	AI supervision selection	Specifies the analog input limits to be supervised. See parameter <a href="#">12.3 AI supervision function</a> .	- / uint16
b0	AI1 < MIN	1 = Minimum limit supervision of AI1 active.	
b1	AI1 > MAX	1 = Maximum limit supervision of AI1 active.	
b2	AI2 < MIN	1 = Minimum limit supervision of AI2 active.	
b3	AI2 > MAX	1 = Maximum limit supervision of AI2 active.	
b4...15	Reserved		
	0000h...FFFFh		1 = 1 / 1 = 1
12.5	AI supervision force	Activates analog input supervision separately for each control location (see section <a href="#">Local control vs. external control (page 23)</a> ).  The parameter is primarily intended for analog input supervision when the input is connected to the application program and not selected as a control source by drive parameters.	0000 0000b / uint16
b0	AI1 Ext 1	1 = AI1 supervision active when EXT1 is being used.	
b1	AI1 Ext 2	1 = AI1 supervision active when EXT2 is being used.	
b2	AI1 Local	1 = AI1 supervision active when local control is being used.	
b3	Reserved		
b4	AI2 Ext 1	1 = AI2 supervision active when EXT1 is being used.	
b5	AI2 Ext 2	1 = AI2 supervision active when EXT2 is being used.	
b6	AI2 Local	1 = AI2 supervision active when local control is being used.	
b7...15	Reserved		
	0000 0000b...0111 0111b		1 = 1 / 1 = 1




No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
12.11	AI1 actual value	Displays the value of analog input AI1 in mA or V (depending on whether the input is set to current or voltage by a hardware setting). This parameter is read-only.	- / real32
	-22.000 ... 22.000 mA or V	Value of analog input AI1.	1000 = 1 mA or V / 1000 = 1 mA or V
12.12	AI1 scaled value	Displays the value of analog input AI1 after scaling. See parameters <a href="#">12.19 AI1 scaled at AI1 min</a> and <a href="#">12.20 AI1 scaled at AI1 max</a> . This parameter is read-only.	- / real32
	-32768.000 ... 32767.000	Scaled value of analog input AI1.	1 = 1 / 1000 = 1
12.15	AI1 unit selection	Selects the unit for readings and settings related to analog input AI1.  <b>Note:</b> This setting must match the corresponding hardware setting on the drive control unit (see the hardware manual of the drive). Control board reboot (either by cycling the power or through parameter <a href="#">96.8 Control board boot</a> ) is required to validate any changes in the hardware settings.	V / uint16
	V	Volts.	2
	mA	Milliamperes.	10
12.16	AI1 filter time	Defines the filter time constant for analog input AI1.   $O = I \times (1 - e^{-t/T})$ <p> <math>I</math> = filter input (step)  <math>O</math> = filter output  <math>t</math> = time  <math>T</math> = filter time constant         </p> <b>Note:</b> The signal is also filtered due to the signal interface hardware (approximately 0.25 ms time constant). This cannot be changed by any parameter.	0.100 s / real32
	0.000 ... 30.000 s	Filter time constant.	1000 = 1 s / 1000 = 1 s

## 202 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
12.17	AI1 min	Defines the minimum site value for analog input AI1. Set the value actually sent to the drive when the analog signal from plant is wound to its minimum setting. See also parameter <a href="#">12.1 AI tune</a> .	0.000 mA or V / real32
	-22.000 ... 22.000 mA or V	Minimum value of AI1.	1000 = 1 mA or V / 1000 = 1 mA or V
12.18	AI1 max	Defines the maximum site value for analog input AI1. Set the value actually sent to the drive when the analog signal from plant is wound to its maximum setting. See also parameter <a href="#">12.1 AI tune</a> .	20.000 mA or V / real32
	-22.000 ... 22.000 mA or V	Maximum value of AI1.	1000 = 1 mA or V / 1000 = 1 mA or V
12.19	AI1 scaled at AI1 min	Defines the real internal value that corresponds to the minimum analog input AI1 value defined by parameter <a href="#">12.17 AI1 min</a> . (Changing the polarity settings of <a href="#">12.19</a> and <a href="#">12.20</a> can effectively invert the analog input.)  	0.000 / real32
	-32768.000 ... 32767.000	Real value corresponding to minimum AI1 value.	1 = 1 / 1000 = 1
12.20	AI1 scaled at AI1 max	Defines the real internal value that corresponds to the maximum analog input AI1 value defined by parameter <a href="#">12.18 AI1 max</a> . See the drawing at parameter <a href="#">12.19 AI1 scaled at AI1 min</a> .	1500.000; 1800.000 (95.20 b0) / real32
	-32768.000 ... 32767.000	Real value corresponding to maximum AI1 value.	1 = 1 / 1000 = 1
12.21	AI2 actual value	Displays the value of analog input AI2 in mA or V (depending on whether the input is set to current or voltage by a hardware setting).  This parameter is read-only	- / real32
	-22.000 ... 22.000 mA or V	Value of analog input AI2.	1000 = 1 mA or V / 1000 = 1 mA or V


No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
12.22	AI2 scaled value	Displays the value of analog input AI2 after scaling. See parameters <a href="#">12.29 AI2 scaled at AI2 min</a> and <a href="#">12.30 AI2 scaled at AI2 max</a> . This parameter is read-only.	- / real32
	-32768.000 ... 32767.000	Scaled value of analog input AI2.	1 = 1 / 1000 = 1
12.25	AI2 unit selection	Selects the unit for readings and settings related to analog input AI2.  <b>Note:</b> This setting must match the corresponding hardware setting on the drive control unit (see the hardware manual of the drive). Control board reboot (either by cycling the power or through parameter <a href="#">96.8 Control board boot</a> ) is required to validate any changes in the hardware settings.	mA / uint16
	V	Volts.	2
	mA	Milliamperes.	10
12.26	AI2 filter time	Defines the filter time constant for analog input AI2. See parameter <a href="#">12.16 AI1 filter time</a> .	0.100 s / real32
	0.000 ... 30.000 s	Filter time constant.	1000 = 1 s / 1000 = 1 s
12.27	AI2 min	Defines the minimum site value for analog input AI2. Set the value actually sent to the drive when the analog signal from plant is wound to its minimum setting. See also parameter <a href="#">12.1 AI tune</a> .	0.000 mA or V / real32
	-22.000 ... 22.000 mA or V	Minimum value of AI2.	1000 = 1 mA or V / 1000 = 1 mA or V
12.28	AI2 max	Defines the maximum site value for analog input AI2. Set the value actually sent to the drive when the analog signal from plant is wound to its maximum setting. See also parameter <a href="#">12.1 AI tune</a> .	20.000 mA or V / real32
	-22.000 ... 22.000 mA or V	Maximum value of AI2.	1000 = 1 mA or V / 1000 = 1 mA or V



## 204 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
12.29	AI2 scaled at AI2 min	Defines the real value that corresponds to the minimum analog input AI2 value defined by parameter <a href="#">12.27 AI2 min</a> . (Changing the polarity settings of <a href="#">12.29</a> and <a href="#">12.30</a> can effectively invert the analog input.)  <p>The graph shows a coordinate system with a vertical axis labeled <math>AI_{scaled}(12.22)</math> and a horizontal axis labeled <math>AI_{in}(12.21)</math>. The origin is at the center. A solid line represents the scaling function. It is horizontal at a negative value for <math>AI_{in}</math> values less than 12.27. At <math>AI_{in} = 12.27</math>, the line begins to rise linearly, passing through the origin. At <math>AI_{in} = 12.28</math>, the line becomes horizontal again at a positive value. Dashed lines indicate the points (12.27, 12.29) and (12.28, 12.30) on the graph.</p>	0.000 / real32
	-32768.000 ... 32767.000	Real value corresponding to minimum AI2 value.	1 = 1 / 1000 = 1
12.30	AI2 scaled at AI2 max	Defines the real value that corresponds to the maximum analog input AI2 value defined by parameter <a href="#">12.28 AI2 max</a> . See the drawing at parameter <a href="#">12.29 AI2 scaled at AI2 min</a> .	100.000 / real32
	-32768.000 ... 32767.000	Real value corresponding to maximum AI2 value.	1 = 1 / 1000 = 1

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
<b>13</b>	Standard AO	Configuration of standard analog outputs.	
13.11	AO1 actual value	Displays the value of AO1 in mA. This parameter is read-only.	- / real32
	0.000 ... 22.000 mA	Value of AO1.	1000 = 1 mA / 1000 = 1 mA
13.12	AO1 source	Selects a signal to be connected to analog output AO1. Alternatively, sets the output to excitation mode to feed a constant current to a temperature sensor.	Motor speed used / uint32
	Zero	None	0
	Motor speed used	<a href="#">1.1 Motor speed used (page 138)</a> .	1
	Output frequency	<a href="#">1.6 Output frequency (page 138)</a> .	3
	Motor current	<a href="#">1.7 Motor current (page 138)</a> .	4
	Motor torque	<a href="#">1.10 Motor torque (page 138)</a> .	6
	DC voltage	<a href="#">1.11 DC voltage (page 139)</a> .	7
	Power inu out	<a href="#">1.14 Output power (page 139)</a> .	8
	Speed ref ramp in	<a href="#">23.1 Speed ref ramp input (page 288)</a> .	10
	Speed ref ramp out	<a href="#">23.2 Speed ref ramp output (page 288)</a> .	11
	Speed ref used	<a href="#">24.1 Used speed reference (page 295)</a> .	12
	Torq ref used	<a href="#">26.2 Torque reference used (page 314)</a> .	13
	Freq ref used	<a href="#">28.2 Frequency ref ramp output (page 323)</a> .	14
	Process PID out	<a href="#">40.1 Process PID output actual (page 399)</a> .	16
	Process PID fbk	<a href="#">40.2 Process PID feedback actual (page 399)</a> .	17
	Process PID act	<a href="#">40.3 Process PID setpoint actual (page 399)</a> .	18
	Process PID dev	<a href="#">40.4 Process PID deviation actual (page 399)</a> .	19
	Other [bit]	Source selection (see <a href="#">Terms and abbreviations (page 134)</a> ).	-
	Force Pt100 excitation	The output is used to feed an excitation current to 1...3 Pt100 sensors. See section <a href="#">Motor thermal protection (page 90)</a> .	20
	Force KTY84 excitation	The output is used to feed an excitation current to a KTY84 sensor. See section <a href="#">Motor thermal protection (page 90)</a> .	21
	Force PTC excitation	The output is used to feed an excitation current to 1...3 PTC sensors. See section <a href="#">Motor thermal protection (page 90)</a> .	22
	Force Pt1000 excitation	The output is used to feed an excitation current to 1...3 Pt1000 sensors. See section <a href="#">Motor thermal protection (page 90)</a> .	23
	AO1 data storage	<a href="#">13.91 AO1 data storage (page 210)</a> .	37
	AO2 data storage	<a href="#">13.92 AO2 data storage (page 210)</a> .	38

## 206 Parameters



No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
13.16	AO1 filter time	<p>Defines the filtering time constant for analog output AO1.</p>  <p> <math>O = I \times (1 - e^{-t/T})</math>  <math>I</math> = filter input (step)  <math>O</math> = filter output  <math>t</math> = time  <math>T</math> = filter time constant         </p>	0.100 s / real32
	0.000 ... 30.000 s	Filter time constant.	1000 = 1 s / 1000 = 1 s

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
13.17	AO1 source min	<p>Defines the real minimum value of the signal (selected by parameter <a href="#">13.12 AO1 source</a>) that corresponds to the minimum required AO1 output value (defined by parameter <a href="#">13.19 AO1 out at AO1 src min</a>).</p>  <p>Programming <a href="#">13.17</a> as the maximum value and <a href="#">13.18</a> as the minimum value inverts the output.</p> 	0.0 / real32
	-32768.0 ... 32767.0	Real signal value corresponding to minimum AO1 output value.	1 = 1 / 10 = 1
13.18	AO1 source max	Defines the real maximum value of the signal (selected by parameter <a href="#">13.12 AO1 source</a> ) that corresponds to the maximum required AO1 output value (defined by parameter <a href="#">13.20 AO1 out at AO1 src max</a> ). See parameter <a href="#">13.17 AO1 source min</a> .	1500.000; 1800.000 (95.20 b0) / real32
	-32768.0 ... 32767.0	Real signal value corresponding to maximum AO1 output value.	1 = 1 / 10 = 1
13.19	AO1 out at AO1 src min	Defines the minimum output value for analog output AO1. See also drawing at parameter <a href="#">13.17 AO1 source min</a> .	0.000 mA / real32
	0.000 ... 22.000 mA	Minimum AO1 output value.	1000 = 1 mA / 1000 = 1 mA

## 208 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
13.20	AO1 out at AO1 src max	Defines the maximum output value for analog output AO1. See also drawing at parameter <a href="#">13.17 AO1 source min.</a>	20.000 mA / real32
	0.000 ... 22.000 mA	Maximum AO1 output value.	1000 = 1 mA / 1000 = 1 mA
13.21	AO2 actual value	Displays the value of AO2 in mA. This parameter is read-only.	- / real32
	0.000 ... 22.000 mA	Value of AO2.	1000 = 1 mA / 1000 = 1 mA
13.22	AO2 source	Selects a signal to be connected to analog output AO2. Alternatively, sets the output to excitation mode to feed a constant current to a temperature sensor. For the selections, see parameter <a href="#">13.12 AO1 source.</a>	Motor current / uint32
13.26	AO2 filter time	Defines the filtering time constant for analog output AO2. See parameter <a href="#">13.16 AO1 filter time.</a>	0.100 s / real32
	0.000 ... 30.000 s	Filter time constant.	1000 = 1 s / 1000 = 1 s



No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
13.27	AO2 source min	<p>Defines the real minimum value of the signal (selected by parameter <a href="#">13.22 AO2 source</a>) that corresponds to the minimum required AO2 output value (defined by parameter <a href="#">13.29 AO2 out at AO2 src min</a>).</p>  <p>Programming <a href="#">13.27</a> as the maximum value and <a href="#">13.28</a> as the minimum value inverts the output.</p> 	0.0 / real32
	-32768.0 ... 32767.0	Real signal value corresponding to minimum AO2 output value.	1 = 1 / 10 = 1
13.28	AO2 source max	Defines the real maximum value of the signal (selected by parameter <a href="#">13.22 AO2 source</a> ) that corresponds to the maximum required AO2 output value (defined by parameter <a href="#">13.30 AO2 out at AO2 src max</a> ). See parameter <a href="#">13.27 AO2 source min</a> .	100.0 / real32
	-32768.0 ... 32767.0	Real signal value corresponding to maximum AO2 output value.	1 = 1 / 10 = 1
13.29	AO2 out at AO2 src min	Defines the minimum output value for analog output AO2. See also drawing at parameter <a href="#">13.27 AO2 source min</a> .	0.000 mA / real32
	0.000 ... 22.000 mA	Minimum AO2 output value.	1000 = 1 mA / 1000 = 1 mA

## 210 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
13.30	AO2 out at AO2 src max	Defines the maximum output value for analog output AO2. See also drawing at parameter <a href="#">13.27 AO2 source min.</a>	20.000 mA / real32
	0.000 ... 22.000 mA	Maximum AO2 output value.	1000 = 1 mA / 1000 = 1 mA
13.91	AO1 data storage	Storage parameter for controlling analog output AO1 eg. through fieldbus. In <a href="#">13.12 AO1 source</a> , select <a href="#">AO1 data storage</a> . Then set this parameter as the target of the incoming value data. With the embedded fieldbus interface, simply set the target selection parameter of that particular data ( <a href="#">58.101...58.124</a> ) to <a href="#">AO1 data storage</a> .	0.00 / real32
	-327.68 ... 327.67	Storage parameter for AO1.	100 = 1 / 100 = 1
13.92	AO2 data storage	Storage parameter for controlling analog output AO2 eg. through fieldbus. In <a href="#">13.22 AO2 source</a> , select <a href="#">AO2 data storage</a> . Then set this parameter as the target of the incoming value data. With the embedded fieldbus interface, simply set the target selection parameter of that particular data ( <a href="#">58.101...58.124</a> ) to <a href="#">AO2 data storage</a> .	0.00 / real32
	-327.68 ... 327.67	Storage parameter for AO2.	100 = 1 / 100 = 1

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
<b>14</b>	I/O extension module 1	Configuration of I/O extension module 1. See also section <a href="#">Programmable I/O extensions (page 33)</a> . <b>Note:</b> The contents of the parameter group vary according to the selected I/O extension module type.	
14.1	Module 1 type	Activates (and specifies the type of) I/O extension module 1. <b>Note:</b> This parameter cannot be changed while the drive is running.	None / uint16
	None	Inactive.	0
	FIO-01	FIO-01.	1
	FIO-11	FIO-11.	2
	FAIO-01	FAIO-01.	4
	FDIO-01	FDIO-01.	3
14.2	Module 1 location	Specifies the slot (1...3) on the control unit of the drive into which the I/O extension module is installed. Alternatively, specifies the node ID of the slot on an FEA-03 extension adapter. <b>Note:</b> This parameter cannot be changed while the drive is running.	1 / uint16
	1...254	Slot 1 = 1; Slot 2 = 2; Slot 3 = 3. 4...254: Node ID of the slot on the FEA-03 extension adapter.	1 = 1 / 1 = 1
14.3	Module 1 status	Displays the status of I/O extension module 1.	No option / uint16
	No option	No module detected in the specified slot.	0
	No communication	A module has been detected but cannot be communicated with.	1
	Unknown	The module type is unknown.	2
	FIO-01	An FIO-01 module has been detected and is active.	15
	FIO-11	An FIO-11 module has been detected and is active.	20
	FAIO-01	An FAIO-01 module has been detected and is active.	24

## 212 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
14.5	DI status	<p>(Visible when <a href="#">14.1 Module 1 type = FDIO-01</a>)            Displays the status of the digital inputs on the extension module. The activation/deactivation delays (if any are specified) are ignored. A filtering time (for input mode) can be defined by parameter <a href="#">14.8 DI filter time</a>.</p> <p>Bit 0 indicates the status of DI1.</p> <p><b>Note:</b> The number of active bits in this parameter depends on the number of digital input/outputs on the extension module.</p> <p><b>Example:</b> 0101b = DI1 and DI3 are on, remainder are off.</p> <p>This parameter is read-only.</p>	- / uint16
14.5	DIO status	<p>(Visible when <a href="#">14.1 Module 1 type = FIO-11</a>)            Displays the status of the digital input/outputs on the extension module. The activation/deactivation delays (if any are specified) are ignored. A filtering time (for input mode) can be defined by parameter <a href="#">14.8 DIO filter time</a>.</p> <p>Bit 0 indicates the status of DIO1.</p> <p><b>Note:</b> The number of active bits in this parameter depends on the number of digital input/outputs on the extension module.</p> <p><b>Example:</b> 1001b = DIO1 and DIO4 are on, remainder are off.</p> <p>This parameter is read-only.</p>	- / uint16
14.5	DIO status	<p>(Visible when <a href="#">14.1 Module 1 type = FIO-01</a>)            Displays the status of the digital input/outputs on the extension module. The activation/deactivation delays (if any are specified) are ignored. A filtering time (for input mode) can be defined by parameter <a href="#">14.8 DIO filter time</a>.</p> <p>Bit 0 indicates the status of DIO1.</p> <p><b>Note:</b> The number of active bits in this parameter depends on the number of digital input/outputs on the extension module.</p> <p><b>Example:</b> 1001b = DIO1 and DIO4 are on, remainder are off.</p> <p>This parameter is read-only.</p>	- / uint16



No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
14.6	DI delayed status	<p>(Visible when <a href="#">14.1 Module 1 type = FDIO-01</a>)            Displays the delayed status of the digital inputs on the extension module. The word is updated only after activation/deactivation delays (if any are specified).            Bit 0 indicates the status of DI1.</p> <p><b>Note:</b> The number of active bits in this parameter depends on the number of digital inputs on the extension module.</p> <p><b>Example:</b> 0101b = DI1 and DI3 are on, remainder are off.</p> <p>This parameter is read-only.</p>	- / uint16
14.6	DIO delayed status	<p>(Visible when <a href="#">14.1 Module 1 type = FIO-11</a>)            Displays the delayed status of the digital input/outputs on the extension module. This word is updated only after activation/deactivation delays (if any are specified).            Bit 0 indicates the status of DIO1.</p> <p><b>Note:</b> The number of active bits in this parameter depends on the number of digital input/outputs on the extension module.</p> <p><b>Example:</b> 1001b = DIO1 and DIO4 are on, remainder are off.</p> <p>This parameter is read-only.</p>	- / uint16
14.6	DIO delayed status	<p>(Visible when <a href="#">14.1 Module 1 type = FIO-01</a>)            Displays the delayed status of the digital input/outputs on the extension module. This word is updated only after activation/deactivation delays (if any are specified).            Bit 0 indicates the status of DIO1.</p> <p><b>Note:</b> The number of active bits in this parameter depends on the number of digital input/outputs on the extension module.</p> <p><b>Example:</b> 1001b = DIO1 and DIO4 are on, remainder are off.</p> <p>This parameter is read-only.</p>	- / uint16
14.8	DI filter time	<p>(Visible when <a href="#">14.1 Module 1 type = FDIO-01</a>)            Defines a filtering time for parameters <a href="#">14.5 DI status</a> and <a href="#">14.6 DI delayed status</a>.</p>	10.0 ms / real32
	0.8 ... 100.0 ms	Filtering time for DI status parameters.	10 = 1 ms / 10 = 1 ms
14.8	DIO filter time	<p>(Visible when <a href="#">14.1 Module 1 type = FIO-11</a>)            Defines a filtering time for parameters <a href="#">14.5 DIO status</a> and <a href="#">14.6 DIO delayed status</a>. The filtering time will only affect the DIOs that are in input mode.</p>	10.0 ms / real32
	0.8 ... 100.0 ms	Filtering time for DIO status parameters.	10 = 1 ms / 10 = 1 ms

## 214 Parameters


No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
14.8	DIO filter time	(Visible when <a href="#">14.1 Module 1 type = FIO-01</a> ) Defines a filtering time for parameters <a href="#">14.5 DIO status</a> and <a href="#">14.6 DIO delayed status</a> . The filtering time will only affect the DIOs that are in input mode.	10.0 ms / real32
	0.8 ... 100.0 ms	Filtering time for DIO status parameters.	10 = 1 ms / 10 = 1 ms
14.9	DIO1 function	(Visible when <a href="#">14.1 Module 1 type = FIO-11</a> ) Selects whether DIO1 of the extension module is used as a digital input or output.	Input / uint16
	Output	DIO1 is used as a digital output.	0
	Input	DIO1 is used as a digital input.	1
14.9	DIO1 function	(Visible when <a href="#">14.1 Module 1 type = FIO-01</a> ) Selects whether DIO1 of the extension module is used as a digital input or output.	Input / uint16
	Output	DIO1 is used as a digital output.	0
	Input	DIO1 is used as a digital input.	1
14.11	DIO1 output source	(Visible when <a href="#">14.1 Module 1 type = FIO-11</a> ) Selects a drive signal to be connected to digital input/output DIO1 of the extension module when parameter <a href="#">14.9 DIO1 function</a> is set to Output.	Not energized / uint32
	Not energized	Output is not energized.	0
	Energized	Output is energized.	1
	Ready run	Bit 1 of <a href="#">6.11 Main status word (page 162)</a> .	2
	Enabled	Bit 0 of <a href="#">6.16 Drive status word 1 (page 162)</a> .	4
	Started	Bit 5 of <a href="#">6.16 Drive status word 1 (page 162)</a> .	5
	Magnetized	Bit 1 of <a href="#">6.17 Drive status word 2 (page 163)</a> .	6
	Running	Bit 6 of <a href="#">6.16 Drive status word 1 (page 162)</a> .	7
	Ready ref	Bit 2 of <a href="#">6.11 Main status word (page 162)</a> .	8
	At setpoint	Bit 8 of <a href="#">6.11 Main status word (page 162)</a> .	9
	Reverse	Bit 2 of <a href="#">6.19 Speed control status word (page 165)</a> .	10
	Zero speed	Bit 0 of <a href="#">6.19 Speed control status word (page 165)</a> .	11
	Above limit	Bit 10 of <a href="#">6.17 Drive status word 2 (page 163)</a> .	12
	Warning	Bit 7 of <a href="#">6.11 Main status word (page 162)</a> .	13
	Fault	Bit 3 of <a href="#">6.11 Main status word (page 162)</a> .	14
	Fault (-1)	Inverted bit 3 of <a href="#">6.11 Main status word (page 162)</a> .	15
	Start request	Bit 13 of <a href="#">6.16 Drive status word 1 (page 162)</a> .	16
	Open brake command	Bit 0 of <a href="#">44.1 Brake control status (page 420)</a> .	22
	Ext2 active	Bit 11 of <a href="#">6.16 Drive status word 1 (page 162)</a> .	23
	Remote control	Bit 9 of <a href="#">6.11 Main status word (page 162)</a> .	24
	Supervision 1	Bit 0 of <a href="#">32.1 Supervision status (page 362)</a> .	33
	Supervision 2	Bit 1 of <a href="#">32.1 Supervision status (page 362)</a> .	34

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	Supervision 3	Bit 2 of 32.1 Supervision status (page 362).	35
	RO/DIO control word bit0	Bit 0 of 10.99 RO/DIO control word (page 189).	40
	RO/DIO control word bit1	Bit 1 of 10.99 RO/DIO control word (page 189).	41
	RO/DIO control word bit2	Bit 2 of 10.99 RO/DIO control word (page 189).	42
	RO/DIO control word bit8	Bit 8 of 10.99 RO/DIO control word (page 189).	43
	RO/DIO control word bit9	Bit 9 of 10.99 RO/DIO control word (page 189).	44
	Other [bit]	See <a href="#">Terms and abbreviations</a> (page 134).	-
14.11	DIO1 output source	(Visible when 14.1 Module 1 type = FIO-01) Selects a drive signal to be connected to digital input/output DIO1 of the extension module when parameter 14.9 DIO1 function is set to Output.	Not energized / uint32
	Not energized	Output is not energized.	0
	Energized	Output is energized.	1
	Ready run	Bit 1 of 6.11 Main status word (page 162).	2
	Enabled	Bit 0 of 6.16 Drive status word 1 (page 162).	4
	Started	Bit 5 of 6.16 Drive status word 1 (page 162).	5
	Magnetized	Bit 1 of 6.17 Drive status word 2 (page 163).	6
	Running	Bit 6 of 6.16 Drive status word 1 (page 162).	7
	Ready ref	Bit 2 of 6.11 Main status word (page 162).	8
	At setpoint	Bit 8 of 6.11 Main status word (page 162).	9
	Reverse	Bit 2 of 6.19 Speed control status word (page 165).	10
	Zero speed	Bit 0 of 6.19 Speed control status word (page 165).	11
	Above limit	Bit 10 of 6.17 Drive status word 2 (page 163).	12
	Warning	Bit 7 of 6.11 Main status word (page 162).	13
	Fault	Bit 3 of 6.11 Main status word (page 162).	14
	Fault (-1)	Inverted bit 3 of 6.11 Main status word (page 162).	15
	Start request	Bit 13 of 6.16 Drive status word 1 (page 162).	16
	Open brake command	Bit 0 of 44.1 Brake control status (page 420).	22
	Ext2 active	Bit 11 of 6.16 Drive status word 1 (page 162).	23
	Remote control	Bit 9 of 6.11 Main status word (page 162).	24
	Supervision 1	Bit 0 of 32.1 Supervision status (page 362).	33
	Supervision 2	Bit 1 of 32.1 Supervision status (page 362).	34
	Supervision 3	Bit 2 of 32.1 Supervision status (page 362).	35

216 Parameters



No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	RO/DIO control word bit0	Bit 0 of 10.99 RO/DIO control word (page 189).	40
	RO/DIO control word bit1	Bit 1 of 10.99 RO/DIO control word (page 189).	41
	RO/DIO control word bit2	Bit 2 of 10.99 RO/DIO control word (page 189).	42
	RO/DIO control word bit8	Bit 8 of 10.99 RO/DIO control word (page 189).	43
	RO/DIO control word bit9	Bit 9 of 10.99 RO/DIO control word (page 189).	44
	Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-
14.12	DI1 ON delay	<p>(Visible when <a href="#">14.1 Module 1 type = FDIO-01</a>)            Defines the activation delay for digital input DI1.</p>  <p><math>t_{On}</math> = <a href="#">14.12 DI1 ON delay</a>  <math>t_{Off}</math> = <a href="#">14.13 DI1 OFF delay</a></p> <p>*Electrical status of DI or status of selected source (in output mode). Indicated by <a href="#">14.5 DI status</a>.            **Indicated by <a href="#">14.6 DI delayed status</a>.</p>	0.00 s / real32
	0.00 ... 3000.00 s	Activation delay for DI1.	10 = 1 s / 100 = 1 s
14.12	DIO1 ON delay	<p>(Visible when <a href="#">14.1 Module 1 type = FIO-11</a>)            Defines the activation delay for digital input/output DIO1.</p>  <p><math>t_{On}</math> = <a href="#">14.12 DIO1 ON delay</a>  <math>t_{Off}</math> = <a href="#">14.13 DIO1 OFF delay</a></p> <p>*Electrical status of DIO (in input mode) or status of selected source (in output mode). Indicated by <a href="#">14.5 DIO status</a>.            **Indicated by <a href="#">14.6 DIO delayed status</a>.</p>	0.00 s / real32
	0.00 ... 3000.00 s	Activation delay for DIO1.	10 = 1 s / 100 = 1 s



No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
14.12	DIO1 ON delay	<p>(Visible when <a href="#">14.1 Module 1 type = FIO-01</a>)            Defines the activation delay for digital input/output DIO1.</p>  <p><math>t_{On} = 14.12</math> DIO1 ON delay  <math>t_{Off} = 14.13</math> DIO1 OFF delay</p> <p>*Electrical status of DIO (in input mode) or status of selected source (in output mode). Indicated by <a href="#">14.5 DIO status</a>.</p> <p>**Indicated by <a href="#">14.6 DIO delayed status</a>.</p>	0.00 s / real32
	0.00 ... 3000.00 s	Activation delay for DIO1.	10 = 1 s / 100 = 1 s
14.13	DI1 OFF delay	<p>(Visible when <a href="#">14.1 Module 1 type = FDIO-01</a>)            Defines the deactivation delay for digital input DI1.            See parameter <a href="#">14.12 DI1 ON delay</a>.</p>	0.00 s / real32
	0.00 ... 3000.00 s	Deactivation delay for DI1.	10 = 1 s / 100 = 1 s
14.13	DIO1 OFF delay	<p>(Visible when <a href="#">14.1 Module 1 type = FIO-11</a>)            Defines the deactivation delay for digital input/output DIO1.            See parameter <a href="#">14.12 DIO1 ON delay</a>.</p>	0.00 s / real32
	0.00 ... 3000.00 s	Deactivation delay for DIO1.	10 = 1 s / 100 = 1 s
14.13	DIO1 OFF delay	<p>(Visible when <a href="#">14.1 Module 1 type = FIO-01</a>)            Defines the deactivation delay for digital input/output DIO1.            See parameter <a href="#">14.12 DIO1 ON delay</a>.</p>	0.00 s / real32
	0.00 ... 3000.00 s	Deactivation delay for DIO1.	10 = 1 s / 100 = 1 s
14.14	DIO2 function	<p>(Visible when <a href="#">14.1 Module 1 type = FIO-11</a>)            Selects whether DIO2 of the extension module is used as a digital input or output.</p>	Input / uint16
	Output	DIO2 is used as a digital output.	0
	Input	DIO2 is used as a digital input.	1
14.14	DIO2 function	<p>(Visible when <a href="#">14.1 Module 1 type = FIO-01</a>)            Selects whether DIO2 of the extension module is used as a digital input or output.</p>	Input / uint16
	Output	DIO2 is used as a digital output.	0
	Input	DIO2 is used as a digital input.	1

## 218 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
14.16	DIO2 output source	(Visible when <a href="#">14.1 Module 1 type = FIO-11</a> ) Selects a drive signal to be connected to digital input/output DIO2 when parameter <a href="#">14.14 DIO2 function</a> is set to <a href="#">Output</a> .  For the available selections, see parameter <a href="#">14.11 DIO1 output source</a> .	Not energized / uint32
14.16	DIO2 output source	(Visible when <a href="#">14.1 Module 1 type = FIO-01</a> ) Selects a drive signal to be connected to digital input/output DIO2 when parameter <a href="#">14.14 DIO2 function</a> is set to <a href="#">Output</a> .  For the available selections, see parameter <a href="#">14.11 DIO1 output source</a> .	Not energized / uint32
14.17	DI2 ON delay	(Visible when <a href="#">14.1 Module 1 type = FDIO-01</a> ) Defines the activation delay for digital input DI2. See parameter <a href="#">14.12 DI1 ON delay</a> .	0.00 s / real32
	0.00 ... 3000.00 s	Activation delay for DI2.	10 = 1 s / 100 = 1 s
14.17	DIO2 ON delay	(Visible when <a href="#">14.1 Module 1 type = FIO-11</a> ) Defines the activation delay for digital input/output DIO2. See parameter <a href="#">14.12 DIO1 ON delay</a> .	0.00 s / real32
	0.00 ... 3000.00 s	Activation delay for DIO2.	10 = 1 s / 100 = 1 s
14.17	DIO2 ON delay	(Visible when <a href="#">14.1 Module 1 type = FIO-01</a> ) Defines the activation delay for digital input/output DIO2. See parameter <a href="#">14.12 DIO1 ON delay</a> .	0.00 s / real32
	0.00 ... 3000.00 s	Activation delay for DIO2.	10 = 1 s / 100 = 1 s
14.18	DI2 OFF delay	(Visible when <a href="#">14.1 Module 1 type = FDIO-01</a> ) Defines the deactivation delay for digital input DI2. See parameter <a href="#">14.12 DI1 ON delay</a> .	0.00 s / real32
	0.00 ... 3000.00 s	Deactivation delay for DI2.	10 = 1 s / 100 = 1 s
14.18	DIO2 OFF delay	(Visible when <a href="#">14.1 Module 1 type = FIO-11</a> ) Defines the deactivation delay for digital input/output DIO2.  See parameter <a href="#">14.12 DIO1 ON delay</a> .	0.00 s / real32
	0.00 ... 3000.00 s	Deactivation delay for DIO2.	10 = 1 s / 100 = 1 s
14.18	DIO2 OFF delay	(Visible when <a href="#">14.1 Module 1 type = FIO-01</a> ) Defines the deactivation delay for digital input/output DIO2.  See parameter <a href="#">14.12 DIO1 ON delay</a> .	0.00 s / real32
	0.00 ... 3000.00 s	Deactivation delay for DIO2.	10 = 1 s / 100 = 1 s
14.19	AI supervision function	(Visible when <a href="#">14.1 Module 1 type = FAIO-01</a> ) Selects how the drive reacts when an analog input signal moves out of the minimum and/or maximum limits specified for the input.  The inputs and the limits to be observed are selected by parameter <a href="#">14.20 AI supervision selection</a> .	No action / uint16
	No action	No action taken.	0

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	Fault	Drive trips on <a href="#">80A0 AI Supervision</a> .	1
	Warning	Drive generates an <a href="#">A8A0 AI Supervised Warning</a> warning.	2
	Last speed	Drive generates a warning ( <a href="#">A8A0 AI Supervised Warning</a> ) and freezes the speed (or frequency) to the level the drive was operating at. The speed/frequency is determined on the basis of actual speed using 850 ms low-pass filtering.   <b>WARNING!</b> Make sure that it is safe to continue operation in case of a communication break.	3
	Speed ref safe	Drive generates a warning ( <a href="#">A8A0 AI Supervised Warning</a> ) and sets the speed to the speed defined by parameter <a href="#">22.41 Speed ref safe</a> (or <a href="#">28.41 Frequency ref safe</a> when frequency reference is being used).   <b>WARNING!</b> Make sure that it is safe to continue operation in case of a communication break.	4
14.19	DIO3 function	(Visible when <a href="#">14.1 Module 1 type = FIO-01</a> ) Selects whether DIO3 of the extension module is used as a digital input or output.	Input / uint16
	Output	DIO3 is used as a digital output.	0
	Input	DIO3 is used as a digital input.	1
14.20	AI supervision selection	(Visible when <a href="#">14.1 Module 1 type = FAIO-01</a> ) Specifies the analog input limits to be supervised. See parameter <a href="#">14.19 AI supervision function</a> .  <b>Note:</b> The number of active bits in this parameter depends on the number of inputs on the extension module.	- / uint16
b0	AI1 < MIN	1 = Minimum limit supervision of AI1 active.	
b1	AI1 > MAX	1 = Maximum limit supervision of AI1 active.	
b2	AI2 < MIN	1 = Minimum limit supervision of AI2 active.	
b3	AI2 > MAX	1 = Maximum limit supervision of AI2 active.	
b4...15	Reserved		
	0000h...FFFFh		1 = 1 / 1 = 1
14.20	AI supervision selection	(Visible when <a href="#">14.1 Module 1 type = FIO-11</a> ) Specifies the analog input limits to be supervised. See parameter <a href="#">14.19 AI supervision function</a> .	- / uint16
b0	AI1 < MIN	1 = Minimum limit supervision of AI1 active.	
b1	AI1 > MAX	1 = Maximum limit supervision of AI1 active.	
b2	AI2 < MIN	1 = Minimum limit supervision of AI2 active.	
b3	AI2 > MAX	1 = Maximum limit supervision of AI2 active.	

## 220 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
b4	AI3 < MIN	1 = Minimum limit supervision of AI3 active.	
b5	AI3 > MAX	1 = Maximum limit supervision of AI3 active.	
b6...15	Reserved		
	0000h...FFFFh		1 = 1 / 1 = 1
14.21	AI tune	(Visible when <a href="#">14.1 Module 1 type = FAIO-01</a> ) Triggers the analog input tuning function, which enables the use of actual measurements as the minimum and maximum input values instead of potentially inaccurate estimates.  Apply the minimum or maximum signal to the input and select the appropriate tuning function.  See also the drawing at parameter <a href="#">14.35 AI1 scaled at AI1 min.</a>	No action / uint16
	No action	Tuning action completed or no action has been requested.  The parameter automatically reverts to this value after any tuning action.	0
	AI1 min tune	The measured value of AI1 is set as the minimum value of AI1 into parameter <a href="#">14.33 AI1 min.</a>	1
	AI1 max tune	The measured value of AI1 is set as the maximum value of AI1 into parameter <a href="#">14.34 AI1 max.</a>	2
	AI2 min tune	The measured value of AI2 is set as the minimum value of AI2 into parameter <a href="#">14.48 AI2 min.</a>	3
	AI2 max tune	The measured value of AI2 is set as the maximum value of AI2 into parameter <a href="#">14.49 AI2 max.</a>	4
14.21	AI tune	(Visible when <a href="#">14.1 Module 1 type = FIO-11</a> ) Triggers the analog input tuning function, which enables the use of actual measurements as the minimum and maximum input values instead of potentially inaccurate estimates.  Apply the minimum or maximum signal to the input and select the appropriate tuning function.  See also the drawing at parameter <a href="#">14.35 AI1 scaled at AI1 min.</a>	No action / uint16
	No action	Tuning action completed or no action has been requested.  The parameter automatically reverts to this value after any tuning action.	0
	AI1 min tune	The measured value of AI1 is set as the minimum value of AI1 into parameter <a href="#">14.33 AI1 min.</a>	1
	AI1 max tune	The measured value of AI1 is set as the maximum value of AI1 into parameter <a href="#">14.34 AI1 max.</a>	2
	AI2 min tune	The measured value of AI2 is set as the minimum value of AI2 into parameter <a href="#">14.48 AI2 min.</a>	3


No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	AI2 max tune	The measured value of AI2 is set as the maximum value of AI2 into parameter <a href="#">14.49 AI2 max.</a>	4
	AI3 min tune	The measured value of AI3 is set as the minimum value of AI3 into parameter <a href="#">14.63 AI3 min.</a>	5
	AI3 max tune	The measured value of AI3 is set as the maximum value of AI3 into parameter <a href="#">14.64 AI3 max.</a>	6
14.21	DIO3 output source	(Visible when <a href="#">14.1 Module 1 type = FIO-01</a> ) Selects a drive signal to be connected to digital input/output DIO3 when parameter <a href="#">14.19 DIO3 function</a> is set to <a href="#">Output</a> .  For the available selections, see parameter <a href="#">14.11 DIO1 output source</a> .	Not energized / uint32
14.22	AI force selection	(Visible when <a href="#">14.1 Module 1 type = FAIO-01</a> ) The true readings of the analog inputs can be overridden for eg. testing purposes. A forced value parameter is provided for each analog input, and its value is applied whenever the corresponding bit in this parameter is 1.	- / uint16
b0	AI1	1 = Force mode: Force AI1 to value of parameter <a href="#">14.28 AI1 force data</a> .	
b1	AI2	1 = Force mode: Force AI2 to value of parameter <a href="#">14.43 AI2 force data</a> .	
b2...15	Reserved		
	0000h...FFFFh		1 = 1 / 1 = 1
14.22	DI3 ON delay	(Visible when <a href="#">14.1 Module 1 type = FDIO-01</a> ) Defines the activation delay for digital input DI3. See parameter <a href="#">14.12 DI1 ON delay</a> .	0.00 s / real32
	0.00 ... 3000.00 s	Activation delay for DI3.	10 = 1 s / 100 = 1 s
14.22	AI force selection	(Visible when <a href="#">14.1 Module 1 type = FIO-11</a> ) The true readings of the analog inputs can be overridden for eg. testing purposes. A forced value parameter is provided for each analog input, and its value is applied whenever the corresponding bit in this parameter is 1.	- / uint16
b0	AI1	1 = Force mode: Force AI1 to value of parameter <a href="#">14.28 AI1 force data</a> .	
b1	AI2	1 = Force mode: Force AI2 to value of parameter <a href="#">14.43 AI2 force data</a> .	
b2	AI3	1 = Force mode: Force AI3 to value of parameter <a href="#">14.58 AI3 force data (FIO-11 only)</a> .	
b3...15	Reserved		
	0000h...FFFFh		1 = 1 / 1 = 1
14.22	DIO3 ON delay	(Visible when <a href="#">14.1 Module 1 type = FIO-01</a> ) Defines the activation delay for digital input/output DIO3. See parameter <a href="#">14.12 DIO1 ON delay</a> .	0.00 s / real32

## 222 Parameters




No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	0.00 ... 3000.00 s	Activation delay for DIO3.	10 = 1 s / 100 = 1 s
14.23	DI3 OFF delay	(Visible when <a href="#">14.1 Module 1 type = FDIO-01</a> ) Defines the deactivation delay for digital input DI3. See parameter <a href="#">14.12 DI1 ON delay</a> .	0.00 s / real32
	0.00 ... 3000.00 s	Deactivation delay for DI3.	10 = 1 s / 100 = 1 s
14.23	DIO3 OFF delay	(Visible when <a href="#">14.1 Module 1 type = FIO-01</a> ) Defines the deactivation delay for digital input/output DIO3.  See parameter <a href="#">14.12 DIO1 ON delay</a> .	0.00 s / real32
	0.00 ... 3000.00 s	Deactivation delay for DIO3.	10 = 1 s / 100 = 1 s
14.24	DIO4 function	(Visible when <a href="#">14.1 Module 1 type = FIO-01</a> ) Selects whether DIO4 of the extension module is used as a digital input or output.	Input / uint16
	Output	DIO4 is used as a digital output.	0
	Input	DIO4 is used as a digital input.	1
14.26	AI1 actual value	(Visible when <a href="#">14.1 Module 1 type = FAIO-01</a> ) Displays the value of analog input AI1 in mA or V (depending on whether the input is set to current or voltage).  This parameter is read-only.	- / real32
	-22.000 ... 22.000 mA or V	Value of analog input AI1.	1000 = 1 mA or V / 1000 = 1 mA or V
14.26	DIO4 output source	(Visible when <a href="#">14.1 Module 1 type = FIO-01</a> ) Selects a drive signal to be connected to digital input/output DIO4 when parameter <a href="#">14.24 DIO4 function</a> is set to <a href="#">Output</a> .  For the available selections, see parameter <a href="#">14.11 DIO1 output source</a> .	Not energized / uint32
14.27	AI1 scaled value	(Visible when <a href="#">14.1 Module 1 type = FAIO-01</a> ) Displays the value of analog input AI1 after scaling. See parameter <a href="#">14.35 AI1 scaled at AI1 min</a> .  This parameter is read-only.	- / real32
	-32768.000 ... 32767.000	Scaled value of analog input AI1.	1 = 1 / 1000 = 1
14.27	DIO4 ON delay	(Visible when <a href="#">14.1 Module 1 type = FIO-01</a> ) Defines the activation delay for digital input/output DIO4. See parameter <a href="#">14.12 DIO1 ON delay</a> .	0.00 s / real32
	0.00 ... 3000.00 s	Activation delay for DIO4.	10 = 1 s / 100 = 1 s
14.28	AI1 force data	(Visible when <a href="#">14.1 Module 1 type = FAIO-01</a> ) Forced value that can be used instead of the true reading of the input. See parameter <a href="#">14.22 AI force selection</a> .	- / real32
	-22.000 ... 22.000 mA or V	Forced value of analog input AI1.	1000 = 1 mA or V / 1000 = 1 mA or V

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
14.28	DIO4 OFF delay	(Visible when <a href="#">14.1 Module 1 type = FIO-01</a> ) Defines the deactivation delay for digital input/output DIO4. See parameter <a href="#">14.12 DIO1 ON delay</a> .	0.00 s / real32
	0.00 ... 3000.00 s	Deactivation delay for DIO4.	10 = 1 s / 100 = 1 s
14.29	AI1 HW switch position	(Visible when <a href="#">14.1 Module 1 type = FAIO-01</a> ) Shows the position of the hardware current/voltage selector on the I/O extension module.  <b>Note:</b> The setting of the current/voltage selector must match the unit selection made in parameter <a href="#">14.30 AI1 unit selection</a> . I/O module reboot either by cycling the power or through parameter <a href="#">96.8 Control board boot</a> is required to validate any changes in the hardware settings.	mA / uint16
	mA	Milliamperes.	10
	V	Volts.	2
14.30	AI1 unit selection	(Visible when <a href="#">14.1 Module 1 type = FAIO-01</a> ) Selects the unit for readings and settings related to analog input AI1.  <b>Note:</b> This setting must match the corresponding hardware setting on the I/O extension module (see the manual of the I/O extension module). The hardware setting is shown by parameter <a href="#">14.29 AI1 HW switch position</a> . I/O module reboot either by cycling the power or through parameter <a href="#">96.8 Control board boot</a> is required to validate any changes in the hardware settings.	mA / uint16
	mA	Milliamperes.	10
	V	Volts.	2
14.31	RO status	(Visible when <a href="#">14.1 Module 1 type = FDIO-01</a> ) Status of relay outputs on the I/O extension module.  <b>Example:</b> 0001b = RO1 is energized, RO2 is de-energized.	- / uint16
	0000h...FFFFh		1 = 1 / 1 = 1
14.31	AI1 filter gain	(Visible when <a href="#">14.1 Module 1 type = FAIO-01</a> ) Selects a hardware filtering time for AI1.  See also parameter <a href="#">14.32 AI1 filter time</a> .	1 ms / uint16
	No filtering	No filtering.	0
	125 us	125 microseconds.	1
	250 us	250 microseconds.	2
	500 us	500 microseconds.	3
	1 ms	1 millisecond.	4
	2 ms	2 milliseconds.	5
	4 ms	4 milliseconds.	6
	7.9375 ms	7.9375 milliseconds.	7

224 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
14.31	RO status	(Visible when <a href="#">14.1 Module 1 type = FIO-01</a> ) Status of relay outputs on the I/O extension module. <b>Example:</b> 0001b = RO1 is energized, RO2 is de-energized.	- / uint16
	0000h...FFFFh		1 = 1 / 1 = 1
14.32	AI1 filter time	(Visible when <a href="#">14.1 Module 1 type = FAIO-01</a> ) Defines the filter time constant for analog input AI1.   $O = I \times (1 - e_{-t/T})$ I = filter input (step) O = filter output t = time T = filter time constant  <b>Note:</b> The signal is also filtered due to the signal interface hardware. See parameter <a href="#">14.31 AI1 filter gain</a> .	0.100 s / real32
	0.000 ... 30.000 s	Filter time constant.	1000 = 1 s / 1000 = 1 s
14.33	AI1 min	(Visible when <a href="#">14.1 Module 1 type = FAIO-01</a> ) Defines the minimum value for analog input AI1. See also parameter <a href="#">14.21 AI tune</a> .	0.000 mA or V / real32
	-22.000 ... 22.000 mA or V	Minimum value of AI1.	1000 = 1 mA or V / 1000 = 1 mA or V
14.34	RO1 source	(Visible when <a href="#">14.1 Module 1 type = FDIO-01</a> ) Selects a drive signal to be connected to relay output RO1. For the available selections, see parameter <a href="#">14.11 DIO1 output source</a> .	Not energized / uint32
14.34	AI1 max	(Visible when <a href="#">14.1 Module 1 type = FAIO-01</a> ) Defines the maximum value for analog input AI1. See also parameter <a href="#">14.21 AI tune</a> .	10.000 mA or V / real32
	-22.000 ... 22.000 mA or V	Maximum value of AI1.	1000 = 1 mA or V / 1000 = 1 mA or V




No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
14.34	RO1 source	(Visible when 14.1 Module 1 type = FIO-01) Selects a drive signal to be connected to relay output RO1.  For the available selections, see parameter 14.11 DIO1 output source.	Not energized / uint32
14.35	RO1 ON delay	(Visible when 14.1 Module 1 type = FDIO-01) Defines the activation delay for relay output RO1.   $t_{On} = 14.35$ RO1 ON delay $t_{Off} = 14.36$ RO1 OFF delay	0.00 s / real32
	0.00 ... 3000.00 s	Activation delay for RO1.	10 = 1 s / 100 = 1 s
14.35	AI1 scaled at AI1 min	(Visible when 14.1 Module 1 type = FAIO-01) Defines the real value that corresponds to the minimum analog input AI1 value defined by parameter 14.33 AI1 min.  	0.000 / real32
	-32768.000 ... 32767.000	Real value corresponding to minimum AI1 value.	1 = 1 / 1000 = 1
14.35	RO1 ON delay	(Visible when 14.1 Module 1 type = FIO-01) Defines the activation delay for relay output RO1.   $t_{On} = 14.35$ RO1 ON delay $t_{Off} = 14.36$ RO1 OFF delay	0.00 s / real32
	0.00 ... 3000.00 s	Activation delay for RO1.	10 = 1 s / 100 = 1 s


## 226 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
14.36	RO1 OFF delay	(Visible when <a href="#">14.1 Module 1 type = FDIO-01</a> ) Defines the deactivation delay for relay output RO1. See parameter <a href="#">14.35 RO1 ON delay</a> .	0.00 s / real32
	0.00 ... 3000.00 s	Deactivation delay for RO1.	10 = 1 s / 100 = 1 s
14.36	AI1 scaled at AI1 max	(Visible when <a href="#">14.1 Module 1 type = FAIO-01</a> ) Defines the real value that corresponds to the maximum analog input AI1 value defined by parameter <a href="#">14.34 AI1 max</a> .  See the drawing at parameter <a href="#">14.35 AI1 scaled at AI1 min</a> .	100.000 / real32
	-32768.000 ... 32767.000	Real value corresponding to maximum AI1 value.	1 = 1 / 1000 = 1
14.36	RO1 OFF delay	(Visible when <a href="#">14.1 Module 1 type = FIO-01</a> ) Defines the deactivation delay for relay output RO1. See parameter <a href="#">14.35 RO1 ON delay</a> .	0.00 s / real32
	0.00 ... 3000.00 s	Deactivation delay for RO1.	10 = 1 s / 100 = 1 s
14.37	RO2 source	(Visible when <a href="#">14.1 Module 1 type = FDIO-01</a> ) Selects a drive signal to be connected to relay output RO2.  For the available selections, see parameter <a href="#">14.11 DIO1 output source</a> .	Not energized / uint32
14.37	RO2 source	(Visible when <a href="#">14.1 Module 1 type = FIO-01</a> ) Selects a drive signal to be connected to relay output RO2.  For the available selections, see parameter <a href="#">14.11 DIO1 output source</a> .	Not energized / uint32
14.38	RO2 ON delay	(Visible when <a href="#">14.1 Module 1 type = FDIO-01</a> ) Defines the activation delay for relay output RO2. See parameter <a href="#">14.35 RO1 ON delay</a> .	0.00 s / real32
	0.00 ... 3000.00 s	Activation delay for RO2.	10 = 1 s / 100 = 1 s
14.38	RO2 ON delay	(Visible when <a href="#">14.1 Module 1 type = FIO-01</a> ) Defines the activation delay for relay output RO2. See parameter <a href="#">14.35 RO1 ON delay</a> .	0.00 s / real32
	0.00 ... 3000.00 s	Activation delay for RO2.	10 = 1 s / 100 = 1 s
14.39	RO2 OFF delay	(Visible when <a href="#">14.1 Module 1 type = FDIO-01</a> ) Defines the deactivation delay for relay output RO2. See parameter <a href="#">14.35 RO1 ON delay</a> .	0.00 s / real32
	0.00 ... 3000.00 s	Deactivation delay for RO2.	10 = 1 s / 100 = 1 s
14.39	RO2 OFF delay	(Visible when <a href="#">14.1 Module 1 type = FIO-01</a> ) Defines the deactivation delay for relay output RO2. See parameter <a href="#">14.35 RO1 ON delay</a> .	0.00 s / real32
	0.00 ... 3000.00 s	Deactivation delay for RO2.	10 = 1 s / 100 = 1 s

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
14.41	AI2 actual value	(Visible when <a href="#">14.1 Module 1 type = FAIO-01</a> ) Displays the value of analog input AI2 in mA or V (depending on whether the input is set to current or voltage).  This parameter is read-only.	- / real32
	-22.000 ... 22.000 mA or V	Value of analog input AI2.	1000 = 1 mA or V / 1000 = 1 mA or V
14.42	AI2 scaled value	(Visible when <a href="#">14.1 Module 1 type = FAIO-01</a> ) Displays the value of analog input AI2 after scaling. See parameter <a href="#">14.50 AI2 scaled at AI2 min</a> .  This parameter is read-only.	- / real32
	-32768.000 ... 32767.000 mA or V	Scaled value of analog input AI2.	1 = 1 mA or V / 1000 = 1 mA or V
14.43	AI2 force data	(Visible when <a href="#">14.1 Module 1 type = FAIO-01</a> ) Forced value that can be used instead of the true reading of the input. See parameter <a href="#">14.22 AI force selection</a> .	- / real32
	-22.000 ... 22.000 mA or V	Forced value of analog input AI2.	1000 = 1 mA or V / 1000 = 1 mA or V
14.44	AI2 HW switch position	(Visible when <a href="#">14.1 Module 1 type = FAIO-01</a> ) Shows the position of the hardware current/voltage selector on the I/O extension module.  <b>Note:</b> The setting of the current/voltage selector must match the unit selection made in parameter <a href="#">14.45 AI2 unit selection</a> . I/O module reboot either by cycling the power or through parameter <a href="#">96.8 Control board boot</a> is required to validate any changes in the hardware settings.	mA / uint16
	mA	Milliamperes.	10
	V	Volts.	2
14.45	AI2 unit selection	(Visible when <a href="#">14.1 Module 1 type = FAIO-01</a> ) Selects the unit for readings and settings related to analog input AI2.  <b>Note:</b> This setting must match the corresponding hardware setting on the I/O extension module (see the manual of the I/O extension module). The hardware setting is shown by parameter <a href="#">14.44 AI2 HW switch position</a> . I/O module reboot either by cycling the power or through parameter <a href="#">96.8 Control board boot</a> is required to validate any changes in the hardware settings.	mA / uint16
	mA	Milliamperes.	10
	V	Volts.	2
14.46	AI2 filter gain	(Visible when <a href="#">14.1 Module 1 type = FAIO-01</a> ) Selects a hardware filtering time for AI2.  See also parameter <a href="#">14.47 AI2 filter time</a> .	1 ms / uint16
	No filtering	No filtering.	0


228 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	125 us	125 microseconds.	1
	250 us	250 microseconds.	2
	500 us	500 microseconds.	3
	1 ms	1 millisecond.	4
	2 ms	2 milliseconds.	5
	4 ms	4 milliseconds.	6
	7.9375 ms	7.9375 milliseconds.	7
14.47	AI2 filter time	<p>(Visible when <a href="#">14.1 Module 1 type = FAIO-01</a>)            Defines the filter time constant for analog input AI2.</p>  <p><math>O = I \times (1 - e^{-t/T})</math>  <math>I</math> = filter input (step)  <math>O</math> = filter output  <math>t</math> = time  <math>T</math> = filter time constant</p> <p><b>Note:</b> The signal is also filtered due to the signal interface hardware. See parameter <a href="#">14.46 AI2 filter gain</a>.</p>	0.100 s / real32
	0.000 ... 30.000 s	Filter time constant.	1000 = 1 s / 1000 = 1 s
14.48	AI2 min	<p>(Visible when <a href="#">14.1 Module 1 type = FAIO-01</a>)            Defines the minimum value for analog input AI2.            See also parameter <a href="#">14.21 AI tune</a>.</p>	0.000 mA or V / real32
	-22.000 ... 22.000 mA or V	Minimum value of AI2.	1000 = 1 mA or V / 1000 = 1 mA or V
14.49	AI2 max	<p>(Visible when <a href="#">14.1 Module 1 type = FAIO-01</a>)            Defines the maximum value for analog input AI2.            See also parameter <a href="#">14.21 AI tune</a>.</p>	10.000 mA or V / real32
	-22.000 ... 22.000 mA or V	Maximum value of AI2.	1000 = 1 mA or V / 1000 = 1 mA or V


No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
14.50	AI2 scaled at AI2 min	<p>(Visible when <a href="#">14.1 Module 1 type = FAIO-01</a>)            Defines the real value that corresponds to the minimum analog input AI2 value defined by parameter <a href="#">14.48 AI2 min</a>.</p> 	0.000 / real32
	-32768.000 ... 32767.000	Real value corresponding to minimum AI2 value.	1 = 1 / 1000 = 1
14.51	AI2 scaled at AI2 max	<p>(Visible when <a href="#">14.1 Module 1 type = FAIO-01</a>)            Defines the real value that corresponds to the maximum analog input AI2 value defined by parameter <a href="#">14.49 AI2 max</a>.</p> <p>See the drawing at parameter <a href="#">14.50 AI2 scaled at AI2 min</a>.</p>	100.000 / real32
	-32768.000 ... 32767.000	Real value corresponding to maximum AI2 value.	1 = 1 / 1000 = 1
14.56	AI3 actual value	<p>(Visible when <a href="#">14.1 Module 1 type = FIO-11</a>)            Displays the value of analog input AI3 in mA or V (depending on whether the input is set to current or voltage).</p> <p>This parameter is read-only.</p>	- / real32
	-22.000 ... 22.000 mA or V	Value of analog input AI3.	1000 = 1 mA or V / 1000 = 1 mA or V
14.57	AI3 scaled value	<p>(Visible when <a href="#">14.1 Module 1 type = FIO-11</a>)            Displays the value of analog input AI3 after scaling.            See parameter <a href="#">14.65 AI3 scaled at AI3 min</a>.</p> <p>This parameter is read-only.</p>	- / real32
	-32768.000 ... 32767.000	Scaled value of analog input AI3.	1 = 1 / 1000 = 1
14.58	AI3 force data	<p>(Visible when <a href="#">14.1 Module 1 type = FIO-11</a>)            Forced value that can be used instead of the true reading of the input. See parameter <a href="#">14.22 AI force selection</a>.</p>	- / real32
	-22.000 ... 22.000 mA or V	Forced value of analog input AI3.	1000 = 1 mA or V / 1000 = 1 mA or V

## 230 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
14.59	AI3 HW switch position	(Visible when <a href="#">14.1 Module 1 type = FIO-11</a> ) Shows the position of the hardware current/voltage selector on the I/O extension module.  <b>Note:</b> The setting of the current/voltage selector must match the unit selection made in parameter <a href="#">14.60 AI3 unit selection</a> . I/O module reboot either by cycling the power or through parameter <a href="#">96.8 Control board boot</a> is required to validate any changes in the hardware settings.	mA / uint16
	mA	Milliamperes.	10
	V	Volts.	2
14.60	AI3 unit selection	(Visible when <a href="#">14.1 Module 1 type = FIO-11</a> ) Selects the unit for readings and settings related to analog input AI3.  <b>Note:</b> This setting must match the corresponding hardware setting on the I/O extension module (see the manual of the I/O extension module). The hardware setting is shown by parameter <a href="#">14.59 AI3 HW switch position</a> . I/O module reboot either by cycling the power or through parameter <a href="#">96.8 Control board boot</a> is required to validate any changes in the hardware settings.	mA / uint16
	mA	Milliamperes.	10
	V	Volts.	2
14.61	AI3 filter gain	(Visible when <a href="#">14.1 Module 1 type = FIO-11</a> ) Selects a hardware filtering time for AI3.  See also parameter <a href="#">14.62 AI3 filter time</a> .	1 ms / uint16
	No filtering	No filtering.	0
	125 us	125 microseconds.	1
	250 us	250 microseconds.	2
	500 us	500 microseconds.	3
	1 ms	1 millisecond.	4
	2 ms	2 milliseconds.	5
	4 ms	4 milliseconds.	6
	7.9375 ms	7.9375 milliseconds.	7

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
14.62	AI3 filter time	<p>(Visible when <a href="#">14.1 Module 1 type = FIO-11</a>)            Defines the filter time constant for analog input AI3.</p>  <p><math>O = I \times (1 - e^{-t/T})</math>  <math>I</math> = filter input (step)  <math>O</math> = filter output  <math>t</math> = time  <math>T</math> = filter time constant</p> <p><b>Note:</b> The signal is also filtered due to the signal interface hardware. See parameter <a href="#">14.61 AI3 filter gain</a>.</p>	0.100 s / real32
	0.000 ... 30.000 s	Filter time constant.	1000 = 1 s / 1000 = 1 s
14.63	AI3 min	<p>(Visible when <a href="#">14.1 Module 1 type = FIO-11</a>)            Defines the minimum value for analog input AI3.            See also parameter <a href="#">14.21 AI tune</a>.</p>	0.000 mA or V / real32
	-22.000 ... 22.000 mA or V	Minimum value of AI3.	1000 = 1 mA or V / 1000 = 1 mA or V
14.64	AI3 max	<p>(Visible when <a href="#">14.1 Module 1 type = FIO-11</a>)            Defines the maximum value for analog input AI3.            See also parameter <a href="#">14.21 AI tune</a>.</p>	10.000 mA or V / real32
	-22.000 ... 22.000 mA or V	Maximum value of AI3.	1000 = 1 mA or V / 1000 = 1 mA or V


232 Parameters


No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
14.65	AI3 scaled at AI3 min	<p>(Visible when <a href="#">14.1 Module 1 type = FIO-11</a>)                      Defines the real value that corresponds to the minimum analog input AI3 value defined by parameter <a href="#">14.63 AI3 min</a>.</p> 	0.000 / real32
	-32768.000 ... 32767.000	Real value corresponding to minimum AI3 value.	1 = 1 / 1000 = 1
14.66	AI3 scaled at AI3 max	<p>(Visible when <a href="#">14.1 Module 1 type = FIO-11</a>)                      Defines the real value that corresponds to the maximum analog input AI3 value defined by parameter <a href="#">14.64 AI3 max</a>.                      See the drawing at parameter <a href="#">14.65 AI3 scaled at AI3 min</a>.</p>	100.000 / real32
	-32768.000 ... 32767.000	Real value corresponding to maximum AI3 value.	1 = 1 / 1000 = 1
14.71	AO force selection	<p>(Visible when <a href="#">14.1 Module 1 type = FAIO-01</a>)                      The value of the analog output can be overridden for eg. testing purposes. A forced value parameter (<a href="#">14.78 AO1 force data</a>) is provided for the analog output, and its value is applied whenever the corresponding bit in this parameter is 1.</p>	- / uint16
	b0 AO1	1 = Force mode: Force AO1 to value of parameter <a href="#">14.78 AO1 force data</a> .	
	b1 AO2	1 = Force mode: Force AO2 to value of parameter <a href="#">14.88 AO2 force data</a> (FAIO-01 only).	
	b2...15 Reserved		
	0000h...FFFFh		1 = 1 / 1 = 1
14.71	AO force selection	<p>(Visible when <a href="#">14.1 Module 1 type = FIO-11</a>)                      The value of the analog output can be overridden for eg. testing purposes. A forced value parameter (<a href="#">14.78 AO1 force data</a>) is provided for the analog output, and its value is applied whenever the corresponding bit in this parameter is 1.</p>	- / uint16
	b0 AO1	1 = Force mode: Force AO1 to value of parameter <a href="#">14.78 AO1 force data</a> .	



No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
b1...15	Reserved		
	0000h...FFFFh		1 = 1 / 1 = 1
14.76	AO1 actual value	(Visible when <a href="#">14.1 Module 1 type = FAIO-01</a> ) Displays the value of AO1 in mA. This parameter is read-only.	- / real32
	0.000 ... 22.000 mA	Value of AO1.	1000 = 1 mA / 1000 = 1 mA
14.77	AO1 source	(Visible when <a href="#">14.1 Module 1 type = FAIO-01</a> ) Selects a signal to be connected to analog output AO1. Alternatively, sets the output to excitation mode to feed a constant current to a temperature sensor.	Zero / uint32
	Zero	None	0
	Motor speed used	<a href="#">1.1 Motor speed used (page 138)</a> .	1
	Output frequency	<a href="#">1.6 Output frequency (page 138)</a> .	3
	Motor current	<a href="#">1.7 Motor current (page 138)</a> .	4
	Motor torque	<a href="#">1.10 Motor torque (page 138)</a> .	6
	DC voltage	<a href="#">1.11 DC voltage (page 139)</a> .	7
	Power inu out	<a href="#">1.14 Output power (page 139)</a> .	8
	Speed ref ramp in	<a href="#">23.1 Speed ref ramp input (page 288)</a> .	10
	Speed ref ramp out	<a href="#">23.2 Speed ref ramp output (page 288)</a> .	11
	Speed ref used	<a href="#">24.1 Used speed reference (page 295)</a> .	12
	Torq ref used	<a href="#">26.2 Torque reference used (page 314)</a> .	13
	Freq ref used	<a href="#">28.2 Frequency ref ramp output (page 323)</a> .	14
	Process PID out	<a href="#">40.1 Process PID output actual (page 399)</a> .	16
	Process PID fbk	<a href="#">40.2 Process PID feedback actual (page 399)</a> .	17
	Process PID act	<a href="#">40.3 Process PID setpoint actual (page 399)</a> .	18
	Process PID dev	<a href="#">40.4 Process PID deviation actual (page 399)</a> .	19
	Other [bit]	Source selection (see <a href="#">Terms and abbreviations (page 134)</a> ).	-
	Force Pt100 excitation	The output is used to feed an excitation current to 1...3 Pt100 sensors. See section <a href="#">Motor thermal protection (page 90)</a> .	20
	Force KTY84 excitation	The output is used to feed an excitation current to a KTY84 sensor. See section <a href="#">Motor thermal protection (page 90)</a> .	21
	Force PTC excitation	The output is used to feed an excitation current to 1...3 PTC sensors. See section <a href="#">Motor thermal protection (page 90)</a> .	22
	Force Pt1000 excitation	The output is used to feed an excitation current to 1...3 Pt1000 sensors. See section <a href="#">Motor thermal protection (page 90)</a> .	23


234 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	AO1 data storage	<a href="#">13.91 AO1 data storage.</a>	37
	AO2 data storage	<a href="#">13.92 AO2 data storage.</a>	38
14.78	AO1 force data	(Visible when <a href="#">14.1 Module 1 type = FIO-11</a> ) Forced value that can be used instead of the selected output signal. See parameter <a href="#">14.71 AO force selection.</a>	- / real32
	0.000 ... 22.000 mA	Forced value of analog output AO1.	1000 = 1 mA / 1000 = 1 mA
14.78	AO1 force data	(Visible when <a href="#">14.1 Module 1 type = FAIO-01</a> ) Forced value that can be used instead of the selected output signal. See parameter <a href="#">14.71 AO force selection.</a>	0.000 mA / real32
	0.000 ... 20.000 mA	Forced value of analog output AO1.	1000 = 1 mA / 1000 = 1 mA
14.79	AO1 filter time	(Visible when <a href="#">14.1 Module 1 type = FAIO-01</a> ) Defines the filtering time constant for analog output AO1.   $O = I \times (1 - e^{-t/T})$ I = filter input (step) O = filter output t = time T = filter time constant	0.100 s / real32
	0.000 ... 30.000 s	Filter time constant.	1000 = 1 s / 1000 = 1 s

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
14.80	AO1 source min	<p>(Visible when 14.1 Module 1 type = FAIO-01)            Defines the real value of the signal (selected by parameter 14.77 AO1 source) that corresponds to the minimum AO1 output value (defined by parameter 14.82 AO1 out at AO1 src min).</p> 	0.0 / real32
	-32768.0 ... 32767.0	Real signal value corresponding to minimum AO1 output value.	1 = 1 / 10 = 1
14.81	AO1 source max	<p>(Visible when 14.1 Module 1 type = FAIO-01)            Defines the real value of the signal (selected by parameter 14.77 AO1 source) that corresponds to the maximum AO1 output value (defined by parameter 14.83 AO1 out at AO1 src max). See parameter 14.80 AO1 source min.</p>	100.0 / real32
	-32768.0 ... 32767.0	Real signal value corresponding to maximum AO1 output value.	1 = 1 / 10 = 1
14.82	AO1 out at AO1 src min	<p>(Visible when 14.1 Module 1 type = FIO-11)            Defines the minimum output value for analog output AO1.            See also drawing at parameter 14.80 AO1 source min.</p>	0.000 mA / real32

## 236 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	0.000 ... 22.000 mA	Minimum AO1 output value.	1000 = 1 mA / 1000 = 1 mA
14.82	AO1 out at AO1 src min	(Visible when <a href="#">14.1 Module 1 type = FAIO-01</a> ) Defines the minimum output value for analog output AO1.  See also drawing at parameter <a href="#">14.80 AO1 source min.</a>	0.000 mA / real32
	0.000 ... 20.000 mA	Minimum AO1 output value.	1000 = 1 mA / 1000 = 1 mA
14.83	AO1 out at AO1 src max	(Visible when <a href="#">14.1 Module 1 type = FIO-11</a> ) Defines the maximum output value for analog output AO1.  See also drawing at parameter <a href="#">14.80 AO1 source min.</a>	10.000 mA / real32
	0.000 ... 22.000 mA	Maximum AO1 output value.	1000 = 1 mA / 1000 = 1 mA
14.83	AO1 out at AO1 src max	(Visible when <a href="#">14.1 Module 1 type = FAIO-01</a> ) Defines the maximum output value for analog output AO1.  See also drawing at parameter <a href="#">14.80 AO1 source min.</a>	10.000 mA / real32
	0.000 ... 20.000 mA	Maximum AO1 output value.	1000 = 1 mA / 1000 = 1 mA
14.86	AO2 actual value	(Visible when <a href="#">14.1 Module 1 type = FAIO-01</a> ) Displays the value of AO2 in mA.  This parameter is read-only.	- / real32
	0.000 ... 22.000 mA	Value of AO2.	1000 = 1 mA / 1000 = 1 mA
14.87	AO2 source	(Visible when <a href="#">14.1 Module 1 type = FAIO-01</a> ) Selects a signal to be connected to analog output AO2.  Alternatively, sets the output to excitation mode to feed a constant current to a temperature sensor.  For the selections, see parameter <a href="#">14.77 AO1 source.</a>	Zero / uint32
14.88	AO2 force data	(Visible when <a href="#">14.1 Module 1 type = FAIO-01</a> ) Forced value that can be used instead of the selected output signal. See parameter <a href="#">14.71 AO force selection.</a>	0.000 mA / real32
	0.000 ... 20.000 mA	Forced value of analog output AO2.	1000 = 1 mA / 1000 = 1 mA
14.89	AO2 filter time	(Visible when <a href="#">14.1 Module 1 type = FAIO-01</a> ) Defines the filtering time constant for analog output AO2. See parameter <a href="#">14.79 AO1 filter time.</a>	0.100 s / real32
	0.000 ... 30.000 s	Filter time constant.	1000 = 1 s / 1000 = 1 s

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
14.90	AO2 source min	<p>(Visible when 14.1 Module 1 type = FAIO-01)            Defines the real value of the signal (selected by parameter 14.87 AO2 source) that corresponds to the minimum AO2 output value (defined by parameter 14.92 AO2 out at AO2 src min).</p>  <p>The figure consists of two graphs. The top graph plots <math>I_{AO2}</math> (mA) on the y-axis against the signal value on the x-axis. The y-axis has values 14.92 and 14.93. The x-axis has values 14.90 and 14.91. The curve is constant at 14.92 mA for signal values up to 14.90, then rises linearly to 14.93 mA at signal value 14.91, and remains constant thereafter. The bottom graph plots <math>I_{AO2}</math> (mA) on the y-axis against the signal value on the x-axis. The y-axis has values 14.92 and 14.93. The x-axis has values 14.91 and 14.90. The curve is constant at 14.93 mA for signal values up to 14.91, then falls linearly to 14.92 mA at signal value 14.90, and remains constant thereafter.</p>	0.0 / real32
	-32768.0 ... 32767.0	Real signal value corresponding to minimum AO2 output value.	1 = 1 / 10 = 1
14.91	AO2 source max	<p>(Visible when 14.1 Module 1 type = FAIO-01)            Defines the real value of the signal (selected by parameter 14.87 AO2 source) that corresponds to the maximum AO2 output value (defined by parameter 14.93 AO2 out at AO2 src max). See parameter 14.90 AO2 source min.</p>	100.0 / real32
	-32768.0 ... 32767.0	Real signal value corresponding to maximum AO2 output value.	1 = 1 / 10 = 1
14.92	AO2 out at AO2 src min	<p>(Visible when 14.1 Module 1 type = FAIO-01)            Defines the minimum output value for analog output AO2.             See also drawing at parameter 14.90 AO2 source min.</p>	0.000 mA / real32

## 238 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	0.000 ... 20.000 mA	Minimum AO2 output value.	1000 = 1 mA / 1000 = 1 mA
14.93	AO2 out at AO2 src max	(Visible when <a href="#">14.1 Module 1 type = FAIO-01</a> ) Defines the maximum output value for analog output AO2.  See also drawing at parameter <a href="#">14.90 AO2 source min.</a>	10.000 mA / real32
	0.000 ... 20.000 mA	Maximum AO2 output value.	1000 = 1 mA / 1000 = 1 mA

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
15	I/O extension module 2	Configuration of I/O extension module 2. See also section <a href="#">Programmable I/O extensions (page 33)</a> .  <b>Note:</b> The contents of the parameter group vary according to the selected I/O extension module type.	
15.1	Module 2 type	See parameter 14.1 Module 1 type.	- / uint16
15.2	Module 2 location	See parameter 14.2 Module 1 location.	- / uint16
15.3	Module 2 status	See parameter 14.3 Module 1 status.	No option / uint16
15.5	DI status	(Visible when 15.1 Module 2 type = FDIO-01) See parameter 14.5 DI status.	- / uint16
15.5	DIO status	(Visible when 15.1 Module 2 type = FIO-11) See parameter 14.5 DIO status.	- / uint16
15.5	DIO status	(Visible when 15.1 Module 2 type = FIO-01) See parameter 14.5 DIO status.	- / uint16
15.6	DI delayed status	(Visible when 15.1 Module 2 type = FDIO-01) See parameter 14.6 DI delayed status.	- / uint16
15.6	DIO delayed status	(Visible when 15.1 Module 2 type = FIO-11) See parameter 14.6 DIO delayed status.	- / uint16
15.6	DIO delayed status	(Visible when 15.1 Module 2 type = FIO-01) See parameter 14.6 DIO delayed status.	- / uint16
15.8	DI filter time	(Visible when 15.1 Module 2 type = FDIO-01) See parameter 14.8 DI filter time.	- / real32
15.8	DIO filter time	(Visible when 15.1 Module 2 type = FIO-11) See parameter 14.8 DIO filter time.	- / real32
15.8	DIO filter time	(Visible when 15.1 Module 2 type = FIO-01) See parameter 14.8 DIO filter time.	- / real32
15.9	DIO1 function	(Visible when 15.1 Module 2 type = FIO-11) See parameter 14.9 DIO1 function.	Input / uint16
15.9	DIO1 function	(Visible when 15.1 Module 2 type = FIO-01) See parameter 14.9 DIO1 function.	Input / uint16
15.11	DIO1 output source	(Visible when 15.1 Module 2 type = FIO-11) See parameter 14.11 DIO1 output source.	Not energized / uint32
15.11	DIO1 output source	(Visible when 15.1 Module 2 type = FIO-01) See parameter 14.11 DIO1 output source.	Not energized / uint32
15.12	D11 ON delay	(Visible when 15.1 Module 2 type = FDIO-01) See parameter 14.12 D11 ON delay.	- / real32
15.12	DIO1 ON delay	(Visible when 15.1 Module 2 type = FIO-11) See parameter 14.12 DIO1 ON delay.	- / real32
15.12	DIO1 ON delay	(Visible when 15.1 Module 2 type = FIO-01) See parameter 14.12 DIO1 ON delay.	- / real32
15.13	D11 OFF delay	(Visible when 15.1 Module 2 type = FDIO-01) See parameter 14.13 D11 OFF delay.	- / real32

## 240 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
15.13	DIO1 OFF delay	(Visible when 15.1 Module 2 type = FIO-11) See parameter 14.13 DIO1 OFF delay.	- / real32
15.13	DIO1 OFF delay	(Visible when 15.1 Module 2 type = FIO-01) See parameter 14.13 DIO1 OFF delay.	- / real32
15.14	DIO2 function	(Visible when 15.1 Module 2 type = FIO-11) See parameter 14.14 DIO2 function.	- / uint16
15.14	DIO2 function	(Visible when 15.1 Module 2 type = FIO-01) See parameter 14.14 DIO2 function.	- / uint16
15.16	DIO2 output source	(Visible when 15.1 Module 2 type = FIO-11) See parameter 14.16 DIO2 output source.	- / uint32
15.16	DIO2 output source	(Visible when 15.1 Module 2 type = FIO-01) See parameter 14.16 DIO2 output source.	- / uint32
15.17	DI2 ON delay	(Visible when 15.1 Module 2 type = FDIO-01) See parameter 14.17 DI2 ON delay.	- / real32
15.17	DIO2 ON delay	(Visible when 15.1 Module 2 type = FIO-11) See parameter 14.17 DIO2 ON delay.	- / real32
15.17	DIO2 ON delay	(Visible when 15.1 Module 2 type = FIO-01) See parameter 14.17 DIO2 ON delay.	- / real32
15.18	DI2 OFF delay	(Visible when 15.1 Module 2 type = FDIO-01) See parameter 14.18 DI2 OFF delay.	- / real32
15.18	DIO2 OFF delay	(Visible when 15.1 Module 2 type = FIO-11) See parameter 14.18 DIO2 OFF delay.	- / real32
15.18	DIO2 OFF delay	(Visible when 15.1 Module 2 type = FIO-01) See parameter 14.18 DIO2 OFF delay.	- / real32
15.19	DIO3 function	(Visible when 15.1 Module 2 type = FIO-01) See parameter 14.19 DIO3 function.	Input / uint16
15.19	AI supervision function	(Visible when 15.1 Module 2 type = FAIO-01) See parameter 14.19 AI supervision function.	No action / uint16
15.20	AI supervision selection	(Visible when 15.1 Module 2 type = FAIO-01) See parameter 14.20 AI supervision selection.	- / uint16
15.20	AI supervision selection	(Visible when 15.1 Module 2 type = FIO-11) See parameter 14.20 AI supervision selection.	- / uint16
15.21	DIO3 output source	(Visible when 15.1 Module 2 type = FIO-01) See parameter 14.21 DIO3 output source.	Not energized / uint32
15.21	AI tune	(Visible when 15.1 Module 2 type = FAIO-01) See parameter 14.21 AI tune.	No action / uint16
15.21	AI tune	(Visible when 15.1 Module 2 type = FIO-11) See parameter 14.21 AI tune.	No action / uint16
15.22	DI3 ON delay	(Visible when 15.1 Module 2 type = FDIO-01) See parameter 14.22 DI3 ON delay.	- / real32
15.22	DIO3 ON delay	(Visible when 15.1 Module 2 type = FIO-01) See parameter 14.22 DIO3 ON delay.	- / real32
15.22	AI force selection	(Visible when 15.1 Module 2 type = FAIO-01) See parameter 14.22 AI force selection.	- / uint16



No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
15.22	AI force selection	(Visible when 15.1 Module 2 type = FIO-11) See parameter 14.22 AI force selection.	- / uint16
15.23	DI3 OFF delay	(Visible when 15.1 Module 2 type = FDIO-01) See parameter 14.23 DI3 OFF delay.	- / real32
15.23	DIO3 OFF delay	(Visible when 15.1 Module 2 type = FIO-01) See parameter 14.23 DIO3 OFF delay.	- / real32
15.24	DIO4 function	(Visible when 15.1 Module 2 type = FIO-01) See parameter 14.24 DIO4 function.	Input / uint16
15.26	DIO4 output source	(Visible when 15.1 Module 2 type = FIO-01) See parameter 14.26 DIO4 output source.	- / uint32
15.26	AI1 actual value	(Visible when 15.1 Module 2 type = FAIO-01) See parameter 14.26 AI1 actual value.	- / real32
15.27	DIO4 ON delay	(Visible when 15.1 Module 2 type = FIO-01) See parameter 14.27 DIO4 ON delay.	- / real32
15.27	AI1 scaled value	(Visible when 15.1 Module 2 type = FAIO-01) See parameter 14.27 AI1 scaled value.	- / real32
15.28	DIO4 OFF delay	(Visible when 15.1 Module 2 type = FIO-01) See parameter 14.28 DIO4 OFF delay.	- / real32
15.28	AI1 force data	(Visible when 15.1 Module 2 type = FAIO-01) See parameter 14.28 AI1 force data.	- / real32
15.29	AI1 HW switch position	(Visible when 15.1 Module 2 type = FAIO-01) See parameter 14.29 AI1 HW switch position.	mA / uint16
15.30	AI1 unit selection	(Visible when 15.1 Module 2 type = FAIO-01) See parameter 14.30 AI1 unit selection.	mA / uint16
15.31	RO status	(Visible when 15.1 Module 2 type = FDIO-01) See parameter 14.31 RO status.	- / uint16
15.31	RO status	(Visible when 15.1 Module 2 type = FIO-01) See parameter 14.31 RO status.	- / uint16
15.31	AI1 filter gain	(Visible when 15.1 Module 2 type = FAIO-01) See parameter 14.31 AI1 filter gain.	1 ms / uint16
15.32	AI1 filter time	(Visible when 15.1 Module 2 type = FAIO-01) See parameter 14.32 AI1 filter time.	- / real32
15.33	AI1 min	(Visible when 15.1 Module 2 type = FAIO-01) See parameter 14.33 AI1 min.	- / real32
15.34	RO1 source	(Visible when 15.1 Module 2 type = FDIO-01) See parameter 14.34 RO1 source.	Not energized / uint32
15.34	RO1 source	(Visible when 15.1 Module 2 type = FIO-01) See parameter 14.34 RO1 source.	Not energized / uint32
15.34	AI1 max	(Visible when 15.1 Module 2 type = FAIO-01) See parameter 14.34 AI1 max.	- / real32
15.35	RO1 ON delay	(Visible when 15.1 Module 2 type = FDIO-01) See parameter 14.35 RO1 ON delay.	- / real32
15.35	RO1 ON delay	(Visible when 15.1 Module 2 type = FIO-01) See parameter 14.35 RO1 ON delay.	- / real32

## 242 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
15.35	AI1 scaled at AI1 min	(Visible when 15.1 Module 2 type = FAIO-01) See parameter 14.35 AI1 scaled at AI1 min.	- / real32
15.36	RO1 OFF delay	(Visible when 15.1 Module 2 type = FDIO-01) See parameter 14.36 RO1 OFF delay.	- / real32
15.36	RO1 OFF delay	(Visible when 15.1 Module 2 type = FIO-01) See parameter 14.36 RO1 OFF delay.	- / real32
15.36	AI1 scaled at AI1 max	(Visible when 15.1 Module 2 type = FAIO-01) See parameter 14.36 AI1 scaled at AI1 max.	- / real32
15.37	RO2 source	(Visible when 15.1 Module 2 type = FDIO-01) See parameter 14.37 RO2 source.	Not energized / uint32
15.37	RO2 source	(Visible when 15.1 Module 2 type = FIO-01) See parameter 14.37 RO2 source.	Not energized / uint32
15.38	RO2 ON delay	(Visible when 15.1 Module 2 type = FDIO-01) See parameter 14.38 RO2 ON delay.	- / real32
15.38	RO2 ON delay	(Visible when 15.1 Module 2 type = FIO-01) See parameter 14.38 RO2 ON delay.	- / real32
15.39	RO2 OFF delay	(Visible when 15.1 Module 2 type = FDIO-01) See parameter 14.39 RO2 OFF delay.	- / real32
15.39	RO2 OFF delay	(Visible when 15.1 Module 2 type = FIO-01) See parameter 14.39 RO2 OFF delay.	- / real32
15.41	AI2 actual value	(Visible when 15.1 Module 2 type = FAIO-01) See parameter 14.41 AI2 actual value.	- / real32
15.42	AI2 scaled value	(Visible when 15.1 Module 2 type = FAIO-01) See parameter 14.42 AI2 scaled value.	- / real32
15.43	AI2 force data	(Visible when 15.1 Module 2 type = FAIO-01) See parameter 14.43 AI2 force data.	- / real32
15.44	AI2 HW switch position	(Visible when 15.1 Module 2 type = FAIO-01) See parameter 14.44 AI2 HW switch position.	mA / uint16
15.45	AI2 unit selection	(Visible when 15.1 Module 2 type = FAIO-01) See parameter 14.45 AI2 unit selection.	mA / uint16
15.46	AI2 filter gain	(Visible when 15.1 Module 2 type = FAIO-01) See parameter 14.46 AI2 filter gain.	1 ms / uint16
15.47	AI2 filter time	(Visible when 15.1 Module 2 type = FAIO-01) See parameter 14.47 AI2 filter time.	- / real32
15.48	AI2 min	(Visible when 15.1 Module 2 type = FAIO-01) See parameter 14.48 AI2 min.	- / real32
15.49	AI2 max	(Visible when 15.1 Module 2 type = FAIO-01) See parameter 14.49 AI2 max.	- / real32
15.50	AI2 scaled at AI2 min	(Visible when 15.1 Module 2 type = FAIO-01) See parameter 14.50 AI2 scaled at AI2 min.	- / real32
15.51	AI2 scaled at AI2 max	(Visible when 15.1 Module 2 type = FAIO-01) See parameter 14.51 AI2 scaled at AI2 max.	- / real32
15.56	AI3 actual value	(Visible when 15.1 Module 2 type = FIO-11) See parameter 14.56 AI3 actual value.	- / real32

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
15.57	AI3 scaled value	(Visible when 15.1 Module 2 type = FIO-11) See parameter 14.57 AI3 scaled value.	- / real32
15.58	AI3 force data	(Visible when 15.1 Module 2 type = FIO-11) See parameter 14.58 AI3 force data.	- / real32
15.59	AI3 HW switch position	(Visible when 15.1 Module 2 type = FIO-11) See parameter 14.59 AI3 HW switch position.	mA / uint16
15.60	AI3 unit selection	(Visible when 15.1 Module 2 type = FIO-11) See parameter 14.60 AI3 unit selection.	mA / uint16
15.61	AI3 filter gain	(Visible when 15.1 Module 2 type = FIO-11) See parameter 14.61 AI3 filter gain.	1 ms / uint16
15.62	AI3 filter time	(Visible when 15.1 Module 2 type = FIO-11) See parameter 14.62 AI3 filter time.	- / real32
15.63	AI3 min	(Visible when 15.1 Module 2 type = FIO-11) See parameter 14.63 AI3 min.	- / real32
15.64	AI3 max	(Visible when 15.1 Module 2 type = FIO-11) See parameter 14.64 AI3 max.	- / real32
15.65	AI3 scaled at AI3 min	(Visible when 15.1 Module 2 type = FIO-11) See parameter 14.65 AI3 scaled at AI3 min.	- / real32
15.66	AI3 scaled at AI3 max	(Visible when 15.1 Module 2 type = FIO-11) See parameter 14.66 AI3 scaled at AI3 max.	- / real32
15.71	AO force selection	(Visible when 15.1 Module 2 type = FAIO-01) See parameter 14.71 AO force selection.	- / uint16
15.71	AO force selection	(Visible when 15.1 Module 2 type = FIO-11) See parameter 14.71 AO force selection.	- / uint16
15.76	AO1 actual value	(Visible when 15.1 Module 2 type = FAIO-01) See parameter 14.76 AO1 actual value.	- / real32
15.77	AO1 source	(Visible when 15.1 Module 2 type = FAIO-01) See parameter 14.77 AO1 source.	Zero / uint32
15.78	AO1 force data	(Visible when 15.1 Module 2 type = FIO-11) See parameter 14.78 AO1 force data.	- / real32
15.78	AO1 force data	(Visible when 15.1 Module 2 type = FAIO-01) See parameter 14.78 AO1 force data.	- / real32
15.79	AO1 filter time	(Visible when 15.1 Module 2 type = FAIO-01) See parameter 14.79 AO1 filter time.	- / real32
15.80	AO1 source min	(Visible when 15.1 Module 2 type = FAIO-01) See parameter 14.80 AO1 source min.	- / real32
15.81	AO1 source max	(Visible when 15.1 Module 2 type = FAIO-01) See parameter 14.81 AO1 source max.	- / real32
15.82	AO1 out at AO1 src min	(Visible when 15.1 Module 2 type = FIO-11) See parameter 14.82 AO1 out at AO1 src min.	- / real32
15.82	AO1 out at AO1 src min	(Visible when 15.1 Module 2 type = FAIO-01) See parameter 14.82 AO1 out at AO1 src min.	- / real32
15.83	AO1 out at AO1 src max	(Visible when 15.1 Module 2 type = FIO-11) See parameter 14.83 AO1 out at AO1 src max.	- / real32

## 244 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
15.83	AO1 out at AO1 src max	(Visible when 15.1 Module 2 type = FAIO-01) See parameter 14.83 AO1 out at AO1 src max.	- / real32
15.86	AO2 actual value	(Visible when 15.1 Module 2 type = FAIO-01) See parameter 14.86 AO2 actual value.	- / real32
15.87	AO2 source	(Visible when 15.1 Module 2 type = FAIO-01) See parameter 14.87 AO2 source.	Zero / uint32
15.88	AO2 force data	(Visible when 15.1 Module 2 type = FAIO-01) See parameter 14.88 AO2 force data.	- / real32
15.89	AO2 filter time	(Visible when 15.1 Module 2 type = FAIO-01) See parameter 14.89 AO2 filter time.	- / real32
15.90	AO2 source min	(Visible when 15.1 Module 2 type = FAIO-01) See parameter 14.90 AO2 source min.	- / real32
15.91	AO2 source max	(Visible when 15.1 Module 2 type = FAIO-01) See parameter 14.91 AO2 source max.	- / real32
15.92	AO2 out at AO2 src min	(Visible when 15.1 Module 2 type = FAIO-01) See parameter 14.92 AO2 out at AO2 src min.	- / real32
15.93	AO2 out at AO2 src max	(Visible when 15.1 Module 2 type = FAIO-01) See parameter 14.93 AO2 out at AO2 src max.	- / real32

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
16	I/O extension module 3	Configuration of I/O extension module 3. See also section <a href="#">Programmable I/O extensions (page 33)</a> . <b>Note:</b> The contents of the parameter group vary according to the selected I/O extension module type.	
16.1	Module 3 type	See parameter 14.1 <a href="#">Module 1 type</a> .	None / uint16
16.2	Module 3 location	See parameter 14.2 <a href="#">Module 1 location</a> .	- / uint16
16.3	Module 3 status	See parameter 14.3 <a href="#">Module 1 status</a> .	No option / uint16
16.5	DI status	(Visible when 16.1 <a href="#">Module 3 type</a> = FDIO-01) See parameter 14.5 <a href="#">DI status</a> .	- / uint16
16.5	DIO status	(Visible when 16.1 <a href="#">Module 3 type</a> = FIO-11) See parameter 14.5 <a href="#">DIO status</a> .	- / uint16
16.5	DIO status	(Visible when 16.1 <a href="#">Module 3 type</a> = FIO-01) See parameter 14.5 <a href="#">DIO status</a> .	- / uint16
16.6	DI delayed status	(Visible when 16.1 <a href="#">Module 3 type</a> = FDIO-01) See parameter 14.6 <a href="#">DI delayed status</a> .	- / uint16
16.6	DIO delayed status	(Visible when 16.1 <a href="#">Module 3 type</a> = FIO-11) See parameter 14.6 <a href="#">DIO delayed status</a> .	- / uint16
16.6	DIO delayed status	(Visible when 16.1 <a href="#">Module 3 type</a> = FIO-01) See parameter 14.6 <a href="#">DIO delayed status</a> .	- / uint16
16.8	DI filter time	(Visible when 16.1 <a href="#">Module 3 type</a> = FDIO-01) See parameter 14.8 <a href="#">DI filter time</a> .	10.0 ms / real32
	0.8 ... 100.0 ms		10 = 1 ms / 1 = 1 ms
16.8	DIO filter time	(Visible when 16.1 <a href="#">Module 3 type</a> = FIO-11) See parameter 14.8 <a href="#">DIO filter time</a> .	- / real32
16.8	DIO filter time	(Visible when 16.1 <a href="#">Module 3 type</a> = FIO-01) See parameter 14.8 <a href="#">DIO filter time</a> .	- / real32
16.9	DIO1 function	(Visible when 16.1 <a href="#">Module 3 type</a> = FIO-11) See parameter 14.9 <a href="#">DIO1 function</a> .	Input / uint16
16.9	DIO1 function	(Visible when 16.1 <a href="#">Module 3 type</a> = FIO-01) See parameter 14.9 <a href="#">DIO1 function</a> .	Input / uint16
16.11	DIO1 output source	(Visible when 16.1 <a href="#">Module 3 type</a> = FIO-11) See parameter 14.11 <a href="#">DIO1 output source</a> .	Not energized / uint32
16.11	DIO1 output source	(Visible when 16.1 <a href="#">Module 3 type</a> = FIO-01) See parameter 14.11 <a href="#">DIO1 output source</a> .	Not energized / uint32
16.12	DI1 ON delay	(Visible when 16.1 <a href="#">Module 3 type</a> = FDIO-01) See parameter 14.12 <a href="#">DI1 ON delay</a> .	- / real32
16.12	DIO1 ON delay	(Visible when 16.1 <a href="#">Module 3 type</a> = FIO-11) See parameter 14.12 <a href="#">DIO1 ON delay</a> .	- / real32
16.12	DIO1 ON delay	(Visible when 16.1 <a href="#">Module 3 type</a> = FIO-01) See parameter 14.12 <a href="#">DIO1 ON delay</a> .	- / real32
16.13	DI1 OFF delay	(Visible when 16.1 <a href="#">Module 3 type</a> = FDIO-01) See parameter 14.13 <a href="#">DI1 OFF delay</a> .	- / real32

## 246 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
16.13	DIO1 OFF delay	(Visible when 16.1 Module 3 type = FIO-11) See parameter 14.13 DIO1 OFF delay.	- / real32
16.13	DIO1 OFF delay	(Visible when 16.1 Module 3 type = FIO-01) See parameter 14.13 DIO1 OFF delay.	- / real32
16.14	DIO2 function	(Visible when 16.1 Module 3 type = FIO-11) See parameter 14.14 DIO2 function.	Input / uint16
16.14	DIO2 function	(Visible when 16.1 Module 3 type = FIO-01) See parameter 14.14 DIO2 function.	Input / uint16
16.16	DIO2 output source	(Visible when 16.1 Module 3 type = FIO-11) See parameter 14.16 DIO2 output source.	Not energized / uint32
16.16	DIO2 output source	(Visible when 16.1 Module 3 type = FIO-01) See parameter 14.16 DIO2 output source.	Not energized / uint32
16.17	DI2 ON delay	(Visible when 16.1 Module 3 type = FDIO-01) See parameter 14.17 DI2 ON delay.	- / real32
16.17	DIO2 ON delay	(Visible when 16.1 Module 3 type = FIO-11) See parameter 14.17 DIO2 ON delay.	- / real32
16.17	DIO2 ON delay	(Visible when 16.1 Module 3 type = FIO-01) See parameter 14.17 DIO2 ON delay.	- / real32
16.18	DI2 OFF delay	(Visible when 16.1 Module 3 type = FDIO-01) See parameter 14.18 DI2 OFF delay.	- / real32
16.18	DIO2 OFF delay	(Visible when 16.1 Module 3 type = FIO-11) See parameter 14.18 DIO2 OFF delay.	- / real32
16.18	DIO2 OFF delay	(Visible when 16.1 Module 3 type = FIO-01) See parameter 14.18 DIO2 OFF delay.	- / real32
16.19	AI supervision function	(Visible when 16.1 Module 3 type = FAIO-01) See parameter 14.19 AI supervision function.	No action / uint16
16.19	DIO3 function	(Visible when 16.1 Module 3 type = FIO-01) See parameter 14.19 DIO3 function.	Input / uint16
16.20	AI supervision selection	(Visible when 16.1 Module 3 type = FAIO-01) See parameter 14.20 AI supervision selection.	- / uint16
16.20	AI supervision selection	(Visible when 16.1 Module 3 type = FIO-11) See parameter 14.20 AI supervision selection.	- / uint16
16.21	AI tune	(Visible when 16.1 Module 3 type = FAIO-01) See parameter 14.21 AI tune.	No action / uint16
16.21	AI tune	(Visible when 16.1 Module 3 type = FIO-11) See parameter 14.21 AI tune.	No action / uint16
16.21	DIO3 output source	(Visible when 16.1 Module 3 type = FIO-01) See parameter 14.21 DIO3 output source.	Not energized / uint32
16.22	AI force selection	(Visible when 16.1 Module 3 type = FAIO-01) See parameter 14.22 AI force selection.	- / uint16
16.22	AI force selection	(Visible when 16.1 Module 3 type = FIO-11) See parameter 14.22 AI force selection.	- / uint16
16.22	DI3 ON delay	(Visible when 16.1 Module 3 type = FDIO-01) See parameter 14.22 DI3 ON delay.	- / real32

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
16.22	DIO3 ON delay	(Visible when 16.1 Module 3 type = FIO-01) See parameter 14.22 DIO3 ON delay.	- / real32
16.23	DI3 OFF delay	(Visible when 16.1 Module 3 type = FDI0-01) See parameter 14.23 DI3 OFF delay.	- / real32
16.23	DIO3 OFF delay	(Visible when 16.1 Module 3 type = FIO-01) See parameter 14.23 DIO3 OFF delay.	- / real32
16.24	DIO4 function	(Visible when 16.1 Module 3 type = FIO-01) See parameter 14.24 DIO4 function.	Input / uint16
16.26	AI1 actual value	(Visible when 16.1 Module 3 type = FAIO-01) See parameter 14.26 AI1 actual value.	- / real32
16.26	DIO4 output source	(Visible when 16.1 Module 3 type = FIO-01) See parameter 14.26 DIO4 output source.	Not energized / uint32
16.27	AI1 scaled value	(Visible when 16.1 Module 3 type = FAIO-01) See parameter 14.27 AI1 scaled value.	- / real32
16.27	DIO4 ON delay	(Visible when 16.1 Module 3 type = FIO-01) See parameter 14.27 DIO4 ON delay.	- / real32
16.28	AI1 force data	(Visible when 16.1 Module 3 type = FAIO-01) See parameter 14.28 AI1 force data.	- / real32
16.28	DIO4 OFF delay	(Visible when 16.1 Module 3 type = FIO-01) See parameter 14.28 DIO4 OFF delay.	- / real32
16.29	AI1 HW switch position	(Visible when 16.1 Module 3 type = FAIO-01) See parameter 14.29 AI1 HW switch position.	mA / uint16
16.30	AI1 unit selection	(Visible when 16.1 Module 3 type = FAIO-01) See parameter 14.30 AI1 unit selection.	mA / uint16
16.31	RO status	(Visible when 16.1 Module 3 type = FDI0-01) See parameter 14.31 RO status.	- / uint16
16.31	RO status	(Visible when 16.1 Module 3 type = FIO-01) See parameter 14.31 RO status.	- / uint16
16.31	AI1 filter gain	(Visible when 16.1 Module 3 type = FAIO-01) See parameter 14.31 AI1 filter gain.	1 ms / uint16
16.32	AI1 filter time	(Visible when 16.1 Module 3 type = FAIO-01) See parameter 14.32 AI1 filter time.	- / real32
16.33	AI1 min	(Visible when 16.1 Module 3 type = FAIO-01) See parameter 14.33 AI1 min.	- / real32
16.34	RO1 source	(Visible when 16.1 Module 3 type = FDI0-01) See parameter 14.34 RO1 source.	Not energized / uint32
16.34	RO1 source	(Visible when 16.1 Module 3 type = FIO-01) See parameter 14.34 RO1 source.	Not energized / uint32
16.34	AI1 max	(Visible when 16.1 Module 3 type = FAIO-01) See parameter 14.34 AI1 max.	- / real32
16.35	RO1 ON delay	(Visible when 16.1 Module 3 type = FDI0-01) See parameter 14.35 RO1 ON delay.	- / real32
16.35	RO1 ON delay	(Visible when 16.1 Module 3 type = FIO-01) See parameter 14.35 RO1 ON delay.	- / real32

## 248 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
16.35	AI1 scaled at AI1 min	(Visible when 16.1 Module 3 type = FAIO-01) See parameter 14.35 AI1 scaled at AI1 min.	- / real32
16.36	RO1 OFF delay	(Visible when 16.1 Module 3 type = FDIO-01) See parameter 14.36 RO1 OFF delay.	- / real32
16.36	RO1 OFF delay	(Visible when 16.1 Module 3 type = FIO-01) See parameter 14.36 RO1 OFF delay.	- / real32
16.36	AI1 scaled at AI1 max	(Visible when 16.1 Module 3 type = FAIO-01) See parameter 14.36 AI1 scaled at AI1 max.	- / real32
16.37	RO2 source	(Visible when 16.1 Module 3 type = FDIO-01) See parameter 14.37 RO2 source.	Not energized / uint32
16.37	RO2 source	(Visible when 16.1 Module 3 type = FIO-01) See parameter 14.37 RO2 source.	Not energized / uint32
16.38	RO2 ON delay	(Visible when 16.1 Module 3 type = FDIO-01) See parameter 14.38 RO2 ON delay.	- / real32
16.38	RO2 ON delay	(Visible when 16.1 Module 3 type = FIO-01) See parameter 14.38 RO2 ON delay.	- / real32
16.39	RO2 OFF delay	(Visible when 16.1 Module 3 type = FDIO-01) See parameter 14.39 RO2 OFF delay.	- / real32
16.39	RO2 OFF delay	(Visible when 16.1 Module 3 type = FIO-01) See parameter 14.39 RO2 OFF delay.	- / real32
16.41	AI2 actual value	(Visible when 16.1 Module 3 type = FAIO-01) See parameter 14.41 AI2 actual value.	- / real32
16.42	AI2 scaled value	(Visible when 16.1 Module 3 type = FAIO-01) See parameter 14.42 AI2 scaled value.	- / real32
16.43	AI2 force data	(Visible when 16.1 Module 3 type = FAIO-01) See parameter 14.43 AI2 force data.	- / real32
16.44	AI2 HW switch position	(Visible when 16.1 Module 3 type = FAIO-01) See parameter 14.44 AI2 HW switch position.	mA / uint16
16.45	AI2 unit selection	(Visible when 16.1 Module 3 type = FAIO-01) See parameter 14.45 AI2 unit selection.	mA / uint16
16.46	AI2 filter gain	(Visible when 16.1 Module 3 type = FAIO-01) See parameter 14.46 AI2 filter gain.	1 ms / uint16
16.47	AI2 filter time	(Visible when 16.1 Module 3 type = FAIO-01) See parameter 14.47 AI2 filter time.	- / real32
16.48	AI2 min	(Visible when 16.1 Module 3 type = FAIO-01) See parameter 14.48 AI2 min.	- / real32
16.49	AI2 max	(Visible when 16.1 Module 3 type = FAIO-01) See parameter 14.49 AI2 max.	- / real32
16.50	AI2 scaled at AI2 min	(Visible when 16.1 Module 3 type = FAIO-01) See parameter 14.50 AI2 scaled at AI2 min.	- / real32
16.51	AI2 scaled at AI2 max	(Visible when 16.1 Module 3 type = FAIO-01) See parameter 14.51 AI2 scaled at AI2 max.	- / real32
16.56	AI3 actual value	(Visible when 16.1 Module 3 type = FIO-11) See parameter 14.56 AI3 actual value.	- / real32



No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
16.57	AI3 scaled value	(Visible when 16.1 Module 3 type = FIO-11) See parameter 14.57 AI3 scaled value.	- / real32
16.58	AI3 force data	(Visible when 16.1 Module 3 type = FIO-11) See parameter 14.58 AI3 force data.	- / real32
16.59	AI3 HW switch position	(Visible when 16.1 Module 3 type = FIO-11) See parameter 14.59 AI3 HW switch position.	mA / uint16
16.60	AI3 unit selection	(Visible when 16.1 Module 3 type = FIO-11) See parameter 14.60 AI3 unit selection.	mA / uint16
16.61	AI3 filter gain	(Visible when 16.1 Module 3 type = FIO-11) See parameter 14.61 AI3 filter gain.	1 ms / uint16
16.62	AI3 filter time	(Visible when 16.1 Module 3 type = FIO-11) See parameter 14.62 AI3 filter time.	- / real32
16.63	AI3 min	(Visible when 16.1 Module 3 type = FIO-11) See parameter 14.63 AI3 min.	- / real32
16.64	AI3 max	(Visible when 16.1 Module 3 type = FIO-11) See parameter 14.64 AI3 max.	- / real32
16.65	AI3 scaled at AI3 min	(Visible when 16.1 Module 3 type = FIO-11) See parameter 14.65 AI3 scaled at AI3 min.	- / real32
16.66	AI3 scaled at AI3 max	(Visible when 16.1 Module 3 type = FIO-11) See parameter 14.66 AI3 scaled at AI3 max.	- / real32
16.71	AO force selection	(Visible when 16.1 Module 3 type = FAIO-01) See parameter 14.71 AO force selection.	- / uint16
16.71	AO force selection	(Visible when 16.1 Module 3 type = FIO-11) See parameter 14.71 AO force selection.	- / uint16
16.76	AO1 actual value	(Visible when 16.1 Module 3 type = FAIO-01) See parameter 14.76 AO1 actual value.	- / real32
16.77	AO1 source	(Visible when 16.1 Module 3 type = FAIO-01) See parameter 14.77 AO1 source.	Zero / uint32
16.78	AO1 force data	(Visible when 16.1 Module 3 type = FIO-11) See parameter 14.78 AO1 force data.	- / real32
16.78	AO1 force data	(Visible when 16.1 Module 3 type = FAIO-01) See parameter 14.78 AO1 force data.	- / real32
16.79	AO1 filter time	(Visible when 16.1 Module 3 type = FAIO-01) See parameter 14.79 AO1 filter time.	- / real32
16.80	AO1 source min	(Visible when 16.1 Module 3 type = FAIO-01) See parameter 14.80 AO1 source min.	- / real32
16.81	AO1 source max	(Visible when 16.1 Module 3 type = FAIO-01) See parameter 14.81 AO1 source max.	- / real32
16.82	AO1 out at AO1 src min	(Visible when 16.1 Module 3 type = FIO-11) See parameter 14.82 AO1 out at AO1 src min.	- / real32
16.82	AO1 out at AO1 src min	(Visible when 16.1 Module 3 type = FAIO-01) See parameter 14.82 AO1 out at AO1 src min.	- / real32
16.83	AO1 out at AO1 src max	(Visible when 16.1 Module 3 type = FIO-11) See parameter 14.83 AO1 out at AO1 src max.	- / real32


## 250 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
16.83	AO1 out at AO1 src max	(Visible when 16.1 Module 3 type = FAIO-01) See parameter 14.83 AO1 out at AO1 src max.	- / real32
16.86	AO2 actual value	(Visible when 16.1 Module 3 type = FAIO-01) See parameter 14.86 AO2 actual value.	- / real32
16.87	AO2 source	(Visible when 16.1 Module 3 type = FAIO-01) See parameter 14.87 AO2 source.	Zero / uint32
16.88	AO2 force data	(Visible when 16.1 Module 3 type = FAIO-01) See parameter 14.88 AO2 force data.	- / real32
16.89	AO2 filter time	(Visible when 16.1 Module 3 type = FAIO-01) See parameter 14.89 AO2 filter time.	- / real32
16.90	AO2 source min	(Visible when 16.1 Module 3 type = FAIO-01) See parameter 14.90 AO2 source min.	- / real32
16.91	AO2 source max	(Visible when 16.1 Module 3 type = FAIO-01) See parameter 14.91 AO2 source max.	- / real32
16.92	AO2 out at AO2 src min	(Visible when 16.1 Module 3 type = FAIO-01) See parameter 14.92 AO2 out at AO2 src min.	- / real32
16.93	AO2 out at AO2 src max	(Visible when 16.1 Module 3 type = FAIO-01) See parameter 14.93 AO2 out at AO2 src max.	- / real32

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
<b>19</b>	Operation mode	Selection of local and external control location sources and operating modes.  See also section <a href="#">Operating modes of the drive (page 26)</a> .	
19.1	Actual operation mode	Displays the operating mode currently used.  See parameters <a href="#">19.11...19.14</a> .  This parameter is read-only.	Zero / uint16
	Zero	None.	1
	Speed	Speed control (in DTC motor control mode).	2
	Torque	Torque control (in DTC motor control mode).	3
	Min	The torque selector is comparing the output of the speed controller ( <a href="#">25.1 Torque reference speed control</a> ) and torque reference ( <a href="#">26.74 Torque ref ramp out</a> ) and the smaller of the two is used.	4
	Max	The torque selector is comparing the output of the speed controller ( <a href="#">25.1 Torque reference speed control</a> ) and torque reference ( <a href="#">26.74 Torque ref ramp out</a> ) and the greater of the two is used.	5
	Add	The speed controller output is added to the torque reference.	6
	Voltage	DC voltage control.	7
	Scalar (Hz)	Frequency control in scalar motor control mode.	10
	Scalar (rpm)	Speed control in scalar motor control mode.	11
	Forced magn.	Motor is in magnetizing mode.	20
19.11	Ext1/Ext2 selection	Selects the source for external control location EXT1/EXT2 selection.  0 = EXT1 1 = EXT2	EXT1 / uint32
	EXT1	EXT1 (permanently selected).	0
	EXT2	EXT2 (permanently selected).	1
	FBA A MCW bit 11	Control word bit 11 received through fieldbus interface A.	2
	DI1	Digital input DI1 ( <a href="#">10.2 DI delayed status</a> , bit 0).	3
	DI2	Digital input DI2 ( <a href="#">10.2 DI delayed status</a> , bit 1).	4
	DI3	Digital input DI3 ( <a href="#">10.2 DI delayed status</a> , bit 2).	5
	DI4	Digital input DI4 ( <a href="#">10.2 DI delayed status</a> , bit 3).	6
	DI5	Digital input DI5 ( <a href="#">10.2 DI delayed status</a> , bit 4).	7
	DI6	Digital input DI6 ( <a href="#">10.2 DI delayed status</a> , bit 5).	8
	DIO1	Digital input/output DIO1 ( <a href="#">11.2 DIO delayed status</a> , bit 0).	11

## 252 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	DIO2	Digital input/output DIO2 ( <a href="#">11.2 DIO delayed status</a> , bit 1).	12
	EFB MCW bit 11	Control word bit 11 received through the embedded fieldbus interface.	32
	Other [bit]	See <a href="#">Terms and abbreviations</a> (page 134).	-
19.12	Ext1 control mode	Selects the operating mode for external control location EXT1.	Speed / uint16
	Zero	None.	1
	Speed	Speed control. The torque reference used is <a href="#">25.1 Torque reference speed control</a> (output of the speed reference chain).	2
	Torque	Torque control. The torque reference used is <a href="#">26.74 Torque ref ramp out</a> (output of the torque reference chain).	3
	Minimum	Combination of selections <a href="#">Speed</a> and <a href="#">Torque</a> : the torque selector compares the speed controller output ( <a href="#">25.1 Torque reference speed control</a> ) and the torque reference ( <a href="#">26.74 Torque ref ramp out</a> ) and selects the smaller of the two.  If speed error becomes negative, the drive follows the speed controller output until speed error becomes positive again.  This prevents the drive from accelerating uncontrollably if the load is lost in torque control.	4
	Maximum	Combination of selections <a href="#">Speed</a> and <a href="#">Torque</a> : the torque selector compares the speed controller output ( <a href="#">25.1 Torque reference speed control</a> ) and the torque reference ( <a href="#">26.74 Torque ref ramp out</a> ) and selects the greater of the two.  If speed error becomes positive, the drive follows the speed controller output until speed error becomes negative again.  This prevents the drive from accelerating uncontrollably if the load is lost in torque control.	5
	Add	Combination of selections <a href="#">Speed</a> and <a href="#">Torque</a> : Torque selector adds the speed reference chain output to the torque reference chain output.	6
	Voltage	(Type BCU control units only) DC voltage control. The torque reference used is <a href="#">29.1 Torque ref DC voltage control</a> (output of the DC voltage reference chain).	7
19.14	Ext2 control mode	Selects the operating mode for external control location EXT2.  For the selections, see parameter <a href="#">19.12 Ext1 control mode</a> .	Speed / uint16
19.16	Local control mode	Selects the operating mode for local control.	Speed / uint16

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	Speed	Speed control. The torque reference used is <a href="#">25.1 Torque reference speed control</a> (output of the speed reference chain).	0
	Torque	Torque control. The torque reference used is <a href="#">26.74 Torque ref ramp out</a> (output of the torque reference chain).	1
19.17	Local control disable	<p>Enables/disables local control (start and stop buttons on the control panel, and the local controls on the PC tool).</p> <p> <b>WARNING!</b> Before disabling local control, ensure that the control panel is not needed for stopping the drive.</p>	No / uint16
	No	Local control enabled.	0
	Yes	Local control disabled.	1
19.20	Scalar control reference unit	<p>Selects the reference type for scalar motor control mode.</p> <p>See also section operating <a href="#">Operating modes of the drive (page 26)</a>, and parameter <a href="#">99.4 Motor control mode</a>.</p> <p><b>Note:</b> This parameter cannot be changed while the drive is running.</p>	Rpm / uint16
	Hz	<p>Hz.</p> <p>The reference is taken from parameter <a href="#">28.2 Frequency ref ramp output</a> (output of the frequency control chain).</p>	0
	Rpm	Rpm. The reference is taken from parameter <a href="#">23.2 Speed ref ramp output</a> (speed reference after ramping and shaping).	1

254 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b																					
20	Start/stop/direction	Start/stop/direction and run/start/jog enable signal source selection; positive/negative reference enable signal source selection.  For information on control locations, see section <a href="#">Local control vs. external control (page 23)</a> .																						
20.1	Ext1 commands	Selects the source of start, stop and direction commands for external control location 1 (EXT1).  See also parameters <a href="#">20.2...20.5</a> .	In1 Start; In2 Dir / uint16																					
	Not selected	No start or stop command sources selected.	0																					
	In1 Start	The source of the start and stop commands is selected by parameter <a href="#">20.3 Ext1 in1 source</a> . The state transitions of the source bits are interpreted as follows: <table border="1" data-bbox="342 533 818 676"> <thead> <tr> <th>State of source 1 (20.3)</th> <th>Command</th> </tr> </thead> <tbody> <tr> <td>0→1 (20.2 = Edge)</td> <td>Start</td> </tr> <tr> <td>1 (20.2 = Level)</td> <td></td> </tr> <tr> <td>0</td> <td>Stop</td> </tr> </tbody> </table>	State of source 1 (20.3)	Command	0→1 (20.2 = Edge)	Start	1 (20.2 = Level)		0	Stop	1													
State of source 1 (20.3)	Command																							
0→1 (20.2 = Edge)	Start																							
1 (20.2 = Level)																								
0	Stop																							
	In1 Start; In2 Dir	The source selected by <a href="#">20.3 Ext1 in1 source</a> is the start signal; the source selected by <a href="#">20.4 Ext1 in2 source</a> determines the direction. The state transitions of the source bits are interpreted as follows: <table border="1" data-bbox="342 788 818 975"> <thead> <tr> <th>State of source 1 (20.3)</th> <th>State of source 2 (20.4)</th> <th>Command</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Any</td> <td>Stop</td> </tr> <tr> <td>0→1 (20.2 = Edge)</td> <td>0</td> <td>Start forward</td> </tr> <tr> <td>1 (20.2 = Level)</td> <td>1</td> <td>Start reverse</td> </tr> </tbody> </table>	State of source 1 (20.3)	State of source 2 (20.4)	Command	0	Any	Stop	0→1 (20.2 = Edge)	0	Start forward	1 (20.2 = Level)	1	Start reverse	2									
State of source 1 (20.3)	State of source 2 (20.4)	Command																						
0	Any	Stop																						
0→1 (20.2 = Edge)	0	Start forward																						
1 (20.2 = Level)	1	Start reverse																						
	In1 Start fwd; In2 Start rev	The source selected by <a href="#">20.3 Ext1 in1 source</a> is the forward start signal; the source selected by <a href="#">20.4 Ext1 in2 source</a> is the reverse start signal. The state transitions of the source bits are interpreted as follows: <table border="1" data-bbox="342 1086 818 1401"> <thead> <tr> <th>State of source 1 (20.3)</th> <th>State of source 2 (20.4)</th> <th>Command</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>Stop</td> </tr> <tr> <td>0→1 (20.2 = Edge)</td> <td>0</td> <td>Start forward</td> </tr> <tr> <td>1 (20.2 = Level)</td> <td></td> <td></td> </tr> <tr> <td>0</td> <td>0→1 (20.2 = Edge)</td> <td>Start reverse</td> </tr> <tr> <td>1</td> <td>1 (20.2 = Level)</td> <td></td> </tr> <tr> <td>1</td> <td>1</td> <td>Stop</td> </tr> </tbody> </table>	State of source 1 (20.3)	State of source 2 (20.4)	Command	0	0	Stop	0→1 (20.2 = Edge)	0	Start forward	1 (20.2 = Level)			0	0→1 (20.2 = Edge)	Start reverse	1	1 (20.2 = Level)		1	1	Stop	3
State of source 1 (20.3)	State of source 2 (20.4)	Command																						
0	0	Stop																						
0→1 (20.2 = Edge)	0	Start forward																						
1 (20.2 = Level)																								
0	0→1 (20.2 = Edge)	Start reverse																						
1	1 (20.2 = Level)																							
1	1	Stop																						

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b																
	In1P Start; In2 Stop	<p>The sources of the start and stop commands are selected by parameters <a href="#">20.3 Ext1 in1 source</a> and <a href="#">20.4 Ext1 in2 source</a>.</p> <p>The state transitions of the source bits are interpreted as follows:</p> <table border="1" data-bbox="390 331 866 464"> <thead> <tr> <th data-bbox="395 338 549 387">State of source 1 (20.3)</th> <th data-bbox="554 338 708 387">State of source 2 (20.4)</th> <th data-bbox="713 338 862 387">Command</th> </tr> </thead> <tbody> <tr> <td data-bbox="395 394 549 427">0→1</td> <td data-bbox="554 394 708 427">1</td> <td data-bbox="713 394 862 427">Start</td> </tr> <tr> <td data-bbox="395 434 549 467">Any</td> <td data-bbox="554 434 708 467">0</td> <td data-bbox="713 434 862 467">Stop</td> </tr> </tbody> </table> <p><b>Note:</b> The start signal is always edge-triggered with this setting regardless of parameter <a href="#">20.2 Ext1 start trigger type</a>.</p>	State of source 1 (20.3)	State of source 2 (20.4)	Command	0→1	1	Start	Any	0	Stop	4							
State of source 1 (20.3)	State of source 2 (20.4)	Command																	
0→1	1	Start																	
Any	0	Stop																	
	In1P Start; In2 Stop; In3 Dir	<p>The sources of the start and stop commands are selected by parameters <a href="#">20.3 Ext1 in1 source</a> and <a href="#">20.4 Ext1 in2 source</a>.</p> <p>The source selected by <a href="#">20.5 Ext1 in3 source</a> determines the direction. The state transitions of the source bits are interpreted as follows:</p> <table border="1" data-bbox="390 722 866 962"> <thead> <tr> <th data-bbox="395 729 508 799">State of source 1 (20.3)</th> <th data-bbox="512 729 626 799">State of source 2 (20.4)</th> <th data-bbox="630 729 743 799">State of source 3 (20.5)</th> <th data-bbox="748 729 862 799">Command</th> </tr> </thead> <tbody> <tr> <td data-bbox="395 805 508 855">0→1</td> <td data-bbox="512 805 626 855">1</td> <td data-bbox="630 805 743 855">0</td> <td data-bbox="748 805 862 855">Start forward</td> </tr> <tr> <td data-bbox="395 861 508 911">0→1</td> <td data-bbox="512 861 626 911">1</td> <td data-bbox="630 861 743 911">1</td> <td data-bbox="748 861 862 911">Start reverse</td> </tr> <tr> <td data-bbox="395 917 508 967">Any</td> <td data-bbox="512 917 626 967">0</td> <td data-bbox="630 917 743 967">Any</td> <td data-bbox="748 917 862 967">Stop</td> </tr> </tbody> </table> <p><b>Note:</b> The start signal is always edge-triggered with this setting regardless of parameter <a href="#">20.2 Ext1 start trigger type</a>.</p>	State of source 1 (20.3)	State of source 2 (20.4)	State of source 3 (20.5)	Command	0→1	1	0	Start forward	0→1	1	1	Start reverse	Any	0	Any	Stop	5
State of source 1 (20.3)	State of source 2 (20.4)	State of source 3 (20.5)	Command																
0→1	1	0	Start forward																
0→1	1	1	Start reverse																
Any	0	Any	Stop																

## 256 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b																
	In1P Start fwd; In2P Start rev; In3 Stop	<p>The sources of the start and stop commands are selected by parameters <a href="#">20.3 Ext1 in1 source</a>, <a href="#">20.4 Ext1 in2 source</a> and <a href="#">20.5 Ext1 in3 source</a>. The state transitions of the source bits are interpreted as follows:</p> <table border="1" data-bbox="341 296 819 536"> <thead> <tr> <th data-bbox="341 296 460 376">State of source 1 (20.3)</th> <th data-bbox="460 296 579 376">State of source 2 (20.4)</th> <th data-bbox="579 296 697 376">State of source 3 (20.5)</th> <th data-bbox="697 296 819 376">Command</th> </tr> </thead> <tbody> <tr> <td data-bbox="341 376 460 437">0→1</td> <td data-bbox="460 376 579 437">Any</td> <td data-bbox="579 376 697 437">1</td> <td data-bbox="697 376 819 437">Start forward</td> </tr> <tr> <td data-bbox="341 437 460 497">Any</td> <td data-bbox="460 437 579 497">0→1</td> <td data-bbox="579 437 697 497">1</td> <td data-bbox="697 437 819 497">Start reverse</td> </tr> <tr> <td data-bbox="341 497 460 536">Any</td> <td data-bbox="460 497 579 536">Any</td> <td data-bbox="579 497 697 536">0</td> <td data-bbox="697 497 819 536">Stop</td> </tr> </tbody> </table> <p><b>Note:</b> The start signal is always edge-triggered with this setting regardless of parameter <a href="#">20.2 Ext1 start trigger type</a>.</p>	State of source 1 (20.3)	State of source 2 (20.4)	State of source 3 (20.5)	Command	0→1	Any	1	Start forward	Any	0→1	1	Start reverse	Any	Any	0	Stop	6
State of source 1 (20.3)	State of source 2 (20.4)	State of source 3 (20.5)	Command																
0→1	Any	1	Start forward																
Any	0→1	1	Start reverse																
Any	Any	0	Stop																
	Control panel	The start and stop commands are taken from the control panel.	11																
	Fieldbus A	<p>The start and stop commands are taken from fieldbus adapter A.</p> <p><b>Note:</b> The start signal is always level-triggered with this setting regardless of parameter <a href="#">20.2 Ext1 start trigger type</a>.</p>	12																
	Embedded fieldbus	<p>The start and stop commands are taken from the embedded fieldbus interface.</p> <p><b>Note:</b> The start signal is always level-triggered with this setting regardless of parameter <a href="#">20.2 Ext1 start trigger type</a>.</p>	14																
	M/F link	<p>The start and stop commands are taken from another drive through the master/follower link.</p> <p><b>Note:</b> The start signal is always level-triggered with this setting regardless of parameter <a href="#">20.2 Ext1 start trigger type</a>.</p>	15																
	Application Program	<p>The start and stop commands are taken from the application program control word (parameter <a href="#">6.2 Application control word</a>).</p> <p><b>Note:</b> The start signal is always level-triggered with this setting regardless of parameter <a href="#">20.2 Ext1 start trigger type</a>.</p>	21																
	ATF	Reserved.	22																



No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	DDCS controller	The start and stop commands are taken from an external (DDCS) controller.  <b>Note:</b> The start signal is always level-triggered with this setting regardless of parameter <a href="#">20.2 Ext1 start trigger type</a> .	16
20.2	Ext1 start trigger type	Defines whether the start signal for external control location EXT1 is edge-triggered or level-triggered.  <b>Note:</b> This parameter is only effective when parameter <a href="#">20.1 Ext1 commands</a> is set to <a href="#">In1 Start</a> , <a href="#">In1 Start; In2 Dir</a> , <a href="#">In1 Start fwd</a> ; <a href="#">In2 Start rev</a> , or <a href="#">Control panel</a> .	Edge / uint16
	Edge	The start signal is edge-triggered.	0
	Level	The start signal is level-triggered.	1
20.3	Ext1 in1 source	Selects source 1 for parameter <a href="#">20.1 Ext1 commands</a> .	D11 / uint32
	Not selected	0 (always off).	0
	Selected	1 (always on).	1
	DI1	Digital input DI1 ( <a href="#">10.2 DI delayed status</a> , bit 0).	2
	DI2	Digital input DI2 ( <a href="#">10.2 DI delayed status</a> , bit 1).	3
	DI3	Digital input DI3 ( <a href="#">10.2 DI delayed status</a> , bit 2).	4
	DI4	Digital input DI4 ( <a href="#">10.2 DI delayed status</a> , bit 3).	5
	DI5	Digital input DI5 ( <a href="#">10.2 DI delayed status</a> , bit 4).	6
	DI6	Digital input DI6 ( <a href="#">10.2 DI delayed status</a> , bit 5).	7
	DIO1	Digital input/output DIO1 ( <a href="#">11.2 DIO delayed status</a> , bit 0).	10
	DIO2	Digital input/output DIO2 ( <a href="#">11.2 DIO delayed status</a> , bit 1).	11
	Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-
20.4	Ext1 in2 source	Selects source 2 for parameter <a href="#">20.1 Ext1 commands</a> . For the available selections, see parameter <a href="#">20.3 Ext1 in1 source</a> .	D12 / uint32
20.5	Ext1 in3 source	Selects source 3 for parameter <a href="#">20.1 Ext1 commands</a> . For the available selections, see parameter <a href="#">20.3 Ext1 in1 source</a> .	Not selected / uint32
20.6	Ext2 commands	Selects the source of start, stop and direction commands for external control location 2 (EXT2).  See also parameters <a href="#">20.7...20.10</a> .	Not selected / uint16
	Not selected	No start or stop command sources selected.	0


258 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b														
	In1 Start	<p>The source of the start and stop commands is selected by parameter <a href="#">20.8 Ext2 in1 source</a>. The state transitions of the source bits are interpreted as follows:</p> <table border="1" data-bbox="342 272 814 416"> <thead> <tr> <th data-bbox="342 272 581 304">State of source 1 (20.8)</th> <th data-bbox="581 272 814 304">Command</th> </tr> </thead> <tbody> <tr> <td data-bbox="342 304 581 379">0→1 (20.7 = Edge) 1 (20.7 = Level)</td> <td data-bbox="581 304 814 379">Start</td> </tr> <tr> <td data-bbox="342 379 581 416">0</td> <td data-bbox="581 379 814 416">Stop</td> </tr> </tbody> </table>	State of source 1 (20.8)	Command	0→1 (20.7 = Edge) 1 (20.7 = Level)	Start	0	Stop	1								
State of source 1 (20.8)	Command																
0→1 (20.7 = Edge) 1 (20.7 = Level)	Start																
0	Stop																
	In1 Start; In2 Dir	<p>The source selected by <a href="#">20.8 Ext2 in1 source</a> is the start signal; the source selected by <a href="#">20.9 Ext2 in2 source</a> determines the direction. The state transitions of the source bits are interpreted as follows:</p> <table border="1" data-bbox="342 528 814 715"> <thead> <tr> <th data-bbox="342 528 501 587">State of source 1 (20.8)</th> <th data-bbox="501 528 661 587">State of source 2 (20.9)</th> <th data-bbox="661 528 814 587">Command</th> </tr> </thead> <tbody> <tr> <td data-bbox="342 587 501 624">0</td> <td data-bbox="501 587 661 624">Any</td> <td data-bbox="661 587 814 624">Stop</td> </tr> <tr> <td data-bbox="342 624 501 715" rowspan="2">0→1 (20.7 = Edge) 1 (20.7 = Level)</td> <td data-bbox="501 624 661 660">0</td> <td data-bbox="661 624 814 660">Start forward</td> </tr> <tr> <td data-bbox="501 660 661 715">1</td> <td data-bbox="661 660 814 715">Start reverse</td> </tr> </tbody> </table>	State of source 1 (20.8)	State of source 2 (20.9)	Command	0	Any	Stop	0→1 (20.7 = Edge) 1 (20.7 = Level)	0	Start forward	1	Start reverse	2			
State of source 1 (20.8)	State of source 2 (20.9)	Command															
0	Any	Stop															
0→1 (20.7 = Edge) 1 (20.7 = Level)	0	Start forward															
	1	Start reverse															
	In1 Start fwd; In2 Start rev	<p>The source selected by <a href="#">20.8 Ext2 in1 source</a> is the forward start signal; the source selected by <a href="#">20.9 Ext2 in2 source</a> is the reverse start signal. The state transitions of the source bits are interpreted as follows:</p> <table border="1" data-bbox="342 826 814 1139"> <thead> <tr> <th data-bbox="342 826 501 885">State of source 1 (20.8)</th> <th data-bbox="501 826 661 885">State of source 2 (20.9)</th> <th data-bbox="661 826 814 885">Command</th> </tr> </thead> <tbody> <tr> <td data-bbox="342 885 501 922">0</td> <td data-bbox="501 885 661 922">0</td> <td data-bbox="661 885 814 922">Stop</td> </tr> <tr> <td data-bbox="342 922 501 1013" rowspan="2">0→1 (20.7 = Edge) 1 (20.7 = Level)</td> <td data-bbox="501 922 661 1013">0</td> <td data-bbox="661 922 814 1013">Start forward</td> </tr> <tr> <td data-bbox="501 1013 661 1104">0→1 (20.7 = Edge) 1 (20.7 = Level)</td> <td data-bbox="661 1013 814 1104">Start reverse</td> </tr> <tr> <td data-bbox="342 1104 501 1139">1</td> <td data-bbox="501 1104 661 1139">1</td> <td data-bbox="661 1104 814 1139">Stop</td> </tr> </tbody> </table>	State of source 1 (20.8)	State of source 2 (20.9)	Command	0	0	Stop	0→1 (20.7 = Edge) 1 (20.7 = Level)	0	Start forward	0→1 (20.7 = Edge) 1 (20.7 = Level)	Start reverse	1	1	Stop	3
State of source 1 (20.8)	State of source 2 (20.9)	Command															
0	0	Stop															
0→1 (20.7 = Edge) 1 (20.7 = Level)	0	Start forward															
	0→1 (20.7 = Edge) 1 (20.7 = Level)	Start reverse															
1	1	Stop															

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b																
	In1P Start; In2 Stop	<p>The sources of the start and stop commands are selected by parameters <a href="#">20.8 Ext2 in1 source</a> and <a href="#">20.9 Ext2 in2 source</a>.</p> <p>The state transitions of the source bits are interpreted as follows:</p> <table border="1" data-bbox="393 331 864 464"> <thead> <tr> <th data-bbox="397 338 549 384">State of source 1 (20.8)</th> <th data-bbox="554 338 706 384">State of source 2 (20.9)</th> <th data-bbox="711 338 859 384">Command</th> </tr> </thead> <tbody> <tr> <td data-bbox="397 391 549 421">0→1</td> <td data-bbox="554 391 706 421">1</td> <td data-bbox="711 391 859 421">Start</td> </tr> <tr> <td data-bbox="397 427 549 458">Any</td> <td data-bbox="554 427 706 458">0</td> <td data-bbox="711 427 859 458">Stop</td> </tr> </tbody> </table> <p><b>Note:</b> The start signal is always edge-triggered with this setting regardless of parameter <a href="#">20.7 Ext2 start trigger type</a>.</p>	State of source 1 (20.8)	State of source 2 (20.9)	Command	0→1	1	Start	Any	0	Stop	4							
State of source 1 (20.8)	State of source 2 (20.9)	Command																	
0→1	1	Start																	
Any	0	Stop																	
	In1P Start; In2 Stop; In3 Dir	<p>The sources of the start and stop commands are selected by parameters <a href="#">20.8 Ext2 in1 source</a> and <a href="#">20.9 Ext2 in2 source</a>.</p> <p>The source selected by <a href="#">20.10 Ext2 in3 source</a> determines the direction. The state transitions of the source bits are interpreted as follows:</p> <table border="1" data-bbox="393 722 864 962"> <thead> <tr> <th data-bbox="397 729 508 794">State of source 1 (20.8)</th> <th data-bbox="512 729 623 794">State of source 2 (20.9)</th> <th data-bbox="628 729 739 794">State of source 3 (20.10)</th> <th data-bbox="743 729 854 794">Command</th> </tr> </thead> <tbody> <tr> <td data-bbox="397 801 508 858">0→1</td> <td data-bbox="512 801 623 858">1</td> <td data-bbox="628 801 739 858">0</td> <td data-bbox="743 801 854 858">Start forward</td> </tr> <tr> <td data-bbox="397 865 508 922">0→1</td> <td data-bbox="512 865 623 922">1</td> <td data-bbox="628 865 739 922">1</td> <td data-bbox="743 865 854 922">Start reverse</td> </tr> <tr> <td data-bbox="397 928 508 959">Any</td> <td data-bbox="512 928 623 959">0</td> <td data-bbox="628 928 739 959">Any</td> <td data-bbox="743 928 854 959">Stop</td> </tr> </tbody> </table> <p><b>Note:</b> The start signal is always edge-triggered with this setting regardless of parameter <a href="#">20.7 Ext2 start trigger type</a>.</p>	State of source 1 (20.8)	State of source 2 (20.9)	State of source 3 (20.10)	Command	0→1	1	0	Start forward	0→1	1	1	Start reverse	Any	0	Any	Stop	5
State of source 1 (20.8)	State of source 2 (20.9)	State of source 3 (20.10)	Command																
0→1	1	0	Start forward																
0→1	1	1	Start reverse																
Any	0	Any	Stop																

## 260 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b																
	In1P Start fwd; In2P Start rev; In3 Stop	<p>The sources of the start and stop commands are selected by parameters <a href="#">20.8 Ext2 in1 source</a>, <a href="#">20.9 Ext2 in2 source</a> and <a href="#">20.10 Ext2 in3 source</a>. The state transitions of the source bits are interpreted as follows:</p> <table border="1" data-bbox="340 296 820 536"> <thead> <tr> <th data-bbox="340 296 460 376">State of source 1 (20.8)</th> <th data-bbox="460 296 580 376">State of source 2 (20.9)</th> <th data-bbox="580 296 700 376">State of source 3 (20.10)</th> <th data-bbox="700 296 820 376">Command</th> </tr> </thead> <tbody> <tr> <td data-bbox="340 376 460 438">0→1</td> <td data-bbox="460 376 580 438">Any</td> <td data-bbox="580 376 700 438">1</td> <td data-bbox="700 376 820 438">Start forward</td> </tr> <tr> <td data-bbox="340 438 460 501">Any</td> <td data-bbox="460 438 580 501">0→1</td> <td data-bbox="580 438 700 501">1</td> <td data-bbox="700 438 820 501">Start reverse</td> </tr> <tr> <td data-bbox="340 501 460 536">Any</td> <td data-bbox="460 501 580 536">Any</td> <td data-bbox="580 501 700 536">0</td> <td data-bbox="700 501 820 536">Stop</td> </tr> </tbody> </table> <p><b>Note:</b> The start signal is always edge-triggered with this setting regardless of parameter <a href="#">20.7 Ext2 start trigger type</a>.</p>	State of source 1 (20.8)	State of source 2 (20.9)	State of source 3 (20.10)	Command	0→1	Any	1	Start forward	Any	0→1	1	Start reverse	Any	Any	0	Stop	6
State of source 1 (20.8)	State of source 2 (20.9)	State of source 3 (20.10)	Command																
0→1	Any	1	Start forward																
Any	0→1	1	Start reverse																
Any	Any	0	Stop																
	Control panel	The start and stop commands are taken from the control panel.	11																
	Fieldbus A	<p>The start and stop commands are taken from fieldbus adapter A.</p> <p><b>Note:</b> The start signal is always edge-triggered with this setting regardless of parameter <a href="#">20.7 Ext2 start trigger type</a>.</p>	12																
	Embedded fieldbus	<p>The start and stop commands are taken from the embedded fieldbus interface.</p> <p><b>Note:</b> The start signal is always edge-triggered with this setting regardless of parameter <a href="#">20.7 Ext2 start trigger type</a>.</p>	14																
	M/F link	<p>The start and stop commands are taken from another drive through the master/follower link.</p> <p><b>Note:</b> The start signal is always edge-triggered with this setting regardless of parameter <a href="#">20.7 Ext2 start trigger type</a>.</p>	15																
	Application Program	<p>The start and stop commands are taken from the application program control word (parameter <a href="#">6.2 Application control word</a>).</p> <p><b>Note:</b> The start signal is always edge-triggered with this setting regardless of parameter <a href="#">20.7 Ext2 start trigger type</a>.</p>	21																
	ATF	Reserved.	22																


No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	DDCS controller	The start and stop commands are taken from an external (DDCS) controller.  <b>Note:</b> The start signal is always edge-triggered with this setting regardless of parameter <a href="#">20.7 Ext2 start trigger type</a> .	16
20.7	Ext2 start trigger type	Defines whether the start signal for external control location EXT2 is edge-triggered or level-triggered.  <b>Note:</b> This parameter is only effective when parameter <a href="#">20.6 Ext2 commands</a> is set to <a href="#">In1 Start</a> ; <a href="#">In2 Dir</a> , <a href="#">In1 Start fwd</a> ; <a href="#">In2 Start rev</a> , or <a href="#">Control panel</a> .	Edge / uint16
	Edge	The start signal is edge-triggered.	0
	Level	The start signal is level-triggered.	1
20.8	Ext2 in1 source	Selects source 1 for parameter <a href="#">20.6 Ext2 commands</a> . For the available selections, see parameter <a href="#">20.3 Ext1 in1 source</a> .	Not selected / uint32
20.9	Ext2 in2 source	Selects source 2 for parameter <a href="#">20.6 Ext2 commands</a> . For the available selections, see parameter <a href="#">20.3 Ext1 in1 source</a> .	Not selected / uint32
20.10	Ext2 in3 source	Selects source 3 for parameter <a href="#">20.6 Ext2 commands</a> . For the available selections, see parameter <a href="#">20.3 Ext1 in1 source</a> .	Not selected / uint32
20.11	Run enable stop mode	Selects the way the motor is stopped when the run enable signal switches off.  The source of the run enable signal is selected by parameter <a href="#">20.12 Run enable 1 source</a> .	Coast (95.20 b10) / uint16
	Coast	Stop by switching off the output semiconductors of the drive.  The motor coasts to a stop.   <b>WARNING!</b> If a mechanical brake is used, ensure it is safe to stop the drive by coasting.	0
	Ramp	Stop along the active deceleration ramp. See parameter group <a href="#">23 Speed reference ramp</a> (page 288).	1
	Torque limit	Stop according to torque limits (parameters <a href="#">30.19</a> and <a href="#">30.20</a> ).	2

## 262 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
20.12	Run enable 1 source	<p>Selects the source of the external run enable signal. If the run enable signal is switched off, the drive will not start. If already running, the drive will stop according to the setting of parameter <a href="#">20.11 Run enable stop mode</a>.</p> <p>1 = Run enable signal on.</p> <p><b>Note:</b> The warning that indicates a missing signal can be suppressed using parameter <a href="#">20.30 Enable signals warning function</a>.</p> <p>See also parameter <a href="#">20.19 Enable start command</a>.</p>	DIIL (95.20 b10); Selected (95.20 b5); DI5 (95.20 b9) / uint32
	Not selected	0	0
	Selected	1	1
	DI1	Digital input DI1 ( <a href="#">10.2 DI delayed status</a> , bit 0).	2
	DI2	Digital input DI2 ( <a href="#">10.2 DI delayed status</a> , bit 1).	3
	DI3	Digital input DI3 ( <a href="#">10.2 DI delayed status</a> , bit 2).	4
	DI4	Digital input DI4 ( <a href="#">10.2 DI delayed status</a> , bit 3).	5
	DI5	Digital input DI5 ( <a href="#">10.2 DI delayed status</a> , bit 4).	6
	DI6	Digital input DI6 ( <a href="#">10.2 DI delayed status</a> , bit 5).	7
	DIO1	Digital input/output DIO1 ( <a href="#">11.2 DIO delayed status</a> , bit 0).	10
	DIO2	Digital input/output DIO2 ( <a href="#">11.2 DIO delayed status</a> , bit 1).	11
	FBA A MCW bit 3	Control word bit 3 received through fieldbus interface A.	30
	EFB MCW bit 3	Control word bit 3 received through the embedded fieldbus interface.	32
	DIIL	DIIL input ( <a href="#">10.2 DI delayed status</a> , bit 15).	33
	Active control source MCW bit 3	<p>Control word bit 3 received from the active control source.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>If the drive is running in fieldbus control, switching bit 3 off effectively removes both the start and run enable signals.</li> <li>In this case, the stop mode is determined by either <a href="#">20.11 Run enable stop mode</a> or <a href="#">21.3 Stop mode</a>, whichever mode has higher priority. The order of stop modes from highest to lowest priority is <a href="#">Coast – Torque limit – Ramp</a>.</li> </ul> <p>In case the active source is the control panel, PC tool or drive I/O, the run enable signal is always on.</p>	34
	Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
20.19	Enable start command	<p>Selects the source for the start enable signal.</p> <p>1 = Start enable.</p> <p>With the signal switched off, any drive start command is inhibited. (Switching the signal off while the drive is running will not stop the drive.)</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>If a level-triggered start command is on when the start enable signal switches on, the drive will start. (An edgetriggered start signal must be cycled for the drive to start.) See parameters <a href="#">20.2 Ext1 start trigger type</a>, <a href="#">20.7 Ext2 start trigger type</a> and <a href="#">20.29 Local start trigger type</a>.</li> <li>The warning that indicates a missing signal can be suppressed using parameter <a href="#">20.30 Enable signals warning function</a>.</li> </ul> <p>See also parameter <a href="#">20.12 Run enable 1 source</a>.</p>	Selected / uint32
	Not selected	0	0
	Selected	1	1
	DI1	Digital input DI1 ( <a href="#">10.2 DI delayed status</a> , bit 0).	2
	DI2	Digital input DI2 ( <a href="#">10.2 DI delayed status</a> , bit 1).	3
	DI3	Digital input DI3 ( <a href="#">10.2 DI delayed status</a> , bit 2).	4
	DI4	Digital input DI4 ( <a href="#">10.2 DI delayed status</a> , bit 3).	5
	DI5	Digital input DI5 ( <a href="#">10.2 DI delayed status</a> , bit 4).	6
	DI6	Digital input DI6 ( <a href="#">10.2 DI delayed status</a> , bit 5).	7
	DIO1	Digital input/output DIO1 ( <a href="#">11.2 DIO delayed status</a> , bit 0).	10
	DIO2	Digital input/output DIO1 ( <a href="#">11.2 DIO delayed status</a> , bit 1).	11
	DIIL	DIIL input ( <a href="#">10.2 DI delayed status</a> , bit 15).	30
	Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-

## 264 Parameters


No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
20.23	Positive speed enable	<p>Selects the source of the positive speed enable command.</p> <p>1 = Positive speed enabled.</p> <p>0 = Positive speed interpreted as zero speed reference. In the figure below, <a href="#">23.1 Speed ref ramp input</a> is set to zero after the positive speed enable signal has cleared.</p> <p>Actions in different control modes:</p> <p>Speed control: Speed reference is set to zero and the motor ramps down along the currently active deceleration ramp. The drive keeps modulating. The rush controller prevents additional torque terms from running the motor in the positive direction.</p> <p>Torque control: The rush controller monitors the rotation direction of the motor.</p> 	Selected / uint32
	Not selected	0	0
	Selected	1	1
	DI1	Digital input DI1 ( <a href="#">10.2 DI delayed status</a> , bit 0).	2
	DI2	Digital input DI2 ( <a href="#">10.2 DI delayed status</a> , bit 1).	3
	DI3	Digital input DI3 ( <a href="#">10.2 DI delayed status</a> , bit 2).	4
	DI4	Digital input DI4 ( <a href="#">10.2 DI delayed status</a> , bit 3).	5
	DI5	Digital input DI5 ( <a href="#">10.2 DI delayed status</a> , bit 4).	6
	DI6	Digital input DI6 ( <a href="#">10.2 DI delayed status</a> , bit 5).	7
	DIO1	Digital input/output DIO1 ( <a href="#">11.2 DIO delayed status</a> , bit 0).	10
	DIO2	Digital input/output DIO2 ( <a href="#">11.2 DIO delayed status</a> , bit 1).	11
	Other [bit]	See <a href="#">Terms and abbreviations</a> (page 134).	-
20.24	Negative speed enable	Selects the source of the negative speed reference enable command. See parameter <a href="#">20.23 Positive speed enable</a> .	Selected / uint32




No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
20.25	Jogging enable	<p>Selects the source for a jog enable signal.</p> <p>(The sources for jogging activation signals are selected by parameters <a href="#">20.26 Jogging 1 start source</a> and <a href="#">20.27 Jogging 2 start source</a>.)</p> <p>1 = Jogging is enabled. 0 = Jogging is disabled.</p> <p><b>Note:</b> Jogging can be enabled only when no start command from an external control location is active. On the other hand, if jogging is already enabled, the drive cannot be started from an external control location (apart from inching commands through fieldbus).</p> <p>See section <a href="#">Jogging (page 60)</a>.</p>	Not selected / uint32
	Not selected	0	0
	Selected	1	1
	DI1	Digital input DI1 ( <a href="#">10.2 DI delayed status</a> , bit 0).	2
	DI2	Digital input DI2 ( <a href="#">10.2 DI delayed status</a> , bit 1).	3
	DI3	Digital input DI3 ( <a href="#">10.2 DI delayed status</a> , bit 2).	4
	DI4	Digital input DI4 ( <a href="#">10.2 DI delayed status</a> , bit 3).	5
	DI5	Digital input DI5 ( <a href="#">10.2 DI delayed status</a> , bit 4).	6
	DI6	Digital input DI6 ( <a href="#">10.2 DI delayed status</a> , bit 5).	7
	DIO1	Digital input/output DIO1 ( <a href="#">11.2 DIO delayed status</a> , bit 0).	10
	DIO2	Digital input/output DIO1 ( <a href="#">11.2 DIO delayed status</a> , bit 1).	11
	Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-
20.26	Jogging 1 start source	<p>If enabled by parameter <a href="#">20.25 Jogging enable</a>, selects the source for the activation of jogging function 1. (Jogging function 1 can also be activated through fieldbus regardless of parameter <a href="#">20.25</a>.)</p> <p>1 = Jogging 1 active.</p> <p><b>Note:</b> If both jogging 1 and 2 are activated, the one that was activated first has priority.</p>	Not selected / uint32
	Not selected	0	0
	Selected	1	1
	DI1	Digital input DI1 ( <a href="#">10.2 DI delayed status</a> , bit 0).	2
	DI2	Digital input DI2 ( <a href="#">10.2 DI delayed status</a> , bit 1).	3
	DI3	Digital input DI3 ( <a href="#">10.2 DI delayed status</a> , bit 02).	4
	DI4	Digital input DI4 ( <a href="#">10.2 DI delayed status</a> , bit 3).	5
	DI5	Digital input DI5 ( <a href="#">10.2 DI delayed status</a> , bit 4).	6
	DI6	Digital input DI6 ( <a href="#">10.2 DI delayed status</a> , bit 5).	7

## 266 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	DIO1	Digital input/output DIO1 (11.2 DIO delayed status, bit 0).	10
	DIO2	Digital input/output DIO1 (11.2 DIO delayed status, bit 0).	11
	Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-
20.27	Jogging 2 start source	<p>If enabled by parameter <a href="#">20.25 Jogging enable</a>, selects the source for the activation of jogging function 2. (Jogging function 2 can also be activated through fieldbus regardless of parameter <a href="#">20.25</a>.)</p> <p>1 = Jogging 2 active.</p> <p>For the selections, see parameter <a href="#">20.26 Jogging 1 start source</a>.</p> <p><b>Note:</b> If both jogging 1 and 2 are activated, the one that was activated first has priority.</p>	Not selected / uint32
20.29	Local start trigger type	Defines whether the start signal for local control (for example, control panel or PC tool) is edge-triggered or level-triggered.	Edge / uint16
	Edge	The start signal is edge-triggered.	0
	Level	The start signal is level-triggered.	1
20.30	Enable signals warning function	<p>Selects enable signal (eg. run enable, start enable) warnings to be suppressed. This parameter can be used to prevent these warnings from flooding the event log.</p> <p>Whenever a bit of this parameter is set to 1, the corresponding warning is suppressed, ie. no warning is generated even if the signal is switched off.</p> <p>The bits of this binary number correspond to the following warnings:</p>	- / uint16
	b0 Enable Start	<a href="#">AFEA Enable start signal missing</a>	
	b1 Run enable 1	<a href="#">AFEB Run enable missing</a>	
	b2...15 Reserved		
	0000h...FFFFh		1 = 1 / 1 = 1

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
21	Start/stop mode	Start and stop modes; emergency stop mode and signal source selection; DC magnetization settings; autophasing mode selection.	
21.1	Start mode	<p>Selects the motor start function for the DTC motor control mode, ie. when <a href="#">99.4 Motor control mode</a> is set to <a href="#">DTC</a>.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>• The start function for the scalar motor control mode is selected by parameter <a href="#">21.19 Scalar start mode</a>.</li> <li>• Starting into a rotating motor is not possible when DC magnetizing is selected (<a href="#">Fast</a> or <a href="#">Constant time</a>).</li> <li>• With permanent magnet motors and synchronous reluctance motors, <a href="#">Automatic</a> start mode must be used.</li> <li>• This parameter cannot be changed while the drive is running.</li> </ul> <p>See also section <a href="#">DC magnetization (page 67)</a>.</p>	Automatic / uint16
	Fast	The drive pre-magnetizes the motor before start. The premagnetizing time is determined automatically, being typically 200 ms to 2 s depending on motor size. This mode should be selected if a high break-away torque is required.	0
	Constant time	<p>The drive pre-magnetizes the motor before start. The premagnetizing time is defined by parameter <a href="#">21.2 Magnetization time</a>. This mode should be selected if constant pre-magnetizing time is required (e.g. if the motor start must be synchronized with the release of a mechanical brake). This setting also guarantees the highest possible break-away torque when the pre-magnetizing time is set long enough.</p> <p> <b>WARNING!</b> The drive will start after the set magnetizing time has passed even if motor magnetization is not completed. In applications where a full break-away torque is essential, ensure that the constant magnetizing time is long enough to allow generation of full magnetization and torque.</p>	1
	Automatic	<p>Automatic start guarantees optimal motor start in most cases.</p> <p>It includes the flying start function (starting into a rotating motor) and the automatic restart function (a stopped motor can be restarted immediately without waiting the motor flux to die away). The drive motor control program identifies the flux as well as the mechanical state of the motor and starts the motor instantly under all conditions.</p>	2
	Flying start	This method is intended for asynchronous motors only, and is optimized for applications where the drive must be started into a rotating motor at high frequencies (above 150 Hz).	3



## 268 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b										
21.2	Magnetization time	<p>Defines the pre-magnetization time when</p> <ul style="list-style-type: none"> <li>parameter <a href="#">21.1 Start mode</a> is set to <a href="#">Constant time</a> (in DTC motor control mode), or</li> <li>parameter <a href="#">21.19 Scalar start mode</a> is set to <a href="#">Const time</a> (in scalar motor control mode).</li> </ul> <p>After the start command, the drive automatically pre-magnetizes the motor for the set time. To ensure full magnetizing, set this parameter to the same value as, or higher than, the rotor time constant. If not known, use the rule-of-thumb value given in the table below:</p> <table border="1" data-bbox="342 440 818 651"> <thead> <tr> <th data-bbox="342 440 580 501">Motor rated power</th> <th data-bbox="580 440 818 501">Constant magnetizing time</th> </tr> </thead> <tbody> <tr> <td data-bbox="342 501 580 536">&lt; 1 kW</td> <td data-bbox="580 501 818 536">≥ 50 to 100 ms</td> </tr> <tr> <td data-bbox="342 536 580 571">1 to 10 kW</td> <td data-bbox="580 536 818 571">≥ 100 to 200 ms</td> </tr> <tr> <td data-bbox="342 571 580 606">10 to 200 kW</td> <td data-bbox="580 571 818 606">≥ 200 to 1000 ms</td> </tr> <tr> <td data-bbox="342 606 580 651">200 to 1000 kW</td> <td data-bbox="580 606 818 651">≥ 1000 to 2000 ms</td> </tr> </tbody> </table> <p><b>Note:</b> This parameter cannot be changed while the drive is running.</p>	Motor rated power	Constant magnetizing time	< 1 kW	≥ 50 to 100 ms	1 to 10 kW	≥ 100 to 200 ms	10 to 200 kW	≥ 200 to 1000 ms	200 to 1000 kW	≥ 1000 to 2000 ms	500 ms / uint16
Motor rated power	Constant magnetizing time												
< 1 kW	≥ 50 to 100 ms												
1 to 10 kW	≥ 100 to 200 ms												
10 to 200 kW	≥ 200 to 1000 ms												
200 to 1000 kW	≥ 1000 to 2000 ms												
	0...10000 ms	Constant DC magnetizing time.	1 = 1 ms / 1 = 1 ms										
21.3	Stop mode	<p>Selects the way the motor is stopped when a stop command is received.</p> <p>Additional braking is possible by selecting flux braking (see parameter <a href="#">97.5 Flux braking</a>).</p> <p><b>Note:</b> This parameter has no effect in a follower drive in a master/follower configuration.</p>	Coast / uint16										
	Coast	<p>Stop by switching off the output semiconductors of the drive.</p> <p>The motor coasts to a stop.</p> <p> <b>WARNING!</b> If a mechanical brake is used, ensure it is safe to stop the drive by coasting.</p>	0										
	Ramp	Stop along the active deceleration ramp. See parameter group <a href="#">23 Speed reference ramp</a> (page 288).	1										
	Torque limit	Stop according to torque limits (parameters <a href="#">30.19</a> and <a href="#">30.20</a> ).	2										
21.4	Emergency stop mode	<p>Selects the way the motor is stopped when an emergency stop command is received.</p> <p>The source of the emergency stop signal is selected by parameter <a href="#">21.5 Emergency stop source</a>.</p>	Ramp stop (Off1); Coast stop (Off2) (95.20 b1); Eme ramp stop (Off3) (95.20 b2) / uint16										

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	Ramp stop (Off1)	With the drive running: <ul style="list-style-type: none"> <li>• 1 = Normal operation.</li> <li>• 0 = Normal stop along the standard deceleration ramp defined for the particular reference type (see section <a href="#">Reference ramping (page 46)</a>). After the drive has stopped, it can be restarted by removing the emergency stop signal and switching the start signal from 0 to 1.</li> </ul> With the drive stopped: <ul style="list-style-type: none"> <li>• 1 = Starting allowed.</li> <li>• 0 = Starting not allowed.</li> </ul>	0
	Coast stop (Off2)	With the drive running: <ul style="list-style-type: none"> <li>• 1 = Normal operation.</li> <li>• 0 = Stop by coasting. The drive can be restarted by restoring the start interlock signal and switching the start signal from 0 to 1.</li> </ul> With the drive stopped: <ul style="list-style-type: none"> <li>• 1 = Starting allowed.</li> <li>• 0 = Starting not allowed.</li> </ul>	1
	Eme ramp stop (Off3)	With the drive running: <ul style="list-style-type: none"> <li>• 1 = Normal operation.</li> <li>• 0 = Stop by ramping along emergency stop ramp defined by parameter <a href="#">23.23 Emergency stop time</a>. After the drive has stopped, it can be restarted by removing the emergency stop signal and switching the start signal from 0 to 1.</li> </ul> With the drive stopped: <ul style="list-style-type: none"> <li>• 1 = Starting allowed.</li> <li>• 0 = Starting not allowed.</li> </ul>	2
21.5	Emergency stop source	Selects the source of the emergency stop signal. The stop mode is selected by parameter <a href="#">21.4 Emergency stop mode</a> . 0 = Emergency stop active 1 = Normal operation  <b>Note:</b> This parameter cannot be changed while the drive is running.	Inactive (true); DI4 (95.20 b1, 95.20 b2) / uint32
	Active (false)	0.	0
	Inactive (true)	1.	1
	DIIL	DIIL input ( <a href="#">10.2 DI delayed status</a> , bit 15).	2
	DI1	Digital input DI1 ( <a href="#">10.2 DI delayed status</a> , bit 0).	3
	DI2	Digital input DI2 ( <a href="#">10.2 DI delayed status</a> , bit 1).	4
	DI3	Digital input DI3 ( <a href="#">10.2 DI delayed status</a> , bit 2).	5
	DI4	Digital input DI4 ( <a href="#">10.2 DI delayed status</a> , bit 3).	6
	DI5	Digital input DI5 ( <a href="#">10.2 DI delayed status</a> , bit 4).	7
	DI6	Digital input DI6 ( <a href="#">10.2 DI delayed status</a> , bit 5).	8

## 270 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	DIO1	Digital input/output DIO1 ( <a href="#">11.2 DIO delayed status</a> , bit 0).	11
	DIO2	Digital input/output DIO2 ( <a href="#">11.2 DIO delayed status</a> , bit 1).	12
	Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-
21.6	Zero speed limit	<p>Defines the zero speed limit. The motor is stopped along a speed ramp (when ramped stop is selected) until the defined zero speed limit is reached. After the zero speed delay, the motor coasts to a stop.</p> <p><b>Note:</b> If you use a value below the default, make sure the drive is able to stop.</p>	30.00 rpm / real32
	0.00 ... 30000.00 rpm	Zero speed limit. For 16-bit scaling, see parameter <a href="#">46.1</a> .	- / 100 = 1 rpm

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
21.7	Zero speed delay	<p>Defines the delay for the zero speed delay function. The function is useful in applications where a smooth and quick restarting is essential. During the delay, the drive knows the rotor position accurately.</p> <p><u>Without zero speed delay:</u></p> <p>The drive receives a stop command and decelerates along a ramp. When actual motor speed falls below the value of parameter <a href="#">21.6 Zero speed limit</a>, inverter modulation is stopped and the motor coasts to a standstill.</p>  <p><u>With zero speed delay:</u></p> <p>The drive receives a stop command and decelerates along a ramp. When actual motor speed falls below the value of parameter <a href="#">21.6 Zero speed limit</a>, the zero speed delay function activates. During the delay the function keeps the speed controller live: the inverter modulates, motor is magnetized and the drive is ready for a quick restart. Zero speed delay can be used e.g. with the jogging function.</p> 	0 ms / real32
	0...30000 ms	Zero speed delay.	1 = 1 ms / 1 = 1 ms

## 272 Parameters



No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
21.8	DC current control	<p>Activates/deactivates the DC hold and post-magnetization functions. See section <a href="#">DC magnetization (page 67)</a>.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>DC hold is only available with speed control in DTC motor control mode (see page 26).</li> <li>DC magnetization causes the motor to heat up. In applications where long DC magnetization times are required, externally ventilated motors should be used. If the DC magnetization period is long, DC magnetization cannot prevent the motor shaft from rotating if a constant load is applied to the motor.</li> </ul>	- / uint16
b0	DC hold	<p>1 = Enable DC hold. See section <a href="#">DC hold (page 67)</a>.</p> <p><b>Note:</b> The DC hold function has no effect if the start signal is switched off.</p>	
b1	Post magnetization	<p>1 = Enable post-magnetization. See section <a href="#">Post-magnetization (page 68)</a>.</p> <p><b>Note:</b> Post-magnetization is only available when ramping is the selected stop mode (see parameter <a href="#">21.3 Stop mode</a>).</p>	
b2...15	Reserved		
	0000h...FFFFh		1 = 1 / 1 = 1
21.9	DC hold speed	<p>Defines the DC hold speed. See parameter <a href="#">21.8 DC current control</a>, and section <a href="#">DC hold (page 67)</a>.</p>	5.00 rpm / real32
	0.00 ... 1000.00 rpm	DC hold speed. For 16-bit scaling, see parameter <a href="#">46.1</a> .	- / 100 = 1 rpm
21.10	DC current reference	<p>Defines the DC hold current in percent of the motor nominal current. See parameter <a href="#">21.8 DC current control</a>, and section <a href="#">DC magnetization (page 67)</a>.</p>	30.0 % / real32
	0.0 ... 100.0 %	DC hold current.	1 = 1 % / 10 = 1 %
21.11	Post magnetization time	<p>Defines the length of time for which post-magnetization is active after stopping the motor. The magnetization current is defined by parameter <a href="#">21.10 DC current reference</a>.</p> <p>See parameter <a href="#">21.8 DC current control</a>.</p>	0 s / uint32
	0...3000 s	Post-magnetization time.	1 = 1 s / 1 = 1 s




No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
21.12	Continuous magnetization command	<p>Activates/deactivates (or selects a source that activates/deactivates) continuous magnetization. See section <a href="#">Continuous magnetization (page 68)</a>.</p> <p>The magnetization current is calculated on the basis of flux reference (see parameter group <a href="#">97 Motor control</a>).</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>This function is only available in DTC motor control mode.</li> <li>Continuous magnetization causes the motor to heat up. In applications where long magnetization times are required, externally ventilated motors should be used.</li> <li>Continuous magnetization may not be able to prevent the motor shaft from rotating during a long period if a constant load is applied to the motor.</li> </ul> <p>0 = Normal operation 1 = Magnetization active</p>	Off / uint32
	Off	0.	0
	On	1.	1
	Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-
21.13	Autophasing mode	<p>Selects the way autophasing is performed. See section <a href="#">Autophasing (page 63)</a>.</p> <p><b>Note:</b> This parameter cannot be changed while the drive is running.</p>	Turning / uint16
	Turning	<p>This mode gives the most accurate autophasing result. This mode can be used, and is recommended, if the motor is allowed to rotate and the start-up is not time-critical.</p> <p><b>Note:</b> This mode will cause the motor to rotate. The load torque must be less than 5%.</p>	0
	Standstill 1	<p>Faster than the <a href="#">Turning</a> mode, but not as accurate. The motor will not rotate.</p> <p>Permanent magnet motors: This mode is recommended with salient-pole motors.</p>	1
	Standstill 2	<p>An alternative standstill autophasing mode that can be used if the <a href="#">Turning</a> mode cannot be used, and the <a href="#">Standstill 1</a> mode gives erratic results. However, this mode is considerably slower than <a href="#">Standstill 1</a>.</p> <p>Permanent magnet motors: This mode is recommended with non salient-pole motors.</p>	2
	Turning with Z-pulse	<p>This mode should be used if the zero pulse signal of the pulse encoder is to be observed, and other modes do not give a result. The motor will turn until a zero pulse is detected.</p>	3

## 274 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
21.14	Pre-heating input source	<p>Selects the source of the motor pre-heat on/off command.</p> <p>See section <a href="#">Pre-heating (page 67)</a>.</p> <p><b>Note:</b> The pre-heating function will not activate if</p> <ul style="list-style-type: none"> <li>• the Safe torque off function is active,</li> <li>• a fault is active,</li> <li>• less than one minute has elapsed after stopping, or</li> <li>• PID sleep function is active.</li> </ul> <p>Pre-heating is deactivated when the drive is started, and overridden by pre-magnetization, post-magnetization or continuous magnetization.</p> <p>0 = Pre-heating inactive 1 = Pre-heating active</p>	Inactive (false) / uint32
	Inactive (false)	0. Pre-heating is always deactivated.	0
	Active (true)	1. Pre-heating is always activated when the drive is stopped (apart from conditions stated above).	1
	DI1	Digital input DI1 ( <a href="#">10.2 DI delayed status</a> , bit 0).	2
	DI2	Digital input DI2 ( <a href="#">10.2 DI delayed status</a> , bit 1).	3
	DI3	Digital input DI3 ( <a href="#">10.2 DI delayed status</a> , bit 2).	4
	DI4	Digital input DI4 ( <a href="#">10.2 DI delayed status</a> , bit 3).	5
	DI5	Digital input DI5 ( <a href="#">10.2 DI delayed status</a> , bit 4).	6
	DI6	Digital input DI6 ( <a href="#">10.2 DI delayed status</a> , bit 5).	7
	Supervision 1	Supervision 1 active ( <a href="#">32.1 Supervision status</a> , bit 0).	8
	Supervision 2	Supervision 2 active ( <a href="#">32.1 Supervision status</a> , bit 1).	9
	Supervision 3	Supervision 3 active ( <a href="#">32.1 Supervision status</a> , bit 2).	10
	Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-
21.15	Pre-heating time delay	Defines the delay time for the pre-heating function.	60 s / real32
	10...3000 s	Pre-heating time delay.	1 = 1 s / 1 = 1 s
21.16	Pre-heating current	Defines the motor pre-heating current that is fed into the motor when the source selected by <a href="#">21.14 Pre-heating input source</a> is on. The value is in percent of the nominal motor current.	0.0 % / real32
	0.0 ... 30.0 %	Pre-heating current.	1 = 1 % / 10 = 1 %


No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
21.18	Auto restart time	<p>The motor can be automatically started after a short supply power failure using the automatic restart function. See section <a href="#">Automatic restart (page 81)</a>.</p> <p>When this parameter is set to 0.0 seconds, automatic restarting is disabled. Otherwise, the parameter defines the maximum duration of the power failure after which restarting is attempted. Note that this time also includes the DC precharging delay.</p> <p> <b>WARNING!</b> The function restarts the drive automatically and continues operation after a supply break. Make sure that no dangerous situations can occur.</p>	5.0 s / real32
	0.0 ... 10.0 s	<p>0.0 s = Automatic restarting disabled.</p> <p>0.1 ... 10.0 s = Maximum power failure duration.</p>	1 = 1 s / 10 = 1 s
21.19	Scalar start mode	<p>Selects the motor start function for the scalar motor control mode, ie. when <a href="#">99.4 Motor control mode</a> is set to <i>Scalar</i>.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>The start function for the DTC motor control mode is selected by parameter <a href="#">21.1 Start mode</a>.</li> <li>With permanent magnet motors, <i>Automatic start mode</i> must be used.</li> </ul> <p>See also section <a href="#">DC magnetization (page 67)</a>.</p>	Normal / uint16
	Normal	Immediate start from zero speed.	0
	Const time	<p>The drive pre-magnetizes the motor before start. The premagnetizing time is defined by parameter <a href="#">21.2 Magnetization time</a>. This mode should be selected if constant pre-magnetizing time is required (e.g. if the motor start must be synchronized with the release of a mechanical brake). This setting also guarantees the highest possible break-away torque when the pre-magnetizing time is set long enough.</p> <p><b>Note:</b> This mode cannot be used to start into a rotating motor.</p> <p> <b>WARNING!</b> The drive will start after the set magnetizing time has passed even if motor magnetization is not completed. In applications where a full break-away torque is essential, ensure that the constant magnetizing time is long enough to allow generation of full magnetization and torque.</p>	1
	Automatic	<p>This setting should be used</p> <ul style="list-style-type: none"> <li>in applications where flying starts (ie. starting into a rotating motor) are required, and</li> <li>with permanent magnet motors.</li> </ul>	2

276 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
21.20	Follower force ramp stop	<p>In a torque-controlled follower drive, forces (or selects a source that forces) the drive to switch to speed control upon a ramp stop (Off1 or Off3) command. This is required for an independent ramp stop of the follower.</p> <p>See also section <a href="#">Master/follower functionality</a>.</p> <p>1 = Ramp stop forces speed control</p>	Not selected / uint32
	Not selected	0.	0
	Selected	1.	1
	DIIL	DIIL input (10.2 DI delayed status, bit 15).	2
	DI1	Digital input DI1 (10.2 DI delayed status, bit 0).	3
	DI2	Digital input DI2 (10.2 DI delayed status, bit 1).	4
	DI3	Digital input DI3 (10.2 DI delayed status, bit 2).	5
	DI4	Digital input DI4 (10.2 DI delayed status, bit 3).	6
	DI5	Digital input DI5 (10.2 DI delayed status, bit 4).	7
	DI6	Digital input DI6 (10.2 DI delayed status, bit 5).	8
	DIO1	Digital input/output DIO1 (11.2 DIO delayed status, bit 0).	11
	DIO2	Digital input/output DIO2 (11.2 DIO delayed status, bit 1).	12
	Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-
21.37	Motor temperature estimation	<p>Selects the source of the motor temperature estimation on/off command.</p> <p>See section <a href="#">Motor temperature estimation (page 69)</a>.</p> <p><b>Note:</b> The motor temperature estimation function requires that</p> <ul style="list-style-type: none"> <li>• ID run is performed</li> <li>• ID run request is not active</li> <li>• a fault is not active, and</li> <li>• drive is in stopped state and ready to run.</li> </ul> <hr/> <p> <b>WARNING!</b> The drive starts modulation when the above conditions are fulfilled and the selection is active. Take extra care when rebooting the drive.</p>	Inactive (false) / uint32
	Inactive (false)	0	0
	Active (true)	1	1
	DI1	Digital input DI1 (10.2 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.2 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.2 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.2 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.2 DI delayed status, bit 4).	6

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	DI6	Digital input DI6 ( <a href="#">10.2 DI delayed status</a> , bit 5).	7
	Supervision 1	Supervision 1 active ( <a href="#">32.1 Supervision status</a> , bit 0).	8
	Supervision 2	Supervision 2 active ( <a href="#">32.1 Supervision status</a> , bit 1).	9
	Supervision 3	Supervision 3 active ( <a href="#">32.1 Supervision status</a> , bit 2).	10
	Drive start command	Motor temperature estimation is performed always with drive start command.	11
	Drive power-up	Motor temperature estimation is performed once after drive power-up (control board boot).	12
21.38	Motor temperature estimation time	Defines the motor temperature estimation time. Motor temperature estimation is activated with parameter <a href="#">21.37 Motor temperature estimation</a> .	4.0 s / real32
	0.5 ... 20.0 s	Motor temperature estimation time in seconds.	10 = 1 s / 10 = 1 s

278 Parameters


No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
22	Speed reference selection	Speed reference selection; motor potentiometer settings. See the control chain diagrams on pages 668...670.	
22.1	Speed ref unlimited	Displays the output of the speed reference selection block. See the control chain diagram on page 669. This parameter is read-only.	- / real32
	-30000.00 ... 30000.00 rpm	Value of the selected speed reference. For 16-bit scaling, see parameter 46.1.	- / 100 = 1 rpm
22.11	Speed ref1 source	<p>Selects speed reference source 1.</p> <p>Two signal sources can be defined by this parameter and 22.12 Speed ref2 source. A digital source selected by 22.14 Speed ref1/2 selection can be used to switch between the two sources, or a mathematical function (22.13 Speed ref1 function) applied to the two signals to create the reference.</p> 	All1 scaled / uint32
	Zero	None.	0
	All1 scaled	12.12 All1 scaled value (page 201).	1
	All2 scaled	12.22 All2 scaled value (page 203).	2
	FB A ref1	3.5 FB A reference 1 (page 144).	4
	FB A ref2	3.6 FB A reference 2 (page 144).	5
	EFB ref1	3.9 EFB reference 1 (page 144).	8
	EFB ref2	3.10 EFB reference 2 (page 144).	9
	DDCS ctrl ref1	3.11 DDCS controller ref 1 (page 144).	10
	DDCS ctrl ref2	3.12 DDCS controller ref 2 (page 145).	11
	M/F reference 1	3.13 M/F or D2D ref1 (page 145).	12
	M/F reference 2	3.14 M/F or D2D ref2 (page 145).	13
	Motor potentiometer	22.80 Motor potentiometer ref act (output of the motor potentiometer).	15
	PID	40.1 Process PID output actual (output of the process PID controller).	16
	Control panel (ref saved)	Control panel reference, with initial value from last-used panel reference. See section Using the control panel as an external control source (page 25).	18

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	Control panel (ref copied)	Control panel reference, with initial value from previous source or actual value. See section <a href="#">Using the control panel as an external control source (page 25)</a> .	19
	Other [bit]	Source selection (see <a href="#">Terms and abbreviations (page 134)</a> ).	-
22.12	Speed ref2 source	Selects speed reference source 2.  For the selections, and a diagram of reference source selection, see parameter <a href="#">22.11 Speed ref1 source</a> .	Zero / uint32
22.13	Speed ref1 function	Selects a mathematical function between the reference sources selected by parameters <a href="#">22.11 Speed ref1 source</a> and <a href="#">22.12 Speed ref2 source</a> . See diagram at <a href="#">22.11 Speed ref1 source</a> .	Ref1 / uint16
	Ref1	Signal selected by <a href="#">22.11 Speed ref1 source</a> is used as speed reference 1 as such (no function applied).	0
	Add (ref1 + ref2)	The sum of the reference sources is used as speed reference 1.	1
	Sub (ref1 - ref2)	The subtraction ( <a href="#">[22.11 Speed ref1 source]</a> - <a href="#">[22.12 Speed ref2 source]</a> ) of the reference sources is used as speed reference 1.	2
	Mul (ref1 x ref2)	The multiplication of the reference sources is used as speed reference 1.	3
	Min (ref1, ref2)	The smaller of the reference sources is used as speed reference 1.	4
	Max (ref1, ref2)	The greater of the reference sources is used as speed reference 1.	5
22.14	Speed ref1/2 selection	Configures the selection between speed references 1 and 2.  See diagram at <a href="#">22.11 Speed ref1 source</a> .  0 = Speed reference 1 1 = Speed reference 2	Follow Ext1/Ext2 selection / uint32
	Speed reference 1	0.	0
	Speed reference 2	1.	1
	Follow Ext1/Ext2 selection	Speed reference 1 is used when external control location EXT1 is active. Speed reference 2 is used when external control location EXT2 is active.  See also parameter <a href="#">19.11 Ext1/Ext2 selection</a> .	2
	DI1	Digital input DI1 ( <a href="#">10.2 DI delayed status</a> , bit 0).	3
	DI2	Digital input DI2 ( <a href="#">10.2 DI delayed status</a> , bit 1).	4
	DI3	Digital input DI3 ( <a href="#">10.2 DI delayed status</a> , bit 2).	5
	DI4	Digital input DI4 ( <a href="#">10.2 DI delayed status</a> , bit 3).	6
	DI5	Digital input DI5 ( <a href="#">10.2 DI delayed status</a> , bit 4).	7
	DI6	Digital input DI6 ( <a href="#">10.2 DI delayed status</a> , bit 5).	8

## 280 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	DIO1	Digital input/output DIO1 (11.2 DIO delayed status, bit 0).	11
	DIO2	Digital input/output DIO2 (11.2 DIO delayed status, bit 1).	12
	Other [bit]	See <a href="#">Terms and abbreviations</a> (page 134).	-
22.15	Speed additive 1 source	<p>Defines a reference to be added to the speed reference after reference selection (see page 668).</p> <p>For the selections, see parameter 22.11 <a href="#">Speed ref1 source</a>.</p> <p><b>Note:</b> For safety reasons, the additive is not applied when any of the stop functions are active.</p>	Zero / uint32
22.16	Speed share	<p>Defines a scaling factor for the selected speed referencec (speed reference 1 or 2, multiplied by the defined value).</p> <p>Speed reference 1 or 2 is selected by parameter 22.14 <a href="#">Speed ref1/2 selection</a>.</p>	1.000 / real32
	-8.000 ... 8.000	Speed reference scaling factor.	1000 = 1 / 1000 = 1
22.17	Speed additive 2 source	<p>Defines a reference to be added to the speed reference after the speed share function (see page 668).</p> <p>For the selections, see parameter 22.11 <a href="#">Speed ref1 source</a>.</p> <p><b>Note:</b> For safety reasons, the additive is not applied when any of the stop functions are active.</p>	Zero / uint32
22.21	Constant speed function	Determines how constant speeds are selected, and whether the rotation direction signal is considered or not when applying a constant speed.	- / uint16
b0	Constant speed mode	<p>1 = Packed: 7 constant speeds are selectable using the three sources defined by parameters 22.22, 22.23 and 22.24.</p> <p>0 = Separate: Constant speeds 1, 2 and 3 are separately activated by the sources defined by parameters 22.22, 22.23 and 22.24 respectively.</p> <p>In case of conflict, the constant speed with the smaller number takes priority.</p>	



No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b																																				
b1	Direction enable	<p>1 = Start dir: To determine running direction for a constant speed, the sign of the constant speed setting (parameters <a href="#">22.26...</a><a href="#">22.32</a>) is multiplied by the direction signal (forward: +1, reverse: -1). This effectively allows the drive to have 14 (7 forward, 7 reverse) constant speeds if all values in <a href="#">22.26...</a><a href="#">22.32</a> are positive.</p> <p> <b>WARNING!</b> If the direction signal is reverse and the active constant speed is negative, the drive will run in the forward direction.</p> <p>0 = Accord Par: The running direction for the constant speed is determined by the sign of the constant speed setting (parameters <a href="#">22.26...</a><a href="#">22.32</a>).</p>																																					
b2...15	Reserved																																						
	0000h...FFFFh		1 = 1 / 1 = 1																																				
22.22	Constant speed sel1	<p>When bit 0 of parameter <a href="#">22.21 Constant speed function</a> is 0 (Separate), selects a source that activates constant speed 1.</p> <p>When bit 0 of parameter <a href="#">22.21 Constant speed function</a> is 1 (Packed), this parameter and parameters <a href="#">22.23 Constant speed sel2</a> and <a href="#">22.24 Constant speed sel3</a> select three sources whose states activate constant speeds as follows:</p> <table border="1" data-bbox="389 820 866 1359"> <thead> <tr> <th data-bbox="393 825 508 895">Source defined by par. <a href="#">22.22</a></th> <th data-bbox="511 825 627 895">Source defined by par. <a href="#">22.23</a></th> <th data-bbox="630 825 745 895">Source defined by par. <a href="#">22.24</a></th> <th data-bbox="749 825 864 895">Constant speed active</th> </tr> </thead> <tbody> <tr> <td data-bbox="393 900 508 927">0</td> <td data-bbox="511 900 627 927">0</td> <td data-bbox="630 900 745 927">0</td> <td data-bbox="749 900 864 927">None</td> </tr> <tr> <td data-bbox="393 932 508 959">1</td> <td data-bbox="511 932 627 959">0</td> <td data-bbox="630 932 745 959">0</td> <td data-bbox="749 932 864 959">Constant speed 1</td> </tr> <tr> <td data-bbox="393 963 508 991">0</td> <td data-bbox="511 963 627 991">1</td> <td data-bbox="630 963 745 991">0</td> <td data-bbox="749 963 864 991">Constant speed 2</td> </tr> <tr> <td data-bbox="393 995 508 1023">1</td> <td data-bbox="511 995 627 1023">1</td> <td data-bbox="630 995 745 1023">0</td> <td data-bbox="749 995 864 1023">Constant speed 3</td> </tr> <tr> <td data-bbox="393 1027 508 1054">0</td> <td data-bbox="511 1027 627 1054">0</td> <td data-bbox="630 1027 745 1054">1</td> <td data-bbox="749 1027 864 1054">Constant speed 4</td> </tr> <tr> <td data-bbox="393 1059 508 1086">1</td> <td data-bbox="511 1059 627 1086">0</td> <td data-bbox="630 1059 745 1086">1</td> <td data-bbox="749 1059 864 1086">Constant speed 5</td> </tr> <tr> <td data-bbox="393 1091 508 1118">0</td> <td data-bbox="511 1091 627 1118">1</td> <td data-bbox="630 1091 745 1118">1</td> <td data-bbox="749 1091 864 1118">Constant speed 6</td> </tr> <tr> <td data-bbox="393 1123 508 1150">1</td> <td data-bbox="511 1123 627 1150">1</td> <td data-bbox="630 1123 745 1150">1</td> <td data-bbox="749 1123 864 1150">Constant speed 7</td> </tr> </tbody> </table>	Source defined by par. <a href="#">22.22</a>	Source defined by par. <a href="#">22.23</a>	Source defined by par. <a href="#">22.24</a>	Constant speed active	0	0	0	None	1	0	0	Constant speed 1	0	1	0	Constant speed 2	1	1	0	Constant speed 3	0	0	1	Constant speed 4	1	0	1	Constant speed 5	0	1	1	Constant speed 6	1	1	1	Constant speed 7	D15 / uint32
Source defined by par. <a href="#">22.22</a>	Source defined by par. <a href="#">22.23</a>	Source defined by par. <a href="#">22.24</a>	Constant speed active																																				
0	0	0	None																																				
1	0	0	Constant speed 1																																				
0	1	0	Constant speed 2																																				
1	1	0	Constant speed 3																																				
0	0	1	Constant speed 4																																				
1	0	1	Constant speed 5																																				
0	1	1	Constant speed 6																																				
1	1	1	Constant speed 7																																				
	Not selected	0	0																																				
	Selected	1	1																																				
	DI1	Digital input DI1 ( <a href="#">10.2 DI delayed status</a> , bit 0).	2																																				

## 282 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	DI2	Digital input DI2 (10.2 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.2 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.2 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.2 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.2 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1 (11.2 DIO delayed status, bit 0).	10
	DIO2	Digital input/output DIO2 (11.2 DIO delayed status, bit 1).	11
	Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-
22.23	Constant speed sel2	<p>When bit 0 of parameter <a href="#">22.21 Constant speed function</a> is 0 (Separate), selects a source that activates constant speed 2.</p> <p>When bit 0 of parameter <a href="#">22.21 Constant speed function</a> is 1 (Packed), this parameter and parameters <a href="#">22.22 Constant speed sel1</a> and <a href="#">22.24 Constant speed sel3</a> select three sources that are used to activate constant speeds. See table at parameter <a href="#">22.22 Constant speed sel1</a>.</p> <p>For the selections, see parameter <a href="#">22.22 Constant speed sel1</a>.</p>	Not selected / uint32
22.24	Constant speed sel3	<p>When bit 0 of parameter <a href="#">22.21 Constant speed function</a> is 0 (Separate), selects a source that activates constant speed 3.</p> <p>When bit 0 of parameter <a href="#">22.21 Constant speed function</a> is 1 (Packed), this parameter and parameters <a href="#">22.22 Constant speed sel1</a> and <a href="#">22.23 Constant speed sel2</a> select three sources that are used to activate constant speeds. See table at parameter <a href="#">22.22 Constant speed sel1</a>.</p> <p>For the selections, see parameter <a href="#">22.22 Constant speed sel1</a>.</p>	Not selected / uint32
22.26	Constant speed 1	Defines constant speed 1 (the speed the motor will turn when constant speed 1 is selected).	300.00 rpm / real32
	-30000.00 ... 30000.00 rpm	Constant speed 1. For 16-bit scaling, see parameter <a href="#">46.1</a> .	- / 100 = 1 rpm
22.27	Constant speed 2	Defines constant speed 2.	0.00 rpm / real32
	-30000.00 ... 30000.00 rpm	Constant speed 2. For 16-bit scaling, see parameter <a href="#">46.1</a> .	- / 100 = 1 rpm
22.28	Constant speed 3	Defines constant speed 3.	0.00 rpm / real32
	-30000.00 ... 30000.00 rpm	Constant speed 3. For 16-bit scaling, see parameter <a href="#">46.1</a> .	- / 100 = 1 rpm
22.29	Constant speed 4	Defines constant speed 4.	0.00 rpm / real32
	-30000.00 ... 30000.00 rpm	Constant speed 4. For 16-bit scaling, see parameter <a href="#">46.1</a> .	- / 100 = 1 rpm

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
22.30	Constant speed 5	Defines constant speed 5.	0.00 rpm / real32
	-30000.00 ... 30000.00 rpm	Constant speed 5. For 16-bit scaling, see parameter <a href="#">46.1</a> .	- / 100 = 1 rpm
22.31	Constant speed 6	Defines constant speed 6.	0.00 rpm / real32
	-30000.00 ... 30000.00 rpm	Constant speed 6. For 16-bit scaling, see parameter <a href="#">46.1</a> .	- / 100 = 1 rpm
22.32	Constant speed 7	Defines constant speed 7.	0.00 rpm / real32
	-30000.00 ... 30000.00 rpm	Constant speed 7. For 16-bit scaling, see parameter <a href="#">46.1</a> .	- / 100 = 1 rpm
22.41	Speed ref safe	Defines a safe speed reference value that is used with supervision functions such as <ul style="list-style-type: none"> <li>• <a href="#">12.3 AI supervision function</a></li> <li>• <a href="#">49.5 Communication loss action</a></li> <li>• <a href="#">50.2 FBA A comm loss func</a></li> <li>• <a href="#">50.32 FBA B comm loss func</a></li> <li>• <a href="#">58.14 Communication loss action</a>.</li> </ul>	- / real32
	-30000.00 ... 30000.00 rpm	Safe speed reference. For 16-bit scaling, see parameter <a href="#">46.1</a> .	- / 100 = 1 rpm
22.42	Jogging 1 ref	Defines the speed reference for jogging function 1. For more information on jogging, see <a href="#">page 60</a> .	0.00 rpm / real32
	-30000.00 ... 30000.00 rpm	Speed reference for jogging function 1. For 16-bit scaling, see parameter <a href="#">46.1</a> .	- / 100 = 1 rpm
22.43	Jogging 2 ref	Defines the speed reference for jogging function 2. For more information on jogging, see <a href="#">page 60</a> .	0.00 rpm / real32
	-30000.00 ... 30000.00 rpm	Speed reference for jogging function 2. For 16-bit scaling, see parameter <a href="#">46.1</a> .	- / 100 = 1 rpm
22.51	Critical speed function	Enables/disables the critical speeds function. Also determines whether the specified ranges are effective in both rotating directions or not. See also section <a href="#">Critical speeds/frequencies (page 47)</a> .	- / uint16
	b0 Enable	1 = Enable: Critical speeds enabled. 0 = Disable: Critical speeds disabled.	
	b1 Sign mode	1 = Signed: The signs of parameters <a href="#">22.52...22.57</a> are taken into account. 0 = Absolute: Parameters <a href="#">22.52...22.57</a> are handled as absolute values. Each range is effective in both directions of rotation.	
	b2...15 Reserved		
	0000h...FFFFh		1 = 1 / 1 = 1
22.52	Critical speed 1 low	Defines the low limit for critical speed range 1.  <b>Note:</b> This value must be less than or equal to the value of <a href="#">22.53 Critical speed 1 high</a> .	0.00 rpm / real32

## 284 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	-30000.00 ... 30000.00 rpm	Low limit for critical speed 1. For 16-bit scaling, see parameter <a href="#">46.1</a> .	- / 100 = 1 rpm
22.53	Critical speed 1 high	Defines the high limit for critical speed range 1.  <b>Note:</b> This value must be greater than or equal to the value of <a href="#">22.52 Critical speed 1 low</a> .	0.00 rpm / real32
	-30000.00 ... 30000.00 rpm	High limit for critical speed 1. For 16-bit scaling, see parameter <a href="#">46.1</a> .	- / 100 = 1 rpm
22.54	Critical speed 2 low	Defines the low limit for critical speed range 2.  <b>Note:</b> This value must be less than or equal to the value of <a href="#">22.55 Critical speed 2 high</a> .	0.00 rpm / real32
	-30000.00 ... 30000.00 rpm	Low limit for critical speed 2. For 16-bit scaling, see parameter <a href="#">46.1</a> .	- / 100 = 1 rpm
22.55	Critical speed 2 high	Defines the high limit for critical speed range 2.  <b>Note:</b> This value must be greater than or equal to the value of <a href="#">22.54 Critical speed 2 low</a> .	0.00 rpm / real32
	-30000.00 ... 30000.00 rpm	High limit for critical speed 2. For 16-bit scaling, see parameter <a href="#">46.1</a> .	- / 100 = 1 rpm
22.56	Critical speed 3 low	Defines the low limit for critical speed range 3.  <b>Note:</b> This value must be less than or equal to the value of <a href="#">22.57 Critical speed 3 high</a> .	0.00 rpm / real32
	-30000.00 ... 30000.00 rpm	Low limit for critical speed 3. For 16-bit scaling, see parameter <a href="#">46.1</a> .	- / 100 = 1 rpm
22.57	Critical speed 3 high	Defines the high limit for critical speed range 3.  <b>Note:</b> This value must be greater than or equal to the value of <a href="#">22.56 Critical speed 3 low</a> .	0.00 rpm / real32
	-30000.00 ... 30000.00 rpm	High limit for critical speed 3. For 16-bit scaling, see parameter <a href="#">46.1</a> .	- / 100 = 1 rpm
22.71	Motor potentiometer function	Activates and selects the mode of the motor potentiometer.  See section <a href="#">Motor potentiometer (page 73)</a> .	Disabled / uint16
	Disabled	Motor potentiometer is disabled and its value set to 0.	0
	Enabled (init at stop/power-up)	When enabled, the motor potentiometer first adopts the value defined by parameter <a href="#">22.72 Motor potentiometer initial value</a> .  When the drive is running, the value can be adjusted from the up and down sources defined by parameters <a href="#">22.73 Motor potentiometer up source</a> and <a href="#">22.74 Motor potentiometer down source</a> .  A stop or a power cycle will reset the motor potentiometer to the initial value ( <a href="#">22.72</a> ).	1

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	Enabled (resume always)	As <a href="#">Enabled (init at stop/power-up)</a> , but the motor potentiometer value is retained over a stop or a power cycle.	2
22.72	Motor potentiometer initial value	Defines an initial value (starting point) for the motor potentiometer. See the selections of parameter <a href="#">22.71 Motor potentiometer function</a> .	0.00 / real32
	-32768.00 ... 32767.00	Initial value for motor potentiometer.	1 = 1 / 100 = 1
22.73	Motor potentiometer up source	Selects the source of motor potentiometer up signal. 0 = No change 1 = Increase motor potentiometer value. (If both the up and down sources are on, the potentiometer value will not change.)	Not selected / uint32
	Not selected	0	0
	Selected	1	1
	DI1	Digital input DI1 ( <a href="#">10.2 DI delayed status</a> , bit 0).	2
	DI2	Digital input DI2 ( <a href="#">10.2 DI delayed status</a> , bit 1).	3
	DI3	Digital input DI3 ( <a href="#">10.2 DI delayed status</a> , bit 2).	4
	DI4	Digital input DI4 ( <a href="#">10.2 DI delayed status</a> , bit 3).	5
	DI5	Digital input DI5 ( <a href="#">10.2 DI delayed status</a> , bit 4).	6
	DI6	Digital input DI6 ( <a href="#">10.2 DI delayed status</a> , bit 5).	7
	DIO1	Digital input/output DIO1 ( <a href="#">11.2 DIO delayed status</a> , bit 0).	10
	DIO2	Digital input/output DIO2 ( <a href="#">11.2 DIO delayed status</a> , bit 1).	11
	Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-
22.74	Motor potentiometer down source	Selects the source of motor potentiometer down signal. 0 = No change 1 = Decrease motor potentiometer value. (If both the up and down sources are on, the potentiometer value will not change.) For the selections, see parameter <a href="#">22.73 Motor potentiometer up source</a> .	Not selected / uint32
22.75	Motor potentiometer ramp time	Defines the change rate of the motor potentiometer. This parameter specifies the time required for the motor potentiometer to change from minimum ( <a href="#">22.76</a> ) to maximum ( <a href="#">22.77</a> ). The same change rate applies in both directions.	60.0 s / real32
	0.0 ... 3600.0 s	Motor potentiometer change time.	10 = 1 s / 10 = 1 s
22.76	Motor potentiometer min value	Defines the minimum value of the motor potentiometer.	-1500.00 / real32
	-32768.00 ... 32767.00	Motor potentiometer minimum.	1 = 1 / 100 = 1

286 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
22.77	Motor potentiometer max value	Defines the maximum value of the motor potentiometer.	1500.00 / real32
	-32768.00 ... 32767.00	Motor potentiometer maximum.	1 = 1 / 100 = 1
22.80	Motor potentiometer ref act	Displays the output of the motor potentiometer function. (The motor potentiometer is configured using parameters 22.71...22.74.)  This parameter is read-only.	- / real32
	-32768.00 ... 32767.00	Value of motor potentiometer.	1 = 1 / 100 = 1
22.81	Speed reference act 1	Displays the value of speed reference source 1 (selected by parameter 22.11 Speed ref1 source). See the control chain diagram on page 668.  This parameter is read-only.	- / real32
	-30000.00 ... 30000.00 rpm	Value of reference source 1. For 16-bit scaling, see parameter 46.1.	- / 100 = 1 rpm
22.82	Speed reference act 2	Displays the value of speed reference source 2 (selected by parameter 22.12 Speed ref2 source). See the control chain diagram on page 668.  This parameter is read-only.	- / real32
	-30000.00 ... 30000.00 rpm	Value of reference source 2. For 16-bit scaling, see parameter 46.1.	- / 100 = 1 rpm
22.83	Speed reference act 3	Displays the value of speed reference after the mathematical function applied by parameter 22.13 Speed ref1 function and reference 1/2 selection (22.14 Speed ref1/2 selection). See the control chain diagram on page 668.  This parameter is read-only.	- / real32
	-30000.00 ... 30000.00 rpm	Speed reference after source selection. For 16-bit scaling, see parameter 46.1.	- / 100 = 1 rpm
22.84	Speed reference act 4	Displays the value of speed reference after application of 1st speed additive (22.15 Speed additive 1 source). See the control chain diagram on page 668.  This parameter is read-only.	- / real32
	-30000.00 ... 30000.00 rpm	Speed reference after additive 1. For 16-bit scaling, see parameter 46.1.	- / 100 = 1 rpm
22.85	Speed reference act 5	Displays the value of speed reference after the application of the speed share scaling factor (22.16 Speed share). See the control chain diagram on page 668.  This parameter is read-only.	- / real32
	-30000.00 ... 30000.00 rpm	Speed reference after speed share scaling. For 16-bit scaling, see parameter 46.1.	- / 100 = 1 rpm

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
22.86	Speed reference act 6	Displays the value of speed reference after application of 2nd speed additive (22.17 Speed additive 2 source). See the control chain diagram on page 668.  This parameter is read-only.	- / real32
	-30000.00 ... 30000.00 rpm	Speed reference after additive 2. For 16-bit scaling, see parameter 46.1.	- / 100 = 1 rpm
22.87	Speed reference act 7	Displays the value of speed reference before application of critical speeds. See the control chain diagram on page 669.  The value is received from 22.86 Speed reference act 6 unless overridden by <ul style="list-style-type: none"> <li>• any constant speed</li> <li>• a jogging reference</li> <li>• network control reference (see Terms and abbreviations (page 18))</li> <li>• control panel reference</li> <li>• safe speed reference.</li> </ul> This parameter is read-only.	- / real32
	-30000.00 ... 30000.00 rpm	Speed reference before application of critical speeds. For 16-bit scaling, see parameter 46.1.	- / 100 = 1 rpm



## 288 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
<b>23</b>	Speed reference ramp	Speed reference ramp settings (programming of the acceleration and deceleration rates for the drive). See the control chain diagram on page 670.	
23.1	Speed ref ramp input	Displays the used speed reference (in rpm) before it enters the ramping and shaping functions. See the control chain diagram on page 670.  This parameter is read-only.	- / real32
	-30000.00 ... 30000.00 rpm	Speed reference before ramping and shaping. For 16-bit scaling, see parameter 46.1.	- / 100 = 1 rpm
23.2	Speed ref ramp output	Displays the ramped and shaped speed reference in rpm. See the control chain diagram on page 670.  This parameter is read-only.	- / real32
	-30000.00 ... 30000.00 rpm	Speed reference after ramping and shaping. For 16-bit scaling, see parameter 46.1.	- / 100 = 1 rpm
23.11	Ramp set selection	Selects the source that switches between the two sets of acceleration/deceleration ramp times defined by parameters 23.12...23.15.  0 = Acceleration time 1 and deceleration time 1 are active 1 = Acceleration time 2 and deceleration time 2 are active	DI4; Acc/Dec time 2 (95.20 b1) / uint32
	Acc/Dec time 1	0.	0
	Acc/Dec time 2	1.	1
	DI1	Digital input DI1 (10.2 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.2 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.2 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.2 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.2 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.2 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1 (11.2 DIO delayed status, bit 0).	10
	DIO2	Digital input/output DIO2 (11.2 DIO delayed status, bit 1).	11
	Other [bit]	See <a href="#">Terms and abbreviations</a> (page 134).	-



No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
23.12	Acceleration time 1	<p>Defines acceleration time 1 as the time required for the speed to change from zero to the speed defined by parameter <a href="#">46.1 Speed scaling</a> (not to parameter <a href="#">30.12 Maximum speed</a>).</p> <p>If the speed reference increases faster than the set acceleration rate, the motor speed will follow the acceleration rate.</p> <p>If the speed reference increases slower than the set acceleration rate, the motor speed will follow the reference.</p> <p>If the acceleration time is set too short, the drive will automatically prolong the acceleration in order not to exceed the drive torque limits.</p>	20.000 s / real32
	0.000 ... 1800.000 s	Acceleration time 1.	10 = 1 s / 1000 = 1 s
23.13	Deceleration time 1	<p>Defines deceleration time 1 as the time required for the speed to change from the speed defined by parameter <a href="#">46.1 Speed scaling</a> (<b>not</b> from parameter <a href="#">30.12 Maximum speed</a>) to zero.</p> <p>If the speed reference decreases slower than the set deceleration rate, the motor speed will follow the reference.</p> <p>If the reference changes faster than the set deceleration rate, the motor speed will follow the deceleration rate.</p> <p>If the deceleration rate is set too short, the drive will automatically prolong the deceleration in order not to exceed drive torque limits (or not to exceed a safe DC link voltage). If there is any doubt about the deceleration time being too short, ensure that DC overvoltage control is on (parameter <a href="#">30.30 Overvoltage control</a>).</p> <p><b>Note:</b> If a short deceleration time is needed for a high inertia application, the drive should be equipped with braking equipment such as a brake chopper and brake resistor.</p>	20.000 s / real32
	0.000 ... 1800.000 s	Deceleration time 1.	10 = 1 s / 1000 = 1 s
23.14	Acceleration time 2	Defines acceleration time 2. See parameter <a href="#">23.12 Acceleration time 1</a> .	60.000 s / real32
	0.000 ... 1800.000 s	Acceleration time 2.	10 = 1 s / 1000 = 1 s
23.15	Deceleration time 2	Defines deceleration time 2. See parameter <a href="#">23.13 Deceleration time 1</a> .	60.000 s / real32
	0.000 ... 1800.000 s	Deceleration time 2.	10 = 1 s / 1000 = 1 s


290 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
23.16	Shape time acc 1	<p>Defines the shape of the acceleration ramp at the beginning of the acceleration.</p> <p>0.000 s: Linear ramp. Suitable for steady acceleration or deceleration and for slow ramps.</p> <p>0.001...1000.000 s: S-curve ramp. S-curve ramps are ideal for lifting applications. The S-curve consists of symmetrical curves at both ends of the ramp and a linear part in between.</p> <p><b>Note:</b> For safety reasons, shape times are not applied to emergency stop ramps.</p> <p><b>Note:</b> Ramp shape times may not always be obeyed if changed during ramping and reference would overshoot.</p> <p><b>Acceleration:</b></p>  <p><b>Deceleration:</b></p> 	- / real32
	0.000 ... 1800.000 s	Ramp shape at start of acceleration.	10 = 1 s / 1000 = 1 s
23.17	Shape time acc 2	Defines the shape of the acceleration ramp at the end of the acceleration. See parameter <a href="#">23.16 Shape time acc 1</a> .	0.000 s / real32
	0.000 ... 1800.000 s	Ramp shape at end of acceleration.	10 = 1 s / 1000 = 1 s

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
23.18	Shape time dec 1	Defines the shape of the deceleration ramp at the beginning of the deceleration. See parameter <a href="#">23.16 Shape time acc 1</a> .	0.000 s / real32
	0.000 ... 1800.000 s	Ramp shape at start of deceleration.	10 = 1 s / 1000 = 1 s
23.19	Shape time dec 2	Defines the shape of the deceleration ramp at the end of the deceleration. See parameter <a href="#">23.16 Shape time acc 1</a> .	0.000 s / real32
	0.000 ... 1800.000 s	Ramp shape at end of deceleration.	10 = 1 s / 1000 = 1 s
23.20	Acc time jogging	Defines the acceleration time for the jogging function i.e. the time required for the speed to change from zero to the speed value defined by parameter <a href="#">46.1 Speed scaling</a> . See section <a href="#">Jogging (page 60)</a> .	60.000 s / real32
	0.000 ... 1800.000 s	Acceleration time for jogging.	10 = 1 s / 1000 = 1 s
23.21	Dec time jogging	Defines the deceleration time for the jogging function i.e. the time required for the speed to change from the speed value defined by parameter <a href="#">46.1 Speed scaling</a> to zero. See section <a href="#">Jogging (page 60)</a> .	60.000 s / real32
	0.000 ... 1800.000 s	Deceleration time for jogging.	10 = 1 s / 1000 = 1 s
23.23	Emergency stop time	In speed control mode, this parameter defines the deceleration rate for emergency stop Off3 as the time it would take for the speed to decrease from the value of parameter <a href="#">46.1 Speed scaling</a> . This also applies to torque control because the drive switches to speed control on receiving an emergency stop Off3 command.  In frequency control mode, this parameter specifies the time it would take for the frequency to decrease from the value of <a href="#">46.2 Frequency scaling</a> to zero.  The emergency stop mode and activation source are selected by parameters <a href="#">21.4 Emergency stop mode</a> and <a href="#">21.5 Emergency stop source</a> respectively. Emergency stop can also be activated through fieldbus.  <b>Note:</b> Emergency stop Off1 uses the standard deceleration ramp as defined by parameters <a href="#">23.11...23.19</a> or <a href="#">28.71...28.75</a> (frequency control).	3.000 s / real32
	0.000 ... 1800.000 s	Emergency stop Off3 deceleration time.	10 = 1 s / 1000 = 1 s
23.24	Speed ramp in zero source	Selects a source that forces the speed reference to zero just before it enters the ramp function.  0 = Force speed reference to zero before the ramp function  1 = Speed reference continues towards the ramp function as normal	Inactive / uint32
	Active	0.	0
	Inactive	1.	1


292 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	DI1	Digital input DI1 (10.2 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.2 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.2 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.2 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.2 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.2 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1 (11.2 DIO delayed status, bit 0).	10
	DIO2	Digital input/output DIO2 (11.2 DIO delayed status, bit 1).	11
	Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-
23.26	Ramp out balancing enable	<p>Selects the source for enabling/disabling speed reference ramp balancing.</p> <p>This function is used to generate a smooth transfer from a torque- or tension-controlled motor back to being speed-controlled. The balancing output would be tracking the present “line” speed of the application and when transfer is required, the speed reference can then be quickly “seeded” to the correct line speed.</p> <p>Balancing is also possible in the speed controller, see parameter 25.9 Speed ctrl balancing enable.</p> <p>See also parameter 23.27 Ramp out balancing ref.</p> <p>0 = Disabled 1 = Enabled</p>	Not selected / uint32
	Not selected	0	0
	Selected	1	1
	DI1	Digital input DI1 (10.2 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.2 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.2 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.2 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.2 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.2 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1 (11.2 DIO delayed status, bit 0).	10
	DIO2	Digital input/output DIO2 (11.2 DIO delayed status, bit 1).	11
	Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-
23.27	Ramp out balancing ref	<p>Defines the reference for speed ramp balancing. The output of the ramp generator is forced to this value when balancing is enabled by parameter 23.26 Ramp out balancing enable.</p>	- / real32


No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	-30000.00 ... 30000.00 rpm	Speed ramp balancing reference. For 16-bit scaling, see parameter 46.1.	- / 100 = 1 rpm
23.28	Variable slope enable	<p>Activates the variable slope function, which controls the slope of the speed ramp during a speed reference change. This allows for a constantly variable ramp rate to be generated, instead of just the standard two ramps normally available.</p> <p>If the update interval of the signal from an external control system and the variable slope rate (23.29 Variable slope rate) are equal, the resulting speed reference (23.2 Speed ref ramp output) is a straight line.</p>  <p>t = update interval of signal from external control system A = speed reference change during t</p> <p>This function is only active in remote control.</p>	Off / uint32
	Off	Variable slope disabled.	0
	On	Variable slope enabled (not available in local control).	1
	Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-
23.29	Variable slope rate	<p>Defines the rate of the speed reference change when variable slope is enabled by parameter 23.28 Variable slope enable.</p> <p>For the best result, enter the reference update interval into this parameter.</p>	50 ms / real32
	2...30000 ms	Variable slope rate.	1 = 1 ms / 1 = 1 ms
23.39	Follower speed correction out	<p>Displays the speed correction term for the load share function with a speed-controlled follower drive.</p> <p>See section <a href="#">Load share function with a speed-controlled follower (page 36)</a>.</p> <p>This parameter is read-only.</p>	- / real32
	-30000.00 ... 30000.00 rpm	Speed correction term. For 16-bit scaling, see parameter 46.1.	- / 100 = 1 rpm

## 294 Parameters



No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
23.40	Follower speed correction enable	With a speed-controlled follower, selects the source for enabling/disabling the load share function.  See section <a href="#">Load share function with a speed-controlled follower (page 36)</a> .  0 = Disabled 1 = Enabled	Not selected / uint32
	Not selected	0	0
	Selected	1	1
	DI1	Digital input DI1 ( <a href="#">10.2 DI delayed status</a> , bit 0).	2
	DI2	Digital input DI2 ( <a href="#">10.2 DI delayed status</a> , bit 1).	3
	DI3	Digital input DI3 ( <a href="#">10.2 DI delayed status</a> , bit 2).	4
	DI4	Digital input DI4 ( <a href="#">10.2 DI delayed status</a> , bit 3).	5
	DI5	Digital input DI5 ( <a href="#">10.2 DI delayed status</a> , bit 4).	6
	DI6	Digital input DI6 ( <a href="#">10.2 DI delayed status</a> , bit 5).	7
	DIO1	Digital input/output DIO1 ( <a href="#">11.2 DIO delayed status</a> , bit 0).	10
	DIO2	Digital input/output DIO2 ( <a href="#">11.2 DIO delayed status</a> , bit 1).	11
	Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-
23.41	Follower speed correction gain	Adjusts the gain of the speed correction term in a speed-controlled follower. In effect, defines how accurately the follower follows the master torque. A greater value results in a more accurate performance.  See section <a href="#">Load share function with a speed-controlled follower (page 36)</a> .	1.00 % / real32
	0.00 ... 100.00 %	Speed correction term adjustment.	1 = 1 % / 100 = 1 %
23.42	Follower speed correction source	Selects the source of the torque reference for the load share function.  See section <a href="#">Load share function with a speed-controlled follower (page 36)</a> .	MF ref 2 / uint32
	NULL	None.	0
	MF ref 2	<a href="#">3.14 M/F or D2D ref2 (page 145)</a> .	1
	Other [bit]	Source selection (see <a href="#">Terms and abbreviations (page 134)</a> ).	-

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
<b>24</b>	Speed reference conditioning	Speed error calculation; speed error window control configuration; speed error step. See the control chain diagrams on pages 673 and 674.	
24.1	Used speed reference	Displays the ramped and corrected speed reference (before speed error calculation). See the control chain diagram on page 673. This parameter is read-only.	- / real32
	-30000.00 ... 30000.00 rpm	Speed reference used for speed error calculation. For 16-bit scaling, see parameter 46.1.	- / 100 = 1 rpm
24.2	Used speed feedback	Displays the speed feedback used for speed error calculation. See the control chain diagram on page 673. This parameter is read-only.	- / real32
	-30000.00 ... 30000.00 rpm	Speed feedback used for speed error calculation. For 16-bit scaling, see parameter 46.1.	- / 100 = 1 rpm
24.3	Speed error filtered	Displays the filtered speed error. See the control chain diagram on page 673. This parameter is read-only.	0.00 rpm / real32
	-30000.00 ... 30000.00 rpm	Filtered speed error. For 16-bit scaling, see parameter 46.1.	- / 100 = 1 rpm
24.4	Speed error inverted	Displays the inverted (unfiltered) speed error. See the control chain diagram on page 673. This parameter is read-only	0.00 rpm / real32
	-30000.00 ... 30000.00 rpm	Inverted speed error. For 16-bit scaling, see parameter 46.1.	- / 100 = 1 rpm
24.11	Speed correction	Defines a speed reference correction, ie. a value added to the existing reference between ramping and limitation. This is useful to trim the speed if necessary, for example to adjust draw between sections of a paper machine.  <b>Note:</b> For safety reasons, the correction is not applied when an emergency stop is active.   <b>WARNING!</b> If the speed reference correction exceeds 21.6 Zero speed limit, a ramp stop may be impossible. Make sure the correction is reduced or removed when a ramp stop is required.  See the control chain diagram on page 673.	0.00 rpm / real32
	-10000.00 ... 10000.00 rpm	Speed reference correction. For 16-bit scaling, see parameter 46.1.	- / 100 = 1 rpm


296 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
24.12	Speed error filter time	<p>Defines the time constant of the speed error low-pass filter.</p> <p>If the used speed reference changes rapidly, the possible interferences in the speed measurement can be filtered with the speed error filter. Reducing the ripple with this filter may cause speed controller tuning problems. A long filter time constant and fast acceleration time contradict one another. A very long filter time results in unstable control.</p>	0 ms / real32
	0...10000 ms	Speed error filtering time constant. 0 = filtering disabled.	1 = 1 ms / 1 = 1 ms
24.13	RFE speed filter	<p>Enables/disables resonance frequency filtering. The filtering is configured by parameters 24.13...24.17.</p> <p>The speed error value coming to the speed controller is filtered by a common 2nd order band-elimination filter to eliminate the amplification of mechanical resonance frequencies.</p> <p><b>Note:</b> Tuning the resonance frequency filter requires a basic understanding of frequency filters. Incorrect tuning can amplify mechanical oscillations and damage the drive hardware. To ensure the stability of the speed controller, stop the drive or disable the filtering before changing the parameter settings.</p> <p>0 = Resonance frequency filtering disabled. 1 = Resonance frequency filtering enabled.</p>	Off / uint16
	On	1.	1
	Off	0.	0
24.14	Frequency of zero	<p>Defines the zero frequency of the resonance frequency filter.</p> <p>The value must be set near the resonance frequency, which is filtered out before the speed controller.</p> <p>The drawing shows the frequency response.</p> 	45.00 Hz / real32
	0.50 ... 500.00 Hz	Zero frequency.	1 = 1 Hz / 100 = 1 Hz





No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
24.15	Damping of zero	<p>Defines the damping coefficient for parameter 24.14. The value of 0 corresponds to the maximum elimination of the resonance frequency.</p> <p><math>20\log_{10} H(\omega) </math></p>  <p><b>Note:</b> To ensure that the resonance frequency band is filtered (rather than amplified), the value of 24.15 must be smaller than 24.17.</p>	0.000 / real32
	-1.000 ... 1.000	Damping coefficient.	100 = 1 / 1000 = 1
24.16	Frequency of pole	<p>Defines the frequency of pole of the resonance frequency filter.</p> <p><math>20\log_{10} H(\omega) </math></p>  <p><b>Note:</b> If this value is very different from the value of 24.14, the frequencies near the frequency of pole are amplified, which can damage the driven machine.</p>	40.00 Hz / real32
	0.50 ... 500.00 Hz	Frequency of pole.	1 = 1 Hz / 100 = 1 Hz

298 Parameters


No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
24.17	Damping of pole	<p>Defines the damping coefficient for parameter 24.16. The coefficient shapes the frequency response of the resonance frequency filter. A narrower bandwidth results in better dynamic properties. By setting this parameter to 1, the effect of the pole is eliminated.</p> <p><math>20\log_{10} H(\omega) </math></p>  <p><b>Note:</b> To ensure that the resonance frequency band is filtered (rather than amplified), the value of 24.15 must be smaller than 24.17.</p>	0.250 / real32
	-1.000 ... 1.000	Damping coefficient.	100 = 1 / 1000 = 1


No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
24.41	Speed error window control enable	<p>Enables/disables (or selects a source that enables/disables) speed error window control, sometimes also referred to as deadband control or strip break protection. It forms a speed supervision function for a torque-controlled drive, preventing the motor from running away if the material that is being held under tension breaks.</p> <p><b>Note:</b> Speed error window control is only effective when the <a href="#">Add</a> operating mode is active (see parameters <a href="#">19.12</a> and <a href="#">19.14</a>), or when the drive is a speed-controlled follower (see page <a href="#">36</a>).</p> <p>In normal operation, window control keeps the speed controller input at zero so the drive stays in torque control.</p> <p>If the motor load is lost, then the motor speed will rise as the torque controller tries to maintain torque. The speed error (speed reference - actual speed) will increase until it exits the speed error window. When this is detected, the exceeding part of the error value is connected to the speed controller. The speed controller produces a reference term relative to the input and gain (<a href="#">25.2 Speed proportional gain</a>) which the torque selector adds to the torque reference. The result is used as the internal torque reference for the drive.</p> <p>The activation of speed error window control is indicated by bit 3 of <a href="#">6.19 Speed control status word</a>.</p>	Disable / uint32

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
		<p>The window boundaries are defined by <a href="#">24.43 Speed error window high</a> and <a href="#">24.44 Speed error window low</a> as follows:</p>  <p>Note that it is parameter <a href="#">24.44</a> (rather than <a href="#">24.43</a>) that defines the overspeed limit in both directions of rotation. This is because the function monitors speed error (which is negative in case of overspeed, positive in case of underspeed).</p> <p><b>⚠ WARNING!</b> In a speed-controlled follower, the speed error window must not exceed <a href="#">21.6 Zero speed limit</a> for a reliable ramp stop. Make sure both <a href="#">24.43</a> and <a href="#">24.44</a> are smaller than <a href="#">21.6</a> (or speed error window control disabled) when a ramp stop is required.</p> <p>0 = Speed error window control disabled 1 = Speed error window control enabled</p>	
	Disable	0.	0
	Enable	1.	1
	Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-
24.42	Speed window control mode	When speed error window control (see parameter <a href="#">24.41 Speed error window control enable</a> ) is enabled, this parameter determines whether the speed controller only observes the proportional term instead of all three (P, I and D) terms.	Normal speed control / uint16
	Normal speed control	All three terms (parameters <a href="#">25.2</a> , <a href="#">25.3</a> and <a href="#">25.4</a> ) are observed by the speed controller.	0


No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	P-control	Only the proportional term (25.2) is observed by the speed controller. The integral and derivative terms are internally forced to zero.	1
24.43	Speed error window high	Defines the upper boundary of the speed error window. See parameter 24.41 <a href="#">Speed error window control enable</a> .	0.00 rpm / real32
	0.00 ... 3000.00 rpm	Upper boundary of speed error window. For 16-bit scaling, see parameter 46.1.	- / 100 = 1 rpm
24.44	Speed error window low	Defines the lower boundary of the speed error window. See parameter 24.41 <a href="#">Speed error window control enable</a> .	0.00 rpm / real32
	0.00 ... 3000.00 rpm	Lower boundary of speed error window. For 16-bit scaling, see parameter 46.1.	- / 100 = 1 rpm
24.46	Speed error step	<p>Defines an additional speed error step given to the input of the speed controller (and added to the speed error value). This can be used in large drive systems for dynamic speed normalizing.</p> <p> <b>WARNING!</b> Make sure the error step value is removed when a stop command is given.</p>	0.00 rpm / real32
	-3000.00 ... 3000.00 rpm	Speed error step. For 16-bit scaling, see parameter 46.1.	- / 100 = 1 rpm

## 302 Parameters



No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
25	Speed control	Speed controller settings. See the control chain diagrams on pages 673 and 674.	
25.1	Torque reference speed control	Displays the speed controller output that is transferred to the torque controller. See the control chain diagram on page 674. This parameter is read-only.	- / real32
	-1600.0 ... 1600.0 %	Limited speed controller output torque. For 16-bit scaling, see parameter 46.3.	- / 10 = 1 %
25.2	Speed proportional gain	<p>Defines the proportional gain (<math>K_p</math>) of the speed controller. Too high a gain may cause speed oscillation. The figure below shows the speed controller output after an error step when the error remains constant.</p>  <p>Gain = <math>K_p = 1</math>  <math>T_i</math> = Integration time = 0  <math>T_d</math> = Derivation time = 0</p> <p>Controller output = <math>K_p \times e</math></p> <p>If gain is set to 1.00, a 10% error (reference - actual value) in the motor synchronous speed produces a proportional term of 10%.</p> <p><b>Note:</b> This parameter is automatically set by the speed controller autotune function. See section <a href="#">Speed controller autotune (page 48)</a>.</p>	10.00; 5.00 (95.21 b1/b2) / real32
	0.00 ... 250.00	Proportional gain for speed controller.	100 = 1 / 100 = 1

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
25.3	Speed integration time	<p>Defines the integration time of the speed controller. The integration time defines the rate at which the controller output changes when the error value is constant and the proportional gain of the speed controller is 1. The shorter the integration time, the faster the continuous error value is corrected.</p> <p>Setting the integration time to zero disables the I-part of the controller. This is useful to do when tuning the proportional gain; adjust the proportional gain first, then return the integration time.</p> <p>The integrator has anti-windup control for operation at a torque or current limit.</p> <p>The figure below shows the speed controller output after an error step when the error remains constant.</p>  <p><b>Note:</b> This parameter is automatically set by the speed controller autotune function. See section <a href="#">Speed controller autotune (page 48)</a>.</p>	2.50; 5.00 s (95.21 b1/b2) s / real32
	0.00 ... 1000.00 s	Integration time for speed controller.	10 = 1 s / 100 = 1 s


304 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
25.4	Speed derivation time	<p>Defines the derivation time of the speed controller. Derivative action boosts the controller output if the error value changes.</p> <p>The longer the derivation time, the more the speed controller output is boosted during the change. If the derivation time is set to zero, the controller works as a PI controller, otherwise as a PID controller. The derivation makes the control more responsive for disturbances. For simple applications (especially those without an encoder), derivative time is not normally required and should be left at zero.</p> <p>The figure below shows the speed controller output after an error step when the error remains constant. The speed error derivative must be filtered with a low pass filter to eliminate external disturbances.</p>  <p>Gain = <math>K_p = 1</math>  <math>T_i</math> = Integration time &gt; 0  <math>T_D</math> = Derivation time &gt; 0  <math>T_s</math> = Sample time period = 500 <math>\mu</math>s  <math>\Delta e</math> = Error value change between two samples</p>	0.000 s / real32
	0.000 ... 10.000 s	Derivation time for speed controller.	1000 = 1 s / 1000 = 1 s
25.5	Derivation filter time	Defines the derivation filter time constant. See parameter <a href="#">25.4 Speed derivation time</a> .	8 ms / real32
	0...10000 ms	Derivation filter time constant.	1 = 1 ms / 1 = 1 ms




No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
25.6	Acc comp derivation time	<p>Defines the derivation time for acceleration(/deceleration) compensation. In order to compensate for a high inertia load during acceleration, a derivative of the reference is added to the output of the speed controller. The principle of a derivative action is described under parameter <a href="#">25.4 Speed derivation time</a>.</p> <p><b>Note:</b> As a general rule, set this parameter to the value between 50 and 100% of the sum of the mechanical time constants of the motor and the driven machine.</p> <p>The figure below shows the speed responses when a high inertia load is accelerated along a ramp.</p> <p><b>No acceleration compensation:</b></p>  <p><b>Acceleration compensation:</b></p> 	- / real32
	0.00 ... 1000.00 s	Acceleration compensation derivation time.	10 = 1 s / 100 = 1 s
25.7	Acc comp filter time	Defines the acceleration (or deceleration) compensation filter time constant. See parameters <a href="#">25.4 Speed derivation time</a> and <a href="#">25.6 Acc comp derivation time</a> .	8.0 ms / real32
	0.0 ... 1000.0 ms	Acceleration/deceleration compensation filter time.	1 = 1 ms / 10 = 1 ms


306 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
25.8	Drooping rate	<p>Defines the droop rate in percent of the nominal motor speed.</p> <p>Drooping decreases the drive speed slightly as the drive load increases. The actual speed decrease at a certain operating point depends on the droop rate setting and the drive load (= torque reference / speed controller output). At 100 % speed controller output, drooping is at its nominal level, i.e. equal to the value of this parameter. The drooping effect decreases linearly to zero along with the decreasing load.</p> <p>The droop rate can be used e.g. to adjust the load sharing in a Master/Follower application run by several drives. In a Master/Follower application the motor shafts are coupled to each other.</p> <p>The correct droop rate for a process must be found out case by case in practice.</p> <p><b>Speed decrease</b> = Speed controller output × Drooping × Synchronous speed</p> <p><b>Example:</b> Speed controller output is 50 %, droop rate is 1 %, synchronous speed of the drive is 1500 rpm.</p> <p>Speed decrease = 0.50 × 0.01 × 1500 rpm = 7.5 rpm.</p>  <p>The graph plots 'Motor speed in % of nominal' on the y-axis and 'Drive load' on the x-axis. A horizontal solid line at 100% is labeled 'No drooping'. A dashed line below it is labeled 'Drooping'. At 100% drive load, the drooping rate is 25.08%.</p>	- / real32
	0.00 ... 100.00 %	Droop rate.	100 = 1 % / 100 = 1 %
25.9	Speed ctrl balancing enable	<p>Selects the source for enabling/disabling speed controller output balancing.</p> <p>This function is used to generate a smooth, “bumpless” transfer from a torque- or tension-controlled motor back to being speed-controlled. When balancing is enabled, the output of the speed controller is forced to the value of <a href="#">25.10 Speed ctrl balancing ref.</a></p> <p>Balancing is also possible in the ramp generator (see parameter <a href="#">23.26 Ramp out balancing enable</a>).</p> <p>0 = Disabled 1 = Enabled</p>	Not selected / uint32
	Not selected	0	0
	Selected	1	1
	DI1	Digital input DI1 ( <a href="#">10.2 DI delayed status</a> , bit 0).	2
	DI2	Digital input DI2 ( <a href="#">10.2 DI delayed status</a> , bit 1).	3


No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	DI3	Digital input DI3 (10.2 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.2 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.2 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.2 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1 (11.2 DIO delayed status, bit 0).	10
	DIO2	Digital input/output DIO2 (11.2 DIO delayed status, bit 1).	11
	Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-
25.10	Speed ctrl balancing ref	Defines the reference used in speed controller output balancing. The output of the speed controller is forced to this value when balancing is enabled by parameter 25.9 Speed ctrl balancing enable.	0.0 % / real32
	-300.0 ... 300.0 %	Speed control output balancing reference. For 16-bit scaling, see parameter 46.3.	- / 10 = 1 %
25.11	Speed control min torque	Defines the minimum speed controller output torque.	-300.0 % / real32
	-1600.0 ... 0.0 %	Minimum speed controller output torque. For 16-bit scaling, see parameter 46.3.	- / 10 = 1 %
25.12	Speed control max torque	Defines the maximum speed controller output torque.	300.0 % / real32
	0.0 ... 1600.0 %	Maximum speed controller output torque. For 16-bit scaling, see parameter 46.3.	- / 10 = 1 %
25.13	Min torq sp ctrl em stop	Defines the minimum speed controller output torque during a ramped emergency stop (Off1 or Off3).	-400.0 % / real32
	-1600.0 ... 0.0 %	Minimum speed controller output torque for ramped emergency stop. For 16-bit scaling, see parameter 46.3.	- / 10 = 1 %
25.14	Max torq sp ctrl em stop	Defines the maximum speed controller output torque during a ramped emergency stop (Off1 or Off3).	400.0 % / real32
	0.0 ... 1600.0 %	Maximum speed controller output torque for ramped emergency stop. For 16-bit scaling, see parameter 46.3.	- / 10 = 1 %
25.15	Proportional gain em stop	Defines the proportional gain for the speed controller when an emergency stop is active. See parameter 25.2 Speed proportional gain.	10.00; 5.00 (95.21 b1/b2) / real32
	1.00 ... 250.00	Proportional gain upon an emergency stop.	100 = 1 / 100 = 1

### 308 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
25.18	Speed adapt min limit	<p>Minimum actual speed for speed controller adaptation.</p> <p>Speed controller gain and integration time can be adapted according to actual speed (90.1 Motor speed for control).</p> <p>This is done by multiplying the gain (25.2 Speed proportional gain) and integration time (25.3 Speed integration time) by coefficients at certain speeds. The coefficients are defined individually for both gain and integration time.</p> <p>When actual speed is below or equal to 25.18 Speed adapt min limit, the gain is multiplied by 25.21 Kp adapt coef at min speed, and the integration time divided by 25.22 Ti adapt coef at min speed.</p> <p>When actual speed is equal to or above 25.19 Speed adapt max limit, no adaptation takes place (the coefficient is 1).</p> <p>When actual speed is between 25.18 Speed adapt min limit and 25.19 Speed adapt max limit, the coefficients for the gain and integration time are calculated linearly on the basis of the breakpoints.</p> <p>See also the block diagram on page 674.</p> 	- / real32
	0...30000 rpm	Minimum actual speed for speed controller adaptation.	1 = 1 rpm / 1 = 1 rpm
25.19	Speed adapt max limit	<p>Maximum actual speed for speed controller adaptation.</p> <p>See parameter 25.18 Speed adapt min limit.</p>	- / real32
	0...30000 rpm	Maximum actual speed for speed controller adaptation.	1 = 1 rpm / 1 = 1 rpm
25.21	Kp adapt coef at min speed	<p>Proportional gain coefficient at minimum actual speed.</p> <p>See parameter 25.18 Speed adapt min limit.</p>	1.000 / real32
	0.000 ... 10.000	Proportional gain coefficient at minimum actual speed.	1000 = 1 / 1000 = 1
25.22	Ti adapt coef at min speed	<p>Integration time coefficient at minimum actual speed.</p> <p>See parameter 25.18 Speed adapt min limit.</p>	1.000 / real32
	0.000 ... 10.000	Integration time coefficient at minimum actual speed.	1000 = 1 / 1000 = 1

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
25.25	Torque adapt max limit	<p>Maximum torque reference for speed controller adaptation.</p> <p>Speed controller gain can be adapted according to the final unlimited torque reference (26.1 Torque reference to TC).</p> <p>This can be used to smooth out disturbances caused by a small load and backlashes.</p> <p>The functionality involves multiplying the gain (25.2 Speed proportional gain) by a coefficient within a certain torque range.</p> <p>When the torque reference is 0%, the gain is multiplied by the value of parameter 25.27 Kp adapt coef at min torque.</p> <p>When the torque reference is equal to or above 25.25 Torque adapt max limit, no adaptation takes place (the coefficient is 1).</p> <p>Between 0% and 25.25 Torque adapt max limit, the coefficient for the gain is calculated linearly on the basis of the breakpoints.</p> <p>Filtering can be applied on the torque reference using parameter 25.26 Torque adapt filt time.</p> <p>See also the block diagram on page 674.</p> <p>Coefficient for <math>k_p</math> (proportional gain)</p> 	- / real32
	0.0 ... 1600.0 %	Maximum torque reference for speed controller adaptation. For 16-bit scaling, see parameter 46.3.	- / 10 = 1 %
25.26	Torque adapt filt time	<p>Defines a filter time constant for the adaptation, in effect adjusting the rate of change of the gain.</p> <p>See parameter 25.25 Torque adapt max limit.</p>	0.000 s / real32
	0.000 ... 100.000 s	Filter time for adaptation.	100 = 1 s / 1000 = 1 s
25.27	Kp adapt coef at min torque	<p>Proportional gain coefficient at 0% torque reference.</p> <p>See parameter 25.25 Torque adapt max limit.</p>	1.000 / real32
	0.000 ... 10.000	Proportional gain coefficient at 0% torque reference.	1000 = 1 / 1000 = 1

# 310 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
25.30	Flux adaptation enable	<p>Enables/disables speed controller adaptation based on motor flux reference (1.24 Flux actual %).</p> <p>The proportional gain of the speed controller is multiplied by a coefficient of 0...1 between 0...100% flux reference respectively.</p> <p>See also the block diagram on page 674.</p> <p>Coefficient for K (proportional gain)</p> 	Enable / uint16
	Disable	Speed controller adaptation based on flux reference disabled	0
	Enable	Speed controller adaptation based on flux reference enabled.	1
25.33	Speed controller autotune	<p>Activates (or selects a source that activates) the speed controller autotune function. See section <a href="#">Speed controller autotune</a> (page 48).</p> <p>The autotune will automatically set parameters <a href="#">25.2 Speed proportional gain</a>, <a href="#">25.3 Speed integration time</a> and <a href="#">25.37 Mechanical time constant</a>.</p> <p>The prerequisites for performing the autotune routine are:</p> <ul style="list-style-type: none"> <li>the motor identification run (ID run) has been successfully completed</li> <li>the speed and torque limits (parameter group <a href="#">30 Limits</a>) have been set</li> <li>speed feedback filtering (parameter group <a href="#">90 Feedback selection</a>), speed error filtering (<a href="#">24 Speed reference conditioning</a>) and zero speed (<a href="#">21 Start/stop mode</a>) have been set, and</li> <li>the drive has been started and is running in speed control mode.</li> </ul> <p><b>⚠ WARNING!</b> The motor and machinery will run against the torque and speed limits during the autotune routine. MAKE SURE IT IS SAFE TO ACTIVATE THE AUTOTUNE FUNCTION!</p> <p>The autotune routine can be aborted by stopping the drive.</p> <p>0→1 = Activate speed controller autotune</p> <p><b>Note:</b> The value does not revert to 0 automatically.</p>	Off / uint32

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	Off	0.	0
	On	1.	1
	Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-
25.34	Speed controller autotune mode	Defines a control preset for the speed controller autotune function. The setting affects the way the torque reference will respond to a speed reference step.	Normal / uint16
	Smooth	Slow but robust response.	0
	Normal	Medium setting.	1
	Tight	Fast response. May produce too high a gain value for some applications.	2
25.37	Mechanical time constant	Mechanical time constant of the drive and the machinery as determined by the speed controller autotune function. The value can be adjusted manually.	0.00 s / real32
	0.00 ... 1000.00 s	Mechanical time constant.	10 = 1 s / 100 = 1 s
25.38	Autotune torque step	Defines an added torque value used by the autotune function.  This value is scaled to motor nominal torque.  Note that the torque used by the autotune function can also be limited by the torque limits (in parameter group <a href="#">30 Limits</a> ) and nominal motor torque.	10.00 % / real32
	0.00 ... 100.00 %	Autotune torque step.	100 = 1 % / 100 = 1 %
25.39	Autotune speed step	Defines a speed value added to the initial speed for the autotune routine. The initial speed (speed used when autotune is activated) plus the value of this parameter is the calculated maximum speed used by the autotune routine. The maximum speed can also be limited by the speed limits (in parameter group <a href="#">30 Limits</a> ) and nominal motor speed.  The value is scaled to motor nominal speed.  <b>Note:</b> The motor will exceed the calculated maximum speed slightly at the end of each acceleration stage.	10.00 % / real32
	0.00 ... 100.00 %	Autotune speed step.	100 = 1 % / 100 = 1 %
25.40	Autotune repeat times	Determines how many acceleration/deceleration cycles are performed during the autotune routine. Increasing the value will improve the accuracy of the autotune function, and allow the use of smaller torque or speed step values.	10 / uint16
	1...10	Number of cycles during autotune routine.	1 = 1 / 1 = 1
25.41	Torque reference Autotune2	Reserved	- / real32

## 312 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
25.42	Integral term enable	Selects a source that enables/disables the integral (I) part of the speed controller. 0 = I-part disabled 1 = I-part enabled	Selected / uint32
	Not selected	0	0
	Selected	1	1
	DI1	Digital input DI1 (10.2 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.2 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.2 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.2 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.2 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.2 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1 (11.2 DIO delayed status, bit 0).	10
	DIO2	Digital input/output DIO2 (11.2 DIO delayed status, bit 1).	11
	Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-
25.53	Torque prop reference	Displays the output of the proportional (P) part of the speed controller. See the control chain diagram on page 674. This parameter is read-only.	- / real32
	-30000.0 ... 30000.0 %	P-part output of speed controller. For 16-bit scaling, see parameter 46.3.	- / 10 = 1 %
25.54	Torque integral reference	Displays the output of the integral (I) part of the speed controller. See the control chain diagram on page 674. This parameter is read-only.	- / real32
	-30000.0 ... 30000.0 %	I-part output of speed controller. For 16-bit scaling, see parameter 46.3.	- / 10 = 1 %
25.55	Torque deriv reference	Displays the output of the derivative (D) part of the speed controller. See the control chain diagram on page 674. This parameter is read-only.	- / real32
	-30000.0 ... 30000.0 %	D-part output of speed controller. For 16-bit scaling, see parameter 46.3.	- / 10 = 1 %
25.56	Torque acc compensation	Displays the output of the acceleration compensation function on page 674. See the control chain diagram. This parameter is read-only.	- / real32
	-30000.0 ... 30000.0 %	Output of acceleration compensation function. For 16-bit scaling, see parameter 46.3.	- / 10 = 1 %



No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
25.57	Torque reference unbalanced	Displays the acceleration-compensated output of the speed controller. See the control chain diagram on page 674. This parameter is read-only.	- / real32
	-30000.0 ... 30000.0 %	Acceleration-compensated output of speed controller. For 16-bit scaling, see parameter 46.3.	- / 10 = 1 %


### 314 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
26	Torque reference chain	Settings for the torque reference chain. See the control chain diagrams on pages 675 and 677.	
26.1	Torque reference to TC	Displays the final torque reference given to the torque controller in percent. This reference is then acted upon by various final limiters, like power, torque, load etc. See the control chain diagrams on pages 677 and 678. This parameter is read-only.	- / real32
	-1600.0 ... 1600.0 %	Torque reference for torque control. For 16-bit scaling, see parameter 46.3.	- / 10 = 1 %
26.2	Torque reference used	Displays the final torque reference (in percent of motor nominal torque) given to the DTC core, and comes after frequency, voltage and torque limitation. See the control chain diagram on page 678. This parameter is read-only.	- / real32
	-1600.0 ... 1600.0 %	Torque reference for torque control. For 16-bit scaling, see parameter 46.3.	- / 10 = 1 %
26.8	Minimum torque ref	Defines the minimum torque reference. Allows for local limiting of the torque reference before it is passed on to the torque ramp controller. For absolute torque limiting, refer to parameter 30.19 Minimum torque 1.	-300.0 % / real32
	-1000.0 ... 0.0 %	Minimum torque reference. For 16-bit scaling, see parameter 46.3.	- / 10 = 1 %
26.9	Maximum torque ref	Defines the maximum torque reference. Allows for local limiting of the torque reference before it is passed on to the torque ramp controller. For absolute torque limiting, refer to parameter 30.20 Maximum torque 1.	300.0 % / real32
	0.0 ... 1000.0 %	Maximum torque reference. For 16-bit scaling, see parameter 46.3.	- / 10 = 1 %
26.11	Torque ref1 source	Selects torque reference source 1.  Two signal sources can be defined by this parameter and 26.12 Torque ref2 source. A digital source selected by 26.14 Torque ref1/2 selection can be used to switch between the two sources, or a mathematical function (26.13 Torque ref1 function) applied to the two signals to create the reference.	Zero / uint32


No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	Zero	None.	0
	AI1 scaled	<a href="#">12.12 AI1 scaled value (page 201)</a> .	1
	AI2 scaled	<a href="#">12.22 AI2 scaled value (page 203)</a> .	2
	FB A ref1	<a href="#">3.5 FB A reference 1 (page 144)</a> .	4
	FB A ref2	<a href="#">3.6 FB A reference 2 (page 144)</a> .	5
	EFB ref1	<a href="#">3.9 EFB reference 1 (page 144)</a> .	8
	EFB ref2	<a href="#">3.10 EFB reference 2 (page 144)</a> .	9
	DDCS ctrl ref1	<a href="#">3.11 DDCS controller ref 1 (page 144)</a> .	10
	DDCS ctrl ref2	<a href="#">3.12 DDCS controller ref 2 (page 145)</a> .	11
	M/F reference 1	<a href="#">3.13 M/F or D2D ref1 (page 145)</a> .	12
	M/F reference 2	<a href="#">3.14 M/F or D2D ref2 (page 145)</a> .	13
	Motor potentiometer	<a href="#">22.80 Motor potentiometer ref act</a> (output of the motor potentiometer).	15
	PID	<a href="#">40.1 Process PID output actual</a> (output of the process PID controller).	16
	Control panel (ref saved)	Control panel reference, with initial value from last-used panel reference. See section <a href="#">Using the control panel as an external control source (page 25)</a> .	18
	Control panel (ref copied)	Control panel reference, with initial value from previous source or actual value. See section <a href="#">Using the control panel as an external control source (page 25)</a> .	19
	Other [bit]	Source selection (see <a href="#">Terms and abbreviations (page 134)</a> ).	-
26.12	Torque ref2 source	Selects torque reference source 2.  For the selections, and a diagram of reference source selection, see parameter <a href="#">26.11 Torque ref1 source</a> .	Zero / uint32
26.13	Torque ref1 function	Selects a mathematical function between the reference sources selected by parameters <a href="#">26.11 Torque ref1 source</a> and <a href="#">26.12 Torque ref2 source</a> . See diagram at <a href="#">26.11 Torque ref1 source</a> .	Ref1 / uint16
	Ref1	Signal selected by <a href="#">26.11 Torque ref1 source</a> is used as torque reference 1 as such (no function applied).	0
	Add (ref1 + ref2)	The sum of the reference sources is used as torque reference 1.	1
	Sub (ref1 - ref2)	The subtraction ( <a href="#">26.11 Torque ref1 source</a> - <a href="#">26.12 Torque ref2 source</a> ) of the reference sources is used as torque reference 1.	2
	Mul (ref1 x ref2)	The multiplication of the reference sources is used as torque reference 1.	3
	Min (ref1, ref2)	The smaller of the reference sources is used as torque reference 1.	4
	Max (ref1, ref2)	The greater of the reference sources is used as torque reference 1.	5

## 316 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
26.14	Torque ref1/2 selection	Configures the selection between torque references 1 and 2. See diagram at <a href="#">26.11 Torque ref1 source</a> . 0 = Torque reference 1 1 = Torque reference 2	Torque reference 1 / uint32
	Torque reference 1	0.	0
	Torque reference 2	1.	1
	Follow Ext1/Ext2 selection	Torque reference 1 is used when external control location EXT1 is active. Torque reference 2 is used when external control location EXT2 is active. See also parameter <a href="#">19.11 Ext1/Ext2 selection</a> .	2
	DI1	Digital input DI1 ( <a href="#">10.2 DI delayed status</a> , bit 0).	3
	DI2	Digital input DI2 ( <a href="#">10.2 DI delayed status</a> , bit 1).	4
	DI3	Digital input DI3 ( <a href="#">10.2 DI delayed status</a> , bit 2).	5
	DI4	Digital input DI4 ( <a href="#">10.2 DI delayed status</a> , bit 3).	6
	DI5	Digital input DI5 ( <a href="#">10.2 DI delayed status</a> , bit 4).	7
	DI6	Digital input DI6 ( <a href="#">10.2 DI delayed status</a> , bit 5).	8
	Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-
26.15	Load share	Defines the scaling factor for the torque reference (the torque reference is multiplied by the value). This allows drives sharing the load between two motors on the same mechanical plant to be tailored to share the correct amount each, yet use the same master torque reference.	1.000 / real32
	-8.000 ... 8.000	Torque reference scaling factor.	1000 = 1 / 1000 = 1
26.16	Torque additive 1 source	Selects the source of torque reference additive 1. <b>Note:</b> For safety reasons, the additive is not applied when an emergency stop is active. See the control chain diagram on page <a href="#">675</a> . For the selections, see parameter <a href="#">26.11 Torque ref1 source</a> .	Zero / uint32
26.17	Torque ref filter time	Defines a low-pass filter time constant for the torque reference.	0.000 s / real32
	0.000 ... 30.000 s	Filter time constant for torque reference.	1000 = 1 s / 1000 = 1 s
26.18	Torque ramp up time	Defines the torque reference ramp-up time, ie. the time for the reference to increase from zero to nominal motor torque.	0.000 s / real32
	0.000 ... 60.000 s	Torque reference ramp-up time.	100 = 1 s / 1000 = 1 s
26.19	Torque ramp down time	Defines the torque reference ramp-down time, ie. the time for the reference to decrease from nominal motor torque to zero.	0.000 s / real32

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	0.000 ... 60.000 s	Torque reference ramp-down time.	100 = 1 s / 1000 = 1 s
26.25	Torque additive 2 source	<p>Selects the source of torque reference additive 2.</p> <p>The value received from the selected source is added to the torque reference after operating mode selection. Because of this, the additive can be used in speed and torque modes.</p> <p><b>Note:</b> For safety reasons, the additive is not applied when an emergency stop is active.</p> <p> <b>WARNING!</b> If the additive exceeds the limits set by parameters <a href="#">25.11 Speed control min torque</a> and <a href="#">25.12 Speed control max torque</a>, a ramp stop may be impossible. Make sure the additive is reduced or removed when a ramp stop is required eg. by using parameter <a href="#">26.26 Force torque ref add 2 zero</a>.</p> <p>See the control chain diagram on page <a href="#">677</a>. For the selections, see parameter <a href="#">26.11 Torque ref1 source</a>.</p>	Zero / uint32
26.26	Force torque ref add 2 zero	<p>Selects a source that forces torque reference additive 2 (see parameter <a href="#">26.25 Torque additive 2 source</a>) to zero.</p> <p>0 = Normal operation 1 = Force torque reference additive 2 to zero.</p>	Not selected / uint32
	Not selected	0	0
	Selected	1	1
	DI1	Digital input DI1 ( <a href="#">10.2 DI delayed status</a> , bit 0).	2
	DI2	Digital input DI2 ( <a href="#">10.2 DI delayed status</a> , bit 1).	3
	DI3	Digital input DI3 ( <a href="#">10.2 DI delayed status</a> , bit 2).	4
	DI4	Digital input DI4 ( <a href="#">10.2 DI delayed status</a> , bit 3).	5
	DI5	Digital input DI5 ( <a href="#">10.2 DI delayed status</a> , bit 4).	6
	DI6	Digital input DI6 ( <a href="#">10.2 DI delayed status</a> , bit 5).	7
	DIO1	Digital input/output DIO1 ( <a href="#">11.2 DIO delayed status</a> , bit 0).	10
	DIO2	Digital input/output DIO2 ( <a href="#">11.2 DIO delayed status</a> , bit 1).	11
	Other [bit]	See <a href="#">Terms and abbreviations</a> (page <a href="#">134</a> ).	-
26.27	Torque limit filter time	<p>Defines the filtering time of the torque limit.</p> <p>This parameter is used to smooth the step when changing the limit if the drive is running on torque limit.</p>	100 ms / real32
	0...100 ms	Torque limit filter time.	1 = 1 ms / 1 = 1 ms

## 318 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
26.41	Torque step	<p>When enabled by parameter <a href="#">26.42 Torque step enable</a>, adds an additional step to the torque reference.</p> <p>A second torque step can be added using pointer parameters <a href="#">26.43 Torque step pointer enable</a> and <a href="#">26.44 Torque step source</a>.</p> <p>The two torque steps work independently of each other, and are summed up to calculate the total torque step.</p> <p><b>Note:</b> For safety reasons, the torque steps are not applied when an emergency stop is active.</p> <p> <b>WARNING!</b> If the total torque step exceeds the limits set by parameters <a href="#">25.11 Speed control min torque</a> and <a href="#">25.12 Speed control max torque</a>, a ramp stop may be impossible. Make sure the torque step is reduced or disabled when a ramp stop is required.</p>	0.0 % / real32
	-300.0 ... 300.0 %	Torque step. For 16-bit scaling, see parameter <a href="#">46.3</a> .	- / 10 = 1 %
26.42	Torque step enable	Enables/disables the torque step defined by parameter <a href="#">26.41 Torque step</a> .	Disable / uint32
	Disable	Torque step disabled.	0
	Enable	Torque step enabled.	1
26.43	Torque step pointer enable	<p>Selects a source that enables/disables the torque step defined by parameter <a href="#">26.44 Torque step source</a>.</p> <p>See also parameter <a href="#">26.41 Torque step</a>.</p> <p>1 = Torque step enabled.</p>	Selected / uint32
	Not selected	0	0
	Selected	1	1
	DI1	Digital input DI1 ( <a href="#">10.2 DI delayed status</a> , bit 0).	2
	DI2	Digital input DI2 ( <a href="#">10.2 DI delayed status</a> , bit 1).	3
	DI3	Digital input DI3 ( <a href="#">10.2 DI delayed status</a> , bit 2).	4
	DI4	Digital input DI4 ( <a href="#">10.2 DI delayed status</a> , bit 3).	5
	DI5	Digital input DI5 ( <a href="#">10.2 DI delayed status</a> , bit 4).	6
	DI6	Digital input DI6 ( <a href="#">10.2 DI delayed status</a> , bit 5).	7
	DIO1	Digital input/output DIO1 ( <a href="#">11.2 DIO delayed status</a> , bit 0).	10
	DIO2	Digital input/output DIO2 ( <a href="#">11.2 DIO delayed status</a> , bit 1).	11
	Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-
26.44	Torque step source	Selects the source of the torque step enabled by <a href="#">26.43 Torque step pointer enable</a> .	Zero / uint32
	Zero	None.	0

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	AI1 scaled	<a href="#">12.12 AI1 scaled value (page 201).</a>	1
	AI2 scaled	<a href="#">12.22 AI2 scaled value (page 203).</a>	2
	FB A ref1	<a href="#">3.5 FB A reference 1 (page 144).</a>	4
	FB A ref2	<a href="#">3.6 FB A reference 2 (page 144).</a>	5
	EFB ref1	<a href="#">3.9 EFB reference 1 (page 144).</a>	8
	EFB ref2	<a href="#">3.10 EFB reference 2 (page 144).</a>	9
	DDCS ctrl ref1	<a href="#">3.11 DDCS controller ref 1 (page 144).</a>	10
	DDCS ctrl ref2	<a href="#">3.12 DDCS controller ref 2 (page 145).</a>	11
	M/F reference 1	<a href="#">3.13 M/F or D2D ref1 (page 145).</a>	12
	M/F reference 2	<a href="#">3.14 M/F or D2D ref2 (page 145).</a>	13
	Motor potentiometer	<a href="#">22.80 Motor potentiometer ref act</a> (output of the motor potentiometer).	15
	PID	<a href="#">40.1 Process PID output actual</a> (output of the process PID controller).	16
	Control panel (ref saved)	Control panel reference, with initial value from last-used panel reference. See section <a href="#">Using the control panel as an external control source (page 25)</a> .	18
	Control panel (ref copied)	Control panel reference, with initial value from previous source or actual value. See section <a href="#">Using the control panel as an external control source (page 25)</a> .	19
	Other [bit]	Source selection (see <a href="#">Terms and abbreviations (page 134)</a> ).	-
26.51	Oscillation damping	Parameters <a href="#">26.51...26.58</a> configure the oscillation damping function. See section <a href="#">Oscillation damping (page 51)</a> , and the block diagram on <a href="#">page 677</a> .  This parameter enables (or selects a source that enables) the oscillation damping algorithm.  1 = Oscillation damping algorithm enabled	Not selected / uint32
	Not selected	0	0
	Selected	1	1
	DI1	Digital input DI1 ( <a href="#">10.2 DI delayed status</a> , bit 0).	2
	DI2	Digital input DI2 ( <a href="#">10.2 DI delayed status</a> , bit 1).	3
	DI3	Digital input DI3 ( <a href="#">10.2 DI delayed status</a> , bit 2).	4
	DI4	Digital input DI4 ( <a href="#">10.2 DI delayed status</a> , bit 3).	5
	DI5	Digital input DI5 ( <a href="#">10.2 DI delayed status</a> , bit 4).	6
	DI6	Digital input DI6 ( <a href="#">10.2 DI delayed status</a> , bit 5).	7
	DIO1	Digital input/output DIO1 ( <a href="#">11.2 DIO delayed status</a> , bit 0).	10
	DIO2	Digital input/output DIO2 ( <a href="#">11.2 DIO delayed status</a> , bit 1).	11
	Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-

## 320 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b	
26.52	Oscillation damping out enable	Determines (or selects a source that determines) whether the output of the oscillation damping function is applied to the torque reference or not.  <b>Note:</b> Before enabling the oscillation damping output, adjust parameters 26.53...26.57. Then monitor the input signal (selected by 26.53) and the output (26.58) to make sure that the correction is safe to apply.  1 = Apply oscillation damping output to torque reference	Not selected / uint32	
	Not selected	0	0	
	Selected	1	1	
	DI1	Digital input DI1 (10.2 DI delayed status, bit 0).	2	
	DI2	Digital input DI2 (10.2 DI delayed status, bit 1).	3	
	DI3	Digital input DI3 (10.2 DI delayed status, bit 2).	4	
	DI4	Digital input DI4 (10.2 DI delayed status, bit 3).	5	
	DI5	Digital input DI5 (10.2 DI delayed status, bit 4).	6	
	DI6	Digital input DI6 (10.2 DI delayed status, bit 5).	7	
	DIO1	Digital input/output DIO1 (11.2 DIO delayed status, bit 0).	10	
	DIO2	Digital input/output DIO2 (11.2 DIO delayed status, bit 1).	11	
	Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-	
	26.53	Oscillation compensation input	Selects the input signal for the oscillation damping function.  <b>Note:</b> Before changing this parameter run-time, disable the oscillation damping output using parameter 26.52. Monitor the behavior of 26.58 before re-enabling the output.	Speed error / uint32
		Speed error	24.1 Used speed reference - unfiltered motor speed.  <b>Note:</b> This setting is not supported in scalar motor control mode.	0
DC voltage		1.11 DC voltage. (The value is internally filtered.)	1	
26.55	Oscillation damping frequency	Defines the center frequency of the oscillation damping filter.  Set the value according to the number of oscillation peaks in the monitored signal (selected by 26.53) per second.  <b>Note:</b> Before changing this parameter run-time, disable the oscillation damping output using parameter 26.52. Monitor the behavior of 26.58 before re-enabling the output.	31.0 Hz / real32	
	0.1 ... 60.0 Hz	Center frequency for oscillation damping.	10 = 1 Hz / 10 = 1 Hz	



No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
26.56	Oscillation damping phase	Defines a phase shift for the output of the filter.  <b>Note:</b> Before changing this parameter run-time, disable the oscillation damping output using parameter 26.52. Monitor the behavior of 26.58 before re-enabling the output.	180 deg / real32
	0...360 deg	Phase shift for oscillation damping function output.	10 = 1 deg / 1 = 1 deg
26.57	Oscillation damping gain	Defines a gain for the output of the oscillation damping function, ie. how much the output of the filter is amplified before it is added to the torque reference.  Oscillation gain is scaled according to the speed controller gain so that changing the gain will not disturb oscillation damping.  <b>Note:</b> Before changing this parameter run-time, disable the oscillation damping output using parameter 26.52. Monitor the behavior of 26.58 before re-enabling the output.	1.0 % / real32
	0.0 ... 100.0 %	Gain setting for oscillation damping output.	10 = 1 % / 10 = 1 %
26.58	Oscillation damping output	Displays the output of the oscillation damping function. This value is added to the torque reference (as allowed by parameter 26.52 Oscillation damping output enable).  This parameter is read-only.	- / real32
	-1600.000 ... 1600.000 %	Output of the oscillation damping function.	10 = 1 % / 1000 = 1 %
26.70	Torque reference act 1	Displays the value of torque reference source 1 (selected by parameter 26.11 Torque ref1 source). See the control chain diagram on page 675.  This parameter is read-only.	- / real32
	-1600.0 ... 1600.0 %	Value of torque reference source 1. For 16-bit scaling, see parameter 46.3.	- / 10 = 1 %
26.71	Torque reference act 2	Displays the value of torque reference source 2 (selected by parameter 26.12 Torque ref2 source). See the control chain diagram on page 675.  This parameter is read-only.	- / real32
	-1600.0 ... 1600.0 %	Value of torque reference source 2. For 16-bit scaling, see parameter 46.3.	- / 10 = 1 %
26.72	Torque reference act 3	Displays the torque reference after the function applied by parameter 26.13 Torque ref1 function (if any), and after selection (26.14 Torque ref1/2 selection). See the control chain diagram on page 675.  This parameter is read-only.	- / real32
	-1600.0 ... 1600.0 %	Torque reference after selection. For 16-bit scaling, see parameter 46.3.	- / 10 = 1 %


## 322 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
26.73	Torque reference act 4	Displays the torque reference after application of reference additive 1. See the control chain diagram on page 675. This parameter is read-only.	- / real32
	-1600.0 ... 1600.0 %	Torque reference after application of reference additive 1. For 16-bit scaling, see parameter 46.3.	- / 10 = 1 %
26.74	Torque ref ramp out	Displays the torque reference after limiting and ramping. See the control chain diagram on page 675. This parameter is read-only.	- / real32
	-1600.0 ... 1600.0 %	Torque reference after limiting and ramping. For 16-bit scaling, see parameter 46.3.	- / 10 = 1 %
26.75	Torque reference act 5	Displays the torque reference after control mode selection. See the control chain diagram on page 677. This parameter is read-only.	- / real32
	-1600.0 ... 1600.0 %	Torque reference after control mode selection. For 16-bit scaling, see parameter 46.3.	- / 10 = 1 %
26.76	Torque reference act 6	Displays the torque reference after application of reference additive 2. See the control chain diagram on page 677. This parameter is read-only.	- / real32
	-1600.0 ... 1600.0 %	Torque reference after application of reference additive 2. For 16-bit scaling, see parameter 46.3.	- / 10 = 1 %
26.77	Torque ref add A actual	Displays the value of the source of torque reference additive 2. See the control chain diagram on page 677. This parameter is read-only.	- / real32
	-1600.0 ... 1600.0 %	Torque reference additive 2. For 16-bit scaling, see parameter 46.3.	- / 10 = 1 %
26.78	Torque ref add B actual	Displays the value of torque reference additive 2 before it is added to torque reference. See the control chain diagram on page 677. This parameter is read-only.	- / real32
	-1600.0 ... 1600.0 %	Torque reference additive 2. For 16-bit scaling, see parameter 46.3.	- / 10 = 1 %
26.81	Rush control gain	Rush controller gain term. See section <a href="#">Rush control</a> (page 53).	10.0 / real32
	0.0 ... 10000.0	Rush controller gain (0.0 = disabled).	1 = 1 / 10 = 1
26.82	Rush control integration time	Rush controller integration time term.	2.0 s / real32
	0.0 ... 10.0 s	Rush controller integration time (0.0 = disabled).	1 = 1 s / 10 = 1 s

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
<b>28</b>	Frequency reference chain	Settings for the frequency reference chain. See the control chain diagrams <a href="#">680</a> and <a href="#">681</a> .	
28.1	Frequency ref ramp input	Displays the used frequency reference before ramping. See the control chain diagram on page <a href="#">681</a> . This parameter is read-only.	- / real32
	-598.00 ... 598.00 Hz	Frequency reference before ramping. For 16-bit scaling, see parameter <a href="#">46.2</a> .	- / 100 = 1 Hz
28.2	Frequency ref ramp output	Displays the final frequency reference (after selection, limitation and ramping). See the control chain diagram on page <a href="#">681</a> . This parameter is read-only.	- / real32
	-598.00 ... 598.00 Hz	Final frequency reference. For 16-bit scaling, see parameter <a href="#">46.2</a> .	- / 100 = 1 Hz
28.11	Frequency ref1 source	Selects frequency reference source 1.  Two signal sources can be defined by this parameter and <a href="#">28.12 Frequency ref2 source</a> . A digital source selected by <a href="#">28.14 Frequency ref1/2 selection</a> can be used to switch between the two sources, or a mathematical function ( <a href="#">28.13 Frequency ref1 function</a> ) applied to the two signals to create the reference.	Zero / uint32
	Zero	None.	0
	AI1 scaled	<a href="#">12.12 AI1 scaled value</a> (page <a href="#">201</a> ).	1
	AI2 scaled	<a href="#">12.22 AI2 scaled value</a> (page <a href="#">203</a> ).	2
	FB A ref1	<a href="#">3.5 FB A reference 1</a> (page <a href="#">144</a> ).	4
	FB A ref2	<a href="#">3.6 FB A reference 2</a> (page <a href="#">144</a> ).	5
	EFB ref1	<a href="#">3.9 EFB reference 1</a> (page <a href="#">144</a> ).	8
	EFB ref2	<a href="#">3.10 EFB reference 2</a> (page <a href="#">144</a> ).	9
	DDCS ctrl ref1	<a href="#">3.11 DDCS controller ref 1</a> (page <a href="#">144</a> ).	10
	DDCS ctrl ref2	<a href="#">3.12 DDCS controller ref 2</a> (page <a href="#">145</a> ).	11
	M/F reference 1	<a href="#">3.13 M/F or D2D ref1</a> (page <a href="#">145</a> ).	12
	M/F reference 2	<a href="#">3.14 M/F or D2D ref2</a> (page <a href="#">145</a> ).	13
	Motor potentiometer	<a href="#">22.80 Motor potentiometer ref act</a> (output of the motor potentiometer).	15

## 324 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	PID	<a href="#">40.1 Process PID output actual</a> (output of the process PID controller).	16
	Control panel (ref saved)	Control panel reference, with initial value from last-used panel reference. See section <a href="#">Using the control panel as an external control source</a> (page 25).	18
	Control panel (ref copied)	Control panel reference, with initial value from previous source or actual value. See section <a href="#">Using the control panel as an external control source</a> (page 25).	19
	Other [bit]	Source selection (see <a href="#">Terms and abbreviations</a> (page 134)).	-
28.12	Frequency ref2 source	Selects frequency reference source 2. For the selections, and a diagram of reference source selection, see parameter <a href="#">28.11 Frequency ref1 source</a> .	Zero / uint32
28.13	Frequency ref1 function	Selects a mathematical function between the reference sources selected by parameters <a href="#">28.11 Frequency ref1 source</a> and <a href="#">28.12 Frequency ref2 source</a> . See diagram at <a href="#">28.11 Frequency ref1 source</a> .	Ref1 / uint16
	Ref1	Signal selected by <a href="#">28.11 Frequency ref1 source</a> is used as frequency reference 1 as such (no function applied).	0
	Add (ref1 + ref2)	The sum of the reference sources is used as frequency reference 1.	1
	Sub (ref1 - ref2)	The subtraction ( <a href="#">[28.11 Frequency ref1 source]</a> - <a href="#">[28.12 Frequency ref2 source]</a> ) of the reference sources is used as frequency reference 1.	2
	Mul (ref1 x ref2)	The multiplication of the reference sources is used as frequency reference 1.	3
	Min (ref1, ref2)	The smaller of the reference sources is used as frequency reference 1.	4
	Max (ref1, ref2)	The greater of the reference sources is used as frequency reference 1.	5
28.14	Frequency ref1/2 selection	Configures the selection between frequency references 1 and 2. See diagram at <a href="#">28.11 Frequency ref1 source</a> . 0 = Frequency reference 1 1 = Frequency reference 2	Follow Ext1/Ext2 selection / uint32
	Frequency reference 1	0.	0
	Frequency reference 2	1.	1
	Follow Ext1/Ext2 selection	Frequency reference 1 is used when external control location EXT1 is active. Frequency reference 2 is used when external control location EXT2 is active. See also parameter <a href="#">19.11 Ext1/Ext2 selection</a> .	2
	DI1	Digital input DI1 ( <a href="#">10.2 DI delayed status</a> , bit 0).	3
	DI2	Digital input DI2 ( <a href="#">10.2 DI delayed status</a> , bit 1).	4
	DI3	Digital input DI3 ( <a href="#">10.2 DI delayed status</a> , bit 2).	5

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	DI4	Digital input DI4 (10.2 DI delayed status, bit 3).	6
	DI5	Digital input DI5 (10.2 DI delayed status, bit 4).	7
	DI6	Digital input DI6 (10.2 DI delayed status, bit 5).	8
	Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-
28.21	Constant frequency function	Determines how constant frequencies are selected, and whether the rotation direction signal is considered or not when applying a constant frequency.	- / uint16
b0	Constant freq mode	<p>1 = Packed: 7 constant frequencies are selectable using the three sources defined by parameters <a href="#">28.22</a>, <a href="#">28.23</a> and <a href="#">28.24</a>.</p> <p>0 = Separate: Constant frequencies 1, 2 and 3 are separately activated by the sources defined by parameters <a href="#">28.22</a>, <a href="#">28.23</a> and <a href="#">28.24</a> respectively. In case of conflict, the constant frequency with the smaller number takes priority.</p>	
b1	Direction enable	<p>1 = Start dir: To determine running direction for a constant frequency, the sign of the constant frequency setting (parameters <a href="#">28.26...28.32</a>) is multiplied by the direction signal (forward: +1, reverse: -1). This effectively allows the drive to have 14 (7 forward, 7 reverse) constant frequencies if all values in <a href="#">28.26...28.32</a> are positive.</p> <p> <b>WARNING!</b> If the direction signal is reverse and the active constant frequency is negative, the drive will run in the forward direction.</p> <p>0 = According to Par: The running direction for the constant frequency is determined by the sign of the constant speed setting (parameters <a href="#">28.26...28.32</a>).</p>	
b2...15	Reserved		
	0000h...FFFFh		1 = 1 / 1 = 1

### 326 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b																																				
28.22	Constant frequency sel1	<p>When bit 0 of parameter <a href="#">28.21 Constant frequency function</a> is 0 (Separate), selects a source that activates constant frequency 1.</p> <p>When bit 0 of parameter <a href="#">28.21 Constant frequency function</a> is 1 (Packed), this parameter and parameters <a href="#">28.23 Constant frequency sel2</a> and <a href="#">28.24 Constant frequency sel3</a> select three sources whose states activate constant frequencies as follows:</p> <table border="1" data-bbox="340 395 820 938"> <thead> <tr> <th data-bbox="340 395 460 475">Source defined by par. <a href="#">28.22</a></th> <th data-bbox="460 395 580 475">Source defined by par. <a href="#">28.23</a></th> <th data-bbox="580 395 700 475">Source defined by par. <a href="#">28.24</a></th> <th data-bbox="700 395 820 475">Constant frequency active</th> </tr> </thead> <tbody> <tr> <td data-bbox="340 475 460 512">0</td> <td data-bbox="460 475 580 512">0</td> <td data-bbox="580 475 700 512">0</td> <td data-bbox="700 475 820 512">None</td> </tr> <tr> <td data-bbox="340 512 460 572">1</td> <td data-bbox="460 512 580 572">0</td> <td data-bbox="580 512 700 572">0</td> <td data-bbox="700 512 820 572">Constant frequency 1</td> </tr> <tr> <td data-bbox="340 572 460 633">0</td> <td data-bbox="460 572 580 633">1</td> <td data-bbox="580 572 700 633">0</td> <td data-bbox="700 572 820 633">Constant frequency 2</td> </tr> <tr> <td data-bbox="340 633 460 694">1</td> <td data-bbox="460 633 580 694">1</td> <td data-bbox="580 633 700 694">0</td> <td data-bbox="700 633 820 694">Constant frequency 3</td> </tr> <tr> <td data-bbox="340 694 460 754">0</td> <td data-bbox="460 694 580 754">0</td> <td data-bbox="580 694 700 754">1</td> <td data-bbox="700 694 820 754">Constant frequency 4</td> </tr> <tr> <td data-bbox="340 754 460 815">1</td> <td data-bbox="460 754 580 815">0</td> <td data-bbox="580 754 700 815">1</td> <td data-bbox="700 754 820 815">Constant frequency 5</td> </tr> <tr> <td data-bbox="340 815 460 876">0</td> <td data-bbox="460 815 580 876">1</td> <td data-bbox="580 815 700 876">1</td> <td data-bbox="700 815 820 876">Constant frequency 6</td> </tr> <tr> <td data-bbox="340 876 460 938">1</td> <td data-bbox="460 876 580 938">1</td> <td data-bbox="580 876 700 938">1</td> <td data-bbox="700 876 820 938">Constant frequency 7</td> </tr> </tbody> </table>	Source defined by par. <a href="#">28.22</a>	Source defined by par. <a href="#">28.23</a>	Source defined by par. <a href="#">28.24</a>	Constant frequency active	0	0	0	None	1	0	0	Constant frequency 1	0	1	0	Constant frequency 2	1	1	0	Constant frequency 3	0	0	1	Constant frequency 4	1	0	1	Constant frequency 5	0	1	1	Constant frequency 6	1	1	1	Constant frequency 7	Not selected / uint32
Source defined by par. <a href="#">28.22</a>	Source defined by par. <a href="#">28.23</a>	Source defined by par. <a href="#">28.24</a>	Constant frequency active																																				
0	0	0	None																																				
1	0	0	Constant frequency 1																																				
0	1	0	Constant frequency 2																																				
1	1	0	Constant frequency 3																																				
0	0	1	Constant frequency 4																																				
1	0	1	Constant frequency 5																																				
0	1	1	Constant frequency 6																																				
1	1	1	Constant frequency 7																																				
	Not selected	0	0																																				
	Selected	1	1																																				
	DI1	Digital input DI1 ( <a href="#">10.2 DI delayed status</a> , bit 0).	2																																				
	DI2	Digital input DI2 ( <a href="#">10.2 DI delayed status</a> , bit 1).	3																																				
	DI3	Digital input DI3 ( <a href="#">10.2 DI delayed status</a> , bit 2).	4																																				
	DI4	Digital input DI4 ( <a href="#">10.2 DI delayed status</a> , bit 3).	5																																				
	DI5	Digital input DI5 ( <a href="#">10.2 DI delayed status</a> , bit 4).	6																																				
	DI6	Digital input DI6 ( <a href="#">10.2 DI delayed status</a> , bit 5).	7																																				
	DIO1	Digital input/output DIO1 ( <a href="#">11.2 DIO delayed status</a> , bit 0).	10																																				
	DIO2	Digital input/output DIO2 ( <a href="#">11.2 DIO delayed status</a> , bit 1).	11																																				
	Other [bit]	See <a href="#">Terms and abbreviations</a> (page 134).	-																																				

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
28.23	Constant frequency sel2	<p>When bit 0 of parameter <a href="#">28.21 Constant frequency function</a> is 0 (Separate), selects a source that activates constant frequency 2.</p> <p>When bit 0 of parameter <a href="#">28.21 Constant frequency function</a> is 1 (Packed), this parameter and parameters <a href="#">28.22 Constant frequency sel1</a> and <a href="#">28.24 Constant frequency sel3</a> select three sources that are used to activate constant frequencies.</p> <p>See table at parameter <a href="#">28.22 Constant frequency sel1</a>.</p> <p>For the selections, see parameter <a href="#">28.22 Constant frequency sel1</a>.</p>	Not selected / uint32
28.24	Constant frequency sel3	<p>When bit 0 of parameter <a href="#">28.21 Constant frequency function</a> is 0 (Separate), selects a source that activates constant frequency 3.</p> <p>When bit 0 of parameter <a href="#">28.21 Constant frequency function</a> is 1 (Packed), this parameter and parameters <a href="#">28.22 Constant frequency sel1</a> and <a href="#">28.23 Constant frequency sel2</a> select three sources that are used to activate constant frequencies.</p> <p>See table at parameter <a href="#">28.22 Constant frequency sel1</a>.</p> <p>For the selections, see parameter <a href="#">28.22 Constant frequency sel1</a>.</p>	Not selected / uint32
28.26	Constant frequency 1	Defines constant frequency 1 (the frequency the motor will turn when constant frequency 1 is selected).	0.00 Hz / real32
	-598.00 ... 598.00 Hz	Constant frequency 1. For 16-bit scaling, see parameter <a href="#">46.2</a> .	- / 100 = 1 Hz
28.27	Constant frequency 2	Defines constant frequency 2.	0.00 Hz / real32
	-598.00 ... 598.00 Hz	Constant frequency 2. For 16-bit scaling, see parameter <a href="#">46.2</a> .	- / 100 = 1 Hz
28.28	Constant frequency 3	Defines constant frequency 3.	0.00 Hz / real32
	-598.00 ... 598.00 Hz	Constant frequency 3. For 16-bit scaling, see parameter <a href="#">46.2</a> .	- / 100 = 1 Hz
28.29	Constant frequency 4	Defines constant frequency 4.	0.00 Hz / real32
	-598.00 ... 598.00 Hz	Constant frequency 4. For 16-bit scaling, see parameter <a href="#">46.2</a> .	- / 100 = 1 Hz
28.30	Constant frequency 5	Defines constant frequency 5.	0.00 Hz / real32
	-598.00 ... 598.00 Hz	Constant frequency 5. For 16-bit scaling, see parameter <a href="#">46.2</a> .	- / 100 = 1 Hz
28.31	Constant frequency 6	Defines constant frequency 6.	0.00 Hz / real32
	-598.00 ... 598.00 Hz	Constant frequency 6. For 16-bit scaling, see parameter <a href="#">46.2</a> .	- / 100 = 1 Hz

## 328 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
28.32	Constant frequency 7	Defines constant frequency 7.	0.00 Hz / real32
	-598.00 ... 598.00 Hz	Constant frequency 7. For 16-bit scaling, see parameter <a href="#">46.2</a> .	- / 100 = 1 Hz
28.41	Frequency ref safe	Defines a safe frequency reference value that is used with supervision functions such as <ul style="list-style-type: none"> <li><a href="#">12.3 AI supervision function</a></li> <li><a href="#">49.5 Communication loss action</a></li> <li><a href="#">50.2 FBA A comm loss func</a></li> <li><a href="#">50.32 FBA B comm loss func</a></li> <li><a href="#">58.14 Communication loss action</a>.</li> </ul>	- / real32
	-598.00 ... 598.00 Hz	Safe frequency reference. For 16-bit scaling, see parameter <a href="#">46.2</a> .	- / 100 = 1 Hz
28.51	Critical frequency function	Enables/disables the critical frequencies function. Also determines whether the specified ranges are effective in both rotating directions or not.  See also section <a href="#">Critical speeds/frequencies (page 47)</a> .	- / uint16
b0	Enable	1 = Enable: Critical frequencies enabled. 0 = Disable: Critical frequencies disabled.	
b1	Sign mode	1 = According to par: The signs of parameters <a href="#">28.52...28.57</a> are taken into account. 0 = Absolute: Parameters <a href="#">28.52...28.57</a> are handled as absolute values.  Each range is effective in both directions of rotation.	
b2...15	Reserved		
	0000h...FFFFh		1 = 1 / 1 = 1
28.52	Critical frequency 1 low	Defines the low limit for critical frequency 1.  <b>Note:</b> This value must be less than or equal to the value of <a href="#">28.53 Critical frequency 1 high</a> .	0.00 Hz / real32
	-598.00 ... 598.00 Hz	Low limit for critical frequency 1. For 16-bit scaling, see parameter <a href="#">46.2</a> .	- / 100 = 1 Hz
28.53	Critical frequency 1 high	Defines the high limit for critical frequency 1.  <b>Note:</b> This value must be greater than or equal to the value of <a href="#">28.52 Critical frequency 1 low</a> .	0.00 Hz / real32
	-598.00 ... 598.00 Hz	High limit for critical frequency 1. For 16-bit scaling, see parameter <a href="#">46.2</a> .	- / 100 = 1 Hz
28.54	Critical frequency 2 low	Defines the low limit for critical frequency 2.  <b>Note:</b> This value must be less than or equal to the value of <a href="#">28.55 Critical frequency 2 high</a> .	0.00 Hz / real32
	-598.00 ... 598.00 Hz	Low limit for critical frequency 2. For 16-bit scaling, see parameter <a href="#">46.2</a> .	- / 100 = 1 Hz



No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
28.55	Critical frequency 2 high	Defines the high limit for critical frequency 2.  <b>Note:</b> This value must be greater than or equal to the value of <a href="#">28.54 Critical frequency 2 low</a> .	0.00 Hz / real32
	-598.00 ... 598.00 Hz	High limit for critical frequency 2. For 16-bit scaling, see parameter <a href="#">46.2</a> .	- / 100 = 1 Hz
28.56	Critical frequency 3 low	Defines the low limit for critical frequency 3.  <b>Note:</b> This value must be less than or equal to the value of <a href="#">28.57 Critical frequency 3 high</a> .	0.00 Hz / real32
	-598.00 ... 598.00 Hz	Low limit for critical frequency 3. For 16-bit scaling, see parameter <a href="#">46.2</a> .	- / 100 = 1 Hz
28.57	Critical frequency 3 high	Defines the high limit for critical frequency 3.  <b>Note:</b> This value must be greater than or equal to the value of <a href="#">28.56 Critical frequency 3 low</a> .	0.00 Hz / real32
	-598.00 ... 598.00 Hz	High limit for critical frequency 3. For 16-bit scaling, see parameter <a href="#">46.2</a> .	- / 100 = 1 Hz
28.71	Freq ramp set selection	Selects a source that switches between the two sets of acceleration/deceleration times defined by parameters <a href="#">28.72...28.75</a> .  0 = Acceleration time 1 and deceleration time 1 are in force  1 = Acceleration time 2 and deceleration time 2 are in force	Acc/Dec time 1 / uint32
	Acc/Dec time 1	0.	0
	Acc/Dec time 2	1.	1
	DI1	Digital input DI1 ( <a href="#">10.2 DI delayed status</a> , bit 0).	2
	DI2	Digital input DI2 ( <a href="#">10.2 DI delayed status</a> , bit 1).	3
	DI3	Digital input DI3 ( <a href="#">10.2 DI delayed status</a> , bit 2).	4
	DI4	Digital input DI4 ( <a href="#">10.2 DI delayed status</a> , bit 3).	5
	DI5	Digital input DI5 ( <a href="#">10.2 DI delayed status</a> , bit 4).	6
	DI6	Digital input DI6 ( <a href="#">10.2 DI delayed status</a> , bit 5).	7
	DIO1	Digital input/output DIO1 ( <a href="#">11.2 DIO delayed status</a> , bit 0).	10
	DIO2	Digital input/output DIO2 ( <a href="#">11.2 DIO delayed status</a> , bit 1).	11
	Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-

### 330 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
28.72	Freq acceleration time 1	<p>Defines acceleration time 1 as the time required for the frequency to change from zero to the frequency defined by parameter <a href="#">46.2 Frequency scaling</a> (not to parameter <a href="#">30.14 Maximum frequency</a>).</p> <p>If the reference increases faster than the set acceleration rate, the motor will follow the acceleration rate.</p> <p>If the reference increases slower than the set acceleration rate, the motor frequency will follow the reference.</p> <p>If the acceleration time is set too short, the drive will automatically prolong the acceleration in order not to exceed the drive torque limits.</p>	20.000 s / real32
	0.000 ... 1800.000 s	Acceleration time 1.	10 = 1 s / 1000 = 1 s
28.73	Freq deceleration time 1	<p>Defines deceleration time 1 as the time required for the frequency to change from the frequency defined by parameter <a href="#">46.2 Frequency scaling</a> (not from parameter <a href="#">30.14 Maximum frequency</a>) to zero.</p> <p>If there is any doubt about the deceleration time being too short, ensure that DC overvoltage control (<a href="#">30.30 Overvoltage control</a>) is on.</p> <p><b>Note:</b> If a short deceleration time is needed for a high inertia application, the drive should be equipped with braking equipment such as a brake chopper and brake resistor.</p>	20.000 s / real32
	0.000 ... 1800.000 s	Deceleration time 1.	10 = 1 s / 1000 = 1 s
28.74	Freq acceleration time 2	Defines acceleration time 2. See parameter <a href="#">28.72 Freq acceleration time 1</a> .	60.000 s / real32
	0.000 ... 1800.000 s	Acceleration time 2.	10 = 1 s / 1000 = 1 s
28.75	Freq deceleration time 2	Defines deceleration time 2. See parameter <a href="#">28.73 Freq deceleration time 1</a> .	60.000 s / real32
	0.000 ... 1800.000 s	Deceleration time 2.	10 = 1 s / 1000 = 1 s
28.76	Freq ramp in zero source	<p>Selects a source that forces the frequency reference to zero.</p> <p>0 = Force frequency reference to zero 1 = Normal operation</p>	Inactive / uint32
	Active	0.	0
	Inactive	1.	1
	DI1	Digital input DI1 ( <a href="#">10.2 DI delayed status</a> , bit 0).	2
	DI2	Digital input DI2 ( <a href="#">10.2 DI delayed status</a> , bit 1).	3
	DI3	Digital input DI3 ( <a href="#">10.2 DI delayed status</a> , bit 2).	4
	DI4	Digital input DI4 ( <a href="#">10.2 DI delayed status</a> , bit 3).	5
	DI5	Digital input DI5 ( <a href="#">10.2 DI delayed status</a> , bit 4).	6
	DI6	Digital input DI6 ( <a href="#">10.2 DI delayed status</a> , bit 5).	7


No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	DIO1	Digital input/output DIO1 (11.2 DIO delayed status, bit 0).	10
	DIO2	Digital input/output DIO2 (11.2 DIO delayed status, bit 1).	11
	Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-
28.77	Freq ramp hold	Selects a source that forces the output of the frequency ramp generator to actual frequency value. 0 = Force ramp output to actual frequency 1 = Normal operation	Inactive / uint32
	Active	0.	0
	Inactive	1.	1
	DI1	Digital input DI1 (10.2 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.2 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.2 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.2 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.2 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.2 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1 (11.2 DIO delayed status, bit 0).	10
	DIO2	Digital input/output DIO2 (11.2 DIO delayed status, bit 1).	11
	Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-
28.78	Freq ramp output balancing	Defines a reference for frequency ramp balancing. The output of the ramp generator is forced to this value when balancing is enabled by parameter 28.79 <a href="#">Freq ramp out balancing enable</a> .	- / real32
	-598.00 ... 598.00 Hz	Frequency ramp balancing reference. For 16-bit scaling, see parameter 46.2.	- / 100 = 1 Hz
28.79	Freq ramp out balancing enable	Selects the source for enabling/disabling speed ramp balancing. See parameter 28.78 <a href="#">Freq ramp output balancing</a> . 0 = Disabled 1 = Enabled	Not selected / uint32
	Not selected	0	0
	Selected	1	1
	DI1	Digital input DI1 (10.2 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.2 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.2 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.2 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.2 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.2 DI delayed status, bit 5).	7

### 332 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	DIO1	Digital input/output DIO1 (11.2 DIO delayed status, bit 0).	10
	DIO2	Digital input/output DIO2 (11.2 DIO delayed status, bit 1).	11
	Other [bit]	See <a href="#">Terms and abbreviations</a> (page 134).	-
28.90	Frequency ref act 1	Displays the value of frequency reference source 1 (selected by parameter <a href="#">28.11 Frequency ref1 source</a> ). See the control chain diagram on page 680.  This parameter is read-only.	- / real32
	-598.00 ... 598.00 Hz	Value of frequency reference source 1. For 16-bit scaling, see parameter <a href="#">46.2</a> .	- / 100 = 1 Hz
28.91	Frequency ref act 2	Displays the value of frequency reference source 2 (selected by parameter <a href="#">28.12 Frequency ref2 source</a> ). See the control chain diagram on page 680.  This parameter is read-only.	- / real32
	-598.00 ... 598.00 Hz	Value of frequency reference source 2. For 16-bit scaling, see parameter <a href="#">46.2</a> .	- / 100 = 1 Hz
28.92	Frequency ref act 3	Displays the frequency reference after the function applied by parameter <a href="#">28.13 Frequency ref1 function</a> (if any), and after selection ( <a href="#">28.14 Frequency ref1/2 selection</a> ). See the control chain diagram on page 680.  This parameter is read-only.	- / real32
	-598.00 ... 598.00 Hz	Frequency reference after selection. For 16-bit scaling, see parameter <a href="#">46.2</a> .	- / 100 = 1 Hz
28.96	Frequency ref act 7	Displays the frequency reference after application of constant frequencies, control panel reference, etc. See the control chain diagram on page 680.  This parameter is read-only.	- / real32
	-598.00 ... 598.00 Hz	Frequency reference 7. For 16-bit scaling, see parameter <a href="#">46.2</a> .	- / 100 = 1 Hz
28.97	Frequency ref unlimited	Displays the frequency reference after application of critical frequencies, but before ramping and limiting. See the control chain diagram on page 681.  This parameter is read-only.	- / real32
	-598.00 ... 598.00 Hz	Frequency reference before ramping and limiting. For 16-bit scaling, see parameter <a href="#">46.2</a> .	- / 100 = 1 Hz

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
<b>29</b>	Voltage reference chain	Settings for the DC voltage reference chain. See section <a href="#">DC voltage control mode (page 27)</a> and the control chain diagrams (pages <a href="#">682</a> and <a href="#">683</a> ). This group is only visible with a BCU control unit.	
29.1	Torque ref DC voltage control	Displays the DC voltage controller output that is transferred to the torque controller. This parameter is read-only.	- / real32
	-1600.0 ... 1600.0 %	Final DC voltage reference.	100 = 1 % / 10 = 1 %
29.2	DC voltage ref	Displays the DC voltage reference after the function applied by parameter <a href="#">29.13 DC voltage ref1 function</a> (if any), and after selection ( <a href="#">29.14 DC voltage ref1/2 selection</a> ). See the diagram at parameter <a href="#">29.11 DC voltage ref1 source</a> .	- / real32
	0...2000 V	DC voltage reference after selection.	10 = 1 V / 1 = 1 V
29.3	DC voltage ref used	Displays the DC voltage reference between minimum/maximum limitation and ramping.	- / real32
	0...2000 V	DC voltage reference before ramping.	10 = 1 V / 1 = 1 V
29.4	DC voltage ref ramped	Displays the DC voltage reference after ramping.	- / real32
	0...2000 V	DC voltage reference after ramping.	10 = 1 V / 1 = 1 V
29.5	Filtered DC voltage	Displays the measured DC voltage after filtering.	- / real32
	0...2000 V	Measured and filtered DC voltage.	10 = 1 V / 1 = 1 V
29.6	DC voltage error	Displays the difference between the ramped voltage reference ( <a href="#">29.4</a> ) and measured, filtered DC voltage ( <a href="#">29.5</a> ).	- / real32
	-2000...2000 V	Measured and filtered DC voltage.	10 = 1 V / 1 = 1 V
29.7	Power reference	Displays the output of the PI controller, ie. the DC voltage reference before it is converted to a torque reference.	- / real32
	-300.00 ... 300.00 %	Output of the PI controller.	10 = 1 % / 100 = 1 %
29.9	Minimum DC voltage reference	Defines a minimum limit for the DC voltage reference before it is ramped.	0 V / real32
	0...2000 V	Minimum DC voltage reference.	1 = 1 V / 1 = 1 V
29.10	Maximum DC voltage reference	Defines a maximum limit for the DC voltage reference before it is ramped.	2000 V / real32
	0...2000 V	Maximum DC voltage reference.	1 = 1 V / 1 = 1 V

### 334 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
29.11	DC voltage ref1 source	<p>Selects DC voltage reference source 1.</p> <p>Two signal sources can be defined by this parameter and <a href="#">29.12 DC voltage ref2 source</a>. A digital source selected by <a href="#">29.14 DC voltage ref1/2 selection</a> can be used to switch between the two sources, or a mathematical function (<a href="#">29.13 DC voltage ref1 function</a>) applied to the two signals to create the reference.</p> 	Zero / uint32
	Zero	None.	0
	AI1 scaled	<a href="#">12.12 AI1 scaled value (page 201)</a> .	1
	AI2 scaled	<a href="#">12.22 AI2 scaled value (page 203)</a> .	2
	FB A ref1	<a href="#">3.5 FB A reference 1 (page 144)</a> .	4
	FB A ref2	<a href="#">3.6 FB A reference 2 (page 144)</a> .	5
	EFB ref1	<a href="#">3.9 EFB reference 1 (page 144)</a> .	8
	EFB ref2	<a href="#">3.10 EFB reference 2 (page 144)</a> .	9
	DDCS ctrl ref1	<a href="#">3.11 DDCS controller ref 1 (page 144)</a> .	10
	DDCS ctrl ref2	<a href="#">3.12 DDCS controller ref 2 (page 145)</a> .	11
	M/F reference 1	<a href="#">3.13 M/F or D2D ref1 (page 145)</a> .	12
	M/F reference 2	<a href="#">3.14 M/F or D2D ref2 (page 145)</a> .	13
	Motor potentiometer	<a href="#">22.80 Motor potentiometer ref act</a> (output of the motor potentiometer).	15
	PID	<a href="#">40.1 Process PID output actual</a> (output of the process PID controller).	16
	Control panel (ref saved)	Control panel reference, with initial value from last-used panel reference. See section <a href="#">Using the control panel as an external control source (page 25)</a> .	18
	Control panel (ref copied)	Control panel reference, with initial value from previous source or actual value. See section <a href="#">Using the control panel as an external control source (page 25)</a> .	19
	Other [bit]	Source selection (see <a href="#">Terms and abbreviations (page 134)</a> ).	-
29.12	DC voltage ref2 source	<p>Selects DC voltage reference source 2.</p> <p>For the selections, and a diagram of reference source selection, see parameter <a href="#">29.11 DC voltage ref1 source</a>.</p>	Zero / uint32

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
29.13	DC voltage ref1 function	Selects a mathematical function between the reference sources selected by parameters <a href="#">29.11 DC voltage ref1 source</a> and <a href="#">29.12 DC voltage ref2 source</a> . See diagram at <a href="#">29.11 DC voltage ref1 source</a> .	Ref1 / uint16
	Ref1	Signal selected by <a href="#">29.11 DC voltage ref1 source</a> is used as DC voltage reference 1 as such (no function applied).	0
	Add (ref1 + ref2)	The sum of the reference sources is used as DC voltage reference 1.	1
	Sub (ref1 - ref2)	The subtraction ( <a href="#">[29.11 DC voltage ref1 source]</a> - <a href="#">[29.12 DC voltage ref2 source]</a> ) of the reference sources is used as DC voltage reference 1.	2
	Mul (ref1 x ref2)	The multiplication of the reference sources is used as DC voltage reference 1.	3
	Min (ref1, ref2)	The smaller of the reference sources is used as DC voltage reference 1.	4
	Max (ref1, ref2)	The greater of the reference sources is used as DC voltage reference 1.	5
29.14	DC voltage ref1/2 selection	Configures the selection between DC voltage references 1 and 2. See diagram at <a href="#">29.11 DC voltage ref1 source</a> .  0 = DC voltage reference 1 1 = DC voltage reference 2	Follow Ext1/Ext2 selection / uint32
	DC voltage reference 1	0.	0
	DC voltage reference 2	1.	1
	Follow Ext1/Ext2 selection	DC voltage reference 1 is used when external control location EXT1 is active. DC voltage reference 2 is used when external control location EXT2 is active.  See also parameter <a href="#">19.11 Ext1/Ext2 selection</a> .	2
	DI1	Digital input DI1 ( <a href="#">10.2 DI delayed status</a> , bit 0).	3
	DI2	Digital input DI2 ( <a href="#">10.2 DI delayed status</a> , bit 1).	4
	DI3	Digital input DI3 ( <a href="#">10.2 DI delayed status</a> , bit 2).	5
	DI4	Digital input DI4 ( <a href="#">10.2 DI delayed status</a> , bit 3).	6
	DI5	Digital input DI5 ( <a href="#">10.2 DI delayed status</a> , bit 4).	7
	DI6	Digital input DI6 ( <a href="#">10.2 DI delayed status</a> , bit 5).	8
Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-	
29.17	DC voltage filter time	Defines a filtering time for measured DC voltage.	10 ms / real32
	0...10000 ms	Filtering time for DC voltage measurement.	1 = 1 ms / 1 = 1 ms
29.18	DC voltage ramp down speed	Defines the maximum decrease rate for the DC voltage reference.	10 V/s / real32
	0...30000 V/s	DC voltage reference decrease rate.	1 = 1 V/s / 1 = 1 V/s

### 336 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
29.19	DC voltage ramp up speed	Defines the maximum increase rate for the DC voltage reference.	10 V/s / real32
	0...30000 V/s	DC voltage reference increase rate.	1 = 1 V/s / 1 = 1 V/s
29.20	DC voltage proportional gain	Defines the proportional gain for the DC voltage reference PI controller.	54.66 V/s / real32
	0.00 ... 1000.00 V/s	Proportional gain.	100 = 1 V/s / 100 = 1 V/s
29.21	DC voltage integration time	Defines the integration time for the DC voltage reference PI controller.  Setting the integration time to zero disables the I-part of the controller.	0.1646 s / real32
	0.0000 ... 60.0000 s	Integration time.	10000 = 1 s / 10000 = 1 s
29.25	DC capacitance source	Selects the source of the total DC circuit capacitance value.  The value is used in DC voltage reference calculation.  <b>Note:</b> This parameter cannot be changed while the drive is running.	Copy from database / uint16
	Copy from database	DC capacitance value is taken from an internal database according to drive type.	0
	User value	The DC capacitance value is read from parameter <a href="#">29.26 Used DC capacitance</a> .	1
29.26	Used DC capacitance	Defines the DC circuit capacitance when parameter <a href="#">29.25 DC capacitance source</a> is set to User value.  <b>Note:</b> This parameter cannot be changed while the drive is running.	0.000 mF / real32
	0.000 ... 1000.000 mF	User-specified DC capacitance.	100 = 1 mF / 1000 = 1 mF
29.70	Speed data point 1	Parameters <a href="#">29.70...29.79</a> define a maximum torque limitation curve as a function of speed. The limit is applied before the reference is forwarded to the torque controller.  This parameter defines the speed at the first point of the curve. The curve is linear between 0 rpm and this speed.	400.00 rpm / real32



No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	0.00 ... 30000.00 rpm	Speed at 1st point of curve.	1 = 1 rpm / 100 = 1 rpm
29.71	Torque data point 1	Defines the maximum torque at the first point of the limitation curve.	300.0 % / real32
	0.0 ... 1600.0 %	Maximum torque at 1st point of curve.	1 = 1 % / 10 = 1 %
29.72	Speed data point 2	Defines the speed at the second point of the curve.	800.00 rpm / real32
	0.00 ... 30000.00 rpm	Speed at 2nd point of curve.	1 = 1 rpm / 100 = 1 rpm
29.73	Torque data point 2	Defines the maximum torque at the second point of the limitation curve.	300.0 % / real32
	0.0 ... 1600.0 %	Maximum torque at 2nd point of curve.	1 = 1 % / 10 = 1 %
29.74	Speed data point 3	Defines the speed at the third point of the curve.	1200.00 rpm / real32
	0.00 ... 30000.00 rpm	Speed at 3rd point of curve.	1 = 1 rpm / 100 = 1 rpm
29.75	Torque data point 3	Defines the maximum torque at the third point of the limitation curve.	300.0 % / real32
	0.0 ... 1600.0 %	Maximum torque at 3rd point of curve.	1 = 1 % / 10 = 1 %
29.76	Speed data point 4	Defines the speed at the fourth point of the curve.	1600.00 rpm / real32
	0.00 ... 30000.00 rpm	Speed at 4th point of curve.	1 = 1 rpm / 100 = 1 rpm
29.77	Torque data point 4	Defines the maximum torque at the fourth point of the limitation curve.	300.0 % / real32
	0.0 ... 1600.0 %	Maximum torque at 4th point of curve.	1 = 1 % / 10 = 1 %
29.78	Speed data point 5	Defines the speed at the fifth point of the curve.	2000.00 rpm / real32
	0.00 ... 30000.00 rpm	Speed at 5th point of curve.	1 = 1 rpm / 100 = 1 rpm
29.79	Torque data point 5	Defines the maximum torque at the fifth point of the limitation curve.	300.0 % / real32
	0.0 ... 1600.0 %	Maximum torque at 5th point of curve.	1 = 1 % / 10 = 1 %





### 338 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
<b>30</b>	Limits	Drive operation limits.	
30.1	Limit word 1	Displays limit word 1. This parameter is read-only.	- / uint16
b0	Torq lim	1 = Drive torque is being limited by the motor control (undervoltage control, current control, load angle control or pull-out control), or by the torque limits defined by parameters.	
b1	Spd ctl tlim min	1 = Speed controller output is being limited by <a href="#">25.11 Speed control min torque</a>	
b2	Spd ctl tlim max	1 = Speed controller output is being limited by <a href="#">25.12 Speed control max torque</a>	
b3	Torq ref max	1 = Torque reference ramp input is being limited by <a href="#">26.9 Maximum torque ref</a> , source of <a href="#">30.25 Maximum torque sel</a> , <a href="#">30.26 Power motoring limit</a> or <a href="#">30.27 Power generating limit</a> . See diagram on page 678.	
b4	Torq ref min	1 = Torque reference ramp input is being limited by <a href="#">26.8 Minimum torque ref</a> , source of <a href="#">30.18 Minimum torque sel</a> , <a href="#">30.26 Power motoring limit</a> or <a href="#">30.27 Power generating limit</a> . See diagram on page 678.	
b5	Tlim max speed	1 = Torque reference is being limited by the rush control because of maximum speed limit ( <a href="#">30.12 Maximum speed</a> )	
b6	Tlim min speed	1 = Torque reference is being limited by the rush control because of minimum speed limit ( <a href="#">30.11 Minimum speed</a> )	
b7	Max speed ref lim	1 = Speed reference is being limited by <a href="#">30.12 Maximum speed</a> , or by maximum permanent magnet motor speed limit based on DC voltage	
b8	Min speed ref lim	1 = Speed reference is being limited by <a href="#">30.11 Minimum speed</a> , or by maximum permanent magnet motor speed limit based on DC voltage	
b9	Max freq ref lim	1 = Frequency reference is being limited by <a href="#">30.14 Maximum frequency</a>	
b10	Min freq ref lim	1 = Frequency reference is being limited by <a href="#">30.13 Minimum frequency</a>	
b11	Reserved		
b12	Sw freq ref lim	1 = Requested output frequency cannot be reached because of switching frequency limitation (because of eg. output filtering or ATEXrelated protections)	


No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
b13	Load angle lim	(With permanent magnet motors and synchronous reluctance motors, and externally-excited synchronous motors in steady state)  1 = Maximum load angle is being limited, ie. the motor cannot produce any more torque  (With externally-excited synchronous motors in dynamic situations)  1 = Torque is being limited	
b14...15	Reserved		
	0000h...FFFFh		1 = 1 / 1 = 1
30.2	Torque limit status	Displays the torque controller limitation status word.  This parameter is read-only.  *Only one out of bits 0...3, and one out of bits 9...13 can be on simultaneously. The bit typically indicates the limit that is exceeded first.	- / uint16
b0	Undervoltage	*1 = Intermediate DC circuit undervoltage	
b1	Overvoltage	*1 = Intermediate DC circuit overvoltage	
b2	Minimum torque	*1 = Torque is being limited by <a href="#">30.26 Power motoring limit</a> , <a href="#">30.27 Power generating limit</a> or the source of <a href="#">30.18 Minimum torque sel.</a> See diagram on page 678.	
b3	Maximum torque	*1 = Torque is being limited by <a href="#">30.26 Power motoring limit</a> , <a href="#">30.27 Power generating limit</a> or the source of <a href="#">30.25 Maximum torque sel.</a>  See diagram on page 678.	
b4	Internal current	1 = An inverter current limit (identified by bits 8...11) is active	
b5	Maximum load angle	(With permanent magnet motors, synchronous reluctance motors, and externally-excited synchronous motors only)  1 = Maximum load angle limit is active, ie. the motor is producing as much torque as possible	
b6	Motor pullout	(With asynchronous motors only)  1 = Motor pull-out limit is active, ie. the motor cannot produce any more torque	
b7	Reserved		
b8	Thermal	1 = Input current is being limited by the main circuit thermal limit	
b9	Max current	*1 = Maximum output current ( $I_{MAX}$ ) is being limited	
b10	User current	*1 = Output current is being limited by <a href="#">30.17 Maximum current</a>	
b11	Thermal IGBT	*1 = Output current is being limited by a calculated thermal current value	

### 340 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
b12	IGBT overtemperature	*1 = Output current is being limited because of estimated IGBT temperature	
b13	IGBT overload	*1 = Output current is being limited because of IGBT junction to case temperature	
b14...15	Reserved		
	0000h...FFFFh		1 = 1 / 1 = 1
30.11	Minimum speed	<p>Defines the minimum allowed speed.</p> <p> <b>WARNING!</b> This value must not be higher than <a href="#">30.12 Maximum speed</a>.</p> <p> <b>WARNING!</b> In frequency control mode, this limit is not effective. Make sure the frequency limits (<a href="#">30.13</a> and <a href="#">30.14</a>) are set appropriately if frequency control is used.</p> <p> <b>WARNING!</b> In a master/follower configuration, do not set maximum and minimum speed limits with the same sign on a follower drive. See section <a href="#">Master/follower functionality</a>.</p>	-1500.00; -1800.00 (95.20 b0) rpm / real32
	-30000.00 ... 30000.00 rpm	Minimum allowed speed. For 16-bit scaling, see parameter <a href="#">46.1</a> .	- / 100 = 1 rpm
30.12	Maximum speed	<p>Defines the maximum allowed speed.</p> <p> <b>WARNING!</b> This value must not be lower than <a href="#">30.11 Minimum speed</a>.</p> <p> <b>WARNING!</b> In frequency control mode, this limit is not effective. Make sure the frequency limits (<a href="#">30.13</a> and <a href="#">30.14</a>) are set appropriately if frequency control is used.</p> <p> <b>WARNING!</b> In a master/follower configuration, do not set maximum and minimum speed limits with the same sign on a follower drive. See section <a href="#">Master/follower functionality</a>.</p>	1500.00; 1800.00 (95.20 b0) rpm / real32
	-30000.00 ... 30000.00 rpm	Maximum speed. For 16-bit scaling, see parameter <a href="#">46.1</a> .	- / 100 = 1 rpm

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
30.13	Minimum frequency	<p>Defines the minimum allowed frequency.</p> <p> <b>WARNING!</b> This value must not be higher than <a href="#">30.14 Maximum frequency</a>.</p> <p> <b>WARNING!</b> This limit is effective in frequency control mode only.</p>	-50.00; -60.00 (95.20 b0) Hz / real32
	-598.00 ... 598.00 Hz	Minimum frequency. For 16-bit scaling, see parameter <a href="#">46.2.</a>	- / 100 = 1 Hz
30.14	Maximum frequency	<p>Defines the maximum allowed frequency.</p> <p> <b>WARNING!</b> This value must not be lower than <a href="#">30.13 Minimum frequency</a>.</p> <p> <b>WARNING!</b> This limit is effective in frequency control mode only.</p>	50.00; 60.00 (95.20 b0) Hz / real32
	-598.00 ... 598.00 Hz	Maximum frequency. For 16-bit scaling, see parameter <a href="#">46.2.</a>	- / 100 = 1 Hz
30.15	Maximum start current enable	<p>A temporary motor current limit specifically for starting can be defined by this parameter and <a href="#">30.16 Maximum start current</a>.</p> <p>When this parameter is set to <a href="#">Enable</a>, the drive observes the start current limit defined by <a href="#">30.16 Maximum start current</a>. The limit is in force for 2 seconds after initial magnetization (of an asynchronous induction motor) or autophasing (of a permanent magnet motor), but not more often than once in every 7 seconds. Otherwise, the limit defined by <a href="#">30.17 Maximum current</a> is in force.</p> <p><b>Note:</b> The availability of a start current higher than the general limit depends on drive hardware. See the rating data in the hardware manual of the drive.</p>	Disable / uint16
	Disable	Start current limit disabled.	0
	Enable	Start current limit enabled.	1
30.16	Maximum start current	Defines a maximum start current when enabled by parameter <a href="#">30.15 Maximum start current enable</a> .	0.00 A / real32
	0.00 ... 30000.00 A	Maximum start current.	1 = 1 A / 1 = 1 A
30.17	Maximum current	Defines the maximum allowed motor current.	0.00 A / real32
	0.00 ... 30000.00 A	Maximum motor current.	1 = 1 A / 1 = 1 A

### 342 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
30.18	Minimum torque sel	<p>Selects a source that switches between two different predefined minimum torque limits.</p> <p>0 = Minimum torque limit defined by 30.19 is active            1 = Minimum torque limit selected by 30.21 is active</p> <p>The user can define two sets of torque limits, and switch between the sets using a binary source such as a digital input.</p> <p>The minimum limit selection (30.18) is independent of the maximum limit selection (30.25).</p> <p>The first set of limits is defined by parameters 30.19 and 30.20. The second set has selector parameters for both the minimum (30.21) and maximum (30.22) limits that allows the use of a selectable analog source (such as an analog input).</p>  <p>The limit selection parameters are updated on a 10 ms time level.</p> <p><b>Note:</b> In addition to the user-defined limits, torque may be limited for other reasons (such as power limitation). Refer to the block diagram on page 678.</p>	Minimum torque 1 / uint32
	Minimum torque 1	0 (minimum torque limit defined by 30.19 is active).	0
	Minimum torque 2 source	1 (minimum torque limit selected by 30.21 is active).	1
	DI1	Digital input DI1 (10.2 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.2 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.2 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.2 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.2 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.2 DI delayed status, bit 5).	7

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	DIO1	Digital input/output DIO1 ( <a href="#">11.2 DIO delayed status</a> , bit 0).	10
	DIO2	Digital input/output DIO2 ( <a href="#">11.2 DIO delayed status</a> , bit 1).	11
	Other [bit]	See <a href="#">Terms and abbreviations</a> (page 134).	-
30.19	Minimum torque 1	Defines a minimum torque limit for the drive (in percent of nominal motor torque). See diagram at parameter <a href="#">30.18 Minimum torque sel</a> .  The limit is effective when <ul style="list-style-type: none"> <li>the source selected by <a href="#">30.18 Minimum torque sel</a> is 0, or</li> <li><a href="#">30.18</a> is set to <a href="#">Minimum torque 1</a>.</li> </ul> <p><b>Note:</b> Do not set this parameter to 0% in an attempt to prevent reverse rotation. In an open-loop application, that is likely to prevent the motor from stopping altogether. To prevent reverse rotation, use the speed/frequency limits in this parameter group, or parameters <a href="#">20.23/20.24</a>.</p>	-300.0 % / real32
	-1600.0 ... 0.0 %	Minimum torque limit 1. For 16-bit scaling, see parameter <a href="#">46.3</a> .	- / 10 = 1 %
30.20	Maximum torque 1	Defines a maximum torque limit for the drive (in percent of nominal motor torque). See diagram at parameter <a href="#">30.18 Minimum torque sel</a> .  The limit is effective when <ul style="list-style-type: none"> <li>the source selected by <a href="#">30.25 Maximum torque sel</a> is 0, or</li> <li><a href="#">30.25</a> is set to <a href="#">Maximum torque 1</a>.</li> </ul>	300.0 % / real32
	0.0 ... 1600.0 %	Maximum torque 1. For 16-bit scaling, see parameter <a href="#">46.3</a> .	- / 10 = 1 %
30.21	Minimum torque 2 source	Defines the source of the minimum torque limit for the drive (in percent of nominal motor torque) when <ul style="list-style-type: none"> <li>the source selected by parameter <a href="#">30.18 Minimum torque sel</a> is 1, or</li> <li><a href="#">30.18</a> is set to <a href="#">Minimum torque 2 source</a></li> </ul> See diagram at <a href="#">30.18 Minimum torque sel</a> .  <b>Note:</b> Any positive values received from the selected source are inverted.	Minimum torque 2 / uint32
	Zero	None.	0
	AI1 scaled	<a href="#">12.12 AI1 scaled value</a> (page 201).	1
	AI2 scaled	<a href="#">12.22 AI2 scaled value</a> (page 203).	2
	PID	<a href="#">40.1 Process PID output actual</a> (output of the process PID controller).	5
	Minimum torque 2	<a href="#">30.23 Minimum torque 2</a> .	6
	Other [bit]	Source selection (see <a href="#">Terms and abbreviations</a> (page 134)).	-

## 344 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
30.22	Maximum torque 2 source	<p>Defines the source of the maximum torque limit for the drive (in percent of nominal motor torque) when</p> <ul style="list-style-type: none"> <li>the source selected by parameter <a href="#">30.25 Maximum torque sel</a> is 1, or</li> <li><a href="#">30.25</a> is set to <a href="#">Maximum torque 2 source</a>.</li> </ul> <p>See diagram at <a href="#">30.18 Minimum torque sel</a>.</p> <p><b>Note:</b> Any negative values received from the selected source are inverted.</p>	Maximum torque 2 / uint32
	Zero	None.	0
	AI1 scaled	<a href="#">12.12 AI1 scaled value (page 201)</a> .	1
	AI2 scaled	<a href="#">12.22 AI2 scaled value (page 203)</a> .	2
	PID	<a href="#">40.1 Process PID output actual</a> (output of the process PID controller).	5
	Maximum torque 2	<a href="#">30.24 Maximum torque 2</a> .	6
	Other [bit]	Source selection (see <a href="#">Terms and abbreviations (page 134)</a> ).	-
30.23	Minimum torque 2	<p>Defines the minimum torque limit for the drive (in percent of nominal motor torque) when</p> <ul style="list-style-type: none"> <li>the source selected by parameter <a href="#">30.18 Minimum torque sel</a> is 1, and</li> <li><a href="#">30.21</a> is set to <a href="#">PID</a>.</li> </ul> <p><b>Note:</b> Do not set this parameter to 0% in an attempt to prevent reverse rotation. In an open-loop application, that is likely to prevent the motor from stopping altogether. To prevent reverse rotation, use the <a href="#">speed/frequency limits</a> in this parameter group, or parameters <a href="#">20.23/20.24</a>.</p> <p>See diagram at <a href="#">30.18 Minimum torque sel</a>.</p>	-300.0 % / real32
	-1600.0 ... 0.0 %	Minimum torque limit 2. For 16-bit scaling, see parameter <a href="#">46.3</a> .	- / 10 = 1 %
30.24	Maximum torque 2	<p>Defines the maximum torque limit for the drive (in percent of nominal motor torque) when</p> <ul style="list-style-type: none"> <li>the source selected by parameter <a href="#">30.25 Maximum torque sel</a> is 1, and</li> <li><a href="#">30.22</a> is set to <a href="#">Maximum torque 2</a>.</li> </ul> <p>See diagram at <a href="#">30.18 Minimum torque sel</a>.</p>	300.0 % / real32
	0.0 ... 1600.0 %	Maximum torque limit 2. For 16-bit scaling, see parameter <a href="#">46.3</a> .	- / 10 = 1 %
30.25	Maximum torque sel	<p>Selects a source that switches between two different maximum torque limits.</p> <p>0 = Maximum torque limit 1 defined by <a href="#">30.20</a> is active            1 = Maximum torque limit selected by <a href="#">30.22</a> is active</p> <p>See also parameter <a href="#">30.18 Minimum torque sel</a>.</p>	Maximum torque 1 / uint32
	Maximum torque 1	0.	0



No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	Maximum torque 2 source	1.	1
	DI1	Digital input DI1 (10.2 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.2 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.2 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.2 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.2 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.2 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1 (11.2 DIO delayed status, bit 0).	10
	DIO2	Digital input/output DIO2 (11.2 DIO delayed status, bit 1).	11
	Other [bit]	Source selection (see <a href="#">Terms and abbreviations (page 134)</a> ).	-
30.26	Power motoring limit	<p>Defines the maximum shaft power in motoring mode, ie. when power is being transferred from the motor to the machinery.</p> <p>The value is given in percent of nominal motor power.</p> <p><b>Note:</b> If nominal shaft torque is defined by parameter <a href="#">99.12 Motor nominal torque</a> then nominal shaft power is calculated according to parameters <a href="#">99.9 Motor nominal speed</a> and <a href="#">99.12 Motor nominal torque</a>.</p>	300.00 % / real32
	0.00 ... 600.00 %	Maximum shaft power in motoring mode.	1 = 1 % / 100 = 1 %
30.27	Power generating limit	<p>Defines the maximum shaft power in generating mode, ie. when power is being transferred from the machinery to the motor. The value is given in percent of nominal motor power.</p> <p><b>Note:</b> Do not set this parameter to 0% in an attempt to prevent reverse rotation. In an open-loop application, that is likely to prevent the motor from stopping altogether. To prevent reverse rotation, use the speed/frequency limits in this parameter group, or parameters <a href="#">20.23/20.24</a>.</p> <p><b>Note:</b> If nominal shaft torque is defined by parameter <a href="#">99.12 Motor nominal torque</a> then nominal shaft power is calculated according to parameters <a href="#">99.9 Motor nominal speed</a> and <a href="#">99.12 Motor nominal torque</a>.</p>	-300.00 % / real32
	-600.00 ... 0.00 %	Maximum shaft power in generating mode.	1 = 1 % / 100 = 1 %

## 346 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
30.30	Overvoltage control	<p>Enables the overvoltage control of the intermediate DC link.</p> <p>Fast braking of a high inertia load causes the voltage to rise to the overvoltage control limit. To prevent the DC voltage from exceeding the limit, the overvoltage controller automatically decreases the braking torque.</p> <p><b>Note:</b> With internal brake chopper, drive increases its internal overvoltage control limit to enable higher reliability in breaking.</p>	Enable / uint16
	Disable	Overvoltage control disabled.	0
	Enable	Overvoltage control enabled.	1
30.31	Undervoltage control	<p>Enables the undervoltage control of the intermediate DC link.</p> <p>If the DC voltage drops due to input power cut off, the undervoltage controller will automatically decrease the motor torque in order to keep the voltage above the lower limit. By decreasing the motor torque, the inertia of the load will cause regeneration back to the drive, keeping the DC link charged and preventing an undervoltage trip until the motor coasts to a stop. This will act as a power-loss ride-through functionality in systems with high inertia, such as a centrifuge or a fan.</p>	Enable / uint16
	Disable	Undervoltage control disabled.	0
	Enable	Undervoltage control enabled.	1
30.33	Motor RMS voltage limit	Defines the maximum motor RMS voltage limit.	10000.0 % / real32
	50.0 ... 10000.0 %	Maximum motor RMS voltage limit.	1 = 1 % / 1 = 1 %
30.35	Thermal current limitation	<p>Enables/disables temperature-based output current limitation.</p> <p>The limitation should only be disabled if required by the application.</p>	Enable / uint16
	Disable	Thermal current limitation disabled.	0
	Enable	Thermal current limitation enabled.	1
30.101	LSU limit word 1	<p><i>(Only visible when IGBT supply unit control activated by 95.20)</i></p> <p>Displays limit word 1 of the supply unit.</p> <p>This parameter is read-only.</p>	- / uint16
	b0 P user ref max	1 = Power reference is being limited by supply control program parameters	
	b1 P user ref min	1 = Power reference is being limited by supply control program parameters	
	b2 P user max	1 = Power is being limited by parameter <a href="#">30.149</a>	
	b3 P user min	1 = Power is being limited by parameter <a href="#">30.148</a>	

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
b4	P cooling overtemp	1 = Power reference is being limited because of coolant overtemperature	
b5	P power unit overtemp	1 = Power reference is being limited because of supply unit overtemperature	
b6...15	Reserved		
	0000h...FFFFh		1 = 1 / 1 = 1
30.102	LSU limit word 2	<i>(Only visible when IGBT supply unit control activated by 95.20)</i> Displays limit word 2 of the supply unit. This parameter is read-only.	- / uint16
b0	Q user ref max	1 = Reactive power reference is being limited	
b1	Q user ref min	1 = Reactive power reference is being limited	
b2	Q cooling overtemp	1 = Reactive power reference is being limited because of coolant overtemperature	
b3	Q power unit overtemp	1 = Reactive power reference is being limited because of supply unit overtemperature	
b4	AC overvoltage	1 = AC overvoltage protection	
b5...6	Reserved		
b7	AC diff max	1 = (When AC voltage-type reactive power reference is being used) Input of AC control is being limited	
b8	AC diff min	1 = (When AC voltage-type reactive power reference is being used) Input of AC control is being limited	
b9...15	Reserved		
	0000h...FFFFh		1 = 1 / 1 = 1
30.103	LSU limit word 3	<i>(Only visible when IGBT supply unit control activated by 95.20)</i> Displays limit word 3 of the supply unit. This parameter is read-only.	- / uint16
b0	Undervoltage limit	1 = Power is being limited by the undervoltage controller	
b1	Overvoltage limit	1 = Power is being limited by the overvoltage controller	
b2	Motoring power	1 = Power is being limited by temperature or user power limits (see parameters 30.148 and 30.149)	
b3	Generating power	1 = Power is being limited by temperature or user power limits (see parameters 30.148 and 30.149)	
b4	Active current limit	1 = Active current is being limited. For details, see bits 6...9 and 14...15.	
b5	Reactive current limit	1 = Reactive current is being limited. For details, see bits 12...13.	


## 348 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
b6	Thermal limit	1 = Active current is being limited by internal main circuit thermal limit	
b7	SOA limit	1 = Active current is being limited by internal safe operation area limit	
b8	User current limit	1 = Active current is being limited by current limit set by supply control program parameters	
b9	Thermal IGBT	1 = Active current is being limited based on internal maximum thermal IGBT stress limit	
b10...11	Reserved		
b12	Q act neg	1 = Negative reactive current is being limited by maximum total current	
b13	Q act pos	1 = Positive reactive current is being limited by maximum total current	
b14	P act neg	1 = Negative active current is being limited by maximum total current	
b15	P act pos	1 = Positive active current is being limited by maximum total current	
	0000h...FFFFh		1 = 1 / 1 = 1
30.104	LSU limit word 4	<i>(Only visible when IGBT supply unit control activated by 95.20)</i> Displays limit word 4 of the supply unit. This parameter is read-only.	- / uint16
b0	Udc ref max	1 = DC reference is being limited by supply control program parameters	
b1	Udc ref min	1 = DC reference is being limited by supply control program parameters	
b2	User I max	1 = Current is being limited by supply control program parameters	
b3	Temp I max	1 = Current is being limited based on temperature	
b4...15	Reserved		
	0000h...FFFFh		1 = 1 / 1 = 1
30.148	LSU minimum power limit	<i>(Only visible when IGBT supply unit control activated by 95.20)</i> Defines a minimum power limit for the supply unit. Negative values refer to regenerating, ie. feeding power into the supply network.	-200.0 % / real32
	-200.0 ... 0.0 %	Minimum power limit for supply unit.	1 = 1 % / 10 = 1 %
30.149	LSU maximum power limit	<i>(Only visible when IGBT supply unit control activated by 95.20)</i> Defines a maximum power limit for the supply unit.	200.0 % / real32
	0.0 ... 200.0 %	Maximum power limit for supply unit.	1 = 1 % / 10 = 1 %

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
<b>31</b>	<b>Fault functions</b>	Configuration of external events; selection of behavior of the drive upon fault situations.	
31.1	External event 1 source	Defines the source of external event 1. See also parameter <a href="#">31.2 External event 1 type</a> . 0 = Trigger event 1 = Normal operation	Inactive (true); DI6 (95.20 b8) / uint32
	Active (false)	0.	0
	Inactive (true)	1.	1
	DIIL	DIIL input ( <a href="#">10.2 DI delayed status</a> , bit 15).	2
	DI1	Digital input DI1 ( <a href="#">10.2 DI delayed status</a> , bit 0).	3
	DI2	Digital input DI2 ( <a href="#">10.2 DI delayed status</a> , bit 1).	4
	DI3	Digital input DI3 ( <a href="#">10.2 DI delayed status</a> , bit 2).	5
	DI4	Digital input DI4 ( <a href="#">10.2 DI delayed status</a> , bit 3).	6
	DI5	Digital input DI5 ( <a href="#">10.2 DI delayed status</a> , bit 4).	7
	DI6	Digital input DI6 ( <a href="#">10.2 DI delayed status</a> , bit 5).	8
	DIO1	Digital input/output DIO1 ( <a href="#">11.2 DIO delayed status</a> , bit 0).	11
	DIO2	Digital input/output DIO2 ( <a href="#">11.2 DIO delayed status</a> , bit 1).	12
	Other [bit]	Source selection (see <a href="#">Terms and abbreviations (page 134)</a> ).	-
31.2	External event 1 type	Selects the type of external event 1.	Fault (95.20 b8) / uint16
	Fault	The external event generates a fault.	0
	Warning	The external event generates a warning.	1
	Warning/Fault	If the drive is modulating, the external event generates a fault. Otherwise, the event generates a warning.	3
31.3	External event 2 source	Defines the source of external event 2. See also parameter <a href="#">31.4 External event 2 type</a> . For the selections, see parameter <a href="#">31.1 External event 1 source</a> .	Inactive (true); DIIL (95.20 b5) / uint32
31.4	External event 2 type	Selects the type of external event 2.	Fault / uint16
	Fault	The external event generates a fault.	0
	Warning	The external event generates a warning.	1
	Warning/Fault	If the drive is modulating, the external event generates a fault. Otherwise, the event generates a warning.	3

## 350 Parameters


No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
31.5	External event 3 source	Defines the source of external event 3. See also parameter <a href="#">31.6 External event 3 type</a> . For the selections, see parameter <a href="#">31.1 External event 1 source</a> .	Inactive (true) / uint32
31.6	External event 3 type	Selects the type of external event 3.	Fault / uint16
	Fault	The external event generates a fault.	0
	Warning	The external event generates a warning.	1
	Warning/Fault	If the drive is modulating, the external event generates a fault. Otherwise, the event generates a warning.	3
31.7	External event 4 source	Defines the source of external event 4. See also parameter <a href="#">31.8 External event 4 type</a> . For the selections, see parameter <a href="#">31.1 External event 1 source</a> .	Inactive (true) / uint32
31.8	External event 4 type	Selects the type of external event 4.	Fault / uint16
	Fault	The external event generates a fault.	0
	Warning	The external event generates a warning.	1
	Warning/Fault	If the drive is modulating, the external event generates a fault. Otherwise, the event generates a warning.	3
31.9	External event 5 source	Defines the source of external event 5. See also parameter <a href="#">31.10 External event 5 type</a> . For the selections, see parameter <a href="#">31.1 External event 1 source</a> .	Inactive (true) / uint32
31.10	External event 5 type	Selects the type of external event 5.	Fault / uint16
	Fault	The external event generates a fault.	0
	Warning	The external event generates a warning.	1
	Warning/Fault	If the drive is modulating, the external event generates a fault. Otherwise, the event generates a warning.	3
31.11	Fault reset selection	Selects the source of an external fault reset signal. This signal will be observed even if it is not the active source in the current control location (EXT1/EXT2/Local). (A reset from the active source will be observed regardless of this parameter.) 0 → 1 = Reset	DI3 / uint32
	Not selected	0	0
	Selected	1	1
	DI1	Digital input DI1 ( <a href="#">10.2 DI delayed status</a> , bit 0).	2

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	DI2	Digital input DI2 (10.2 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.2 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.2 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.2 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.2 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1 (11.2 DIO delayed status, bit 0).	10
	DIO2	Digital input/output DIO2 (11.2 DIO delayed status, bit 1).	11
	FBA A MCW bit 7	Control word bit 7 received through fieldbus interface A.	30
	EFB MCW bit 7	Control word bit 7 received through the embedded fieldbus interface.	32
	Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-
31.12	Autoreset selection	<p>Selects faults that are automatically reset. The parameter is a 16-bit word with each bit corresponding to a fault type.</p> <p>Whenever a bit is set to 1, the corresponding fault is automatically reset.</p> <p>The number and interval of reset attempts are defined by parameters <a href="#">31.14...31.16</a>.</p> <p> <b>WARNING!</b> Before you activate the function, make sure that no dangerous situations can occur. The function resets the drive automatically and continues operation after a fault.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>The autoreset function is only available in external control; see section <a href="#">Local control vs. external control (page 23)</a>.</li> <li>Faults related to the Safe torque off (STO) function cannot be automatically reset.</li> <li>In case bit 4 (Supply unit) is set and the inverter unit has tripped to <a href="#">7583 Line side unit faulted</a>, a reset command is given for both the inverter and supply units.</li> </ul> <p>The bits of this binary number correspond to the following faults:</p>	0000h / uint16
	b0	Overcurrent	
	b1	Overvoltage	
	b2	Undervoltage	
	b3	AI supervision fault	
	b4	Supply unit	

## 352 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
b5...7	Reserved		
b8	Application fault 1	Defined in the application program.	
b9	Application fault 2	Defined in the application program.	
b10	Selectable fault	See parameter <a href="#">31.13 User selectable fault</a> .	
b11	External fault 1	From source selected by parameter <a href="#">31.1 External event 1 source</a> .	
b12	External fault 2	From source selected by parameter <a href="#">31.3 External event 2 source</a> .	
b13	External fault 3	From source selected by parameter <a href="#">31.5 External event 3 source</a> .	
b14	External fault 4	From source selected by parameter <a href="#">31.7 External event 4 source</a> .	
b15	External fault 5	From source selected by parameter <a href="#">31.9 External event 5 source</a> .	
	0000h...FFFFh		1 = 1 / 1 = 1
31.13	User selectable fault	Defines the fault that can be automatically reset using parameter <a href="#">31.12 Autoreset selection</a> , bit 10. The faults are listed in chapter Fault tracing.	0 / uint32
	0000...FFFFh	Fault code.	1 = 1
31.14	Number of trials	Defines the maximum number of automatic resets that the drive is allowed to attempt within the time specified by <a href="#">31.15 Total trials time</a> .  If the fault persists, subsequent reset attempts will be made at intervals defined by <a href="#">31.16 Delay time</a> .  The faults to be automatically reset are defined by <a href="#">31.12 Autoreset selection</a> .	0 / uint32
	0...5	Number of automatic resets.	1 = 1 / 1 = 1
31.15	Total trials time	Defines a time window for automatic fault resets. The maximum number of attempts made during any period of this length is defined by <a href="#">31.14 Number of trials</a> .  <b>Note:</b> If the fault condition remains and cannot be reset, each reset attempt will generate an event and start a new time window. In practice, if the specified number of resets ( <a href="#">31.14</a> ) at specified intervals ( <a href="#">31.16</a> ) take longer than the value of <a href="#">31.15</a> , the drive will continue to attempt resetting the fault until the cause is eventually removed.	30.0 s / real32
	1.0 ... 600.0 s	Time for automatic resets.	10 = 1 s / 10 = 1 s
31.16	Delay time	Defines the time that the drive will wait after a fault (or a previous reset attempt) before attempting an automatic reset.  See parameter <a href="#">31.12 Autoreset selection</a> .	0.0 s / real32
	0.0 ... 120.0 s	Autoreset delay.	10 = 1 s / 10 = 1 s



No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
31.19	Motor phase loss	<p>Selects how the drive reacts when a motor phase loss is detected.</p> <p><b>Note:</b> The drive may not be able to reliably detect a phase loss in a multimotor application: a separate protection method (eg. a motor protection switch) should be installed for each motor.</p>	Fault / uint16
	No action	No action taken.	0
	Fault	The drive trips on fault <a href="#">3381 Output phase loss</a> .	1
31.20	Earth fault	<p>Selects how the drive reacts when an earth fault or current unbalance is detected in the motor or the motor cable.</p> <p>See also section <a href="#">Earth (Ground) fault detection (parameter 31.20)</a> (page 98).</p>	Fault / uint16
	No action	No action taken.	0
	Warning	The drive generates an <a href="#">A2B3 Earth leakage</a> warning.	1
	Fault	The drive trips on fault <a href="#">2330 Earth leakage</a> .	2
31.22	STO indication run/stop	<p>Selects which indications are given when both Safe torque off (STO) signals are switched off or lost. The indications also depend on whether the drive is running or stopped when this occurs.</p> <p>The tables at each selection below show the indications generated with that particular setting.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>This parameter does not affect the operation of the STO function itself. The STO function will operate regardless of the setting of this parameter: a running drive will stop upon removal of one or both STO signals, and will not start until both STO signals are restored and all faults reset.</li> <li>The loss of only one STO signal always generates a fault as it is interpreted as a malfunction.</li> <li>This parameter cannot be changed while the drive is running.</li> </ul> <p> <b>WARNING!</b> The drive cannot detect or memorize any changes in the STO circuitry when the drive control unit is not powered or when the main power to the drive is off. If both STO circuits are closed and a level-type start signal is active when the power is restored, it is possible that the drive starts without a fresh start command. Take this into account in the risk assessment of the system.</p> <p>For more information on the STO, see the Hardware manual of the drive.</p>	Fault/Fault / uint16


354 Parameters

No.	Name / Range / Selection	Description				Def / Type FbEq 16b / 32b	
	Fault/Fault	<b>Inputs</b>		<b>Indication (running or stopped)</b>	0		
		<b>IN1</b>	<b>IN2</b>				
		0	0	Fault 5091 Safe torque off			
		0	1	Faults 5091 Safe torque off and FA81 Safe torque off 1 loss			
		1	0	Faults 5091 Safe torque off and FA82 Safe torque off 2 loss			
		1	1	(Normal operation)			
	Fault/Warning	<b>Inputs</b>		<b>Indication</b>		1	
		<b>IN1</b>	<b>IN2</b>	<b>Running</b>	<b>Stopped</b>		
		0	0	Fault 5091 Safe torque off 5091 Safe torque off	Warning A5A0 Safe torque off		
		0	1	Faults 5091 Safe torque off and FA81 Safe torque off 1 loss	Warning A5A0 Safe torque off and fault FA81 Safe torque off 1 loss		
		1	0	Faults 5091 Safe torque off and FA82 Safe torque off 2 loss	Warning A5A0 Safe torque off and fault FA82 Safe torque off 2 loss		
		1	1	(Normal operation)			

No.	Name / Range / Selection	Description				Def / Type FbEq 16b / 32b	
	Fault/Event	<b>Inputs</b>		<b>Indication</b>		2	
		<b>IN1</b>	<b>IN2</b>	<b>Running</b>	<b>Stopped</b>		
		0	0	Fault 5091 Safe torque off	Event B5A0 STO event		
		0	1	Faults 5091 Safe torque off and FA81 Safe torque off 1 loss	Event B5A0 STO event and fault FA81 Safe torque off 1 loss		
		1	0	Faults 5091 Safe torque off and FA82 Safe torque off 2 loss	Event B5A0 STO event and fault FA82 Safe torque off 2 loss		
		1	1	(Normal operation)			
	Warning/Warning	<b>Inputs</b>		<b>Indication (run- ning or stopped)</b>		3	
		<b>IN1</b>	<b>IN2</b>				
		0	0	Warning A5A0 Safe torque off			
		0	1	Warning A5A0 Safe torque off and fault FA81 Safe torque off 1 loss			
		1	0	Warning A5A0 Safe torque off and fault FA82 Safe torque off 2 loss			
		1	1	(Normal operation)			

356 Parameters

No.	Name / Range / Selection	Description		Def / Type FbEq 16b / 32b																	
	Event/Event	<table border="1"> <thead> <tr> <th colspan="2" data-bbox="340 197 658 233">Inputs</th> <th data-bbox="658 197 818 268" rowspan="2">Indication (running or stopped)</th> </tr> <tr> <th data-bbox="340 233 500 268">IN1</th> <th data-bbox="500 233 658 268">IN2</th> </tr> </thead> <tbody> <tr> <td data-bbox="340 268 500 330">0</td> <td data-bbox="500 268 658 330">0</td> <td data-bbox="658 268 818 330">Event B5A0 STO event</td> </tr> <tr> <td data-bbox="340 330 500 435">0</td> <td data-bbox="500 330 658 435">1</td> <td data-bbox="658 330 818 435">Event B5A0 STO event and fault FA81 Safe torque off 1 loss</td> </tr> <tr> <td data-bbox="340 435 500 541">1</td> <td data-bbox="500 435 658 541">0</td> <td data-bbox="658 435 818 541">Event B5A0 STO event and fault FA82 Safe torque off 2 loss</td> </tr> <tr> <td data-bbox="340 541 500 603">1</td> <td data-bbox="500 541 658 603">1</td> <td data-bbox="658 541 818 603">(Normal operation)</td> </tr> </tbody> </table>		Inputs		Indication (running or stopped)	IN1	IN2	0	0	Event B5A0 STO event	0	1	Event B5A0 STO event and fault FA81 Safe torque off 1 loss	1	0	Event B5A0 STO event and fault FA82 Safe torque off 2 loss	1	1	(Normal operation)	4
Inputs		Indication (running or stopped)																			
IN1	IN2																				
0	0	Event B5A0 STO event																			
0	1	Event B5A0 STO event and fault FA81 Safe torque off 1 loss																			
1	0	Event B5A0 STO event and fault FA82 Safe torque off 2 loss																			
1	1	(Normal operation)																			
	No indication/No indication	<table border="1"> <thead> <tr> <th colspan="2" data-bbox="340 612 658 647">Inputs</th> <th data-bbox="658 612 818 683" rowspan="2">Indication (running or stopped)</th> </tr> <tr> <th data-bbox="340 647 500 683">IN1</th> <th data-bbox="500 647 658 683">IN2</th> </tr> </thead> <tbody> <tr> <td data-bbox="340 683 500 719">0</td> <td data-bbox="500 683 658 719">0</td> <td data-bbox="658 683 818 719">None</td> </tr> <tr> <td data-bbox="340 719 500 780">0</td> <td data-bbox="500 719 658 780">1</td> <td data-bbox="658 719 818 780">Fault FA81 Safe torque off 1 loss</td> </tr> <tr> <td data-bbox="340 780 500 841">1</td> <td data-bbox="500 780 658 841">0</td> <td data-bbox="658 780 818 841">Fault FA82 Safe torque off 2 loss</td> </tr> <tr> <td data-bbox="340 841 500 903">1</td> <td data-bbox="500 841 658 903">1</td> <td data-bbox="658 841 818 903">(Normal operation)</td> </tr> </tbody> </table>		Inputs		Indication (running or stopped)	IN1	IN2	0	0	None	0	1	Fault FA81 Safe torque off 1 loss	1	0	Fault FA82 Safe torque off 2 loss	1	1	(Normal operation)	5
Inputs		Indication (running or stopped)																			
IN1	IN2																				
0	0	None																			
0	1	Fault FA81 Safe torque off 1 loss																			
1	0	Fault FA82 Safe torque off 2 loss																			
1	1	(Normal operation)																			
31.23	Wiring or earth fault	<p>Selects how the drive reacts to incorrect input power and motor cable connection (i.e. input power cable is connected to drive motor connection).</p> <p><b>Note:</b> The protection must be disabled with drive/inverter hardware supplied from a common DC bus.</p>		Fault; No action (95.20 b15) / uint16																	
	No action	No action taken (protection disabled).		0																	
	Fault	The drive trips on fault 3181 Wiring or earth fault.		1																	
31.24	Stall function	<p>Selects how the drive reacts to a motor stall condition.</p> <p>A stall condition is defined as follows:</p> <ul style="list-style-type: none"> <li>The drive exceeds the stall current limit (31.25 Stall current limit), and</li> <li>the output frequency is below the level set by parameter 31.27 Stall frequency limit or the motor speed is below the level set by parameter 31.26 Stall speed limit, and</li> <li>the conditions above have been true longer than the time set by parameter 31.28 Stall time.</li> </ul>		Fault / uint16																	
	No action	None (stall supervision disabled).		0																	
	Warning	The drive generates an A780 Motor stall.		1																	

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	Fault	The drive trips on fault <a href="#">7121 Motor stall</a> .	2
31.25	Stall current limit	Stall current limit in percent of the nominal current of the motor. See parameter <a href="#">31.24 Stall function</a> .	200.0 % / real32
	0.0 ... 1600.0 %	Stall current limit.	10 = 1 % / 10 = 1 %
31.26	Stall speed limit	Stall speed limit in rpm. See parameter <a href="#">31.24 Stall function</a> .	150.00; 180.00 rpm (95.20 b0) rpm / real32
	0.00 ... 10000.00 rpm	Stall speed limit. For 16-bit scaling, see parameter <a href="#">46.1</a> .	- / 100 = 1 rpm
31.27	Stall frequency limit	Stall frequency limit. See parameter <a href="#">31.24 Stall function</a> .  <b>Note:</b> Setting the limit below 10 Hz is not recommended.	15.00; 18.00 Hz (95.20 b0) Hz / real32
	0.00 ... 500.00 Hz	Stall frequency limit. For 16-bit scaling, see parameter <a href="#">46.2</a> .	- / 100 = 1 Hz
31.28	Stall time	Stall time. See parameter <a href="#">31.24 Stall function</a> .	20 s / real32
	0...3600 s	Stall time.	1 = 1 s / 1 = 1 s
31.30	Overspeed trip margin	Defines, together with <a href="#">30.11 Minimum speed</a> and <a href="#">30.12 Maximum speed</a> , the maximum allowed speed of the motor (overspeed protection). If <a href="#">90.1 Motor speed for control</a> or the estimated speed exceeds the speed limit defined by parameter <a href="#">30.11</a> or <a href="#">30.12</a> by more than the value of this parameter, the drive trips on the <a href="#">7310 Overspeed</a> .  <b>Example:</b> If the maximum speed is 1420 rpm and speed trip margin is 300 rpm, the drive trips at 1720 rpm.  	500.00 rpm / real32
	0.00 ... 10000.00 rpm	Overspeed trip margin. For 16-bit scaling, see parameter <a href="#">46.1</a> .	- / 100 = 1 rpm

358 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
31.32	Emergency ramp supervision	<p>Parameters <a href="#">31.32 Emergency ramp supervision</a> and <a href="#">31.33 Emergency ramp supervision delay</a>, together with <a href="#">1.29 Speed change rate</a>, provide a supervision function for emergency stop modes Off1 and Off3.</p> <p>The supervision is based on either</p> <ul style="list-style-type: none"> <li>observing the time within which the motor stops, or</li> <li>comparing the actual and expected deceleration rates.</li> </ul> <p>If this parameter is set to 0%, the maximum stop time is directly set in parameter <a href="#">31.33</a>. Otherwise, <a href="#">31.32</a> defines the maximum allowed deviation from the expected deceleration rate, which is calculated from parameters <a href="#">23.11...23.19</a></p> <p>If <a href="#">31.32</a> is set to 0% and <a href="#">31.33</a> is set to 0 s, the emergency stop ramp supervision is disabled.</p>	- / real32
	0...300 %	Maximum deviation from expected deceleration rate.	1 = 1 % / 1 = 1 %
31.33	Emergency ramp supervision delay	<p>If parameter <a href="#">31.32 Emergency ramp supervision</a> is set to 0%, this parameter defines the maximum time an emergency stop (mode Off1 or Off3) is allowed to take. If the motor has not stopped when the time elapses, the drive trips on <a href="#">73B0 Emergency ramp failed</a>, sets bit 8 of <a href="#">6.17 Drive status word 2</a>, and coasts to a stop.</p> <p>If <a href="#">31.32</a> is set to a value other than 0%, this parameter defines a delay between the receipt of the emergency stop command and the activation of the supervision. It is recommended to specify a short delay to allow the speed change rate to stabilize.</p>	- / real32
	0...32767 s	Maximum ramp-down time, or supervision activation delay.	1 = 1 s / 1 = 1 s
31.35	Main fan fault function	<p>Selects how the drive reacts when a main cooling fan fault is detected.</p> <p><b>Note:</b> With an inverter unit consisting of one or more frame R8i inverter modules with speed-controlled fans, it may be possible to continue operation even if one main fan of a module stops. When fan failure is detected, the control program will automatically</p> <ul style="list-style-type: none"> <li>set the other fan of the module to full speed</li> <li>set the fans of the other modules (if any) to full speed</li> <li>decrease the switching frequency to a minimum, and</li> <li>disable the supervision of temperature difference between the modules.</li> </ul> <p>If this parameter is set to <a href="#">Fault</a>, the inverter unit will trip (but still carry out the actions listed above). Otherwise, the inverter will attempt to continue operation.</p> <p>This parameter has no effect with Liquid cooled (LC) inverters and drives. Set parameter <a href="#">206.07 Fan speed fault limit</a> to zero to disable fault in LC units.</p>	Warning / uint16
	Fault	The drive trips on fault <a href="#">5080 Fan</a> .	0

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	Warning	The drive generates an <a href="#">A581 Fan</a> .	1
	No action	No action taken.	2
31.36	Aux fan fault function	<i>(Only visible with a ZCU control unit)</i> Selects how the drive reacts when a modules internal auxiliary fan fault is detected.	Fault / uint16
	Fault	The drive trips on fault <a href="#">5081 Auxiliary fan not running</a> .  <b>Note:</b> The fault is suppressed for two minutes after power-up.  During this time, the drive only generates a warning, <a href="#">A582 Auxiliary fan not running</a> .	0
	Warning	The drive generates a warning, <a href="#">A582 Auxiliary fan not running</a> .	1
31.37	Ramp stop supervision	Parameters <a href="#">31.37 Ramp stop supervision</a> and <a href="#">31.38 Ramp stop supervision delay</a> , together with <a href="#">1.29 Speed change rate</a> , provide a supervision function for normal (ie. nonemergency) ramp stopping.  The supervision is based on either <ul style="list-style-type: none"> <li>observing the time within which the motor stops, or</li> <li>comparing the actual and expected deceleration rates.</li> </ul> If this parameter is set to 0%, the maximum stop time is directly set in parameter <a href="#">31.38</a> . Otherwise, <a href="#">31.37</a> defines the maximum allowed deviation from the expected deceleration rate, which is calculated from parameters <a href="#">23.11...23.19</a> . If the actual deceleration rate ( <a href="#">1.29</a> ) deviates too much from the expected rate, the drive trips on <a href="#">73B1 Stop failed</a> , sets bit 14 of <a href="#">6.17 Drive status word 2</a> , and coasts to a stop.  If <a href="#">31.37</a> is set to 0% and <a href="#">31.38</a> is set to 0 s, the ramp stop supervision is disabled.	- / real32
	0...300 %	Maximum deviation from expected deceleration rate.	1 = 1 % / 0 = 1 %
31.38	Ramp stop supervision delay	If parameter <a href="#">31.37 Ramp stop supervision</a> is set to 0%, this parameter defines the maximum time a ramp stop is allowed to take. If the motor has not stopped when the time elapses, the drive trips on <a href="#">73B1 Stop failed</a> , sets bit 14 of <a href="#">6.17 Drive status word 2</a> , and coasts to a stop.  If <a href="#">31.37</a> is set to a value other than 0%, this parameter defines a delay between the receipt of the stop command and the activation of the supervision. It is recommended to specify a short delay to allow the speed change rate to stabilize.	0 s / real32
	0...32767 s	Maximum ramp-down time, or supervision activation delay.	1 = 1 s / 1 = 1 s

## 360 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
31.40	Disable warning messages	<p>Selects warnings to be suppressed. The parameter is a 16-bit word with each bit corresponding to a warning. Whenever a bit is set to 1, the corresponding warning is suppressed.</p> <p>The bits of this binary number correspond to the following warnings:</p>	- / uint16
b0	Overvoltage	<a href="#">A3A1 DC link overvoltage</a>	
b1	Reserved		
b2	Encoder 1	<a href="#">A7E1 Encoder</a> (for encoder 1)	
b3	Encoder 2	<a href="#">A7E1 Encoder</a> (for encoder 2)	
b4	CU Battery	<a href="#">A5F4 Control unit battery</a>	
b5	EmergencyStop Off2	<a href="#">AFE1 Emergency stop (off2)</a>	
b6	EmergencyStop Off1 Off3	<a href="#">AFE2 Emergency stop (off1 or off3)</a>	
b7...15	Reserved		
	0000h...FFFFh		1 = 1 / 1 = 1
31.42	Overcurrent fault limit	<p>Sets a custom motor current fault limit.</p> <p>The drive automatically sets an internal motor current limit according to the drive hardware. The internal limit is appropriate in most cases, but this parameter can be used to set a lower current limit, for example, to protect a permanent magnet motor from demagnetization.</p> <p><b>Note:</b> The limit defines the maximum peak current of one phase.</p> <p>With this parameter at 0.0 A, only the internal limit is in force.</p>	0.00 A / real32
	0.00 ... 30000.00 A	Custom motor current fault limit. For 16-bit scaling, see parameter <a href="#">46.5</a> .	- / 100 = 1 A
31.54	Fault action	Selects the stop mode when a non-critical fault occurs.	Coast / uint16
	Coast	The drive coasts to a stop.	0
	Emergency ramp	The drive follows the ramp specified for an emergency stop in parameter <a href="#">23.23 Emergency stop time</a> .	1
31.55	Ext I/O comm loss event	Selects how the drive reacts when the communication to an I/O extension module fails.	Fault / uint16
	No action	No action taken.	0
	Warning	The drive generates a warning, <a href="#">A799 ExtI/O comm loss</a> .	1
	Fault	The drive trips on a fault, <a href="#">7082 Ext I/O comm loss</a> .	2



No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
31.120	LSU earth fault	<i>(Only visible when IGBT supply unit control activated by 95.20)</i> Selects how the supply unit reacts when an earth fault or current unbalance is detected.	Fault / uint16
	No action	No action taken.	0
	Warning	The supply unit generates a warning <a href="#">AE02 Earth leakage</a> .	1
	Fault	The supply unit trips on a fault, <a href="#">2E01 Earth leakage</a> .	2
31.121	LSU supply phase loss	<i>(Only visible when IGBT supply unit control activated by 95.20)</i> Selects how the supply unit reacts when a supply phase loss is detected.	Fault / uint16
	No action	No action taken.	0
	Fault	The supply unit trips on a fault, <a href="#">3E00 Input phase loss</a> .	1

## 362 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
32	Supervision	Configuration of signal supervision functions 1...3. Three values can be chosen to be monitored; a warning or fault is generated whenever predefined limits are exceeded. See also section <a href="#">Signal supervision (page 100)</a> .	
32.1	Supervision status	Signal supervision status word. Indicates whether the values monitored by the signal supervision functions are within or outside their respective limits. <b>Note:</b> This word is independent of the drive actions defined by parameters <a href="#">32.6</a> , <a href="#">32.16</a> and <a href="#">32.26</a> .	- / uint16
b0	Supervision 1 active	1 = Signal selected by <a href="#">32.7</a> is outside its limits.	
b1	Supervision 2 active	1 = Signal selected by <a href="#">32.17</a> is outside its limits.	
b2	Supervision 3 active	1 = Signal selected by <a href="#">32.27</a> is outside its limits.	
b3...15	Reserved		
	0000h...FFFFh		1 = 1 / 1 = 1
32.5	Supervision 1 function	Selects the mode of signal supervision function 1. Determines how the monitored signal (see parameter <a href="#">32.7</a> ) is compared to its lower and upper limits ( <a href="#">32.9</a> and <a href="#">32.10</a> respectively). The action to be taken when the condition is fulfilled is selected by <a href="#">32.6</a> .	Disabled / uint16
	Disabled	Signal supervision 1 not in use.	0
	Low	Action is taken whenever the signal falls below its lower limit.	1
	High	Action is taken whenever the signal rises above its upper limit.	2
	Abs low	Action is taken whenever the absolute value of the signal falls below its (absolute) lower limit.	3
	Abs high	Action is taken whenever the absolute value of the signal rises above its (absolute) upper limit.	4
	Both	Action is taken whenever the signal falls below its low limit or rises above its high limit.	5
	Abs both	Action is taken whenever the absolute value of the signal falls below its (absolute) low limit or rises above its (absolute) high limit.	6
32.6	Supervision 1 action	Selects the action the drive takes when the value monitored by signal supervision 1 exceeds its limits. <b>Note:</b> This parameter does not affect the status indicated by <a href="#">32.1 Supervision status</a> .	No action / uint16
	No action	No action taken.	0
	Warning	A warning ( <a href="#">A8B0 Signal supervision</a> ) is generated.	1

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	Fault	The drive trips on <a href="#">80B0 Signal supervision</a> .	2
	Fault if running	If running, the drive trips on <a href="#">80B0 Signal supervision</a> .	3
32.7	Supervision 1 signal	Selects the signal to be monitored by signal supervision function 1.	Zero / uint32
	Zero	None.	0
	Speed	<a href="#">1.1 Motor speed used</a> .	1
	Frequency	<a href="#">1.6 Output frequency</a> .	3
	Current	<a href="#">1.7 Motor current</a> .	4
	Torque	<a href="#">1.10 Motor torque</a> .	6
	DC voltage	<a href="#">1.11 DC voltage</a> .	7
	Output power	<a href="#">1.14 Output power</a> .	8
	AI1	<a href="#">12.11 AI1 actual value</a> .	9
	AI2	<a href="#">12.21 AI2 actual value (page 202)</a> .	10
	Speed ref ramp in	<a href="#">23.1 Speed ref ramp input (page 288)</a> .	18
	Speed ref ramp out	<a href="#">23.2 Speed ref ramp output (page 288)</a> .	19
	Speed ref used	<a href="#">24.1 Used speed reference (page 295)</a> .	20
	Torque ref used	<a href="#">26.2 Torque reference used (page 314)</a> .	21
	Freq ref used	<a href="#">28.2 Frequency ref ramp output (page 323)</a> .	22
	Process PID Output	<a href="#">40.1 Process PID output actual (page 399)</a> .	24
	Process PID feedback	<a href="#">40.2 Process PID feedback actual (page 399)</a> .	25
	Other [bit]	Source selection (see <a href="#">Terms and abbreviations (page 134)</a> ).	-
32.8	Supervision 1 filter time	Defines a filter time constant for the signal monitored by signal supervision 1.	0.000 s / real32
	0.000 ... 30.000 s	Signal filter time.	1000 = 1 s / 1000 = 1 s
32.9	Supervision 1 low	Defines the lower limit for signal supervision 1.	0.00 / real32
	-21474830.00 ... 21474830.00	Low limit.	- / 100 = 1
32.10	Supervision 1 high	Defines the upper limit for signal supervision 1.	0.00 / real32
	-21474830.00 ... 21474830.00	Upper limit.	- / 100 = 1
32.15	Supervision 2 function	Selects the mode of signal supervision function 2. Determines how the monitored signal (see parameter <a href="#">32.17</a> ) is compared to its lower and upper limits ( <a href="#">32.19</a> and <a href="#">32.20</a> respectively). The action to be taken when the condition is fulfilled is selected by <a href="#">32.16</a> .	Disabled / uint16
	Disabled	Signal supervision 2 not in use.	0

## 364 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	Low	Action is taken whenever the signal falls below its lower limit.	1
	High	Action is taken whenever the signal rises above its upper limit.	2
	Abs low	Action is taken whenever the absolute value of the signal falls below its (absolute) lower limit.	3
	Abs high	Action is taken whenever the absolute value of the signal rises above its (absolute) upper limit.	4
	Both	Action is taken whenever the signal falls below its low limit or rises above its high limit.	5
	Abs both	Action is taken whenever the absolute value of the signal falls below its (absolute) low limit or rises above its (absolute) high limit.	6
32.16	Supervision 2 action	Selects the action the drive takes when the value monitored by signal supervision 2 exceeds its limits.  <b>Note:</b> This parameter does not affect the status indicated by <a href="#">32.1 Supervision status</a> .	No action / uint16
	No action	No action taken.	0
	Warning	A warning ( <a href="#">A8B1 Signal supervision 2</a> ) is generated.	1
	Fault	The drive trips on <a href="#">80B1 Signal supervision 2</a> .	2
	Fault if running	If running, the drive trips on <a href="#">80B1 Signal supervision 2</a> .	3
32.17	Supervision 2 signal	Selects the signal to be monitored by signal supervision function 2.  For the available selections, see parameter <a href="#">32.7 Supervision 1 signal</a> .	Zero / uint32
32.18	Supervision 2 filter time	Defines a filter time constant for the signal monitored by signal supervision 2.	0.000 s / real32
	0.000 ... 30.000 s	Signal filter time.	1000 = 1 s / 1000 = 1 s
32.19	Supervision 2 low	Defines the lower limit for signal supervision 2.	0.00 / real32
	-21474830.00 ... 21474830.00	Low limit.	- / 100 = 1
32.20	Supervision 2 high	Defines the upper limit for signal supervision 2.	0.00 / real32
	-21474830.00 ... 21474830.00	Upper limit.	- / 100 = 1
32.25	Supervision 3 function	Selects the mode of signal supervision function 3. Determines how the monitored signal (see parameter <a href="#">32.27</a> ) is compared to its lower and upper limits ( <a href="#">32.29</a> and <a href="#">32.30</a> respectively).  The action to be taken when the condition is fulfilled is selected by <a href="#">32.26</a> .	Disabled / uint16
	Disabled	Signal supervision 3 not in use.	0

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	Low	Action is taken whenever the signal falls below its lower limit.	1
	High	Action is taken whenever the signal rises above its upper limit.	2
	Abs low	Action is taken whenever the absolute value of the signal falls below its (absolute) lower limit.	3
	Abs high	Action is taken whenever the absolute value of the signal rises above its (absolute) upper limit.	4
	Both	Action is taken whenever the signal falls below its low limit or rises above its high limit.	5
	Abs both	Action is taken whenever the absolute value of the signal falls below its (absolute) low limit or rises above its (absolute) high limit.	6
32.26	Supervision 3 action	Selects the action the drive takes when the value monitored by signal supervision 3 exceeds its limits.  <b>Note:</b> This parameter does not affect the status indicated by <a href="#">32.1 Supervision status</a> .	No action / uint16
	No action	No action taken.	0
	Warning	A warning ( <a href="#">A8B2 Signal supervision 3</a> ) is generated.	1
	Fault	The drive trips on <a href="#">80B2 Signal supervision 3</a> .	2
	Fault if running	If running, the drive trips on <a href="#">80B2 Signal supervision 3</a> .	3
32.27	Supervision 3 signal	Selects the signal to be monitored by signal supervision function 3.  For the available selections, see parameter <a href="#">32.7 Supervision 1 signal</a> .	Zero / uint32
32.28	Supervision 3 filter time	Defines a filter time constant for the signal monitored by signal supervision 3.	0.000 s / real32
	0.000 ... 30.000 s	Signal filter time.	1000 = 1 s / 1000 = 1 s
32.29	Supervision 3 low	Defines the lower limit for signal supervision 3.	0.00 / real32
	-21474830.00 ... 21474830.00	Low limit.	- / 100 = 1
32.30	Supervision 3 high	Defines the upper limit for signal supervision 3.	0.00 / real32
	-21474830.00 ... 21474830.00	Upper limit.	- / 100 = 1

## 366 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
<b>33</b>	Generic timer & counter	Configuration of maintenance timers/counters. See also section <a href="#">Maintenance timers and counters (page 100)</a> .	
33.1	Counter status	Displays the maintenance timer/counter status word, indicating which maintenance timers/counters have exceeded their limits.  This parameter is read-only.	- / uint16
b0	On-time 1	1 = On-time timer 1 has reached its preset limit.	
b1	On-time 2	1 = On-time timer 2 has reached its preset limit.	
b2	Edge 1	1 = Signal edge counter 1 has reached its preset limit.	
b3	Edge 2	1 = Signal edge counter 2 has reached its preset limit.	
b4	Value 1	1 = Value counter 1 has reached its preset limit.	
b5	Value 2	1 = Value counter 2 has reached its preset limit.	
b6...15	Reserved		
	0000h...FFFFh		1 = 1 / 1 = 1
33.10	On-time 1 actual	Displays the actual present value of on-time timer 1.  The timer runs whenever the signal selected by parameter <a href="#">33.13 On-time 1 source</a> is on.  When the timer exceeds the limit set by <a href="#">33.11 On-time 1 warn limit</a> , bit 0 of <a href="#">33.1 Counter status</a> is set to 1. The warning specified by <a href="#">33.14 On-time 1 warn message</a> is also given if enabled by <a href="#">33.12 On-time 1 function</a> .  The timer can be reset from the Drive Composer PC tool, or from the control panel by keeping Reset depressed for over 3 seconds.	- / uint32
	0...4294967295 s	Actual present value of on-time timer 1.	- / 1 = 1 s
33.11	On-time 1 warn limit	Sets the warning limit for on-time timer 1.	- / uint32
	0...4294967295 s	Warning limit for on-time timer 1.	- / 1 = 1 s
33.12	On-time 1 function	Configures on-time timer 1.	- / uint16
b0	Counter mode	0 = Loop: When the limit is reached, the counter is reset. The counter status (bit 0 of <a href="#">33.1</a> ) switches to 1 for one second. The warning (if enabled) stays active for at least 10 seconds.  1 = Saturate: When the limit is reached, the counter status (bit 0 of <a href="#">33.1</a> ) switches to 1, and remains so until <a href="#">33.10</a> is reset. The warning (if enabled) also stays active until <a href="#">33.10</a> is reset.	
b1	Warning enable	0 = Disable: No warning is given when the limit is reached  1 = Enable: A warning (see <a href="#">33.14</a> ) is given when the limit is reached	
b2...15	Reserved		

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	0000h...FFFFh		1 = 1 / 1 = 1
33.13	On-time 1 source	Selects the signal to be monitored by on-time timer 1.	False / uint32
	False	Constant 0 (timer disabled).	0
	True	Constant 1.	1
	RO1	Bit 0 of <a href="#">10.21 RO status (page 185)</a> .	2
	Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-
33.14	On-time 1 warn message	Selects the optional warning message for on-time timer 1.	On-time 1 exceeded / uint32
	On-time 1 exceeded	<a href="#">A886 On-Time 1</a> . The message text can be edited on the control panel by choosing Menu – Settings – Edit texts.	0
	Clean device	<a href="#">A88C Device clean</a> .	6
	Maintain additional cooling fan	<a href="#">A890 Additional cooling fan</a> .	7
	Maintain cabinet fan	<a href="#">A88E Cabinet fan</a> .	8
	Maintain DC capacitors	<a href="#">A88D DC capacitor</a> .	9
	Maintain motor bearing	<a href="#">A880 Motor bearing</a> .	10
33.20	On-time 2 actual	Displays the actual present value of on-time timer 2.  The timer runs whenever the signal selected by parameter <a href="#">33.23 On-time 2 source</a> is on.  When the timer exceeds the limit set by <a href="#">33.21 On-time 2 warn limit</a> , bit 1 of <a href="#">33.1 Counter status</a> is set to 1. The warning specified by <a href="#">33.24 On-time 2 warn message</a> is also given if enabled by <a href="#">33.22 On-time 2 function</a> .  The timer can be reset from the Drive Composer PC tool, or from the control panel by keeping Reset depressed for over 3 seconds.	- / uint32
	0...4294967295 s	Actual present value of on-time timer 2.	- / 1 = 1 s
33.21	On-time 2 warn limit	Sets the warning limit for on-time timer 2.	- / uint32
	0...4294967295 s	Warning limit for on-time timer 2.	- / 1 = 1 s
33.22	On-time 2 function	Configures on-time timer 2.	- / uint16
	b0 Counter mode	0 = Loop: When the limit is reached, the counter is reset. The counter status (bit 1 of <a href="#">33.1</a> ) switches to 1 for one second. The warning (if enabled) stays active for at least 10 seconds.  1 = Saturate: When the limit is reached, the counter status (bit 1 of <a href="#">33.1</a> ) switches to 1, and remains so until <a href="#">33.20</a> is reset. The warning (if enabled) also stays active until <a href="#">33.20</a> is reset.	

## 368 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
b1	Warning enable	0 = Disable: No warning is given when the limit is reached  1 = Enable: A warning (see 33.24) is given when the limit is reached	
b2...15	Reserved		
	0000h...FFFFh		1 = 1 / 1 = 1
33.23	On-time 2 source	Selects the signal to be monitored by on-time timer 2.	False / uint32
	False	Constant 0 (timer disabled).	0
	True	Constant 1.	1
	RO1	Bit 0 of 10.21 RO status (page 185).	2
	Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-
33.24	On-time 2 warn message	Selects the optional warning message for on-time timer 2.	On-time 2 exceeded / uint32
	On-time 2 exceeded	<a href="#">A887 On-Time 2</a> . The message text can be edited on the control panel by choosing Menu – Settings – Edit texts.	1
	Clean device	<a href="#">A88C Device clean</a> .	6
	Maintain additional cooling fan	<a href="#">A890 Additional cooling fan</a> .	7
	Maintain cabinet fan	<a href="#">A88E Cabinet fan</a> .	8
	Maintain DC capacitors	<a href="#">A88D DC capacitor</a> .	9
	Maintain motor bearing	<a href="#">A880 Motor bearing</a> .	10
33.30	Edge counter 1 actual	Actual present value of signal edge counter 1.  The counter is incremented every time the signal selected by parameter <a href="#">33.33 Edge counter 1 source</a> switches on or off (or either, depending on the setting of <a href="#">33.32 Edge counter 1 function</a> ). A divisor may be applied to the count (see <a href="#">33.34 Edge counter 1 divider</a> ).  When the counter exceeds the limit set by <a href="#">33.31 Edge counter 1 warn limit</a> , bit 2 of <a href="#">33.1 Counter status</a> is set to 1. The warning specified by <a href="#">33.35 Edge counter 1 warn message</a> is also given if enabled by <a href="#">33.32 Edge counter 1 function</a> .  The counter can be reset from the Drive Composer PC tool, or from the control panel by keeping Reset depressed for over 3 seconds.	- / uint32
	0...4294967295	Actual present value of signal edge counter 1.	- / 1 = 1
33.31	Edge counter 1 warn limit	Sets the warning limit for signal edge counter 1.	- / uint32
	0...4294967295	Warning limit for signal edge counter 1.	- / 1 = 1



No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
33.32	Edge counter 1 function	Configures signal edge counter 1.	- / uint16
b0	Counter mode	0 = Loop: When the limit is reached, the counter is reset. The counter status (bit 2 of 33.1) switches to 1 and remains so until the counter is again incremented. The warning (if enabled) stays active for at least 10 seconds.  1 = Saturate: When the limit is reached, the counter status (bit 2 of 33.1) switches to 1, and remains so until 33.30 is reset. The warning (if enabled) also stays active until 33.30 is reset.	
b1	Warning enable	0 = Disable: No warning is given when the limit is reached  1 = Enable: A warning (see 33.35) is given when the limit is reached	
b2	Count rising edges	Count rising edges  0 = Disable: Rising edges are not counted 1 = Enable: Rising edges are counted	
b3	Count falling edges	Count falling edges  0 = Disable: Falling edges are not counted 1 = Enable: Falling edges are counted	
b4...15	Reserved		
	0000h...FFFFh		1 = 1 / 1 = 1
33.33	Edge counter 1 source	Selects the signal to be monitored by signal edge counter 1.	False / uint32
	False	Constant 0.	0
	True	Constant 1.	1
	RO1	Bit 0 of 10.21 RO status (page 185).	2
	Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-
33.34	Edge counter 1 divider	Defines a divisor for signal edge counter 1. Determines how many signal edges increment the counter by 1.	1 / uint32
	1...2147483647	Divisor for signal edge counter 1.	- / 1 = 1
33.35	Edge counter 1 warn message	Selects the optional warning message for signal edge counter 1.	Edge counter 1 exceeded / uint32
	Edge counter 1 exceeded	<a href="#">A888 Edge counter 1</a> . The message text can be edited on the control panel by choosing Menu – Settings – Edit texts.	2
	Counted main contactor	<a href="#">A884 Main contactor</a> .	11
	Counted output relay	<a href="#">A881 Output relay</a> .	12
	Counted motor starts	<a href="#">A882 Motor starts</a> .	13

## 370 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	Counted power ups	A883 Power ups.	14
	Counted DC charges	A885 DC charge.	15
33.40	Edge counter 2 actual	<p>Displays the actual present value of signal edge counter 2.</p> <p>The counter is incremented every time the signal selected by parameter <a href="#">33.43 Edge counter 2 source</a> switches on or off (or either, depending on the setting of <a href="#">33.42 Edge counter 2 function</a>). A divisor may be applied to the count (see <a href="#">33.44 Edge counter 2 divider</a>).</p> <p>When the counter exceeds the limit set by <a href="#">33.41 Edge counter 2 warn limit</a>, bit 3 of <a href="#">33.1 Counter status</a> is set to 1. The warning specified by <a href="#">33.45 Edge counter 2 warn message</a> is also given if enabled by <a href="#">33.42 Edge counter 2 function</a>.</p> <p>The counter can be reset from the Drive Composer PC tool, or from the control panel by keeping Reset depressed for over 3 seconds.</p>	- / uint32
	0...4294967295	Actual present value of signal edge counter 2.	- / 1 = 1
33.41	Edge counter 2 warn limit	Sets the warning limit for signal edge counter 2.	- / uint32
	0...4294967295	Warning limit for signal edge counter 2.	- / 1 = 1
33.42	Edge counter 2 function	Configures signal edge counter 2.	- / uint16
b0	Counter mode	<p>0 = Loop: When the limit is reached, the counter is reset. The counter status (bit 3 of <a href="#">33.1</a>) remains 1 until the counter is again incremented. The warning (if enabled) stays active for at least 10 seconds.</p> <p>1 = Saturate: After the limit is reached, the counter status (bit 3 of <a href="#">33.1</a>) remains 1 until <a href="#">33.40</a> is reset. The warning (if enabled) also stays active until <a href="#">33.40</a> is reset.</p>	
b1	Warning enable	<p>Warning enable</p> <p>0 = Disable: No warning is given when the limit is reached</p> <p>1 = Enable: A warning (see <a href="#">33.45</a>) is given when the limit is reached</p>	
b2	Count rising edges	<p>Count rising edges</p> <p>0 = Disable: Rising edges are not counted</p> <p>1 = Enable: Rising edges are counted</p>	
b3	Count falling edges	<p>Count falling edges</p> <p>0 = Disable: Falling edges are not counted</p> <p>1 = Enable: Falling edges are counted</p>	
b4...15	Reserved		
	0000h...FFFFh		1 = 1 / 1 = 1

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
33.43	Edge counter 2 source	Selects the signal to be monitored by signal edge counter 2.	False / uint32
	False	0.	0
	True	1.	1
	RO1	Bit 0 of <a href="#">10.21 RO status (page 185)</a> .	2
	Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-
33.44	Edge counter 2 divider	Defines a divisor for signal edge counter 2. Determines how many signal edges increment the counter by 1.	1 / uint32
	1...4294967295	Divisor for signal edge counter 2.	- / 1 = 1
33.45	Edge counter 2 warn message	Selects the optional warning message for signal edge counter 2.	Edge counter 2 exceeded / uint32
	Edge counter 2 exceeded	<a href="#">A889 Edge counter 2</a> . The message text can be edited on the control panel by choosing Menu – Settings – Edit texts.	3
	Counted main contactor	<a href="#">A884 Main contactor</a> .	11
	Counted output relay	<a href="#">A881 Output relay</a> .	12
	Counted motor starts	<a href="#">A882 Motor starts</a> .	13
	Counted power ups	<a href="#">A883 Power ups</a> .	14
	Counted DC charges	<a href="#">A885 DC charge</a> .	15
33.50	Value counter 1 actual	Displays the actual present value of value counter 1.  The value of the source selected by parameter <a href="#">33.53 Value counter 1 source</a> is read at one-second intervals and added to the counter. A divisor can be applied to the count (see <a href="#">33.54 Value counter 1 divider</a> ).  When the counter exceeds the limit set by <a href="#">33.51 Value counter 1 warn limit</a> , bit 4 of <a href="#">33.1 Counter status</a> is set to 1.  The warning specified by <a href="#">33.55 Value counter 1 warn message</a> is also given if enabled by <a href="#">33.52 Value counter 1 function</a> .  The counter can be reset from the Drive Composer PC tool, or from the control panel by keeping Reset depressed for over 3 seconds.	0 / real32
	-2147483000,2147483000	Actual present value of value counter 1.	- / 1 = 1

## 372 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
33.51	Value counter 1 warn limit	Sets the limit for value counter 1.  With a positive limit, bit 4 of <a href="#">33.1 Counter status</a> is set to 1 (and a warning optionally generated) when the counter is equal or greater than the limit.  With a negative limit, bit 4 of <a href="#">33.1 Counter status</a> is set to 1 (and a warning optionally generated) when the counter is equal or smaller than the limit.  0 = Counter disabled.	- / real32
	-2147483000..2147483000	Limit for value counter 1.	- / 1 = 1
33.52	Value counter 1 function	Configures value counter 1.	- / uint16
b0	Counter mode	0 = Loop: When the limit is reached, the counter is reset. The counter status (bit 4 of <a href="#">33.1</a> ) switches to 1 for one second. The warning (if enabled) stays active for at least 10 seconds.  1 = Saturate: When the limit is reached, the counter status (bit 4 of <a href="#">33.1</a> ) switches to 1, and remains so until <a href="#">33.50</a> is reset. The warning (if enabled) also stays active until <a href="#">33.50</a> is reset.	
b1	Warning enable	0 = Disable: No warning is given when the limit is reached  1 = Enable: A warning (see <a href="#">33.55</a> ) is given when the limit is reached	
b2...15	Reserved		
	0000h...FFFFh		1 = 1 / 1 = 1
33.53	Value counter 1 source	Selects the signal to be monitored by value counter 1.	Not selected / uint32
	Not selected	None (counter disabled).	0
	Motor speed	<a href="#">1.1 Motor speed used</a> .	1
	Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-
33.54	Value counter 1 divider	Defines a divisor for value counter 1. The value of the monitored signal is divided by this value before integration.	1.000 / real32
	0.001 ... 2147483.000	Divisor for value counter 1.	- / 1 = 1
33.55	Value counter 1 warn message	Selects the optional warning message for value counter 1.	Value counter 1 exceeded / uint32
	Value counter 1 exceeded	<a href="#">A88A Value counter 1</a> . The message text can be edited on the control panel by choosing Menu – Settings – Edit texts.	4
	Maintain motor bearing	<a href="#">A880 Motor bearing</a> .	10

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
33.60	Value counter 2 actual	<p>Displays the actual present value of value counter 2.</p> <p>The value of the source selected by parameter <a href="#">33.63 Value counter 2 source</a> is read at one-second intervals and added to the counter. A divisor can be applied to the count (see <a href="#">33.64 Value counter 2 divider</a>).</p> <p>When the counter exceeds the limit set by <a href="#">33.61 Value counter 2 warn limit</a>, bit 5 of <a href="#">33.1 Counter status</a> is set to 1.</p> <p>The warning specified by <a href="#">33.65 Value counter 2 warn message</a> is also given if enabled by <a href="#">33.62 Value counter 2 function</a>.</p> <p>The counter can be reset from the Drive Composer PC tool, or from the control panel by keeping Reset depressed for over 3 seconds.</p>	0 / real32
	<del>2147483008</del> . <del>2147483008</del>	Actual present value of value counter 2.	- / 1 = 1
33.61	Value counter 2 warn limit	<p>Sets the limit for value counter 2.</p> <p>With a positive limit, bit 5 of <a href="#">33.1 Counter status</a> is set to 1 (and a warning optionally generated) when the counter is equal or greater than the limit.</p> <p>With a negative limit, bit 5 of <a href="#">33.1 Counter status</a> is set to 1 (and a warning optionally generated) when the counter is equal or smaller than the limit.</p> <p>0 = Counter disabled.</p>	- / real32
	<del>2147483008</del> . <del>2147483008</del>	Limit for value counter 2.	- / 1 = 1
33.62	Value counter 2 function	Configures value counter 2.	- / uint16
b0	Counter mode	<p>0 = Loop: When the limit is reached, the counter is reset. The counter status (bit 5 of <a href="#">33.1</a>) switches to 1 for one second. The warning (if enabled) stays active for at least 10 seconds.</p> <p>1 = Saturate: When the limit is reached, the counter status (bit 5 of <a href="#">33.1</a>) switches to 1, and remains so until <a href="#">33.60</a> is reset. The warning (if enabled) also stays active until <a href="#">33.60</a> is reset.</p>	
b1	Warning enable	<p>Warning enable</p> <p>0 = Disable: No warning is given when the limit is reached</p> <p>1 = Enable: A warning (see <a href="#">33.65</a>) is given when the limit is reached</p>	
b2...15	Reserved		
	0000h...FFFFh		1 = 1 / 1 = 1
33.63	Value counter 2 source	Selects the signal to be monitored by value counter 2.	Not selected / uint32
	Not selected	None (counter disabled).	0
	Motor speed	<a href="#">1.1 Motor speed used</a> .	1

### 374 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	Other [bit]	Source selection (see <a href="#">Terms and abbreviations (page 134)</a> ).	-
33.64	Value counter 2 divider	Defines a divisor for value counter 2. The value of the monitored signal is divided by this value before integration.	1.000 / real32
	0.001 ... 2147483.000	Divisor for value counter 2.	- / 1 = 1
33.65	Value counter 2 warn message	Selects the optional warning message for value counter 2.	Value counter 2 exceeded / uint32
	Value counter 2 exceeded	<a href="#">A88B Value counter 2</a> . The message text can be edited on the control panel by choosing Menu – Settings – Edit texts.	5
	Maintain motor bearing	<a href="#">A880 Motor bearing</a> .	10

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
35	Motor thermal protection	Motor thermal protection settings such as temperature measurement configuration, load curve definition and motor fan control configuration.  See also section <a href="#">Motor thermal protection (page 90)</a> .	
35.1	Motor estimated temperature	Displays the motor temperature as estimated by the internal motor thermal protection model (see parameters <a href="#">35.50...35.55</a> ). The unit (°C or °F) is selected by parameter <a href="#">96.16 Unit selection</a> .  This parameter is read-only.	- / real32
	-60.0 ... 1000.0 °	Estimated motor temperature.	1 = 1° / 1 = 1°
35.2	Measured temperature 1	Displays the temperature received through the source defined by parameter <a href="#">35.11 Temperature 1 source</a> . The unit is selected by parameter <a href="#">96.16 Unit selection</a> .  <b>Note:</b> With °F, the range is -76...1832. With a PTC sensor, the range is 0...5000 ohms.  This parameter is read-only.	- / real32
	-60...1000 °	Measured temperature 1.	1 = 1° / 1 = 1°
35.3	Measured temperature 2	Displays the temperature received through the source defined by parameter <a href="#">35.21 Temperature 2 source</a> . The unit is selected by parameter <a href="#">96.16 Unit selection</a> .  <b>Note:</b> With °F, the range is -76...1832. With a PTC sensor, the range is 0...5000 ohms.  This parameter is read-only.	- / real32
	-60...1000 °	Measured temperature 2.	1 = 1° / 1 = 1°
35.4	FPTC status word	Displays the status of optional FPTC-xx thermistor protection modules. The word can be used as the source of eg. external events.  <b>Note:</b> The “module found” bits are updated regardless of whether the corresponding module is activated. However, the “fault active” and “warning active” bits are not updated if the module is not activated. Modules are activated by parameter <a href="#">35.30 FPTC configuration word</a> .  This parameter is read-only.	- / uint16
b0	Module found in slot 1	1 = Yes: An FPTC-xx module has been detected in slot 1.	
b1	Fault active in slot 1	1 = Yes: The module in slot 1 has an active fault ( <a href="#">4991 Safe motor temperature 1</a> ).	
b2	Warning active in slot 1	1 = Yes: The module in slot 1 has an active warning ( <a href="#">A497 Motor temperature 1</a> ).	
b3	Module found in slot 2	1 = Yes: An FPTC-xx module has been detected in slot 2.	
b4	Fault active in slot 2	1 = Yes: The module in slot 2 has an active fault ( <a href="#">4992 Safe motor temperature 2</a> ).	

### 376 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
b5	Warning active in slot 2	1 = Yes: The module in slot 2 has an active warning ( <a href="#">A498 Motor temperature 2</a> ).	
b6	Module found in slot 3	1 = Yes: An FPTC-xx module has been detected in slot 3.	
b7	Fault active in slot 3	1 = Yes: The module in slot 3 has an active fault ( <a href="#">4993 Safe motor temperature 3</a> ).	
b8	Warning active in slot 3	1 = Yes: The module in slot 3 has an active warning ( <a href="#">A499 Motor temperature 3</a> ).	
b9...15	Reserved		
	0000h...FFFFh		1 = 1 / 1 = 1
35.5	Motor overload level	Displays the motor overload level as a percent of the motor overload fault limit. See parameter <a href="#">35.56 Motor overload action</a> and section <a href="#">Motor overload protection (page 95)</a> .	- / real32
	0.0 ... 300.0 %	Motor overload level. 0.0% No motor overloading. 88.0% Motor overloaded to warning level. 100.0% Motor overloaded to fault level.	10 = 1 % / 10 = 1 %
35.9	Temperature Calibration status word	Shows temperature calibration status word.	- / uint16
b0	Temperature1 calibration done	Calibration status of temperature 1. See parameter <a href="#">35.17 Temperature 1 calibration</a> .	
b1	Temperature2 calibration done	Calibration status of temperature 2. See parameter <a href="#">35.27 Temperature 2 calibration</a> .	
b2...15	Reserved		
	0000h...FFFFh		1 = 1 / 1 = 1
35.11	Temperature 1 source	Selects the source from which measured temperature 1 is read.  For wiring examples, see the hardware manual of the drive.  Usually this source is from a sensor connected to the motor controlled by the drive, but it could be used to measure and monitor a temperature from other parts of the process as long as a suitable sensor is used as per the selection list.	Disabled / uint16
	Disabled	None. Temperature monitoring function 1 is disabled.	0
	Estimated temperature	Estimated motor temperature (see parameter <a href="#">35.1 Motor estimated temperature</a> ).  The temperature is estimated from an internal drive calculation. It is important to set up the ambient temperature of the motor in <a href="#">35.50 Motor ambient temperature</a> .	1



No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	KTY84 analog I/O	<p>KTY84 sensor connected to the analog input selected by parameter <a href="#">35.14 Temperature 1 AI source</a> and an analog output. The input and output can be on the drive control unit or on an extension module.</p> <p>The following settings are required:</p> <ul style="list-style-type: none"> <li>• Set the hardware jumper or switch related to the analog input to <b>U</b> (voltage). Any change must be validated by a control unit reboot.</li> <li>• Set the unit selection parameter of the input to volt.</li> <li>• Set the source selection parameter of the analog output to “<b>Force KTY84 excitation</b>”.</li> <li>• Select the analog input in parameter <a href="#">35.14</a>. In case the input is located on an I/O extension module, use selection Other (see <a href="#">Terms and abbreviations (page 18)</a>) to point at the actual input value parameter (for example, <a href="#">14.26 AI1 actual value</a>).</li> </ul> <p>The analog output feeds a constant current through the sensor. As the resistance of the sensor changes along with its temperature, the voltage over the sensor changes. The voltage is read by the analog input and converted into degrees.</p>	2
	KTY84 encoder module 1	<p>KTY84 sensor connected to encoder interface 1.</p> <p>See also parameters <a href="#">91.21 Module 1 temp sensor type</a> and <a href="#">91.22 Module 1 temp filter time</a>.</p>	3
	KTY84 encoder module 2	<p>KTY84 sensor connected to encoder interface 2.</p> <p>See also parameters <a href="#">91.24 Module 2 temp sensor type</a> and <a href="#">91.25 Module 2 temp filter time</a>.</p>	4
	1 x Pt100 analog I/O	<p>Pt100 sensor connected to a standard analog input selected by parameter <a href="#">35.14 Temperature 1 AI source</a> and an analog output. The input and output can be on the drive control unit or on an extension module.</p> <p>The required settings are the same as with selection <a href="#">KTY84 analog I/O</a>, except that the source selection parameter of the analog output must be set to <a href="#">Force Pt100 excitation</a>.</p>	5
	2 x Pt100 analog I/O	<p>As selection <a href="#">1 x Pt100 analog I/O</a>, but with two sensors connected in series. Using multiple sensors improves measurement accuracy significantly.</p>	6
	3 x Pt100 analog I/O	<p>As selection <a href="#">1 x Pt100 analog I/O</a>, but with three sensors connected in series. Using multiple sensors improves measurement accuracy significantly.</p>	7
	PTC DI6	<p>PTC sensor connected to digital input DI6 (see the connection diagram on page <a href="#">91</a>).</p> <p><b>Note:</b> Either 0 ohm (normal temperature) or 4000 ohm (excessive temperature) will be shown by <a href="#">35.2 Measured temperature 1</a>. By default, an excessive temperature will generate a warning as per parameter <a href="#">35.13 Temperature 1 warning limit</a>. If you want a fault instead, set <a href="#">35.12 Temperature 1 fault limit</a> to 4000 ohm.</p>	8

### 378 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	PTC analog I/O	<p>PTC sensor connected to a standard analog input selected by parameter <a href="#">35.14 Temperature 1 AI source</a> and an analog output. The input and output can be on the drive control unit or on an extension module.</p> <p>The required settings are the same as with selection <a href="#">KTY84 analog I/O</a>, except that the source selection parameter of the analog output must be set to <a href="#">Force PTC excitation</a>.</p>	20
	PTC encoder module 1	<p>PTC sensor connected to encoder interface 1.</p> <p>See also parameters <a href="#">91.21 Module 1 temp sensor type</a> and <a href="#">91.22 Module 1 temp filter time</a>.</p>	9
	PTC encoder module 2	<p>PTC sensor connected to encoder interface 2.</p> <p>See also parameters <a href="#">91.24 Module 2 temp sensor type</a> and <a href="#">91.25 Module 2 temp filter time</a>.</p>	10
	Direct temperature	<p>The temperature is taken from the source selected by parameter <a href="#">35.14 Temperature 1 AI source</a>. The value of the source is assumed to be in the unit of temperature specified by <a href="#">96.16 Unit selection</a>.</p>	11
	1 x Pt1000 analog I/O	<p>Pt1000 sensor connected to a standard analog input selected by parameter <a href="#">35.14 Temperature 1 AI source</a> and an analog output. The input and output can be on the drive control unit or on an extension module.</p> <p>The required settings are the same as with selection <a href="#">KTY84 analog I/O</a>, except that the source selection parameter of the analog output must be set to <a href="#">Force Pt1000 excitation</a>.</p>	13
	2 x Pt1000 analog I/O	<p>As selection <a href="#">1 x Pt1000 analog I/O</a>, but with two sensors connected in series. Using multiple sensors improves measurement accuracy significantly.</p>	14
	3 x Pt1000 analog I/O	<p>As selection <a href="#">1 x Pt1000 analog I/O</a>, but with three sensors connected in series. Using multiple sensors improves measurement accuracy significantly.</p>	15
	Pt1000 encoder module 1	<p>Pt1000 sensor connected to encoder interface 1. See parameters <a href="#">91.21 Module 1 temp sensor type</a> and <a href="#">91.22 Module 1 temp filter time</a>.</p> <p><b>Note:</b> Pt1000 sensor supports FEN-11 and FEN-31 encoder modules only.</p>	16
	Pt1000 encoder module 2	<p>Pt1000 sensor connected to encoder interface 2. See parameters <a href="#">91.24 Module 2 temp sensor type</a> and <a href="#">91.25 Module 2 temp filter time</a>.</p> <p><b>Note:</b> Pt1000 sensor supports FEN-11 and FEN-31 encoder modules only.</p>	17

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
35.12	Temperature 1 fault limit	<p>Defines the fault limit for temperature monitoring function 1.</p> <p>When measured temperature 1 exceeds the limit, the drive trips on fault <a href="#">4981 External temperature 1</a>.</p> <p>The unit is selected by parameter <a href="#">96.16 Unit selection</a>.</p> <p><b>Note:</b> With °F, the range is -76...1832. With a PTC sensor, the range is 0...5000 ohms.</p>	130 ° / real32
	-60...1000 °	Fault limit for temperature monitoring function 1.	1 = 1 ° / 1 = 1 °
35.13	Temperature 1 warning limit	<p>Defines the warning limit for temperature monitoring function 1. When measured temperature 1 exceeds this limit, a warning (<a href="#">A491 External temperature 1</a>) is generated.</p> <p>The unit is selected by parameter <a href="#">96.16 Unit selection</a>.</p> <p><b>Note:</b> With °F, the range is -76...1832. With a PTC sensor, the range is 0...5000 ohms.</p>	110 ° / real32
	-60...1000 °	Warning limit for temperature monitoring function 1.	1 = 1 ° / 1 = 1 °
35.14	Temperature 1 AI source	<p>Specifies the analog input when the setting of <a href="#">35.11 Temperature 1 source</a> requires measurement through an analog input.</p> <p><b>Note:</b> If the input is located on an I/O extension module, use the selection <i>Other</i> to point to the AI actual value in group 14, 15 or 16, eg. <a href="#">14.26 AI1 actual value</a>.</p>	Not selected / uint32
	Not selected	None.	0
	AI1 actual value	Analog input AI1 on the control unit.	1
	AI2 actual value	Analog input AI2 on the control unit.	2
	Other [bit]	Source selection (see <a href="#">Terms and abbreviations (page 134)</a> ).	-
35.17	Temperature 1 calibration	<p>Defines the calibration of temperature 1.</p> <p>Calibration can be used to fine-tune the motor temperature measurement. Once the motor has cooled down, measure its ambient temperature and set this value accordingly.</p> <p>This parameter affects only if Pt100 or Pt1000 measurement is using AI and AO of the control unit or I/O extension modules.</p>	0 ° / real32
	-30...1000 °	Calibration of temperature 1 in celsius.	1 = 1 ° / 1 = 1 °


## 380 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
35.21	Temperature 2 source	<p>Selects the source from which measured temperature 2 is read.</p> <p>For wiring examples, see the hardware manual of the drive.</p> <p>Usually this source is from a sensor connected to the motor controlled by the drive, but it could be used to measure and monitor a temperature from other parts of the process as long as a suitable sensor is used as per the selection list.</p>	Disabled / uint16
	Disabled	None. Temperature monitoring function 2 is disabled.	0
	Estimated temperature	<p>Estimated motor temperature (see parameter <a href="#">35.1 Motor estimated temperature</a>).</p> <p>The temperature is estimated from an internal drive calculation. It is important to set up the ambient temperature of the motor in <a href="#">35.50 Motor ambient temperature</a>.</p>	1
	KTY84 analog I/O	<p>KTY84 sensor connected to the analog input selected by parameter <a href="#">35.24 Temperature 2 AI source</a> and an analog output. The input and output can be on the drive control unit or on an extension module.</p> <p>The following settings are required:</p> <ul style="list-style-type: none"> <li>Set the hardware jumper or switch related to the analog input to U (voltage). Any change must be validated by a control unit reboot.</li> <li>Set the unit selection parameter of the input to volt.</li> <li>Set the source selection parameter of the analog output to “<a href="#">Force KTY84 excitation</a>”.</li> <li>Select the analog input in parameter <a href="#">35.24</a>. In case the input is located on an I/O extension module, use the selection Other (see <a href="#">Terms and abbreviations (page 18)</a>) to point at the actual input value parameter (for example, <a href="#">14.26 AI1 actual value</a>).</li> </ul> <p>The analog output feeds a constant current through the sensor. As the resistance of the sensor changes along with its temperature, the voltage over the sensor changes. The voltage is read by the analog input and converted into degrees.</p>	2
	KTY84 encoder module 1	<p>KTY84 sensor connected to encoder interface 1.</p> <p>See also parameters <a href="#">91.21 Module 1 temp sensor type</a> and <a href="#">91.22 Module 1 temp filter time</a>.</p>	3
	KTY84 encoder module 2	<p>KTY84 sensor connected to encoder interface 2.</p> <p>See also parameters <a href="#">91.24 Module 2 temp sensor type</a> and <a href="#">91.25 Module 2 temp filter time</a>.</p>	4


No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	1 x Pt100 analog I/O	Pt100 sensor connected to a standard analog input selected by parameter <a href="#">35.24 Temperature 2 AI source</a> and an analog output. The input and output can be on the drive control unit or on an extension module.  The required settings are the same as with selection <a href="#">KTY84 analog I/O</a> , except that the source selection parameter of the analog output must be set to <a href="#">Force Pt100 excitation</a> .	5
	2 x Pt100 analog I/O	As selection <a href="#">1 x Pt100 analog I/O</a> , but with two sensors connected in series. Using multiple sensors improves measurement accuracy significantly.	6
	3 x Pt100 analog I/O	As selection <a href="#">1 x Pt100 analog I/O</a> , but with three sensors connected in series. Using multiple sensors improves measurement accuracy significantly.	7
	PTC DI6	PTC sensor connected to digital input DI6 (see the connection diagram on page <a href="#">91</a> ).  <b>Note:</b> Either 0 ohm (normal temperature) or 4000 ohm (excessive temperature) will be shown by <a href="#">35.3 Measured temperature 2</a> . By default, an excessive temperature will generate a warning as per parameter <a href="#">35.23 Temperature 2 warning limit</a> . If you want a fault instead, set <a href="#">35.22 Temperature 2 fault limit</a> to 4000 ohm.	8
	PTC analog I/O	PTC sensor connected to a standard analog input selected by parameter <a href="#">35.24 Temperature 2 AI source</a> and an analog output. The input and output can be on the drive control unit or on an extension module.  The required settings are the same as with selection <a href="#">KTY84 analog I/O</a> , except that the source selection parameter of the analog output must be set to <a href="#">Force Pt100 excitation</a> .	20
	PTC encoder module 1	PTC sensor connected to encoder interface 1.  See also parameters <a href="#">91.21 Module 1 temp sensor type</a> and <a href="#">91.22 Module 1 temp filter time</a> .	9
	PTC encoder module 2	PTC sensor connected to encoder interface 2.  See also parameters <a href="#">91.24 Module 2 temp sensor type</a> and <a href="#">91.25 Module 2 temp filter time</a> .	10
	Direct temperature	The temperature is taken from the source selected by parameter <a href="#">35.24 Temperature 2 AI source</a> . The value of the source is assumed to be in the unit of temperature specified by <a href="#">96.16 Unit selection</a> .	11
	1 x Pt1000 analog I/O	Pt1000 sensor connected to a standard analog input selected by parameter <a href="#">35.24 Temperature 2 AI source</a> and an analog output. The input and output can be on the drive control unit or on an extension module.  The required settings are the same as with selection <a href="#">KTY84 analog I/O</a> , except that the source selection parameter of the analog output must be set to <a href="#">Force Pt100 excitation</a> .	13

### 382 Parameters



No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	2 x Pt1000 analog I/O	As selection 1 x Pt1000 analog I/O, but with two sensors connected in series. Using multiple sensors improves measurement accuracy significantly.	14
	3 x Pt1000 analog I/O	As selection 1 x Pt1000 analog I/O, but with three sensors connected in series. Using multiple sensors improves measurement accuracy significantly.	15
	Pt1000 encoder module 1	Pt1000 sensor connected to encoder interface 1. See parameters <a href="#">91.21 Module 1 temp sensor type</a> and <a href="#">91.22 Module 1 temp filter time</a> .  <b>Note:</b> Pt1000 sensor is supported with FEN-11 and FEN-31 encoder modules only.	16
	Pt1000 encoder module 2	Pt1000 sensor connected to encoder interface 2. See parameters <a href="#">91.24 Module 2 temp sensor type</a> and <a href="#">91.25 Module 2 temp filter time</a> .  <b>Note:</b> Pt1000 sensor is supported with FEN-11 and FEN-31 encoder modules only.	17
35.22	Temperature 2 fault limit	Defines the fault limit for temperature monitoring function 2.  When measured temperature 2 exceeds the limit, the drive trips on fault <a href="#">4982 External temperature 2</a> .  The unit is selected by parameter <a href="#">96.16 Unit selection</a> .  <b>Note:</b> With °F, the range is -76...1832. With a PTC sensor, the range is 0...5000 ohms.	130 ° / real32
	-60...1000 °	Fault limit for temperature monitoring function 2.	1 = 1 ° / 1 = 1 °
35.23	Temperature 2 warning limit	Defines the warning limit for temperature monitoring function 2. When measured temperature 2 exceeds the limit, a warning ( <a href="#">A492 External temperature 2</a> ) is generated.  The unit is selected by parameter <a href="#">96.16 Unit selection</a> .  <b>Note:</b> With °F, the range is -76...1832. With a PTC sensor, the range is 0...5000 ohms.	110 ° / real32
	-60...1000 °	Warning limit for temperature monitoring function 2.	1 = 1 ° / 1 = 1 °
35.24	Temperature 2 AI source	Selects the input for parameter <a href="#">35.21 Temperature 2 source</a> , selections <a href="#">KTY84 analog I/O</a> , <a href="#">1 x Pt100 analog I/O</a> , <a href="#">2 x Pt100 analog I/O</a> , <a href="#">3 x Pt100 analog I/O</a> and <a href="#">Direct temperature</a> .	Not selected / uint32
	Not selected	None.	0
	AI1 actual value	Analog input AI1 on the control unit.	1
	AI2 actual value	Analog input AI2 on the control unit.	2
	Other [bit]	Source selection (see <a href="#">Terms and abbreviations (page 134)</a> ).	-

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
35.27	Temperature 2 calibration	Defines the calibration of temperature 2. See parameter <a href="#">35.17 Temperature 1 calibration</a> .	0 ° / real32
	-30...1000 °	Calibration of temperature 2 in celsius.	1 = 1 ° / 1 = 1 °
35.30	FPTC configuration word	Activates FPTC-xx thermistor protection modules installed on the control unit of the drive. Using this word, it is also possible to suppress the warnings (but not faults) from each module.	- / uint16
b0	Module in slot 1	1 = Yes: Module installed in slot 1.	
b1	Disable slot 1 warning	1 = Yes: Warnings from the module in slot 1 suppressed.	
b2	Module in slot 2	1 = Yes: Module installed in slot 2.	
b3	Disable slot 2 warning	1 = Yes: Warnings from the module in slot 2 suppressed.	
b4	Module in slot 3	1 = Yes: Module installed in slot 3.	
b5	Disable slot 3 warning	1 = Yes: Warnings from the module in slot 3 suppressed.	
b6...15	Reserved		
	0000h...FFFFh		1 = 1 / 1 = 1
35.50	Motor ambient temperature	Defines the ambient temperature of the motor for the motor thermal protection model. The unit (°C or °F) is selected by parameter <a href="#">96.16 Unit selection</a> .  The motor thermal protection model estimates the motor temperature on the basis of parameters <a href="#">35.50...35.55</a> . The motor temperature increases if it operates in the region above the load curve, and decreases if it operates in the region below the load curve.   <b>WARNING!</b> The model cannot protect the motor if the motor does not cool properly because of dust, dirt, etc.	20 ° / real32
	-60...100 °	Ambient temperature.	1 = 1 ° / 1 = 1 °


### 384 Parameters


No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
35.51	Motor load curve	<p>Defines the motor load curve together with parameters <a href="#">35.52 Zero speed load</a> and <a href="#">35.53 Break point</a>. The load curve is used by the motor thermal protection model to estimate the motor temperature.</p> <p>When the parameter is set to 100%, the maximum load is taken as the value of parameter <a href="#">99.6 Motor nominal current</a> (higher loads heat up the motor). The load curve level should be adjusted if the ambient temperature differs from the nominal value set in <a href="#">35.50 Motor ambient temperature</a>.</p>  <p>The graph shows the relationship between the motor load curve and drive output frequency. The y-axis represents the current ratio <math>I/I_n</math> in percent, ranging from 0 to 150. The x-axis represents the drive output frequency. The curve starts at a value of 35.52 on the y-axis (representing the zero speed load). It then rises linearly until it reaches 100% on the y-axis at a frequency of 35.53 (representing the break point). From this point, the curve remains constant at 100% for higher frequencies. A legend indicates that <math>I</math> is the motor current and <math>I_n</math> is the nominal motor current.</p>	100 % / uint16
	50...150 %	Maximum load for the motor load curve.	1 = 1 % / 1 = 1 %
35.52	Zero speed load	<p>Defines the motor load curve together with parameters <a href="#">35.51 Motor load curve</a> and <a href="#">35.53 Break point</a>. Defines the maximum motor load at zero speed of the load curve. A higher value can be used if the motor has an external motor fan to boost the cooling. See the motor manufacturer's recommendations.</p> <p>See parameter <a href="#">35.51 Motor load curve</a>.</p>	70 % / uint16
	25...150 %	Zero speed load for the motor load curve.	1 = 1 % / 1 = 1 %
35.53	Break point	<p>Defines the motor load curve together with parameters <a href="#">35.51 Motor load curve</a> and <a href="#">35.52 Zero speed load</a>. Defines the break point frequency of the load curve i.e. the point at which the motor load curve begins to decrease from the value of parameter <a href="#">35.51 Motor load curve</a> towards the value of parameter <a href="#">35.52 Zero speed load</a>.</p> <p>See parameter <a href="#">35.51 Motor load curve</a>.</p>	45.00 Hz / uint16
	1.00 ... 500.00 Hz	Break point for the motor load curve. For 16-bit scaling, see parameter <a href="#">46.2</a> .	- / 100 = 1 Hz



No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
35.54	Motor nominal temperature rise	<p>Defines the temperature rise of the motor above ambient when the motor is loaded with nominal current. See the motor manufacturer's recommendations.</p> <p>The unit (°C or °F) is selected by parameter <a href="#">96.16 Unit selection</a>.</p> 	80 ° / real32
	0...300 °	Temperature rise.	1 = 1 ° / 1 = 1 °
35.55	Motor thermal time constant	<p>Defines the thermal time constant for use with the motor thermal protection model, defined as the time to reach 63% of the nominal motor temperature. See the motor manufacturer's recommendations.</p> 	256 s / uint16
	100...10000 s	Motor thermal time constant.	1 = 1 s / 1 = 1 s
35.56	Motor overload action	<p>Selects the action taken when motor overload is detected.</p> <p>See section <a href="#">Motor overload protection (page 95)</a>.</p>	No action / uint16
	No action	No action taken.	0

## 386 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	Warning only	Drive generates warning <b>A783 Motor overload</b> when the motor is overloaded to the warning level, that is, parameter <b>35.5 Motor overload level</b> reaches value 88.0%.	1
	Warning and fault	Drive generates warning <b>A783 Motor overload</b> when the motor is overloaded to the warning level, that is, parameter <b>35.5 Motor overload level</b> reaches value 88.0%.  Drive trips on fault <b>7122 Motor overload</b> when the motor is overloaded to the fault level, that is, parameter <b>35.5 Motor overload level</b> reaches value 100.0%.	2
35.57	Motor overload class	Defines the motor overload class to be used. The class of protection is specified by the user as the time for tripping at 7.2 times (IEC 60947-4-1) or 6 times (NEMA ICS) the tripping level current.  See section <b>Motor overload protection (page 95)</b> .	Class 20 / uint16
	Class 5	Motor overload class 5.	0
	Class 10	Motor overload class 10.	1
	Class 20	Motor overload class 20.	2
	Class 30	Motor overload class 30.	3
	Class 40	Motor overload class 40.	4
35.60	Cable temperature	Shows the calculated temperature of the motor cable. See section <b>Thermal protection of motor cable (page 96)</b> .  102% = overtemperature warning ( <b>A480 Motor cable overload</b> )  106% = overtemperature fault ( <b>4000 Motor cable overload</b> )  This parameter is read-only.	0.0 % / real32
	0.0 ... 200.0 %	Calculated temperature of motor cable.	1 = 1 % / 10 = 1 %
35.61	Cable nominal current	Specifies the continuous current of the motor cable for the thermal protection function in the control program.   <b>WARNING!</b> The value entered in this parameter must be limited according to all factors affecting the loadability of the cable, such as ambient temperature, cabling arrangement, and shrouding. Refer to the technical data from the cable manufacturer.	10000.00 A / real32
	0.00 ... 10000.00 A	Continuous current-carrying capacity of motor cable.	1 = 1 A / 100 = 1 A

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
35.62	Cable thermal rise time	<p>Specifies the thermal time of the motor cable for the thermal protection function in the control program. This value is defined as the time to reach 63% of the nominal cable temperature when the cable is loaded with nominal current (parameter <a href="#">35.61 Cable nominal current</a>).</p> <p>0 s = Thermal protection of motor cable disabled.</p> <p>Refer to the technical data from the cable manufacturer.</p> 	1 s / uint16
	0...50000 s	<p>0 s → Thermal protection of motor cable disabled.</p> <p>1...50000 s → Motor cable thermal time constant.</p>	1 = 1 s / 1 = 1 s
35.100	DOL starter control source	<p>Parameters <a href="#">35.100...35.106</a> configure a monitored start/stop control logic for external equipment such as a contactor controlled motor cooling fan.</p> <p>This parameter selects the signal that starts and stops the fan.</p> <p>0 = Stop</p> <p>1 = Start</p> <p>The output controlling the fan contactor is to be connected to parameter <a href="#">35.105</a>, bit 1. On and off delays can be set for the fan by <a href="#">35.101</a> and <a href="#">35.102</a> respectively. A feedback signal from the fan can be connected to an input selected by <a href="#">35.103</a>; the loss of the feedback will optionally trigger a warning or fault (see <a href="#">35.104</a> and <a href="#">35.106</a>).</p>	Off, 06.16 b6 (95.20 b6) / uint32
	Off	0 (function disabled).	0
	On	1.	1
	Running	Bit 6 of <a href="#">6.16 Drive status word 1</a> (page 162).	2

## 388 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-
35.101	DOL starter on delay	Defines a start delay for the motor fan.  The delay timer starts when the control source selected by parameter <a href="#">35.100</a> switches on. After the delay, bit 1 of <a href="#">35.105</a> switches on.	- / uint32
	0...42949673 s	Motor fan start delay.	1 = 1 s / 100 = 1 s
35.102	DOL starter off delay	Defines a stop delay for the motor fan.  The delay timer starts when the control source selected by parameter <a href="#">35.100</a> switches off. After the delay, bit 1 of <a href="#">35.105</a> switches off.	20 min / uint32
	0...715828 min	Motor fan stop delay.	1 = 1 min / 1 = 1 min
35.103	DOL starter feedback source	Selects the input for motor fan feedback signal. 0 = Stopped 1 = Running  After the fan is started (bit 1 of <a href="#">35.105</a> switches on), feedback is expected within the time set by <a href="#">35.104</a> .	Not selected; DI5 (95.20 b6) / uint32
	Not selected	0	0
	Selected	1	1
	DI1	Digital input DI1 ( <a href="#">10.2 DI delayed status</a> , bit 0).	2
	DI2	Digital input DI2 ( <a href="#">10.2 DI delayed status</a> , bit 1).	3
	DI3	Digital input DI3 ( <a href="#">10.2 DI delayed status</a> , bit 2).	4
	DI4	Digital input DI4 ( <a href="#">10.2 DI delayed status</a> , bit 3).	5
	DI5	Digital input DI5 ( <a href="#">10.2 DI delayed status</a> , bit 4).	6
	DI6	Digital input DI6 ( <a href="#">10.2 DI delayed status</a> , bit 5).	7
	DIO1	Digital input/output DIO1 ( <a href="#">11.2 DIO delayed status</a> , bit 0).	10
	DIO2	Digital input/output DIO2 ( <a href="#">11.2 DIO delayed status</a> , bit 1).	11
	Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-
35.104	DOL starter feedback delay	Defines a feedback delay for the motor fan.  The delay timer starts when bit 1 of <a href="#">35.105</a> switches on. If no feedback is received from the fan until the delay elapses, the action selected by <a href="#">35.106</a> is taken.  <b>Note:</b> This delay is only applied at start. If the feedback signal is lost during run, the action selected by <a href="#">35.106</a> is taken immediately.	0; 5 (95.20 b6) s / uint32
	0...42949673 s	Motor fan start delay.	1 = 1 s / 1 = 1 s

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
35.105	DOL starter status word	Status of the motor fan control logic. Bit 1 is the control output for the fan, to be selected as the source of, for example, a digital or relay output. The other bits indicate the statuses of the selected control and feedback sources, and the fault status. This parameter is read-only.	- / uint16
b0	Start command:	Status of fan control source selected by 35.100. 0 = Stop requested 1 = Start requested	
b1	Delayed start command:	Fan control bit (delays observed). Select this bit as the source of the output controlling the fan. 0 = Stopped 1 = Started	
b2	DOL feedback:	Status of fan feedback (source selected by 35.103). 0 = Stopped 1 = Running	
b3	DOL fault (-1):	Fault status. 0 = Fault (fan feedback missing). The action taken is selected by 35.106. 1 = No fault	
b4...15	Reserved		
	0000h...FFFFh		1 = 1 / 1 = 1
35.106	DOL starter event type	Selects the action taken when missing fan feedback is detected by the motor fan control logic.	Fault / uint16
	No action	No action taken.	0
	Warning	The drive generates a warning (A781 Motor fan).	1
	Fault	Drive trips on 71B1 Motor fan.	2

## 390 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
36	Load analyzer	Peak value and amplitude logger settings. See also section <a href="#">Load analyzer (page 101)</a> .	
36.1	PVL signal source	Selects the signal to be monitored by the peak value logger. The signal is filtered using the filtering time specified by parameter <a href="#">36.2 PVL filter time</a> . The peak value is stored, along with other pre-selected signals at the time, into parameters <a href="#">36.12...36.15</a> . The peak value logger can be reset using parameter <a href="#">36.9 Reset loggers</a> . The logger is also reset whenever the signal source is changed. The date and time of the last reset are stored into parameters <a href="#">36.16</a> and <a href="#">36.17</a> respectively.	Power inu out / uint32
	Zero	None	0
	Motor speed used	<a href="#">1.1 Motor speed used (page 138)</a> .	1
	Output frequency	<a href="#">1.6 Output frequency (page 138)</a> .	3
	Motor current	<a href="#">1.7 Motor current (page 138)</a> .	4
	Motor torque	<a href="#">1.10 Motor torque (page 138)</a> .	6
	DC voltage	<a href="#">1.11 DC voltage (page 139)</a> .	7
	Power inu out	<a href="#">1.14 Output power (page 139)</a> .	8
	Speed ref ramp in	<a href="#">23.1 Speed ref ramp input (page 288)</a> .	10
	Speed ref ramp out	<a href="#">23.2 Speed ref ramp output (page 288)</a> .	11
	Speed ref used	<a href="#">24.1 Used speed reference (page 295)</a> .	12
	Torq ref used	<a href="#">26.2 Torque reference used (page 314)</a> .	13
	Freq ref used	<a href="#">28.2 Frequency ref ramp output (page 323)</a> .	14
	Process PID out	<a href="#">40.1 Process PID output actual (page 399)</a> .	16
	Process PID fbk	<a href="#">40.2 Process PID feedback actual (page 399)</a> .	17
	Process PID act	<a href="#">40.3 Process PID setpoint actual (page 399)</a> .	18
	Process PID dev	<a href="#">40.4 Process PID deviation actual (page 399)</a> .	19
	Other [bit]	Source selection (see <a href="#">Terms and abbreviations (page 134)</a> ).	-
36.2	PVL filter time	Defines a filtering time for the peak value logger. See parameter <a href="#">36.1 PVL signal source</a> .	2.00 s / real32
	0.00 ... 120.00 s	Peak value logger filtering time.	100 = 1 s / 100 = 1 s

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
36.6	AL2 signal source	<p>Selects the signal to be monitored by amplitude logger 2. The signal is sampled at 200 ms intervals, and can be scaled using parameter <a href="#">36.7 AL2 signal scaling</a>.</p> <p>The results are displayed by parameters <a href="#">36.40...36.49</a>. Each parameter represents an amplitude range, and shows what portion of the samples fall within that range.</p> <p>Amplitude logger 2 can be reset using parameter <a href="#">36.9 Reset loggers</a>. The logger is also reset whenever the signal source or scaling is changed. The date and time of the last reset are stored into parameters <a href="#">36.50</a> and <a href="#">36.51</a> respectively.</p>	Ambient temperature / uint32
	Zero	None	0
	Motor speed used	<a href="#">1.1 Motor speed used (page 138)</a> .	1
	Output frequency	<a href="#">1.6 Output frequency (page 138)</a> .	3
	Motor current	<a href="#">1.7 Motor current (page 138)</a> .	4
	Motor torque	<a href="#">1.10 Motor torque (page 138)</a> .	6
	DC voltage	<a href="#">1.11 DC voltage (page 139)</a> .	7
	Power inu out	<a href="#">1.14 Output power (page 139)</a> .	8
	Speed ref ramp in	<a href="#">23.1 Speed ref ramp input (page 288)</a> .	10
	Speed ref ramp out	<a href="#">23.2 Speed ref ramp output (page 288)</a> .	11
	Speed ref used	<a href="#">24.1 Used speed reference (page 295)</a> .	12
	Torq ref used	<a href="#">26.2 Torque reference used (page 314)</a> .	13
	Freq ref used	<a href="#">28.2 Frequency ref ramp output (page 323)</a> .	14
	Process PID out	<a href="#">40.1 Process PID output actual (page 399)</a> .	16
	Process PID fbk	<a href="#">40.2 Process PID feedback actual (page 399)</a> .	17
	Process PID act	<a href="#">40.3 Process PID setpoint actual (page 399)</a> .	18
	Process PID dev	<a href="#">40.4 Process PID deviation actual (page 399)</a> .	19
	Other [bit]	Source selection (see <a href="#">Terms and abbreviations (page 134)</a> ).	-
	Ambient temperature	<p><a href="#">1.70 Ambient temperature % (page 142)</a>.</p> <p>The amplitude range of 0...100% corresponds to 0...60 °C or 32...140 °F.</p>	20
36.7	AL2 signal scaling	Defines the signal value that corresponds to 100% amplitude.	100.00 / real32
	0.00 ... 32767.00	Signal value corresponding to 100%.	1 = 1 / 100 = 1
36.8	Logger function	Determines whether amplitude loggers 1 and 2 are active continuously or only when the drive is modulating.	- / uint16
	b0 AL1	<p>0 = Amplitude logger 1 active continuously</p> <p>1 = Amplitude logger 1 active only when the drive is modulating</p>	

## 392 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
b1	AL2	0 = Amplitude logger 2 active continuously 1 = Amplitude logger 2 active only when the drive is modulating	
b2...15	Reserved		
	0000h...FFFFh		1 = 1 / 1 = 1
36.9	Reset loggers	Resets the peak value logger and/or amplitude logger 2. (Amplitude logger 1 cannot be reset.)	Done / uint16
	Done	Reset completed or not requested (normal operation).	0
	All	Reset both the peak value logger and amplitude logger 2.	1
	PVL	Reset the peak value logger.	2
	AL2	Reset amplitude logger 2.	3
36.10	PVL peak value	Displays the peak value recorded by the peak value logger.	- / real32
	-32768.00 ... 32767.00	Peak value.	1 = 1 / 100 = 1
36.11	PVL peak date	Displays the date on which the peak value was recorded.	- / uint16
36.12	PVL peak time	Displays the time at which the peak value was recorded.	0 / uint32
	00:00:00...23:59:59	Peak occurrence time.	1 = 1
36.13	PVL current at peak	Displays the motor current at the moment the peak value was recorded.	- / real32
	-32768.00 ... 32767.00 A	Motor current at peak.	1 = 1 A / 100 = 1 A
36.14	PVL DC voltage at peak	Displays the voltage in the intermediate DC circuit of the drive at the moment the peak value was recorded.	- / real32
	0.00 ... 2000.00 V	DC voltage at peak.	10 = 1 V / 100 = 1 V
36.15	PVL speed at peak	Displays the motor speed at the moment the peak value was recorded.	- / real32
	-32768.00 ... 32767.00 rpm	Motor speed at peak. For 16-bit scaling, see parameter 46.1.	- / 100 = 1 rpm
36.16	PVL reset date	Displays the date on which the peak value logger was last reset.	0 / uint16
	-	Last reset date of the peak value logger.	1 = 1
36.17	PVL reset time	Displays the time at which the peak value logger was last reset.	0 / uint32
	00:00:00...23:59:59	Last reset time of the peak value logger.	1 = 1



No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
36.20	AL1 below 10%	Displays the percentage of samples recorded by amplitude logger 1 that were below 10%. Note that this percentage also includes the samples that had a negative value.	- / real32
	0.00 ... 100.00 %	Amplitude logger 1 samples below 10%.	$1 = 1 \% / 100 = 1 \%$
36.21	AL1 10 to 20%	Displays the percentage of samples recorded by amplitude logger 1 that fall between 10 and 20 %.	- / real32
	0.00 ... 100.00 %	Amplitude logger 1 samples between 10 and 20 %.	$1 = 1 \% / 100 = 1 \%$
36.22	AL1 20 to 30%	Displays the percentage of samples recorded by amplitude logger 1 that fall between 20 and 30 %.	- / real32
	0.00 ... 100.00 %	Amplitude logger 1 samples between 20 and 30 %.	$1 = 1 \% / 100 = 1 \%$
36.23	AL1 30 to 40%	Displays the percentage of samples recorded by amplitude logger 1 that fall between 30 and 40 %.	- / real32
	0.00 ... 100.00 %	Amplitude logger 1 samples between 30 and 40 %.	$1 = 1 \% / 100 = 1 \%$
36.24	AL1 40 to 50%	Displays the percentage of samples recorded by amplitude logger 1 that fall between 40 and 50 %.	- / real32
	0.00 ... 100.00 %	Amplitude logger 1 samples between 40 and 50 %.	$1 = 1 \% / 100 = 1 \%$
36.25	AL1 50 to 60%	Displays the percentage of samples recorded by amplitude logger 1 that fall between 50 and 60 %.	- / real32
	0.00 ... 100.00 %	Amplitude logger 1 samples between 50 and 60 %.	$1 = 1 \% / 100 = 1 \%$
36.26	AL1 60 to 70%	Displays the percentage of samples recorded by amplitude logger 1 that fall between 60 and 70 %.	- / real32
	0.00 ... 100.00 %	Amplitude logger 1 samples between 60 and 70 %.	$1 = 1 \% / 100 = 1 \%$
36.27	AL1 70 to 80%	Displays the percentage of samples recorded by amplitude logger 1 that fall between 70 and 80 %.	- / real32
	0.00 ... 100.00 %	Amplitude logger 1 samples between 70 and 80 %.	$1 = 1 \% / 100 = 1 \%$
36.28	AL1 80 to 90%	Displays the percentage of samples recorded by amplitude logger 1 that fall between 80 and 90 %.	- / real32
	0.00 ... 100.00 %	Amplitude logger 1 samples between 80 and 90 %.	$1 = 1 \% / 100 = 1 \%$
36.29	AL1 over 90%	Displays the percentage of samples recorded by amplitude logger 1 that exceed 90 %.	- / real32
	0.00 ... 100.00 %	Amplitude logger 1 samples over 90 %.	$1 = 1 \% / 100 = 1 \%$
36.40	AL2 below 10%	Displays the percentage of samples recorded by amplitude logger 2 that were below 10 %. Note that this percentage also includes the samples that had a negative value.	- / real32
	0.00 ... 100.00 %	Amplitude logger 2 samples below 10 %.	$1 = 1 \% / 100 = 1 \%$
36.41	AL2 10 to 20%	Displays the percentage of samples recorded by amplitude logger 2 that fall between 10 and 20 %.	- / real32
	0.00 ... 100.00 %	Amplitude logger 2 samples between 10 and 20 %.	$1 = 1 \% / 100 = 1 \%$
36.42	AL2 20 to 30%	Displays the percentage of samples recorded by amplitude logger 2 that fall between 20 and 30 %.	- / real32
	0.00 ... 100.00 %	Amplitude logger 2 samples between 20 and 30 %.	$1 = 1 \% / 100 = 1 \%$

## 394 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
36.43	AL2 30 to 40%	Displays the percentage of samples recorded by amplitude logger 2 that fall between 30 and 40 %.	- / real32
	0.00 ... 100.00 %	Amplitude logger 2 samples between 30 and 40 %.	1 = 1 % / 100 = 1 %
36.44	AL2 40 to 50%	Displays the percentage of samples recorded by amplitude logger 2 that fall between 40 and 50 %.	- / real32
	0.00 ... 100.00 %	Amplitude logger 2 samples between 40 and 50 %.	1 = 1 % / 100 = 1 %
36.45	AL2 50 to 60%	Displays the percentage of samples recorded by amplitude logger 2 that fall between 50 and 60 %.	- / real32
	0.00 ... 100.00 %	Amplitude logger 2 samples between 50 and 60 %.	1 = 1 % / 100 = 1 %
36.46	AL2 60 to 70%	Displays the percentage of samples recorded by amplitude logger 2 that fall between 60 and 70 %.	- / real32
	0.00 ... 100.00 %	Amplitude logger 2 samples between 60 and 70 %.	1 = 1 % / 100 = 1 %
36.47	AL2 70 to 80%	Displays the percentage of samples recorded by amplitude logger 2 that fall between 70 and 80 %.	- / real32
	0.00 ... 100.00 %	Amplitude logger 2 samples between 70 and 80 %.	1 = 1 % / 100 = 1 %
36.48	AL2 80 to 90%	Displays the percentage of samples recorded by amplitude logger 2 that fall between 80 and 90 %.	- / real32
	0.00 ... 100.00 %	Amplitude logger 2 samples between 80 and 90 %.	1 = 1 % / 100 = 1 %
36.49	AL2 over 90%	Displays the percentage of samples recorded by amplitude logger 2 that exceed 90 %.	- / real32
	0.00 ... 100.00 %	Amplitude logger 2 samples over 90 %.	1 = 1 % / 100 = 1 %
36.50	AL2 reset date	Displays the date on which amplitude logger 2 was last reset.	0 / uint16
	-	Last reset date of amplitude logger 2.	1 = 1
36.51	AL2 reset time	Displays the time at which amplitude logger 2 was last reset.	0 / uint32
	00:00:00...23:59:59	Last reset time of amplitude logger 2.	1 = 1

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
<b>37</b>	User load curve	Settings for user load curve. See also section <a href="#">User load curve</a> .	
37.1	ULC output status word	Displays the status of the monitored signal. (The status word is independent of the actions and delays selected by parameters <a href="#">37.3</a> , <a href="#">37.4</a> , <a href="#">37.41</a> and <a href="#">37.42</a> .) This parameter is read-only.	- / uint16
	b0 Under load limit	1 = Monitored signal is below the underload curve	
	b1 Reserved		
	b2 Over load limit	1 = Monitored signal is above the overload curve	
	b3...15 Reserved		
	0000h...FFFFh		1 = 1 / 1 = 1
37.2	ULC supervision signal	Selects the signal to be monitored. The function compares the absolute value of the signal against the load curve.	Not selected / uint32
	Not selected	No signal selected (monitoring disabled).	0
	Motor current %	<a href="#">1.7 Motor current (page 138)</a> .	2
	Motor torque %	<a href="#">1.10 Motor torque (page 138)</a> .	3
	Output power % of motor nominal	<a href="#">1.15 Output power % of motor nom (page 139)</a> .	4
	Other [bit]	Source selection (see <a href="#">Terms and abbreviations (page 134)</a> ).	-
37.3	ULC overload actions	Selects how the drive reacts if the absolute value of the monitored signal stays above the overload curve for longer than the value of <a href="#">37.41 ULC overload timer</a> .	Disabled / uint16
	Disabled	No action taken.	0
	Warning	The drive generates a warning ( <a href="#">A8BE ULC overload</a> ).	1
	Fault	Drive trips on <a href="#">8002 ULC overload</a> .	2
	Warning/Fault	The drive generates a warning ( <a href="#">A8BE ULC overload</a> ) if the signal stays continuously above the overload curve for half of the time defined by <a href="#">37.41 ULC overload timer</a> . The drive trips on <a href="#">8002 ULC overload</a> if the signal stays continuously above the overload curve for the time defined by <a href="#">37.41 ULC overload timer</a> .	3
37.4	ULC underload actions	Selects how the drive reacts if the absolute value of the monitored signal stays below the underload curve for longer than the value of <a href="#">37.42 ULC underload timer</a> .	Disabled / uint16
	Disabled	No action taken.	0
	Warning	The drive generates a warning ( <a href="#">A8BF ULC underload</a> ).	1
	Fault	Drive trips on <a href="#">8001 ULC underload</a> .	2

## 396 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	Warning/Fault	<p>The drive generates a warning (<b>A8BF ULC underload</b>) if the signal stays continuously below the underload curve for half of the time defined by <b>37.42 ULC underload timer</b>.</p> <p>The drive trips on <b>8001 ULC underload</b> if the signal stays continuously below the underload curve for the time defined by <b>37.42 ULC underload timer</b>.</p>	3
37.11	ULC speed table point 1	<p>Defines the 1st speed point on the X-axis of the user load curve.</p> <p>The speed points are used in DTC motor control mode, and in scalar motor control mode when speed control is being used.</p> <p>The five points must be in order from lowest to highest. The points are defined as positive values, but the range is symmetrically effective also in the negative direction. The monitoring is not active outside these two areas.</p>	150.0 rpm / real32
	0.0 ... 30000.0 rpm	Speed.	1 = 1 rpm / 10 = 1 rpm
37.12	ULC speed table point 2	<p>Defines the 2nd speed point on the X-axis of the user load curve.</p>	750.0 rpm / real32
	0.0 ... 30000.0 rpm	Speed.	1 = 1 rpm / 10 = 1 rpm
37.13	ULC speed table point 3	<p>Defines the 3rd speed point on the X-axis of the user load curve.</p>	1290.0 rpm / real32
	0.0 ... 30000.0 rpm	Speed.	1 = 1 rpm / 10 = 1 rpm
37.14	ULC speed table point 4	<p>Defines the 4th speed point on the X-axis of the user load curve.</p>	1500.0 rpm / real32
	0.0 ... 30000.0 rpm	Speed.	1 = 1 rpm / 10 = 1 rpm
37.15	ULC speed table point 5	<p>Defines the 5th speed point on the X-axis of the user load curve.</p>	1800.0 rpm / real32
	0.0 ... 30000.0 rpm	Speed.	1 = 1 rpm / 10 = 1 rpm
37.16	ULC frequency table point 1	<p>Defines the 1st frequency point on the X-axis of the user load curve.</p> <p>The frequency points are used in scalar motor control mode when frequency control is being used.</p> <p>The five points must be in order from lowest to highest. The points are defined as positive values, but the range is symmetrically effective also in the negative direction. The monitoring is not active outside these two areas.</p>	5.0 Hz / real32
	0.0 ... 598.0 Hz	Frequency.	1 = 1 Hz / 10 = 1 Hz
37.17	ULC frequency table point 2	<p>Defines the 2nd frequency point on the X-axis of the user load curve.</p>	25.0 Hz / real32

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	0.0 ... 598.0 Hz	Frequency.	1 = 1 Hz / 10 = 1 Hz
37.18	ULC frequency table point 3	Defines the 3rd frequency point on the X-axis of the user load curve.	43.0 Hz / real32
	0.0 ... 598.0 Hz	Frequency.	1 = 1 Hz / 10 = 1 Hz
37.19	ULC frequency table point 4	Defines the 4th frequency point on the X-axis of the user load curve.	50.0 Hz / real32
	0.0 ... 598.0 Hz	Frequency.	1 = 1 Hz / 10 = 1 Hz
37.20	ULC frequency table point 5	Defines the 5th frequency point on the X-axis of the user load curve.	60.0 Hz / real32
	0.0 ... 598.0 Hz	Frequency.	1 = 1 Hz / 10 = 1 Hz
37.21	ULC underload point 1	Defines the 1st point of the underload curve. Each point of the underload curve must have a lower value than the corresponding overload point.	10.0 % / real32
	0.0 ... 1600.0 %	Underload point.	1 = 1 % / 10 = 1 %
37.22	ULC underload point 2	Defines the 2nd point of the underload curve.	15.0 % / real32
	0.0 ... 1600.0 %	Underload point.	1 = 1 % / 10 = 1 %
37.23	ULC underload point 3	Defines the 3rd point of the underload curve.	25.0 % / real32
	0.0 ... 1600.0 %	Underload point.	1 = 1 % / 10 = 1 %
37.24	ULC underload point 4	Defines the 4th point of the underload curve.	30.0 % / real32
	0.0 ... 1600.0 %	Underload point.	1 = 1 % / 10 = 1 %
37.25	ULC underload point 5	Defines the 5th point of the underload curve.	30.0 % / real32
	0.0 ... 1600.0 %	Underload point.	1 = 1 % / 10 = 1 %
37.31	ULC overload point 1	Defines the 1st point of the overload curve. Each point of the overload curve must have a higher value than the corresponding underload point.	300.0 % / real32
	0.0 ... 1600.0 %	Overload point.	1 = 1 % / 10 = 1 %
37.32	ULC overload point 2	Defines the 2nd point of the overload curve.	300.0 % / real32
	0.0 ... 1600.0 %	Overload point.	1 = 1 % / 10 = 1 %
37.33	ULC overload point 3	Defines the 3rd point of the overload curve.	300.0 % / real32
	0.0 ... 1600.0 %	Overload point.	1 = 1 % / 10 = 1 %
37.34	ULC overload point 4	Defines the 4th point of the overload curve.	300.0 % / real32
	0.0 ... 1600.0 %	Overload point.	1 = 1 % / 10 = 1 %
37.35	ULC overload point 5	Defines the 5th point of the overload curve.	300.0 % / real32

## 398 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	0.0 ... 1600.0 %	Overload point.	1 = 1 % / 10 = 1 %
37.41	ULC overload timer	Defines the time for which the monitored signal must continuously stay above the overload curve before the drive takes the action selected by <a href="#">37.3 ULC overload actions</a> .	20.0 s / real32
	0.0 ... 10000.0 s	Overload timer.	1 = 1 s / 10 = 1 s
37.42	ULC underload timer	Defines the time for which the monitored signal must continuously stay below the underload curve before the drive takes the action selected by <a href="#">37.4 ULC underload actions</a> .	20.0 s / real32
	0.0 ... 10000.0 s	Underload timer.	1 = 1 s / 10 = 1 s

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
40	Process PID set 1	<p>Parameter values for process PID control.</p> <p>The drive contains a single active PID controller for process use, however two separate complete set-ups can be programmed and stored.</p> <p>The first set is made up of parameters <a href="#">40.07...40.56*</a>, the second set is defined by the parameters in group <a href="#">41 Process PID set 2</a>. The binary source that defines which set is used is selected by parameter <a href="#">40.57 PID set1/set2 selection</a>.</p> <p>See section <a href="#">Process PID control (page 71)</a>, and the control chain diagrams on pages <a href="#">684</a> and <a href="#">685</a>.</p> <p>*The remaining parameters in this group are common for both sets.</p>	
40.1	Process PID output actual	<p>Displays the output of the process PID controller. See the control chain diagram on page <a href="#">685</a>.</p> <p>This parameter is read-only. The unit is selected by parameter <a href="#">40.12 Set 1 unit selection</a>.</p>	- / real32
	-32768.0 ... 32767.0	Process PID controller output.	1 = 1 / 10 = 1
40.2	Process PID feedback actual	<p>Displays the value of process feedback after source selection, mathematical function (parameter <a href="#">40.10 Set 1 feedback function</a>), and filtering. See the control chain diagram on page <a href="#">684</a>.</p> <p>This parameter is read-only. The unit is selected by parameter <a href="#">40.12 Set 1 unit selection</a>.</p>	- / real32
	-32768.00 ... 32767.00	Process feedback.	1 = 1 / 100 = 1
40.3	Process PID setpoint actual	<p>Displays the value of process PID setpoint after source selection, mathematical function (<a href="#">40.18 Set 1 setpoint function</a>), limitation and ramping. See the control chain diagram on page <a href="#">685</a>.</p> <p>This parameter is read-only. The unit is selected by parameter <a href="#">40.12 Set 1 unit selection</a>.</p>	- / real32
	-32768.00 ... 32767.00	Setpoint for process PID controller.	1 = 1 / 100 = 1
40.4	Process PID deviation actual	<p>Displays the process PID deviation. By default, this value equals setpoint - feedback, but deviation can be inverted by parameter <a href="#">40.31 Set 1 deviation inversion</a>. See the control chain diagram on page <a href="#">685</a>.</p> <p>This parameter is read-only. The unit is selected by parameter <a href="#">40.12 Set 1 unit selection</a>.</p>	- / real32
	-32768.00 ... 32767.00	PID deviation.	1 = 1 / 100 = 1
40.5	Process PID trim output act	<p>Displays the trimmed reference output. See the control chain diagram on page <a href="#">685</a>.</p> <p>This parameter is read-only. The unit is selected by parameter <a href="#">40.12 Set 1 unit selection</a>.</p>	- / real32

## 400 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	-32768...32767	Trimmed reference.	1 = 1 / 1 = 1
40.6	Process PID status word	Displays status information on process PID control. This parameter is read-only.	- / uint16
	b0 PID active	1 = Process PID control active.	
	b1 Setpoint frozen	1 = Process PID setpoint frozen.	
	b2 Output frozen	1 = Process PID controller output frozen.	
	b3 PID sleep mode	1 = Sleep mode active.	
	b4 Sleep boost	1 = Sleep boost active.	
	b5 Trim mode	1 = Trim function active.	
	b6 Tracking mode	1 = Tracking function active.	
	b7 Output limit high	1 = PID output is being limited by par. <a href="#">40.37</a> .	
	b8 Output limit low	1 = PID output is being limited by par. <a href="#">40.36</a> .	
	b9 Deadband active	1 = Deadband active (see par. <a href="#">40.39</a> )	
	b10 PID set	0 = Parameter set 1 in use. 1 = Parameter set 2 in use.	
	b11 Reserved		
	b12 Internal setpoint active	1 = Internal setpoint active (see par. <a href="#">40.16...40.24</a> )	
	b13...15 Reserved		
	0000h...FFFFh		1 = 1 / 1 = 1
40.7	Set 1 PID operation mode	Activates/deactivates process PID control. See also parameter <a href="#">40.60 Set 1 PID activation source</a> .  <b>Note:</b> Process PID control is only available in external control; see section <a href="#">Local control vs. external control</a> .	Off / uint16
	Off	Process PID control inactive.	0
	On	Process PID control active.	1
	On when drive running	Process PID control is active when the drive is running.	2
40.8	Set 1 feedback 1 source	Selects the first source of process feedback. See the control chain diagram on page <a href="#">684</a> .	AI1 scaled / uint32
	Not selected	None.	0
	AI1 scaled	<a href="#">12.12 AI1 scaled value (page 201)</a> .	1
	AI2 scaled	<a href="#">12.22 AI2 scaled value (page 203)</a> .	2
	Freq in scaled	<a href="#">11.39 Freq in 1 scaled</a> .	3
	Motor current	<a href="#">1.7 Motor current</a> .	5
	Power inu out	<a href="#">1.14 Output power</a> .	6
	Motor torque	<a href="#">1.10 Motor torque (page 138)</a> .	7



No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	Feedback data storage	<a href="#">40.91 Feedback data storage (page 413)</a> .	10
	Other [bit]	Source selection (see <a href="#">Terms and abbreviations (page 134)</a> ).	-
40.9	Set 1 feedback 2 source	Selects the second source of process feedback. For the selections, see parameter <a href="#">40.8 Set 1 feedback 1 source</a> .	Not selected / uint32
40.10	Set 1 feedback function	Defines how process feedback is calculated from the two feedback sources selected by parameters <a href="#">40.8 Set 1 feedback 1 source</a> and <a href="#">40.9 Set 1 feedback 2 source</a> .	In1 / uint16
	In1	Source 1.	0
	In1+In2	Sum of sources 1 and 2.	1
	In1-In2	Source 2 subtracted from source 1.	2
	In1*In2	Source 1 multiplied by source 2.	3
	In1/In2	Source 1 divided by source 2.	4
	MIN(In1,In2)	Smaller of the two sources.	5
	MAX(In1,In2)	Greater of the two sources.	6
	AVE(In1,In2)	Average of the two sources.	7
	sqrt(In1)	Square root of source 1.	8
	sqrt(In1-In2)	Square root of (source 1 - source 2).	9
	sqrt(In1+In2)	Square root of (source 1 + source 2).	10
	sqrt(In1)+sqrt(In2)	Square root of source 1 + square root of source 2.	11
40.11	Set 1 feedback filter time	Defines the filter time constant for process feedback.	0.000 s / real32
	0.000 ... 30.000 s	Feedback filter time.	1 = 1 s / 1000 = 1 s
40.12	Set 1 unit selection	Defines the unit for parameters <a href="#">40.01...40.05</a> , <a href="#">40.21...40.24</a> and <a href="#">40.47</a> .	% / uint16
	rpm	rpm.	7
	%	%.	4
	Hz	Hz.	3
	PID user unit 1	User-definable unit 1. The name of the unit can be edited on the control panel by choosing Menu – Settings – Edit texts.	250

## 402 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
40.14	Set 1 setpoint scaling	<p>Defines, together with parameter <a href="#">40.15 Set 1 output scaling</a>, a general scaling factor for the process PID control chain.</p> <p>The scaling can be utilized when, for example, the process setpoint is input in Hz, and the output of the PID controller is used as an rpm value in speed control. In this case, this parameter might be set to 50, and parameter <a href="#">40.15</a> to the nominal motor speed at 50 Hz.</p> <p>In effect, the output of the PID controller = <math>[40.15]</math> when deviation (setpoint - feedback) = <math>[40.14]</math> and <math>[40.32] = 1</math>.</p> <p><b>Note:</b> The scaling is based on the ratio between <a href="#">40.14</a> and <a href="#">40.15</a>. For example, the values 50 and 1500 would produce the same scaling as 1 and 30.</p>	100.00 / real32
	-32768.00 ... 32767.00	Process setpoint base.	$1 = 1 / 100 = 1$
40.15	Set 1 output scaling	See parameter <a href="#">40.14 Set 1 setpoint scaling</a> .	1500.00; 1800.00 (95.20 b0) / real32
	-32768.00 ... 32767.00	Process PID controller output base.	$1 = 1 / 100 = 1$
40.16	Set 1 setpoint 1 source	Selects the first source of process PID setpoint. This setpoint is available in parameter <a href="#">40.25 Set 1 setpoint selection</a> as setpoint 1. See the control chain diagram on page 684.	Internal setpoint / uint32
	Not selected	None.	0
	Control panel	<a href="#">3.1 Panel reference (page 144)</a> . See section <a href="#">Local control vs. external control (page 23)</a> .	1
	Internal setpoint	Internal setpoint. See parameter <a href="#">40.19 Set 1 internal setpoint sel1</a> .	2
	AI1 scaled	<a href="#">12.12 AI1 scaled value (page 201)</a> .	3
	AI2 scaled	<a href="#">12.22 AI2 scaled value (page 203)</a> .	4
	Motor potentiometer	<a href="#">22.80 Motor potentiometer ref act</a> (output of the motor potentiometer).	8
	Freq in scaled	<a href="#">11.39 Freq in 1 scaled</a> .	10
	Setpoint data storage	<a href="#">40.92 Setpoint data storage (page 413)</a> .	24
	Other [bit]	Source selection (see <a href="#">Terms and abbreviations (page 134)</a> ).	-
40.17	Set 1 setpoint 2 source	<p>Selects the second source of process setpoint. This setpoint is available in parameter <a href="#">40.25 Set 1 setpoint selection</a> as setpoint 2.</p> <p>For the selections, see parameter <a href="#">40.16 Set 1 setpoint 1 source</a>.</p>	Not selected / uint32
40.18	Set 1 setpoint function	Selects a mathematical function between the setpoint sources selected by parameters <a href="#">40.16 Set 1 setpoint 1 source</a> and <a href="#">40.17 Set 1 setpoint 2 source</a> .	In1 or In2 / uint16


No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b															
	ln1 or ln2	No mathematical function applied. The source selected by parameter <a href="#">40.25 Set 1 setpoint selection</a> is used.	0															
	ln1+ln2	Sum of sources 1 and 2.	1															
	ln1-ln2	Source 2 subtracted from source 1.	2															
	ln1*ln2	Source 1 multiplied by source 2.	3															
	ln1/ln2	Source 1 divided by source 2.	4															
	MIN(ln1,ln2)	Smaller of the two sources.	5															
	MAX(ln1,ln2)	Greater of the two sources.	6															
	AVE(ln1,ln2)	Average of the two sources.	7															
	sqrt(ln1)	Square root of source 1.	8															
	sqrt(ln1-ln2)	Square root of (source 1 - source 2).	9															
	sqrt(ln1+ln2)	Square root of (source 1 + source 2).	10															
	sqrt(ln1)+sqrt(ln2)	Square root of source 1 + square root of source 2.	11															
40.19	Set 1 internal setpoint sel1	Selects, together with <a href="#">40.20 Set 1 internal setpoint sel2</a> , the internal setpoint out of the presets defined by parameters <a href="#">40.21...40.24</a> .	Not selected / uint32															
		<table border="1"> <thead> <tr> <th>Source defined by par. <a href="#">40.19</a></th> <th>Source defined by par. <a href="#">40.20</a></th> <th>Setpoint preset active</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>1 (par. <a href="#">40.21</a>)</td> </tr> <tr> <td>1</td> <td>0</td> <td>2 (par. <a href="#">40.22</a>)</td> </tr> <tr> <td>0</td> <td>1</td> <td>3 (par. <a href="#">40.23</a>)</td> </tr> <tr> <td>1</td> <td>1</td> <td>4 (par. <a href="#">40.24</a>)</td> </tr> </tbody> </table>	Source defined by par. <a href="#">40.19</a>	Source defined by par. <a href="#">40.20</a>	Setpoint preset active	0	0	1 (par. <a href="#">40.21</a> )	1	0	2 (par. <a href="#">40.22</a> )	0	1	3 (par. <a href="#">40.23</a> )	1	1	4 (par. <a href="#">40.24</a> )	
		Source defined by par. <a href="#">40.19</a>	Source defined by par. <a href="#">40.20</a>	Setpoint preset active														
		0	0	1 (par. <a href="#">40.21</a> )														
		1	0	2 (par. <a href="#">40.22</a> )														
0	1	3 (par. <a href="#">40.23</a> )																
1	1	4 (par. <a href="#">40.24</a> )																
Not selected	0	0																
Selected	1	1																
	DI1	Digital input DI1 ( <a href="#">10.2 DI delayed status</a> , bit 0).	2															
	DI2	Digital input DI2 ( <a href="#">10.2 DI delayed status</a> , bit 1).	3															
	DI3	Digital input DI3 ( <a href="#">10.2 DI delayed status</a> , bit 2).	4															
	DI4	Digital input DI4 ( <a href="#">10.2 DI delayed status</a> , bit 3).	5															
	DI5	Digital input DI5 ( <a href="#">10.2 DI delayed status</a> , bit 4).	6															
	DI6	Digital input DI6 ( <a href="#">10.2 DI delayed status</a> , bit 5).	7															
	DIO1	Digital input/output DIO1 ( <a href="#">11.2 DIO delayed status</a> , bit 0).	10															
	DIO2	Digital input/output DIO2 ( <a href="#">11.2 DIO delayed status</a> , bit 1).	11															
	Other [bit]	See <a href="#">Terms and abbreviations</a> (page 134).	-															
40.20	Set 1 internal setpoint sel2	Selects, together with <a href="#">40.19 Set 1 internal setpoint sel1</a> , the internal setpoint out of the presets defined by parameters <a href="#">40.21...40.24</a> . See table at <a href="#">40.19 Set 1 internal setpoint sel1</a> .	Not selected / uint32															


## 404 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	Not selected	0	0
	Selected	1	1
	DI1	Digital input DI1 (10.2 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.2 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.2 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.2 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.2 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.2 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1 (11.2 DIO delayed status, bit 0).	10
	DIO2	Digital input/output DIO2 (11.2 DIO delayed status, bit 1).	11
	Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-
40.21	Set 1 internal setpoint 1	Defines process setpoint preset 1. See parameter <a href="#">40.19 Set 1 internal setpoint sel</a> . The unit is selected by parameter <a href="#">40.12 Set 1 unit selection</a> .	- / real32
	-32768.00 ... 32767.00	Process setpoint preset 1.	1 = 1 / 100 = 1
40.22	Set 1 internal setpoint 2	Defines process setpoint preset 2. See parameter <a href="#">40.19 Set 1 internal setpoint sel</a> . The unit is selected by parameter <a href="#">40.12 Set 1 unit selection</a> .	- / real32
	-32768.00 ... 32767.00	Process setpoint preset 2.	1 = 1 / 100 = 1
40.23	Set 1 internal setpoint 3	Defines process setpoint preset 3. See parameter <a href="#">40.19 Set 1 internal setpoint sel</a> . The unit is selected by parameter <a href="#">40.12 Set 1 unit selection</a> .	- / real32
	-32768.00 ... 32767.00	Process setpoint preset 3.	1 = 1 / 100 = 1
40.24	Set 1 internal setpoint 4	Defines process setpoint preset 4. See parameter <a href="#">40.19 Set 1 internal setpoint sel</a> . The unit is selected by parameter <a href="#">40.12 Set 1 unit selection</a> .	- / real32
	-32768.00 ... 32767.00	Process setpoint preset 4.	1 = 1 / 100 = 1
40.25	Set 1 setpoint selection	Configures the selection between setpoint sources 1 ( <a href="#">40.16</a> ) and 2 ( <a href="#">40.17</a> ). This parameter is only effective when parameter <a href="#">40.18 Set 1 setpoint function</a> is set to In1 or In2. 0 = Setpoint source 1 1 = Setpoint source 2	Setpoint source 1 / uint32


No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	Setpoint source 1	0.	0
	Setpoint source 2	1.	1
	DI1	Digital input DI1 (10.2 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.2 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.2 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.2 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.2 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.2 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1 (11.2 DIO delayed status, bit 0).	10
	DIO2	Digital input/output DIO2 (11.2 DIO delayed status, bit 1).	11
	Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-
40.26	Set 1 setpoint min	Defines a minimum limit for the process PID controller setpoint.	0.00 / real32
	-32768.00 ... 32767.00	Minimum limit for process PID controller setpoint.	1 = 1 / 100 = 1
40.27	Set 1 setpoint max	Defines a maximum limit for the process PID controller setpoint.	32767.00 / real32
	-32768.00 ... 32767.00	Maximum limit for process PID controller setpoint.	1 = 1 / 100 = 1
40.28	Set 1 setpoint increase time	Defines the minimum time it takes for the setpoint to increase from 0% to 100%.	0.0 s / real32
	0.0 ... 1800.0 s	Setpoint increase time.	1 = 1 s / 10 = 1 s
40.29	Set 1 setpoint decrease time	Defines the minimum time it takes for the setpoint to decrease from 100% to 0%.	0.0 s / real32
	0.0 ... 1800.0 s	Setpoint decrease time.	1 = 1 s / 10 = 1 s
40.30	Set 1 setpoint freeze enable	Freezes, or defines a source that can be used to freeze, the setpoint of the process PID controller. This feature is useful when the reference is based on a process feedback connected to an analog input, and the sensor must be serviced without stopping the process.  1 = Process PID controller setpoint frozen  See also parameter <a href="#">40.38 Set 1 output freeze enable</a> .	Not selected / uint32
	Not selected	0	0
	Selected	1	1
	DI1	Digital input DI1 (10.2 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.2 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.2 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.2 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.2 DI delayed status, bit 4).	6

406 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	DI6	Digital input DI6 (10.2 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1 (11.2 DIO delayed status, bit 0).	10
	DIO2	Digital input/output DIO2 (11.2 DIO delayed status, bit 1).	11
	Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-
40.31	Set 1 deviation inversion	Inverts the input of the process PID controller. 0 = Deviation not inverted (Deviation = Setpoint - Feedback) 1 = Deviation inverted (Deviation = Feedback - Setpoint) See also section <a href="#">Process PID control (page 71)</a> .	Not inverted (Ref - Fbk) / uint32
	Not inverted (Ref - Fbk)	0.	0
	Inverted (Fbk - Ref)	1.	1
	Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-
40.32	Set 1 gain	Defines the gain for the process PID controller. See parameter <a href="#">40.33 Set 1 integration time</a> .	1.00 / real32
	0.10 ... 100.00	Gain for PID controller.	100 = 1 / 100 = 1
40.33	Set 1 integration time	Defines the integration time for the process PID controller. This time needs to be set to the same order of magnitude as the reaction time of the process being controlled, otherwise instability will result.  <p style="text-align: center;"><i>Error/Controller output</i></p> <p style="text-align: center;">Time</p> <p>I = controller input (error)                      O = controller output                      G = gain                      Ti = integration time</p> <p><b>Note:</b> Setting this value to 0 disables the “I” part, turning the PID controller into a PD controller.</p>	60.0 s / real32
	0.0 ... 32767.0 s	Integration time.	1 = 1 s / 10 = 1 s

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
40.34	Set 1 derivation time	Defines the derivation time of the process PID controller. The derivative component at the controller output is calculated on basis of two consecutive error values ( $E_{K-1}$ and $E_K$ ) according to the following formula: $\text{PID DERIV TIME} \times (E_K - E_{K-1}) / T_S$ in which $T_S = 2 \text{ ms sample time}$ $E = \text{Error} = \text{Process reference} - \text{process feedback}.$	0.000 s / real32
	0.000 ... 10.000 s	Derivation time.	1000 = 1 s / 1000 = 1 s
40.35	Set 1 derivation filter time	Defines the time constant of the 1-pole filter used to smooth the derivative component of the process PID controller.  $O = I \times (1 - e^{-t/T})$ $I = \text{filter input (step)}$ $O = \text{filter output}$ $t = \text{time}$ $T = \text{filter time constant}$	0.0 s / real32
	0.0 ... 10.0 s	Filter time constant.	10 = 1 s / 10 = 1 s
40.36	Set 1 output min	Defines the minimum limit for the process PID controller output. Using the minimum and maximum limits, it is possible to restrict the operation range.	0.0 / real32
	-32768.0 ... 32767.0	Minimum limit for process PID controller output.	1 = 1 / 10 = 1
40.37	Set 1 output max	Defines the maximum limit for the process PID controller output. See parameter <a href="#">40.36 Set 1 output min</a> .	1500.0; 1800.0 (95.20 b0) / real32
	-32768.0 ... 32767.0	Maximum limit for process PID controller output.	1 = 1 / 10 = 1
40.38	Set 1 output freeze enable	Freezes (or defines a source that can be used to freeze) the output of the process PID controller, keeping the output at the value it was before freeze was enabled. This feature can be used when, for example, a sensor providing process feedback must to be serviced without stopping the process. $1 = \text{Process PID controller output frozen}$ See also parameter <a href="#">40.30 Set 1 setpoint freeze enable</a> .	Not selected / uint32

## 408 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	Not selected	Process PID controller output not frozen.	0
	Selected	Process PID controller output frozen.	1
	DI1	Digital input DI1 (10.2 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.2 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.2 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.2 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.2 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.2 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1 (11.2 DIO delayed status, bit 0).	10
	DIO2	Digital input/output DIO2 (11.2 DIO delayed status, bit 1).	11
	Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-
40.39	Set 1 deadband range	<p>Defines a deadband around the setpoint. Whenever process feedback enters the deadband, a delay timer starts. If the feedback remains within the deadband longer than the delay (40.40 Set 1 deadband delay), the PID controller output is frozen. Normal operation resumes after the feedback value leaves the deadband.</p> 	0.0 / real32
	0.0 ... 32767.0	Deadband range.	1 = 1 / 10 = 1
40.40	Set 1 deadband delay	Delay for the deadband. See parameter <a href="#">40.39 Set 1 deadband range</a> .	0.0 s / real32
	0.0 ... 3600.0 s	Delay for deadband area.	1 = 1 s / 10 = 1 s
40.41	Set 1 sleep mode	<p>Selects the mode of the sleep function.</p> <p>See also section <a href="#">Process PID control (page 71)</a>.</p>	Not selected / uint16
	Not selected	Sleep function disabled.	0
	Internal	<p>The output of the PID controller is compared to the value of <a href="#">40.43 Set 1 sleep level</a>.</p> <p>If the PID controller output remains below the sleep level longer than the sleep delay (<a href="#">40.44 Set 1 sleep delay</a>), the drive enters sleep mode.</p> <p>Parameters <a href="#">40.44...40.48</a> are in force.</p>	1



No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	External	The sleep function is activated by the source selected by parameter 40.42 Set 1 sleep enable. Parameters 40.44...40.46 and 40.48 are in force.	2
40.42	Set 1 sleep enable	Defines a source that is used to activate the PID sleep function when parameter 40.41 Set 1 sleep mode is set to External.  0 = Sleep function disabled 1 = Sleep function activated	Not selected / uint32
	Not selected	0	0
	Selected	1	1
	DI1	Digital input DI1 (10.2 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.2 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.2 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.2 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.2 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.2 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1 (11.2 DIO delayed status, bit 0).	10
	DIO2	Digital input/output DIO2 (11.2 DIO delayed status, bit 1).	11
	Other [bit]	See Terms and abbreviations (page 134).	-
40.43	Set 1 sleep level	Defines the start limit for the sleep function when parameter 40.41 Set 1 sleep mode is set to Internal.	0.0 / real32
	0.0 ... 32767.0	Sleep start level.	1 = 1 / 10 = 1
40.44	Set 1 sleep delay	Defines a delay before the sleep function actually becomes enabled, to prevent nuisance sleeping. The delay timer starts when the sleep condition selected by parameter 40.41 Set 1 sleep mode becomes true, and resets if the condition becomes false.	60.0 s / real32
	0.0 ... 3600.0 s	Sleep start delay.	1 = 1 s / 10 = 1 s
40.45	Set 1 sleep boost time	Defines a boost time for the sleep boost step. See parameter 40.46 Set 1 sleep boost step.	0.0 s / real32
	0.0 ... 3600.0 s	Sleep boost time.	1 = 1 s / 10 = 1 s
40.46	Set 1 sleep boost step	When the drive is entering sleep mode, the process setpoint is increased by this value for the time defined by parameter 40.45 Set 1 sleep boost time. If active, sleep boost is aborted when the drive wakes up.	0.0 / real32
	0.0 ... 32767.0	Sleep boost step.	1 = 1 / 10 = 1

## 410 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
40.47	Set 1 wake-up deviation	When <a href="#">40.41 Set 1 sleep mode</a> is set to <a href="#">Internal</a> , this parameter defines the wake-up level as deviation between process setpoint and feedback. The unit is selected by parameter <a href="#">40.12 Set 1 unit selection</a> .  When the deviation exceeds the value of this parameter, and remains there for the duration of the wake-up delay ( <a href="#">40.48 Set 1 wake-up delay</a> ), the drive wakes up.  See also parameter <a href="#">40.31 Set 1 deviation inversion</a> .	- / real32
	-32768.00 ... 32767.00 bar/Pa/psi	Wake-up level (as deviation between process setpoint and feedback).	1 = 1 bar/Pa/psi / 100 = 1 bar/Pa/psi
40.48	Set 1 wake-up delay	Defines a wake-up delay for the sleep function to prevent nuisance wake-ups. See parameter <a href="#">40.47 Set 1 wake-up deviation</a> .  The delay timer starts when the deviation exceeds the wakeup level ( <a href="#">40.47 Set 1 wake-up deviation</a> ), and resets if the deviation falls below the wake-up level.	0.50 s / real32
	0.00 ... 60.00 s	Wake-up delay.	1 = 1 s / 100 = 1 s
40.49	Set 1 tracking mode	Activates (or selects a source that activates) tracking mode. In tracking mode, the value selected by parameter <a href="#">40.50 Set 1 tracking ref selection</a> is substituted for the PID controller output. See also section <a href="#">Process PID control (page 71)</a> .  1 = Tracking mode enabled	Not selected / uint32
	Not selected	0	0
	Selected	1	1
	DI1	Digital input DI1 ( <a href="#">10.2 DI delayed status</a> , bit 0).	2
	DI2	Digital input DI2 ( <a href="#">10.2 DI delayed status</a> , bit 1).	3
	DI3	Digital input DI3 ( <a href="#">10.2 DI delayed status</a> , bit 2).	4
	DI4	Digital input DI4 ( <a href="#">10.2 DI delayed status</a> , bit 3).	5
	DI5	Digital input DI5 ( <a href="#">10.2 DI delayed status</a> , bit 4).	6
	DI6	Digital input DI6 ( <a href="#">10.2 DI delayed status</a> , bit 5).	7
	DIO1	Digital input/output DIO1 ( <a href="#">11.2 DIO delayed status</a> , bit 0).	10
	DIO2	Digital input/output DIO2 ( <a href="#">11.2 DIO delayed status</a> , bit 1).	11
	Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-
40.50	Set 1 tracking ref selection	Selects the value source for tracking mode. See parameter <a href="#">40.49 Set 1 tracking mode</a> .	Not selected / uint32
	Not selected	None.	0
	AI1 scaled	<a href="#">12.12 AI1 scaled value (page 201)</a> .	1
	AI2 scaled	<a href="#">12.22 AI2 scaled value (page 203)</a> .	2
	FB A ref1	<a href="#">3.5 FB A reference 1 (page 144)</a> .	3

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	FB A ref2	<a href="#">3.6 FB A reference 2 (page 144)</a> .	4
	Other [bit]	Source selection (see <a href="#">Terms and abbreviations (page 134)</a> ).	-
40.51	Set 1 trim mode	Activates the trim function and selects between direct and proportional trimming (or a combination of both). With trimming, it is possible to apply a corrective factor to the drive reference (setpoint). The output after trimming is available as parameter <a href="#">40.5 Process PID trim output act</a> . See the control chain diagram on page <a href="#">685</a> .	Off / uint16
	Off	The trim function is inactive.	0
	Direct	The trim function is active. The trimming factor is relative to the maximum speed, torque or frequency; the selection between these is made by parameter <a href="#">40.52 Set 1 trim selection</a> .	1
	Proportional	The trim function is active. The trimming factor is relative to the reference selected by parameter <a href="#">40.53 Set 1 trimmed ref pointer</a> .	2
	Combined	The trim function is active. The trimming factor is a combination of both <a href="#">Direct</a> and <a href="#">Proportional</a> modes; the proportions of each are defined by parameter <a href="#">40.54 Set 1 trim mix</a> .	3
40.52	Set 1 trim selection	Selects whether trimming is used for correcting the speed, torque or frequency reference.	Torque / uint16
	Torque	Torque reference trimming.	1
	Speed	Speed reference trimming.	2
	Frequency	Frequency reference trimming.	3
40.53	Set 1 trimmed ref pointer	Selects the signal source for the trim reference.	Not selected / uint32
	Not selected	None.	0
	AI1 scaled	<a href="#">12.12 AI1 scaled value (page 201)</a> .	1
	AI2 scaled	<a href="#">12.22 AI2 scaled value (page 203)</a> .	2
	FB A ref1	<a href="#">3.5 FB A reference 1 (page 144)</a> .	3
	FB A ref2	<a href="#">3.6 FB A reference 2 (page 144)</a> .	4
	Other [bit]	Source selection (see <a href="#">Terms and abbreviations (page 134)</a> ).	-
40.54	Set 1 trim mix	When parameter <a href="#">40.51 Set 1 trim mode</a> is set to <a href="#">Combined</a> , defines the effect of direct and proportional trim sources in the final trimming factor. 0.000 = 100% proportional 0.500 = 50% proportional, 50% direct 1.000 = 100% direct	0.000 / real32
	0.000 ... 1.000	Trim mix.	1 = 1 / 1000 = 1

## 412 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
40.55	Set 1 trim adjust	Defines a multiplier for the trimming factor. This value is multiplied by the result of parameter <a href="#">40.51 Set 1 trim mode</a> . Consequently, the result of the multiplication is used to multiply the result of parameter <a href="#">40.56 Set 1 trim source</a> .	1.000 / real32
	-100.000 ... 100.000	Multiplier for trimming factor.	1 = 1 / 1000 = 1
40.56	Set 1 trim source	Selects the reference to be trimmed.	PID ref / uint16
	PID ref	PID setpoint.	1
	PID output	PID controller output.	2
40.57	PID set1/set2 selection	Selects the source that determines whether process PID parameter set 1 (parameters <a href="#">40.07...40.56</a> ) or set 2 (group <a href="#">41 Process PID set 2</a> ) is used. 0 = Process PID parameter set 1 in use 1 = Process PID parameter set 2 in use	Not selected / uint32
	Not selected	0	0
	Selected	1	1
	DI1	Digital input DI1 ( <a href="#">10.2 DI delayed status</a> , bit 0).	2
	DI2	Digital input DI2 ( <a href="#">10.2 DI delayed status</a> , bit 1).	3
	DI3	Digital input DI3 ( <a href="#">10.2 DI delayed status</a> , bit 2).	4
	DI4	Digital input DI4 ( <a href="#">10.2 DI delayed status</a> , bit 3).	5
	DI5	Digital input DI5 ( <a href="#">10.2 DI delayed status</a> , bit 4).	6
	DI6	Digital input DI6 ( <a href="#">10.2 DI delayed status</a> , bit 5).	7
	DIO1	Digital input/output DIO1 ( <a href="#">11.2 DIO delayed status</a> , bit 0).	10
	DIO2	Digital input/output DIO2 ( <a href="#">11.2 DIO delayed status</a> , bit 1).	11
Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-	
40.60	Set 1 PID activation source	Selects a source that enables/disables process PID control. See also parameter <a href="#">40.7 Set 1 PID operation mode</a> . 0 = Process PID control disabled. 1 = Process PID control enabled.	On / uint32
	Off	0.	0
	On	1.	1
	Follow Ext1/Ext2 selection	Process PID control is disabled when external control location EXT1 is active, and enabled when external control location EXT2 is active. See also parameter <a href="#">19.11 Ext1/Ext2 selection</a> .	2

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	DI1	Digital input DI1 (10.2 DI delayed status, bit 0).	3
	DI2	Digital input DI2 (10.2 DI delayed status, bit 1).	4
	DI3	Digital input DI3 (10.2 DI delayed status, bit 2).	5
	DI4	Digital input DI4 (10.2 DI delayed status, bit 3).	6
	DI5	Digital input DI5 (10.2 DI delayed status, bit 4).	7
	DI6	Digital input DI6 (10.2 DI delayed status, bit 5).	8
	DIO1	Digital input/output DIO1 (11.2 DIO delayed status, bit 0).	11
	DIO2	Digital input/output DIO2 (11.2 DIO delayed status, bit 1).	12
	Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-
40.91	Feedback data storage	Storage parameter for receiving a process feedback value eg. through the embedded fieldbus interface.  The value can be sent to the drive as Modbus I/O data. Set the target selection parameter of that particular data (58.101...58.124) to <a href="#">Feedback data storage</a> . In <a href="#">40.8 Set 1 feedback 1 source</a> (or <a href="#">40.9 Set 1 feedback 2 source</a> ), select <a href="#">Feedback data storage</a> .	0.00 / real32
	-327.68 ... 327.67	Storage parameter for process feedback.	100 = 1 / 100 = 1
40.92	Setpoint data storage	Storage parameter for receiving a process setpoint value eg. through the embedded fieldbus interface.  The value can be sent to the drive as Modbus I/O data. Set the target selection parameter of that particular data (58.101...58.124) to <a href="#">Setpoint data storage</a> . In <a href="#">40.16 Set 1 setpoint 1 source</a> (or <a href="#">40.17 Set 1 setpoint 2 source</a> ), select <a href="#">Setpoint data storage</a> .	0.00 / real32
	-327.68 ... 327.67	Storage parameter for process setpoint.	100 = 1 / 100 = 1

## 414 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
<b>41</b>	Process PID set 2	<p>A second set of parameter values for process PID control.</p> <p>The selection between this set and first set (parameter group <a href="#">40 Process PID set 1</a>) is made by parameter <a href="#">40.57 PID set1/set2 selection</a>.</p> <p>See section <a href="#">Process PID control (page 71)</a>. See also parameters <a href="#">40.01...40.06</a>, <a href="#">40.91</a>, <a href="#">40.92</a>, and the control chain diagrams on pages <a href="#">684</a> and <a href="#">685</a>.</p>	
41.7	Set 2 PID operation mode	See parameter <a href="#">40.7 Set 1 PID operation mode</a> .	Off / uint16
41.8	Set 2 feedback 1 source	See parameter <a href="#">40.8 Set 1 feedback 1 source</a> .	All scaled / uint32
41.9	Set 2 feedback 2 source	See parameter <a href="#">40.9 Set 1 feedback 2 source</a> .	Not selected / uint32
41.10	Set 2 feedback function	See parameter <a href="#">40.10 Set 1 feedback function</a> .	In1 / uint16
41.11	Set 2 feedback filter time	See parameter <a href="#">40.11 Set 1 feedback filter time</a> .	- / real32
41.12	Set 2 unit selection	Defines the unit for parameters <a href="#">41.21...41.24</a> and <a href="#">41.47</a> .	% / uint16
	rpm	rpm.	7
	%	%.	4
	Hz	Hz.	3
	PID user unit 2	User-definable unit 2. The name of the unit can be edited on the control panel by choosing Menu – Settings – Edit texts.	249
41.14	Set 2 setpoint scaling	See parameter <a href="#">40.14 Set 1 setpoint scaling</a> .	- / real32
41.15	Set 2 output scaling	See parameter <a href="#">40.15 Set 1 output scaling</a> .	- / real32
41.16	Set 2 setpoint 1 source	See parameter <a href="#">40.16 Set 1 setpoint 1 source</a> .	Internal setpoint / uint32
41.17	Set 2 setpoint 2 source	See parameter <a href="#">40.17 Set 1 setpoint 2 source</a> .	Not selected / uint32
41.18	Set 2 setpoint function	See parameter <a href="#">40.18 Set 1 setpoint function</a> .	In1 or In2 / uint16
41.19	Set 2 internal setpoint sel1	See parameter <a href="#">40.19 Set 1 internal setpoint sel1</a> .	Not selected / uint32
41.20	Set 2 internal setpoint sel2	See parameter <a href="#">40.20 Set 1 internal setpoint sel2</a> .	Not selected / uint32
41.21	Set 2 internal setpoint 1	See parameter <a href="#">40.21 Set 1 internal setpoint 1</a> .	- / real32
41.22	Set 2 internal setpoint 2	See parameter <a href="#">40.22 Set 1 internal setpoint 2</a> .	- / real32
41.23	Set 2 internal setpoint 3	See parameter <a href="#">40.23 Set 1 internal setpoint 3</a> .	- / real32

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
41.24	Set 2 internal setpoint 4	See parameter 40.24 Set 1 internal setpoint 4.	- / real32
41.25	Set 2 setpoint selection	See parameter 40.25 Set 1 setpoint selection.	Setpoint source 1 / uint32
41.26	Set 2 setpoint min	See parameter 40.26 Set 1 setpoint min.	- / real32
41.27	Set 2 setpoint max	See parameter 40.27 Set 1 setpoint max.	- / real32
41.28	Set 2 setpoint increase time	See parameter 40.28 Set 1 setpoint increase time.	- / real32
41.29	Set 2 setpoint decrease time	See parameter 40.29 Set 1 setpoint decrease time.	- / real32
41.30	Set 2 setpoint freeze enable	See parameter 40.30 Set 1 setpoint freeze enable.	Not selected / uint32
41.31	Set 2 deviation inversion	See parameter 40.31 Set 1 deviation inversion.	Not inverted (Ref - Fbk) / uint32
41.32	Set 2 gain	See parameter 40.32 Set 1 gain.	- / real32
41.33	Set 2 integration time	See parameter 40.33 Set 1 integration time.	- / real32
41.34	Set 2 derivation time	See parameter 40.34 Set 1 derivation time.	- / real32
41.35	Set 2 derivation filter time	See parameter 40.35 Set 1 derivation filter time.	- / real32
41.36	Set 2 output min	See parameter 40.36 Set 1 output min.	- / real32
41.37	Set 2 output max	See parameter 40.37 Set 1 output max.	- / real32
41.38	Set 2 output freeze enable	See parameter 40.38 Set 1 output freeze enable.	Not selected / uint32
41.39	Set 2 deadband range	See parameter 40.39 Set 1 deadband range.	- / real32
41.40	Set 2 deadband delay	See parameter 40.40 Set 1 deadband delay.	- / real32
41.41	Set 2 sleep mode	See parameter 40.41 Set 1 sleep mode.	Not selected / uint16
41.42	Set 2 sleep enable	See parameter 40.42 Set 1 sleep enable.	Not selected / uint32
41.43	Set 2 sleep level	See parameter 40.43 Set 1 sleep level.	- / real32
41.44	Set 2 sleep delay	See parameter 40.44 Set 1 sleep delay.	- / real32
41.45	Set 2 sleep boost time	See parameter 40.45 Set 1 sleep boost time.	- / real32
41.46	Set 2 sleep boost step	See parameter 40.46 Set 1 sleep boost step.	- / real32
41.47	Set 2 wake-up deviation	See parameter 40.47 Set 1 wake-up deviation.	- / real32
41.48	Set 2 wake-up delay	See parameter 40.48 Set 1 wake-up delay.	- / real32
41.49	Set 2 tracking mode	See parameter 40.49 Set 1 tracking mode.	Not selected / uint32

## 416 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
41.50	Set 2 tracking ref selection	See parameter <a href="#">40.50 Set 1 tracking ref selection.</a>	Not selected / uint32
41.51	Set 2 trim mode	See parameter <a href="#">40.51 Set 1 trim mode.</a>	Off / uint16
41.52	Set 2 trim selection	See parameter <a href="#">40.52 Set 1 trim selection.</a>	Torque / uint16
41.53	Set 2 trimmed ref pointer	See parameter <a href="#">40.53 Set 1 trimmed ref pointer.</a>	Not selected / uint32
41.54	Set 2 trim mix	See parameter <a href="#">40.54 Set 1 trim mix.</a>	- / real32
41.55	Set 2 trim adjust	See parameter <a href="#">40.55 Set 1 trim adjust.</a>	- / real32
41.56	Set 2 trim source	See parameter <a href="#">40.56 Set 1 trim source.</a>	PID ref / uint16
41.60	Set 2 PID activation source	See parameter <a href="#">40.60 Set 1 PID activation source.</a>	On / uint32

---



No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
<b>43</b>	Brake chopper	Settings for the internal brake chopper. See also section <a href="#">DC voltage control (page 80)</a> .	
43.1	Brake resistor temperature	Displays the estimated temperature of the brake resistor, or how close the brake resistor is to being too hot.  The value is given in percent where 100% is the eventual temperature the resistor would reach when loaded long enough with its rated maximum load capacity ( <a href="#">43.9 Brake resistor max cont power</a> ).  The temperature calculation is based on the values of parameters <a href="#">43.08</a> , <a href="#">43.09</a> and <a href="#">43.10</a> , and on the assumption that the resistor is installed as instructed by the manufacturer (ie. it cools down as expected).  This parameter is read-only.	- / real32
	0.0 ... 120.0 %	Estimated brake resistor temperature.	1 = 1 % / 1000 = 1 %
43.6	Brake chopper function	Enables brake chopper control and selects the brake resistor overload protection method (calculation or measurement).  <b>Note:</b> Before enabling brake chopper control, ensure that <ul style="list-style-type: none"> <li>• A brake resistor is connected,</li> <li>• Overvoltage control is switched off (parameter <a href="#">30.30 Overvoltage control</a>), and</li> <li>• The supply voltage range (parameter <a href="#">95.1 Supply voltage</a>) has been selected correctly.</li> </ul>	Disabled / uint16
	Disabled	Brake chopper control disabled.	0
	Enabled with thermal model	Brake chopper control enabled with resistor overload protection based on a thermal model. If you select this, you must also specify the values needed by the model, ie. parameters <a href="#">43.08...43.12</a> . See the resistor data sheet.	1
	Enabled without thermal model	Brake chopper control enabled without resistor overload protection based on a thermal model. This setting can be used, for example, if the resistor is equipped with a thermal circuit breaker that is wired to stop the drive if the resistor overheats.  Before using this setting, ensure that overvoltage control is switched off (parameter <a href="#">30.30 Overvoltage control</a> )	2

## 418 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	Overvoltage peak protection	<p>Brake chopper starts to conduct at 100% pulse width whenever</p> <ul style="list-style-type: none"> <li>The DC voltage exceeds the overvoltage fault limit (a hysteresis applies), and</li> <li>The drive is not modulating (for example, during a coast stop).</li> </ul> <p>The thermal model-based resistor overload protection is not active.</p> <p>This setting is intended for situations where</p> <ul style="list-style-type: none"> <li>The braking chopper is not needed for runtime operation, ie. to dissipate the inertial energy of the motor,</li> <li>The motor is able to store a considerable amount of magnetic energy in its windings, and</li> <li>The motor might, deliberately or inadvertently, be stopped by coasting.</li> </ul> <p>In such a situation, the motor would potentially discharge enough magnetic energy towards the drive to cause damage.</p> <p>To protect the drive, the brake chopper can be used with a small resistor dimensioned merely to handle the magnetic energy (not the inertial energy) of the motor.</p>	3
43.7	Brake chopper run enable	<p>Selects the source for quick brake chopper on/off control.</p> <p>0 = Brake chopper IGBT pulses are cut off</p> <p>1 = Normal brake chopper IGBT modulation allowed.</p> <p>This parameter can be used to enable chopper operation only when the supply is missing from a drive with a regenerative supply unit.</p>	On / uint32
	Off	0.	0
	On	1.	1
	Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-
43.8	Brake resistor thermal tc	Defines the thermal time constant for the brake resistor thermal model.	0 s / real32
	0...10000 s	Brake resistor thermal time constant, ie. the rated time to achieve 63% temperature.	1 = 1 s / 1 = 1 s
43.9	Brake resistor max cont power	Defines the maximum continuous load of the brake resistor which will eventually raise the resistor temperature to the maximum allowed value (= continuous heat dissipation capacity of the resistor in kW) but not above it. The value is used in the resistor overload protection based on the thermal model. See parameter <a href="#">43.6 Brake chopper function</a> , and the brake resistor data sheet.	0.00 kW / real32
	0.00 ... 10000.00 kW	Maximum continuous load of the brake resistor.	1 = 1 kW / 1 = 1 kW

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
43.10	Brake resistance	Defines the resistance value of the brake resistor. The value is used for the brake chopper protection based on the thermal model. See parameter <a href="#">43.6 Brake chopper function</a> .	0.0 Ohm / real32
	0.0 ... 1000.0 Ohm	Brake resistor resistance value.	1 = 1 Ohm / 1 = 1 Ohm
43.11	Brake resistor fault limit	Selects the fault limit for the brake resistor protection based on the thermal model. See parameter <a href="#">43.6 Brake chopper function</a> . When the limit is exceeded, the drive trips on fault <a href="#">7183 BR excess temperature</a> .  The value is given in percent of the temperature the resistor reaches when loaded with the power defined by parameter <a href="#">43.9 Brake resistor max cont power</a> .	105 % / real32
	0...150 %	Brake resistor temperature fault limit.	1 = 1 % / 1 = 1 %
43.12	Brake resistor warning limit	Selects the warning limit for the brake resistor protection based on the thermal model. See parameter <a href="#">43.6 Brake chopper function</a> . When the limit is exceeded, the drive generates a <a href="#">A793 BR excess temperature warning</a> .  The value is given in percent of the temperature the resistor reaches when loaded with the power defined by parameter <a href="#">43.9 Brake resistor max cont power</a> .	95 % / real32
	0...150 %	Brake resistor temperature warning limit.	1 = 1 % / 1 = 1 %

## 420 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
<b>44</b>	Mechanical brake control	Configuration of mechanical brake control. See also section <a href="#">Mechanical brake control (page 75)</a> .	
44.1	Brake control status	Displays the mechanical brake control status word. This parameter is read-only.	- / uint16
b0	Open command	Close/open command to brake actuator (0 = close, 1 = open). Connect this bit to desired output.	
b1	Opening torque request	1 = Opening torque requested from drive logic	
b2	Hold stopped request	1 = Hold requested from drive logic	
b3	Ramp to stopped	1 = Ramping down to zero speed requested from drive logic	
b4	Enabled	1 = Brake control is enabled	
b5	Closed	1 = Brake control logic in <i>BRAKE CLOSED</i> state. See also section <a href="#">Mechanical brake control (page 75)</a> .	
b6	Opening	1 = Brake control logic in <i>BRAKE OPENING</i> state. See section <a href="#">Mechanical brake control (page 75)</a> .	
b7	Open	1 = Brake control logic in <i>BRAKE OPEN</i> state. See section <a href="#">Mechanical brake control (page 75)</a> .	
b8	Closing	1 = Brake control logic in <i>BRAKE CLOSING</i> state. See section <a href="#">Mechanical brake control (page 75)</a> .	
b9...15	Reserved		
	0000h...FFFFh		1 = 1 / 1 = 1
44.2	Brake torque memory	Displays the torque (in percent) at the instant of the previous brake close command. This value can be used as a reference for the brake open torque. See parameters <a href="#">44.9 Brake open torque source</a> and <a href="#">44.10 Brake open torque</a> . A filtering time for this value can be defined using <a href="#">44.21 Filter time brake torque memory</a> .	- / real32
	-1600.0 ... 1600.0 %	Torque at brake closure. For 16-bit scaling, see parameter <a href="#">46.3</a> .	- / 10 = 1 %
44.3	Brake open torque reference	Displays the currently active brake open torque. See parameters <a href="#">44.9 Brake open torque source</a> and <a href="#">44.10 Brake open torque</a> . This parameter is read-only.	- / real32
	-1600.0 ... 1600.0 %	Currently active brake open torque. For 16-bit scaling, see parameter <a href="#">46.3</a> .	- / 10 = 1 %

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
44.6	Brake control enable	Activates/deactivates (or selects a source that activates/deactivates) the mechanical brake control logic.  0 = Brake control inactive 1 = Brake control active  <b>Note:</b> This parameter cannot be changed while the drive is running.	Not selected / uint32
	Not selected	0	0
	Selected	1	1
	DI1	Digital input DI1 (10.2 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.2 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.2 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.2 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.2 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.2 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1 (11.2 DIO delayed status, bit 0).	10
	DIO2	Digital input/output DIO2 (11.2 DIO delayed status, bit 1).	11
	Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-
44.7	Brake acknowledge selection	Activates/deactivates (and selects the source for) brake open/close status (acknowledgement) supervision.  When a brake control error (unexpected state of the acknowledgement signal) is detected, the drive reacts as defined by parameter 44.17 <a href="#">Brake fault function</a> .  0 = Brake closed 1 = Brake open	No acknowledge / uint32
	Off	0.	0
	On	1.	1
	No acknowledge	Brake open/closed supervision disabled.	2
	DI1	Digital input DI1 (10.2 DI delayed status, bit 0).	3
	DI2	Digital input DI2 (10.2 DI delayed status, bit 1).	4
	DI3	Digital input DI3 (10.2 DI delayed status, bit 2).	5
	DI4	Digital input DI4 (10.2 DI delayed status, bit 3).	6
	DI5	Digital input DI5 (10.2 DI delayed status, bit 4).	7
	DI6	Digital input DI6 (10.2 DI delayed status, bit 5).	8
	DIO1	Digital input/output DIO1 (11.2 DIO delayed status, bit 0).	11
	DIO2	Digital input/output DIO2 (11.2 DIO delayed status, bit 1).	12

## 422 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-
44.8	Brake open delay	<p>Defines the brake open delay, ie. the delay between the internal open brake command and the release of motor speed control. The delay timer starts when the drive has magnetized the motor and increased the motor torque to the level required for brake release (parameter <a href="#">44.3 Brake open torque reference</a>). Simultaneously with the timer start, the brake control logic energizes the brake control output and the brake starts to open.</p> <p>Set this parameter to the value of mechanical opening delay specified by the brake manufacturer.</p>	0.00 s / real32
	0.00 ... 5.00 s	Brake open delay.	100 = 1 s / 100 = 1 s
44.9	Brake open torque source	<p>Defines a source that is used as a brake opening torque reference if</p> <ul style="list-style-type: none"> <li>its absolute value is greater than the setting of parameter <a href="#">44.10 Brake open torque</a>, and</li> <li>its sign is the same as the setting of <a href="#">44.10 Brake open torque</a>.</li> </ul> <p>See parameter <a href="#">44.10 Brake open torque</a>.</p>	Brake open torque / uint32
	Zero	Zero.	0
	AI1 scaled	<a href="#">12.12 AI1 scaled value (page 201)</a> .	1
	AI2 scaled	<a href="#">12.22 AI2 scaled value (page 203)</a> .	2
	FBA ref1	<a href="#">3.5 FB A reference 1 (page 144)</a> .	3
	FBA ref2	<a href="#">3.6 FB A reference 2 (page 144)</a> .	4
	Brake torque memory	Parameter <a href="#">44.2 Brake torque memory</a> .	7
	Brake open torque	Parameter <a href="#">44.10 Brake open torque</a> .	8
	Other [bit]	Source selection (see <a href="#">Terms and abbreviations (page 134)</a> ).	-
44.10	Brake open torque	<p>Defines the sign (ie. direction of rotation) and minimum absolute value of the brake open torque (motor torque requested at brake release in percent of motor nominal torque).</p> <p>The value of the source selected by parameter <a href="#">44.9 Brake open torque source</a> is used as the brake open torque only if it has the same sign as this parameter and has a greater absolute value.</p> <p><b>Note:</b> This parameter is not effective in scalar motor control mode.</p>	0.0 % / real32
	-1600.0 ... 1600.0 %	Minimum torque at brake release. For 16-bit scaling, see parameter <a href="#">46.3</a> .	- / 10 = 1 %

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
44.11	Keep brake closed	Selects a source that prevents the brake from opening. 0 = Normal brake operation 1 = Keep brake closed  <b>Note:</b> This parameter cannot be changed while the drive is running.	Not selected / uint32
	Not selected	0	0
	Selected	1	1
	DI1	Digital input DI1 ( <a href="#">10.2 DI delayed status</a> , bit 0).	2
	DI2	Digital input DI2 ( <a href="#">10.2 DI delayed status</a> , bit 1).	3
	DI3	Digital input DI3 ( <a href="#">10.2 DI delayed status</a> , bit 2).	4
	DI4	Digital input DI4 ( <a href="#">10.2 DI delayed status</a> , bit 3).	5
	DI5	Digital input DI5 ( <a href="#">10.2 DI delayed status</a> , bit 4).	6
	DI6	Digital input DI6 ( <a href="#">10.2 DI delayed status</a> , bit 5).	7
	DIO1	Digital input/output DIO1 ( <a href="#">11.2 DIO delayed status</a> , bit 0).	10
	DIO2	Digital input/output DIO2 ( <a href="#">11.2 DIO delayed status</a> , bit 1).	11
	Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-
44.12	Brake close request	Selects the source of an external brake close request signal. When on, the signal overrides the internal logic and closes the brake. 0 = Normal operation/No external close signal connected 1 = Close brake  <b>Note:</b> <ul style="list-style-type: none"> <li>In an open-loop (encoderless) application, if the brake is kept closed by a brake close request against a modulating drive for longer than 5 seconds, the brake is forced to close and the drive trips on a fault, <a href="#">71A5 Mech brk opening not allowed</a>.</li> <li>This parameter cannot be changed while the drive is running.</li> </ul>	Not selected / uint32
	Not selected	0	0
	Selected	1	1
	DI1	Digital input DI1 ( <a href="#">10.2 DI delayed status</a> , bit 0).	2
	DI2	Digital input DI2 ( <a href="#">10.2 DI delayed status</a> , bit 1).	3
	DI3	Digital input DI3 ( <a href="#">10.2 DI delayed status</a> , bit 2).	4
	DI4	Digital input DI4 ( <a href="#">10.2 DI delayed status</a> , bit 3).	5
	DI5	Digital input DI5 ( <a href="#">10.2 DI delayed status</a> , bit 4).	6
	DI6	Digital input DI6 ( <a href="#">10.2 DI delayed status</a> , bit 5).	7

## 424 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	DIO1	Digital input/output DIO1 ( <a href="#">11.2 DIO delayed status</a> , bit 0).	10
	DIO2	Digital input/output DIO2 ( <a href="#">11.2 DIO delayed status</a> , bit 1).	11
	Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-
44.13	Brake close delay	Defines a delay between a close command (that is, when the brake control output is de-energized) and when the drive stops modulating. This is to keep the motor live and under control until the brake actually closes.  Set this parameter equal to the value specified by the brake manufacturer as the mechanical make-up time of the brake.	0.00 s / real32
	0.00 ... 60.00 s	Brake close delay.	100 = 1 s / 100 = 1 s
44.14	Brake close level	Defines the brake close speed as an absolute value.  After motor speed remains below this level for the duration of the brake close level delay ( <a href="#">44.15 Brake close level delay</a> ), a close command is given.  <b>Note:</b> Check the compatibility of this setting with <a href="#">21.3 Stop mode</a> (and the applicable deceleration time).	10.00 rpm / real32
	0.00 ... 1000.00 rpm	Brake close speed. For 16-bit scaling, see parameter <a href="#">46.1</a> .	- / 100 = 1 rpm
44.15	Brake close level delay	Defines a brake close level delay. See parameter <a href="#">44.14 Brake close level</a> .	0.00 s / real32
	0.00 ... 10.00 s	Brake close level delay.	100 = 1 s / 100 = 1 s
44.16	Brake reopen delay	Defines a minimum time between brake closure and a subsequent open command.	0.00 s / real32
	0.00 ... 10.00 s	Brake reopen delay.	100 = 1 s / 100 = 1 s
44.17	Brake fault function	Determines how the drive reacts upon a mechanical brake control error.  <b>Note:</b> If parameter <a href="#">44.7 Brake acknowledge selection</a> is set to <a href="#">No acknowledge</a> , acknowledgement status supervision is disabled altogether and will generate no warnings or faults. However, the brake open conditions are always supervised.	Fault / uint16
	Fault	The drive trips on a <a href="#">71A2 Mech brake closing failed</a> / <a href="#">71A3 Mech brake opening failed</a> fault if the status of the acknowledgement does not match the status presumed by the brake control logic.  The drive trips on a <a href="#">71A5 Mech brk opening not allowed</a> fault if the brake open conditions cannot be fulfilled (for example, the required motor starting torque is not achieved).	0



No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	Warning	<p>The drive generates a <a href="#">A7A1 Mechanical brake closing failed</a> / <a href="#">A7A2 Mechanical brake opening failed</a> warning if the status of the acknowledgement does not match the status presumed by the brake control logic.</p> <p>The drive generates a <a href="#">A7A5 Mechanical brake opening not allowed</a> warning if the brake open conditions cannot be fulfilled (for example, the required motor starting torque is not achieved).</p>	1
	Open fault	<p>Upon closing the brake, the drive generates a <a href="#">A7A1 Mechanical brake closing failed</a> warning if the status of the acknowledgement does not match the status presumed by the brake control logic.</p> <p>Upon opening the brake, the drive trips on a <a href="#">71A3 Mech brake opening failed</a> fault if the status of the acknowledgement does not match the status presumed by the brake control logic.</p> <p>The drive trips on a <a href="#">71A5 Mech brk opening not allowed</a> fault if the brake open conditions cannot be fulfilled (for example, the required motor starting torque is not achieved).</p>	2
44.18	Brake fault delay	Defines a close fault delay, ie. time between brake closure and brake close fault trip.	0.00 s / real32
	0.00 ... 60.00 s	Brake close fault delay.	100 = 1 s / 100 = 1 s
44.21	Filter time brake torque memory	Defines a filtering time for parameter <a href="#">44.2 Brake torque memory</a> (actual torque value used as open torque reference).	100 ms / real32
	0...100 ms	Filtering time.	100 = 1 ms / 1 = 1 ms

## 426 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
<b>45</b>	Energy efficiency	Settings for the energy saving calculators. See also section <a href="#">Energy saving calculators (page 101)</a> .	
45.1	Saved GW hours	Displays the energy saved in GWh compared to direct-on-line motor connection. This parameter is incremented when <a href="#">45.2 Saved MW hours</a> .  This parameter is read-only (see parameter <a href="#">45.21 Energy calculations reset</a> ).	0 GWh / uint16
	0...65535 GWh	Energy savings in GWh.	1 = 1 GWh / 1 = 1 GWh
45.2	Saved MW hours	Displays the energy saved in MWh compared to direct-on-line motor connection. This parameter is incremented when <a href="#">45.3 Saved kW hours</a> rolls over.  When this parameter rolls over, parameter <a href="#">45.1 Saved GW hours</a> is incremented.  This parameter is read-only (see parameter <a href="#">45.21 Energy calculations reset</a> ).	0 MWh / uint16
	0...999 MWh	Energy savings in MWh.	1 = 1 MWh / 1 = 1 MWh
45.3	Saved kW hours	Displays the energy saved in kWh compared to direct-on-line motor connection.  If the internal brake chopper of the drive is enabled, all energy fed by the motor to the drive is assumed to be converted into heat, but the calculation still records savings made by controlling the speed. If the chopper is disabled, then regenerated energy from the motor is also recorded here.  When this parameter rolls over, parameter <a href="#">45.2 Saved MW hours</a> is incremented.  This parameter is read-only (see parameter <a href="#">45.21 Energy calculations reset</a> ).	0.0 kWh / uint16
	0.0 ... 999.9 kWh	Energy savings in kWh.	10 = 1 kWh / 10 = 1 kWh
45.5	Saved money x1000	Displays the monetary savings in thousands compared to direct-on-line motor connection. This parameter is incremented when <a href="#">45.6 Saved money</a> rolls over.  The currency is defined by parameter <a href="#">45.17 Tariff currency unit</a> .  This parameter is read-only (see parameter <a href="#">45.21 Energy calculations reset</a> ).	0 thousands / uint32
	0...4294967295 thousands	Monetary savings in thousands of units.	- / 1 = 1 thousands

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
45.6	Saved money	<p>Displays the monetary savings compared to direct-on-line motor connection. This value is calculated by multiplying the saved energy in kWh by the currently active energy tariff (45.14 Tariff selection).</p> <p>When this parameter rolls over, parameter 45.5 Saved money x1000 is incremented.</p> <p>The currency is defined by parameter 45.17 Tariff currency unit.</p> <p>This parameter is read-only (see parameter 45.21 Energy calculations reset).</p>	0.00 units / uint32
	0.00 ... 999.99 units	Monetary savings.	1 = 1 units / 100 = 1 units
45.8	CO2 reduction in kilotons	<p>Displays the reduction in CO2 emissions in metric kilotons compared to direct-on-line motor connection. This value is incremented when parameter 45.9 CO2 reduction in tons rolls over.</p> <p>This parameter is read-only (see parameter 45.21 Energy calculations reset).</p>	0 metric_kiloton / uint16
	0...65535 metric_kiloton	Reduction in CO <sub>2</sub> emissions in metric kilotons.	1 = 1 metric_kiloton / 1 = 1 metric_kiloton
45.9	CO2 reduction in tons	<p>Displays the reduction in CO2 emissions in metric tons compared to direct-on-line motor connection. This value is calculated by multiplying the saved energy in MWh by the value of parameter 45.18 CO2 conversion factor (by default, 0.5 metric tons/MWh).</p> <p>When this parameter rolls over, parameter 45.8 CO2 reduction in kilotons is incremented.</p> <p>This parameter is read-only (see parameter 45.21 Energy calculations reset).</p>	0.0 metric_ton / uint16
	0.0 ... 999.9 metric_ton	Reduction in CO <sub>2</sub> emissions in metric tons.	1 = 1 metric_ton / 10 = 1 metric_ton

## 428 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
45.11	Energy optimizer	<p>Enables/disables the energy optimization function. The function optimizes the motor flux so that total energy consumption and motor noise level are reduced when the drive operates below the nominal load. The total efficiency (motor and drive) can be improved by 1...20 % depending on load torque and speed.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>In DTC motor control mode with a permanent magnet motor or a synchronous reluctance motor, energy optimization is always enabled regardless of this parameter.</li> <li>In scalar motor control mode with an asynchronous motor, the function optimizes the motor flux as described below. Also with a sine filter connected the motor flux is optimized.</li> <li>In scalar motor control mode with a permanent magnet motor, the function minimizes the motor current. Motor current is also minimized when a sine filter is connected. A model-based optimizer can be enabled by activating parameter <a href="#">98.1 User motor model mode</a> and giving motor values.</li> </ul>	Disable / uint16
	Disable	Energy optimization disabled.	0
	Enable	Energy optimization enabled.	1
45.12	Energy tariff 1	<p>Defines energy tariff 1 (price of energy per kWh). Depending on the setting of parameter <a href="#">45.14 Tariff selection</a>, either this value or <a href="#">45.13 Energy tariff 2</a> is used for reference when monetary savings are calculated.</p> <p>The currency is defined by parameter <a href="#">45.17 Tariff currency unit</a>.</p> <p><b>Note:</b> Tariffs are read only at the instant of selection, and are not applied retroactively.</p>	1.000 units / uint32
	0.000 ... 4294967.295 units	Energy tariff 1.	- / 1000 = 1 units
45.13	Energy tariff 2	<p>Defines energy tariff 2 (price of energy per kWh). See parameter <a href="#">45.12 Energy tariff 1</a>.</p>	2.000 units / uint32
	0.000 ... 4294967.295 units	Energy tariff 2.	- / 1000 = 1 units
45.14	Tariff selection	<p>Selects (or defines a source that selects) which pre-defined energy tariff is used.</p> <p>0 = <a href="#">45.12 Energy tariff 1</a> 1 = <a href="#">45.13 Energy tariff 2</a></p>	Energy tariff 1 / uint32
	Energy tariff 1	0.	0
	Energy tariff 2	1.	1
	DI1	Digital input DI1 ( <a href="#">10.2 DI delayed status</a> , bit 0).	2
	DI2	Digital input DI2 ( <a href="#">10.2 DI delayed status</a> , bit 1).	3
	DI3	Digital input DI3 ( <a href="#">10.2 DI delayed status</a> , bit 2).	4


No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	DI4	Digital input DI4 (10.2 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.2 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.2 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1 (11.2 DIO delayed status, bit 0).	10
	DIO2	Digital input/output DIO2 (11.2 DIO delayed status, bit 1).	11
	Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-
45.17	Tariff currency unit	Specifies the currency used for the savings calculations.	EUR / uint16
	EUR	Euro.	101
	USD	Dollar.	102
	Local currency	Local currency. The name of the currency can be edited by choosing Menu - Settings - Edit texts on the control panel.	100
45.18	CO2 conversion factor	Defines a factor for conversion of saved energy into CO2 emissions (kg/kWh or tn/MWh).	0.500 tn_MWh / uint16
	0.000 ... 65.535 tn_MWh	Factor for conversion of saved energy into CO2 emissions.	1 = 1 tn_MWh / 100 = 1 tn_MWh
45.19	Comparison power	Actual power that the motor absorbs when connected direct on-line and operating the application. The value is used for reference when energy savings are calculated.  <b>Note:</b> The accuracy of the energy savings calculation is directly dependent on the accuracy of this value. If nothing is entered here, then the nominal motor power is used by the calculation, but that may inflate the energy savings reported as many motors do not absorb name-plate power.	0.0 kW / real32
	0.0 ... 100000.0 kW	Motor power. For 16-bit scaling, see parameter 46.4.	- / 10 = 1 kW
45.21	Energy calculations reset	Resets the savings counter parameters 45.1...45.9	Done / uint16
	Done	Reset not requested (normal operation), or reset complete.	0
	Reset	Reset the savings counter parameters. The value reverts automatically to <a href="#">Done</a> .	1

## 430 Parameters



No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
46	Monitoring/scaling settings	Speed supervision settings; actual signal filtering; general scaling settings.  <b>Note:</b> The 16-bit scalings apply when parameter values are read or written directly. With protocol- and profile-specific read/write commands (eg. communication objects), the scaling depends on the protocol or profile. See the documentation of the adapter module.	
46.1	Speed scaling	Defines the maximum speed value used to define the acceleration ramp rate and the initial speed value used to define the deceleration ramp rate (see parameter group 23 <a href="#">Speed reference ramp</a> ). The speed acceleration and deceleration ramp times are therefore related to this value (not to parameter 30.12 <a href="#">Maximum speed</a> ).  Also defines the 16-bit scaling of speed-related parameters.  The value of this parameter corresponds to 20000 in fieldbus, master/follower etc. communication.	1500.00; 1800.00 rpm (95.20 b0) rpm / real32
	0.10 ... 30000.00 rpm	Acceleration/deceleration terminal/initial speed.	1 = 1 rpm / 100 = 1 rpm
46.2	Frequency scaling	Defines the maximum frequency value used to define the acceleration ramp rate and the initial frequency value used to define deceleration ramp rate (see parameter group 28 <a href="#">Frequency reference chain</a> ). The frequency acceleration and deceleration ramp times are therefore related to this value (not to parameter 30.14 <a href="#">Maximum frequency</a> ).  Also defines the 16-bit scaling of frequency-related parameters. The value of this parameter corresponds to 20000 in fieldbus, master/follower etc. communication.	50.00 Hz; 60.00 Hz (95.20 b0) Hz / real32
	0.10 ... 1000.00 Hz	Acceleration/deceleration terminal/initial frequency.	10 = 1 Hz / 100 = 1 Hz
46.3	Torque scaling	Defines the 16-bit scaling of torque parameters. The value of this parameter (in percent of nominal motor torque) corresponds to 10000 in fieldbus, master/follower etc. communication.  See also parameter 46.42 <a href="#">Torque decimals</a> .	100.0 % / real32
	0.1 ... 1000.0 %	Torque corresponding to 10000 on fieldbus.	10 = 1 % / 10 = 1 %
46.4	Power scaling	Defines the output power value that corresponds to 10000 in fieldbus, master/follower etc. communication. The unit is selected by parameter 96.16 <a href="#">Unit selection</a> .	1000.00 kW or hp / real32
	0.10 ... 30000.00 kW or hp	Power corresponding to 10000 on fieldbus.	1 = 1 kW or hp / 100 = 1 kW or hp
46.5	Current scaling	Defines the 16-bit scaling of current parameters. The value of this parameter corresponds to 10000 in fieldbus, master/follower etc. communication.	10000 A / real32
	0...30000 A	Current corresponding to 10000 on fieldbus.	1 = 1 A / 1 = 1 A

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
46.6	Speed ref zero scaling	Defines a speed corresponding to a zero reference received from fieldbus (either the embedded fieldbus interface, or interface FBA A or FBA B). For example, with a setting of 500, the fieldbus reference range of 0...20000 would correspond to a speed of 500...[46.1] rpm.  <b>Note:</b> This parameter is effective only with the ABB Drives communication profile.	0.00 rpm / real32
	0.00 ... 30000.00 rpm	Speed corresponding to minimum fieldbus reference.	1 = 1 rpm / 100 = 1 rpm
46.7	Frequency ref zero scaling	Defines a frequency corresponding to a zero reference received from fieldbus (either the embedded fieldbus interface, or interface FBA A or FBA B). For example, with a setting of 30, the fieldbus reference range of 0...20000 would correspond to a speed of 30...[46.2] Hz.  <b>Note:</b> This parameter is effective only with the ABB Drives communication profile.	0.00 Hz / real32
	0.00 ... 1000.00 Hz	Frequency corresponding to minimum fieldbus reference.	10 = 1 Hz / 100 = 1 Hz
46.11	Filter time motor speed	Defines a filter time for signals <a href="#">1.1 Motor speed used</a> , <a href="#">1.2 Motor speed estimated</a> , <a href="#">1.4 Encoder 1 speed filtered</a> and <a href="#">1.5 Encoder 2 speed filtered</a> .	500 ms / real32
	0...20000 ms	Motor speed signal filter time.	1 = 1 ms / 1 = 1 ms
46.12	Filter time output frequency	Defines a filter time for signal <a href="#">1.6 Output frequency</a> .	500 ms / real32
	0...20000 ms	Output frequency signal filter time.	1 = 1 ms / 1 = 1 ms
46.13	Filter time motor torque	Defines a filter time for signal <a href="#">1.10 Motor torque</a> .	100 ms / real32
	0...20000 ms	Motor torque signal filter time.	1 = 1 ms / 1 = 1 ms
46.14	Filter time power out	Defines a filter time for signal <a href="#">1.14 Output power</a> .	100 ms / real32
	0...20000 ms	Output power signal filter time.	1 = 1 ms / 1 = 1 ms

432 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
46.21	At speed hysteresis	<p>Defines the “at setpoint” limits for speed control of the drive.</p> <p>When the absolute difference between reference (22.87 Speed reference act 7) and actual speed (90.1 Motor speed for control) becomes smaller than half the value of 46.21 At speed hysteresis, the drive is considered to be “at setpoint”.</p> <p>This is indicated by bit 8 of 6.11 Main status word.</p> <p>The bit switches off when the absolute difference between reference and actual speed exceeds the value of 46.21 At speed hysteresis.</p> 	100.00 rpm / real32
	0.00 ... 30000.00 rpm	Limit for “at setpoint” indication in speed control. For 16-bit scaling, see parameter 46.1.	- / 100 = 1 rpm



No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
46.22	At frequency hysteresis	<p>Defines the “at setpoint” limits for frequency control of the drive. When the absolute difference between reference (28.96 Frequency ref act 7) and actual frequency (1.6 Output frequency) is smaller than 46.22 At frequency hysteresis, the drive is considered to be “at setpoint”. This is indicated by bit 8 of 6.11 Main status word.</p> 	10.00 Hz / real32
	0.00 ... 1000.00 Hz	Limit for “at setpoint” indication in frequency control. For 16-bit scaling, see parameter 46.2.	- / 100 = 1 Hz
46.23	At torque hysteresis	<p>Defines the “at setpoint” limits for torque control of the drive.</p> <p>When the absolute difference between reference (26.73 Torque reference act 4) and actual torque (1.10 Motor torque) is smaller than 46.23 At torque hysteresis, the drive is considered to be “at setpoint”. This is indicated by bit 8 of 6.11 Main status word.</p> 	10.0 % / real32

## 434 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	0.0 ... 300.0 %	Limit for “at setpoint” indication in torque control. For 16-bit scaling, see parameter 46.3.	- / 1 = 1 %
46.31	Above speed limit	Defines the trigger level for “above limit” indication in speed control. When actual speed exceeds the limit, bit 10 of 6.17 Drive status word 2 is set.	1500.00 rpm / real32
	0.00 ... 30000.00 rpm	“Above limit” indication trigger level for speed control. For 16-bit scaling, see parameter 46.1.	- / 100 = 1 rpm
46.32	Above frequency limit	Defines the trigger level for “above limit” indication in frequency control. When actual frequency exceeds the limit, bit 10 of 6.17 Drive status word 2 is set.	50.00 Hz / real32
	0.00 ... 1000.00 Hz	“Above limit” indication trigger level for frequency control. For 16-bit scaling, see parameter 46.2.	- / 100 = 1 Hz
46.33	Above torque limit	Defines the trigger level for “above limit” indication in torque control. When actual torque exceeds the limit, bit 10 of 6.17 Drive status word 2 is set.	300.0 % / real32
	0.0 ... 1600.0 %	“Above limit” indication trigger level for torque control. For 16-bit scaling, see parameter 46.3.	- / 10 = 1 %
46.42	Torque decimals	Defines the number of decimal places of torque-related parameters.	1 / uint16
	0...2	Number of decimal places of torque parameters.	1 = 1 / 1 = 1


No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
<b>47</b>	Data storage	Data storage parameters that can be written to and read from using other parameters' source and target settings.  Note that there are different storage parameters for different data types. Integer-type storage parameters cannot be used as the source of other parameters.  See also section <a href="#">Data storage parameters (page 106)</a> .	
47.1	DataStorage 1 real32	Data storage parameter 1.  Parameters <a href="#">47.1...47.8</a> are real 32-bit numbers that can be used as source values of other parameters.  Storage parameters <a href="#">47.1...47.8</a> can be used as the target of received 16-bit data (parameter group <a href="#">62 D2D and DDCS receive data</a> ) or the source of transmitted 16-bit data (parameter group <a href="#">61 D2D and DDCS transmit data</a> ). The scaling and range are defined by parameters <a href="#">47.31...47.38</a> .	- / real32
	-32768.000 ... 32767.000	32-bit real (floating point) number. For 16-bit scaling, see parameter <a href="#">47.31</a> .	- / 1000 = 1
47.2	DataStorage 2 real32	Data storage parameter 2.  See also parameter <a href="#">47.1 DataStorage 1 real32</a> .	- / real32
	-32768.000 ... 32767.000	32-bit real (floating point) number. For 16-bit scaling, see parameter <a href="#">47.32</a> .	- / 1000 = 1
47.3	DataStorage 3 real32	Data storage parameter 3.  See also parameter <a href="#">47.1 DataStorage 1 real32</a> .	- / real32
	-32768.000 ... 32767.000	32-bit real (floating point) number. For 16-bit scaling, see parameter <a href="#">47.33</a> .	- / 1000 = 1
47.4	DataStorage 4 real32	Data storage parameter 4.  See also parameter <a href="#">47.1 DataStorage 1 real32</a> .	- / real32
	-32768.000 ... 32767.000	32-bit real (floating point) number. For 16-bit scaling, see parameter <a href="#">47.34</a> .	- / 1000 = 1
47.5	DataStorage 5 real32	Data storage parameter 5.  See also parameter <a href="#">47.1 DataStorage 1 real32</a> .	- / real32
	-32768.000 ... 32767.000	32-bit real (floating point) number. For 16-bit scaling, see parameter <a href="#">47.35</a> .	- / 1000 = 1
47.6	DataStorage 6 real32	Data storage parameter 6.  See also parameter <a href="#">47.1 DataStorage 1 real32</a> .	- / real32
	-32768.000 ... 32767.000	32-bit real (floating point) number. For 16-bit scaling, see parameter <a href="#">47.36</a> .	- / 1000 = 1
47.7	DataStorage 7 real32	Data storage parameter 7.  See also parameter <a href="#">47.1 DataStorage 1 real32</a> .	- / real32
	-32768.000 ... 32767.000	32-bit real (floating point) number. For 16-bit scaling, see parameter <a href="#">47.37</a> .	- / 1000 = 1



## 436 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
47.8	DataStorage 8 real32	Data storage parameter 8. See also parameter <a href="#">47.1 DataStorage 1 real32</a> .	- / real32
	-32768.000 ... 32767.000	32-bit real (floating point) number. For 16-bit scaling, see parameter <a href="#">47.38</a> .	- / 1000 = 1
47.11	DataStorage 1 int32	Data storage parameter 9.	- / int32
	-2147483648..2147483647	32-bit integer.	- / 1 = 1
47.12	DataStorage 2 int32	Data storage parameter 10.	- / int32
	-2147483648..2147483647	32-bit integer.	- / 1 = 1
47.13	DataStorage 3 int32	Data storage parameter 11.	- / int32
	-2147483648..2147483647	32-bit integer.	- / 1 = 1
47.14	DataStorage 4 int32	Data storage parameter 12.	- / int32
	-2147483648..2147483647	32-bit integer.	- / 1 = 1
47.15	DataStorage 5 int32	Data storage parameter 13.	- / int32
	-2147483648..2147483647	32-bit integer.	- / 1 = 1
47.16	DataStorage 6 int32	Data storage parameter 14.	- / int32
	-2147483648..2147483647	32-bit integer	- / 1 = 1
47.17	DataStorage 7 int32	Data storage parameter 15.	- / int32
	-2147483648..2147483647	32-bit integer.	- / 1 = 1
47.18	DataStorage 8 int32	Data storage parameter 16.	- / int32
	-2147483648..2147483647	32-bit integer.	- / 1 = 1
47.21	DataStorage 1 int16	Data storage parameter 17.	- / int16
	-32768...32767	16-bit integer.	1 = 1 / 1 = 1
47.22	DataStorage 2 int16	Data storage parameter 18.	- / int16
	-32768...32767	16-bit integer.	1 = 1 / 1 = 1
47.23	DataStorage 3 int16	Data storage parameter 19.	- / int16
	-32768...32767	16-bit integer.	1 = 1 / 1 = 1
47.24	DataStorage 4 int16	Data storage parameter 20.	- / int16
	-32768...32767	16-bit integer.	1 = 1 / 1 = 1
47.25	DataStorage 5 int16	Data storage parameter 21.	- / int16
	-32768...32767	16-bit integer.	1 = 1 / 1 = 1
47.26	DataStorage 6 int16	Data storage parameter 22.	- / int16
	-32768...32767	16-bit integer.	1 = 1 / 1 = 1
47.27	DataStorage 7 int16	Data storage parameter 23.	- / int16
	-32768...32767	16-bit integer.	1 = 1 / 1 = 1
47.28	DataStorage 8 int16	Data storage parameter 24.	- / int16
	-32768...32767	16-bit integer.	1 = 1 / 1 = 1


No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
47.31	DataStorage 1 real32 type	Defines the scaling of parameter <a href="#">47.1 DataStorage 1 real32</a> to and from 16-bit integer format. This scaling is used when the data storage parameter is the target of received 16-bit data (defined in parameter group <a href="#">62 D2D and DDCS receive data</a> ), or when the data storage parameter is the source of transmitted 16-bit data (defined in parameter group <a href="#">61 D2D and DDCS transmit data</a> ).  The setting also defines the visible range of the storage parameter.	Unscaled / uint16
	Unscaled	Data storage only. Range: -2147483.264 ... 2147473.264.	0
	Transparent	Scaling: 1 = 1. Range: -32768 ... 32767.	1
	General	Scaling: 1 = 100. Range: -327.68 ... 327.67.	2
	Torque	The scaling is defined by parameter <a href="#">46.3 Torque scaling</a> . Range: -1600.0 ... 1600.0.	3
	Speed	The scaling is defined by parameter <a href="#">46.1 Speed scaling</a> . Range: -30000.00 ... 30000.00.	4
	Frequency	The scaling is defined by parameter <a href="#">46.2 Frequency scaling</a> . Range: -600.00...600.00.	5
47.32	DataStorage 2 real32 type	Defines the 16-bit scaling of parameter <a href="#">47.2 DataStorage 2 real32</a> . See parameter <a href="#">47.31 DataStorage 1 real32</a> type.	Unscaled / uint16
47.33	DataStorage 3 real32 type	Defines the 16-bit scaling of parameter <a href="#">47.3 DataStorage 3 real32</a> . See parameter <a href="#">47.31 DataStorage 1 real32</a> type.	Unscaled / uint16
47.34	DataStorage 4 real32 type	Defines the 16-bit scaling of parameter <a href="#">47.4 DataStorage 4 real32</a> . See parameter <a href="#">47.31 DataStorage 1 real32</a> type.	Unscaled / uint16
47.35	DataStorage 5 real32 type	Defines the 16-bit scaling of parameter <a href="#">47.5 DataStorage 5 real32</a> . See parameter <a href="#">47.31 DataStorage 1 real32</a> type.	Unscaled / uint16
47.36	DataStorage 6 real32 type	Defines the 16-bit scaling of parameter <a href="#">47.6 DataStorage 6 real32</a> . See parameter <a href="#">47.31 DataStorage 1 real32</a> type.	Unscaled / uint16
47.37	DataStorage 7 real32 type	Defines the 16-bit scaling of parameter <a href="#">47.7 DataStorage 7 real32</a> . See parameter <a href="#">47.31 DataStorage 1 real32</a> type.	Unscaled / uint16
47.38	DataStorage 8 real32 type	Defines the 16-bit scaling of parameter <a href="#">47.8 DataStorage 8 real32</a> . See parameter <a href="#">47.31 DataStorage 1 real32</a> type.	Unscaled / uint16

## 438 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
<b>49</b>	Panel port communication	Communication settings for the control panel port on the drive.	
49.1	Node ID number	Defines the node ID of the drive. All devices connected to the network must have a unique node ID.  <b>Note:</b> For networked drives, it is advisable to reserve ID 1 for spare/replacement drives.	1 / uint32
	1...32	Node ID.	1 = 1 / 1 = 1
49.3	Baud rate	Defines the transfer rate of the link.	230.4 kbps / uint32
	38.4 kbps	38.4 kbit/s.	1
	57.6 kbps	57.6 kbit/s.	2
	86.4 kbps	86.4 kbit/s.	3
	115.2 kbps	115.2 kbit/s.	4
	230.4 kbps	230.4 kbit/s.	5
49.4	Communication loss time	Sets a timeout for control panel (or PC tool) communication. If a communication break lasts longer than the timeout, the action specified by parameter <a href="#">49.5 Communication loss action</a> is taken.	10.0 s / uint32
	0.3 ... 3000.0 s	Panel/PC tool communication timeout.	10 = 1 s / 1000 = 1 s
49.5	Communication loss action	Selects how the drive reacts to a control panel (or PC tool) communication break.  Changes to this parameter take effect after the control unit is rebooted or the new settings validated by parameter <a href="#">49.6 Refresh settings</a> .  See also parameters <a href="#">49.7 Panel comm supervision force</a> and <a href="#">49.8 Secondary comm. loss action</a> .	Fault / uint16
	No action	No action taken.	0
	Fault	Drive trips on <a href="#">7081 Control panel loss</a> . This only occurs if control is expected from the control panel (it is selected as source of start/stop/reference in the currently active control location), or if supervision is forced using parameter <a href="#">49.7 Panel comm supervision force</a> .	1
	Last speed	Drive generates an <a href="#">A7EE Control panel loss</a> warning and freezes the speed to the level the drive was operating at. This only occurs if control is expected from the control panel, or if supervision is forced using parameter <a href="#">49.7 Panel comm supervision force</a> .  The speed is determined on the basis of actual speed using 850 ms low-pass filtering.   <b>WARNING!</b> Make sure that it is safe to continue operation in case of a communication break.	2

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	Speed ref safe	<p>Drive generates an <a href="#">A7EE Control panel loss</a> warning and sets the speed to the speed defined by parameter <a href="#">22.41 Speed ref safe</a> (or <a href="#">28.41 Frequency ref safe</a> when frequency reference is being used). This only occurs if control is expected from the control panel, or if supervision is forced using parameter <a href="#">49.7 Panel comm supervision force</a>.</p> <p> <b>WARNING!</b> Make sure that it is safe to continue operation in case of a communication break.</p>	3
	Warning	<p>Drive generates an <a href="#">A7EE Control panel loss</a> warning. This only occurs if control is expected from the control panel, or if supervision is forced using parameter <a href="#">49.7 Panel comm supervision force</a>.</p> <p> <b>WARNING!</b> Make sure that it is safe to continue operation in case of a communication break.</p>	5
49.6	Refresh settings	<p>Applies the settings of parameters <a href="#">49.1 Node ID number...49.5</a>.</p> <p><b>Note:</b> Refreshing may cause a communication break, so reconnecting the drive may be required.</p>	Done / uint16
	Done	Refresh done or not requested.	0
	Refresh	Refresh parameters <a href="#">49.1 Node ID number...49.5</a> . The value reverts automatically to <a href="#">Done</a> .	1
49.7	Panel comm supervision force	<p>Activates control panel communication monitoring separately for each control location (see section <a href="#">Local control vs. external control (page 23)</a>).</p> <p>The parameter is primarily intended for monitoring the communication with the panel when it is connected to the application program and not selected as a control source by drive parameters.</p>	- / uint16
	b0 Ext 1	1 = Communication monitoring active when Ext 1 is being used.	
	b1 Ext 2	1 = Communication monitoring active when Ext 2 is being used.	
	b2 Local	1 = Communication monitoring active when local control is being used.	
	b3...15 Reserved		
	0000h...FFFFh		1 = 1 / 1 = 1


## 440 Parameters



No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
49.8	Secondary comm. loss action	<p>Selects how the drive reacts to a control panel (or PC tool) communication break. This action is taken when</p> <ul style="list-style-type: none"> <li>the panel is parametrized as an alternative control or reference source but is not currently the active source, and</li> <li>communication supervision for the active control location is not forced by parameter <a href="#">49.7 Panel comm supervision force</a>.</li> </ul>	No action / uint16
	No action	No action taken.	0
	Warning	<p>Drive generates an <a href="#">A7EE Control panel loss</a> warning.</p> <p> <b>WARNING!</b> Make sure that it is safe to continue operation in case of a communication break.</p>	5
49.14	Panel speed reference unit	Defines the unit for speed reference when given from the control panel.	rpm / uint16
	rpm	rpm.	0
	%	Percent of parameter <a href="#">46.1 Speed scaling</a> .	1
49.15	Minimum ext speed ref panel	<p>Defines a minimum limit for control panel speed reference in external control.</p> <p>In local control, the limits in parameter group <a href="#">30 Limits</a> are in force. See section <a href="#">Local control vs. external control (page 23)</a>.</p>	-30000.00 rpm / real32
	-30000.00 ... 30000.00 rpm	Minimum speed reference. For 16-bit scaling, see parameter <a href="#">46.1</a> .	- / 100 = 1 rpm
49.16	Maximum ext speed ref panel	<p>Defines a maximum limit for control panel speed reference in external control.</p> <p>In local control, the limits in parameter group <a href="#">30 Limits</a> are in force. See section <a href="#">Local control vs. external control (page 23)</a>.</p>	30000.00 rpm / real32
	-30000.00 ... 30000.00 rpm	Maximum speed reference. For 16-bit scaling, see parameter <a href="#">46.1</a> .	- / 100 = 1 rpm
49.17	Minimum ext frequency ref panel	<p>Defines a minimum limit for control panel frequency reference in external control.</p> <p>In local control, the limits in parameter group <a href="#">30 Limits</a> are in force. See section <a href="#">Local control vs. external control (page 23)</a>.</p>	-500.00 Hz / real32
	-598.00 ... 598.00 Hz	Minimum frequency reference. For 16-bit scaling, see parameter <a href="#">46.2</a> .	- / 100 = 1 Hz
49.18	Maximum ext frequency ref panel	<p>Defines a maximum limit for control panel frequency reference in external control.</p> <p>In local control, the limits in parameter group <a href="#">30 Limits</a> are in force. See section <a href="#">Local control vs. external control (page 23)</a>.</p>	500.00 Hz / real32
	-598.00 ... 598.00 Hz	Maximum frequency reference. For 16-bit scaling, see parameter <a href="#">46.2</a> .	- / 100 = 1 Hz



No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
49.24	Panel actual source	Selects an actual value to be displayed in the top right corner of the control panel. This parameter is only effective when the control panel is not an active reference source.	Automatic / uint32
	Automatic	The active reference is displayed.	0
	Process PID setpoint actual	<a href="#">40.3 Process PID setpoint actual</a> .	1
	Other [bit]	Source selection (see <a href="#">Terms and abbreviations (page 134)</a> ).	-

## 442 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
50	Fieldbus adapter (FBA)	Fieldbus communication configuration. See also chapter Fieldbus control through a fieldbus adapter.	
50.1	FBA A enable	Enables/disables communication between the drive and fieldbus adapter A, and specifies the slot the adapter is installed into.  <b>Note:</b> This parameter cannot be changed while the drive is running.	Disable / uint16
	Disable	Communication between drive and fieldbus adapter A disabled.	0
	Option slot 1	Communication between drive and fieldbus adapter A enabled. The adapter is in slot 1.	1
	Option slot 2	Communication between drive and fieldbus adapter A enabled. The adapter is in slot 2.	2
	Option slot 3	Communication between drive and fieldbus adapter A enabled. The adapter is in slot 3.	3
50.2	FBA A comm loss func	Selects how the drive reacts upon a fieldbus communication break. A time delay for the action can be defined by parameter <a href="#">50.3 FBA A comm loss t out</a> . See also parameter <a href="#">50.26 FBA A comm supervision force</a> .	No action / uint16
	No action	No action taken.	0
	Fault	Drive trips on <a href="#">7510 FBA A communication</a> . This only occurs if control is expected from the FBA A interface (FBA A selected as source of start/stop/reference in the currently active control location), or if supervision is forced using parameter <a href="#">50.26 FBA A comm supervision force</a> .	1
	Last speed	Drive generates an <a href="#">A7C1 FBA A communication</a> warning and freezes the speed to the level the drive was operating at. This only occurs if control is expected from the FBA A interface, or if supervision is forced using parameter <a href="#">50.26 FBA A comm supervision force</a> . The speed is determined on the basis of actual speed using 850 ms low-pass filtering.   <b>WARNING!</b> Make sure that it is safe to continue operation in case of a communication break.	2

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	Speed ref safe	<p>Drive generates an <a href="#">A7C1 FBA A communication</a> warning and sets the speed to the value defined by parameter <a href="#">22.41 Speed ref safe</a> (when speed reference is being used) or <a href="#">28.41 Frequency ref safe</a> (when frequency reference is being used).</p> <p>This only occurs if control is expected from the FBA A interface, or if supervision is forced using parameter <a href="#">50.26 FBA A comm supervision force</a>.</p> <p> <b>WARNING!</b> Make sure that it is safe to continue operation in case of a communication break.</p>	3
	Fault always	<p>Drive trips on <a href="#">7510 FBA A communication</a>. This occurs even though no control is expected from the FBA A interface.</p>	4
	Warning	<p>Drive generates an <a href="#">A7C1 FBA A communication</a> warning. This only occurs if control is expected from the FBA A interface, or if supervision is forced using parameter <a href="#">50.26 FBA A comm supervision force</a>.</p> <p> <b>WARNING!</b> Make sure that it is safe to continue operation in case of a communication break.</p>	5
50.3	FBA A comm loss t out	<p>Defines the time delay before the action defined by parameter <a href="#">50.2 FBA A comm loss func</a> is taken. Time count starts when the communication link fails to update the message. As a rule of thumb, this parameter should be set to at least 3 times the transmit interval of the master.</p> <p><b>Note:</b> There is a 60-second boot-up delay immediately after power-up. During the delay, the communication break monitoring is disabled (but communication itself can be active).</p>	0.3 s / uint16
	0.1 ... 6553.5 s	Time delay.	10 = 1 s / 10 = 1 s
50.4	FBA A ref1 type	<p>Selects the type and scaling of reference 1 received from fieldbus adapter A.</p> <p><b>Note:</b> Fieldbus-specific communication profiles may use different scalings. For more information, see the manual of the fieldbus adapter.</p>	Auto / uint16
	Auto	<p>Type and scaling are chosen automatically according to which reference chain (see settings <a href="#">Torque</a>, <a href="#">Speed</a>, <a href="#">Frequency</a>) the incoming reference is connected to. If the reference is not connected to any chain, no scaling is applied (as with setting <a href="#">Transparent</a>).</p>	0
	Transparent	No scaling is applied (the 16-bit scaling is 1 = 1 unit).	1
	General	Generic reference with a 16-bit scaling of 100 = 1 (ie. integer and two decimals).	2


## 444 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	Torque	The scaling is defined by parameter <a href="#">46.3 Torque scaling</a> .	3
	Speed	The scaling is defined by parameter <a href="#">46.1 Speed scaling</a> .	4
	Frequency	The scaling is defined by parameter <a href="#">46.2 Frequency scaling</a> .	5
50.5	FBA A ref2 type	Selects the type and scaling of reference 2 received from fieldbus adapter A. See parameter <a href="#">50.4 FBA A ref1 type</a> .	Auto / uint16
50.7	FBA A actual 1 type	Selects the type/source and scaling of actual value 1 transmitted to the fieldbus network through fieldbus adapter A.  <b>Note:</b> Fieldbus-specific communication profiles may use different scalings. For more information, see the manual of the fieldbus adapter.	Auto / uint16
	Auto	Type/source and scaling follow the type of reference 1 selected by parameter <a href="#">50.4 FBA A ref1 type</a> . See the individual settings below for the sources and scalings.	0
	Transparent	The value selected by parameter <a href="#">50.10 FBA A act1 transparent source</a> is sent as actual value 1. No scaling is applied (the 16-bit scaling is 1 = 1 unit).	1
	General	The value selected by parameter <a href="#">50.10 FBA A act1 transparent source</a> is sent as actual value 1 with a 16-bit scaling of 100 = 1 unit (ie. integer and two decimals).	2
	Torque	<a href="#">1.10 Motor torque</a> is sent as actual value 1. The scaling is defined by parameter <a href="#">46.3 Torque scaling</a> .	3
	Speed	<a href="#">1.1 Motor speed used</a> is sent as actual value 1. The scaling is defined by parameter <a href="#">46.1 Speed scaling</a> .	4
	Frequency	<a href="#">1.6 Output frequency</a> is sent as actual value 1. The scaling is defined by parameter <a href="#">46.2 Frequency scaling</a> .	5
	Position	Motor position is sent as actual value 1. See parameter <a href="#">90.6 Motor position scaled</a> .	6
50.8	FBA A actual 2 type	Selects the type/source and scaling of actual value 2 transmitted to the fieldbus network through fieldbus adapter A. See parameter <a href="#">50.7 FBA A actual 1 type</a> .	Auto / uint16
50.9	FBA A SW transparent source	Selects the source of the fieldbus status word when the fieldbus adapter is set to a transparent communication profile eg. by its configuration parameters (group <a href="#">51 FBA A settings</a> ).	Not selected / uint32
	Not selected	No source selected.	0
	Other [bit]	Source selection (see <a href="#">Terms and abbreviations (page 134)</a> ).	-



No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
50.10	FBA A act1 transparent source	When parameter <a href="#">50.7 FBA A actual 1 type</a> is set to <a href="#">Transparent</a> or <a href="#">General</a> , this parameter selects the source of actual value 1 transmitted to the fieldbus network through fieldbus adapter A.	Not selected / uint32
	Not selected	No source selected.	0
	Other [bit]	Source selection (see <a href="#">Terms and abbreviations (page 134)</a> ).	-
50.11	FBA A act2 transparent source	When parameter <a href="#">50.8 FBA A actual 2 type</a> is set to <a href="#">Transparent</a> or <a href="#">General</a> , this parameter selects the source of actual value 2 transmitted to the fieldbus network through fieldbus adapter A.	Not selected / uint32
	Not selected	No source selected.	0
	Other [bit]	Source selection (see <a href="#">Terms and abbreviations (page 134)</a> ).	-
50.12	FBA A debug mode	Enables the display of raw (unmodified) data received from and sent to fieldbus adapter A in parameters <a href="#">50.13...50.18</a> .  This functionality should only be used for debugging.  <b>Note:</b> This parameter cannot be changed while the drive is running.	Disable / uint16
	Disable	Display of raw data from fieldbus adapter A disabled.	0
	Fast	Display of raw data from fieldbus adapter A enabled.	1
50.13	FBA A control word	Displays the raw (unmodified) control word sent by the master (PLC) to fieldbus adapter A if debugging is enabled by parameter <a href="#">50.12 FBA A debug mode</a> .  This parameter is read-only.	0 / uint32
	00000000..FFFFFFFFh	Control word sent by master to fieldbus adapter A.	1 = 1
50.14	FBA A reference 1	Displays raw (unmodified) reference REF1 sent by the master (PLC) to fieldbus adapter A if debugging is enabled by parameter <a href="#">50.12 FBA A debug mode</a> .  This parameter is read-only.	- / int32
50.15	FBA A reference 2	Displays raw (unmodified) reference REF2 sent by the master (PLC) to fieldbus adapter A if debugging is enabled by parameter <a href="#">50.12 FBA A debug mode</a> .  This parameter is read-only.	- / int32
50.16	FBA A status word	Displays the raw (unmodified) status word sent by fieldbus adapter A to the master (PLC) if debugging is enabled by parameter <a href="#">50.12 FBA A debug mode</a> .  This parameter is read-only.	0 / uint32
	00000000..FFFFFFFFh	Status word sent by fieldbus adapter A to master.	1 = 1
50.17	FBA A actual value 1	Displays raw (unmodified) actual value ACT1 sent by fieldbus adapter A to the master (PLC) if debugging is enabled by parameter <a href="#">50.12 FBA A debug mode</a> .  This parameter is read-only.	- / int32

## 446 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b															
50.18	FBA A actual value 2	<p>Displays raw (unmodified) actual value ACT2 sent by fieldbus adapter A to the master (PLC) if debugging is enabled by parameter <a href="#">50.12 FBA A debug mode</a>.</p> <p>This parameter is read-only.</p>	- / int32															
50.21	FBA A timelevel sel	<p>Selects the communication time levels.</p> <p>In general, lower time levels of read/write services reduce CPU load. The table below shows the time levels of the read/write services for cyclic high and cyclic low data with each parameter setting.</p> <table border="1" data-bbox="342 443 818 630"> <thead> <tr> <th data-bbox="342 443 501 475">Selection</th> <th data-bbox="501 443 660 475">Cyclic high *</th> <th data-bbox="660 443 818 475">Cyclic low **</th> </tr> </thead> <tbody> <tr> <td data-bbox="342 475 501 515">Monitoring</td> <td data-bbox="501 475 660 515">10 ms</td> <td data-bbox="660 475 818 515">2 ms</td> </tr> <tr> <td data-bbox="342 515 501 555">Normal</td> <td data-bbox="501 515 660 555">2 ms</td> <td data-bbox="660 515 818 555">10 ms</td> </tr> <tr> <td data-bbox="342 555 501 595">Fast</td> <td data-bbox="501 555 660 595">500 µs</td> <td data-bbox="660 555 818 595">2 ms</td> </tr> <tr> <td data-bbox="342 595 501 630">Very fast</td> <td data-bbox="501 595 660 630">250 µs</td> <td data-bbox="660 595 818 630">2 ms</td> </tr> </tbody> </table> <p>* Cyclic high data consists of fieldbus Status word, Act1 and Act2.</p> <p>** Cyclic low data consists of the parameter data mapped to parameter groups <a href="#">52 FBA A data in</a> and <a href="#">53 FBA A data out</a>, and acyclic data.</p> <p>Control word, Ref1 and Ref2 are handled as interrupts generated on receipt of cyclic high messages.</p> <p><b>Note:</b> This parameter cannot be changed while the drive is running.</p>	Selection	Cyclic high *	Cyclic low **	Monitoring	10 ms	2 ms	Normal	2 ms	10 ms	Fast	500 µs	2 ms	Very fast	250 µs	2 ms	Normal / uint16
Selection	Cyclic high *	Cyclic low **																
Monitoring	10 ms	2 ms																
Normal	2 ms	10 ms																
Fast	500 µs	2 ms																
Very fast	250 µs	2 ms																
	Normal	Normal speed.	0															
	Fast	Fast speed.	1															
	Very fast	Very fast speed.	2															
	Monitoring	Low speed. Optimized for PC tool communication and monitoring usage.	3															
50.26	FBA A comm supervision force	<p>Activates fieldbus communication monitoring separately for each control location (see section <a href="#">Local control vs. external control (page 23)</a> on page 20).</p> <p>The parameter is primarily intended for monitoring the communication with FBA A when it is connected to the application program and not selected as a control source by drive parameters.</p>	- / uint16															
b0	Ext 1	1 = Communication monitoring active when Ext 1 is being used.																
b1	Ext 2	1 = Communication monitoring active when Ext 2 is being used.																
b2	Local	1 = Communication monitoring active when local control is being used.																
b3...15	Reserved																	

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	0000h...FFFFh		1 = 1 / 1 = 1
50.31	FBA B enable	<p>Enables/disables communication between the drive and fieldbus adapter B, and specifies the slot the adapter is installed into.</p> <p><b>Note:</b> This parameter cannot be changed while the drive is running.</p>	Disable / uint16
	Disable	Communication between drive and fieldbus adapter B disabled.	0
	Option slot 1	Communication between drive and fieldbus adapter B enabled. The adapter is in slot 1.	1
	Option slot 2	Communication between drive and fieldbus adapter B enabled. The adapter is in slot 2.	2
	Option slot 3	Communication between drive and fieldbus adapter B enabled. The adapter is in slot 3.	3
50.32	FBA B comm loss func	<p>Selects how the drive reacts upon a fieldbus communication break. A time delay for the action can be defined by parameter <a href="#">50.33 FBA B comm loss timeout</a>. See also parameter <a href="#">50.56 FBA B comm supervision force</a>.</p>	No action / uint16
	No action	No action taken.	0
	Fault	<p>Drive trips on <a href="#">7520 FBA B communication</a>. This only occurs if control is expected from the FBA B interface (FBA B selected as source of start/stop/reference in the currently active control location), or if supervision is forced using parameter <a href="#">50.56 FBA B comm supervision force</a>.</p>	1
	Last speed	<p>Drive generates an <a href="#">A7C2 FBA B communication</a> warning and freezes the speed to the level the drive was operating at. This only occurs if control is expected from the FBA B interface, or if supervision is forced using parameter <a href="#">50.56 FBA B comm supervision force</a>.</p> <p>The speed is determined on the basis of actual speed using 850 ms low-pass filtering.</p> <p> <b>WARNING!</b> Make sure that it is safe to continue operation in case of a communication break.</p>	2

## 448 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	Speed ref safe	<p>Drive generates an <a href="#">A7C2 FBA B communication</a> warning and sets the speed to the value defined by parameter <a href="#">22.41 Speed ref safe</a> (when speed reference is being used) or <a href="#">28.41 Frequency ref safe</a> (when frequency reference is being used).</p> <p>This only occurs if control is expected from the FBA B interface, or if supervision is forced using parameter <a href="#">50.56 FBA B comm supervision force</a>.</p> <p> <b>WARNING!</b> Make sure that it is safe to continue operation in case of a communication break.</p>	3
	Fault always	<p>Drive trips on <a href="#">7520 FBA B communication</a>. This occurs even though no control is expected from the FBA B interface.</p>	4
	Warning	<p>Drive generates an <a href="#">A7C2 FBA B communication</a> warning. This only occurs if control is expected from the FBA B interface, or if supervision is forced using parameter <a href="#">50.56 FBA B comm supervision force</a>.</p> <p> <b>WARNING!</b> Make sure that it is safe to continue operation in case of a communication break.</p>	5
50.33	FBA B comm loss timeout	<p>Defines the time delay before the action defined by parameter <a href="#">50.32 FBA B comm loss func</a> is taken. Time count starts when the communication link fails to update the message.</p> <p>As a rule of thumb, this parameter should be set to at least 3 times the transmit interval of the master.</p> <p><b>Note:</b> There is a 60-second boot-up delay immediately after power-up. During the delay, the communication break monitoring is disabled (but communication itself can be active).</p>	0.3 s / uint16
	0.1 ... 6553.5 s	Time delay.	10 = 1 s / 10 = 1 s
50.34	FBA B ref1 type	<p>Selects the type and scaling of reference 1 received from fieldbus adapter B.</p> <p>See parameter <a href="#">50.4 FBA A ref1 type</a>.</p>	Auto / uint16
50.35	FBA B ref2 type	<p>Selects the type and scaling of reference 2 received from fieldbus adapter B.</p> <p>See parameter <a href="#">50.4 FBA A ref1 type</a>.</p>	Auto / uint16
50.37	FBA B actual 1 type	<p>Selects the type/source and scaling of actual value 1 transmitted to the fieldbus network through fieldbus adapter B.</p> <p>See parameter <a href="#">50.7 FBA A actual 1 type</a>.</p>	Auto / uint16



No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
50.38	FBA B actual 2 type	Selects the type/source and scaling of actual value 2 transmitted to the fieldbus network through fieldbus adapter B. See parameter <a href="#">50.8 FBA A actual 2 type</a> .	Auto / uint16
50.39	FBA B SW transparent source	Selects the source of the fieldbus status word when the fieldbus adapter is set to a transparent communication profile eg. by its configuration parameters (group <a href="#">54 FBA B settings</a> ).	Not selected / uint32
	Not selected	No source selected.	0
	Other [bit]	Source selection (see <a href="#">Terms and abbreviations (page 134)</a> ).	-
50.40	FBA B act1 transparent source	When parameter <a href="#">50.37 FBA B actual 1 type</a> is set to <a href="#">Transparent</a> or <a href="#">General</a> , this parameter selects the source of actual value 1 transmitted to the fieldbus network through fieldbus adapter B.	Not selected / uint32
	Not selected	No source selected.	0
	Other [bit]	Source selection (see <a href="#">Terms and abbreviations (page 134)</a> ).	-
50.41	FBA B act2 transparent source	When parameter <a href="#">50.38 FBA B actual 2 type</a> is set to <a href="#">Transparent</a> or <a href="#">General</a> , this parameter selects the source of actual value 2 transmitted to the fieldbus network through fieldbus adapter B.	Not selected / uint32
	Not selected	No source selected.	0
	Other [bit]	Source selection (see <a href="#">Terms and abbreviations (page 134)</a> ).	-
50.42	FBA B debug mode	Enables the display of raw (unmodified) data received from and sent to fieldbus adapter B in parameters <a href="#">50.43...50.48</a> .  This functionality should only be used for debugging.  <b>Note:</b> This parameter cannot be changed while the drive is running.	Disable / uint16
	Disable	Display of raw data from fieldbus adapter B disabled.	0
	Fast	Display of raw data from fieldbus adapter B enabled.	1
50.43	FBA B control word	Displays the raw (unmodified) control word sent by the master (PLC) to fieldbus adapter B if debugging is enabled by parameter <a href="#">50.42 FBA B debug mode</a> .  This parameter is read-only.	0 / uint32
	00000000..FFFFFFFFh	Control word sent by master to fieldbus adapter B.	1 = 1
50.44	FBA B reference 1	Displays raw (unmodified) reference REF1 sent by the master (PLC) to fieldbus adapter B if debugging is enabled by parameter <a href="#">50.42 FBA B debug mode</a> .  This parameter is read-only.	- / int32

## 450 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b															
50.45	FBA B reference 2	Displays raw (unmodified) reference REF2 sent by the master (PLC) to fieldbus adapter B if debugging is enabled by parameter <a href="#">50.42 FBA B debug mode</a> . This parameter is read-only.	- / int32															
50.46	FBA B status word	Displays the raw (unmodified) status word sent by fieldbus adapter B to the master (PLC) if debugging is enabled by parameter <a href="#">50.42 FBA B debug mode</a> . This parameter is read-only.	0 / uint32															
	00000000..FFFFFFFFh	Status word sent by fieldbus adapter B to master.	1 = 1															
50.47	FBA B actual value 1	Displays raw (unmodified) actual value ACT1 sent by fieldbus adapter B to the master (PLC) if debugging is enabled by parameter <a href="#">50.42 FBA B debug mode</a> . This parameter is read-only.	- / int32															
50.48	FBA B actual value 2	Displays raw (unmodified) actual value ACT2 sent by fieldbus adapter B to the master (PLC) if debugging is enabled by parameter <a href="#">50.42 FBA B debug mode</a> . This parameter is read-only.	- / int32															
50.51	FBA B timelevel sel	<p>Selects the communication time levels.</p> <p>In general, lower time levels of read/write services reduce CPU load. The table below shows the time levels of the read/write services for cyclic high and cyclic low data with each parameter setting.</p> <table border="1"> <thead> <tr> <th>Selection</th> <th>Cyclic high *</th> <th>Cyclic low **</th> </tr> </thead> <tbody> <tr> <td><a href="#">Monitoring</a></td> <td>10 ms</td> <td>2 ms</td> </tr> <tr> <td><a href="#">Normal</a></td> <td>2 ms</td> <td>10 ms</td> </tr> <tr> <td><a href="#">Fast</a></td> <td>500 µs</td> <td>2 ms</td> </tr> <tr> <td><a href="#">Very fast</a></td> <td>250 µs</td> <td>2 ms</td> </tr> </tbody> </table> <p>* Cyclic high data consists of fieldbus Status word, Act1 and Act2.</p> <p>** Cyclic low data consists of the parameter data mapped to parameter groups <a href="#">55 FBA B data in</a> and <a href="#">56 FBA B data out</a>, and acyclic data.</p> <p>Control word, Ref1 and Ref2 are handled as interrupts generated on receipt of cyclic high messages.</p> <p><b>Note:</b> This parameter cannot be changed while the drive is running.</p>	Selection	Cyclic high *	Cyclic low **	<a href="#">Monitoring</a>	10 ms	2 ms	<a href="#">Normal</a>	2 ms	10 ms	<a href="#">Fast</a>	500 µs	2 ms	<a href="#">Very fast</a>	250 µs	2 ms	Normal / uint16
Selection	Cyclic high *	Cyclic low **																
<a href="#">Monitoring</a>	10 ms	2 ms																
<a href="#">Normal</a>	2 ms	10 ms																
<a href="#">Fast</a>	500 µs	2 ms																
<a href="#">Very fast</a>	250 µs	2 ms																
	Normal	Normal speed.	0															
	Fast	Fast speed.	1															
	Very fast	Very fast speed.	2															
	Monitoring	Low speed. Optimized for PC tool communication and monitoring usage.	3															

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
50.56	FBA B comm supervision force	<p>Activates fieldbus communication monitoring separately for each control location (see section <a href="#">Local control vs. external control (page 23)</a>).</p> <p>The parameter is primarily intended for monitoring the communication with FBA B when it is connected to the application program and not selected as a control source by drive parameters.</p>	- / uint16
b0	Ext 1	1 = Communication monitoring active when Ext 1 is being used.	
b1	Ext 2	1 = Communication monitoring active when Ext 2 is being used.	
b2	Local	1 = Communication monitoring active when local control is being used.	
b3...15	Reserved		
	0000h...FFFFh		1 = 1 / 1 = 1
50.99	FBA automatic detection	<p>Enables/disables the FBA automatic detection.</p> <p><b>Note:</b> FBA automatic detection works with one fieldbus adapter only.</p>	Enable / uint16
	Disable	FBA automatic detection is disabled.	0
	Enable	FBA automatic detection is enabled.	1

## 452 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
<b>51</b>	FBA A settings	Fieldbus adapter A configuration.	
51.1	FBA A type	Displays the type of the connected fieldbus adapter module.  <b>0</b> = Module is not found or is not properly connected, or is disabled by parameter <b>50.1 FBA A enable</b> ; <b>1</b> = FPBA; <b>32</b> = FCAN; <b>37</b> = FDNA; <b>101</b> = FCNA, <b>128</b> = FENA-11/21; <b>135</b> = FECA; <b>136</b> = FEPL; <b>485</b> = FSCA.  This parameter is read-only.	None / uint16
51.2	FBA A Par2	Parameters <b>51.02...51.26</b> are adapter module-specific. For more information, see the documentation of the fieldbus adapter module. Note that not all of these parameters are necessarily in use.	- / uint16
	0...65535	Fieldbus adapter configuration parameter.	1 = 1 / 1 = 1
...	...	...	...
51.26	FBA A Par26	See parameter <b>51.2 FBA A Par2</b> .	- / uint16
	0...65535	Fieldbus adapter configuration parameter.	1 = 1 / 1 = 1
51.27	FBA A par refresh	Validates any changed fieldbus adapter module configuration settings. After refreshing, the value reverts automatically to <b>Done</b> .  <b>Note:</b> This parameter cannot be changed while the drive is running.	Done / uint16
	Done	Refreshing done.	0
	Refresh	Refreshing.	1
51.28	FBA A par table ver	Displays the parameter table revision of the fieldbus adapter module mapping file (stored in the memory of the drive).  In format axyz, where ax = major table revision number; yz = minor table revision number.  This parameter is read-only.	0 / uint16
	0000...FFFFh	Parameter table revision of adapter module.	1 = 1
51.29	FBA A drive type code	Displays the drive type code in the fieldbus adapter module mapping file (stored in the memory of the drive).  This parameter is read-only.	- / uint16
		Drive type code stored in the mapping file.	1 = 1 / 1 = 1
51.30	FBA A mapping file ver	Displays the fieldbus adapter module mapping file revision stored in the memory of the drive in decimal format.  This parameter is read-only.	- / uint16
		Mapping file revision.	1 = 1 / 1 = 1
51.31	D2FBA A comm status	Displays the status of the fieldbus adapter module communication.	Not configured / uint16
	Not configured	Adapter is not configured.	0

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	Initializing	Adapter is initializing.	1
	Time out	A timeout has occurred in the communication between the adapter and the drive.	2
	Configuration error	Adapter configuration error: mapping file not found in the file system of the drive, or mapping file upload has failed more than three times.	3
	Off-line	Fieldbus communication is off-line.	4
	On-line	Fieldbus communication is on-line, or fieldbus adapter has been configured not to detect a communication break. For more information, see the documentation of the fieldbus adapter.	5
	Reset	Adapter is performing a hardware reset.	6
51.32	FBA A comm SW ver	Displays the patch and build versions of the adapter module firmware in format xxyy, where xx = patch version number, yy = build version number.  Example: C802 = 200.02 (patch version 200, build version 2).	0 / uint16
	0000...FFFFh	Patch and build versions of adapter module firmware.	1 = 1
51.33	FBA A appl SW ver	Displays the major and minor versions of the adapter module firmware in format xyy, where x = major revision number, yy = minor revision number.  Example: 300 = 3.00 (major version 3, minor version 00).	0 / uint16
	0000...FFFFh	Major and minor versions of adapter module firmware.	1 = 1

## 454 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
52	FBA A data in	Selection of data to be transferred from drive to fieldbus controller through fieldbus adapter A.  <b>Note:</b> 32-bit values require two consecutive parameters. Whenever a 32-bit value is selected in a data parameter, the next parameter is automatically reserved.	
52.1	FBA A data in1	Parameters 52.01...52.12 select data to be transferred from the drive to the fieldbus controller through fieldbus adapter A.	None / uint32
	None	None.	0
	CW 16bit	Control Word (16 bits)	1
	Ref1 16bit	Reference REF1 (16 bits)	2
	Ref2 16bit	Reference REF2 (16 bits)	3
	SW 16bit	Status Word (16 bits)	4
	Act1 16bit	Actual value ACT1 (16 bits)	5
	Act2 16bit	Actual value ACT2 (16 bits)	6
	CW 32bit	Control Word (32 bits)	11
	Ref1 32bit	Reference REF1 (32 bits)	12
	Ref2 32bit	Reference REF2 (32 bits)	13
	SW 32bit	Status Word (32 bits)	14
	Act1 32bit	Actual value ACT1 (32 bits)	15
	Act2 32bit	Actual value ACT2 (32 bits)	16
	SW2 16bit	Status Word 2 (16 bits)	24
	Other [bit]	Source selection (see <a href="#">Terms and abbreviations (page 134)</a> ).	-
...	...	...	...
52.12	FBA A data in12	See parameter 52.1 FBA A data in1.	None / uint32

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
<b>53</b>	FBA A data out	Selection of data to be transferred from fieldbus controller to drive through fieldbus adapter A.  <b>Note:</b> 32-bit values require two consecutive parameters. Whenever a 32-bit value is selected in a data parameter, the next parameter is automatically reserved.	
53.1	FBA data out1	Parameters 53.01...53.12 select data to be transferred from the fieldbus controller to the drive through fieldbus adapter A.	None / uint32
	None	None.	0
	CW 16bit	Control Word (16 bits)	1
	Ref1 16bit	Reference REF1 (16 bits)	2
	Ref2 16bit	Reference REF2 (16 bits)	3
	CW 32bit	Control Word (32 bits)	11
	Ref1 32bit	Reference REF1 (32 bits)	12
	Ref2 32bit	Reference REF2 (32 bits)	13
	CW2 16bit	Control Word 2 (16 bits)	21
	Other [bit]	Source selection (see <a href="#">Terms and abbreviations (page 134)</a> ).	-
53.2	FBA data out2	Parameters 53.01...53.12 select data to be transferred from the fieldbus controller to the drive through fieldbus adapter A.	None / uint32
	None	None.	0
	CW 16bit	Control Word (16 bits)	1
	Ref1 16bit	Reference REF1 (16 bits)	2
	Ref2 16bit	Reference REF2 (16 bits)	3
	CW 32bit	Control Word (32 bits)	11
	Ref1 32bit	Reference REF1 (32 bits)	12
	Ref2 32bit	Reference REF2 (32 bits)	13
	CW2 16bit	Control Word 2 (16 bits)	21
	Other [bit]	Source selection (see <a href="#">Terms and abbreviations (page 134)</a> ).	-
53.12	FBA data out12	See parameter 53.1 FBA data out1.	None / uint32

## 456 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
<b>54</b>	FBA B settings	Fieldbus adapter B configuration.	
54.1	FBA B type	Displays the type of the connected fieldbus adapter module. <b>0</b> = Module is not found or is not properly connected, or is disabled by parameter <a href="#">50.31 FBA B enable</a> ; <b>1</b> = FPBA; <b>32</b> = FCAN; <b>37</b> = FDNA; <b>101</b> = FCNA; <b>128</b> = FENA-11/21; <b>135</b> = FECA; <b>136</b> = FEPL; <b>485</b> = FSCA. This parameter is read-only.	None / uint16
54.2	FBA B Par2	Parameters <a href="#">54.02</a> ... <a href="#">54.26</a> are adapter module-specific. For more information, see the documentation of the fieldbus adapter module. Note that not all of these parameters are necessarily in use.	- / uint16
	0.0 ... 65535.0	Fieldbus adapter configuration parameter.	1 = 1 / 1 = 1
...	...	...	...
54.26	FBA B Par26	See parameter <a href="#">54.2 FBA B Par2</a> .	- / uint16
	0.0 ... 65535.0	Fieldbus adapter configuration parameter.	1 = 1 / 1 = 1
54.27	FBA B par refresh	Validates any changed fieldbus adapter module configuration settings. After refreshing, the value reverts automatically to <a href="#">Done</a> .  <b>Note:</b> This parameter cannot be changed while the drive is running.	Done / uint16
	Done	Refreshing done.	0
	Refresh	Refreshing.	1
54.28	FBA B par table ver	Displays the parameter table revision of the fieldbus adapter module mapping file (stored in the memory of the drive). In format axyz, where ax = major table revision number; yz = minor table revision number. This parameter is read-only.	0 / uint16
	0000...FFFFh	Parameter table revision of adapter module.	1 = 1
54.29	FBA B drive type code	Displays the drive type code in the fieldbus adapter module mapping file (stored in the memory of the drive). This parameter is read-only.	- / uint16
	0...65535	Drive type code stored in the mapping file.	1 = 1 / 1 = 1
54.30	FBA B mapping file ver	Displays the fieldbus adapter module mapping file revision stored in the memory of the drive in decimal format. This parameter is read-only.	- / uint16
	0...65535	Mapping file revision.	1 = 1 / 1 = 1
54.31	D2FBA B comm status	Displays the status of the fieldbus adapter module communication.	Not configured / uint16
	Not configured	Adapter is not configured.	0
	Initializing	Adapter is initializing.	1



No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	Time out	A timeout has occurred in the communication between the adapter and the drive.	2
	Configuration error	Adapter configuration error: mapping file not found in the file system of the drive, or mapping file upload has failed more than three times.	3
	Off-line	Fieldbus communication is off-line.	4
	On-line	Fieldbus communication is on-line, or fieldbus adapter has been configured not to detect a communication break. For more information, see the documentation of the fieldbus adapter.	5
	Reset	Adapter is performing a hardware reset.	6
54.32	FBA B comm SW ver	Displays the patch and build versions of the adapter module firmware in format xyy, where xx = patch version number, yy = build version number.  Example: C802 = 200.02 (patch version 200, build version 2).	0 / uint16
	0000...FFFFh	Patch and build versions of adapter module firmware.	1 = 1
54.33	FBA B appl SW ver	Displays the major and minor versions of the adapter module firmware in format xyy, where x = major revision number, yy = minor revision number.  Example: 300 = 3.00 (major version 3, minor version 00).	0 / uint16
	0000...FFFFh	Major and minor versions of adapter module firmware.	1 = 1

## 458 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
<b>55</b>	FBA B data in	Selection of data to be transferred from drive to fieldbus controller through fieldbus adapter B.	
55.1	FBA B data in1	Parameters 55.01...55.12 select data to be transferred from the drive to the fieldbus controller through fieldbus adapter B.	None / uint32
	None	None.	0
	CW 16bit	Control Word (16 bits)	1
	Ref1 16bit	Reference REF1 (16 bits)	2
	Ref2 16bit	Reference REF2 (16 bits)	3
	SW 16bit	Status Word (16 bits)	4
	Act1 16bit	Actual value ACT1 (16 bits)	5
	Act2 16bit	Actual value ACT2 (16 bits)	6
	CW 32bit	Control Word (32 bits)	11
	Ref1 32bit	Reference REF1 (32 bits)	12
	Ref2 32bit	Reference REF2 (32 bits)	13
	SW 32bit	Status Word (32 bits)	14
	Act1 32bit	Actual value ACT1 (32 bits)	15
	Act2 32bit	Actual value ACT2 (32 bits)	16
	SW2 16bit	Status Word 2 (16 bits)	24
	Other [bit]	Source selection (see <a href="#">Terms and abbreviations (page 134)</a> ).	-
...	...	...	...
55.12	FBA B data in12	See parameter <a href="#">55.1 FBA B data in1</a> .	None / uint32

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
<b>56</b>	<b>FBA B data out</b>	Selection of data to be transferred from fieldbus controller to drive through fieldbus adapter B.	
56.1	FBA B data out1	Parameters <a href="#">56.01</a> ... <a href="#">56.12</a> select data to be transferred from the fieldbus controller to the drive through fieldbus adapter B.	None / uint32
	None	None.	0
	CW 16bit	Control Word (16 bits)	1
	Ref1 16bit	Reference REF1 (16 bits)	2
	Ref2 16bit	Reference REF2 (16 bits)	3
	CW 32bit	Control Word (32 bits)	11
	Ref1 32bit	Reference REF1 (32 bits)	12
	Ref2 32bit	Reference REF2 (32 bits)	13
	CW2 16bit	Control Word 2 (16 bits)	21
	Other [bit]	Source selection (see <a href="#">Terms and abbreviations (page 134)</a> ).	-
...	...	...	...
56.12	FBA B data out12	See parameter <a href="#">56.1 FBA B data out1</a> .	None / uint32




## 460 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
<b>58</b>	Embedded fieldbus	Configuration of the embedded fieldbus (EFB) interface.  See also chapter Fieldbus control through the embedded fieldbus interface (EFB).	
58.1	Protocol enable	Enables/disables the embedded fieldbus interface and selects the protocol to use.  <b>Note:</b> <ul style="list-style-type: none"> <li>When the embedded fieldbus interface is enabled, the drive-to-drive link functionality is automatically disabled.</li> <li>This parameter cannot be changed while the drive is running.</li> </ul>	None / uint16
	None	None (communication disabled).	0
	Modbus RTU	Embedded fieldbus interface is enabled and uses the Modbus RTU protocol.	1
58.2	Protocol ID	Displays the protocol ID and revision.  This parameter is read-only.	0 / uint16
	0000...FFFFh	Protocol ID and revision.	1 = 1
58.3	Node address	Defines the node address of the drive on the fieldbus link. Values 1...247 are allowable. Two devices with the same address are not allowed on-line.  Changes to this parameter take effect after the control unit is rebooted or the new settings validated by parameter <a href="#">58.6 Communication control</a> .	1 / uint16
	0...255	Node address (values 1...247 are allowable).	1 = 1 / 1 = 1
58.4	Baud rate	Selects the transfer rate of the fieldbus link.  Changes to this parameter take effect after the control unit is rebooted or the new settings validated by parameter <a href="#">58.6 Communication control</a> .	19.2 kbps / uint16
	4.8 kbps	4.8 kbit/s.	1
	9.6 kbps	9.6 kbit/s.	2
	19.2 kbps	19.2 kbit/s.	3
	38.4 kbps	38.4 kbit/s.	4
	57.6 kbps	57.6 kbit/s.	5
	76.8 kbps	76.8 kbit/s.	6
	115.2 kbps	115.2 kbit/s.	7
58.5	Parity	Selects the type of parity bit and the number of stop bits.  Changes to this parameter take effect after the control unit is rebooted or the new settings validated by parameter <a href="#">58.6 Communication control</a> .	8 EVEN 1 / uint16
	8 NONE 1	Eight data bits, no parity bit, one stop bit.	0
	8 NONE 2	Eight data bits, no parity bit, two stop bits.	1

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	8 EVEN 1	Eight data bits, even parity bit, one stop bit.	2
	8 ODD 1	Eight data bits, odd parity bit, one stop bit.	3
58.6	Communication control	Validates any changes in the EFB settings, or activates silent mode.	Enabled / uint16
	Enabled	Normal operation.	0
	Refresh settings	Validates any changed EFB configuration settings. Reverts automatically to <b>Enabled</b> .	1
	Silent mode	Activates silent mode (no messages are transmitted). Silent mode can be terminated by activating the <b>Refresh settings</b> selection of this parameter.	2
58.7	Communication diagnostics	Displays the status of the EFB communication. This parameter is read-only.	- / uint16
	b0 Init failed	1 = EFB initialization failed	
	b1 Addr config err	1 = Node address not allowed by protocol	
	b2 Silent mode	1 = Drive not allowed to transmit 0 = Drive allowed to transmit	
	b3 Autobauding	Reserved	
	b4 Wiring error	1 = Errors detected (A/B wires possibly swapped)	
	b5 Parity error	1 = Error detected: check parameters <a href="#">58.04</a> and <a href="#">58.05</a>	
	b6 Baud rate error	1 = Error detected: check parameters <a href="#">58.05</a> and <a href="#">58.04</a>	
	b7 No bus activity	1 = 0 bytes received during last 5 seconds	
	b8 No packets	1 = 0 packets (addressed to any device) detected during last 5 seconds	
	b9 Noise or addressing error	1 = Errors detected (interference, or another device with the same address on line)	
	b10 Comm loss	1 = 0 packets addressed to the drive received within timeout ( <a href="#">58.16</a> )	
	b11 CW/Ref loss	1 = No control word or references received within timeout ( <a href="#">58.16</a> )	
	b12 Not active	Reserved	
	b13 Protocol 1	1 = Protocol-dependent status information	
	b14 Protocol 2	1 = Protocol-dependent status information	
	b15 Internal error	1 = Problem with calls to drive control program	
	0000h...FFFFh		1 = 1 / 1 = 1
58.8	Received packets	Displays a count of valid packets addressed to the drive.  During normal operation, this number increases constantly.  Can be reset from the control panel by keeping Reset depressed for over 3 seconds.	0 / uint32

## 462 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	0...4294967295	Number of received packets addressed to the drive.	1 = 1 / 1 = 1
58.9	Transmitted packets	<p>Displays a count of valid packets transmitted by the drive.</p> <p>During normal operation, this number increases constantly.</p> <p>Can be reset from the control panel by keeping Reset depressed for over 3 seconds.</p>	0 / uint32
	0...4294967295	Number of transmitted packets.	1 = 1 / 1 = 1
58.10	All packets	<p>Displays a count of valid packets addressed to any device on the bus. During normal operation, this number increases constantly.</p> <p>Can be reset from the control panel by keeping Reset depressed for over 3 seconds.</p>	0 / uint32
	0...4294967295	Number of all received packets.	1 = 1 / 1 = 1
58.11	UART errors	<p>Displays a count of character errors received by the drive. An increasing count indicates a configuration problem on the bus.</p> <p>Can be reset from the control panel by keeping Reset depressed for over 3 seconds.</p>	0 / uint32
	0...4294967295	Number of UART errors.	1 = 1 / 1 = 1
58.12	CRC errors	<p>Displays a count of packets with a CRC error received by the drive. An increasing count indicates interference on the bus.</p> <p>Can be reset from the control panel by keeping Reset depressed for over 3 seconds.</p>	0 / uint32
	0...4294967295	Number of CRC errors.	1 = 1 / 1 = 1
58.14	Communication loss action	<p>Selects how the drive reacts to an EFB communication break.</p> <p>Changes to this parameter take effect after the control unit is rebooted or the new settings validated by parameter <a href="#">58.6 Communication control</a>.</p> <p>See also parameters <a href="#">58.15 Communication loss mode</a> and <a href="#">58.16 Communication loss time</a>.</p>	Fault / uint16
	No	No action taken (monitoring disabled).	0
	Fault	Drive trips on <a href="#">6681 EFB communication loss</a> . This only occurs if control is expected from the EFB (EFB selected as source of start/stop/reference in the currently active control location), or if supervision is forced using parameter <a href="#">58.36 EFB comm supervision force</a> .	1

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	Last speed	<p>Drive generates an <a href="#">A7CE EFB comm loss</a> warning and freezes the speed to the level the drive was operating at. This only occurs if control is expected from the EFB, or if supervision is forced using parameter <a href="#">58.36 EFB comm supervision force</a>.</p> <p>The speed is determined on the basis of actual speed using 850 ms low-pass filtering.</p> <p> <b>WARNING!</b> Make sure that it is safe to continue operation in case of a communication break.</p>	2
	Speed ref safe	<p>Drive generates an <a href="#">A7CE EFB comm loss</a> warning and sets the speed to the speed defined by parameter <a href="#">22.41 Speed ref safe</a> (or <a href="#">28.41 Frequency ref safe</a> when frequency reference is being used). This only occurs if control is expected from the EFB, or if supervision is forced using parameter <a href="#">58.36 EFB comm supervision force</a>.</p> <p> <b>WARNING!</b> Make sure that it is safe to continue operation in case of a communication break.</p>	3
	Fault always	<p>Drive trips on <a href="#">6681 EFB communication loss</a>. This occurs even though no control is expected from the EFB.</p>	4
	Warning	<p>Drive generates an <a href="#">A7CE EFB comm loss</a> warning. This only occurs if control is expected from the EFB, or if supervision is forced using parameter <a href="#">58.36 EFB comm supervision force</a>.</p> <p> <b>WARNING!</b> Make sure that it is safe to continue operation in case of a communication break.</p>	5
58.15	Communication loss mode	<p>Defines which message types reset the timeout counter for detecting an EFB communication loss.</p> <p>Changes to this parameter take effect after the control unit is rebooted or the new settings validated by parameter <a href="#">58.6 Communication control</a>.</p> <p>See also parameters <a href="#">58.14 Communication loss action</a> and <a href="#">58.16 Communication loss time</a>.</p>	Cw / Ref1 / Ref2 / uint16
	Any message	<p>Any message addressed to the drive resets the timeout.</p>	1
	Cw / Ref1 / Ref2	<p>A write of the control word or a reference from the fieldbus resets the timeout.</p>	2

## 464 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
58.16	Communication loss time	<p>Sets a timeout for EFB communication. If a communication break lasts longer than the timeout, the action specified by parameter <a href="#">58.14 Communication loss action</a> is taken.</p> <p>Changes to this parameter take effect after the control unit is rebooted or the new settings validated by parameter <a href="#">58.6 Communication control</a>.</p> <p><b>Note:</b> There is a 30-second boot-up delay immediately after power-up. During the delay, the communication break monitoring is disabled (but communication itself can be active).</p> <p>See also parameter <a href="#">58.15 Communication loss mode</a>.</p>	3.0 s / uint16
	0.0 ... 6000.0 s	EFB communication timeout.	1 = 1 s / 10 = 1 s
58.17	Transmit delay	<p>Defines a minimum response delay in addition to any fixed delay imposed by the protocol.</p> <p>Changes to this parameter take effect after the control unit is rebooted or the new settings validated by parameter <a href="#">58.6 Communication control</a>.</p>	0 ms / uint16
	0...65535 ms	Minimum response delay.	1 = 1 ms / 1 = 1 ms
58.18	EFB control word	<p>Displays the raw (unmodified) control word sent by the Modbus controller to the drive. For debugging purposes.</p> <p>This parameter is read-only.</p>	0 / uint32
	00000000..FFFFFFFFh	Control word sent by Modbus controller to the drive.	1 = 1
58.19	EFB status word	<p>Displays the raw (unmodified) status word sent by the drive to the Modbus controller. For debugging purposes.</p> <p>This parameter is read-only.</p>	0 / uint32
	00000000..FFFFFFFFh	Status word sent by the drive to the Modbus controller.	1 = 1
58.25	Control profile	Defines the control profile used by the protocol.	ABB Drives / uint16
	ABB Drives	ABB Drives profile (with a 16-bit control word) with registers in the classic format for backward compatibility.	0
	Transparent	Transparent profile (16-bit or 32-bit control word) with registers in the classic format.	2
58.26	EFB ref1 type	<p>Selects the type and scaling of reference 1 received through the embedded fieldbus interface.</p> <p>The scaled reference is displayed by <a href="#">3.9 EFB reference 1</a>.</p>	Auto / uint16
	Auto	Type and scaling are chosen automatically according to which reference chain (see settings <a href="#">Torque</a> , <a href="#">Speed</a> , <a href="#">Frequency</a> ) the incoming reference is connected to. If the reference is not connected to any chain, no scaling is applied (as with setting <a href="#">Transparent</a> ).	0
	Transparent	No scaling is applied.	1



No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	General	Generic reference with a scaling of 100 = 1 (ie. integer and two decimals).	2
	Torque	The scaling is defined by parameter <a href="#">46.3 Torque scaling</a> .	3
	Speed	The scaling is defined by parameter <a href="#">46.1 Speed scaling</a> .	4
	Frequency	The scaling is defined by parameter <a href="#">46.2 Frequency scaling</a> .	5
58.27	EFB ref2 type	Selects the type and scaling of reference 2 received through the embedded fieldbus interface.  The scaled reference is displayed by <a href="#">3.10 EFB reference 2</a> .  For the selections, see parameter <a href="#">58.26 EFB ref1 type</a> .	Torque / uint16
58.28	EFB act1 type	Selects the type/source and scaling of actual value 1 transmitted to the fieldbus network through the embedded fieldbus interface.	Auto / uint16
	Auto	Type/source and scaling follow the type of reference 1 selected by parameter <a href="#">58.26 EFB ref1 type</a> . See the individual settings below for the sources and scalings.	0
	Transparent	The value selected by parameter <a href="#">58.31 EFB act1 transparent source</a> is sent as actual value 1. No scaling is applied (the 16-bit scaling is 1 = 1 unit).	1
	General	The value selected by parameter <a href="#">58.31 EFB act1 transparent source</a> is sent as actual value 1 with a 16-bit scaling of 100 = 1 unit (ie. integer and two decimals).	2
	Torque	<a href="#">1.10 Motor torque</a> is sent as actual value 1. The scaling is defined by parameter <a href="#">46.3 Torque scaling</a> .	3
	Speed	<a href="#">1.1 Motor speed used</a> is sent as actual value 1. The scaling is defined by parameter <a href="#">46.1 Speed scaling</a> .	4
	Frequency	<a href="#">1.6 Output frequency</a> is sent as actual value 1. The scaling is defined by parameter <a href="#">46.2 Frequency scaling</a> .	5
	Position	Motor position is sent as actual value 1. See parameter <a href="#">90.6 Motor position scaled</a> .	6
58.29	EFB act2 type	Selects the type/source and scaling of actual value 2 transmitted to the fieldbus network through the embedded fieldbus interface.	Torque / uint16
	Auto	Type/source and scaling follow the type of reference 2 selected by parameter <a href="#">58.27 EFB ref2 type</a> . See the individual settings below for the sources and scalings.	0
	Transparent	The value selected by parameter <a href="#">58.32 EFB act2 transparent source</a> is sent as actual value 2. No scaling is applied (the 16-bit scaling is 1 = 1 unit).	1
	General	The value selected by parameter <a href="#">58.32 EFB act2 transparent source</a> is sent as actual value 2 with a 16-bit scaling of 100 = 1 unit (ie. integer and two decimals).	2

## 466 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	Torque	<a href="#">1.10 Motor torque</a> is sent as actual value 2. The scaling is defined by parameter <a href="#">46.3 Torque scaling</a> .	3
	Speed	<a href="#">1.1 Motor speed used</a> is sent as actual value 2. The scaling is defined by parameter <a href="#">46.1 Speed scaling</a> .	4
	Frequency	<a href="#">1.6 Output frequency</a> is sent as actual value 2. The scaling is defined by parameter <a href="#">46.2 Frequency scaling</a> .	5
	Position	Motor position is sent as actual value 1. See parameter <a href="#">90.6 Motor position scaled</a> .	6
58.30	EFB status word transparent source	Selects the source of the status word when <a href="#">58.25 Control profile</a> is set to <a href="#">Transparent</a> .	Not selected / uint32
	Not selected	None.	0
	Other [bit]	Source selection (see <a href="#">Terms and abbreviations (page 134)</a> ).	-
58.31	EFB act1 transparent source	Selects the source of actual value 1 when <a href="#">58.28 EFB act1 type</a> is set to <a href="#">Transparent</a> or <a href="#">General</a> .	Not selected / uint32
	Not selected	None.	0
	Other [bit]	Source selection (see <a href="#">Terms and abbreviations (page 134)</a> ).	-
58.32	EFB act2 transparent source	Selects the source of actual value 1 when <a href="#">58.29 EFB act2 type</a> is set to <a href="#">Transparent</a> or <a href="#">General</a> .	Not selected / uint32
	Not selected	None.	0
	Other [bit]	Source selection (see <a href="#">Terms and abbreviations (page 134)</a> ).	-
58.33	Addressing mode	Defines the mapping between parameters and holding registers in the 400101...465535 Modbus register range.  Changes to this parameter take effect after the control unit is rebooted or the new settings validated by parameter <a href="#">58.6 Communication control</a> .	Mode 0 / uint16
	Mode 0	<u>16-bit values (groups 1...99, indexes 1...99):</u> Register address = 400000 + 100 × parameter group + parameter index. For example, parameter 22.80 would be mapped to register 400000 + 2200 + 80 = 402280.  <u>32-bit values (groups 1...99, indexes 1...99):</u> Register address = 420000 + 200 × parameter group + 2 × parameter index. For example, parameter 22.80 would be mapped to register 420000 + 4400 + 160 = 424560.	0
	Mode 1	<u>16-bit values (groups 1...255, indexes 1...255):</u> Register address = 400000 + 256 × parameter group + parameter index. For example, parameter 22.80 would be mapped to register 400000 + 5632 + 80 = 405712.	1

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	Mode 2	<u>32-bit values (groups 1...127, indexes 1...255):</u> Register address = 400000 + 512 × parameter group + 2 × parameter index. For example, parameter 22.80 would be mapped to register 400000 + 11264 + 160 = 411424.	2
58.34	Word order	Selects in which order 16-bit registers of 32-bit parameters are transferred.  For each register, the first byte contains the high order byte and the second byte contains the low order byte.  Changes to this parameter take effect after the control unit is rebooted or the new settings validated by parameter 58.6 <a href="#">Communication control</a> .	LO-HI / uint16
	HI-LO	The first register contains the high order word, the second contains the low order word.	0
	LO-HI	The first register contains the low order word, the second contains the high order word.	1
58.36	EFB comm supervision force	Activates fieldbus communication monitoring separately for each control location (see section <a href="#">Local control vs. external control (page 23)</a> ).  The parameter is primarily intended for monitoring the communication with EFB when it is connected to the application program and not selected as a control source by drive parameters.	- / uint16
	b0 Ext 1	1 = Communication monitoring active when Ext 1 is being used.	
	b1 Ext 2	1 = Communication monitoring active when Ext 2 is being used.	
	b2 Local	1 = Communication monitoring active when local control is being used.	
	b3...15 Reserved		
	0000h...FFFFh		1 = 1 / 1 = 1
58.101	Data I/O 1	Defines the address in the drive which the Modbus master accesses when it reads from or writes to register address 400001.  The master defines the type of the data (input or output). The value is transmitted in a Modbus frame consisting of two 16-bit words. If the value is 16-bit, it is transmitted in the LSW (least significant word). If the value is 32-bit, the subsequent parameter is also reserved for it and must be set to <a href="#">None</a> .	CW 16bit / uint32
	None	None.	0
	CW 16bit	Control Word (16 bits).	1
	Ref1 16bit	Reference REF1 (16 bits).	2
	Ref2 16bit	Reference REF2 (16 bits).	3
	SW 16bit	Status Word (16 bits).	4

## 468 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	Act1 16bit	Actual value ACT1 (16 bits).	5
	Act2 16bit	Actual value ACT2 (16 bits).	6
	CW 32bit	Control Word (32 bits).	11
	Ref1 32bit	Reference REF1 (32 bits).	12
	Ref2 32bit	Reference REF2 (32 bits).	13
	SW 32bit	Status Word (32 bits).	14
	Act1 32bit	Actual value ACT1 (32 bits).	15
	Act2 32bit	Actual value ACT2 (32 bits).	16
	CW2 16bit	Control Word 2 (16 bits). When a 32-bit control word is used, this setting means the most-significant 16 bits.	21
	SW2 16bit	Status Word 2 (16 bits). When a 32-bit control word is used, this setting means the most-significant 16 bits.	24
	RO/DIO control word	Parameter <a href="#">10.99 RO/DIO control word</a> .	31
	AO1 data storage	Parameter <a href="#">13.91 AO1 data storage</a> .	32
	AO2 data storage	Parameter <a href="#">13.92 AO2 data storage</a> .	33
	Feedback data storage	Parameter <a href="#">40.91 Feedback data storage</a> .	40
	Setpoint data storage	Parameter <a href="#">40.92 Setpoint data storage</a> .	41
	Other [bit]	Source selection (see <a href="#">Terms and abbreviations (page 134)</a> ).	-
58.102	Data I/O 2	Defines the address in the drive which the Modbus master accesses when it reads from or writes to register address 400002. For the selections, see parameter <a href="#">58.101 Data I/O 1</a> .	Ref1 16bit / uint32
58.103	Data I/O 3	Defines the address in the drive which the Modbus master accesses when it reads from or writes to register address 400003. For the selections, see parameter <a href="#">58.101 Data I/O 1</a> .	Ref2 16bit / uint32
58.104	Data I/O 4	Defines the address in the drive which the Modbus master accesses when it reads from or writes to register address 400004. For the selections, see parameter <a href="#">58.101 Data I/O 1</a> .	SW 16bit / uint32
58.105	Data I/O 5	Defines the address in the drive which the Modbus master accesses when it reads from or writes to register address 400005. For the selections, see parameter <a href="#">58.101 Data I/O 1</a> .	Act1 16bit / uint32


No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
58.106	Data I/O 6	Defines the address in the drive which the Modbus master accesses when it reads from or writes to register address 400006. For the selections, see parameter <a href="#">58.101 Data I/O 1</a> .	Act2 16bit / uint32
58.107	Data I/O 7	Parameter selector for Modbus register address 400007. For the selections, see parameter <a href="#">58.101 Data I/O 1</a> .	None / uint32
...	...	...	...
58.124	Data I/O 24	Parameter selector for Modbus register address 400024. For the selections, see parameter <a href="#">58.101 Data I/O 1</a> .	None / uint32

## 470 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
60	DDCS communication	<p>DDCS communication configuration.</p> <p>The DDCS protocol is used in the communication between</p> <ul style="list-style-type: none"> <li>• drives in a master/follower configuration (see page 34),</li> <li>• the drive and an external controller such as the AC 800M (see page 42), or</li> <li>• the drive (or more precisely, an inverter unit) and the supply unit of the drive system (see page 44).</li> </ul> <p>All of the above utilize a fiber optic link which also requires an FDCO module (typically with ZCU control units) or an RDCO module (with BCU control units). Master/follower and external controller communication can also be implemented through shielded twisted-pair cable connected to the XD2D connector of the drive.</p> <p>This group also contains parameters for drive-to-drive (D2D) communication supervision.</p>	
60.1	M/F communication port	Selects the connection used by the master/follower functionality.	Not in use / uint16
	Not in use	None (communication disabled).	0
	Slot 1A	Channel A on FDCO module in slot 1 (with ZCU control unit only).	1
	Slot 2A	Channel A on FDCO module in slot 2 (with ZCU control unit only).	2
	Slot 3A	Channel A on FDCO module in slot 3 (with ZCU control unit only).	3
	Slot 1B	Channel B on FDCO module in slot 1 (with ZCU control unit only).	4
	Slot 2B	Channel B on FDCO module in slot 2 (with ZCU control unit only).	5
	Slot 3B	Channel B on FDCO module in slot 3 (with ZCU control unit only).	6
	RDCO CH 2	Channel 2 on RDCO module (with BCU control unit only).	12
	XD2D	<p>Connector XD2D.</p> <p><b>Note:</b> This connection cannot co-exist, and is not to be confused with, drive-to-drive (D2D) communication implemented by application programming (detailed in <i>Drive application programming manual (IEC 61131-3)</i>, 3AUA0000127808 [English]).</p>	7
60.2	M/F node address	<p>Selects the node address of the drive for master/follower communication. No two nodes on-line may have the same address.</p> <p><b>Note:</b> The allowable addresses for the master are 0 and 1. The allowable addresses for followers are 2...60.</p>	1 / uint16

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	1...254	Node address.	- / -
60.3	M/F mode	Defines the role of the drive on the master/follower or drive-to-drive link.	Not in use / uint16
	Not in use	Master/follower functionality not active.	0
	DDCS master	The drive is the master on the master/follower (DDCS) link.	1
	DDCS follower	The drive is a follower on the master/follower (DDCS) link.	2
	D2D master	The drive is the master on the master/follower (D2D) link.  <b>Note:</b> This setting is only to be used with D2D communication implemented by application programming. If you are using the master/follower functionality (see page 34) through the XD2D connector, select <b>DDCS master</b> instead.	3
	D2D follower	The drive is a follower on the master/follower (D2D) link.  <b>Note:</b> This setting is only to be used with D2D communication implemented by application programming. If you are using the master/follower functionality (see page 34) through the XD2D connector, select <b>DDCS follower</b> instead.	4
	DDCS forcing	The role of the drive on the master/follower (DDCS) link is defined by parameters 60.15 <b>Force master</b> and 60.16 <b>Force follower</b> .	5
	D2D forcing	The role of the drive on the master/follower (D2D) link is defined by parameters 60.15 <b>Force master</b> and 60.16 <b>Force follower</b> .  <b>Note:</b> This setting is only to be used with D2D communication implemented by application programming. If you are using the master/follower functionality (see page 34) through the XD2D connector, select <b>DDCS forcing</b> instead.	6
60.5	M/F HW connection	Selects the topology of the master/follower link.  <b>Note:</b> Use the setting <b>Star</b> if using the master/follower functionality (see page 34) through the XD2D connector (as opposed to a fiber optic link).	Ring / uint16
	Ring	The devices are connected in a ring topology. Forwarding of messages is enabled.	0
	Star	The devices are connected in a star topology (for example, through a branching unit). Forwarding of messages is disabled.	1

## 472 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
60.7	M/F link control	<p>Defines the light intensity of the transmission LED of RDCO module channel CH2. (This parameter is effective only when parameter <a href="#">60.1 M/F communication port</a> is set to <a href="#">RDCO CH 2</a>. FDCO modules have a hardware transmitter current selector.)</p> <p>In general, use higher values with longer fiber optic cables.</p> <p>The maximum setting is applicable to the maximum length of the fiber optic link. See <a href="#">Master/follower functionality (page 34)</a>.</p>	10 / uint16
	1...15	Light intensity.	- / -
60.8	M/F comm loss timeout	<p>Sets a timeout for master/follower (DDCS) communication. If a communication break lasts longer than the timeout, the action specified by parameter <a href="#">60.9 M/F comm loss function</a> is taken.</p> <p>As a rule of thumb, this parameter should be set to at least 3 times the transmit interval of the master.</p>	100 ms / uint16
	0..65535 ms	Master/follower communication timeout.	- / -
60.9	M/F comm loss function	Selects how the drive reacts to a master/follower communication break.	Fault / uint16
	NoAction	No action taken.	0
	Warning	<p>The drive generates an <a href="#">A7CB M/F comm loss</a> warning. This only occurs if control is expected from the master/follower link, or if supervision is forced using parameter <a href="#">60.32 M/F comm supervision force</a>.</p> <p> <b>WARNING!</b> Make sure that it is safe to continue operation in case of a communication break.</p>	1
	Fault	Drive trips on <a href="#">7582 M/F comm loss</a> . This only occurs if control is expected from the master/follower link, or if supervision is forced using parameter <a href="#">60.32 M/F comm supervision force</a> .	2
	Fault always	Drive trips on <a href="#">7582 M/F comm loss</a> . This occurs even though no control is expected from the master/follower link.	3
60.10	M/F ref1 type	Selects the type and scaling of reference 1 received from the master/follower link. The resulting value is shown by <a href="#">3.13 M/F or D2D ref1</a> .	Auto / uint16
	Auto	Type and scaling are chosen automatically according to which reference chain (see settings <a href="#">Torque</a> , <a href="#">Speed</a> , <a href="#">Frequency</a> ) the incoming reference is connected to. If the reference is not connected to any chain, no scaling is applied (as with setting Transparent).	0
	Transparent	No scaling is applied.	1
	General	Generic reference with a scaling of 100 = 1 (ie. integer and two decimals).	2



No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	Torque	The scaling is defined by parameter <a href="#">46.3 Torque scaling</a> .	3
	Speed	The scaling is defined by parameter <a href="#">46.1 Speed scaling</a> .	4
	Frequency	The scaling is defined by parameter <a href="#">46.2 Frequency scaling</a> .	5
60.11	M/F ref2 type	Selects the type and scaling of reference 2 received from the master/follower link. The resulting value is shown by <a href="#">3.14 M/F or D2D ref2</a> .  For the selections, see parameter <a href="#">60.10 M/F ref1 type</a> .	Torque / uint16
60.12	M/F act1 type	Selects the type/source and scaling of actual value ACT1 transmitted to the master/follower link.	Auto / uint16
	Auto	Type/source and scaling follow the type of reference 1 selected by parameter <a href="#">60.10 M/F ref1 type</a> . See the individual settings below for the sources and scalings.	0
	Transparent	Reserved	1
	General	Reserved	2
	Torque	<a href="#">1.10 Motor torque</a> is sent as actual value 1. The scaling is defined by parameter <a href="#">46.3 Torque scaling</a> .	3
	Speed	<a href="#">1.1 Motor speed used</a> is sent as actual value 1. The scaling is defined by parameter <a href="#">46.1 Speed scaling</a> .	4
	Frequency	<a href="#">1.6 Output frequency</a> is sent as actual value 1. The scaling is defined by parameter <a href="#">46.2 Frequency scaling</a> .	5
60.13	M/F act2 type	Selects the type/source and scaling of actual value ACT2 transmitted to the master/follower link.	Auto / uint16
	Auto	Type/source and scaling follow the type of reference 2 selected by parameter <a href="#">60.11 M/F ref2 type</a> . See the individual settings below for the sources and scalings.	0
	Transparent	Reserved	1
	General	Reserved	2
	Torque	<a href="#">1.10 Motor torque</a> is sent as actual value 2. The scaling is defined by parameter <a href="#">46.3 Torque scaling</a> .	3
	Speed	<a href="#">1.1 Motor speed used</a> is sent as actual value 2. The scaling is defined by parameter <a href="#">46.1 Speed scaling</a> .	4
	Frequency	<a href="#">1.6 Output frequency</a> is sent as actual value 2. The scaling is defined by parameter <a href="#">46.2 Frequency scaling</a> .	5
60.14	M/F follower selection	(Effective in the master only.) Defines the followers from which data is read. See also parameters <a href="#">62.28...62.33</a> .	None / uint32
	Follower node 2	Data is read from the follower with node address 2.	2
	Follower node 3	Data is read from the follower with node address 3.	4
	Follower node 4	Data is read from the follower with node address 4.	8
	Follower nodes 2+3	Data is read from the followers with node addresses 2 and 3.	6

## 474 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	Follower nodes 2+4	Data is read from the followers with node addresses 2 and 4.	10
	Follower nodes 3+4	Data is read from the followers with node addresses 3 and 4.	12
	Follower nodes 2+3+4	Data is read from the followers with node addresses 2, 3 and 4.	14
	None	None.	0
60.15	Force master	When parameter <a href="#">60.3 M/F mode</a> is set to <a href="#">DDCS forcing</a> or <a href="#">D2D forcing</a> , this parameter selects a source that forces the drive to be the master on the master/follower link.  1 = Drive is master on the master/follower link	FALSE / uint32
	FALSE	0.	0
	TRUE	1.	1
	Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-
60.16	Force follower	When parameter <a href="#">60.3 M/F mode</a> is set to <a href="#">DDCS forcing</a> or <a href="#">D2D forcing</a> , this parameter selects a source that forces the drive to be a follower on the master/follower link.  1 = Drive is follower on the master/follower link	FALSE / uint32
	FALSE	0.	0
	TRUE	1.	1
	Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-
60.17	Follower fault action	(Effective in the master only.) Selects how the drive reacts to a fault in a follower.  See also parameter <a href="#">60.23 M/F status supervision sel 1</a> .  <b>Note:</b> Each follower must be configured to transmit its status word as one of the three data words in parameters <a href="#">60.1...60.3</a> . In the master, the corresponding target parameter ( <a href="#">62.4...62.12</a> ) must be set to <a href="#">Follower SW</a> .	Fault / uint16
	No action	No action taken. Unaffected drives on the master/follower link will continue running.	0
	Warning	The drive generates a warning ( <a href="#">AFE7 Follower</a> ).	1
	Fault	Drive trips on <a href="#">FF7E Follower</a> . All followers will be stopped.	2

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
60.18	Follower enable	<p>Interlocks the starting of the master to the status of the followers.</p> <p>See also parameter <a href="#">60.23 M/F status supervision sel 1</a>.</p> <p><b>Note:</b> Each follower must be configured to transmit its status word as one of the three data words in parameters <a href="#">60.1...60.3</a>. In the master, the corresponding target parameter (<a href="#">62.4...62.12</a>) must be set to <a href="#">Follower SW</a>.</p>	Always / uint16
	MSW bit 0	The master can only be started if all followers are ready to switch on (bit 0 of <a href="#">6.11 Main status word</a> in each follower is on).	0
	MSW bit 1	The master can only be started if all followers are ready to operate (bit 1 of <a href="#">6.11 Main status word</a> in each follower is on).	1
	MSW bits 0 + 1	The master can only be started if all followers are ready to switch on and ready to operate (bits 0 and 1 of <a href="#">6.11 Main status word</a> in each follower are on).	2
	Always	The starting of the master is not interlocked to the status of the followers.	3
	MSW bit 12	The master can only be started if user-definable bit 12 of <a href="#">6.11 Main status word</a> in each follower is on. See parameter <a href="#">6.31 MSW bit 12 sel</a> .	4
	MSW bits 0 + 12	The master can only be started if both bit 0 and bit 12 of <a href="#">6.11 Main status word</a> in each follower are on.	5
	MSW bits 1 + 12	The master can only be started if both bit 1 and bit 12 of <a href="#">6.11 Main status word</a> in each follower are on.	6
60.19	M/F comm supervision sel 1	<p>Parameters <a href="#">60.19...60.28</a> are only effective when the drive is the master on a D2D (drive-to-drive) link, implemented by application programming. See parameters <a href="#">60.1 M/F communication port</a> and <a href="#">60.3 M/F mode</a>, and <i>Drive (IEC 61131-3) application programming manual</i> (3AUA0000127808 [English]).</p> <p>In the master, parameters <a href="#">60.19 M/F comm supervision sel 1</a> and <a href="#">60.20 M/F comm supervision sel 2</a> specify the followers that are monitored for loss of communication.</p> <p>This parameter selects which followers (out of followers 1...16) are monitored. Each of the selected followers is polled by the master. If no reply is received, the action specified in <a href="#">60.9 M/F comm loss function</a> is taken.</p> <p>The status of communication is shown by <a href="#">62.37 M/F communication status 1</a> and <a href="#">62.38 M/F communication status 2</a>.</p>	- / uint16
	b0 Follower 1	1 = Follower 1 is polled by the master.	
	b1 Follower 2	1 = Follower 2 is polled by the master.	
	b2 Follower 3	1 = Follower 3 is polled by the master.	

# 476 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
b3	Follower 4	1 = Follower 4 is polled by the master.	
b4	Follower 5	1 = Follower 5 is polled by the master.	
b5	Follower 6	1 = Follower 6 is polled by the master.	
b6	Follower 7	1 = Follower 7 is polled by the master.	
b7	Follower 8	1 = Follower 8 is polled by the master.	
b8	Follower 9	1 = Follower 9 is polled by the master.	
b9	Follower 10	1 = Follower 10 is polled by the master.	
b10	Follower 11	1 = Follower 11 is polled by the master.	
b11	Follower 12	1 = Follower 12 is polled by the master.	
b12	Follower 13	1 = Follower 13 is polled by the master.	
b13	Follower 14	1 = Follower 14 is polled by the master.	
b14	Follower 15	1 = Follower 15 is polled by the master.	
b15	Follower 16	1 = Follower 16 is polled by the master.	
	0000h...FFFFh		1 = 1 / 1 = 1
60.20	M/F comm supervision sel 2	Selects which followers (out of followers 17...32) are monitored for loss of communication. See parameter <a href="#">60.19 M/F comm supervision sel 1</a> .	- / uint16
b0	Follower 17	1 = Follower 17 is polled by the master.	
b1	Follower 18	1 = Follower 18 is polled by the master.	
b2	Follower 19	1 = Follower 19 is polled by the master.	
b3	Follower 20	1 = Follower 20 is polled by the master.	
b4	Follower 21	1 = Follower 21 is polled by the master.	
b5	Follower 22	1 = Follower 22 is polled by the master.	
b6	Follower 23	1 = Follower 23 is polled by the master.	
b7	Follower 24	1 = Follower 24 is polled by the master.	
b8	Follower 25	1 = Follower 25 is polled by the master.	
b9	Follower 26	1 = Follower 26 is polled by the master.	
b10	Follower 27	1 = Follower 27 is polled by the master.	
b11	Follower 28	1 = Follower 28 is polled by the master.	
b12	Follower 29	1 = Follower 29 is polled by the master.	
b13	Follower 30	1 = Follower 30 is polled by the master.	
b14	Follower 31	1 = Follower 31 is polled by the master.	
b15	Follower 32	1 = Follower 32 is polled by the master.	
	0000h...FFFFh		1 = 1 / 1 = 1

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
60.23	M/F status supervision sel 1	<p>(This parameter is only effective when the drive is the master on a D2D link. See parameters <a href="#">60.1 M/F communication port</a> and <a href="#">60.3 M/F mode</a>.)</p> <p>In the master, parameters <a href="#">60.23 M/F status supervision sel 1</a> and <a href="#">60.24 M/F status supervision sel 2</a> specify the followers whose status word is monitored by the master.</p> <p>This parameter selects the followers (out of followers 1...16) whose status words are monitored by the master.</p> <p>If a follower reports a fault (bit 3 of the status word is on), the action specified in <a href="#">60.17 Follower fault action</a> is taken. Bits 0 and 1 of the status word (ready states) are handled as defined by <a href="#">60.18 Follower enable</a>.</p> <p>Using <a href="#">60.27 M/F status supv mode sel 1</a> and <a href="#">60.28 M/F status supv mode sel 2</a>, it is possible to define whether any given follower is only monitored when it is stopped.</p> <p><b>Note:</b> Also activate communication supervision for the same followers in parameter <a href="#">60.19 M/F comm supervision sel 1</a>.</p> <p>The status of communication is shown by <a href="#">62.37 M/F communication status 1</a> and <a href="#">62.38 M/F communication status 2</a>.</p>	- / uint16
b0	Follower 1	Status of follower 1 is monitored.	
b1	Follower 2	Status of follower 2 is monitored.	
b2	Follower 3	Status of follower 3 is monitored.	
b3	Follower 4	Status of follower 4 is monitored.	
b4	Follower 5	Status of follower 5 is monitored.	
b5	Follower 6	Status of follower 6 is monitored.	
b6	Follower 7	Status of follower 7 is monitored.	
b7	Follower 8	Status of follower 8 is monitored.	
b8	Follower 9	Status of follower 9 is monitored.	
b9	Follower 10	Status of follower 10 is monitored.	
b10	Follower 11	Status of follower 11 is monitored.	
b11	Follower 12	Status of follower 12 is monitored.	
b12	Follower 13	Status of follower 13 is monitored.	
b13	Follower 14	Status of follower 14 is monitored.	
b14	Follower 15	Status of follower 15 is monitored.	
b15	Follower 16	Status of follower 16 is monitored.	
	0000h...FFFFh		1 = 1 / 1 = 1

## 478 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
60.24	M/F status supervision sel 2	<p>Selects the followers (out of followers 17...32) whose status words are monitored by the D2D master.</p> <p><b>Note:</b> Also activate communication supervision for the same followers in parameter <a href="#">60.20 M/F comm supervision sel 2</a>.</p> <p>See parameter <a href="#">60.23 M/F status supervision sel 1</a>.</p>	- / uint16
b0	Follower 17	1 = Status of follower 17 is monitored.	
b1	Follower 18	1 = Status of follower 18 is monitored.	
b2	Follower 19	1 = Status of follower 19 is monitored.	
b3	Follower 20	1 = Status of follower 20 is monitored.	
b4	Follower 21	1 = Status of follower 21 is monitored.	
b5	Follower 22	1 = Status of follower 22 is monitored.	
b6	Follower 23	1 = Status of follower 23 is monitored.	
b7	Follower 24	1 = Status of follower 24 is monitored.	
b8	Follower 25	1 = Status of follower 25 is monitored.	
b9	Follower 26	1 = Status of follower 26 is monitored.	
b10	Follower 27	1 = Status of follower 27 is monitored.	
b11	Follower 28	1 = Status of follower 28 is monitored.	
b12	Follower 29	1 = Status of follower 29 is monitored.	
b13	Follower 30	1 = Status of follower 30 is monitored.	
b14	Follower 31	1 = Status of follower 31 is monitored.	
b15	Follower 32	1 = Status of follower 32 is monitored.	
	0000h...FFFh		1 = 1 / 1 = 1
60.27	M/F status superv mode sel 1	<p>In the D2D master, parameters <a href="#">60.27 M/F status superv mode sel 1</a> and <a href="#">60.28 M/F status superv mode sel 2</a> specify the mode of follower status word monitoring. Each follower can individually be set to be monitored continuously, or only when it is in stopped state.</p> <p>This parameter selects the mode of status word monitoring of followers 1...16.</p>	- / uint16
b0	Follower 1	<p>0 = Status of follower 1 is monitored continuously.</p> <p>1 = Status of follower 1 is monitored only when it is in stopped state.</p>	
b1	Follower 2	<p>0 = Status of follower 2 is monitored continuously.</p> <p>1 = Status of follower 2 is monitored only when it is in stopped state.</p>	
b2	Follower 3	<p>0 = Status of follower 3 is monitored continuously.</p> <p>1 = Status of follower 3 is monitored only when it is in stopped state.</p>	

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
b3	Follower 4	0 = Status of follower 4 is monitored continuously. 1 = Status of follower 4 is monitored only when it is in stopped state.	
b4	Follower 5	0 = Status of follower 5 is monitored continuously. 1 = Status of follower 5 is monitored only when it is in stopped state.	
b5	Follower 6	0 = Status of follower 6 is monitored continuously. 1 = Status of follower 6 is monitored only when it is in stopped state.	
b6	Follower 7	0 = Status of follower 7 is monitored continuously. 1 = Status of follower 7 is monitored only when it is in stopped state.	
b7	Follower 8	0 = Status of follower 8 is monitored continuously. 1 = Status of follower 8 is monitored only when it is in stopped state.	
b8	Follower 9	0 = Status of follower 9 is monitored continuously. 1 = Status of follower 9 is monitored only when it is in stopped state.	
b9	Follower 10	0 = Status of follower 10 is monitored continuously. 1 = Status of follower 10 is monitored only when it is in stopped state.	
b10	Follower 11	0 = Status of follower 11 is monitored continuously. 1 = Status of follower 11 is monitored only when it is in stopped state.	
b11	Follower 12	0 = Status of follower 12 is monitored continuously. 1 = Status of follower 12 is monitored only when it is in stopped state.	
b12	Follower 13	0 = Status of follower 13 is monitored continuously. 1 = Status of follower 13 is monitored only when it is in stopped state.	
b13	Follower 14	0 = Status of follower 14 is monitored continuously. 1 = Status of follower 14 is monitored only when it is in stopped state.	
b14	Follower 15	0 = Status of follower 15 is monitored continuously. 1 = Status of follower 15 is monitored only when it is in stopped state.	
b15	Follower 16	0 = Status of follower 16 is monitored continuously. 1 = Status of follower 16 is monitored only when it is in stopped state.	
	0000h...FFFFh		1 = 1 / 1 = 1
60.28	M/F status supv mode sel 2	Selects the mode of status word monitoring of followers 17...32.	- / uint16

## 480 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
b0	Follower 17	0 = Status of follower 17 is monitored continuously. 1 = Status of follower 17 is monitored only when it is in stopped state.	
b1	Follower 18	0 = Status of follower 18 is monitored continuously. 1 = Status of follower 18 is monitored only when it is in stopped state.	
b2	Follower 19	0 = Status of follower 19 is monitored continuously. 1 = Status of follower 19 is monitored only when it is in stopped state.	
b3	Follower 20	0 = Status of follower 20 is monitored continuously. 1 = Status of follower 20 is monitored only when it is in stopped state.	
b4	Follower 21	0 = Status of follower 21 is monitored continuously. 1 = Status of follower 21 is monitored only when it is in stopped state.	
b5	Follower 22	0 = Status of follower 22 is monitored continuously. 1 = Status of follower 22 is monitored only when it is in stopped state.	
b6	Follower 23	0 = Status of follower 23 is monitored continuously. 1 = Status of follower 23 is monitored only when it is in stopped state.	
b7	Follower 24	0 = Status of follower 24 is monitored continuously. 1 = Status of follower 24 is monitored only when it is in stopped state.	
b8	Follower 25	0 = Status of follower 25 is monitored continuously. 1 = Status of follower 25 is monitored only when it is in stopped state.	
b9	Follower 26	0 = Status of follower 26 is monitored continuously. 1 = Status of follower 26 is monitored only when it is in stopped state.	
b10	Follower 27	0 = Status of follower 27 is monitored continuously. 1 = Status of follower 27 is monitored only when it is in stopped state.	
b11	Follower 28	0 = Status of follower 28 is monitored continuously. 1 = Status of follower 28 is monitored only when it is in stopped state.	
b12	Follower 29	0 = Status of follower 29 is monitored continuously. 1 = Status of follower 29 is monitored only when it is in stopped state.	
b13	Follower 30	0 = Status of follower 30 is monitored continuously. 1 = Status of follower 30 is monitored only when it is in stopped state.	






No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
b14	Follower 31	0 = Status of follower 31 is monitored continuously. 1 = Status of follower 31 is monitored only when it is in stopped state.	
b15	Follower 32	0 = Status of follower 32 is monitored continuously. 1 = Status of follower 32 is monitored only when it is in stopped state.	
	0000h...FFFFh		1 = 1 / 1 = 1
60.31	M/F wake up delay	Defines a wake-up delay during which no master/follower communication faults or warnings are generated. This is to allow all drives on the master/follower link to power up.  The master cannot be started until the delay elapses or all monitored followers are found to be ready.	60.0 s / uint16
	0.0 ... 180.0 s	Master/follower wake-up delay.	10 = 1 s / 10 = 1 s
60.32	M/F comm supervision force	Activates master/follower communication monitoring separately for each control location (see section <a href="#">Local control vs. external control (page 23)</a> ).  The parameter is primarily intended for monitoring the communication with master or follower when it is connected to the application program and not selected as a control source by drive parameters.	- / uint16
b0	Ext 1	1 = Communication monitoring active when Ext 1 is being used.	
b1	Ext 2	1 = Communication monitoring active when Ext 2 is being used.	
b2	Local	1 = Communication monitoring active when local control is being used.	
b3...15	Reserved		
	0000h...FFFFh		1 = 1 / 1 = 1
60.41	Extension adapter com port	Selects the channel used for connecting an optional FEA-xx extension adapter.	Not in use / uint16
	Not in use	None (communication disabled).	0
	Slot 1A	Channel A on FDCO module in slot 1.	1
	Slot 2A	Channel A on FDCO module in slot 2.	2
	Slot 3A	Channel A on FDCO module in slot 3.	3
	Slot 1B	Channel B on FDCO module in slot 1.	4
	Slot 2B	Channel B on FDCO module in slot 2.	5
	Slot 3B	Channel B on FDCO module in slot 3.	6
	RDCO CH 3	Channel CH 3 on RDCO module (with BCU control unit only).	13

## 482 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
60.50	DDCS controller drive type	In ModuleBus communication, defines whether the drive is of the "engineered" or "standard" type.  <b>Note:</b> This parameter cannot be changed while the drive is running.	ABB engineered drive / uint16
	ABB engineered drive	The drive is an "engineered drive" (data sets 10...25 are used).	0
	ABB standard drive	The drive is a "standard drive" (data sets 1...4 are used).	1
60.51	DDCS controller comm port	Selects the DDCS channel used for connecting an external controller (such as an AC 800M).	Not in use / uint16
	Not in use	None (communication disabled).	0
	Slot 1A	Channel A on FDCO module in slot 1.	1
	Slot 2A	Channel A on FDCO module in slot 2.	2
	Slot 3A	Channel A on FDCO module in slot 3.	3
	Slot 1B	Channel B on FDCO module in slot 1.	4
	Slot 2B	Channel B on FDCO module in slot 2.	5
	Slot 3B	Channel B on FDCO module in slot 3.	6
	RDCO CH 0	Channel 0 on RDCO module (with BCU control unit only).	10
	XD2D	Connector XD2D.	7
60.52	DDCS controller node address	Selects the node address of the drive for communication with the external controller. No two nodes on-line may have the same address.  With an AC 800M (CI858) DriveBus connection, drives must be addressed 1...24; with an AC 80 DriveBus connection, drives must be addressed 1...12. Note that the BusManager function must be disabled in the DriveBus controller.  With optical ModuleBus, the drive address is set according to the position value as follows: 1. Multiply the hundreds of the position value by 16. 2. Add the tens and ones of the position value to the result.  For example, if the position value is 101, this parameter must be set to $1 \times 16 + 1 = 17$ .	1 / uint16
	1...254	Node address.	- / -
60.55	DDCS controller HW connection	Selects the topology of the fiber optic link with an external controller.	Star / uint16
	Ring	The devices are connected in a ring topology. Forwarding of messages is enabled.	0
	Star	The devices are connected in a star topology (for example, through a branching unit). Forwarding of messages is disabled.	1

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
60.56	DDCS controller baud rate	Selects the communication speed of the channel selected by parameter <a href="#">60.51 DDCS controller comm port</a> .	4 mbps / uint16
	1 mbps	1 megabit/second.	1
	2 mbps	2 megabit/second.	2
	4 mbps	4 megabit/second.	4
	8 mbps	8 megabit/second.	8
60.57	DDCS controller link control	Defines the light intensity of the transmission LED of RDCO module channel CH0. (This parameter is effective only when parameter <a href="#">60.51 DDCS controller comm port</a> is set to <a href="#">RDCO CH 0</a> . FDCO modules have a hardware transmitter current selector.)  In general, use higher values with longer fiber optic cables.  The maximum setting is applicable to the maximum length of the fiber optic link. See <a href="#">Master/follower functionality (page 34)</a> .	10 / uint16
	1...15	Light intensity.	- / -
60.58	DDCS controller comm loss time	Sets a timeout for communication with the external controller.  If a communication break lasts longer than the timeout, the action specified by parameter <a href="#">60.59 DDCS controller comm loss function</a> is taken.  As a rule of thumb, this parameter should be set to at least 3 times the transmit interval of the controller.  <b>Note:</b> <ul style="list-style-type: none"> <li>There is a 60-second boot-up delay immediately after power-up. During the delay, the communication break monitoring is disabled (but communication itself can be active).</li> <li>With an AC 800M controller, the controller detects a communication break immediately but re-establishing the communication is done at 9-second idle intervals. Also note that the sending interval of a data set is not the same as the execution interval of the application task. On ModuleBus, the sending interval is defined by controller parameter Scan Cycle Time (by default, 100 ms).</li> </ul>	100 ms / uint16
	0...60000 ms	Timeout for communication with external controller.	- / -
60.59	DDCS controller comm loss function	Selects how the drive reacts to a communication break between the drive and the external controller.	Fault / uint16
	No action	No action taken (monitoring disabled).	0
	Fault	Drive trips on <a href="#">7581 DDCS controller comm loss</a> . This only occurs if control is expected from the external controller, or if supervision is forced using parameter <a href="#">60.65 DDCS controller comm supervision force</a> .	1


## 484 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	Last speed	<p>Drive generates an <a href="#">A7CA DDCS controller comm loss</a> warning and freezes the speed to the level the drive was operating at. This only occurs if control is expected from the external controller, or if supervision is forced using parameter <a href="#">60.65 DDCS controller comm supervision force</a>.</p> <p>The speed is determined on the basis of actual speed using 850 ms low-pass filtering.</p> <p> <b>WARNING!</b> Make sure that it is safe to continue operation in case of a communication break.</p>	2
	Speed ref safe	<p>Drive generates an <a href="#">A7CA DDCS controller comm loss</a> warning and sets the speed to the speed defined by parameter <a href="#">22.41 Speed ref safe</a> (or <a href="#">28.41 Frequency ref safe</a> when frequency reference is being used). This only occurs if control is expected from the external controller, or if supervision is forced using parameter <a href="#">60.65 DDCS controller comm supervision force</a>.</p> <p> <b>WARNING!</b> Make sure that it is safe to continue operation in case of a communication break.</p>	3
	Fault always	<p>Drive trips on <a href="#">7581 DDCS controller comm loss</a>. This occurs even though no control is expected from the external controller.</p>	4
	Warning	<p>Drive generates an <a href="#">A7CA DDCS controller comm loss</a> warning. This only occurs if control is expected from the external controller, or if supervision is forced using parameter <a href="#">60.65 DDCS controller comm supervision force</a>.</p> <p> <b>WARNING!</b> Make sure that it is safe to continue operation in case of a communication break.</p>	5
60.60	DDCS controller ref1 type	<p>Selects the type and scaling of reference 1 received from the external controller. The resulting value is shown by <a href="#">3.11 DDCS controller ref 1</a>.</p>	Auto / uint16
	Auto	<p>Type and scaling are chosen automatically according to which reference chain (see settings <a href="#">Torque</a>, <a href="#">Speed</a>, <a href="#">Frequency</a>) the incoming reference is connected to. If the reference is not connected to any chain, no scaling is applied (as with setting Transparent).</p>	0
	Transparent	<p>No scaling is applied.</p>	1
	General	<p>Generic reference with a scaling of 100 = 1 (ie. integer and two decimals).</p>	2
	Torque	<p>The scaling is defined by parameter <a href="#">46.3 Torque scaling</a>.</p>	3
	Speed	<p>The scaling is defined by parameter <a href="#">46.1 Speed scaling</a>.</p>	4

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	Frequency	The scaling is defined by parameter <a href="#">46.2 Frequency scaling</a> .	5
60.61	DDCS controller ref2 type	Selects the type and scaling of reference 2 received from the external controller. The resulting value is shown by <a href="#">3.12 DDCS controller ref 2</a> .  For the selections, see parameter <a href="#">60.60 DDCS controller ref1 type</a> .	Auto / uint16
60.62	DDCS controller act1 type	Selects the type/source and scaling of actual value ACT1 transmitted to the external controller.	Auto / uint16
	Auto	Type/source and scaling follow the type of reference 1 selected by parameter <a href="#">60.60 DDCS controller ref1 type</a> . See the individual settings below for the sources and scalings.	0
	Transparent	Reserved.	1
	General	Reserved.	2
	Torque	<a href="#">1.10 Motor torque</a> is sent as actual value 1. The scaling is defined by parameter <a href="#">46.3 Torque scaling</a> .	3
	Speed	<a href="#">1.1 Motor speed used</a> is sent as actual value 1. The scaling is defined by parameter <a href="#">46.1 Speed scaling</a> .	4
	Frequency	<a href="#">1.6 Output frequency</a> is sent as actual value 1. The scaling is defined by parameter <a href="#">46.2 Frequency scaling</a> .	5
60.63	DDCS controller act2 type	Selects the type/source and scaling of actual value ACT2 transmitted to the external controller.	Auto / uint16
	Auto	Type/source and scaling follow the type of reference 2 selected by parameter <a href="#">60.61 DDCS controller ref2 type</a> . See the individual settings below for the sources and scalings.	0
	Transparent	Reserved.	1
	General	Reserved.	2
	Torque	<a href="#">1.10 Motor torque</a> is sent as actual value 2. The scaling is defined by parameter <a href="#">46.3 Torque scaling</a> .	3
	Speed	<a href="#">1.1 Motor speed used</a> is sent as actual value 2. The scaling is defined by parameter <a href="#">46.1 Speed scaling</a> .	4
	Frequency	<a href="#">1.6 Output frequency</a> is sent as actual value 2. The scaling is defined by parameter <a href="#">46.2 Frequency scaling</a> .	5
60.64	Mailbox dataset selection	Selects the pair of data sets used by the mailbox service in the drive/controller communication.  See section <a href="#">External controller interface (page 42)</a> .	0 / uint16
	0...1	Data sets 32 and 33.	- / -

## 486 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
60.65	DDCS controller comm supervision force	Activates DDCS controller communication monitoring separately for each control location (see section <a href="#">Local control vs. external control (page 23)</a> .  The parameter is primarily intended for monitoring the communication with the controller when it is connected to the application program and not selected as a control source by drive parameters.	- / uint16
b0	Ext 1	1 = Communication monitoring active when Ext 1 is being used.	
b1	Ext 2	1 = Communication monitoring active when Ext 2 is being used.	
b2	Local	1 = Communication monitoring active when local control is being used.	
b3...15	Reserved		
	0000h...FFFFh		1 = 1 / 1 = 1
60.71	INU-LSU communication port	<i>(Only visible when supply unit control activated by 95.20)</i>  Selects the DDCS channel used for connecting to another converter (such as a supply unit).  The selections available, as well as the default, depend on drive hardware.  See also section <a href="#">Control of a supply unit (LSU) (page 44)</a> .	Not in use / uint16
	Not in use	None (communication disabled).	0
	RDCO CH 1	Channel 1 on RDCO module.	11
	DDCS via BC	Connector X201.	15
60.77	INU-LSU link control	<i>(Only visible when supply unit control activated by 95.20)</i>  Defines the light intensity of the transmission LED of RDCO module channel CH1. (This parameter is effective only when parameter <a href="#">60.71 INU-LSU communication port</a> is set to <a href="#">RDCO CH 1</a> . FDCO modules have a hardware transmitter current selector.)  In general, use higher values with longer fiber optic cables.  The maximum setting is applicable to the maximum length of the fiber optic link. See <a href="#">Master/follower functionality</a> .	10 / uint16
	1...15	Light intensity.	- / -
60.78	INU-LSU comm loss timeout	<i>(Only visible when supply unit control activated by 95.20)</i>  Sets a timeout for communication with another converter (such as the supply unit). If a communication break lasts longer than the timeout, the action specified by parameter <a href="#">60.79 INU-LSU comm loss function</a> is taken.	100 ms / uint16

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	0 ms	Timeout for communication between converters.	- / -
60.79	INU-LSU comm loss function	<p data-bbox="389 236 837 277"><i>(Only visible when supply unit control activated by 95.20)</i></p> <p data-bbox="389 290 855 357">Selects how the inverter unit reacts to a communication break between the inverter unit and the other converter (typically the supply unit).</p> <p data-bbox="389 379 871 488">  <b>WARNING!</b>            With settings other than <b>Fault</b>, the inverter unit will continue operating based on the status information that was last received from the other converter. Make sure this does not cause danger.         </p>	Fault / uint16
	No action	No action taken.	0
	Warning	The drive generates a warning (AF80 INU-LSU comm loss).	1
	Fault	Drive trips on 7580 INU-LSU comm loss.	2

## 488 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
61	D2D and DDCS transmit data	Defines the data sent to the DDCS link. See also parameter group <a href="#">60 DDCS communication</a> .	
61.1	M/F data 1 selection	Preselects the data to be sent as word 1 onto the master/follower link. See also parameter <a href="#">61.25 M/F data 1 value</a> , and section <a href="#">Master/follower functionality (page 34)</a> .	Follower CW / uint32
	None	None.	0
	CW 16bit	Control Word (16 bits)	1
	SW 16bit	Status Word (16 bits)	4
	Act1 16bit	Actual value ACT1 (16 bits)  <b>Note:</b> Using this setting to send a reference to the follower is not recommended as the source signal is filtered. Use the “reference” selections instead.	5
	Act2 16bit	Actual value ACT2 (16 bits)  <b>Note:</b> Using this setting to send a reference to the follower is not recommended as the source signal is filtered. Use the “reference” selections instead.	6
	Follower CW	A word consisting of bits 0...11 of <a href="#">6.1 Main control word</a> and the bits selected by parameters <a href="#">06.45...06.48</a> .  <b>Note:</b> Bit 3 of the follower control word is kept on as long as the master is modulating, and when it switches to 0, the follower coasts to a stop.	27
	Used speed reference	<a href="#">24.1 Used speed reference (page 295)</a> .	6145
	Torque reference act 5	<a href="#">26.75 Torque reference act 5 (page 322)</a> .	6731
	Torque reference used	<a href="#">26.2 Torque reference used (page 314)</a> .	6658
	ACS800 System ctrl SW	A follower status word compatible with an ACS800 (System Control Program) master. With this setting, status word bit 0 is cleared whenever the run enable signal is missing.	28
	Follower CW B6 high	Otherwise identical to selection <a href="#">Follower CW</a> , but bit 6 of the follower control word is also kept on as long as the master is modulating. This will allow the follower to stop along the stop ramp of the master.	29
	D2D position	Virtual address for Control word for the follower units, bit 6 high as long as the drive modulates  <b>Note:</b> This setting cannot be used in <a href="#">61.03 M/F data 3 selection</a> because the 32-bit value requires two consecutive words.	809013



No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	D2D velocity	Scaled velocity value as displayed by 88.54 D2D velocity send.  <b>Note:</b> Occasionally, below data are also sent to the follower: <ul style="list-style-type: none"> <li>• 32768-Position initialization or position send type changed.</li> <li>• 32767-Latch 1 triggered in master.</li> </ul>	22582
	Other [bit]	Source selection (see <a href="#">Terms and abbreviations (page 134)</a> ).	-
61.2	M/F data 2 selection	Preselects the data to be sent as word 2 onto the master/follower link.  See also parameter <a href="#">61.26 M/F data 2 value</a> .  For the selections, see parameter <a href="#">61.1 M/F data 1 selection</a> .  <b>Note:</b> If the parameters <a href="#">61.2</a> is set to the value other than <i>Used speed reference</i> and <a href="#">60.10</a> to <i>Auto</i> , the follower drive do not follow master drive.	Used speed reference / uint32
61.3	M/F data 3 selection	Preselects the data to be sent as word 3 onto the master/follower link.  See also parameter <a href="#">61.27 M/F data 3 value</a> .  For the selections, see parameter <a href="#">61.1 M/F data 1 selection</a> .	Torque reference act 5 / uint32
61.25	M/F data 1 value	Displays the data to be sent onto the master/follower link as word 1 as an integer.  If no data has been preselected by <a href="#">61.1 M/F data 1 selection</a> , the value to be sent can be written directly into this parameter.	- / uint16
	0...65535	Data to be sent as word 1 in master/follower communication.	- / -
61.26	M/F data 2 value	Displays the data to be sent onto the master/follower link as word 2 as an integer.  If no data has been preselected by <a href="#">61.2 M/F data 2 selection</a> , the value to be sent can be written directly into this parameter.	- / uint16
	0...65535	Data to be sent as word 2 in master/follower communication.	- / -
61.27	M/F data 3 value	Displays the data to be sent onto the master/follower link as word 3 as an integer.  If no data has been preselected by <a href="#">61.3 M/F data 3 selection</a> , the value to be sent can be written directly into this parameter.	- / uint16
	0...65535	Data to be sent as word 3 in master/follower communication.	- / -

490 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
61.45	Data set 2 data 1 selection	Parameters 61.45...61.50 preselect data to be sent in data sets 2 and 4 to the external controller. These data sets are used in ModuleBus communication with a "standard drive" (60.50 DDCS controller drive type = ABB standard drive). Parameters 61.95...61.100 display the data to be sent to the external controller. If no data has been preselected, the value to be sent can be written directly into these parameters. For example, this parameter preselects the data for word 1 of data set 2. Parameter 61.95 Data set 2 data 1 value displays the selected data in integer format. If no data is preselected, the value to be sent can be written directly into parameter 61.95.	None / uint32
	None	None.	0
	CW 16bit	Control Word (16 bits)	1
	SW 16bit	Status Word (16 bits)	4
	Act1 16bit	Actual value ACT1 (16 bits)	5
	Act2 16bit	Actual value ACT2 (16 bits)	6
	Other [bit]	Source selection (see Terms and abbreviations (page 134)).	-
61.46	Data set 2 data 2 selection	Preselects the data to be sent as word 2 of data set 2 to the external controller. See also parameter 61.96 Data set 2 data 2 value. For the selections, see parameter 61.45 Data set 2 data 1 selection.	None / uint32
61.47	Data set 2 data 3 selection	See parameter 61.45 Data set 2 data 1 selection.	None / uint32
...	...	...	...
61.50	Data set 4 data 3 selection	See parameter 61.45 Data set 2 data 1 selection.	None / uint32
61.51	Data set 11 data 1 selection	Parameters 61.51...61.74 preselect data to be sent in data sets 11, 13, 15, 17, 19, 21, 23 and 25 to the external controller. Parameters 61.101...61.124 display the data to be sent to the external controller. If no data has been preselected, the value to be sent can be written directly into these parameters. For example, this parameter preselects the data for word 1 of data set 11. Parameter 61.101 Data set 11 data 1 value displays the selected data in integer format. If no data is preselected, the value to be sent can be written directly into parameter 61.101.	None / uint32
	None	None.	0
	CW 16bit	Control Word (16 bits)	1
	SW 16bit	Status Word (16 bits)	4
	Act1 16bit	Actual value ACT1 (16 bits)	5

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	Act2 16bit	Actual value ACT2 (16 bits)	6
	Other [bit]	Source selection (see <a href="#">Terms and abbreviations (page 134)</a> ).	-
61.52	Data set 11 data 2 selection	Preselects the data to be sent as word 2 of data set 11 to the external controller.  See also parameter <a href="#">61.102 Data set 11 data 2 value</a> .  For the selections, see parameter <a href="#">61.51 Data set 11 data 1 selection</a> .	None / uint32
61.53	Data set 11 data 3 selection	Preselects the data to be sent as word 3 of data set 11 to the external controller.  See also parameter <a href="#">61.103 Data set 11 data 3 value</a> .  For the selections, see parameter <a href="#">61.51 Data set 11 data 1 selection</a> .	None / uint32
61.54	Data set 13 data 1 selection	See parameter <a href="#">61.51 Data set 11 data 1 selection</a> .	None / uint32
...	...	...	...
61.74	Data set 25 data 3 selection	See parameter <a href="#">61.51 Data set 11 data 1 selection</a> .	None / uint32
61.95	Data set 2 data 1 value	Displays (in integer format) the data to be sent to the external controller as word 1 of data set 2.  If no data has been preselected by <a href="#">61.45 Data set 2 data 1 selection</a> , the value to be sent can be written directly into this parameter.	0 / uint16
	0...65535	Data to be sent as word 1 of data set 2.	- / -
61.96	Data set 2 data 2 value	Displays (in integer format) the data to be sent to the external controller as word 2 of data set 2.  If no data has been preselected by <a href="#">61.46 Data set 2 data 2 selection</a> , the value to be sent can be written directly into this parameter.	0 / uint16
	0...65535	Data to be sent as word 2 of data set 2.	- / -
61.97	Data set 2 data 3 value	Displays (in integer format) the data to be sent to the external controller as word 3 of data set 2.  If no data has been preselected by <a href="#">61.47 Data set 2 data 3 selection</a> , the value to be sent can be written directly into this parameter.	0 / uint16
	0...65535	Data to be sent as word 3 of data set 2.	- / -
...	...	...	...
61.100	Data set 4 data 3 value	Displays (in integer format) the data to be sent to the external controller as word 3 of data set 4.  If no data has been selected by <a href="#">61.50 Data set 4 data 3 selection</a> , the value to be sent can be written directly into this parameter.	0 / uint16
	0...65535	Data to be sent as word 3 of data set 4.	- / -

## 492 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
61.101	Data set 11 data 1 value	Displays (in integer format) the data to be sent to the external controller as word 1 of data set 11.  If no data has been preselected by <a href="#">61.51 Data set 11 data 1 selection</a> , the value to be sent can be written directly into this parameter.	- / uint16
	0...65535	Data to be sent as word 1 of data set 11.	- / -
61.102	Data set 11 data 2 value	Displays (in integer format) the data to be sent to the external controller as word 2 of data set 11.  If no data has been preselected by <a href="#">61.52 Data set 11 data 2 selection</a> , the value to be sent can be written directly into this parameter.	- / uint16
	0...65535	Data to be sent as word 2 of data set 11.	- / -
61.103	Data set 11 data 3 value	Displays (in integer format) the data to be sent to the external controller as word 3 of data set 11.  If no data has been selected by <a href="#">61.53 Data set 11 data 3 selection</a> , the value to be sent can be written directly into this parameter.	- / uint16
	0...65535	Data to be sent as word 3 of data set 11.	- / -
61.104	Data set 13 data 1 value	Displays (in integer format) the data to be sent to the external controller as word 1 of data set 13.  If no data has been selected by <a href="#">61.54 Data set 13 data 1 selection</a> , the value to be sent can be written directly into this parameter.	- / uint16
	0...65535	Data to be sent as word 1 of data set 13.	- / -
...	...	...	...
61.124	Data set 25 data 3 value	Displays (in integer format) the data to be sent to the external controller as word 3 of data set 25.  If no data has been selected by <a href="#">61.74 Data set 25 data 3 selection</a> , the value to be sent can be written directly into this parameter.	- / uint16
	0...65535	Data to be sent as word 3 of data set 25.	- / -
61.151	INU-LSU data set 10 data 1 sel	(Parameters <a href="#">61.151...61.203</a> only visible when supply unit control activated by <a href="#">95.20</a> )  Parameters <a href="#">61.151...61.153</a> preselect data to be sent in data set 10 to another converter (typically the supply unit of the drive).  Parameters <a href="#">61.201...61.203</a> display the data to be sent to the other converter. If no data has been preselected, the value to be sent can be written directly into these parameters.  For example, this parameter preselects the data for word 1 of data set 10. Parameter <a href="#">61.201 INU-LSU data set 10 data 1 value</a> displays the selected data in integer format. If no data is preselected, the value to be sent can be written directly into parameter <a href="#">61.201</a> .	LSU CW / uint32
	None	None.	0

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	LSU CW	Control word for the supply unit.	22
	DC voltage reference	<a href="#">94.20 DC voltage reference (page 530)</a> .	24084
	Reactive power reference	<a href="#">94.30 Reactive power reference (page 531)</a> .	24094
	Other [bit]	Source selection (see <a href="#">Terms and abbreviations (page 134)</a> ).	-
61.152	INU-LSU data set 10 data 2 sel	Preselects the data to be sent as word 2 of data set 10 to the other converter.  See also parameter <a href="#">61.202 INU-LSU data set 10 data 2 value</a> .  For the selections, see parameter <a href="#">61.151 INU-LSU data set 10 data 1 sel</a> .	DC voltage reference / uint32
61.153	INU-LSU data set 10 data 3 sel	Preselects the data to be sent as word 3 of data set 10 to the other converter.  See also parameter <a href="#">61.203 INU-LSU data set 10 data 3 value</a> .  For the selections, see parameter <a href="#">61.151 INU-LSU data set 10 data 1 sel</a> .	Reactive power reference / uint32
61.201	INU-LSU data set 10 data 1 value	Displays (in integer format) the data to be sent to the other converter as word 1 of data set 10.  If no data has been preselected by <a href="#">61.151 INU-LSU data set 10 data 1 sel</a> , the value to be sent can be written directly into this parameter.	- / uint16
	0...65535	Data to be sent as word 1 of data set 10.	- / -
61.202	INU-LSU data set 10 data 2 value	Displays (in integer format) the data to be sent to the other converter as word 2 of data set 10.  If no data has been preselected by <a href="#">61.152 INU-LSU data set 10 data 2 sel</a> , the value to be sent can be written directly into this parameter.	- / uint16
	0...65535	Data to be sent as word 2 of data set 10.	- / -
61.203	INU-LSU data set 10 data 3 value	Displays (in integer format) the data to be sent to the other converter as word 3 of data set 10.  If no data has been selected by <a href="#">61.153 INU-LSU data set 10 data 3 sel</a> , the value to be sent can be written directly into this parameter.	- / uint16
	0...65535	Data to be sent as word 3 of data set 10.	- / -

## 494 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
62	D2D and DDCS receive data	Mapping of data received through the DDCS link. See also parameter group <a href="#">60 DDCS communication</a> .	
62.1	M/F data 1 selection	(Follower only) Defines a target for the data received as word 1 from the master through the master/follower link. See also parameter <a href="#">62.25 M/F data 1 value</a> .	None / uint32
	None	None.	0
	CW 16bit	Control Word (16 bits)	1
	Ref1 16bit	Reference REF1 (16 bits)	2
	Ref2 16bit	Reference REF2 (16 bits)	3
	M/F velocity	Scaled velocity value.  <b>Note:</b> This selection should be chosen for the same data word as was set to D2D velocity in the master.	4
	M/F position	32-bit position value.  <b>Note:</b> This selection should be chosen for the same data word as was set to D2D position in the master. (The setting will automatically reserve two consecutive data words.)	30
	Other [bit]	Source selection (see <a href="#">Terms and abbreviations (page 134)</a> ).	-
62.2	M/F data 2 selection	(Follower only) Defines a target for the data received as word 2 from the master through the master/follower link. See also parameter <a href="#">62.26 M/F data 2 value</a> . For the selections, see parameter <a href="#">62.1 M/F data 1 selection</a> .	None / uint32
62.3	M/F data 3 selection	(Follower only) Defines a target for the data received as word 3 from the master through the master/follower link. See also parameter <a href="#">62.27 M/F data 3 value</a> . For the selections, see parameter <a href="#">62.1 M/F data 1 selection</a> .	None / uint32
62.4	Follower node 2 data 1 sel	Defines a target for the data received as word 1 from the first follower (ie. the follower with node address 2) through the master/follower link. See also parameter <a href="#">62.28 Follower node 2 data 1 value</a> .	Follower SW / uint32
	None	None.	0
	Follower SW	Status word of the follower. See also parameter <a href="#">60.18 Follower enable</a> .	26
	Other [bit]	Source selection (see <a href="#">Terms and abbreviations (page 134)</a> ).	-

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
62.5	Follower node 2 data 2 sel	<p>Defines a target for the data received as word 2 from the first follower (ie. the follower with node address 2) through the master/follower link.</p> <p>See also parameter <a href="#">62.29 Follower node 2 data 2 value</a>.</p> <p>For the selections, see parameter <a href="#">62.4 Follower node 2 data 1 sel</a>.</p>	None / uint32
62.6	Follower node 2 data 3 sel	<p>Defines a target for the data received as word 3 from the first follower (ie. the follower with node address 2) through the master/follower link.</p> <p>See also parameter <a href="#">62.30 Follower node 2 data 3 value</a>.</p> <p>For the selections, see parameter <a href="#">62.4 Follower node 2 data 1 sel</a>.</p>	None / uint32
62.7	Follower node 3 data 1 sel	<p>Defines a target for the data received as word 1 from the second follower (ie. the follower with node address 3) through the master/follower link.</p> <p>See also parameter <a href="#">62.31 Follower node 3 data 1 value</a>.</p> <p>For the selections, see parameter <a href="#">62.4 Follower node 2 data 1 sel</a>.</p>	Follower SW / uint32
62.8	Follower node 3 data 2 sel	<p>Defines a target for the data received as word 2 from the second follower (ie. the follower with node address 3) through the master/follower link.</p> <p>See also parameter <a href="#">62.32 Follower node 3 data 2 value</a>.</p> <p>For the selections, see parameter <a href="#">62.4 Follower node 2 data 1 sel</a>.</p>	None / uint32
62.9	Follower node 3 data 3 sel	<p>Defines a target for the data received as word 3 from the second follower (ie. the follower with node address 3) through the master/follower link.</p> <p>See also parameter <a href="#">62.33 Follower node 3 data 3 value</a>.</p> <p>For the selections, see parameter <a href="#">62.4 Follower node 2 data 1 sel</a>.</p>	None / uint32
62.10	Follower node 4 data 1 sel	<p>Defines a target for the data received as word 1 from the third follower (ie. the follower with node address 4) through the master/follower link.</p> <p>See also parameter <a href="#">62.34 Follower node 4 data 1 value</a>.</p> <p>For the selections, see parameter <a href="#">62.4 Follower node 2 data 1 sel</a>.</p>	Follower SW / uint32
62.11	Follower node 4 data 2 sel	<p>Defines a target for the data received as word 2 from the third follower (ie. the follower with node address 4) through the master/follower link.</p> <p>See also parameter <a href="#">62.35 Follower node 4 data 2 value</a>.</p> <p>For the selections, see parameter <a href="#">62.4 Follower node 2 data 1 sel</a>.</p>	None / uint32

## 496 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
62.12	Follower node 4 data 3 sel	<p>Defines a target for the data received as word 3 from the third follower (ie. the follower with node address 4) through the master/follower link.</p> <p>See also parameter <a href="#">62.36 Follower node 4 data 3 value</a>.</p> <p>For the selections, see parameter <a href="#">62.4 Follower node 2 data 1 sel</a>.</p>	None / uint32
62.25	M/F data 1 value	<p>(Follower only) Displays, in integer format, the data received from the master as word 1.</p> <p>Parameter <a href="#">62.1 M/F data 1 selection</a> can be used to select a target for the received data. This parameter can also be used as a signal source by other parameters.</p>	- / uint16
	0...65535	Data received as word 1 in master/follower communication.	- / -
62.26	M/F data 2 value	<p>(Follower only) Displays, in integer format, the data received from the master as word 2.</p> <p>Parameter <a href="#">62.2 M/F data 2 selection</a> can be used to select a target for the received data. This parameter can also be used as a signal source by other parameters.</p>	- / uint16
	0...65535	Data received as word 2 in master/follower communication.	- / -
62.27	M/F data 3 value	<p>(Follower only) Displays, in integer format, the data received from the master as word 3.</p> <p>Parameter <a href="#">62.3 M/F data 3 selection</a> can be used to select a target for the received data. This parameter can also be used as a signal source by other parameters.</p>	- / uint16
	0...65535	Data received as word 3 in master/follower communication.	- / -
62.28	Follower node 2 data 1 value	<p>Displays, in integer format, the data received from the first follower (ie. follower with node address 2) as word 1.</p> <p>Parameter <a href="#">62.4 Follower node 2 data 1 sel</a> can be used to select a target for the received data. This parameter can also be used as a signal source by other parameters.</p>	- / uint16
	0...65535	Data received as word 1 from follower with node address 2.	- / -
62.29	Follower node 2 data 2 value	<p>Displays, in integer format, the data received from the first follower (ie. follower with node address 2) as word 2.</p> <p>Parameter <a href="#">62.5 Follower node 2 data 2 sel</a> can be used to select a target for the received data. This parameter can also be used as a signal source by other parameters.</p>	- / uint16



No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	0...65535	Data received as word 2 from follower with node address 2.	- / -
62.30	Follower node 2 data 3 value	<p>Displays, in integer format, the data received from the first follower (ie. follower with node address 2) as word 3.</p> <p>Parameter <a href="#">62.6 Follower node 2 data 3 sel</a> can be used to select a target for the received data. This parameter can also be used as a signal source by other parameters.</p>	- / uint16
	0...65535	Data received as word 3 from follower with node address 2.	- / -
62.31	Follower node 3 data 1 value	<p>Displays, in integer format, the data received from the second follower (ie. follower with node address 3) as word 1.</p> <p>Parameter <a href="#">62.7 Follower node 3 data 1 sel</a> can be used to select a target for the received data. This parameter can also be used as a signal source by other parameters.</p>	- / uint16
	0...65535	Data received as word 1 from follower with node address 3.	- / -
62.32	Follower node 3 data 2 value	<p>Displays, in integer format, the data received from the second follower (ie. follower with node address 3) as word 2.</p> <p>Parameter <a href="#">62.8 Follower node 3 data 2 sel</a> can be used to select a target for the received data. This parameter can also be used as a signal source by other parameters.</p>	- / uint16
	0...65535	Data received as word 2 from follower with node address 3.	- / -
62.33	Follower node 3 data 3 value	<p>Displays, in integer format, the data received from the second follower (ie. follower with node address 3) as word 3.</p> <p>Parameter <a href="#">62.9 Follower node 3 data 3 sel</a> can be used to select a target for the received data. This parameter can also be used as a signal source by other parameters.</p>	- / uint16
	0...65535	Data received as word 3 from follower with node address 3.	- / -
62.34	Follower node 4 data 1 value	<p>Displays, in integer format, the data received from the third follower (ie. follower with node address 4) as word 1.</p> <p>Parameter <a href="#">62.10 Follower node 4 data 1 sel</a> can be used to select a target for the received data. This parameter can also be used as a signal source by other parameters.</p>	- / uint16
	0...65535	Data received as word 1 from follower with node address 4.	- / -

## 498 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
62.35	Follower node 4 data 2 value	Displays, in integer format, the data received from the third follower (ie. follower with node address 4) as word 2.  Parameter <a href="#">62.11 Follower node 4 data 2 sel</a> can be used to select a target for the received data. This parameter can also be used as a signal source by other parameters.	- / uint16
	0..65535	Data received as word 2 from follower with node address 4.	- / -
62.36	Follower node 4 data 3 value	Displays, in integer format, the data received from the third follower (ie. follower with node address 4) as word 3.  Parameter <a href="#">62.12 Follower node 4 data 3 sel</a> can be used to select a target for the received data. This parameter can also be used as a signal source by other parameters.	- / uint16
	0..65535	Data received as word 3 from follower with node address 4.	- / -
62.37	M/F communication status 1	In the master, displays the status of the communication with followers specified by parameter <a href="#">60.19 M/F comm supervision sel 1</a> .  In a follower, bit 0 indicates the status of the communication with the master.	- / uint16
	b0 Follower 1 / Foll	1 (in the master) = Communication with follower 1 OK. 1 (in a follower) = Communication with master OK.	
	b1 Follower 2	1 = Communication with follower 2 OK.	
	b2 Follower 3	1 = Communication with follower 3 OK.	
	b3 Follower 4	1 = Communication with follower 4 OK.	
	b4 Follower 5	1 = Communication with follower 5 OK.	
	b5 Follower 6	1 = Communication with follower 6 OK.	
	b6 Follower 7	1 = Communication with follower 7 OK.	
	b7 Follower 8	1 = Communication with follower 8 OK.	
	b8 Follower 9	1 = Communication with follower 9 OK.	
	b9 Follower 10	1 = Communication with follower 10 OK.	
	b10 Follower 11	1 = Communication with follower 11 OK.	
	b11 Follower 12	1 = Communication with follower 12 OK.	
	b12 Follower 13	1 = Communication with follower 13 OK.	
	b13 Follower 14	1 = Communication with follower 14 OK.	
	b14 Follower 15	1 = Communication with follower 15 OK.	
	b15 Follower 16	1 = Communication with follower 16 OK.	
	0000h...FFFFh		1 = 1 / 1 = 1

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
62.38	M/F communication status 2	In the master, displays the status of the communication with followers specified by parameter <a href="#">60.20 M/F comm supervision sel 2</a> .	- / uint16
b0	Follower 17	1 = Communication with follower 17 OK.	
b1	Follower 18	1 = Communication with follower 18 OK.	
b2	Follower 19	1 = Communication with follower 19 OK.	
b3	Follower 20	1 = Communication with follower 20 OK.	
b4	Follower 21	1 = Communication with follower 21 OK.	
b5	Follower 22	1 = Communication with follower 22 OK.	
b6	Follower 23	1 = Communication with follower 23 OK.	
b7	Follower 24	1 = Communication with follower 24 OK.	
b8	Follower 25	1 = Communication with follower 25 OK.	
b9	Follower 26	1 = Communication with follower 26 OK.	
b10	Follower 27	1 = Communication with follower 27 OK.	
b11	Follower 28	1 = Communication with follower 28 OK.	
b12	Follower 29	1 = Communication with follower 29 OK.	
b13	Follower 30	1 = Communication with follower 30 OK.	
b14	Follower 31	1 = Communication with follower 31 OK.	
b15	Follower 32	1 = Communication with follower 32 OK.	
	0000h...FFFFh		1 = 1 / 1 = 1
62.41	M/F follower ready status 1	In the master, displays the ready status of the communication with followers specified by parameter <a href="#">60.23 M/F status supervision sel 1</a> .	- / uint16
b0	Follower 1	1 = Follower 1 ready.	
b1	Follower 2	1 = Follower 2 ready.	
b2	Follower 3	1 = Follower 3 ready.	
b3	Follower 4	1 = Follower 4 ready.	
b4	Follower 5	1 = Follower 5 ready.	
b5	Follower 6	1 = Follower 6 ready.	
b6	Follower 7	1 = Follower 7 ready.	
b7	Follower 8	1 = Follower 8 ready.	
b8	Follower 9	1 = Follower 9 ready.	
b9	Follower 10	1 = Follower 10 ready.	
b10	Follower 11	1 = Follower 11 ready.	
b11	Follower 12	1 = Follower 12 ready.	
b12	Follower 13	1 = Follower 13 ready.	

## 500 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
b13	Follower 14	1 = Follower 14 ready.	
b14	Follower 15	1 = Follower 15 ready.	
b15	Follower 16	1 = Follower 16 ready.	
	0000h...FFFFh		1 = 1 / 1 = 1
62.42	M/F follower ready status 2	In the master, displays the ready status of the communication with followers specified by parameter <a href="#">60.24 M/F status supervision sel 2</a> .	- / uint16
b0	Follower 17	1 = Follower 17 ready.	
b1	Follower 18	1 = Follower 18 ready.	
b2	Follower 19	1 = Follower 19 ready.	
b3	Follower 20	1 = Follower 20 ready.	
b4	Follower 21	1 = Follower 21 ready.	
b5	Follower 22	1 = Follower 22 ready.	
b6	Follower 23	1 = Follower 23 ready.	
b7	Follower 24	1 = Follower 24 ready.	
b8	Follower 25	1 = Follower 25 ready.	
b9	Follower 26	1 = Follower 26 ready.	
b10	Follower 27	1 = Follower 27 ready.	
b11	Follower 28	1 = Follower 28 ready.	
b12	Follower 29	1 = Follower 29 ready.	
b13	Follower 30	1 = Follower 30 ready.	
b14	Follower 31	1 = Follower 31 ready.	
b15	Follower 32	1 = Follower 32 ready.	
	0000h...FFFFh		1 = 1 / 1 = 1
62.45	Data set 1 data 1 selection	<p>Parameters <a href="#">62.45...62.50</a> define a target for the data received in data sets 1 and 3 from the external controller. These data sets are used in ModuleBus communication with a "standard drive" (<a href="#">60.50 DDCS controller drive type = ABB standard drive</a>).</p> <p>Parameters <a href="#">62.95...62.100</a> display the data received from the external controller in integer format, and can be used as sources by other parameters.</p> <p>For example, this parameter selects a target for word 1 of data set 1. Parameter <a href="#">62.95 Data set 1 data 1 value</a> displays the received data in integer format, and can also be used as a source by other parameters.</p>	None / uint32
	None	None.	0
	CW 16bit	Control Word (16 bits)	1
	Ref1 16bit	Reference REF1 (16 bits)	2

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	Ref2 16bit	Reference REF2 (16 bits)	3
	Other [bit]	Source selection (see <a href="#">Terms and abbreviations (page 134)</a> ).	-
62.46	Data set 1 data 2 selection	Defines a target for the data received as word 2 of data set 1.  See also parameter <a href="#">62.96 Data set 1 data 2 value</a> .  For the selections, see parameter <a href="#">62.45 Data set 1 data 1 selection</a> .	None / uint32
62.47	Data set 1 data 3 selection	See parameter <a href="#">62.45 Data set 1 data 1 selection</a> .	None / uint32
...	...	...	...
62.50	Data set 3 data 3 selection	See parameter <a href="#">62.45 Data set 1 data 1 selection</a> .	None / uint32
62.51	Data set 10 data 1 selection	Parameters <a href="#">62.51...62.74</a> define a target for the data received in data sets 10, 12, 14, 16, 18, 20, 22 and 24 from the external controller.  Parameters <a href="#">62.101...62.124</a> display the data received from the external controller in integer format, and can be used as sources by other parameters.  For example, this parameter selects a target for word 1 of data set 10. Parameter <a href="#">62.101 Data set 10 data 1 value</a> displays the received data in integer format, and can also be used as a source by other parameters.	None / uint32
	None	None.	0
	CW 16bit	Control Word (16 bits)	1
	Ref1 16bit	Reference REF1 (16 bits)	2
	Ref2 16bit	Reference REF2 (16 bits)	3
	Other [bit]	Source selection (see <a href="#">Terms and abbreviations (page 134)</a> ).	-
62.52	Data set 10 data 2 selection	Defines a target for the data received as word 2 of data set 10.  See also parameter <a href="#">62.102 Data set 10 data 2 value</a> .  For the selections, see parameter <a href="#">62.51 Data set 10 data 1 selection</a> .	None / uint32
62.53	Data set 10 data 3 selection	Defines a target for the data received as word 3 of data set 10.  See also parameter <a href="#">62.103 Data set 10 data 3 value</a> .  For the selections, see parameter <a href="#">62.51 Data set 10 data 1 selection</a> .	None / uint32
62.54	Data set 12 data 1 selection	See parameter <a href="#">62.51 Data set 10 data 1 selection</a> .	None / uint32
...	...	...	...

## 502 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
62.74	Data set 24 data 3 selection	See parameter <a href="#">62.51 Data set 10 data 1 selection</a> .	None / uint32
62.95	Data set 1 data 1 value	Displays (in integer format) the data received from the external controller as word 1 of data set 1.  A target for this data can be selected by parameter <a href="#">62.45 Data set 1 data 1 selection</a> . The value can also be used as a source by another parameter.	0 / uint16
	0...65535	Data received as word 1 of data set 1.	- / -
62.96	Data set 1 data 2 value	Displays (in integer format) the data received from the external controller as word 2 of data set 1.  A target for this data can be selected by parameter <a href="#">62.46 Data set 1 data 2 selection</a> . The value can also be used as a source by another parameter.	0 / uint16
	0...65535	Data received as word 2 of data set 1.	- / -
62.97	Data set 1 data 3 value	Displays (in integer format) the data received from the external controller as word 3 of data set 1.  A target for this data can be selected by parameter <a href="#">62.47 Data set 1 data 3 selection</a> . The value can also be used as a source by another parameter.	0 / uint16
	0...65535	Data received as word 3 of data set 1.	- / -
...	...	...	...
62.100	Data set 3 data 3 value	Displays (in integer format) the data received from the external controller as word 3 of data set 3.  A target for this data can be selected by parameter <a href="#">62.50 Data set 3 data 3 selection</a> . The value can also be used as a source by another parameter.	0 / uint16
	0...65535	Data received as word 3 of data set 3.	- / -
62.101	Data set 10 data 1 value	Displays (in integer format) the data received from the external controller as word 1 of data set 10.  A target for this data can be selected by parameter <a href="#">62.51 Data set 10 data 1 selection</a> . The value can also be used as a source by another parameter.	- / uint16
	0...65535	Data received as word 1 of data set 10.	- / -
62.102	Data set 10 data 2 value	Displays (in integer format) the data received from the external controller as word 2 of data set 10.  A target for this data can be selected by parameter <a href="#">62.52 Data set 10 data 2 selection</a> . The value can also be used as a source by another parameter.	- / uint16
	0...65535	Data received as word 2 of data set 10.	- / -
62.103	Data set 10 data 3 value	Displays (in integer format) the data received from the external controller as word 3 of data set 10.  A target for this data can be selected by parameter <a href="#">62.53 Data set 10 data 3 selection</a> . The value can also be used as a source by another parameter.	- / uint16
	0...65535	Data received as word 3 of data set 10.	- / -

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
62.104	Data set 12 data 1 value	Displays (in integer format) the data received from the external controller as word 1 of data set 12.  A target for this data can be selected by parameter <a href="#">62.54 Data set 12 data 1 selection</a> . The value can also be used as a source by another parameter.	- / uint16
	0...65535	Data received as word 1 of data set 12.	- / -
...	...	...	...
62.124	Data set 24 data 3 value	Displays (in integer format) the data received from the external controller as word 3 of data set 24.  A target for this data can be selected by parameter <a href="#">62.74 Data set 24 data 3 selection</a> . The value can also be used as a source by another parameter.	- / uint16
	0...65535	Data received as word 3 of data set 24.	- / -
62.151	INU-LSU data set 11 data 1 sel	(Parameters <a href="#">62.151</a> ... <a href="#">62.203</a> only visible when supply unit control activated by <a href="#">95.20</a> )  Parameters <a href="#">62.151</a> ... <a href="#">62.153</a> define a target for the data received in data set 11 from another converter (typically the supply unit of the drive).  Parameters <a href="#">62.201</a> ... <a href="#">62.203</a> display the data received from the other converter in integer format, and can be used as sources by other parameters.  For example, this parameter selects a target for word 1 of data set 11. Parameter <a href="#">62.201 INU-LSU data set 11 data 1 value</a> displays the received data in integer format, and can also be used as a source by other parameters.	LSU SW / uint32
	None	None.	0
	LSU SW	Status word of the supply unit.	4
	Other [bit]	Source selection (see <a href="#">Terms and abbreviations (page 134)</a> ).	-
62.152	INU-LSU data set 11 data 2 sel	Defines a target for the data received as word 2 of data set 11.  See also parameter <a href="#">62.202 INU-LSU data set 11 data 2 value</a> .  For the selections, see parameter <a href="#">62.151 INU-LSU data set 11 data 1 sel</a> .	None / uint32
62.153	INU-LSU data set 11 data 3 sel	Defines a target for the data received as word 3 of data set 11.  See also parameter <a href="#">62.203 INU-LSU data set 11 data 3 value</a> .  For the selections, see parameter <a href="#">62.151 INU-LSU data set 11 data 1 sel</a> .	None / uint32

## 504 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
62.201	INU-LSU data set 11 data 1 value	<p>Displays (in integer format) the data received from the other converter as word 1 of data set 11.</p> <p>A target for this data can be selected by parameter <a href="#">62.151 INU-LSU data set 11 data 1 sel</a>. The value can also be used as a source by another parameter.</p>	- / uint16
	0...65535	Data received as word 1 of data set 11.	- / -
62.202	INU-LSU data set 11 data 2 value	<p>Displays (in integer format) the data received from the other converter as word 2 of data set 11.</p> <p>A target for this data can be selected by parameter <a href="#">62.152 INU-LSU data set 11 data 2 sel</a>. The value can also be used as a source by another parameter.</p>	- / uint16
	0...65535	Data received as word 2 of data set 11.	- / -
62.203	INU-LSU data set 11 data 3 value	<p>Displays (in integer format) the data received from the other converter as word 3 of data set 11.</p> <p>A target for this data can be selected by parameter <a href="#">62.153 INU-LSU data set 11 data 3 sel</a>. The value can also be used as a source by another parameter.</p>	- / uint16
	0...65535	Data received as word 3 of data set 11.	- / -



No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
90	Feedback selection	Motor and load feedback configuration. See also section <a href="#">Encoder support (page 53)</a> , and the diagram on page 671.	
90.1	Motor speed for control	Displays the estimated or measured motor speed that is used for speed control, ie. final motor speed feedback selected by parameter <a href="#">90.41 Motor feedback selection</a> and filtered by <a href="#">90.42 Motor speed filter time</a> . In case measured feedback is selected, it is also scaled by the motor gear function ( <a href="#">90.43 Motor gear numerator</a> and <a href="#">90.44 Motor gear denominator</a> ). Estimated speed is always used in scalar control. <b>Note:</b> This parameter is read-only.	- / real32
	-32768.00 ... 32767.00 rpm	Motor speed used for control. For 16-bit scaling, see parameter <a href="#">46.1</a> .	- / 100 = 1 rpm
90.2	Motor position	Displays the motor position (within one revolution) received from the source selected by parameter <a href="#">90.41 Motor feedback selection</a> . In case measured feedback is selected, it is also scaled by the motor gear function ( <a href="#">90.43 Motor gear numerator</a> and <a href="#">90.44 Motor gear denominator</a> ). <b>Note:</b> This parameter is read-only.	- / real32
	0.00000000 ... 1.00000000 rev	Motor position.	32767 = 1 rev / 100000000 = 1 rev
90.3	Load speed	Displays the estimated or measured load speed that is used for motor control, ie. final load speed feedback selected by parameter <a href="#">90.51 Load feedback selection</a> and filtered by <a href="#">90.52 Load speed filter time</a> . In case measured feedback is selected, it is also scaled by the load gear function ( <a href="#">90.53 Load gear numerator</a> and <a href="#">90.54 Load gear denominator</a> ). In case motor feedback or estimated feedback is used, it is inversely scaled by <a href="#">90.61 Gear numerator</a> and <a href="#">90.62 Gear denominator</a> (ie. <a href="#">90.62</a> divided by <a href="#">90.61</a> ). <b>Note:</b> This parameter is read-only.	- / real32
	-32768.00 ... 32767.00 rpm	Load speed. For 16-bit scaling, see parameter <a href="#">46.1</a> .	- / 100 = 1 rpm

## 506 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
90.4	Load position	<p>Displays the load position received from the source selected by parameter <a href="#">90.51 Load feedback selection</a>. The value is multiplied as specified by parameter <a href="#">90.57 Load position resolution</a>.</p> <p>In case measured feedback is selected, it is also scaled by the load gear function (<a href="#">90.53 Load gear numerator</a> and <a href="#">90.54 Load gear denominator</a>).</p> <p>In case motor feedback or estimated feedback is used, it is inversely scaled by <a href="#">90.61 Gear numerator</a> and <a href="#">90.62 Gear denominator</a> (ie. <a href="#">90.62</a> divided by <a href="#">90.61</a>).</p> <p>An offset can be defined by <a href="#">90.56 Load position offset</a>.</p> <p><b>Note:</b> This parameter is read-only.</p>	- / int32
		Load position.	- / 1 = 1
90.5	Load position scaled	<p>Displays the scaled load position in decimal format. The position is relative to the initial position set by parameters <a href="#">90.65</a> and <a href="#">90.66</a>.</p> <p>The number of decimal places is defined by parameter <a href="#">90.38 Pos counter decimals</a>.</p> <p><b>Note:</b> This is a floating point parameter, and the accuracy is compromised near the ends of the range. Consider using parameter <a href="#">90.7 Load position scaled int</a> instead of this parameter.</p> <p><b>Note:</b> This parameter is read-only.</p>	- / real32
	-2147483.648 ... 2147483.647	Scaled load position in decimal format.	- / 100000 = 1
90.6	Motor position scaled	<p>Displays the calculated motor position.</p> <p>The axis mode (linear or rollover) and resolution are defined by parameters <a href="#">90.48 Motor position axis mode</a> and <a href="#">90.49 Motor position resolution</a> respectively.</p> <p><b>Note:</b> The position value can be sent on a fast time level to the fieldbus controller by selecting <a href="#">Position</a> in either <a href="#">50.7 FBA A actual 1 type</a>, <a href="#">50.8 FBA A actual 2 type</a>, <a href="#">50.37 FBA B actual 1 type</a> or <a href="#">50.38 FBA B actual 2 type</a>.</p> <p><b>Note:</b> This parameter is read-only.</p>	- / int32
	-2147483.648 ... 2147483.647	Motor position.	1 = 1 / 1000 = 1
90.7	Load position scaled int	<p>Displays the output of the position counter function as an integer, enabling backwards compatibility with ACS 600 and ACS800 drives. The position is relative to the initial position set by parameters <a href="#">90.58</a> and <a href="#">90.59</a>. See section <a href="#">Position counter (page 55)</a>, and the block diagram on page <a href="#">672</a>.</p> <p><b>Note:</b> This parameter is read-only.</p>	- / int32

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
		Scaled load position in integer format.	- / -
90.10	Encoder 1 speed	Displays encoder 1 speed in rpm.  <b>Note:</b> This parameter is read-only.	- / real32
	-32768.00 ... 32767.00 rpm	Encoder 1 speed. For 16-bit scaling, see parameter 46.1.	- / 100 = 1 rpm
90.11	Encoder 1 position	Displays the actual position of encoder 1 within one revolution.  <b>Note:</b> This parameter is read-only.	- / real32
	0.00000000 ... 1.00000000 rev	Encoder 1 position within one revolution.	32767 = 1 rev / 100000000 = 1 rev
90.12	Encoder 1 multiturn revolutions	Displays the revolutions of (multiturn) encoder 1 within its value range (see parameter 92.14 Revolution data width).  <b>Note:</b> This parameter is read-only.	- / uint32
	0...16777215	Encoder 1 revolutions.	- / 1 = 1
90.13	Encoder 1 revolution extension	Displays the revolution count extension for encoder 1.  With a single-turn encoder, the counter is incremented when encoder position (parameter 90.11) wraps around in the positive direction, and decremented in the negative direction.  With a multiturn encoder, the counter is incremented when the revolutions count (parameter 90.12) exceeds the value range in the positive direction, and decremented in the negative direction.  <b>Note:</b> This parameter is read-only.	- / int32
	<del>2147483648</del> 2147483647	Encoder 1 revolution count extension.	- / 1 = 1
90.14	Encoder 1 position raw	Displays the raw measurement data of encoder 1 position (within one revolution) as a 24-bit unsigned integer received from the encoder interface.  <b>Note:</b> This parameter is read-only.	- / uint32
	0...16777215	Raw encoder 1 position within one revolution.	- / 1 = 1
90.15	Encoder 1 revolutions raw	Displays the revolutions of (multiturn) encoder 1 within its value range (see parameter 92.14 Revolution data width) as a raw measurement.  <b>Note:</b> This parameter is read-only.	- / uint32
	0...16777215	Raw encoder 1 revolution count.	- / 1 = 1
90.20	Encoder 2 speed	Displays encoder 2 speed in rpm.  <b>Note:</b> This parameter is read-only.	- / real32

## 508 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	-32768.00 ... 32767.00 rpm	Encoder 2 speed. For 16-bit scaling, see parameter <a href="#">46.1</a> .	- / 100 = 1 rpm
90.21	Encoder 2 position	Displays the actual position of encoder 2 within one revolution.  <b>Note:</b> This parameter is read-only.	- / real32
	0.00000000 ... 1.00000000 rev	Encoder 2 position within one revolution.	- / 100000000 = 1 rev
90.22	Encoder 2 multturn revolutions	Displays the revolutions of (multiturn) encoder 2 within its value range (see parameter <a href="#">93.14 Revolution data width</a> ).  <b>Note:</b> This parameter is read-only.	- / uint32
	0...16777215	Encoder 2 revolutions.	- / 1 = 1
90.23	Encoder 2 revolution extension	Displays the revolution count extension for encoder 2.  With a single-turn encoder, the counter is incremented when encoder position (parameter <a href="#">90.21</a> ) wraps around in the positive direction, and decremented in the negative direction.  With a multiturn encoder, the counter is incremented when the revolutions count (parameter <a href="#">90.22</a> ) exceeds the value range in the positive direction, and decremented in the negative direction.  <b>Note:</b> This parameter is read-only.	- / int32
		Encoder 2 revolution count extension.	- / 1 = 1
90.24	Encoder 2 position raw	Displays the raw measurement data of encoder 2 position (within one revolution) as a 24-bit unsigned integer received from the encoder interface.  <b>Note:</b> This parameter is read-only.	- / uint32
	0...16777215	Raw encoder 2 position within one revolution.	- / 1 = 1
90.25	Encoder 2 revolutions raw	Displays the revolutions of (multiturn) encoder 2 within its value range (see parameter <a href="#">93.14 Revolution data width</a> ) as a raw measurement.  <b>Note:</b> This parameter is read-only.	- / uint32
	0...16777215	Raw encoder 2 revolution count.	- / 1 = 1
90.26	Motor revolution extension	Displays the motor revolution count extension.  The counter is incremented when the position selected by <a href="#">90.41 Motor feedback selection</a> wraps around in the positive direction, and decremented in the negative direction.  <b>Note:</b> This parameter is read-only.	- / int32
	-2147483648..2147483647	Motor revolution count extension.	- / 1 = 1

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
90.27	Load revolution extension	Displays the load revolution count extension.  The counter is incremented when the position selected by <a href="#">90.51 Load feedback selection</a> wraps around in the positive direction, and decremented in the negative direction.  <b>Note:</b> This parameter is read-only.	- / int32
	<del>2147483648..2147483647</del>	Load revolution count extension.	- / 1 = 1
90.35	Pos counter status	Status information related to the position counter function. See section <a href="#">Position counter (page 55)</a> .  <b>Note:</b> This parameter is read-only.	- / uint16
b0	Encoder 1 feedback	1 = Encoder 1 selected as load feedback source	
b1	Encoder 2 feedback	1 = Encoder 2 selected as load feedback source	
b2	Internal position feedback	1 = Internal load position estimate selected as load feedback source	
b3	Motor feedback	1 = Motor feedback selected as load feedback source	
b4	Pos counter init ready	0 = Position counter not initialized, or encoder feedback was lost. Fresh counter initialization recommended. 1 = Position counter successfully initialized	
b5	Position counter re-init disabled	1 = Position counter initialization is being prevented by par. <a href="#">90.68</a>	
b6	Position data inaccurate	1 = Encoder feedback intermittent or lost. (If the drive is running, estimated position is used whenever encoder feedback is unavailable. If the drive is in stopped state, position counting will continue based on encoder data after the connection is restored.)	
b7...15	Reserved		
	0000h...FFFFh		1 = 1 / 1 = 1
90.38	Pos counter decimals	Scales the values of parameters <a href="#">90.5 Load position scaled</a> and <a href="#">90.65 Pos counter init value</a> when accessed from an external source (eg. fieldbus). The setting corresponds to the number of decimal places.  For example, with the setting of 3, an integer value of 66770 written into <a href="#">90.65 Pos counter init value</a> is divided by 1000, so the final value applied will be 66.770. Likewise, the value of <a href="#">90.5 Load position scaled</a> is multiplied by 1000 when read.	3 / uint16
	0...9	Number of position counter decimal places.	1 = 1 / 1 = 1

## 510 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
90.41	Motor feedback selection	Selects the motor speed feedback value used during motor control.  <b>Note:</b> With a permanent magnet motor, make sure an autophasing routine (see page 63) is performed using the selected encoder. If necessary, set parameter 99.13 <a href="#">ID run requested</a> to <a href="#">Autophasing</a> to request a fresh autophasing routine.	Estimate / uint16
	Estimate	A calculated speed estimate generated from the DTC core is used.	0
	Encoder 1	Actual speed measured by encoder 1. The encoder is set up by the parameters in group 92 <a href="#">Encoder 1 configuration</a> .	1
	Encoder 2	Actual speed measured by encoder 2. The encoder is set up by the parameters in group 93 <a href="#">Encoder 2 configuration</a> .	2
90.42	Motor speed filter time	Defines a filter time for motor speed feedback used for speed control (90.1 <a href="#">Motor speed for control</a> ).	3 ms / real32
	0...10000 ms	Motor speed filter time.	1 = 1 ms / 1 = 1 ms
90.43	Motor gear numerator	Parameters 90.43 and 90.44 define a gear function between the motor speed feedback and motor control. The gear is used to correct a difference between the motor and encoder speeds for example if the encoder is not mounted directly on the motor shaft.  $\frac{90.43}{90.44} = \frac{\text{Motor speed}}{\text{Encoder speed}}$  See also section <a href="#">Load and motor feedback</a> (page 54).  <b>Note:</b> This parameter cannot be changed while the drive is running.	1 / int32
	<del>-2147483648</del> . <del>2147483647</del>	Motor gear numerator.	- / 1 = 1
90.44	Motor gear denominator	See parameter 90.43 <a href="#">Motor gear numerator</a> .  <b>Note:</b> This parameter cannot be changed while the drive is running.	1 / int32
	<del>-2147483648</del> . <del>2147483647</del>	Motor gear denominator.	- / 1 = 1
90.45	Motor feedback fault	Selects how the drive reacts to loss of measured motor feedback.	Fault / uint16
	Fault	Drive trips on a 7301 <a href="#">Motor speed feedback</a> or 7381 <a href="#">Encoder fault</a> .	0
	Warning	Drive generates an A798 <a href="#">Encoder option comm loss</a> , A7B0 <a href="#">Motor speed feedback</a> or A7E1 <a href="#">Encoder warning</a> and continues operation using estimated feedbacks.  <b>Note:</b> Before using this setting, test the stability of the speed control loop with estimated feedback by running the drive on estimated feedback (see 90.41 <a href="#">Motor feedback selection</a> ).	1

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
90.46	Force open loop	Forces the DTC motor model to use estimated motor speed as feedback. This parameter can be activated when the encoder data is obviously unreliable because of slippage, for example.  <b>Note:</b> This parameter only affects the selection of feedback for the motor model, not for the speed controller.	No / uint16
	No	The motor model uses the feedback selected by <a href="#">90.41 Motor feedback selection</a> .	0
	Yes	The motor model uses the calculated speed estimate (regardless of the setting of <a href="#">90.41 Motor feedback selection</a> , which in case only selects the source of feedback for the speed controller).	1
90.48	Motor position axis mode	Selects the axis type for motor position measurement.	Rollover / uint16
	Linear	Linear.	0
	Rollover	The value is between 0 and 1 revolutions, and rolls over at 360 degrees.	1
90.49	Motor position resolution	Defines how many bits are used for motor position count within one revolution. For example, with the setting of 24, the position value is multiplied by 16777216 for display in parameter <a href="#">90.6 Motor position scaled</a> (or for fieldbus).	24 / uint16
	0...31	Motor position resolution.	- / 1 = 1
90.51	Load feedback selection	Selects the source of load speed and position feedbacks used in control.	None / uint16
	None	No load feedback selected.	0
	Encoder 1	Load feedbacks are updated based on the speed and position values read from encoder 1.  The values are scaled by the load gear function ( <a href="#">90.53 Load gear numerator</a> and <a href="#">90.54 Load gear denominator</a> ).  The encoder is set up by the parameters in group <a href="#">92 Encoder 1 configuration</a> .	1
	Encoder 2	Load feedbacks are updated based on the speed and position values read from encoder 2.  The values are scaled by the load gear function ( <a href="#">90.53 Load gear numerator</a> and <a href="#">90.54 Load gear denominator</a> ).  The encoder is set up by the parameters in group <a href="#">93 Encoder 2 configuration</a> .	2
	Estimate	Calculated speed and position estimates are used. The values are scaled from the motor side to the load side using the inverted ratio between <a href="#">90.61 Gear numerator</a> and <a href="#">90.62 Gear denominator</a> (ie. <a href="#">90.62</a> divided by <a href="#">90.61</a> ).	3

## 512 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	Motor feedback	The source selected by parameter <a href="#">90.41 Motor feedback selection</a> for motor feedback is also used for load feedback.  Any difference between the motor and load speeds (and positions) can be compensated by using the inverted ratio between <a href="#">90.61 Gear numerator</a> and <a href="#">90.62 Gear denominator</a> (ie. <a href="#">90.62</a> divided by <a href="#">90.61</a> ).	4
90.52	Load speed filter time	Defines a filter time for load speed feedback ( <a href="#">90.3 Load speed</a> ).	4 ms / real32
	0...10000 ms	Load speed filter time.	- / 1 = 1 ms
90.53	Load gear numerator	Parameters <a href="#">90.53</a> and <a href="#">90.54</a> define a gear function between the load (ie. driven equipment) speed and the encoder feedback selected by parameter <a href="#">90.51 Load feedback selection</a> . The gear can be used to correct a difference between the load and encoder speeds for example if the encoder is not mounted directly on the rotated machinery.  $\frac{90.53}{90.54} = \frac{\text{Load speed}}{\text{Encoder speed}}$  See also section <a href="#">Load and motor feedback (page 54)</a> .  <b>Note:</b> This parameter cannot be changed while the drive is running.	1 / int32
	<del>2147483648</del> .2147483647	Load gear numerator.	- / 1 = 1
90.54	Load gear denominator	See parameter <a href="#">90.53 Load gear numerator</a> .  <b>Note:</b> This parameter cannot be changed while the drive is running.	1 / int32
	<del>2147483648</del> .2147483647	Load gear denominator.	- / 1 = 1
90.55	Load feedback fault	Selects how the drive reacts to loss of load feedback.	Fault / uint16
	Fault	Drive trips on a <a href="#">73A1 Load position feedback</a> fault.	0
	Warning	Drive generates an <a href="#">A798 Encoder option comm loss</a> or <a href="#">A7B1 Load speed feedback</a> warning and continues operation using estimated feedbacks.	1
90.56	Load position offset	Defines a load-side position offset. The resolution is determined by parameter <a href="#">90.57 Load position resolution</a> .	0.0 rev / int32
	<del>2147483648</del> .2147483647 rev	Load-side position offset.	- / 1 = 1 rev
90.57	Load position resolution	Defines how many bits are used for load position count within one revolution. For example, with the setting of 18, the position value is multiplied by 65536 for display in parameter <a href="#">90.4 Load position</a> .	16 / uint16
	0...31	Load position resolution.	- / 1 = 1



No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
90.58	Pos counter init value int	Defines an initial position (or distance) for the position counter (as an integer value) when parameter <a href="#">90.59 Pos counter init value int source</a> is set to <a href="#">Pos counter init value int</a> .  See also section <a href="#">Position counter (page 55)</a> .	- / int32
	<del>2147483648</del> . <del>2147483647</del>	Initial integer value for position counter.	- / 1 = 1
90.59	Pos counter init value int source	Selects the source of the initial position integer value. When the source selected by <a href="#">90.67 Pos counter init cmd source</a> activates, the value selected in this parameter is assumed to be the position of the load.	Pos counter init value int / uint32
	Zero	0.	0
	Pos counter init value int	Parameter <a href="#">90.58 Pos counter init value int</a> .	1
	Other [bit]	Source selection (see <a href="#">Terms and abbreviations (page 134)</a> ).	-
90.60	Pos counter error and boot action	Selects how the position counter reacts to loss of load feedback.	Request re-initialization / uint16
	Request re-initialization	Bit 4 of <a href="#">90.35 Pos counter status</a> is cleared. Reinitialization of position counter is recommended.	0
	Continue from previous value	Position counting resumes from the previous value over a loss of load feedback or control unit reboot. Bit 4 of <a href="#">90.35 Pos counter status</a> is not cleared, but bit 6 is set to indicate that an error has occurred.  <b>Note:</b> If load feedback is lost when the drive is in stopped state or not powered, the counter is not updated even if the load moves.	1
90.61	Gear numerator	Parameter <a href="#">90.61</a> and <a href="#">90.62</a> define a gear function between the motor and load speeds.  $\frac{90.61}{90.62} = \frac{\text{Motor speed}}{\text{Load speed}}$  See also section <a href="#">Load and motor feedback (page 54)</a> .	1 / int32
	<del>2147483648</del> . <del>2147483647</del>	Gear numerator (motor-side).	- / 1 = 1
90.62	Gear denominator	See parameter <a href="#">90.61 Gear numerator</a> .	1 / int32
	<del>2147483648</del> . <del>2147483647</del>	Gear denominator (load-side).	- / 1 = 1

## 514 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
90.63	Feed constant numerator	Parameters <a href="#">90.63</a> and <a href="#">90.64</a> define the feed constant for the position calculation:  $\frac{90.63}{90.64}$ <p>The feed constant converts rotational motion into translatory motion. The feed constant is the distance the load moves during one turn of the motor shaft.</p> <p>The translatory load position is shown by parameter <a href="#">90.7 Load position scaled int</a>. Note that the load position is only updated after new position input data is received.</p>	1 / int32
	<del>-2147483648</del> , <del>2147483647</del>	Feed constant numerator.	- / 1 = 1
90.64	Feed constant denominator	See parameter <a href="#">90.63 Feed constant numerator</a> .	1 / int32
	<del>-2147483648</del> , <del>2147483647</del>	Feed constant denominator.	- / 1 = 1
90.65	Pos counter init value	Defines an initial position (or distance) for the position counter (as a decimal number) when parameter <a href="#">90.66 Pos counter init value source</a> is set to <a href="#">Pos counter init value</a> .  The number of decimal places is defined by parameter <a href="#">90.38 Pos counter decimals</a> .	0.000 / real32
	<del>-2147483.648 ...</del> <del>2147483.647</del>	Initial value for position counter.	- / 1 = 1
90.66	Pos counter init value source	Selects the source of the initial position value. When the source selected by <a href="#">90.67 Pos counter init cmd source</a> activates, the value selected in this parameter is assumed to be the position of the load (in decimal format).	Pos counter init value / uint32
	Zero	0.	0
	Pos counter init value	Parameter <a href="#">90.65 Pos counter init value</a> .	1
	Other [bit]	Source selection (see <a href="#">Terms and abbreviations (page 134)</a> ).	-
90.67	Pos counter init cmd source	Selects a digital source (for example, a limit switch connected to a digital input) that initializes the position counter. When the digital source activates, the value selected by <a href="#">90.66 Pos counter init value source</a> is assumed to be the position of the load.  <b>Note:</b> Position counter initialization can be prevented by parameter <a href="#">90.68 Disable pos counter initialization</a> .	Not selected / uint32
	Not selected	0	0
	Selected	1	1
	DI1	Digital input DI1 ( <a href="#">10.2 DI delayed status</a> , bit 0).	2
	DI2	Digital input DI2 ( <a href="#">10.2 DI delayed status</a> , bit 1).	3

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	DI3	Digital input DI3 (10.2 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.2 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.2 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.2 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1 (11.2 DIO delayed status, bit 0).	10
	DIO2	Digital input/output DIO2 (11.2 DIO delayed status, bit 1).	11
	Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-
90.68	Disable pos counter initialization	Selects a source that prevents the initialization of the position counter.	Not selected / uint32
	Not selected	0	0
	Selected	1	1
	DI1	Digital input DI1 (10.2 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.2 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.2 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.2 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.2 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.2 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1 (11.2 DIO delayed status, bit 0).	10
	DIO2	Digital input/output DIO2 (11.2 DIO delayed status, bit 1).	11
	Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-
90.69	Reset pos counter init ready	Selects a source that enables a new initialization of the position counter, ie. resets bit 4 of <a href="#">90.35 Pos counter status</a> .	Not selected / uint32
	Not selected	0	0
	Selected	1	1
	DI1	Digital input DI1 (10.2 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.2 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.2 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.2 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.2 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.2 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1 (11.2 DIO delayed status, bit 0).	10
	DIO2	Digital input/output DIO2 (11.2 DIO delayed status, bit 1).	11
	Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-

## 516 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
<b>91</b>	Encoder module settings	Configuration of encoder interface modules.	
91.1	FEN DI status	Displays the status of the digital inputs of FEN-xx encoder interface modules.  <b>Note:</b> This parameter is read-only.	- / uint16
b0	DI1 /module 1	DI1 of interface module 1 (see parameters <a href="#">91.11</a> and <a href="#">91.12</a> )	
b1	DI2 /module 1	DI2 of interface module 1 (see parameters <a href="#">91.11</a> and <a href="#">91.12</a> )	
b2...3	Reserved		
b4	DI1 /module 2	DI1 of interface module 2 (see parameters <a href="#">91.13</a> and <a href="#">91.14</a> )	
b5	DI2 /module 2	DI2 of interface module 2 (see parameters <a href="#">91.13</a> and <a href="#">91.14</a> )	
b6...15	Reserved		
	0000h...FFFFh		1 = 1 / 1 = 1
91.2	Module 1 status	Displays the type of the interface module found in the location specified by parameter <a href="#">91.12 Module 1 location</a> .  <b>Note:</b> This parameter is read-only.	No option / uint16
	No option	No module detected in the specified slot.	0
	No communication	A module has been detected but cannot be communicated with.	1
	Unknown	The module type is unknown.	2
	FEN-01	An FEN-01 module has been detected and is active.	16
	FEN-11	An FEN-11 module has been detected and is active.	17
	FEN-21	An FEN-21 module has been detected and is active.	18
	FEN-31	An FEN-31 module has been detected and is active.	21
	FSE-31	An FSE-31 module has been detected and is active.	25
91.3	Module 2 status	Displays the type of the interface module found in the location specified by parameter <a href="#">91.14 Module 2 location</a> .  For the indications, see parameter <a href="#">91.2 Module 1 status</a> .  <b>Note:</b> This parameter is read-only.	No option / uint16
91.4	Module 1 temperature	Displays the temperature measured through the sensor input of interface module 1. The unit (°C or °F) is selected by parameter <a href="#">96.16 Unit selection</a> .  <b>Note:</b> With a PTC sensor, the unit is ohms.  <b>Note:</b> This parameter is read-only.	- / real32

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	0...1000°C	Temperature measured through interface module 1.	- / -
91.6	Module 2 temperature	Displays the temperature measured through the sensor input of interface module 2. The unit (°C or °F) is selected by parameter <a href="#">96.16 Unit selection</a> .  <b>Note:</b> With a PTC sensor, the unit is ohms.  <b>Note:</b> This parameter is read-only.	- / real32
	0...1000°C	Temperature measured through interface module 2.	- / -
91.10	Encoder parameter refresh	Validates any changed encoder interface module parameters. This is needed for any parameter changes in groups 90...93 to take effect.  After refreshing, the value reverts automatically to <a href="#">Done</a> . <ul style="list-style-type: none"> <li>Permanent magnet motors only: The drive will perform a fresh autophasing routine (see <a href="#">page 63</a>) at next start if the motor feedback encoder settings have been changed.</li> <li>The parameter cannot be changed while the drive is running.</li> </ul>	Done / uint16
	Done	Refreshing done.	0
	Refresh	Refreshing.	1
91.11	Module 1 type	Defines the type of the module used as interface module 1.	None / uint16
	None	None (communication disabled).	0
	FEN-01	FEN-01.	1
	FEN-11	FEN-11.	2
	FEN-21	FEN-21.	3
	FEN-31	FEN-31.	4
	FSE-31	FSE-31.	5
91.12	Module 1 location	Specifies the slot (1...3) on the control unit of the drive into which the interface module is installed. Alternatively, specifies the node ID of the slot on an FEA-03 extension adapter.	2 / uint16
	1...254	Slot 1 = 1; Slot 2 = 2; Slot 3 = 3 4...254: Node ID of the slot on the FEA-03 extension adapter	1 = 1 / 1 = 1
91.13	Module 2 type	Defines the type of the module used as interface module 2.	None / uint16
	None	None (communication disabled).	0
	FEN-01	FEN-01.	1
	FEN-11	FEN-11.	2
	FEN-21	FEN-21.	3
	FEN-31	FEN-31.	4

## 518 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	FSE-31	FSE-31.	5
91.14	Module 2 location	Specifies the slot (1...3) on the control unit of the drive into which the interface module is installed. Alternatively, specifies the node ID of the slot on an FEA-03 extension adapter.	3 / uint16
	1...254	Slot 1 = 1; Slot 2 = 2; Slot 3 = 3 4...254: Node ID of the slot on the FEA-03 extension adapter	1 = 1 / 1 = 1
91.21	Module 1 temp sensor type	Specifies the type of temperature sensor connected to interface module 1. Note that the module must also be activated by parameters <a href="#">91.11</a> ... <a href="#">91.12</a> .	None / uint16
	None	None.	0
	PTC	PTC. (The unit is ohms.)	1
	KTY-84	KTY84. (The unit is selected by parameter <a href="#">96.16 Unit selection</a> .)	2
	Pt1000	Pt1000 (The unit is selected by parameter <a href="#">96.16 Unit selection</a> ). <b>Note:</b> Pt1000 sensor supports FEN-11 and FEN-31 encoder modules only.	3
91.22	Module 1 temp filter time	Defines a filtering time for the temperature measurement through interface module 1.	1500 ms / real32
	0...10000 ms	Filtering time for temperature measurement.	- / -
91.24	Module 2 temp sensor type	Specifies the type of temperature sensor connected to interface module 2. Note that the module must also be activated by parameters <a href="#">91.13</a> ... <a href="#">91.14</a> .	None / uint16
	None	None.	0
	PTC	PTC. (The unit is ohms.)	1
	KTY-84	KTY84. (The unit is selected by parameter <a href="#">96.16 Unit selection</a> .)	2
	Pt1000	Pt1000 (The unit is selected by parameter <a href="#">96.16 Unit selection</a> ). <b>Note:</b> Pt1000 sensor supports FEN-11 and FEN-31 encoder modules only.	3
91.25	Module 2 temp filter time	Defines a filtering time for the temperature measurement through interface 2.	1500 ms / real32
	0...10000 ms	Filtering time for temperature measurement.	- / 1 = 1 ms
91.31	Module 1 TTL output source	Selects the encoder input on interface module 1 whose signal is echoed by or emulated to the TTL output. See also section <a href="#">Encoder support (page 53)</a> .	Not selected / uint16
	Not selected	TTL output not in use.	0
	Module input 1	Input 1 is echoed by or emulated to the TTL output.	1
	Module input 2	Input 2 is echoed by or emulated to the TTL output.	2

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
91.32	Module 1 emulation pulses/rev	Defines the number of TTL pulses per revolution for encoder emulation output of interface module 1.	- / uint16
	0...65535	Number of TTL pulses for emulation.	1 = 1 / -
91.33	Module 1 emulated Z-pulse offset	With interface module 1, defines when zero pulses are emulated in relation to zero position received from the encoder.  For example, with a value of 0.50000, a zero pulse is emulated whenever the encoder position passes 0.5 revolutions. With a value of 0.00000, a zero pulse is emulated whenever the encoder position passes zero position.	- / real32
	0.00000 ... 1.00000 rev	Position of emulated zero pulses.	32767 = 1 rev / 100000 = 1 rev
91.41	Module 2 TTL output source	Selects the encoder input on interface module 2 whose signal is echoed by or emulated to the TTL output.  See also section <a href="#">Encoder support (page 53)</a> .	Not selected / uint16
	Not selected	TTL output not in use.	0
	Module input 1	Input 1 is echoed by or emulated to the TTL output.	1
	Module input 2	Input 2 is echoed by or emulated to the TTL output.	2
91.42	Module 2 emulation pulses/rev	Defines the number of TTL pulses per revolution for encoder emulation output of interface module 2.	- / uint16
	0...65535	Number of TTL pulses for emulation.	1 = 1 / 1 = 1
91.43	Module 2 emulated Z-pulse offset	With interface module 2, defines when zero pulses are emulated in relation to zero position received from the encoder.  For example, with a value of 0.50000, a zero pulse is emulated whenever the encoder position passes 0.5 revolutions. With a value of 0.00000, a zero pulse is emulated whenever the encoder position passes zero position.	- / real32
	0.00000 ... 1.00000 rev	Position of emulated zero pulses.	32767 = 1 rev / 100000 = 1 rev

## 520 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
92	Encoder 1 configuration	<p>Settings for encoder 1.</p> <p><b>Note:</b> The contents of this parameter group vary according to the selected encoder type.</p> <p><b>Note:</b> It is recommended that encoder connection 1 (this group) is used whenever possible since the data received through that interface is fresher than the data received through connection 2 (group <a href="#">93 Encoder 2 configuration</a>).</p>	
92.1	Encoder 1 type	Selects the type of encoder/resolver 1.	None configured / uint16
	None configured	None.	0
	TTL	TTL. Module type (input): FEN-01 (X31), FEN-11 (X41) or FEN-21 (X51).	1
	TTL+	TTL+. Module type (input): FEN-01 (X32).	2
	Absolute encoder	Absolute encoder. Module type (input): FEN-11 (X42).	3
	Resolver	Resolver. Module type (input): FEN-21 (X52).	4
	HTL	HTL. Module type (input): FEN-31 (X82).	5
	HTL 1	HTL. Module type (input): FSE-31 (X31).	6
	HTL 2	HTL. Module type (input): FSE-31 (X32). Not supported at the time of publication.	7
92.2	Encoder 1 source	<p>Selects the interface module that the encoder is connected to.</p> <p>(The physical locations and types of encoder interface modules are defined in parameter group <a href="#">91 Encoder module settings</a>.)</p>	Module 1 / uint16
	Module 1	Interface module 1.	0
	Module 2	Interface module 2.	1
92.10	Excitation signal frequency	<p>(Visible when <a href="#">92.1 Encoder 1 type = Resolver</a>)</p> <p>Defines the frequency of the excitation signal.</p> <p><b>Note:</b> With an EnDat or HIPERFACE encoder and FEN-11 FPGA version VIE12200 or later, this parameter is automatically set upon validation of encoder settings (<a href="#">91.10 Encoder parameter refresh</a>).</p>	1 kHz / uint16
	1...20 kHz	Excitation signal frequency.	1 = 1 kHz / 1 = 1 kHz
92.10	Sine/cosine number	<p>(Visible when <a href="#">92.1 Encoder 1 type = Absolute encoder</a>)</p> <p>Defines the number of sine/cosine wave cycles within one revolution.</p> <p><b>Note:</b> This parameter need not be set when an EnDat or SSI encoder is used in continuous mode. See parameter <a href="#">92.30 Serial link mode</a>.</p>	0 / uint16
	0...65535	Number of sine/cosine wave cycles within one revolution.	- / 1 = 1



No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
92.10	Pulses/revolution	(Visible when <a href="#">92.1 Encoder 1 type = HTL 1</a> ) Defines the pulse number per revolution.	2048 / uint16
	0...65535	Number of pulses.	- / 1 = 1
92.11	Excitation signal amplitude	(Visible when <a href="#">92.1 Encoder 1 type = Resolver</a> ) Defines the rms amplitude of the excitation signal.	4.0 V / uint16
	4.0 ... 12.0 V	Excitation signal amplitude.	10 = 1 V / 100 = 1 V
92.11	Absolute position source	(Visible when <a href="#">92.1 Encoder 1 type = Absolute encoder</a> ) Selects the source of the absolute position information.	None / uint16
	None	Not selected.	0
	Commut. signals	Commutation signals.	1
	EnDat	Serial interface: EnDat encoder.	2
	Hiperface	Serial interface: HIPERFACE encoder.	3
	SSI	Serial interface: SSI encoder.	4
	Tamagawa	Serial interface: Tamagawa 17/33-bit encoder.	5
92.11	Pulse encoder type	(Visible when <a href="#">92.1 Encoder 1 type = HTL 1</a> ) Selects the type of encoder.	Quadrature / uint16
	Quadrature	Quadrature encoder (with two channels, A and B).	0
	Single track	Single-track encoder (with one channel, A).  <b>Note:</b> With this setting, the measured speed value is always positive regardless of direction of rotation.	1
92.12	Resolver polepairs	(Visible when <a href="#">92.1 Encoder 1 type = Resolver</a> ) Defines the number of pole pairs of the resolver.	1 / uint16
	1...32	Number of resolver pole pairs.	1 = 1 / 1 = 1
92.12	Zero pulse enable	(Visible when <a href="#">92.1 Encoder 1 type = Absolute encoder</a> ) Enables the encoder zero pulse for the absolute encoder input (X42) of the FEN-11 interface module.  <b>Note:</b> No zero pulse exists with serial interfaces, ie. when parameter <a href="#">92.11 Absolute position source</a> is set to <a href="#">EnDat</a> , <a href="#">Hiperface</a> , <a href="#">SSI</a> or <a href="#">Tamagawa</a> .	Disable / uint16
	Disable	Zero pulse disabled.	0
	Enable	Zero pulse enabled.	1
92.12	Speed calculation mode	(Visible when <a href="#">92.1 Encoder 1 type = HTL 1</a> ) Selects the speed calculation mode.  *With a single-track encoder (parameter <a href="#">92.11 Pulse encoder type</a> is set to <a href="#">Single track</a> ), the speed is always positive.	Auto rising / uint16

## 522 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b								
	A&B all	<p>Channels A and B: Rising and falling edges are used for speed calculation.</p> <p>*Channel B: Defines the direction of rotation.</p> <p><b>Note:</b> With a single-track encoder (parameter <a href="#">92.11 Pulse encoder typee</a>, this setting acts like setting <a href="#">A all</a>.</p>	0								
	A all	<p>Channel A: Rising and falling edges are used for speed calculation.</p> <p>*Channel B: Defines the direction of rotation.</p>	1								
	A rising	<p>Channel A: Rising edges are used for speed calculation.</p> <p>*Channel B: Defines the direction of rotation.</p>	2								
	A falling	<p>Channel A: Falling edges are used for speed calculation.</p> <p>*Channel B: Defines the direction of rotation.</p>	3								
	Auto rising	<p>One of the above modes is selected automatically depending on the pulse frequency as follows:</p> <table border="1" data-bbox="340 639 818 855"> <thead> <tr> <th data-bbox="340 639 583 708">Pulse frequency of the channel(s)</th> <th data-bbox="583 639 818 708">Used mode</th> </tr> </thead> <tbody> <tr> <td data-bbox="340 708 583 759">&lt; 2442 Hz</td> <td data-bbox="583 708 818 759"><a href="#">A&amp;B all</a></td> </tr> <tr> <td data-bbox="340 759 583 810">2442...4884 Hz</td> <td data-bbox="583 759 818 810"><a href="#">A all</a></td> </tr> <tr> <td data-bbox="340 810 583 855">&gt; 4884 Hz</td> <td data-bbox="583 810 818 855"><a href="#">A rising</a></td> </tr> </tbody> </table>	Pulse frequency of the channel(s)	Used mode	< 2442 Hz	<a href="#">A&amp;B all</a>	2442...4884 Hz	<a href="#">A all</a>	> 4884 Hz	<a href="#">A rising</a>	4
Pulse frequency of the channel(s)	Used mode										
< 2442 Hz	<a href="#">A&amp;B all</a>										
2442...4884 Hz	<a href="#">A all</a>										
> 4884 Hz	<a href="#">A rising</a>										
	Auto falling	<p>One of the above modes is selected automatically depending on the pulse frequency as follows:</p> <table border="1" data-bbox="340 920 818 1136"> <thead> <tr> <th data-bbox="340 920 583 989">Pulse frequency of the channel(s)</th> <th data-bbox="583 920 818 989">Used mode</th> </tr> </thead> <tbody> <tr> <td data-bbox="340 989 583 1040">&lt; 2442 Hz</td> <td data-bbox="583 989 818 1040"><a href="#">A&amp;B all</a></td> </tr> <tr> <td data-bbox="340 1040 583 1091">2442...4884 Hz</td> <td data-bbox="583 1040 818 1091"><a href="#">A all</a></td> </tr> <tr> <td data-bbox="340 1091 583 1136">&gt; 4884 Hz</td> <td data-bbox="583 1091 818 1136"><a href="#">A falling</a></td> </tr> </tbody> </table>	Pulse frequency of the channel(s)	Used mode	< 2442 Hz	<a href="#">A&amp;B all</a>	2442...4884 Hz	<a href="#">A all</a>	> 4884 Hz	<a href="#">A falling</a>	5
Pulse frequency of the channel(s)	Used mode										
< 2442 Hz	<a href="#">A&amp;B all</a>										
2442...4884 Hz	<a href="#">A all</a>										
> 4884 Hz	<a href="#">A falling</a>										
92.13	Position data width	<p>(Visible when <a href="#">92.1 Encoder 1 type</a> = <a href="#">Absolute encoder</a>) Defines the number of bits used to indicate position within one revolution. For example, a setting of 15 bits corresponds to 32768 positions per revolution.</p> <p>The value is used when parameter <a href="#">92.11 Absolute position source</a> is set to <a href="#">EnDat</a>, <a href="#">Hiperface</a> or <a href="#">SSI</a>. When parameter <a href="#">92.11 Absolute position source</a> is set to <a href="#">Tamagawa</a>, this parameter is internally set to 17.</p> <p><b>Note:</b> With an EnDat or HIPERFACE encoder and FEN-11 FPGA version VIE12200 or later, this parameter is automatically set upon validation of encoder settings (<a href="#">91.10 Encoder parameter refresh</a>).</p>	0 / uint16								

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	0...32	Number of bits used in position indication within one revolution.	1 = 1 / 1 = 1
92.13	Position estimation enable	(Visible when <a href="#">92.1 Encoder 1 type = HTL 1</a> ) Selects whether position estimation is used with encoder 1 to increase position data resolution or not.	Enable / uint16
	Disable	Measured position used. (The resolution is 4 × pulses per revolution for quadrature encoders, 2 × pulses per revolution for single-track encoders.)	0
	Enable	Estimated position used. (Uses position interpolation; extrapolated at the time of data request.)	1
92.14	Revolution data width	(Visible when <a href="#">92.1 Encoder 1 type = Absolute encoder</a> ) Defines the number of bits used in revolution counting with a multiturn encoder. For example, a setting of 12 bits would support counting up to 4096 revolutions.  The value is used when parameter <a href="#">92.11 Absolute position source</a> is set to <a href="#">EnDat</a> , <a href="#">Hiperface</a> or <a href="#">SSI</a> . When parameter <a href="#">92.11 Absolute position source</a> is set to <a href="#">Tamagawa</a> , setting this parameter to a non-zero value activates multiturn data requesting.  <b>Note:</b> With an EnDat or HIPERFACE encoder and FEN-11 FPGA version VIE12200 or later, this parameter is automatically set upon validation of encoder settings ( <a href="#">91.10 Encoder parameter refresh</a> ).	0 / uint16
	0...32	Number of bits used in revolution count.	1 = 1 / 1 = 1
92.14	Speed estimation enable	(Visible when <a href="#">92.1 Encoder 1 type = HTL 1</a> ) Selects whether calculated or estimated speed is used.  Estimation increases the speed ripple in steady state operation, but improves the dynamics.  <b>Note:</b> This parameter is not effective with FEN-xx modules with FPGA version VIEx 2000 or later.	Disable / uint16
	Disable	Last calculated speed used. (The calculation interval is 62.5 microseconds to 4 milliseconds.)	0
	Enable	Estimated speed (estimated at the time of data request) is used.	1
92.15	Transient filter	(Visible when <a href="#">92.1 Encoder 1 type = HTL 1</a> ) Activates transient filtering for the encoder (changes in direction of rotation are ignored above the selected pulse frequency).	4880Hz / uint16
	4880Hz	Change in direction of rotation allowed below 4880 Hz.	0
	2440Hz	Change in direction of rotation allowed below 2440 Hz.	1
	1220Hz	Change in direction of rotation allowed below 1220 Hz.	2
	Disabled	Change in direction of rotation allowed at any pulse frequency.	3
92.17	Accepted pulse freq of encoder 1	(Visible when <a href="#">92.1 Encoder 1 type = HTL 1</a> ) Defines the maximum pulse frequency of encoder 1.	0 kHz / uint16

## 524 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	0...300 kHz	Pulse frequency.	1 = 1 kHz / 1 = 1 kHz
92.21	Encoder cable fault mode	(Visible when <a href="#">92.1 Encoder 1 type = HTL 1</a> ) Selects which encoder cable channels and wires are monitored for wiring faults.	A, B / uint16
	A+, A-, B+, B-, Z+, Z-	A and B.	0
	A, B, Z	A, B and Z.	1
	A+, A-, B+, B-	A+, A-, B+ and B-.	2
	A+, A-, B+, B-, Z+, Z-	A+, A-, B+, B-, Z+ and Z-.	3
92.24	Pulse edge filtering	(Visible when <a href="#">92.1 Encoder 1 type = HTL</a> ) Enables pulse edge filtering. Pulse edge filtering can improve the reliability of measurements especially from encoders with a single-ended connection.  <b>Note:</b> Pulse edge filtering is only supported by FEN-31 modules with FPGA version VIE3 2200 or later.  <b>Note:</b> Pulse edge filtering decreases the maximum pulse frequency. With 2 $\mu$ s filtering time, the maximum pulse frequency is 200 kHz.	No filtering / uint16
	No filtering	Filtering disabled.	0
	1 $\mu$ s	Filtering time: 1 microsecond.	1
	2 $\mu$ s	Filtering time: 2 microseconds.	2
92.30	Serial link mode	(Visible when <a href="#">92.1 Encoder 1 type = Absolute encoder</a> ) Selects the serial link mode with an EnDat or SSI encoder.	Initial position / uint16
	Initial position	Single position transfer mode (initial position).	0
	Continuous	Continuous position data transfer mode.  <b>Note:</b> Motor control is forced internally as a open loop and estimated speed used.	1
	Continuous speed and position	Continuous speed and position data transfer mode. This setting is intended for EnDat 2.2 encoders without sin/cos signals.  <b>Note:</b> This setting requires an FEN-11 interface revision H or later.	2
92.31	EnDat max calculation time	(Visible when <a href="#">92.1 Encoder 1 type = Absolute encoder</a> ) Selects the maximum encoder calculation time for an EnDat encoder.  <b>Note:</b> This parameter needs to be set only when an EnDat encoder is used in continuous mode, ie. without incremental sin/cos signals (supported only as encoder 1). See also parameter <a href="#">92.30 Serial link mode</a> .	50 ms / uint16
	10 us	10 microseconds.	0
	100 us	100 microseconds.	1

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	1 ms	1 millisecond.	2
	50 ms	50 milliseconds.	3
92.32	SSI cycle time	(Visible when <a href="#">92.1 Encoder 1 type = Absolute encoder</a> ) Selects the transmission cycle for an SSI encoder.  <b>Note:</b> This parameter needs to be set only when an SSI encoder is used in continuous mode, ie. without incremental sin/cos signals (supported only as encoder 1). See also parameter <a href="#">92.30 Serial link mode</a> .	100 us / uint16
	50 us	50 microseconds.	0
	100 us	100 microseconds.	1
	200 us	200 microseconds.	2
	500 us	500 microseconds.	3
	1 ms	1 millisecond.	4
	2 ms	2 milliseconds.	5
92.33	SSI clock cycles	(Visible when <a href="#">92.1 Encoder 1 type = Absolute encoder</a> ) Defines the length of an SSI message. The length is defined as the number of clock cycles. The number of cycles can be calculated by adding 1 to the number of bits in an SSI message frame.	2 / uint16
	2...127	SSI message length.	- / 1 = 1
92.34	SSI position msb	(Visible when <a href="#">92.1 Encoder 1 type = Absolute encoder</a> ) With an SSI encoder, defines the location of the MSB (most significant bit) of the position data within an SSI message.	1 / uint16
	1...126	Position data MSB location (bit number).	- / 1 = 1
92.35	SSI revolution msb	(Visible when <a href="#">92.1 Encoder 1 type = Absolute encoder</a> ) With an SSI encoder, defines the location of the MSB (most significant bit) of the revolution count within an SSI message.	1 / uint16
	1...126	Revolution count MSB location (bit number).	- / 1 = 1
92.36	SSI data format	(Visible when <a href="#">92.1 Encoder 1 type = Absolute encoder</a> ) Selects the data format for an SSI encoder.	Binary / uint16
	Binary	Binary code.	0
	Gray	Gray code.	1
92.37	SSI baud rate	(Visible when <a href="#">92.1 Encoder 1 type = Absolute encoder</a> ) Selects the baud rate for an SSI encoder.	100 kBit/s / uint16
	10 kBit/s	10 kbit/s.	0
	50 kBit/s	50 kbit/s.	1
	100 kBit/s	100 kbit/s.	2
	200 kBit/s	200 kbit/s.	3
	500 kBit/s	500 kbit/s.	4
	1000 kBit/s	1000 kbit/s.	5

## 526 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
92.40	SSI zero phase	(Visible when <a href="#">92.1 Encoder 1 type = Absolute encoder</a> ) Defines the phase angle within one sine/cosine signal period that corresponds to the value of zero on the SSI serial link data. The parameter is used to adjust the synchronization of the SSI position data and the position based on sine/cosine incremental signals. Incorrect synchronization may cause an error of $\pm 1$ incremental period.  <b>Note:</b> This parameter needs to be set only when an SSI encoder is used in initial position mode (see parameter <a href="#">92.30 Serial link mode</a> ).	315-45 deg / uint16
	315-45 deg	315-45 degrees.	0
	45-135 deg	45-135 degrees.	1
	135-225 deg	135-225 degrees.	2
	225-315 deg	225-315 degrees.	3
92.45	Hiperface parity	(Visible when <a href="#">92.1 Encoder 1 type = Absolute encoder</a> ) Defines the use of parity and stop bits with a HIPERFACE encoder.  Typically this parameter need not be set.	Odd / uint16
	Odd	Odd parity indication bit, one stop bit.	0
	Even	Even parity indication bit, one stop bit.	1
92.46	Hiperface baud rate	(Visible when <a href="#">92.1 Encoder 1 type = Absolute encoder</a> ) Defines the transfer rate of the link with a HIPERFACE encoder.  Typically this parameter need not be set.	4800 bits/s / uint16
	4800 bits/s	4800 bit/s.	0
	9600 bits/s	9600 bit/s.	1
	19200 bits/s	19200 bit/s.	2
	38400 bits/s	38400 bit/s.	3
92.47	Hiperface node address	(Visible when <a href="#">92.1 Encoder 1 type = Absolute encoder</a> ) Defines the node address for a HIPERFACE encoder.  Typically this parameter need not be set.	64 / uint16
	0...255	HIPERFACE encoder node address.	- / 1 = 1

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
93	Encoder 2 configuration	<p>Settings for encoder 2.</p> <p><b>Note:</b> The contents of the parameter group vary according to the selected encoder type.</p> <p><b>Note:</b> It is recommended that encoder connection 1 (group <a href="#">92 Encoder 1 configuration</a>) is used whenever possible since the data received through that interface is fresher than the data received through connection 2 (this group).</p>	
93.1	Encoder 2 type	Selects the type of encoder/resolver 2.	None configured / uint16
	None configured	None.	0
	TTL	TTL. Module type (input): FEN-01 (X31), FEN-11 (X41) or FEN-21 (X51).	1
	TTL+	TTL+. Module type (input): FEN-01 (X32).	2
	Absolute encoder	Absolute encoder. Module type (input): FEN-11 (X42).	3
	Resolver	Resolver. Module type (input): FEN-21 (X52).	4
	HTL	HTL. Module type (input): FEN-31 (X82).	5
	HTL 1	HTL. Module type (input): FSE-31 (X31).	6
	HTL 2	HTL. Module type (input): FSE-31 (X32). Not supported at the time of publication.	7
93.2	Encoder 2 source	Selects the interface module that the encoder is connected to. (The physical locations and types of encoder interface modules are defined in parameter group <a href="#">91 Encoder module settings</a> .)	Module 1 / uint16
	Module 1	Interface module 1.	1
	Module 2	Interface module 2.	2
93.10	Excitation signal frequency	(Visible when <a href="#">93.1 Encoder 2 type</a> = <a href="#">Resolver</a> ) See parameter <a href="#">92.10 Excitation signal frequency</a> .	- / uint16
93.10	Sine/cosine number	(Visible when <a href="#">93.1 Encoder 2 type</a> = <a href="#">Absolute encoder</a> ) See parameter <a href="#">92.10 Sine/cosine number</a> .	- / uint16
93.10	Pulses/revolution	(Visible when <a href="#">93.1 Encoder 2 type</a> = <a href="#">HTL 1</a> ) See parameter <a href="#">92.10 Pulses/revolution</a> .	- / uint16
93.11	Excitation signal amplitude	(Visible when <a href="#">93.1 Encoder 2 type</a> = <a href="#">Resolver</a> ) See parameter <a href="#">92.11 Excitation signal amplitude</a> .	- / uint16
93.11	Absolute position source	(Visible when <a href="#">93.1 Encoder 2 type</a> = <a href="#">Absolute encoder</a> ) See parameter <a href="#">92.11 Absolute position source</a> .	None / uint16
93.11	Pulse encoder type	(Visible when <a href="#">93.1 Encoder 2 type</a> = <a href="#">HTL 1</a> ) See parameter <a href="#">92.11 Pulse encoder type</a> .	Quadrature / uint16
93.12	Resolver polepairs	(Visible when <a href="#">93.1 Encoder 2 type</a> = <a href="#">Resolver</a> ) See parameter <a href="#">92.12 Resolver polepairs</a> .	- / uint16
93.12	Zero pulse enable	(Visible when <a href="#">93.1 Encoder 2 type</a> = <a href="#">Absolute encoder</a> ) See parameter <a href="#">92.12 Zero pulse enable</a> .	Disable / uint16

## 528 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
93.12	Speed calculation mode	(Visible when 93.1 Encoder 2 type = HTL 1) See parameter 92.12 Speed calculation mode.	Auto rising / uint16
93.13	Position data width	(Visible when 93.1 Encoder 2 type = Absolute encoder) See parameter 92.13 Position data width.	- / uint16
93.13	Position estimation enable	(Visible when 93.1 Encoder 2 type = HTL 1) See parameter 92.13 Position estimation enable.	Enable / uint16
93.14	Revolution data width	(Visible when 93.1 Encoder 2 type = Absolute encoder) See parameter 92.14 Revolution data width.	- / uint16
93.14	Speed estimation enable	(Visible when 93.1 Encoder 2 type = HTL 1) See parameter 92.14 Speed estimation enable.	Disable / uint16
93.15	Transient filter	(Visible when 93.1 Encoder 2 type = HTL 1) See parameter 92.15 Transient filter.	4880Hz / uint16
93.17	Accepted pulse freq of encoder 2	(Visible when 93.1 Encoder 2 type = HTL 1) See parameter 92.17 Accepted pulse freq of encoder 1.	- / uint16
93.21	Encoder cable fault mode	(Visible when 93.1 Encoder 2 type = HTL 1) See parameter 92.21 Encoder cable fault mode.	A, B / uint16
93.24	Pulse edge filtering	(Visible when 93.1 Encoder 2 type = HTL) See parameter 92.24 Pulse edge filtering.	No filtering / uint16
93.30	Serial link mode	(Visible when 93.1 Encoder 2 type = Absolute encoder) See parameter 92.30 Serial link mode.	Initial position / uint16
93.31	EnDat calc time	(Visible when 93.1 Encoder 2 type = Absolute encoder) See parameter 92.31 EnDat max calculation time.	50 ms / uint16
93.32	SSI cycle time	(Visible when 93.1 Encoder 2 type = Absolute encoder) See parameter 92.32 SSI cycle time.	100 us / uint16
93.33	SSI clock cycles	(Visible when 93.1 Encoder 2 type = Absolute encoder) See parameter 92.33 SSI clock cycles.	- / uint16
93.34	SSI position msb	(Visible when 93.1 Encoder 2 type = Absolute encoder) See parameter 92.34 SSI position msb.	- / uint16
93.35	SSI revolution msb	(Visible when 93.1 Encoder 2 type = Absolute encoder) See parameter 92.35 SSI revolution msb.	- / uint16
93.36	SSI data format	(Visible when 93.1 Encoder 2 type = Absolute encoder) See parameter 92.36 SSI data format.	Binary / uint16
93.37	SSI baud rate	(Visible when 93.1 Encoder 2 type = Absolute encoder) See parameter 92.37 SSI baud rate.	100 kBit/s / uint16
93.40	SSI zero phase	(Visible when 93.1 Encoder 2 type = Absolute encoder) See parameter 92.40 SSI zero phase.	315-45 deg / uint16
93.45	Hiperface parity	(Visible when 93.1 Encoder 2 type = Absolute encoder) See parameter 92.45 Hiperface parity.	Odd / uint16
93.46	Hiperface baud rate	(Visible when 93.1 Encoder 2 type = Absolute encoder) See parameter 92.46 Hiperface baud rate.	4800 bits/s / uint16
93.47	Hiperface node address	(Visible when 93.1 Encoder 2 type = Absolute encoder) See parameter 92.47 Hiperface node address.	- / uint16



No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
94	LSU control	<p>Control of the supply unit of the drive, such as DC voltage and reactive power reference.</p> <p>Note that the references defined here must also be selected as the reference source in the supply control program to be effective.</p> <p>This group is only visible when supply unit control has been activated by parameter <a href="#">95.20 HW options word 1</a>.</p> <p>See also section <a href="#">Control of a supply unit (LSU) (page 44)</a>.</p>	
94.1	LSU Control	<p>Enables/disables the internal INU-LSU state machine.</p> <p>When the state machine is enabled, the inverter unit (INU) controls the supply unit (LSU) and prevents the inverter unit from starting until the supply unit is ready.</p> <p>When the state machine is disabled, the status of the supply unit is ignored by the inverter unit.</p>	On / uint16
	Off	INU-LSU state machine disabled.	0
	On	INU-LSU state machine enabled.	1
94.2	LSU panel communication	<p>Enables/disables control panel and PC tool access to the supply unit (line-side converter) via the inverter unit (motor-side converter).</p> <p><b>Note:</b> This feature is only supported by the following drives:</p> <ul style="list-style-type: none"> <li>• ACS880-11</li> <li>• ACS880-31</li> <li>• ACS880-17 based on an integrated drive module</li> <li>• ACS880-37 based on an integrated drive module.</li> </ul>	Disable / uint16
	Disable	Control panel and PC tool access to supply unit via inverter unit disabled.	0
	Enable	Control panel and PC tool access to supply unit via inverter unit enabled.	1
94.4	INU-LSU status word profile	<p><i>(Only visible with certain drive types.)</i></p> <p>Selects the functionality of bit 1 of <a href="#">6.11 Main status word</a>.</p>	ABB single drives standard SW / uint16
	ABB single drives standard SW	The drive sets bit 1 of <a href="#">6.11 Main status word</a> after the DC link is charged.	0
	Backwards compatible SW	<p>The drive sets bit 1 of <a href="#">6.11 Main status word</a> after the main contactor is closed and the supply unit (line-side converter) is running.</p> <p>This setting can be used eg. when installing the drive into an existing set-up with other ACS880 as well as ACS800 drives.</p>	1


## 530 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
94.5	LSU external start command	<p><i>(Only visible when IGBT supply unit control activated by 95.20)</i></p> <p>Selects the source for LSU external start command.</p> <p>This parameter is visible only if INU-ISU communication is enabled in 95.20 bit 15.</p> <p><b>Note:</b> If LSU is stopped using parameter 94.5 <i>LSU external start command</i>, LSU continues to run during the time defined by 94.11 <i>LSU stop delay</i>.</p>	Not selected / uint32
	Not selected	0	0
	Selected	1	1
	DI1	Digital input DI1 (10.2 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.2 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.2 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.2 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.2 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.2 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1 (11.2 DIO delayed status, bit 0).	10
	DIO2	Digital input/output DIO2 (11.2 DIO delayed status, bit 1).	11
	DIIL	DIIL input (10.2 DI delayed status, bit 15).	30
94.10	LSU max charging time	Defines the maximum time the supply unit (LSU) is allowed for charging before a fault, 7584 <i>LSU charge failed</i> is generated.	15 s / uint16
	0...65535 s	Maximum charging time.	1 = 1 s / 1 = 1 s
94.11	LSU stop delay	Defines a stop delay for the supply unit. This parameter can be used to delay the opening of the main breaker/contactors when a restart is expected.	600.0 s / uint16
	0.0 ... 3600.0 s	Supply unit stop delay.	10 = 1 s / 10 = 1 s
94.20	DC voltage reference	<p><i>(Only visible when IGBT supply unit control activated by 95.20)</i></p> <p>Displays the DC voltage reference sent to the supply unit.</p> <p><b>Note:</b> This parameter is read-only.</p>	- / real32
	0.0 ... 2000.0 V	DC voltage reference sent to supply unit.	10 = 1 V / 10 = 1 V
94.21	DC voltage ref source	<p><i>(Only visible when IGBT supply unit control activated by 95.20)</i></p> <p>Selects the source of the DC voltage reference to be sent to the supply unit.</p>	User ref / uint32
	Zero	None.	0
	User ref	94.22 <i>User DC voltage reference</i> .	1

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	Other [bit]	Source selection (see <a href="#">Terms and abbreviations (page 134)</a> ).	-
94.22	User DC voltage reference	<i>(Only visible when IGBT supply unit control activated by 95.20)</i> Defines the DC voltage reference for the supply unit when <a href="#">94.21 DC voltage ref source</a> is set to <a href="#">User ref</a> .	0.0 V / real32
	0.0 ... 2000.0 V	User DC reference.	10 = 1 V / 10 = 1 V
94.30	Reactive power reference	<i>(Only visible when IGBT supply unit control activated by 95.20)</i> Displays the reactive power reference sent to the supply unit. <b>Note:</b> This parameter is read-only.	- / real32
	-3276.8 ... 3276.7 kVAr	Reactive power reference sent to the supply unit.	10 = 1 kVAr / 10 = 1 kVAr
94.31	Reactive power ref source	<i>(Only visible when IGBT supply unit control activated by 95.20)</i> Selects the source of the reactive power reference to be sent to the supply unit.	User ref / uint32
	Zero	None.	0
	User ref	<a href="#">94.32 User reactive power reference</a> .	1
	Other [bit]	Source selection (see <a href="#">Terms and abbreviations (page 134)</a> ).	-
94.32	User reactive power reference	<i>(Only visible when IGBT supply unit control activated by 95.20)</i> Defines the reactive power reference for the supply unit when <a href="#">94.31 Reactive power ref source</a> is set to <a href="#">User ref</a> .	0.0 kVAr / real32
	-3276.8 ... 3276.7 kVAr	User reactive power reference.	10 = 1 kVAr / 10 = 1 kVAr
94.40	Power mot limit on net loss	Defines the maximum shaft power for motoring mode upon a supply network failure when IGBT supply unit control is active (bit 15 of <a href="#">95.20 HW options word 1</a> is on). The value is given in percent of nominal motor power. <b>Note:</b> With a diode supply unit (bit 11 of <a href="#">95.20</a> is on), the motoring shaft power is limited to 2% upon a network failure regardless of this parameter.	600.00 % / real32
	0.00 ... 600.00 %	Maximum shaft power for motoring mode upon a supply network failure.	1 = 1 % / 100 = 1 %


## 532 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
94.41	Power gen limit on net loss	Defines the maximum shaft power for generating upon a supply network failure when supply unit control is active (bit 15 of <a href="#">95.20 HW options word 1</a> is on). The value is given in percent of nominal motor power.  <b>Note:</b> With a diode supply unit (bit 11 of <a href="#">95.20</a> is on), the motoring shaft power is limited to 2% upon a network failure regardless of this parameter.	-600.00 % / real32
	-600.00 ... 0.00 %	Maximum shaft power for generating mode upon a supply network failure.	1 = 1 % / 100 = 1 %
94.50	LSU weak grid enable	Enables LSU weak grid detection on ACS880-11/31/14/34/17/37 drives to improve stability in weak grids and when the drive is supplied by a generator.  <b>Note:</b> This parameter can be used only with ACS880-11/31/14/34/17/37 frames R3, R6, R8, and R11.	Not selected / uint32
	Not selected	0	0
	Selected	1	1
	DI1	Digital input DI1 ( <a href="#">10.2 DI delayed status</a> , bit 0).	2
	DI2	Digital input DI2 ( <a href="#">10.2 DI delayed status</a> , bit 1).	3
	DI3	Digital input DI3 ( <a href="#">10.2 DI delayed status</a> , bit 2).	4
	DI4	Digital input DI4 ( <a href="#">10.2 DI delayed status</a> , bit 3).	5
	DI5	Digital input DI5 ( <a href="#">10.2 DI delayed status</a> , bit 4).	6
	DI6	Digital input DI6 ( <a href="#">10.2 DI delayed status</a> , bit 5).	7
	DIO1	Digital input/output DIO1 ( <a href="#">11.2 DIO delayed status</a> , bit 0).	10
	DIO2	Digital input/output DIO2 ( <a href="#">11.2 DIO delayed status</a> , bit 1).	11
	Other [bit]	See <a href="#">Terms and abbreviations</a> (page 134).	-

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
95	HW configuration	Various hardware-related settings.	
95.1	Supply voltage	<p>Selects the supply voltage range. This parameter is used by the drive to determine the nominal voltage of the supply network. The parameter also affects the current ratings and the DC voltage control functions (trip and brake chopper activation limits) of the drive.</p> <p> <b>WARNING!</b> An incorrect setting may cause the motor to rush uncontrollably, or the brake chopper or resistor to overload.</p> <p><b>Note:</b> The selections shown depend on the hardware of the drive. If only one voltage range is valid for the drive in question, it is selected by default.</p> <p><b>Note:</b> This parameter cannot be changed while the drive is running.</p>	Not given / uint16
	Not given	No voltage range selected. The drive will not start modulating before a range is selected.	0
	208...240 V	208...240 V	1
	380...415 V	380...415 V	2
	440...480 V	440...480 V	3
	500 V	500 V	4
	525...600 V	525...600 V	5
	660...690 V	660...690 V	6
95.2	Adaptive voltage limits	<p>Enables adaptive voltage limits.</p> <p>Adaptive voltage limits can be used if, for example, an IGBT supply unit is used to raise the DC voltage level. If the communication between the inverter and the IGBT supply unit is active (<a href="#">95.20 HW options word 1</a>), the voltage limits are related to the DC voltage reference transmitted to the supply unit (<a href="#">94.20 DC voltage reference</a>) assuming that the reference is high enough. Otherwise, the limits are calculated based on the measured DC voltage at the end of the pre-charging sequence.</p> <p>This function is also useful if the AC supply voltage to the drive is high, as the warning levels are raised accordingly.</p> <p>*Affected by <a href="#">95.20 HW options word 1</a>, bit 15.</p>	Disable; Enable ( <a href="#">95.20 b15</a> ) / uint16
	Disable	Adaptive voltage limits disabled.	0
	Enable	Adaptive voltage limits enabled.	1
95.4	Control board supply	<p>Specifies how the control unit of the drive is powered.</p> <p>*The default value depends on the type of control unit and the setting of parameter <a href="#">95.20 HW options word 1</a>, bit 4.</p>	Internal 24V (ZCU); External 24V (BCU; <a href="#">95.20 b4</a> ) / uint16

## 534 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	Internal 24V	<p>The drive control unit is powered from the drive power unit it is connected to.</p> <p><b>Note:</b> If reduced run is required, select <a href="#">External 24V</a> or <a href="#">Redundant external 24V</a> instead.</p>	0
	External 24V	<p>The drive control unit is powered from an external power supply. The drive power unit and power unit link faults are masked when the drive is in stopped state, so the main circuit can be powered down without faults while the control unit is powered.</p>	1
	Redundant external 24V	<p><i>(Type BCU control units only)</i></p> <p>The drive control unit is powered from two redundant external power supplies. The loss of one of the supplies generates a warning (<a href="#">AFEC External power signal missing</a>). The drive power unit and power unit link faults are masked when the drive is in stopped state, so the main circuit can be powered down without faults while the control unit is powered.</p>	2

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
95.8	DC switch monitoring	<p><i>(Only visible with a ZCU control unit)</i></p> <p>Enables/disables DC switch monitoring via the DIIL input. This setting is intended for use with inverter modules with an internal charging circuit that are connected to the DC bus through a DC switch.</p> <p>An auxiliary contact of the DC switch must be wired to the DIIL input so that the input switches off when the DC switch is opened.</p>  <p>If the DC switch is opened with the inverter running, the inverter is given a coast-to-stop command, and its charging circuit activated.</p> <p>Starting the inverter is prevented until the DC switch is closed and the DC circuit in the inverter unit recharged.</p> <p><b>Note:</b> By default, DIIL is the input for the Run enable signal. Adjust <a href="#">20.12 Run enable 1 source</a> if necessary.</p> <p><b>Note:</b> An internal charging circuit is standard on some inverter module types but optional on others; check with your local ABB representative.</p>	Disable; Enable (95.20 b5) / uint16
	Disable	DC switch monitoring through the DIIL input disabled.	0
	Enable	DC switch monitoring through the DIIL input enabled.	1

## 536 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
95.9	Switch fuse controller	<p><i>(Only visible with a BCU control unit)</i></p> <p>Activates communication to a BSFC charging controller. This setting is intended for use with inverter modules that are connected to a DC bus through a DC switch/charging circuit controlled by a charging controller. On units without a DC switch, this parameter should be set to <a href="#">Disable</a>.</p> <p>The charging controller monitors the charging of the inverter unit, and sends an enable command when the charging has finished (ie. DC switch is closed after the 'charging OK' lamp lights, and charging switch opened).</p> <p>For more information, see BSFC documentation.</p>	- / uint16
	Disable	Communication with BSFC disabled.	0
	Enable	Communication with BSFC enabled.	1
95.12	Reduced run mask	<p><i>(Only visible with BCU control unit)</i></p> <p>Specifies which converter modules have been removed from the converter configuration. A value other than 0 activates the reduced run function.</p> <p>See section <a href="#">Reduced run function (page 106)</a>.</p>	0000h / uint16
b0	Module 1 removed	Module 1 has been removed.	
b1	Module 2 removed	Module 2 has been removed.	
b2	Module 3 removed	Module 3 has been removed.	
b3	Module 4 removed	Module 4 has been removed.	
b4	Module 5 removed	Module 5 has been removed.	
b5	Module 6 removed	Module 6 has been removed.	
b6	Module 7 removed	Module 7 has been removed.	
b7	Module 8 removed	Module 8 has been removed.	
b8	Module 9 removed	Module 9 has been removed.	
b9	Module 10 removed	Module 10 has been removed.	
b10	Module 11 removed	Module 11 has been removed.	
b11	Module 12 removed	Module 12 has been removed.	
b12...15	Reserved		
	0000h...FFFFh		1 = 1 / 1 = 1




No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
95.13	Reduced run mode	<p><i>(Only visible with a BCU control unit)</i></p> <p>Specifies the number of inverter modules available.</p> <p>This parameter must be set if reduced run is required. A value other than 0 activates the reduced run function.</p> <p>If the control program cannot detect the number of modules specified by this parameter, a fault (5695 <a href="#">Reduced run</a>) is generated.</p> <p>See section <a href="#">Reduced run function (page 106)</a>.</p> <p>0 = Reduced run disabled 1...12 = Number of modules available</p> <p><b>Note:</b> This parameter cannot be changed while the drive is running.</p>	- / uint16
	0...65535	Number of inverter modules available.	- / -
95.14	Connected modules	<p><i>(Only visible with a BCU control unit)</i></p> <p>Shows which of the parallel-connected inverter modules have been detected by the control program.</p> <p><b>Note:</b> This parameter is read-only.</p>	0000h / uint16
b0	Module 1	Module 1 has been detected.	
b1	Module 2	Module 2 has been detected.	
b2	Module 3	Module 3 has been detected.	
b3	Module 4	Module 4 has been detected.	
b4	Module 5	Module 5 has been detected.	
b5	Module 6	Module 6 has been detected.	
b6	Module 7	Module 7 has been detected.	
b7	Module 8	Module 8 has been detected.	
b8	Module 9	Module 9 has been detected.	
b9	Module 10	Module 10 has been detected.	
b10	Module 11	Module 11 has been detected.	
b11	Module 12	Module 12 has been detected.	
b12...15	Reserved		
	0000h...FFFFh		1 = 1 / 1 = 1


## 538 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
95.15	Special HW settings	<p>Contains hardware-related settings that can be enabled and disabled by toggling the specific bits.</p> <p><b>Note:</b> The installation of the hardware specified by this parameter may require derating of drive output, or impose other limitations. Refer to the hardware manual of the drive.</p> <p><b>Note:</b> This parameter cannot be changed while the drive is running.</p>	- / uint16
b0	EX motor	<p>1 = The driven motor is an Ex motor provided by ABB for potentially explosive atmospheres. This sets the required minimum switching frequency for ABB Ex motors.</p> <p><b>Note:</b> For non-ABB Ex motors, contact your local ABB representative.</p>	
b1	ABB sine filter	1 = An ABB sine filter is connected to the output of the drive/inverter.	
b2	High speed mode	1 = Minimum switching frequency limit adaptation to output frequency active. This setting improves control performance at high output frequencies (typically above 120 Hz).	
b3	Custom sine filter	1 = A custom sine filter is connected to the output of the drive/inverter. See also parameters <a href="#">97.1</a> , <a href="#">97.2</a> , <a href="#">99.18</a> , <a href="#">99.19</a> .	
b4...15	Reserved		
	0000h...FFFFh		1 = 1 / 1 = 1
95.16	Router mode	<p><i>(Only visible with a BCU control unit)</i></p> <p>Enables/disables router mode of the BCU control unit. When router mode is active, the PSL2 channels connected to another BCU (ie. those selected by <a href="#">95.17 Router channel config</a>) are routed to the power units (converter modules) connected to this BCU.</p> <p>See section <a href="#">Router mode for BCU control unit (page 109)</a>.</p> <p><b>Note:</b> This parameter cannot be changed while the drive is running.</p>	Off / uint32
	Off	Router mode inactive.	0
	On	Router mode active.	1
	Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
95.17	Router channel config	<p><i>(Only visible with a BCU control unit)</i></p> <p>Selects which PSL2 channels on the BCU control unit are connected to another BCU and routed to a local power unit.</p> <p><b>Note:</b> The local power units are to be connected to successive channels starting from CH1. The other BCU is then connected to one or more successive channels starting from the first free channel.</p> <p><b>Note:</b> The lowest channel selected in this parameter is routed to the local power unit with the lowest number, etc.</p> <p><b>Note:</b> There must be at least as many local power modules as there are routed channels.</p> <p><b>Note:</b> This parameter cannot be changed while the drive is running.</p> <p>See section <a href="#">Router mode for BCU control unit (page 109)</a>.</p>	- / uint16
b0	ch1	0	
b1	ch2	1 = Channel CH2 is routed to the local power unit (which is connected to CH1)	
b2	ch3	1 = Channel CH3 is routed to the local power unit (which is connected to CH1)	
b3	ch4	1 = Channel CH4 is routed to a local power unit	
b4	ch5	1 = Channel CH5 is routed to a local power unit	
b5	ch6	1 = Channel CH6 is routed to a local power unit	
b6	ch7	1 = Channel CH7 is routed to a local power unit	
b7	ch8	1 = Channel CH8 is routed to a local power unit	
b8	ch9	1 = Channel CH9 is routed to a local power unit	
b9	ch10	1 = Channel CH10 is routed to a local power unit	
b10	ch11	1 = Channel CH11 is routed to a local power unit	
b11	ch12	1 = Channel CH12 is routed to a local power unit	
b12...15	Reserved		
	0000h...FFFFh		1 = 1 / 1 = 1

## 540 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
95.20	HW options word 1	<p>Specifies hardware-related options that require differentiated parameter defaults. Activating a bit in this parameter makes the necessary changes in other parameters. For example, activating an emergency stop option reserves a digital input. In many cases, the differentiated parameters will also be write-protected.</p> <p>This parameter, as well as the changes in other parameters implemented by it, are not affected by a parameter restore.</p> <p> <b>WARNING!</b> After switching any bits in this word, recheck the values of the affected parameters.</p> <p><b>Note:</b> This parameter cannot be changed while the drive is running.</p> <p>*See section <a href="#">Control of a supply unit (LSU) (page 44)</a>.</p>	- / uint16
b0	Supply frequency 60 Hz	0 = 50 Hz; 1 = 60 Hz. Affects <a href="#">11.45</a> , <a href="#">11.59</a> , <a href="#">12.20</a> , <a href="#">13.18</a> , <a href="#">30.11</a> , <a href="#">30.12</a> , <a href="#">30.13</a> , <a href="#">30.14</a> , <a href="#">31.26</a> , <a href="#">31.27</a> , <a href="#">40.15</a> , <a href="#">40.37</a> , <a href="#">41.15</a> , <a href="#">41.37</a> , <a href="#">46.1</a> , <a href="#">46.2</a> .	
b1	Emergency stop Cat 0	1 = Emergency stop, Category 0, without FSO module. Affects <a href="#">21.4</a> , <a href="#">21.5</a> , <a href="#">23.11</a> .	
b2	Emergency stop Cat 1	1 = Emergency stop, Category 1, without FSO module. Affects <a href="#">10.24</a> , <a href="#">21.4</a> , <a href="#">21.5</a> , <a href="#">23.11</a> .	
b3	RO2 for -07 cabinet cooling fan	1 = Control of cabinet cooling fan (used only with specific ACS880-07 hardware). Affects <a href="#">10.27</a> , <a href="#">10.28</a> , <a href="#">10.29</a> .	
b4	Externally powered control unit	1 = Control unit powered externally. Affects <a href="#">95.4</a> . <i>(Only visible with a ZCU control unit)</i>	
b5	DC supply switch	1 = DC switch monitoring active. Affects <a href="#">20.12</a> , <a href="#">31.3</a> , <a href="#">95.8</a> . <i>(Only visible with a ZCU control unit)</i>	
b6	DOL motor switch	1 = Motor fan control active. Affects <a href="#">10.24</a> , <a href="#">35.100</a> , <a href="#">35.103</a> , <a href="#">35.104</a> .	
b7	xSFC-01fuse switch controller	1 = xSFC-01 fuse switch controller. Affects <a href="#">95.9</a> . <i>(Only visible with a BCU control unit)</i>	
b8	Service switch or PTC/Pt100 relay	1 = Service switch or PTC/Pt100 relay connected. Affects <a href="#">31.1</a> , <a href="#">31.2</a> .	
b9	Output contactor	1 = Output contactor present. Affects <a href="#">10.24</a> , <a href="#">20.12</a> .	
b10	Brake resistor, sine filter, IP54 fan	1 = Status (eg. thermal) switches connected to DIIL input. Affects <a href="#">20.11</a> , <a href="#">20.12</a> .	
b11	INU-DSU communication	*1 = Diode supply unit control by inverter unit active. Makes several parameters visible in groups <a href="#">6</a> , <a href="#">60</a> , <a href="#">61</a> , <a href="#">62</a> and <a href="#">94</a> . <i>(Only visible with a BCU control unit)</i>	
b12	Reserved		

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
b13	du/dt filter activation	1 = Active: An external du/dt filter is connected to the drive output. The setting will limit the output switching frequency. With inverter module frame sizes R5i to R7i, the fan of the module will be forced to full speed.  <b>Note:</b> This bit is to be left at 0 if the drive/inverter module is equipped with internal du/dt filtering (eg. frame R8i inverter modules with option +E205).	
b14	DOL fan activation	1 = The inverter unit consists of frame R8i modules with direct-on-line cooling fans (option +C188). Disables fan feedback monitoring and changes fan control to ON/OFF type.	
b15	INU-ISU communication	*1 = IGBT supply unit control by inverter unit active. Affects 31.23 and 95.2. Makes several parameters visible in groups 1, 5, 6, 7, 30, 31, 60, 61, 62, 94 and 96.  Bit 15 sets also 195.01 Supply voltage in ISU to the same value as 95.1 in INU is set.	
	0000h...FFFFh		1 = 1 / 1 = 1
95.21	HW options word 2	Specifies more hardware-related options that require differentiated parameter defaults. See parameter 95.20 HW options word 1.   <b>WARNING!</b> After switching any bits in this word, recheck the values of the affected parameters.  <b>Note:</b> This parameter cannot be changed while the drive is running.	- / uint16
b0	Dual use	1 = Dual use active. For drives with option +N8200. (Allows higher output speeds/frequencies and speed/frequency reference limits.)	
b1	SynRM	1 = Synchronous reluctance motor used. Affects 25.2, 25.3, 25.15, 99.3.	
b2	Salient PM	1 = Salient-pole permanent magnet motor used. Affects 25.2, 25.3, 25.15, 99.3.	
b3	LV Synchro	1 = Externally-excited synchronous motor used. Requires a license. Contact your local ABB representative for more information.	
b4	Aux fan 1 supervision	1 = Auxiliary fan 1 installed and supervised.	
b5	Aux fan 2 supervision	1 = Auxiliary fan 2 installed and supervised.	
b6...15	Reserved		
	0000h...FFFFh		1 = 1 / 1 = 1

## 542 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
95.30	Parallel type list filter	<i>(Only visible with a BCU control unit)</i> Filters the list of drive/inverter types listed by parameter <a href="#">95.31 Parallel type configuration</a> . <b>Note:</b> This parameter cannot be changed while the drive is running.	No filter / uint16
	No filter	All types listed.	1
	400 V	-3 (380...415 V) types listed.	2
	500 V	-5 (380...500 V) types listed.	3
	690 V	-7 (525...690 V) types listed.	4
	-7 LC (525-690V)	Liquid-cooled -7 (525...690 V) types listed.	5
95.31	Parallel type configuration	<i>(Only visible with a BCU control unit)</i> Defines the drive/inverter type if it consists of parallel-connected modules. If the drive/inverter consists of a single module, leave the value at <a href="#">Not selected</a> . <b>Note:</b> This parameter cannot be changed while the drive is running.	Not selected / uint16
	Not selected	The drive/inverter does not consist of parallel-connected modules, or type not selected.	0
	[Drive/inverter type]	Drive/inverter type consisting of parallel-connected modules.	-
95.40	Transformation ratio	Defines the ratio of the step-up transformer.	0.000 / real32
	0.000 ... 100.000	Step-up transformer ratio.	1000 = 1 / 1000 = 1

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
96	System	Language selection; access levels; macro selection; parameter save and restore; control unit reboot; user parameter sets; unit selection; data logger triggering; parameter checksum calculation; user lock.	
96.1	Language	<p>Selects the language of the parameter interface and other displayed information when viewed on the control panel.</p> <p><b>Note:</b> Not all languages listed below are necessarily supported.</p> <p><b>Note:</b> This parameter does not affect the languages visible in the Drive Composer PC tool. (Those are specified under View – Settings.)</p>	Not selected / uint16
	Deutsch	German.	1031
	Italiano	Italian.	1040
	Español	Spanish.	3082
	Português	Portuguese.	2070
	Nederlands	Dutch.	1043
	Français	French.	1036
	Dansk	Danish.	1030
	Suomi	Finnish.	1035
	Svenska	Swedish.	1053
	Русский	Russian.	1049
	Not selected	None.	0
	Polski	Polish.	1045
	Česky	Czech.	1029
	Chinese (Simplified, PRC)	Simplified Chinese.	2052
	Türkçe	Turkish.	1055
	Japanese	Japanese.	1041
	English	English.	1033

## 544 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
96.2	Pass code	<p>Pass codes can be entered into this parameter to activate further access levels (see parameter <a href="#">96.3 Access levels active</a>) or to configure the user lock.</p> <p>Entering "358" toggles the parameter lock, which prevents the changing of all other parameters through the control panel or the Drive Composer PC tool.</p> <p>Entering the user pass code (by default, "10000000") enables parameters <a href="#">96.100...96.102</a>, which can be used to define a new user pass code and to select the actions that are to be prevented.</p> <p>Entering an invalid pass code will close the user lock if open, i.e. hide parameters <a href="#">96.100...96.102</a>. After entering the code, check that the parameters are in fact hidden. If they are not, enter another (random) pass code.</p> <p>Entering several invalid pass codes introduces a delay before a new attempt can be made. Entering further invalid codes will progressively lengthen the delay.</p> <p><b>Note:</b> You must change the default user pass code to maintain a high level of cybersecurity. <u>Store the code in a safe place – the protection cannot be disabled even by ABB if the code is lost.</u></p> <p>See also section <a href="#">User lock (page 105)</a>.</p>	0 / uint32
	0...99999999	Pass code.	1 = 1
96.3	Access levels active	<p>Shows which access levels have been activated by pass codes entered into parameter <a href="#">96.2 Pass code</a>.</p> <p><b>Note:</b> This parameter is read-only.</p>	- / uint16
	b0 End user	End user.	
	b1 Service	Service.	
	b2 Advanced programmer	Advanced programmer.	
	b3 Reserved		
	b11 OEM access level 1	OEM access level 1.	
	b12 OEM access level 2	OEM access level 2.	
	b13 OEM access level 3	OEM access level 3.	
	b14 Parameter lock	Parameter lock.	
	b15 Reserved		
	0000h...FFFFh		1 = 1 / 1 = 1



No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
96.4	Macro select	<p>Selects the application macro. See chapter Application macros for more information.</p> <p>After a selection is made, the parameter reverts automatically to <a href="#">Done</a>.</p> <p><b>Note:</b> This parameter cannot be changed while the drive is running.</p>	Done / uint16
	Done	Macro selection complete; normal operation.	0
	Factory	Factory macro (see <a href="#">114</a> ).	1
	Hand/Auto	Hand/Auto macro (see page <a href="#">117</a> ).	2
	PID-CTRL	PID control macro (see page <a href="#">120</a> ).	3
	T-CTRL	Torque control macro (see page <a href="#">125</a> ).	4
	Sequence control	Sequential control macro (see page <a href="#">128</a> ).	5
	FIELDBUS	Reserved.	6
96.5	Macro active	<p>Shows which application macro is currently selected.</p> <p>To change the macro, use parameter <a href="#">96.4 Macro select</a>.</p>	Factory / uint16
	Factory	Factory macro (see <a href="#">114</a> ).	1
	Hand/Auto	Hand/Auto macro (see page <a href="#">117</a> ).	2
	PID-CTRL	PID control macro (see page <a href="#">120</a> ).	3
	T-CTRL	Torque control macro (see page <a href="#">125</a> ).	4
	Sequence control	Sequential control macro (see page <a href="#">128</a> ).	5
	FIELDBUS	Reserved.	6
96.6	Parameter restore	<p>Restores the original settings of the control program, i.e. parameter default values.</p> <p><b>Note:</b> This parameter cannot be changed while the drive is running.</p>	Done / uint16
	Done	Restoring is completed.	0
	Restore defaults	<p>All editable parameter values are restored to default values, except</p> <ul style="list-style-type: none"> <li>• motor data and ID run results</li> <li>• parameter <a href="#">31.42 Overcurrent fault limit</a></li> <li>• control panel/PC communication settings</li> <li>• I/O extension module settings</li> <li>• fieldbus adapter settings</li> <li>• encoder configuration data</li> <li>• application macro selection and the parameter defaults implemented by it</li> <li>• parameter <a href="#">95.21 HW options word 2</a></li> <li>• parameter <a href="#">95.9 Switch fuse controller</a></li> <li>• differentiated defaults implemented by parameters <a href="#">95.20 HW options word 1</a> and <a href="#">95.21 HW options word 2</a></li> <li>• user lock configuration parameters <a href="#">96.100 ... 96.102</a>.</li> </ul>	8

## 546 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	Clear all	<p>All editable parameter values are restored to default values, except</p> <ul style="list-style-type: none"> <li>control panel/PC communication settings</li> <li>application macro selection and the parameter defaults implemented by it</li> <li>parameter <a href="#">95.1 Supply voltage</a></li> <li>parameter <a href="#">95.9 Switch fuse controller</a></li> <li>differentiated defaults implemented by parameters <a href="#">95.20 HW options word 1</a> and <a href="#">95.21 HW options word 2</a></li> <li>user lock configuration parameters <a href="#">96.100 ... 96.102</a>.</li> </ul> <p>PC tool communication is interrupted during the restoring.</p> <p><b>Note:</b> Activating this selection will restore the default settings of the fieldbus adapter if one is connected, potentially including settings that cannot be accessed through drive parameters.</p>	62
	Reset all fieldbus settings	<p>Fieldbus adapter and embedded fieldbus interface settings (parameter groups 50...58) are restored to default values. This will also restore the default settings of the fieldbus adapter if one is connected, potentially including settings that cannot be accessed through drive parameters.</p>	32
96.7	Parameter save manually	<p>Saves the valid parameter values to permanent memory. This parameter should be used to store values sent from a fieldbus, or when using an external power supply to the control board as the supply might have a very short hold-up time when powered off.</p> <p><b>Note:</b> A new parameter value is saved automatically when changed from the PC tool or control panel but not when altered through a fieldbus adapter connection.</p>	Done / uint16
	Done	Save completed.	0
	Save	Start save, or save in progress.	1
96.8	Control board boot	<p>Changing the value of this parameter to 1 reboots the control unit (without requiring a power off/on cycle of the complete drive module).</p> <p>The value reverts to 0 automatically.</p> <p><b>Note:</b> This parameter cannot be changed while the drive is running.</p>	- / uint16
	0...1	1 = Reboot the control unit.	1 = 1 / 1 = 1
96.9	FSO reboot	<p>Changing the value of (or the source selected by) this parameter from 0 to 1 reboots the optional FSO-xx safety functions module.</p> <p><b>Note:</b> The value does not revert to 0 automatically.</p>	False / uint32
	False	0.	0
	True	1.	1

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-
96.10	User set status	Shows the status of the user parameter sets.  <b>Note:</b> This parameter is read-only. See also section <a href="#">User parameter sets (page 103)</a> .	n/a / uint16
	n/a	No user parameter sets have been saved.	0
	Loading	A user set is being loaded.	1
	Saving	A user set is being saved.	2
	Faulted	Invalid parameter set.	3
	User set 1	User set 1 has been loaded.	4
	User set 2	User set 2 has been loaded.	5
	User set 3	User set 3 has been loaded.	6
	User set 4	User set 4 has been loaded.	7
96.11	User set save/load	Enables the saving and restoring of up to four custom sets of parameter settings. See section <a href="#">User parameter sets (page 103)</a> .  The set that was in use before powering down the drive is in use after the next power-up.  <b>Note:</b> Hardware configuration settings such as I/O extension module, fieldbus and encoder configuration parameters (groups 14...16, 51...56, 58 and 92...93, and parameters <a href="#">50.1</a> and <a href="#">50.31</a> ), and forced input/output values (such as <a href="#">10.3</a> and <a href="#">10.4</a> ) are not included in user parameter sets.  <b>Note:</b> Parameter changes made after loading a set are not automatically stored – they must be saved using this parameter.  <b>Note:</b> If no sets have been saved, attempting to load a set will create all sets from the currently active parameter settings.  <b>Note:</b> Switching between sets is only possible with the drive stopped.	No action / uint16
	No action	Load or save operation complete; normal operation.	0
	User set I/O mode	Load user parameter set using parameters <a href="#">96.12</a> and <a href="#">96.13</a> .	1
	Load set 1	Load user parameter set 1.	2
	Load set 2	Load user parameter set 2.	3
	Load set 3	Load user parameter set 3.	4
	Load set 4	Load user parameter set 4.	5
	Save to set 1	Save user parameter set 1.	18
	Save to set 2	Save user parameter set 2.	19

548 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b															
	Save to set 3	Save user parameter set 3.	20															
	Save to set 4	Save user parameter set 4.	21															
96.12	User set I/O mode in1	When parameter 96.11 is set to <a href="#">User set I/O mode (page 547)</a> , selects the user parameter set together with parameter 96.13 as follows:	Not selected / uint32															
		<table border="1"> <thead> <tr> <th>Status of source defined by 96.12</th> <th>Status of source defined by 96.13</th> <th>User parameter set selected</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>Set 1</td> </tr> <tr> <td>1</td> <td>0</td> <td>Set 2</td> </tr> <tr> <td>0</td> <td>1</td> <td>Set 3</td> </tr> <tr> <td>1</td> <td>1</td> <td>Set 4</td> </tr> </tbody> </table>		Status of source defined by 96.12	Status of source defined by 96.13	User parameter set selected	0	0	Set 1	1	0	Set 2	0	1	Set 3	1	1	Set 4
		Status of source defined by 96.12		Status of source defined by 96.13	User parameter set selected													
		0		0	Set 1													
		1		0	Set 2													
0	1	Set 3																
1	1	Set 4																
Not selected	0	0																
Selected	1	1																
DI1	Digital input DI1 ( <a href="#">10.2 DI delayed status</a> , bit 0).	2																
DI2	Digital input DI2 ( <a href="#">10.2 DI delayed status</a> , bit 1).	3																
DI3	Digital input DI3 ( <a href="#">10.2 DI delayed status</a> , bit 2).	4																
DI4	Digital input DI4 ( <a href="#">10.2 DI delayed status</a> , bit 3).	5																
DI5	Digital input DI5 ( <a href="#">10.2 DI delayed status</a> , bit 4).	6																
DI6	Digital input DI6 ( <a href="#">10.2 DI delayed status</a> , bit 5).	7																
DIO1	Digital input/output DIO1 ( <a href="#">11.2 DIO delayed status</a> , bit 0).	10																
DIO2	Digital input/output DIO2 ( <a href="#">11.2 DIO delayed status</a> , bit 1).	11																
Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-																
96.13	User set I/O mode in2	See parameter 96.12 <a href="#">User set I/O mode in1</a> .	Not selected / uint32															
96.16	Unit selection	Selects the unit of parameters indicating power, temperature and torque.	- / uint16															
b0	Power unit	0 = kW 1 = hp																
b1	Reserved																	
b2	Temperature unit	0 = C (°C) 1 = F (°F)																
b3	Reserved																	
b4	Torque unit	0 = Nm (N·m) 1 = lbft (lb·ft)																
b5...15	Reserved																	
	0000h...FFFFh		1 = 1 / 1 = 1															

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
96.20	Time sync primary source	Defines the 1st priority external source for synchronization of the drive's time and date.  The date and time can also be directly set into <a href="#">96.24 ... 96.26</a> in which case this parameter is ignored.	DDCS Controller / uint16
	Internal	No external source selected.	0
	DDCS Controller	External controller.	1
	Fieldbus A or B	Fieldbus interface A or B.	2
	Fieldbus A	Fieldbus interface A.	3
	Fieldbus B	Fieldbus interface B.	4
	D2D or M/F	The master station on a master/follower or drive-to-drive link.	5
	Embedded FB	Embedded fieldbus interface.	6
	Panel link	Control panel, or Drive Composer PC tool connected to the control panel.	8
	Ethernet tool link	Drive Composer PC tool through an FENA module.	9
96.23	M/F and D2D clock synchronization	In the master drive, activates clock synchronization for master/follower and drive-to-drive communication.	Inactive / uint16
	Inactive	Clock synchronization not active.	0
	Active	Clock synchronization active.	1
96.24	Full days since 1st Jan 1980	Number of full days passed since beginning of the year 1980. This parameter, together with <a href="#">96.25 Time in minutes within 24 h</a> and <a href="#">96.26 Time in ms within one minute</a> makes it possible to set the date and time in the drive via the parameter interface from a fieldbus or application program. This may be necessary if the fieldbus protocol does not support time synchronization.	12055 days / uint16
	1...59999 days	Days count. 1 = 1st January 1980.	1 = 1 days / 1 = 1 days
96.25	Time in minutes within 24 h	Number of full minutes passed since midnight. For example, the value 860 corresponds to 2:20 pm.  See parameter <a href="#">96.24 Full days since 1st Jan 1980</a> .	0 min / uint16
	0...1439 min	Minutes since midnight.	1 = 1 min / 1 = 1 min
96.26	Time in ms within one minute	Number of milliseconds passed since last minute.  See parameter <a href="#">96.24 Full days since 1st Jan 1980</a> .	0 ms / uint16
	0...59999 ms	Number of milliseconds since last minute.	1 = 1 ms / 1 = 1 ms
96.29	Time sync source status	Time source status word.  <b>Note:</b> This parameter is read-only.	- / uint16
	b0	Time tick received	1 = 1st priority tick received: Tick has been received from 1st priority source (or from <a href="#">96.24 ... 96.26</a> ).
	b1	Aux Time tick received	1 = 2nd priority tick received: Tick has been received from 2nd priority source.

## 550 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
b2	Tick interval is too long	1 = Yes: Tick interval too long (accuracy compromised).	
b3	DDCS controller	1 = Tick received: Tick has been received from an external controller.	
b4	Master/Follower	1 = Tick received: Tick has been received through the master/follower link.	
b5	Reserved		
b6	D2D	1 = Tick received: Tick has been received through the drive-to-drive link.	
b7	FbusA	1 = Tick received: Tick has been received through fieldbus interface A.	
b8	FbusB	1 = Tick received: Tick has been received through fieldbus interface B.	
b9	EFB	1 = Tick received: Tick has been received through the embedded fieldbus interface.	
b10	Reserved		
b11	Panel link	1 = Tick received: Tick has been received from the control panel, or Drive Composer PC tool connected to the control panel.	
b12	Ethernet tool link	1 = Tick received: Tick has been received from Drive Composer PC tool through an FENA module.	
b13	Parameter setting	1 = Tick received: Tick has been set by parameters <a href="#">96.24 ... 96.26</a> .	
b14	RTC	1 = RTC time in use: Time and date have been read from the real-time clock.	
b15	Drive On-Time	1 = Drive on-time in use: Time and date are displaying drive on-time.	
	0000h...FFFFh		1 = 1 / 1 = 1
96.31	Drive ID number	Specifies an ID number for the drive. The ID can be read by an external controller through DDCS, for example, for comparison with an ID contained by the controller's application.	0 / uint16
	0...32767	ID number.	1 = 1 / 1 = 1
96.39	Power up event logging	Enables/disables power-up logging. When enabled, an event ( <a href="#">B5A2 Power up</a> ) is logged by the drive upon each power-up.	Enable / uint16
	Disable	Power-up event logging disabled.	0
	Enable	Power-up event logging enabled.	1
96.51	Clear fault and event logger	Clears the contents of the event logs. See section <a href="#">Warning/fault history and analysis (page 577)</a> .	- / uint16
	0...65535	00001 = Clear the event logs. (The value will automatically revert to 00000.)	1 = 1 / 1 = 1

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
96.53	Actual checksum	Displays the actual parameter configuration checksum. The checksum is generated and updated whenever an action is selected in <a href="#">96.54 Checksum action</a> .  The parameters included in the calculation have been pre-selected, but the selection can be edited using the Drive customizer PC tool.  See also section <a href="#">Parameter checksum calculation (page 103)</a> .	0 / uint32
	00000000..FFFFFFFFh	Actual checksum.	1 = 1
96.54	Checksum action	Selects how the drive reacts if the parameter checksum ( <a href="#">96.53 Actual checksum</a> ) does not match any of the active approved checksums ( <a href="#">96.56 ... 96.59</a> ). The active checksums are selected by <a href="#">96.55 Checksum control word</a> .	No action / uint16
	No action	No action taken. (The checksum feature is not in use.)	0
	Pure event	The drive generates an event log entry ( <a href="#">B686 Checksum mismatch</a> ).	1
	Warning	The drive generates a warning ( <a href="#">A686 Checksum mismatch</a> ).	2
	Warning and prevent start	The drive generates a warning ( <a href="#">A686 Checksum mismatch</a> ). Starting the drive is prevented.	3
	Fault	The drive trips on <a href="#">6200 Checksum mismatch</a> .	4
96.55	Checksum control word	Bits 0...3 select to which approved checksums (out of <a href="#">96.56 ... 96.59</a> ) the actual checksum ( <a href="#">96.53</a> ) is compared.  Bits 4...7 select an approved (reference) checksum parameter ( <a href="#">96.56 ... 96.59</a> ) into which the actual checksum from parameter <a href="#">96.53</a> is copied.	- / uint16
b0	Approved checksum 1	1 = Enabled: Checksum 1 ( <a href="#">96.56</a> ) is observed.	
b1	Approved checksum 2	1 = Enabled: Checksum 2 ( <a href="#">96.57</a> ) is observed.	
b2	Approved checksum 3	1 = Enabled: Checksum 3 ( <a href="#">96.58</a> ) is observed.	
b3	Approved checksum 4	1 = Enabled: Checksum 4 ( <a href="#">96.59</a> ) is observed.	
b4	Set approved checksum 1	1 = Set: Copy value of <a href="#">96.53</a> into <a href="#">96.56</a> .	
b5	Set approved checksum 2	1 = Set: Copy value of <a href="#">96.53</a> into <a href="#">96.57</a> .	
b6	Set approved checksum 3	1 = Set: Copy value of <a href="#">96.53</a> into <a href="#">96.58</a> .	
b7	Set approved checksum 4	1 = Set: Copy value of <a href="#">96.53</a> into <a href="#">96.59</a> .	
b8...15	Reserved		

## 552 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	0000h...FFFFh		1 = 1 / 1 = 1
96.56	Approved checksum 1	Approved (reference) checksum 1.	0 / uint32
	00000000..FFFFFFFFh	Approved checksum 1.	1 = 1
96.57	Approved checksum 2	Approved (reference) checksum 2.	0 / uint32
	00000000..FFFFFFFFh	Approved checksum 2.	1 = 1
96.58	Approved checksum 3	Approved (reference) checksum 3.	0 / uint32
	00000000..FFFFFFFFh	Approved checksum 3.	1 = 1
96.59	Approved checksum 4	Approved (reference) checksum 4.	0 / uint32
	00000000..FFFFFFFFh	Approved checksum 4.	1 = 1
96.61	User data logger status word	Provides status information on the user data logger. See section <a href="#">Warning/fault history and analysis (page 577)</a> .  <b>Note:</b> This parameter is read-only.	0001h / uint16
	b0 Running	1 = The user data logger is running. The bit is cleared after the post-trigger time has passed.	
	b1 Triggered	1 = The user data logger has been triggered. The bit is cleared when the logger is restarted.	
	b2 Data available	1 = The user data logger contains data that can be read. Note that the bit is not cleared because the data is saved to the memory unit.	
	b3 Configured	1 = The user data logger has been configured. Note that the bit is not cleared because the configuration data is saved to the memory unit.	
	b4...15 Reserved		
	0000h...FFFFh		1 = 1 / 1 = 1
96.63	User data logger trigger	Triggers, or selects a source that triggers, the user data logger.	Off / uint32
	Off	0.	0
	On	1.	1
	Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-
	Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-
96.64	User data logger start	Starts, or selects a source that starts, the user data logger.	Off / uint32
	Off	0.	0
	On	1.	1
	Other [bit]	See <a href="#">Terms and abbreviations (page 134)</a> .	-



No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
96.65	Factory data logger time level	Selects the sampling interval for the factory data logger. See section <a href="#">Warning/fault history and analysis (page 577)</a> .	500us / uint16
	500us	500 microseconds.	500
	2ms	2 milliseconds.	2000
	10ms	10 milliseconds.	10000
96.70	Disable adaptive program	Disables/enables the adaptive program (if present). See also section <a href="#">Adaptive programming (page 31)</a> .  <b>Note:</b> This parameter cannot be changed while the drive is running.	No / uint16
	No	Adaptive program enabled.	0
	Yes	Adaptive program disabled.	1
96.100	Change user pass code	<i>(Visible when user lock is open)</i>  To change the current user pass code, enter a new code into this parameter as well as <a href="#">96.101 Confirm user pass code</a> . A warning will be active until the new pass code is confirmed. To cancel changing the pass code, close the user lock without confirming. To close the lock, enter an invalid pass code in parameter <a href="#">96.2 Pass code</a> , activate parameter <a href="#">96.8 Control board boot</a> , or cycle the power.  See also section <a href="#">User lock (page 105)</a> .	10000000 / uint32
	10000000...99999999	New user pass code.	1 = 1
96.101	Confirm user pass code	<i>(Visible when user lock is open)</i>  Confirms the new user pass code entered in <a href="#">96.100 Change user pass code (page 553)</a> .	10000000 / uint32
	10000000...99999999	Confirmation of new user pass code.	1 = 1
96.102	User lock functionality	<i>(Visible when user lock is open)</i>  Selects the actions or functionalities to be prevented by the user lock. Note that the changes made take effect only when the user lock is closed. See parameter <a href="#">96.2 Pass code</a> .  <b>Note:</b> We recommend you select all the actions and functionalities unless otherwise required by the application.	- / uint16
b0	Disable ABB access levels	1 = ABB access levels (service, advanced programmer, etc. [see <a href="#">96.3</a> ]) disabled	
b1	Freeze parameter lock state	1 = Changing the parameter lock state prevented, ie. pass code 358 has no effect	

## 554 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
b2	Disable file download	1 = Loading of files to drive prevented. This applies to <ul style="list-style-type: none"> <li>• firmware upgrades</li> <li>• safety functions module (FSO-xx) configuration</li> <li>• parameter restore</li> <li>• loading an adaptive program</li> <li>• loading and debugging an application program</li> <li>• changing home view of control panel</li> <li>• editing drive texts</li> <li>• editing the favorite parameters list on control panel</li> <li>• configuration settings made through control panel such as time/date formats and enabling/disabling clock display.</li> </ul>	
b3	Disable FB write to hidden	1 = Access to parameters on disabled access levels from fieldbus prevented	
b4...5	Reserved		
b6	Protect AP	1 = Creating a backup and restoring from a backup prevented	
b7	Disable panel bluetooth	1 = Bluetooth disabled on ACS-AP-W control panel. If the drive is part of a panel bus, Bluetooth is disabled on all panels.	
b8...10	Reserved		
b11	Disable OEM access level 1	1 = OEM access level 1 disabled	
b12	Disable OEM access level 2	1 = OEM access level 2 disabled	
b13	Disable OEM access level 3	1 = OEM access level 3 disabled	
b14...15	Reserved		
	0000h...FFFFh		1 = 1 / 1 = 1
96.108	LSU control board boot	<i>(Visible when IGBT supply unit control activated by 95.20)</i> Changing the value of this parameter to 1 reboots the supply control unit (without requiring a power off/on cycle of the drive system). The value reverts to 0 automatically.	0 / uint16
	0...1	1 = Reboot the supply control unit.	1 = 1 / 1 = 1


No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
<b>97</b>	Motor control	Motor model settings.	
97.1	Switching frequency reference	When parameter 97.9 <b>Switching freq mode</b> is set to <b>Custom</b> , defines the switching frequency when it is not otherwise being internally limited.  <b>Note:</b> This is an expert level parameter and should not be adjusted without appropriate skill.	4.500 kHz / real32
	0.000 ... 24.000 kHz	Switching frequency reference.	1000 = 1 kHz / 1000 = 1 kHz
97.2	Minimum switching frequency	When parameter 97.9 <b>Switching freq mode</b> is set to <b>Custom</b> , defines a minimum switching frequency reference. The actual switching frequency will not fall below this limit under any circumstances.  <b>Note:</b> This is an expert level parameter and should not be adjusted without appropriate skill.  <b>Note:</b> The drive has internal switching frequency limits that may override the value entered here.	1.500 kHz / real32
	0.000 ... 24.000 kHz	Minimum switching frequency.	1000 = 1 kHz / 1000 = 1 kHz
97.3	Slip gain	Defines the slip gain which is used to improve the estimated motor slip. 100% means full slip gain; 0% means no slip gain. The default value is 100%. Other values can be used if a static speed error is detected despite having the setting at full slip gain.  <b>Example</b> (with nominal load and nominal slip of 40 rpm): A 1000 rpm constant speed reference is given to the drive. Despite having full slip gain (= 100%), a manual tachometer measurement from the motor axis gives a speed value of 998 rpm. The static speed error is 1000 rpm - 998 rpm = 2 rpm. To compensate the error, the slip gain should be increased to 105% (2 rpm / 40 rpm = 5%).	100 % / real32
	0...200 %	Slip gain.	1 = 1 % / 100 = 1 %


## 556 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
97.4	Voltage reserve	<p>Defines the minimum allowed voltage reserve. When the voltage reserve has decreased to the set value, the drive enters the field weakening area.</p> <p><b>Note:</b> This is an expert level parameter and should not be adjusted without appropriate skill.</p> <p>If the intermediate circuit DC voltage <math>U_{dc} = 550 \text{ V}</math> and the voltage reserve is 5%, the rms value of the maximum output voltage in steady-state operation is <math>0.95 \times 550 \text{ V} / \sqrt{2} = 369 \text{ V}</math></p> <p>The dynamic performance of the motor control in the field weakening area can be improved by increasing the voltage reserve value, but the drive enters the field weakening area earlier.</p> <p><b>Note:</b> The default value for ACS880-11/31/14/34 and R8, R11 of ACS880-17/37 is -3%.</p>	-2 % / real32
	-5...50 %	Voltage reserve.	1 = 1 % / 100 = 1 %
97.5	Flux braking	<p>Defines the level of flux braking power. (Other stopping and braking modes can be configured in parameter group 21 <i>Start/stop mode</i>).</p> <p>See section <a href="#">Flux braking (page 66)</a>.</p> <p><b>Note:</b> This is an expert level parameter and should not be adjusted without appropriate skill.</p>	Disabled / uint16
	Disabled	Flux braking is disabled.	0
	Moderate	Flux level is limited during the braking. Deceleration time is longer compared to full braking.	1
	Full	Maximum braking power. Almost all available current is used to convert the mechanical braking energy to thermal energy in the motor.	2
97.6	Flux reference select	<p>Defines the source of flux reference.</p> <p><b>Note:</b> This is an expert level parameter and should not be adjusted without appropriate skill.</p>	User flux reference / uint32
	Zero	None.	0
	User flux reference	Parameter <a href="#">97.7 User flux reference</a> .	1
	Other [bit]	Source selection (see <a href="#">Terms and abbreviations (page 134)</a> ).	-
97.7	User flux reference	Defines the flux reference when parameter <a href="#">97.6 Flux reference select</a> is set to <a href="#">User flux reference</a> .	100.00 % / real32
	0.00 ... 200.00 %	User-defined flux reference.	100 = 1 % / 100 = 1 %

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
97.8	Optimizer minimum torque	<p>This parameter can be used to improve the control dynamics of a synchronous reluctance motor or a salient permanent magnet synchronous motor.</p> <p>As a rule of thumb, define a level to which the output torque must rise with minimum delay. This will increase the motor current and improve the torque response at low speeds.</p>	0.0 % / real32
	0.0 ... 1600.0 %	Optimizer torque limit.	10 = 1 % / 10 = 1 %
97.9	Switching freq mode	<p>An optimization setting for balancing between control performance and motor noise level.</p> <p><b>Note:</b> This is an expert level parameter and should not be adjusted without appropriate skill.</p> <p><b>Note:</b> Other settings than <b>Normal</b> may require derating. Refer to the rating data in the hardware manual of the drive.</p> <p><b>Note:</b> To improve the control performance, the switching frequency reference is automatically increased with ABB sine filter if the motor/drive current ratio is less than 0.55.</p>	Normal / uint16
	Normal	Control performance optimized for long motor cables.	0
	Low noise	Minimizes motor noise.	1
	Cyclic	Control performance optimized for cyclic load applications.	2
	Custom	This setting is to be used by ABB-authorized service personnel only.	3
97.10	Signal injection	<p>Enables signal injection. A high-frequency alternating signal is injected into the motor at low speeds to improve the stability of torque control. Signal injection can be enabled with different amplitude levels.</p> <p><b>Note:</b> This is an expert level parameter and should not be adjusted without appropriate skill.</p> <p><b>Note:</b> Use as low a level as possible that gives satisfactory performance.</p> <p><b>Note:</b> Signal injection cannot be applied to asynchronous motors.</p>	Disabled / uint16
	Disabled	Signal injection disabled.	0
	Enabled (5 %)	Signal injection enabled with an amplitude level of 5%.	1
	Enabled (10 %)	Signal injection enabled with an amplitude level of 10%.	2
	Enabled (15 %)	Signal injection enabled with an amplitude level of 15%.	3

558 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	Enabled (20 %)	Signal injection enabled with an amplitude level of 20%.	4
97.11	TR tuning	<p>Rotor time constant tuning.</p> <p>This parameter can be used to improve torque accuracy in closed-loop control of an induction motor. Normally, the motor identification run provides sufficient torque accuracy, but manual fine-tuning can be applied in exceptionally demanding applications to achieve optimal performance.</p> <p><b>Note:</b> This is an expert level parameter and should not be adjusted without appropriate skill.</p>	100 % / real32
	25...400 %	Rotor time constant tuning.	1 = 1 % / 100 = 1 %
97.12	IR comp step-up frequency	<p>IR compensation (i.e. output voltage boost) can be used in step-up applications to compensate for resistive losses in the step-up transformer, cabling and motor. As voltage cannot be fed through a step-up transformer at 0 %, a specific type of IR compensation should be used.</p> <p>This parameter adds a frequency breakpoint for parameter 97.13 IR compensation as shown.</p>  <p>0.0 Hz = Breakpoint disabled.</p> <p><b>Note:</b> This parameter cannot be changed while the drive is running.</p>	0.0 Hz / real32
	0.0 ... 50.0 Hz	IR compensation breakpoint for step-up applications.	1 = 1 Hz / 10 = 1 Hz

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
97.13	IR compensation	<p>Defines the relative output voltage boost at zero speed (IR compensation). The function is useful in applications with a high break-away torque where direct torque control (DTC mode) cannot be applied.</p>  <p>See also section <a href="#">IR compensation for scalar motor control</a> (page 63).</p>	0.00 % / real32
	0.00 ... 50.00 %	Voltage boost at zero speed in percent of nominal motor voltage.	1 = 1 % / 10000 = 1 %
97.15	Motor model temperature adaptation	<p>Selects whether the temperature-dependent parameters (such as stator or rotor resistance) of the motor model adapt to actual (measured or estimated) temperature or not.</p> <p>See parameter group <a href="#">35 Motor thermal protection</a> for selection of temperature measurement sources.</p>	Disabled / uint16
	Disabled	Temperature adaptation of motor model disabled.	0
	Estimated temperature	Estimated temperature ( <a href="#">35.1 Motor estimated temperature</a> ) used for adaptation of motor model.	1
	Measured temperature 1	Measured temperature 1 ( <a href="#">35.2 Measured temperature 1</a> ) used for adaptation of motor model.	2
	Measured temperature 2	Measured temperature 2 ( <a href="#">35.3 Measured temperature 2</a> ) used for adaptation of motor model.	3
97.18	Hexagonal field weakening	<p>Activates hexagonal motor flux pattern in the field weakening area, i.e. above the limit defined by parameter <a href="#">97.19 Hexagonal field weakening point</a>.</p> <p><b>Note:</b> This parameter is only effective in scalar motor control mode.</p> <p>See also section <a href="#">Hexagonal motor flux pattern</a> (page 69).</p>	Off / uint16
	Off	The rotating flux vector follows a circular pattern.	0

## 560 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	On	The flux vector follows a circular pattern below, and a hexagonal pattern above, the hexagonal field weakening point (97.19).	1
97.19	Hexagonal field weakening point	Defines the activation limit for hexagonal field weakening (in percent of the field weakening point, i.e. the frequency at which maximum output voltage is reached). See parameter 97.18 Hexagonal field weakening.  <b>Note:</b> This parameter is only effective in scalar motor control mode.	120.0 % / real32
	0.0 ... 500.0 %	Activation limit for hexagonal field weakening.	1 = 1 % / 1000 = 1 %
97.32	Motor torque unfiltered	Unfiltered motor torque in percent of the nominal motor torque.  <b>Note:</b> This parameter is read-only.	0.0 % / real32
	-1600.0 ... 1600.0 %	Unfiltered motor torque. For 16-bit scaling, see parameter 46.3.	- / 10 = 1 %
97.33	Speed estimate filter time	Defines a filtering time for estimated speed See the diagram on page 671.	5.00 ms / real32
	0.00 ... 100.00 ms	Filtering time for estimated speed.	1 = 1 ms / 100 = 1 ms
97.78	Maximum flux reference assistance	Defines the maximum allowed stator flux assistance reference for boosting the flux when needed.  Stator flux assistance improves the efficiency of the drive in high load conditions with externally-excited synchronous motors.  The function is activated when a non-zero value is set to parameter 97.78. The flux is boosted between parameters 97.7 and 97.7 + 97.78, when needed.	0.00 % / real32
	0.00 ... 200.00 %	Maximum flux reference assistance.	1 = 1 % / 100 = 1 %



No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
98	User motor parameters	<p>Motor values supplied by the user that are used in the motor model.</p> <p>These parameters are useful for non-standard motors, or to just get more accurate motor control of the motor on site. A better motor model always improves the shaft performance.</p>	
98.1	User motor model mode	<p>Activates the motor model parameters 98.2 ... 98.14 and the rotor angle offset parameter 98.15.</p> <p><b>Note:</b> Parameter value is automatically set to zero when ID run is selected by parameter 99.13 ID run requested. The values of parameters 98.2 ... 98.15 are then updated according to the motor characteristics identified during the ID run.</p> <p><b>Note:</b> Measurements made directly from the motor terminals during the ID run are likely to produce slightly different values than those on a datasheet from a motor manufacturer.</p> <p><b>Note:</b> This parameter cannot be changed while the drive is running.</p>	Not selected / uint16
	Not selected	The values detected during the ID run are being used.	0
	Motor parameters	The values of parameters 98.2 ... 98.14 are used in the motor model.	1
	Position offset	The value of parameter 98.15 is used as the rotor angle offset. Parameters 98.2 ... 98.14 are inactive.	2
	Motor parameters & position offset	The values of parameters 98.2 ... 98.14 are used in the motor model, and the value of parameter 98.15 is used as the rotor angle offset.	3
98.2	Rs user	<p>Defines the stator resistance <math>R_S</math> of the motor model.</p> <p>With a star-connected motor, <math>R_S</math> is the resistance of one winding. With a delta-connected motor, <math>R_S</math> is one-third of the resistance of one winding.</p> <p>Resistance value is given at 20 °C (68 °F).</p>	0.00000 pu / real32
	0.00000 ... 0.50000 pu	Stator resistance in per unit.	- / 100000 = 1 pu
98.3	Rr user	<p>Defines the rotor resistance <math>R_R</math> of the motor model.</p> <p>Resistance value is given at 20 °C (68 °F).</p> <p><b>Note:</b> This parameter is valid only for asynchronous motors.</p>	0.00000 pu / real32
	0.00000 ... 0.50000 pu	Rotor resistance in per unit.	- / 100000 = 1 pu
98.4	Lm user	<p>Defines the main inductance <math>L_M</math> of the motor model.</p> <p><b>Note:</b> This parameter is valid only for asynchronous motors.</p>	0.00000 pu / real32

## 562 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	0.00000 ... 10.00000 pu	Main inductance in per unit.	- / 100000 = 1 pu
98.5	SigmaL user	Defines the leakage inductance $\sigma L_s$ .  <b>Note:</b> This parameter is valid only for asynchronous motors.	0.00000 pu / real32
	0.00000 ... 1.00000 pu	Leakage inductance in per unit.	- / 100000 = 1 pu
98.6	Ld user	Defines the direct axis (synchronous) inductance.  <b>Note:</b> This parameter is valid only for permanent magnet motors and SynRM. With SynRM the value can be used to tune the saturation curve.	0.00000 pu / real32
	0.00000 ... 10.00000 pu	Direct axis inductance in per unit.	- / 100000 = 1 pu
98.7	Lq user	Defines the quadrature axis (synchronous) inductance.  <b>Note:</b> This parameter is valid only for permanent magnet motors and SynRM. With SynRM the value can be used to tune the saturation curve.	0.00000 pu / real32
	0.00000 ... 10.00000 pu	Quadrature axis inductance in per unit.	- / 100000 = 1 pu
98.8	PM flux user	Defines the permanent magnet flux.  <b>Note:</b> This parameter is valid only for permanent magnet motors.	0.00000 pu / real32
	0.00000 ... 2.00000 pu	Permanent magnet flux in per unit.	- / 100000 = 1 pu
98.9	Rs user SI	Defines the stator resistance $R_s$ of the motor model. Resistance value is given at 20 °C (68 °F).	0.00000 Ohm / real32
	0.00000 ... 100.00000 Ohm	Stator resistance.	- / 100000 = 1 Ohm
98.10	Rr user SI	Defines the rotor resistance $R_r$ of the motor model. Resistance value is given at 20 °C (68 °F).	0.00000 Ohm / real32
	0.00000 ... 100.00000 Ohm	Rotor resistance.	100 = 1 Ohm / 100000 = 1 Ohm
98.11	Lm user SI	Defines the main inductance $L_M$ of the motor model.  <b>Note:</b> This parameter is valid only for asynchronous motors.	0.00 mH / real32
	0.00 ... 100000.00 mH	Main inductance.	10 = 1 mH / 100 = 1 mH

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
98.12	SigmaL user SI	Defines the leakage inductance $\sigma L_s$ .  <b>Note:</b> This parameter is valid only for asynchronous motors.	0.00 mH / real32
	0.00 ... 100000.00 mH	Leakage inductance.	10 = 1 mH / 100 = 1 mH
98.13	Ld user SI	Defines the direct axis (synchronous) inductance.  <b>Note:</b> This parameter is valid only for permanent magnet motors.	0.00 mH / real32
	0.00 ... 100000.00 mH	Direct axis inductance.	10 = 1 mH / 100 = 1 mH
98.14	Lq user SI	Defines the quadrature axis (synchronous) inductance.  <b>Note:</b> This parameter is valid only for permanent magnet motors.	0.00 mH / real32
	0.00 ... 100000.00 mH	Quadrature axis inductance.	10 = 1 mH / 100 = 1 mH
98.15	Position offset user	Defines an angle offset between the zero position of the synchronous motor and the zero position of the position sensor.  This value is initially set by the autophasing routine when an absolute encoder or an incremental encoder with Z-pulse is used. The value can be fine-tuned by setting <a href="#">98.1 User motor model mode</a> to <a href="#">Position offset</a> or <a href="#">Motor parameters &amp; position offset</a> .  <b>Note:</b> The value is in electrical degrees. The electrical angle equals the mechanical angle multiplied by the number of motor pole pairs.  <b>Note:</b> This parameter is valid only for permanent magnet motors.	0.0 deg / real32
	0.0 ... 360.0 deg	Angle offset.	1 = 1 deg / 1 = 1 deg

## 564 Parameters



No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
<b>99</b>	Motor data	Motor configuration settings.	
99.3	Motor type	Selects the motor type.  <b>Note:</b> This parameter cannot be changed while the drive is running.	Asynchronous motor; SynRM (95.21 b1); Permanent magnet motor (95.21 b2) / uint16
	Asynchronous motor	Standard squirrel cage AC induction motor (asynchronous induction motor).	0
	Permanent magnet motor	Permanent magnet motor. Three-phase AC synchronous motor with permanent magnet motor and sinusoidal BackEMF voltage.	1
	SynRM	Synchronous reluctance motor. Three-phase AC synchronous motor with salient pole rotor without permanent magnets.	2
99.4	Motor control mode	Selects the motor control mode.  <b>Note:</b> This parameter cannot be changed while the drive is running.	DTC / uint16
	DTC	Direct torque control. This mode is suitable for most applications.  <b>Note:</b> Instead of direct torque control, scalar control is also available, and should be used in the following situations: <ul style="list-style-type: none"> <li>with multimotor applications <ol style="list-style-type: none"> <li>if the load is not equally shared between the motors,</li> <li>if the motors are of different sizes, or</li> <li>if the motors are going to be changed after the motor identification (ID) run</li> </ol> </li> <li>if the nominal current of the motor is less than 1/6 of the nominal output current of the drive</li> <li>if the drive is used with no motor connected (for example, for test purposes).</li> </ul> <p>See also section <a href="#">Operating modes of the drive (page 26)</a>.</p>	0
	Scalar	Scalar control. The outstanding motor control accuracy of DTC cannot be achieved in scalar control.  Refer to the selection <a href="#">DTC</a> above for a list of applications where scalar control should definitely be used.  <b>Note:</b> <ul style="list-style-type: none"> <li>Correct motor operation requires that the magnetizing current of the motor does not exceed 90% of the nominal current of the inverter.</li> <li>Some standard features are disabled in scalar control mode.</li> </ul> <p>See also section <a href="#">Scalar motor control (page 62)</a> and section <a href="#">Operating modes of the drive (page 26)</a>.</p>	1

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
99.6	Motor nominal current	<p>Defines the nominal motor current. This setting must match the value on the rating plate of the motor. If multiple motors are connected to the drive, enter the total current of the motors.</p> <p><b>Note:</b> Correct motor operation requires that the magnetizing current of the motor does not exceed 90% of the nominal current of the drive.</p> <p><b>Note:</b> This parameter cannot be changed while the drive is running.</p>	0.0 A / real32
	0.0 ... 10000.0 A	Nominal current of the motor. The allowable range is $1/6...2 \times I_N$ (nominal current) of the drive and $0...2 \times I_N$ with scalar control mode.	$10 = 1 \text{ A} / 10 = 1 \text{ A}$
99.7	Motor nominal voltage	<p>Defines the nominal motor voltage supplied to the motor. This setting must match the value on the rating plate of the motor.</p> <p><b>Note:</b> With permanent magnet motors, the nominal voltage is the BackEMF voltage at nominal speed of the motor. If the voltage is given as voltage per rpm, e.g. 60 V per 1000 rpm, the voltage for a nominal speed of 3000 rpm is <math>3 \times 60 \text{ V} = 180 \text{ V}</math>. Note that nominal voltage is not the same as equivalent DC motor voltage (EDCM) given by some manufacturers. The nominal voltage can be calculated by dividing the EDCM voltage by 1.7 (or square root of 3).</p> <p><b>Note:</b> The stress on the motor insulation is always dependent on the drive supply voltage. This also applies to the case where the motor voltage rating is lower than that of the drive and the supply.</p> <p><b>Note:</b> This parameter cannot be changed while the drive is running.</p>	0.0 V / real32
	0.0 ... 1500.0 V	Nominal voltage of the motor. The allowable range is $1/6...2 \times U_N$ (nominal voltage) of the drive. $U_N$ equals the upper bound of the supply voltage range selected by parameter <a href="#">95.1 Supply voltage</a> .	$10 = 1 \text{ V} / 10 = 1 \text{ V}$
99.8	Motor nominal frequency	<p>Defines the nominal motor frequency. This setting must match the value on the rating plate of the motor.</p> <p><b>Note:</b> This parameter cannot be changed while the drive is running.</p>	50.00 Hz / real32
	0.00 ... 1000.00 Hz	Nominal frequency of the motor.	$10 = 1 \text{ Hz} / 100 = 1 \text{ Hz}$

## 566 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
99.9	Motor nominal speed	<p>Defines the nominal motor speed. The setting must match the value on the rating plate of the motor.</p> <p><b>Note:</b> This parameter cannot be changed while the drive is running.</p> <p><b>Note:</b> (Asynchronous generator) Nominal speed needs to be adjusted as running the generator as a motor.</p>	0 rpm / real32
	0...30000 rpm	Nominal speed of the motor.	1 = 1 rpm / 1 = 1 rpm
99.10	Motor nominal power	<p>Defines the nominal motor power. The setting must match the value on the rating plate of the motor. If nominal power is not shown on the rating plate, nominal torque can be entered instead in parameter 99.12.</p> <p>If multiple motors are connected to the drive, enter the total power of the motors.</p> <p>The unit is selected by parameter 96.16 Unit selection.</p> <p><b>Note:</b> This parameter cannot be changed while the drive is running.</p>	- / real32
	0.00 ... 26000.00 kW or hp	Nominal power of the motor.	1 = 1 kW or hp / 100 = 1 kW or hp
99.11	Motor nominal cos $\phi$	<p>Defines the cosphi of the motor for a more accurate motor model. The value is not obligatory, but is useful with an asynchronous motor, especially when performing a standstill identification run. With a permanent magnet or synchronous reluctance motor, this value is not needed.</p> <p><b>Note:</b> Do not enter an estimated value. If you do not know the exact value, leave the parameter at zero.</p> <p><b>Note:</b> This parameter cannot be changed while the drive is running.</p>	0.00 / real32
	0.00 ... 1.00	Cosphi of the motor.	100 = 1 / 100 = 1
99.12	Motor nominal torque	<p>Defines the nominal motor shaft torque. This value can be given instead of nominal power (99.10) if shown on the rating plate of the motor.</p> <p>The unit is selected by parameter 96.16 Unit selection.</p> <p><b>Note:</b> This setting is an alternative to the nominal power value (99.10). If both are entered, 99.12 takes priority.</p> <p><b>Note:</b> This parameter cannot be changed while the drive is running.</p>	0.000 Nm or lb-ft / uint32
	0.000 ... 4000000.000 Nm or lb-ft	Nominal motor torque.	1 = 1 Nm or lb-ft / 1000 = 1 Nm or lb-ft


No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
99.13	ID run requested	<p>Selects the type of the motor identification routine (ID run) performed at the next start of the drive. During the ID run, the drive will identify the characteristics of the motor for optimum motor control.</p> <p>If no ID run has been performed yet (or if default parameter values have been restored using parameter <a href="#">96.6 Parameter restore</a>), this parameter is automatically set to <a href="#">Standstill</a>, signifying that an ID run must be performed.</p> <p>After the ID run, the drive stops and this parameter is automatically set to <a href="#">None</a>.</p> <p><b>Note:</b> For the <a href="#">Advanced</a> ID run, the machinery must always be de-coupled from the motor.</p> <p><b>Note:</b> Before activating the ID run, configure motor temperature measurement (if used) in parameter group <a href="#">35 Motor thermal protection</a>, and in parameter <a href="#">97.15</a>.</p> <p><b>Note:</b> If a sine filter is installed, set the appropriate bit in parameter <a href="#">95.15 Special HW settings</a> before activating the ID run. With a non-ABB (custom) filter, set also <a href="#">99.18</a> and <a href="#">99.19</a>.</p> <p><b>Note:</b> With scalar control mode (<a href="#">99.4 Motor control mode = Scalar</a>), the ID run is not requested automatically. However, an ID run can be performed for more accurate torque estimation.</p> <p><b>Note:</b> Once the ID run is activated, it can be canceled by stopping the drive.</p> <p><b>Note:</b> The ID run must be performed every time any of the motor parameters (<a href="#">99.4</a>, <a href="#">99.6</a> ... <a href="#">99.12</a>) have been changed.</p> <p><b>Note:</b> Make sure that the Safe torque off and emergency stop circuits (if any) are closed during the ID run.</p> <p><b>Note:</b> Mechanical brake (if present) is not opened by the logic for the ID run.</p> <p><b>Note:</b> For the permanent magnet and SynRM, the Reduced, Normal, and Advanced ID runs are the same. In addition, the Standstill and Advanced Standstill ID runs are identical.</p> <p><b>Note:</b> This parameter cannot be changed while the drive is running.</p>	None; Standstill (95.21 b1/b2) / uint16
	None	No motor ID run is requested. This mode can be selected only if the ID run ( <a href="#">Normal</a> , <a href="#">Reduced</a> , <a href="#">Standstill</a> , <a href="#">Advanced</a> , <a href="#">Advanced Standstill</a> ) has already been performed once.	0

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	Normal	<p>Normal ID run:</p> <ul style="list-style-type: none"> <li>• supports all motor types</li> <li>• load to be decoupled</li> <li>• good performance.</li> </ul> <p>Guarantees good control accuracy for all cases. This mode should be selected whenever it is possible.</p> <p><b>Note:</b> If the load torque will be higher than 20% of motor nominal torque, or if the machinery is not able to withstand the nominal torque transient during the ID run, then the driven machinery must be de-coupled from the motor during a Normal ID run. With the permanent magnet or SynRM motors the transient torque value can be up to two times the nominal torque.</p> <p><b>Note:</b> Check the direction of rotation of the motor before starting the ID run. During the run, the motor will rotate in the forward direction.</p> <p> <b>WARNING!</b> The motor will run at up to approximately 50...100% of the nominal speed during the ID run. MAKE SURE THAT IT IS SAFE TO RUN THE MOTOR BEFORE PERFORMING THE ID RUN!</p>	1
	Reduced	<p>Reduced ID run:</p> <ul style="list-style-type: none"> <li>• supports only induction motors</li> <li>• especially for conical rotor brake motors used in crane applications</li> <li>• load to be decoupled</li> <li>• good performance.</li> </ul> <p>This mode should be selected instead of the <a href="#">Normal</a> or <a href="#">Advanced</a> ID run if</p> <ul style="list-style-type: none"> <li>• mechanical losses are higher than 20% (i.e. the motor cannot be de-coupled from the driven equipment), or if</li> <li>• flux reduction is not allowed while the motor is running (i.e. in case of a motor with an integrated brake supplied from the motor terminals).</li> </ul> <p>With this ID run mode, the resultant motor control in the field weakening area or at high torques is not necessarily as accurate as motor control following a Normal ID run. Reduced ID run is completed faster than the Normal ID run (&lt; 90 seconds).</p> <p><b>Note:</b> Check the direction of rotation of the motor before starting the ID run. During the run, the motor will rotate in the forward direction.</p> <p> <b>WARNING!</b> The motor will run at up to approximately 50...100% of the nominal speed during the ID run. MAKE SURE THAT IT IS SAFE TO RUN THE MOTOR BEFORE PERFORMING THE ID RUN!</p>	2





No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	Standstill	<p>Standstill ID run:</p> <ul style="list-style-type: none"> <li>• supports all motor types</li> <li>• not necessary to decouple the load</li> <li>• moderate performance.</li> </ul> <p>The motor is injected with DC current. With an AC induction (asynchronous) motor, the motor shaft is not rotated. With a permanent magnet motor or synchronous reluctance motor, the shaft can rotate up to half a revolution.</p> <p><b>Note:</b> A standstill ID run should be selected only if the <a href="#">Normal</a>, <a href="#">Reduced</a> or <a href="#">Advanced</a> ID run is not possible because of the restrictions caused by the connected mechanics (e.g. with lift or crane applications).</p> <p>See also selection <a href="#">Advanced Standstill</a>.</p>	3
	Autophasing	<p>The autophasing routine determines the start angle of a permanent magnet or synchronous reluctance motor (see section <a href="#">Autophasing (page 63)</a>). Autophasing does not update the other motor model values.</p> <p>Autophasing is automatically performed as part of the <a href="#">Normal</a>, <a href="#">Reduced</a>, <a href="#">Standstill</a>, <a href="#">Advanced</a> or <a href="#">Advanced Standstill</a> ID runs. Using this setting, it is possible to perform autophasing alone. This is useful after changes in the feedback configuration, such as the replacement or addition of an absolute encoder, resolver, or pulse encoder with commutation signals.</p> <p><b>Note:</b> This setting can only be used after a <a href="#">Normal</a>, <a href="#">Reduced</a>, <a href="#">Standstill</a>, <a href="#">Advanced</a> or <a href="#">Advanced Standstill</a> ID run has already been performed.</p> <p><b>Note:</b> Depending on the selected autophasing mode, the shaft can rotate during autophasing. See parameter <a href="#">21.13 Autophasing mode</a>.</p>	4
	Current measurement calibration	<p>Requests current measurement calibration, i.e. identification of current measurement offset and gain errors.</p> <p>The calibration will be performed at next start.</p>	5

## 570 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	Advanced	<p>Advanced ID run:</p> <ul style="list-style-type: none"> <li>• supports only induction motors</li> <li>• load to be decoupled</li> <li>• highest level of performance</li> <li>• takes more time.</li> </ul> <p>Guarantees the best possible control accuracy. The ID run can take a couple of minutes. This mode should be selected when top performance is needed across the whole operating area.</p> <p><b>Note:</b> If the load torque is higher than 20% of motor nominal torque, or if the machinery is not able to withstand the nominal torque transient during the ID run, then the driven machinery must be de-coupled from the motor during a Advanced ID run.</p> <p><b>Note:</b> Check the direction of rotation of the motor before starting the ID run. During the run, the motor will rotate in the forward direction.</p> <p> <b>WARNING!</b> The motor will run at up to approximately 50...100% of the nominal speed during the ID run. Several accelerations and decelerations are done. <b>MAKE SURE THAT IT IS SAFE TO RUN THE MOTOR BEFORE PERFORMING THE ID RUN!</b></p>	6
	Advanced Standstill	<p>Advanced Standstill ID run:</p> <ul style="list-style-type: none"> <li>• only for Induction motors</li> <li>• recommended &lt;50 kW</li> <li>• not necessary to decouple the load</li> <li>• good performance</li> <li>• takes more time.</li> </ul> <p>This selection is recommended with AC induction motors up to 75 kW instead of the <a href="#">Standstill</a> ID run if</p> <ul style="list-style-type: none"> <li>• the exact nominal ratings of the motor are not known, or</li> <li>• the control performance of the motor is not satisfactory after a <a href="#">Standstill</a> ID run.</li> </ul> <p><b>Note:</b> The time it takes for the <a href="#">Advanced Standstill</a> ID run to complete varies according to motor size. With a small motor, the ID run typically completes within 5 minutes; with a large motor, the ID run may take up to an hour.</p>	7
99.14	Last ID run performed	Displays the type of ID run that was performed last. For more information about the different modes, see the selections of parameter <a href="#">99.13 ID run requested</a> .	None / uint16
	None	No ID run has been performed.	0
	Normal	<a href="#">Normal</a> ID run.	1
	Reduced	<a href="#">Reduced</a> ID run.	2
	Standstill	<a href="#">Standstill</a> ID run.	3

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
	Autophasing	<a href="#">Autophasing</a> .	4
	Current measurement calibration	<a href="#">Current measurement calibration</a> .	5
	Advanced	<a href="#">Advanced ID run</a> .	6
	Advanced Standstill	<a href="#">Advanced Standstill ID run</a> .	7
99.15	Motor polepairs calculated	Calculated number of pole pairs in the motor. This parameter is read-only.	0 / uint16
	0...1000	Number of pole pairs.	1 = 1 / 1 = 1
99.16	Motor phase order	Switches the rotation direction of the motor. This parameter can be used if the motor turns in the wrong direction (for example, because of the wrong phase order in the motor cable), and correcting the cabling is considered impractical.  <b>Note:</b> Changing this parameter does not affect speed reference polarities, so positive speed reference will rotate the motor forward. The phase order selection just ensures that "forward" is in fact the correct direction.  <b>Note:</b> After changing this parameter, the sign of encoder feedback (if any) must be checked. This can be done by setting parameter <a href="#">90.41 Motor feedback selection</a> to <a href="#">Estimate</a> , and comparing the sign of <a href="#">90.1 Motor speed for control</a> to <a href="#">90.10 Encoder 1 speed</a> (or <a href="#">90.20 Encoder 2 speed</a> ). If the sign of the measurement is incorrect, the encoder wiring must be corrected or the sign of <a href="#">90.43 Motor gear numerator</a> reversed.  <b>Note:</b> This parameter cannot be changed while the drive is running.	U V W / uint16
	U V W	Normal.	0
	U W V	Reversed rotation direction.	1
99.18	Sine filter inductance	Defines the inductance of a custom sine filter, i.e. when parameter <a href="#">95.15 Special HW settings</a> bit 3 is activated.  <b>Note:</b> For an ABB sine filter ( <a href="#">95.15 Special HW settings</a> bit 1), this parameter is set automatically and should not be adjusted.	0.000 mH / real32
	0.000 ... 100000.000 mH	Inductance of custom sine filter.	1000 = 1 mH / 1 = 1 mH

572 Parameters

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
99.19	Sine filter capacitance	<p>Defines the capacitance of a custom sine filter, i.e. when parameter <a href="#">95.15 Special HW settings</a> bit 3 is activated.</p> <p>If the capacitors are star/wye-connected, enter the capacitance of <u>one leg</u> into the parameter.</p>  <p style="text-align: right;">99.19 = C</p> <p>If the capacitors are delta-connected, multiply the capacitance of <u>one leg</u> by 3 and enter the result into the parameter.</p>  <p style="text-align: right;">99.19 = 3 × C</p> <p><b>Note:</b> For an ABB sine filter (<a href="#">95.15 Special HW settings</a> bit 1), this parameter is set automatically and should not be adjusted.</p>	0.00 uF / real32
	0.00 ... 100000.00 uF	Capacitance of custom sine filter.	100 = 1 uF / 1 = 1 uF
No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
200	Safety	<p>FSO-xx settings.</p> <p>This group contains parameters related to the optional FSO-xx safety functions module. For details, refer to the documentation of the FSO-xx module.</p>	
No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
206	I/O bus configuration	<p>Distributed I/O bus settings.</p> <p>This group is only visible with a BCU control unit.</p> <p>This group contains parameters related to the distributed I/O bus, which is used with some drives for monitoring the cooling fans of the cabinet system. For details, refer to <a href="#">CIO-01 I/O module for distributed I/O bus control user's manual (3AXD50000126880 [English])</a>.</p>	

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
207	I/O bus service	<p>Distributed I/O bus settings.</p> <p>This group is only visible with a BCU control unit.</p> <p>This group contains parameters related to the distributed I/O bus, which is used with some drives for monitoring the cooling fans of the cabinet system. For details, refer to <a href="#">CIO-01 I/O module for distributed I/O bus control user's manual (3AXD50000126880 [English])</a>.</p>	

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
208	I/O bus diagnostics	<p>Distributed I/O bus settings.</p> <p>This group is only visible with a BCU control unit.</p> <p>This group contains parameters related to the distributed I/O bus, which is used with some drives for monitoring the cooling fans of the cabinet system. For details, refer to <a href="#">CIO-01 I/O module for distributed I/O bus control user's manual (3AXD50000126880 [English])</a>.</p>	

No.	Name / Range / Selection	Description	Def / Type FbEq 16b / 32b
209	I/O bus fan identification	<p>Distributed I/O bus settings.</p> <p>This group is only visible with a BCU control unit.</p> <p>This group contains parameters related to the distributed I/O bus, which is used with some drives for monitoring the cooling fans of the cabinet system. For details, refer to <a href="#">CIO-01 I/O module for distributed I/O bus control user's manual (3AXD50000126880 [English])</a>.</p>	



7

# Fault tracing

---

## What this chapter contains

The chapter lists the warning and fault messages including possible causes and corrective actions. The causes of most warnings and faults can be identified and corrected using the information in this chapter. If not, contact an ABB service representative. If you have the possibility to use the *Drive Composer* PC software, send the Support package created by the Drive Composer tool to the ABB service representative.

Warnings and faults are listed below in separate tables. Each table is sorted by warning/fault code.

## Safety

---

**WARNING!**

Only qualified electricians are allowed to service the drive. Read the instructions in the *Safety instructions* chapter of the *Hardware manual* of the drive before working on the drive.

---

## Indications

### ■ Warnings and faults

Warnings and faults indicate an abnormal drive status. The codes and names of active warnings/faults are displayed on the control panel of the drive as well as the *Drive Composer* PC tool. Only the codes of warnings/faults are available over fieldbus.

Warnings do not need to be reset; they stop showing when the cause of the warning ceases. Warnings do not latch and the drive will continue to operate the motor.

Faults do latch inside the drive and cause the drive to trip, and the motor stops. After the cause of a fault has been removed, the fault can be reset from a selectable source (parameter [31.11 Fault reset selection](#)), such as the control panel, the *Drive Composer* PC tool, the digital inputs of the drive, or fieldbus. After the fault is reset, the drive can be restarted.

Note that some faults require a reboot of the control unit either by switching the power off and on, or using parameter [96.8 Control board boot](#) – this is mentioned in the fault listing wherever appropriate.

Warning and fault indications can be directed to a relay output or a digital input/output by selecting Warning, Fault or Fault (-1) in the source selection parameter. See the following sections:

- [Programmable digital inputs and outputs \(page 32\)](#)
- [Programmable relay outputs \(page 33\)](#), and
- [Programmable I/O extensions \(page 33\)](#).

### ■ Pure events

In addition to warnings and faults, there are pure events that are only recorded in the event logs of the drive. The codes of these events are included in the [Warning, fault and pure event messages](#) table.

### ■ Editable messages

For some warnings and faults, the message text can be edited and instructions and contact information added. To edit these messages, choose **Menu - Settings - Edit texts** on the control panel, or use the Localization editor in *Drive Composer pro*.

---



## Warning/fault history and analysis

### ■ Event logs

The drive has two event logs. One log contains faults and fault resets; the other contains warnings, pure events, and clearing entries. Each log contains the 64 most recent events with a time stamp and other information.

The logs can be accessed separately from the main Menu on the control panel. The logs are displayed as a single list when viewed using the Drive Composer PC tool.

The logs can be cleared using parameter [96.51 Clear fault and event logger](#).

### Auxiliary codes

Some events generate an auxiliary code that often helps in pinpointing the problem. The auxiliary code is displayed on the control panel together with the message. It is also stored in the event log details. In the Drive Composer PC tool, the auxiliary code (if any) is shown in the event listing.

### Factory data logger

The drive has a data logger that samples preselected drive values at 500-microsecond (default; see parameter [96.65 Factory data logger time level](#)) intervals.

The fault data of the last five faults is accessible in the event log when viewed in the Drive Composer pro PC tool. (The fault data is not accessible through the control panel.)

The values that are recorded in the factory data log are [1.7 Motor current](#), [1.10 Motor torque](#), [1.11 DC voltage](#), [1.24 Flux actual %](#), [6.1 Main control word](#), [6.11 Main status word](#), [24.1 Used speed reference](#), [30.1 Limit word 1](#), [30.2 Torque limit status](#) and [90.1 Motor speed for control](#). The selection of parameters cannot be changed by the user.

### ■ Other data loggers

#### User data logger

A custom data logger can be configured using the Drive Composer pro PC tool. This functionality enables the free selection of up to eight drive parameters to be sampled at selectable intervals. The triggering conditions and the length of the monitoring period can also be defined by the user within the limit of approximately 8000 samples. In addition to the PC tool, the status of the logger is shown by drive parameter [96.61 User data logger status word](#). The triggering sources can be selected by parameters [96.63 User data logger trigger](#) and [96.64 User data logger start](#). The configuration, status and collected data is saved to the memory unit for later analysis.

---

## PSL2 data logger

The BCU control unit used with certain drive types (especially those with parallel-connected inverter modules) contains a data logger that collects data from the inverter modules to help fault tracing and analysis. The data is saved onto the SD card attached to the BCU, and can be analyzed by ABB service personnel.

### ■ Parameters that contain warning/fault information

The drive is able to store a list of the active faults actually causing the drive to trip at the present time. The faults are displayed in parameter group [4 Warnings and faults \(page 146\)](#). The parameter group also displays a list of faults and warnings that have previously occurred.

### Event word (parameters *04.40...04.72*)

Parameter [4.40 Event word 1](#) can be configured by the user to indicate the status of 16 selectable events (ie. faults, warnings or pure events). It is possible to specify an auxiliary code for each event to filter out other auxiliary codes.

## QR Code generation for mobile service application

A QR Code (or a series of QR Codes) can be generated by the drive for display on the control panel. The QR Code contains drive identification data, information on the latest events, and values of status and counter parameters. The code can be read with a mobile device containing the ABB service application, which then sends the data to ABB for analysis. For more information on the application, contact your local ABB service representative.

The QR Code can be generated by choosing **Menu - Assistants - QR code** on the control panel.

---

## Warning, fault and pure event messages

Code (hex)	Event name / Aux. code	Cause	What to do
2281	Calibration	Measured offset of output phase current measurement or difference between output phase U2 and W2 current measurement is too great (the values are updated during current calibration).	Try performing the current calibration again (select <a href="#">Current measurement calibration</a> at parameter 99.13). If the fault persists, contact your local ABB representative.
2310	Overcurrent	Output current has exceeded internal fault limit.	<p>Check motor load.</p> <p>If the control unit is externally powered, check the setting of parameter 95.04 Control board supply. Check acceleration times in parameter group 23 <a href="#">Speed reference ramp</a> (speed control), 26 <a href="#">Torque reference chain</a> (torque control) or 28 <a href="#">Frequency reference chain</a> (frequency control). Also check parameters 46.1 <a href="#">Speed scaling</a>, 46.2 <a href="#">Frequency scaling</a> and 46.3 <a href="#">Torque scaling</a>.</p> <p>Check motor and motor cable (including phasing and delta/star connection).</p> <p>Check there are no contactors opening and closing in motor cable.</p> <p>Check that the start-up data in parameter group 99 corresponds to the motor rating plate.</p> <p>Check that there are no power factor correction capacitors or surge absorbers in motor cable.</p> <p>Check encoder cable (including phasing).</p> <p>Check the auxiliary code (format XXXY YYZZ). With parallel-connected inverter modules, "Y YY" specifies through which BCU control unit channel the fault was received. "ZZ" indicates the phase that triggered the fault (0: No detailed information available, 1: U-phase, 2: Vphase, 4: W-phase, 3/5/6/7: multiple phases).</p>
2330	Earth leakage	Drive has detected load unbalance typically due to earth fault in motor or motor cable.	<p>If the control unit is externally powered, check the setting of parameter 95.4 <a href="#">Control board supply</a>.</p> <p>Check there are no power factor correction capacitors or surge absorbers in motor cable.</p> <p>Check for an earth fault in motor or motor cables by measuring the insulation resistances of motor and motor cable.</p> <p>Try running the motor in scalar control mode if allowed. (See parameter 99.4 <a href="#">Motor control mode</a>.)</p>

580 Fault tracing

Code (hex)	Event name / Aux. code	Cause	What to do
			<p>With parallel-connected modules, check the auxiliary code (format XXXY YYZZ).                      “Y YY” specifies through which BCU control unit channel the fault was received.                      If no earth fault can be detected, contact your local ABB representative.</p>
2340	Short circuit	Short-circuit in motor cable(s) or motor.	<p>Check motor and motor cable for cabling errors.                      If the control unit is externally powered, check the setting of parameter <a href="#">95.4 Control board supply</a>.                      Check that parameter <a href="#">99.10 Motor nominal power</a> has been set correctly.                      Check there are no power factor correction capacitors or surge absorbers in motor cable.                      Check the auxiliary code (format XXXY YYZZ). With parallel-connected inverter modules, “Y YY” specifies through which BCU control unit channel the fault was received. “ZZ” indicates the location of the short circuit (<b>0</b>: No detailed information available, <b>1</b>: Upper branch of U-phase, <b>2</b>: Lower branch of U-phase, <b>4</b>: Upper branch of V-phase, <b>8</b>: Lower branch of V-phase, <b>10</b>: Upper branch of W-phase, <b>20</b>: Lower branch of W-phase, <b>other</b>: combinations of the above).                      Check auxiliary code 40h = DC capacitor short circuit.                      After correcting the cause of the fault, reboot the control unit (using parameter <a href="#">96.8 Control board boot</a>) or by cycling power.</p>
2381	IGBT overload	Excessive IGBT junction to case temperature. This fault protects the IGBT(s) and can be activated by a short circuit in the motor cable.	<p>Check motor cable.                      Check ambient conditions.                      Check air flow and fan operation.                      Check heatsink fins for dust pick-up.                      Check motor power against drive power.</p>
2391	BU current difference	AC phase current difference between parallel-connected inverter modules is excessive.	<p>Check motor cabling.                      Check there are no power factor correction capacitors or surge absorbers in motor cable.                      Check the auxiliary code (format XXXY YYZZ). “XXX” specifies the source of the first error (see “YYY”). “YYY” specifies the module through which BCU control unit channel the fault was received (<b>1</b>: Channel 1, <b>2</b>: Channel 2, <b>4</b>: Channel 3, <b>8</b>: Channel 4, ..., <b>800</b>: Channel 12, <b>other</b>: combinations of the</p>

Code (hex)	Event name / Aux. code	Cause	What to do
			above). "ZZ" indicates the phase (1: U, 2: V, 3: W).
2392	BU earth leakage	Total earth leakage of inverter modules is excessive.	Check there are no power factor correction capacitors or surge absorbers in motor cable. Measure insulation resistances of motor cables and motor. Contact your local ABB representative.
2E01	Earth leakage	IGBT supply unit has detected an earth fault.	Check AC fuses. Check for earth leakages. Check supply cabling. Check power modules. Check there are no power factor correction capacitors or surge absorbers in supply cable. If no earth fault can be detected, contact your local ABB representative.
3000	Invalid voltage chain datapoints	Parametrization of the speed/torque limitation curve (in the DC voltage reference chain) are inconsistent.	Check that the speed points of the curve (defined by 29.70...29.79) are in increasing order.
3130	Supply phase loss	Intermediate circuit DC voltage is oscillating due to missing input power line phase or blown fuse or unstable control.	Check input power line fuses. Check for loose power cable connections. Check for input power supply imbalance. Check the control stability and the speed controller settings.
3180	Charge relay lost	No acknowledgement received from charge relay.	Contact your local ABB representative.
3181	Wiring or earth fault	<ol style="list-style-type: none"> <li>1. The drive hardware is supplied from a common DC bus.</li> <li>2. Incorrect input power and motor cable connection (i.e. input power cable is connected to the motor connection).</li> <li>3. Drive has detected load unbalance typically due to earth fault in motor or motor cable.</li> </ol>	<ol style="list-style-type: none"> <li>1. Switch off the protection in parameter 31.23.</li> <li>2. Check the power connections. Check the input fuses.</li> <li>3. Check there are no power factor correction capacitors or surge absorbers in motor cable. Check for an earth fault in motor or motor cables by measuring the insulation resistances of motor and motor cable. Try running the motor in scalar control mode if allowed. (See parameter 99.4 Motor control mode.)</li> </ol>
3210	DC link overvoltage	Excessive intermediate circuit DC voltage.	Check that overvoltage control is on (parameter 30.30 Overvoltage control). Check that the supply voltage matches the nominal input voltage of the drive.

## 582 Fault tracing

Code (hex)	Event name / Aux. code	Cause	What to do
			<p>Check the supply line for static or transient overvoltage.</p> <p>Check brake chopper and resistor (if present).</p> <p>Check deceleration time.</p> <p>Use coast-to-stop function (if applicable).</p> <p>Retrofit drive with brake chopper and brake resistor.</p> <p>With parallel-connected modules, check the auxiliary code (format XXXY YYZZ).</p> <p>“Y YY” specifies through which BCU control unit channel the fault was received.</p>
3220	DC link undervoltage	Intermediate circuit DC voltage is not sufficient because of a missing supply phase, blown fuse or fault in the rectifier bridge.	<p>Check supply cabling, fuses and switchgear.</p> <p>With parallel-connected modules, check the auxiliary code (format XXXY YYZZ).</p> <p>“Y YY” specifies through which BCU control unit channel the fault was received.</p>
3280	Standby timeout	Automatic restart failed (see section <a href="#">Automatic restart (page 81)</a> ).	Check the condition of the supply (voltage, cabling, fuses, switchgear).
3291	DC voltage difference	Difference in DC voltages between parallel-connected inverter modules.	<p>Check the auxiliary code (format XXXY YYZZ). “XXX” specifies the source of the first error (see “YYY”). “YYY” specifies the module through which BCU control unit channel the fault was received (<b>1:</b> Channel 1, <b>2:</b> Channel 2, <b>4:</b> Channel 3, <b>8:</b> Channel 4, ..., <b>800:</b> Channel 12).</p>
3381	Output phase loss	Motor circuit fault due to missing motor connection (all three phases are not connected).	Connect motor cable.
3385	Autophasing	Autophasing routine (see section <a href="#">Autophasing (page 63)</a> ) has failed.	<p>For more information, check the auxiliary code.</p> <p>Check that the motor ID run has been successfully completed.</p> <p>Clear parameter <a href="#">98.15 Position offset user</a>.</p> <p>Check the setting of parameter <a href="#">99.3 Motor type</a>.</p>
	0001	Estimated and measured positions have opposite signs.	<p>Check the signs of measured and estimated speeds.</p> <p>Reverse encoder cable phasing or edit parameter <a href="#">99.16</a>.</p> <p>Check that the load torque is not too high for the Turning mode (must be less than 5%).</p>

Code (hex)	Event name / Aux. code	Cause	What to do
	0002	Motor is rotating during autophasing.	Check that the motor is not already rotating when the autophasing routine starts.
	0003	Too much difference between measured and estimated positions.	Check that encoder is not slipping. Check parameter 98.15 several times to verify that the autophasing routine gives consistent results. Check the motor model parameters.
	0004	Rotor did not rotate as expected between zero pulses.	Check that the zero pulses are given correctly.
	0005	Position estimate did not stabilize.	Check that the selected mode (parameter 21.13) is appropriate for the motor.
	0006	Measured position status information changed.	Check that parameter 90.41 is not changed to Estimate during the routine.
	0007	General autophasing failure.	Contact your local ABB representative.
	0008	Selected mode not supported.	Check that the selected mode (parameter 21.13) is supported by the motor type.
	0009	(LV-Synchro) Standstill failure.	Contact your local ABB representative.
3E00	Input phase loss	Input phase loss detected by the IGBT bridge.	Check the auxiliary code. Check the source of the fault corresponding to the code: 1: Phase A 2: Phase B 4: Phase C 8: Phase cannot be detected Check the AC fuses. Check for input power supply imbalance.
4000	Motor cable overload	Calculated motor cable temperature has exceeded warning limit.	Check the settings of parameters 35.61 and 35.62. Check the dimensioning of the motor cable in regard to required load.
4100	Ambient temperature	Drive module temperature is excessive.	Check ambient temperature. If it exceeds 40 °C (104 °F), ensure that load current does not exceed derated load capacity of drive. See appropriate <i>Hardware manual</i> . Check drive module cooling air flow and fan operation. Check inside of cabinet and heatsink of drive module for dust pick-up. Clean whenever necessary.
4110	Control board temperature	Control board temperature is too high.	Check proper cooling of the drive. Check the auxiliary cooling fan.
4210	IGBT overtemperature	Estimated drive IGBT temperature is excessive.	Check ambient conditions. Check air flow and fan operation. Check heatsink fins for dust pick-up. Check motor power against drive power.

584 Fault tracing

Code (hex)	Event name / Aux. code	Cause	What to do
4290	Cooling	Drive module temperature is excessive.	Check ambient temperature. If it exceeds 40 °C (104 °F), ensure that load current does not exceed derated load capacity of drive. See appropriate <i>Hardware manual</i> . Check drive module cooling air flow and fan operation. Check inside of cabinet and heatsink of drive module for dust pick-up. Clean whenever necessary.
42F1	IGBT temperature	Drive IGBT temperature is excessive.	Check ambient conditions. Check air flow and fan operation. Check heatsink fins for dust pick-up. Check motor power against drive power.
4310	Excess temperature	Power unit module temperature is excessive.	See <a href="#">A4B0 Excess temperature</a> .
4380	Excess temp difference	High temperature difference between the IGBTs of different phases.	See <a href="#">A4B1 Excess temperature difference (page 600)</a> .
4981	External temperature 1	Measured temperature 1 has exceeded fault limit.	Check the value of parameter <a href="#">35.2 Measured temperature 1</a> . Check the cooling of the motor (or other equipment whose temperature is being measured). Check the value of parameter <a href="#">35.12 Temperature 1 fault limit</a> .
4982	External temperature 2	Measured temperature 2 has exceeded fault limit.	Check the value of parameter <a href="#">35.3 Measured temperature 2</a> . Check the cooling of the motor (or other equipment whose temperature is being measured). Check the value of parameter <a href="#">35.22 Temperature 2 fault limit</a> .
4990	FPTC not found	A thermistor protection module has been activated by parameter <a href="#">35.30</a> but cannot be detected.	Power down the control unit and make sure that the module is properly inserted in the correct slot. The last digit of the auxiliary code identifies the slot.
4991	Safe motor temperature 1	The thermistor protection module installed in slot 1 indicates overtemperature.	Check the cooling of the motor. Check the motor load and drive ratings. Check the wiring of the temperature sensor. Repair wiring if faulty. Measure the resistance of the sensor. Replace sensor if faulty.
4992	Safe motor temperature 2	The thermistor protection module installed in slot 2 indicates overtemperature.	Check the cooling of the motor. Check the motor load and drive ratings. Check the wiring of the temperature sensor. Repair wiring if faulty. Measure the resistance of the sensor. Replace sensor if faulty.



Code (hex)	Event name / Aux. code	Cause	What to do
4993	Safe motor temperature 3	The thermistor protection module installed in slot 3 indicates overtemperature.	Check the cooling of the motor. Check the motor load and drive ratings. Check the wiring of the temperature sensor. Repair wiring if faulty. Measure the resistance of the sensor. Replace sensor if faulty.
5080	Fan	Cooling fan feedback missing.	See <a href="#">A581 Fan</a> .
5081	Auxiliary fan not running	An auxiliary cooling fan (connected to the fan connectors on the control unit) is stuck or disconnected.	See <a href="#">A582 Auxiliary fan not running</a> .
5090	STO hardware failure	Safe torque off hardware failure.	Contact your local ABB representative, quoting the auxiliary code. The code contains location information, especially with parallel-connected inverter modules. When converted into a 32-bit binary number, the bits of the code indicate the following: 31...28: Number of faulty inverter module (0...11 decimal). 1111: STO_ACT states of control unit and inverter modules in conflict 27: STO_ACT state of inverter modules 26: STO_ACT state of control unit 25: STO1 of control unit 24: STO2 of control unit 23...12: STO1 of inverter modules 12...1 (Bits of non-existing modules set to 1) 11...0: STO2 of inverter modules 12...1 (Bits of non-existing modules set to 1)
5091	Safe torque off	Safe torque off function is active, i.e. safety circuit signal(s) connected to connector XSTO is broken during start or run.	Check safe torque off circuit connections. For more information, see appropriate drive hardware manual and description of parameter <a href="#">31.22 STO indication run/stop (page 353)</a> .
5092	PU logic error	Power unit memory has cleared.	Cycle the power to the drive. If the control unit is externally powered, also reboot the control unit (using parameter <a href="#">96.8 Control board boot</a> ) or by cycling its power. If the problem persists, contact your local ABB representative.
5093	Rating ID mismatch	The hardware of the drive does not match the information stored in the memory unit. This may occur eg. after a firmware update or memory unit replacement.	Cycle the power to the drive. Check the auxiliary code (format 0X0Y). "X" indicates the first faulty PU channel in hexadecimal (1...C) (With a ZCU control unit, "X" can be 1 or 2 but this is irrelevant to the fault).

586 Fault tracing

Code (hex)	Event name / Aux. code	Cause	What to do
			<p>“Y” indicates the auxiliary code category.                      The auxiliary code categories are as follows:                      1 = PU and CU ratings not the same. Rating ID has changed.                      2 = Parallel connection rating ID has changed.                      3 = PU types not the same in all power units.                      4 = Parallel connection rating ID is active in a single power unit setup.                      5 = It is not possible to implement the selected rating with the current PUs.                      6 = PU rating ID is 0.                      7 = Reading PU rating ID or PU type failed on PU connection.                      8 = PU not supported (illegal rating ID).                      9 = Incompatible module current rating (unit contains a module with too low a current rating).  <b>A</b> - Selected parallel rating ID not found from database.                      With parallel connection faults (BCU control unit), the format of the auxiliary code is OXOY.</p>
5094	Measurement circuit temperature	Problem with internal temperature measurement of the drive.	See <a href="#">A5EA Measurement circuit temperature (page 602)</a> .
5681	PU communication	The way the control unit is powered does not correspond to parameter setting. Communication errors detected between the drive control unit and the power unit.	<p>Check setting of <a href="#">95.4 Control board supply</a>.                      Check the connection between the control unit and the power unit.                      Check the auxiliary code (format XXXY YYZZ). With parallel-connected modules, “Y YY” specifies the affected BCU control unit channel (<b>0</b>: broadcast). “ZZ” specifies the error source (<b>1</b>: Transmitter side [link error], <b>2</b>: Transmitter side [no communication], <b>3</b>: Receiver side [link error], <b>4</b>: Receiver side [no communication], <b>5</b>: Transmitter FIFO error [see “XXX”], <b>6</b>: Module [xINT board] not found, <b>7</b>: BAMU board not found).                      “XXX” specifies the transmitter FIFO error code (<b>1</b>: Internal error [invalid call parameter], <b>2</b>: Internal error [configuration not supported], <b>3</b>: Transmission buffer full).</p>
5682	Power unit lost	Connection between the drive control unit and the power unit is lost.	Check the connection between the control unit and the power unit.

Code (hex)	Event name / Aux. code	Cause	What to do
5690	PU communication internal	Internal communication error.	Contact your local ABB representative.
5691	Measurement circuit ADC	Measurement circuit fault.	If the control unit is externally powered, check the setting of parameter <a href="#">95.4 Control board supply</a> . If the problem persists, contact your local ABB representative, quoting the auxiliary code.
5692	PU board powerfail	Power unit power supply failure.	Check the auxiliary code (format ZZZY YYXX). “YY Y” specifies the affected inverter module ( <b>0</b> ... <b>C</b> , always <b>0</b> for ZCU control units). “XX” specifies the affected power supply ( <b>1</b> : Power supply 1, <b>2</b> : Power supply 2, <b>3</b> : both supplies).
5693	Measurement circuit DFF	Measurement circuit fault.	Contact your local ABB representative, quoting the auxiliary code.
5694	PU communication conf	Number of connected power modules differs from expected.	Check setting of <a href="#">95.31 Parallel type configuration</a> . Cycle the power to the drive. If the control unit is externally powered, also reboot the control unit (using parameter <a href="#">96.8 Control board boot</a> ) or by cycling its power. If the problem persists, contact your local ABB representative.
	0001	BAMU 1 is in the wrong channel.	
	0002	BAMU 2 is in the wrong channel.	
	0003	Power unit (xINT) is in the wrong channel.	
	0005	Too many power units (xINTs).	
5695	Reduced run	Number of inverter modules detected does not match the value of parameter <a href="#">95.13 Reduced run mode</a> .	Check that the value of <a href="#">95.13 Reduced run mode</a> corresponds to the number of inverter modules present. Check that the modules present are powered from the DC bus and connected by fiber optic cables to the BCU control unit. If all modules of the inverter unit are in fact available (eg. maintenance work has been completed), check that parameter <a href="#">95.13 Reduced run mode</a> is set to 0 (reduced run function disabled).
	0000	Parameter <a href="#">95.13 Reduced run mode</a> is set but all PUs are found. Incorrect channel bit.	Check that parameter <a href="#">95.12 Reduced run mask</a> is not set according to reduced PUs.
5696	PU state feedback	State feedback from output phases does not match control signals.	Contact your local ABB representative, quoting the auxiliary code.

## 588 Fault tracing

Code (hex)	Event name / Aux. code	Cause	What to do
5697	Charging feedback	<ul style="list-style-type: none"> <li>Incorrect parameter setting.</li> <li>The charging switch and DC switch were operated out of sequence, or a start command was issued before the unit was ready.</li> <li>Charging circuit fault.</li> <li>Brake circuit fault.</li> </ul>	<ul style="list-style-type: none"> <li>Check the setting of <a href="#">95.9 Switch fuse controller</a>. The parameter should be enabled only if an xSFC charging controller is installed.</li> <li>The normal power-up sequence is:               <ol style="list-style-type: none"> <li>Close charging switch.</li> <li>After charging finishes (charging OK lamp lights), close DC switch.</li> <li>Open charging switch.</li> </ol> </li> <li>Check the charging circuit. With a frame R6i/R7i inverter module, the auxiliary code "FA" indicates that the charging contactor status feedback does not match the control signal. With parallel-connected frame R8i modules, the auxiliary code (format XX00), "XX" specifies the affected BCU control unit channel.</li> <li>Check the wiring and condition of brake resistor.</li> </ul>
5698	Unknown PU fault	Unidentified power unit logic fault.	Check power unit logic and firmware compatibility. Contact your local ABB representative.
6000	Internal SW error	Internal error.	Contact your local ABB representative, quoting the auxiliary code.
6181	FPGA version incompatible	<ul style="list-style-type: none"> <li>Firmware and FPGA file version in the power unit are incompatible.</li> <li>Update of power unit logic failed.</li> </ul>	<ul style="list-style-type: none"> <li>Reboot the control unit (using parameter <a href="#">96.8 Control board boot</a>) or by cycling power. If the problem persists, contact your local ABB representative.</li> <li>Retry.</li> <li>Check the auxiliary code to identify FPGA version compatibility (format: XXYYZZ). "XX" (8: cannot recognize power unit logic, FPGA logic not compatible, 9 = power unit FPGA logic is old, update FPGA logic, 10 = software is not compatible with power unit FPGA logic, update software (or downgrade power unit FPGA)). YY = BCU control unit channel (first channel = 0)</li> </ul>
6200	Checksum mismatch	The calculated parameter checksum does not match any enabled reference checksum.	See <a href="#">A686 Checksum mismatch</a> .

Code (hex)	Event name / Aux. code	Cause	What to do
6306	FBA A mapping file	Fieldbus adapter A mapping file read error.	Contact your local ABB representative.
6307	FBA B mapping file	Fieldbus adapter B mapping file read error.	Contact your local ABB representative.
6481	Task overload	Internal fault.	Reboot the control unit (using parameter <a href="#">96.8 Control board boot</a> ) or by cycling power. If the problem persists, contact your local ABB representative.
6487	Stack overflow	Internal fault.	Reboot the control unit (using parameter <a href="#">96.8 Control board boot</a> ) or by cycling power. If the problem persists, contact your local ABB representative.
6488	Restart after firmware malfunction	Firmware malfunction.	Control unit has rebooted the drive due to CPU error exception, watchdog bark, watchdog bite, or unrecoverable DDR ECC error. If the Drive Composer PC tool is available, send a support package to your local ABB representative. For instructions, see the <i>Drive Composer start-up and maintenance PC tool user's manual</i> (3AUA0000094606 [English]).
64A1	Internal file load	File read error.	Reboot the control unit (using parameter <a href="#">96.8 Control board boot</a> ) or by cycling power. If the problem persists, contact your local ABB representative.
64A2	Internal record load	Internal record load error.	Contact your local ABB representative.
64A3	Application loading	Application file incompatible or corrupted.	Check the auxiliary code. See actions for each code below.
	8006	Not enough memory for the application.	Reduce the size of the application. Reduce the number of parameter mappings. See the drive-specific log generated by Automation Builder.
	8007	The application contains the wrong system library version.	Update the system library or reinstall Automation Builder. See the drive-specific log generated by Automation Builder.
	8008	The application is empty.	In Automation Builder, give a "Clean" command and reload the application.
	8009	The application contains invalid tasks.	In Automation Builder, check application task configuration, give a "Clean all" command, and reload the application.
800A	The application contains an unknown target (system) library function.	Update the system library or reinstall Automation Builder.	

## 590 Fault tracing

Code (hex)	Event name / Aux. code	Cause	What to do
			See the drive-specific log generated by Automation Builder.
64A5	Licensing fault	Running the control program is prevented either because a restrictive license exists, or because a required license is missing.	Record the auxiliary codes of all active licensing faults and contact your product vendor for further instructions.
64A6	Adaptive program	Error running the adaptive program.	Check the auxiliary code (format XXXX YYYY). "XXXX" specifies the number of the function block (0000 = generic error). "YYYY" indicates the problem (see actions for each code below).
	000A	Program corrupted or block non-existent.	Restore the template program or download the program to the drive.
	000C	Required block input missing.	Check the inputs of the block.
	000E	Program corrupted or block non-existent.	Restore the template program or download the program to the drive.
	0011	Program too large.	Remove blocks until the error stops.
	0012	Program is empty.	Correct the program and download it to the drive.
	001C	A nonexistent parameter or block is used in the program.	Edit the program to correct the parameter reference, or to use an existing block.
	001D	Parameter type invalid for selected pin.	Edit the program to correct the parameter reference.
	001E	Output to parameter failed because the parameter was write-protected.	Check the parameter reference in the program. Check for other sources affecting the target parameter.
0023, 0024	0023	Program file incompatible with current firmware version.	Adapt the program to current block library and firmware version.
	0024	Too many blocks.	Edit the program to reduce the number of blocks.
64B0	Memory unit detached	The memory unit was detached when the control unit was powered.	Switch off the power to the control unit and reinstall the memory unit. In case the memory unit was not actually removed when the fault occurred, check that the memory unit is properly inserted into its connector and its mounting screw is tight. Reboot the control unit (using parameter <a href="#">96.8 Control board boot</a> ) or by cycling power. If the problem persists, contact your local ABB representative.
64B1	Internal SSW fault	Internal fault.	Reboot the control unit (using parameter <a href="#">96.8 Control board boot</a> ) or by cycling power. If the problem persists, contact your local ABB representative.

Code (hex)	Event name / Aux. code	Cause	What to do
64B2	User set fault	<p>Loading of user parameter set failed because</p> <ul style="list-style-type: none"> <li>• set is not compatible with control program</li> <li>• drive was switched off during loading.</li> </ul>	Ensure that a valid user parameter set exists. Reload if uncertain.
64E1	Kernel overload	Operating system error.	Reboot the control unit (using parameter <a href="#">96.8 Control board boot</a> ) or by cycling power. If the problem persists, contact your local ABB representative.
64FF	Fault reset	Informative fault.	An active fault has been reset.
6581	Parameter system	Parameter load or save failed.	Try forcing a save using parameter <a href="#">96.7 Parameter save manually</a> . Retry.
6591	Backup/Restore Timeout	Parameter load or save timeout caused by communication break between drive and control panel, or control panel and PC tool.	Check the communication between drive and control panel or PC. Retry.
65A1	FBA A parameter conflict	The drive does not have a functionality requested by PLC, or requested functionality has not been activated.	Check PLC programming. Check settings of parameter groups <a href="#">50 Fieldbus adapter (FBA)</a> and <a href="#">51 FBA A settings</a> .
65A2	FBA B parameter conflict	The drive does not have a functionality requested by PLC, or requested functionality has not been activated.	Check PLC programming. Check settings of parameter groups <a href="#">50 Fieldbus adapter (FBA)</a> and <a href="#">54 FBA B settings</a> .
65B1	Reference source parametrization	A reference source is simultaneously connected to multiple parameters with different units.	See <a href="#">A6DA Reference source parametrization (page 605)</a> .
6681	EFB communication loss	Communication break in embedded fieldbus (EFB) communication.	Check the status of the fieldbus master (online/offline/error etc.). Check cable connections to the XD2D connector on the control unit.
6682	EFB configuration file	Embedded fieldbus (EFB) configuration file could not be read.	Contact your local ABB representative.
6683	EFB invalid parameterization	Embedded fieldbus (EFB) parameter settings inconsistent or not compatible with selected protocol.	Check the settings in parameter group <a href="#">58 Embedded fieldbus</a> .
6684	EFB load fault	<ul style="list-style-type: none"> <li>• Embedded fieldbus (EFB) protocol firmware could not be loaded.</li> <li>• Version mismatch between EFB protocol firmware and drive firmware.</li> </ul>	
6881	Text data overflow	Internal fault.	Reset the fault. Contact your local ABB representative if the fault persists.
6882	Text 32-bit table overflow	Internal fault.	Reset the fault. Contact your local ABB representative if the fault persists.

## 592 Fault tracing

Code (hex)	Event name / Aux. code	Cause	What to do
6883	Text 64-bit table overflow	Internal fault.	Reset the fault. Contact your local ABB representative if the fault persists.
6885	Text file overflow	Internal fault.	Reset the fault. Contact your local ABB representative if the fault persists.
7080	Option module comm loss	Communication between drive and an option module is lost.	See <a href="#">A798 Encoder option comm loss (page 608)</a> .
7081	Control panel loss	Control panel (or PC tool) has stopped communicating.	Check PC tool or control panel connection. Check control panel connector. Disconnect and reconnect the control panel. Check the auxiliary code. The code specifies the I/O port used as follows: <b>0:</b> Panel, <b>1:</b> Fieldbus interface A, <b>2:</b> Fieldbus interface B, <b>3:</b> Ethernet, <b>4:</b> D2D/EFB port).
7082	Ext I/O comm loss	The I/O extension module types specified by parameters do not match the detected configuration.	See <a href="#">A799 ExtIO comm loss (page 608)</a> .
7083	Panel reference conflict	Use of saved control panel reference in multiple control modes attempted.	The control panel reference can only be saved for one reference type at a time. Consider the possibility of using a copied reference instead of saved reference (see the reference selection parameter).
7084	Panel/PC tool version conflict	The current version of the control panel and/or PC tool does not support a function. (For example, older panel versions cannot be used as a source of external reference.)	Update control panel and/or PC tool. Contact your local ABB representative if necessary.
7085	Incompatible option module	Option module not supported. (For example, type Fxxx-xx-M fieldbus adapter modules are not supported.)	Check the auxiliary code. The code specifies the interface to which the unsupported module is connected: <b>1:</b> Fieldbus interface A, <b>2:</b> Fieldbus interface B. Replace the module with a supported type. <b>A</b> - FSO-xx module is not supported by the control board. Remove FSO-xx module to clear the fault. Connect FSO-xx module to the supported control board.
7121	Motor stall	Motor is operating in stall region because of e.g. excessive load or insufficient motor power.	Check motor load and drive ratings. Check fault function parameters.
7122	Motor overload	Motor current is too high.	Check for overloaded motor. Adjust the parameters used for the motor overload function <a href="#">35.51...35.53</a> ) and <a href="#">35.55...35.56</a> .



Code (hex)	Event name / Aux. code	Cause	What to do
7181	Brake resistor	DC overvoltage detected during braking.	Check that a brake resistor has been connected. Check the condition of the brake resistor. Check the dimensioning of the brake chopper and resistor.
7183	BR excess temperature	Brake resistor temperature has exceeded fault limit defined by parameter <a href="#">43.11 Brake resistor fault limit</a> .	Stop drive. Let resistor cool down. Check resistor overload protection function settings (parameter group <a href="#">43 Brake chopper</a> ). Check fault limit setting, parameter <a href="#">43.11 Brake resistor fault limit</a> . Check that braking cycle meets allowed limits.
7184	Brake resistor wiring	Brake resistor short circuit or brake chopper control fault.	Check brake chopper and brake resistor connection. Ensure brake resistor is not damaged. After correcting the cause of the fault, reboot the control unit (using parameter <a href="#">96.8 Control board boot</a> ) or by cycling power.
7191	BC short circuit	Short circuit in brake chopper IGBT.	Ensure brake resistor is connected and not damaged. Check the electrical specifications of the brake resistor against the <i>Hardware manual</i> . Replace brake chopper (if replaceable). After correcting the cause of the fault, reboot the control unit (using parameter <a href="#">96.8 Control board boot</a> ) or by cycling power.
7192	BC IGBT excess temperature	Brake chopper IGBT temperature has exceeded internal fault limit.	Let chopper cool down. Check for excessive ambient temperature. Check for cooling fan failure. Check for obstructions in the air flow. Check the dimensioning and cooling of the cabinet. Check resistor overload protection function settings (parameter group <a href="#">43 Brake chopper</a> ). Check that braking cycle meets allowed limits. Check that drive supply AC voltage is not excessive.
71A2	Mech brake closing failed	Mechanical brake control fault. Activated eg. if brake acknowledgement is not as expected during brake closing.	Check mechanical brake connection. Check mechanical brake settings in parameter group <a href="#">44 Mechanical brake control</a> . Check that acknowledgement signal matches actual status of brake.
71A3	Mech brake opening failed	Mechanical brake control fault.	Check mechanical brake connection.

594 Fault tracing

Code (hex)	Event name / Aux. code	Cause	What to do
		Activated eg. if brake acknowledgement is not as expected during brake opening.	Check mechanical brake settings in parameter group <a href="#">44 Mechanical brake control</a> . Check that acknowledgement signal matches actual status of brake.
71A5	Mech brk opening not allowed	Open conditions of mechanical brake cannot be fulfilled (for example, brake has been prevented from opening by parameter <a href="#">44.11 Keep brake closed</a> ). In an encoderless application, the brake is kept closed by a brake close request (either from parameter <a href="#">44.12 Brake close request</a> or from an FSO-xx safety functions module) against a modulating drive for longer than 5 seconds.	Check mechanical brake settings in parameter group <a href="#">44 Mechanical brake control</a> (especially <a href="#">44.11 Keep brake closed</a> ). Check that acknowledgement signal (if used) matches actual status of brake. Check the source signal selected by parameter <a href="#">44.12 Brake close request</a> . Check the safety circuits connected to the FSO-xx safety functions module.
71B1	Motor fan	No feedback received from external fan.	Check external fan (or other equipment controlled) by the logic. Check settings of parameters <a href="#">35.100...35.106</a> .
7301	Motor speed feedback	No motor speed feedback received.	See <a href="#">A7B0 Motor speed feedback (page 610)</a> .
7310	Overspeed	<ul style="list-style-type: none"> <li>Motor is turning faster than highest allowed speed due to incorrectly set minimum/maximum speed, insufficient braking torque or changes in load when using torque reference.</li> <li>Incorrect estimated speed.</li> </ul>	<ul style="list-style-type: none"> <li>Check minimum/maximum speed settings, parameters <a href="#">30.11 Minimum speed</a>, <a href="#">30.12 Maximum speed</a> and <a href="#">31.30 Overspeed trip margin</a>. Check adequacy of motor braking torque. Check applicability of torque control. Check need for brake chopper and resistor(s).</li> <li>Check the status of motor current measurement. Perform a <a href="#">Normal</a>, <a href="#">Advanced</a> or <a href="#">Advanced Standstill</a> ID run instead of, for example, a <a href="#">Reduced</a> or <a href="#">Standstill</a>. See parameter <a href="#">99.13 ID run requested (page 567)</a>.</li> </ul>
7380	Encoder internal	Internal fault.	Contact your local ABB representative.
7381	Encoder	Encoder feedback fault.	See <a href="#">A7E1 Encoder (page 612)</a> .
73A0	Speed fbk configuration	Speed feedback configuration incorrect.	See <a href="#">A797 Speed feedback configuration (page 607)</a> .
73A1	Load position feedback	No load position feedback received.	Check the auxiliary code (format XXYY ZZZZ). "XX" specifies the number of the encoder interface module ( <b>01</b> : <a href="#">91.11/91.12</a> , <b>02</b> : <a href="#">91.13/91.14</a> ), "YY" specifies the encoder ( <b>01</b> : <a href="#">92 Encoder 1 configuration</a> , <b>02</b> : <a href="#">93 Encoder 2</a>

Code (hex)	Event name / Aux. code	Cause	What to do
			configuration). "ZZZZ" indicates the problem (see actions for each code below).
	0001	Encoder stopped working.	Check encoder status.
	0002	Feed constant definition invalid or outside limits.	Check feed constant settings (90.63 and 90.64).
	0003	Motor/load gear definition invalid or outside limits.	Check motor/load gear settings (90.61 and 90.62).
	0004	Encoder not configured.	Check encoder settings (92 Encoder 1 configuration or 93 Encoder 2 configuration). Use parameter 91.10 Encoder parameter refresh) to validate any changes in the settings.
	0005	Encoder stopped working.	Check encoder status.
73B0	Emergency ramp failed	Emergency stop did not finish within expected time.	Check the settings of parameters 31.32 Emergency ramp supervision and 31.33 Emergency ramp supervision delay. Check the predefined ramp times (23.11...23.19 for mode Off1, 23.23 for mode Off3).
73B1	Stop failed	Ramp stop did not finish within expected time.	Check the settings of parameters 31.37 Ramp stop supervision and 31.38 Ramp stop supervision delay. Check the predefined ramp times in parameter group 23 Speed reference ramp.
73F0	Overfrequency	Maximum allowed output frequency exceeded.	Without a dual-use license, the fault limit is 598 Hz. Contact your local ABB representative for dual-use licensing information.
7510	FBA A communication	Cyclical communication between drive and fieldbus adapter module A or between PLC and fieldbus adapter module A is lost.	Check status of fieldbus communication. See user documentation of fieldbus interface. Check settings of parameter groups 50 Fieldbus adapter (FBA), 51 FBA A settings, 52 FBA A data in and 53 FBA A data out. Check cable connections. Check if communication master is able to communicate.
	0002	Communication problem between adapter and control unit.	Check communication connections between adapter and drive.
	0004	Communication problem between adapter and PLC or parameters refreshed using the parameter 51.27 FBA A par refresh while PLC was communicating with the adapter.	Refresh parameters only when necessary to avoid loss of communication.
	0005	Lost communication with fieldbus communication adapter.	Check fieldbus communication adapter.

## 596 Fault tracing

Code (hex)	Event name / Aux. code	Cause	What to do
7520	FBA B communication	Cyclical communication between drive and fieldbus adapter module B or between PLC and fieldbus adapter module B is lost.	Check status of fieldbus communication. See user documentation of fieldbus interface. Check settings of parameter group <a href="#">50 Fieldbus adapter (FBA)</a> . Check cable connections. Check if communication master is able to communicate.
	0002	Communication problem between adapter and drive.	Check communication connections between adapter and drive.
	0004	Communication problem between adapter and PLC or parameters refreshed using the parameter <a href="#">51.27 FBA A par refresh</a> while PLC was communicating with the adapter.	Refresh parameters only when necessary to avoid loss of communication.
	0005	Lost communication with fieldbus communication adapter.	Check fieldbus communication adapter.
7580	INU-LSU comm loss	DDCS (fiber optic) communication between converters (for example, the inverter unit and the supply unit) is lost.	Check status of other converter (parameter group <a href="#">6 Control and status words</a> ). Check settings of parameter group <a href="#">60 DDCS communication</a> . Check the corresponding settings in the control program of the other converter. Check cable connections. If necessary, replace cables.
7581	DDCS controller comm loss	DDCS (fiber optic) communication between drive and external controller is lost.	Check status of controller. See user documentation of controller. Check settings of parameter group <a href="#">60 DDCS communication</a> . Check cable connections. If necessary, replace cables.
7582	M/F comm loss	Master/follower communication is lost.	See <a href="#">A7CB M/F comm loss (page 612)</a> .
7583	Line side unit faulted	The supply unit (or other converter) connected to the inverter unit has generated a fault.	The auxiliary code specifies the original fault code in the supply unit control program. See section <a href="#">Auxiliary codes for line-side converter faults (page 625)</a> .
7584	LSU charge failed	The supply unit was not ready (ie. the main contactor/breaker could not be closed) within expected time.	Check that communication to the supply unit has been activated by <a href="#">95.20 HW options word 1</a> . Check setting of parameter <a href="#">94.10 LSU max charging time</a> . Check that the supply unit is enabled, allowed to start, and can be controlled by the inverter unit (eg. not in local control mode).
8001	ULC underload	Selected signal has fallen below the user underload curve.	See <a href="#">A8BF ULC underload (page 615)</a> .

Code (hex)	Event name / Aux. code	Cause	What to do
8002	ULC overload	Selected signal has exceeded the user overload curve.	See <a href="#">A8BE ULC overload (page 615)</a> .
80A0	AI Supervision	An analog signal is outside the limits specified for the analog input.	Check the auxiliary code (format XXXX XYZZ). "Y" specifies the location of the input ( <b>0</b> : Control unit, <b>1</b> : I/O extension module 1, <b>2</b> : I/O extension module 2, <b>3</b> : I/O extension module 3). "ZZ" specifies the limit ( <b>01</b> : AI1 under minimum, <b>02</b> : AI1 above maximum, <b>03</b> : AI2 under minimum, <b>04</b> : AI2 above maximum). Check signal level at the analog input. Check the wiring connected to the input. Check the minimum and maximum limits of the input in parameter group <a href="#">12 Standard AI</a> .
80B0	Signal supervision	Fault generated by the signal supervision 1 function.	Check the source of the fault (parameter <a href="#">32.7 Supervision 1 signal</a> ).
80B1	Signal supervision 2	Fault generated by the signal supervision 2 function.	Check the source of the fault (parameter <a href="#">32.17 Supervision 2 signal</a> ).
80B2	Signal supervision 3	Fault generated by the signal supervision 3 function.	Check the source of the fault (parameter <a href="#">32.27 Supervision 3 signal</a> ).
9081	External fault 1	Fault in external device 1.	Check the external device. Check setting of parameter <a href="#">31.1 External event 1 source</a> .
9082	External fault 2	Fault in external device 2.	Check the external device. Check setting of parameter <a href="#">31.3 External event 2 source</a> .
9083	External fault 3	Fault in external device 3.	Check the external device. Check setting of parameter <a href="#">31.5 External event 3 source</a> .
9084	External fault 4	Fault in external device 4.	Check the external device. Check setting of parameter <a href="#">31.7 External event 4 source</a> .
9085	External fault 5	Fault in external device 5.	Check the external device. Check setting of parameter <a href="#">31.9 External event 5 source</a> .
A2A1	Current calibration	Current offset and gain measurement calibration will occur at next start.	Informative warning. (See parameter <a href="#">99.13 ID run requested</a> .)
A2B3	Earth leakage	Drive has detected load unbalance typically due to earth fault in motor or motor cable.	Check there are no power factor correction capacitors or surge absorbers in motor cable. Check for an earth fault in motor or motor cables by measuring the insulation resistances of motor and motor cable. Try running the motor in scalar control mode if allowed. (See parameter <a href="#">99.4 Motor control mode</a> .)

## 598 Fault tracing

Code (hex)	Event name / Aux. code	Cause	What to do
			If no earth fault can be detected, contact your local ABB representative.
A2B4	Short circuit	Short-circuit in motor cable(s) or motor.	Check motor and motor cable for cabling errors. Check there are no power factor correction capacitors or surge absorbers in motor cable.
A2BA	IGBT overload	Excessive IGBT junction to case temperature. This warning protects the IGBT(s) and can be activated by a short circuit in the motor cable.	Check motor cable. Check ambient conditions. Check air flow and fan operation. Check heatsink fins for dust pick-up. Check motor power against drive power.
A3A1	DC link overvoltage	Intermediate circuit DC voltage too high (when the drive is stopped).	Check the supply voltage setting (parameter <a href="#">95.1 Supply voltage</a> ). Note that the wrong setting of the parameter may cause the motor to rush uncontrollably, or may overload the brake chopper or resistor. Check the supply voltage. If the problem persists, contact your local ABB representative.
A3A2	DC link undervoltage	Intermediate circuit DC voltage too low (when the drive is stopped).	Check the supply voltage setting (parameter <a href="#">95.1 Supply voltage</a> ). Note that the wrong setting of the parameter may cause the motor to rush uncontrollably, or may overload the brake chopper or resistor. Check the supply voltage. If the problem persists, contact your local ABB representative.
A3AA	DC not charged	The voltage of the intermediate DC circuit has not yet risen to operating level.	Check the supply voltage setting (parameter <a href="#">95.1 Supply voltage</a> ). Note that the wrong setting of the parameter may cause the motor to rush uncontrollably, or may overload the brake chopper or resistor. Check the supply voltage. If the problem persists, contact your local ABB representative.
A480	Motor cable overload	Calculated motor cable temperature has exceeded warning limit.	Check the settings of parameters <a href="#">35.61</a> and <a href="#">35.62</a> . Check the dimensioning of the motor cable in regard to required load.
A490	Incorrect temperature sensor setup	Problem with motor temperature measurement.	Check the auxiliary code (format OXY YZZZ). "X" identifies the affected temperature monitoring function (1 = parameter <a href="#">35.11</a> , 2 = parameter <a href="#">35.21</a> ). "YY" indicates the selected temperature source, ie. the setting of the selection parameter in hexadecimal.

Code (hex)	Event name / Aux. code	Cause	What to do
			"ZZZZ" indicates the problem (see actions for each code below).
	0001	Sensor type mismatch.	Check parameters 35.11/35.21 against 91.21/91.24.
	0002	Temperature under limit.	Check parameters 35.11...35.14/35.21...35.24 (and 91.21/91.24 if sensor is connected to an encoder interface). Check the sensor and its wiring.
	0003	Short circuit.	Check parameters 35.11...35.14/35.21...35.24 (and 91.21/91.24 if sensor is connected to an encoder interface). Check the sensor and its wiring.
	0004	Open circuit.	Check parameters 35.11...35.14/35.21...35.24 (and 91.21/91.24 if sensor is connected to an encoder interface). Check the sensor and its wiring.
A491	External temperature 1	Measured temperature 1 has exceeded warning limit.	Check the value of parameter 35.2 Measured temperature 1. Check the cooling of the motor (or other equipment whose temperature is being measured). Check the value of 35.13 Temperature 1 warning limit.
A492	External temperature 2	Measured temperature 2 has exceeded warning limit.	Check the value of parameter 35.3 Measured temperature 2. Check the cooling of the motor (or other equipment whose temperature is being measured). Check the value of 35.23 Temperature 2 warning limit.
A497	Motor temperature 1	The thermistor protection module installed in slot 1 indicates overtemperature.	Check the cooling of the motor. Check the motor load and drive ratings. Check the wiring of the temperature sensor. Repair wiring if faulty. Measure the resistance of the sensor. Replace sensor if faulty.
A498	Motor temperature 2	The thermistor protection module installed in slot 2 indicates overtemperature.	Check the cooling of the motor. Check the motor load and drive ratings. Check the wiring of the temperature sensor. Repair wiring if faulty. Measure the resistance of the sensor. Replace sensor if faulty.
A499	Motor temperature 3	The thermistor protection module installed in slot 3 indicates overtemperature.	Check the cooling of the motor. Check the motor load and drive ratings. Check the wiring of the temperature sensor. Repair wiring if faulty. Measure the resistance of the sensor.

## 600 Fault tracing

Code (hex)	Event name / Aux. code	Cause	What to do
			Replace sensor if faulty.
A4A0	Control board temperature	Control unit temperature is excessive.	Check the auxiliary code. See actions for each code below.
	–  1	Temperature above warning limit.  Thermistor broken.	Check ambient conditions. Check air flow and fan operation. Check heatsink fins for dust pick-up. Contact an ABB service representative for control unit replacement.
A4A9	Cooling	Drive module temperature is excessive.	Check ambient temperature. If it exceeds 40 °C (104 °F), ensure that load current does not exceed derated load capacity of drive. See appropriate Hardware manual. Check drive module cooling air flow and fan operation. Check inside of cabinet and heatsink of drive module for dust pick-up. Clean whenever necessary.
A4B0	Excess temperature	Power unit temperature is excessive.	Check ambient conditions. Check air flow and fan operation. Check the setting of <a href="#">31.36 Aux fan fault function</a> (if present). Check heatsink fins for dust pick-up. Check motor power against drive power. See <a href="#">A5EA Measurement circuit temperature (page 602)</a> .
A4B1	Excess temperature difference	High temperature difference between the IGBTs of different phases.	Check the motor cabling. Check cooling of drive module(s). Check the auxiliary code (format XXXY YYZZ). “XXX” indicates the source of difference ( <b>0</b> : Single module, difference between phase IGBTs, <b>1</b> : parallel-connected modules, minimum-maximum difference between all IGBTs of all modules, <b>2</b> : parallel-connected modules, minimum-maximum difference between auxiliary power supply boards). With parallel-connected modules, “Y YY” specifies through which BCU control unit channel the highest temperature was measured. “ZZ” specifies the phase ( <b>0</b> : single module, <b>1</b> : U-phase [parallel connection], <b>2</b> : V-phase [parallel connection], <b>3</b> : W-phase [parallel connection]).
A4F6	IGBT temperature	Drive IGBT temperature is excessive.	Check ambient conditions. Check air flow and fan operation. Check heatsink fins for dust pick-up. Check motor power against drive power.



Code (hex)	Event name / Aux. code	Cause	What to do
A580	PU communication	Communication errors detected between the drive control unit and the power unit.	Check the connections between the drive control unit and the power unit. Check the auxiliary code (format XXXY YYZZ). With parallel-connected modules, "Y YY" specifies the affected BCU control unit channel ( <b>0</b> : broadcast). "ZZ" specifies the error source ( <b>8</b> : Transmission errors in PSL link [see "XXX"], <b>9</b> : Transmitter FIFO warning limit hit). "XXX" specifies the transmission error direction and detailed warning code ( <b>0</b> : Rx/communication error, <b>1</b> : Tx/Reed-Solomon symbol error, <b>2</b> : Tx/no synchronization error, <b>3</b> : Tx/Reed-Solomon decoder failures, <b>4</b> : Tx/Manchester coding errors). Read the PSL2 data log. In Drive Composer pro, check the time stamp of the A580 fault. Load the log with the same date and time. When the file opens, click "Show fault log". Check the power unit hardware.
A581	Fan	Cooling fan feedback missing.	Check the setting of parameter <a href="#">95.20 HW options word 1</a> , bit 14. Check the auxiliary code to identify the fan. Code 0 denotes main fan 1. Other codes (format XYZ): "X" specifies state code ( <b>1</b> : ID run, <b>2</b> : normal). "Y" specifies the index of the inverter module connected to BCU ( <b>0...n</b> , always <b>0</b> for ZCU control units). "Z" specifies the index of the fan ( <b>1</b> : Main fan 1, <b>2</b> : Main fan 2, <b>3</b> : Main fan 3). Note that modules are coded starting from 0. For example, the code <b>101</b> means that Main fan 1 of module 1 (connected to BCU channel V1T/V1R) has faulted during its ID run. Check fan operation and connection. Replace fan if faulty.
A582	Auxiliary fan not running	An auxiliary cooling fan (connected to the fan connectors on the control unit) is stuck or disconnected.	The auxiliary code identifies the fan ( <b>1</b> : Auxiliary fan 1, <b>2</b> : Auxiliary fan 2). Check that the auxiliary fan supervision selection in parameter <a href="#">95.21 HW options word 2</a> matches the hardware. Make sure the front cover of the drive module is in place and tightened. Check auxiliary fan(s) and connection(s). Replace faulty fan.

## 602 Fault tracing

Code (hex)	Event name / Aux. code	Cause	What to do
A5A0	Safe torque off	Safe torque off function is active, i.e. safety circuit signal(s) connected to connector XSTO is lost.	Check safety circuit connections. For more information, see appropriate drive hardware manual and description of parameter <a href="#">31.22 STO indication run/stop (page 353)</a> .
A5EA	Measurement circuit temperature	Problem with internal temperature measurement of the drive.	Check the auxiliary code (format XXXY YYZZ). "Y YY" specifies through which BCU control unit channel the fault was received ("0 00" with a ZCU control unit). "ZZ" specifies the location: <u>With control program version 2.8x and later:</u> <b>1:</b> U-phase IGBT, <b>2:</b> V-phase IGBT, <b>3:</b> W-phase IGBT, <b>4:</b> Power supply board, <b>5:</b> Power unit xINT board, <b>6:</b> Brake chopper, <b>7:</b> Air inlet (TEMP3, X10), <b>8:</b> du/dt filter (TEMP2, X7), <b>9:</b> TEMP1 (X6) Power supply heatsink on ACS880-x04LC frame R7i module. <u>With control program version up to and including 2.7x:</u> <b>1:</b> U-phase IGBT, <b>2:</b> V-phase IGBT, <b>3:</b> W-phase IGBT, <b>4:</b> Power unit INT board, <b>5:</b> Brake chopper, <b>6:</b> Air inlet, <b>7:</b> Power supply board, <b>8:</b> du/dt filter, <b>FAh:</b> Air in temp.
A5EB	PU board powerfail	Power unit power supply failure.	Contact your local ABB representative.
A5EC	PU communication internal	Communication errors detected between the drive control unit and the power unit.	Check the connections between the drive control unit and the power unit.
A5ED	Measurement circuit ADC	Problem with measurement circuit of power unit (analog to digital converter).	Contact your local ABB representative.
A5EE	Measurement circuit DFF	Problem with current or voltage measurement of power unit.	Contact your local ABB representative.
A5EF	PU state feedback	State feedback from output phases does not match control signals.	Contact your local ABB representative.
A5F0	Charging feedback	Charging in progress.	Informative warning. Wait until charging finishes before starting the inverter unit. Charging with the manual fuse switch controller (xSFC) must be ended within two minutes. After that the warning informs that the charging resistor is still connected.
A5F3	Switching frequency below requested	Adequate motor control at requested output frequency cannot be reached because of limited switching frequency (eg. by parameter <a href="#">95.15</a> ).	Informative warning.
A5F4	Control unit battery	The battery of the control unit is low.	Replace control unit battery. This warning can be suppressed using parameter <a href="#">31.40</a> .

Code (hex)	Event name / Aux. code	Cause	What to do
A682	Flash erase speed exceeded	The flash memory (in the memory unit) has been erased too frequently, compromising the lifetime of the memory.	Avoid forcing unnecessary parameter saves by parameter 96.7 or cyclic parameter writes (such as user logger triggering through parameters). Check the auxiliary code (format XYYY YZZZ). "X" specifies the source of warning (1: generic flash erase supervision). "ZZZ" specifies the flash subsector number that generated the warning.
A683	Data saving to power unit	An error in saving data to the power unit.	Check the auxiliary code. See actions for each code below.
	0, 1	An error is preventing saving from initializing.	Cycle the power to the drive. If the control unit is externally powered, also reboot the control unit (using parameter 96.8 Control board boot) or by cycling its power. If the problem persists, contact your local ABB representative.
A684	2	Write error.	Cycle the power to the drive. If the control unit is externally powered, also reboot the control unit (using parameter 96.8 Control board boot) or by cycling its power. If the problem persists, contact your local ABB representative.
	SD card	Error related to SD card used to store data (BCU control unit only).	Check the auxiliary code. See actions for each code below.
A685	0	No SD card.	Insert a compatible, writable SD card into the SD CARD slot of the BCU control unit.
	1	SD card write-protected.	Insert a compatible, writable SD card into the SD CARD slot of the BCU control unit.
	2	SD card unreadable.	Insert a compatible, writable SD card into the SD CARD slot of the BCU control unit.
	3	SD card initialization failed.	Insert a compatible, writable SD card into the SD CARD slot of the BCU control unit.
A686	Power fail saving	Power fail saving is requested too frequently. Because of the limited saving interval, some of the requests do not trigger the saving and power fail data may be lost. This may be caused by DC voltage oscillation.	Check the supply voltage.
A686	Checksum mismatch	The calculated parameter checksum does not match any enabled reference checksum.	Check that all necessary approved (reference) checksums (96.56...96.59) are enabled in 96.55 Checksum control word. Check the parameter configuration. Using 96.55 Checksum control word, enable a checksum parameter and

## 604 Fault tracing

Code (hex)	Event name / Aux. code	Cause	What to do
			copy the actual checksum into that parameter.
A687	Checksum configuration	An action has been defined for a parameter checksum mismatch but the feature has not been configured.	Contact your local ABB representative for configuring the feature, or disable the feature in <a href="#">96.54 Checksum action</a> .
A688	Parameter map configuration	Too much data in parameter mapping table created in Drive customizer.	See the <i>Drive customizer PC tool user's manual</i> (3AUA0000104167 [English]).
A689	Mapped parameter value cut	Parameter value saturated eg. by the scaling specified in parameter mapping table (created in Drive customizer).	Check parameter scaling and format in parameter mapping table. See the <i>Drive customizer PC tool user's manual</i> (3AUA0000104167 [English]).
A6A4	Motor nominal value	The motor parameters are set incorrectly. The drive is not dimensioned correctly.	Check the auxiliary code. See actions for each code below.
	1	Slip frequency is too small.	Check the settings of the motor configuration parameters in groups 98 and 99. Check that the drive is sized correctly for the motor.
	2	Synchronous and nominal speeds differ too much.	Check the settings of the motor configuration parameters in groups 98 and 99. Check that the drive is sized correctly for the motor.
	3	Nominal speed is higher than synchronous speed with 1 pole pair.	Check the settings of the motor configuration parameters in groups 98 and 99. Check that the drive is sized correctly for the motor.
	4	Nominal current is outside limits.	Check the settings of the motor configuration parameters in groups 98 and 99. Check that the drive is sized correctly for the motor.
	5	Nominal voltage is outside limits.	Check the settings of the motor configuration parameters in groups 98 and 99. Check that the drive is sized correctly for the motor.
	6	Mechanical nominal power is higher than electrical active power.	Check the settings of the motor configuration parameters in groups 98 and 99. Check that the drive is sized correctly for the motor.
	7	Nominal power not consistent with nominal speed and torque.	Check the settings of the motor configuration parameters in groups 98 and 99. Check that the drive is sized correctly for the motor.
A6A5	No motor data	Parameters in group 99 have not been set.	Check that all the required parameters in group 99 have been set.

Code (hex)	Event name / Aux. code	Cause	What to do
			<b>Note:</b> It is normal for this warning to appear during the start-up and continue until the motor data is entered.
A6A6	Supply voltage unselected	The supply voltage has not been defined.	Set supply voltage in parameter <a href="#">95.1 Supply voltage</a> .
A6B0	User lock open	The user lock is open, ie. user lock configuration parameters <a href="#">96.100...96.102</a> are visible.	Close the user lock by entering an invalid pass code in parameter <a href="#">96.2 Pass code</a> . See section <a href="#">User lock (page 105)</a> .
A6B1	User pass code not confirmed	A new user pass code has been entered in parameter <a href="#">96.100</a> but not confirmed in <a href="#">96.101</a> .	Confirm the new pass code by entering the same code in <a href="#">96.101</a> . To cancel, close the user lock without confirming the new code. See section <a href="#">User lock (page 105)</a> .
A6D1	FBA A parameter conflict	The drive does not have a functionality requested by a PLC, or requested functionality has not been activated.	Check PLC programming. Check settings of parameter groups <a href="#">50 Fieldbus adapter (FBA)</a> and <a href="#">51 FBA A settings</a> .
A6D2	FBA B Parameter conflict	The drive does not have a functionality requested by a PLC, or requested functionality has not been activated.	Check PLC programming. Check settings of parameter groups <a href="#">50 Fieldbus adapter (FBA)</a> and <a href="#">54 FBA B settings</a> .
A6DA	Reference source parametrization	A reference source is simultaneously connected to multiple parameters with different units.	Check the reference source selection parameters. Check the auxiliary code (format <a href="#">XXYY 00ZZ</a> ). "XX" and "YY" specify the two sets of parameters where the source was connected to (01 = speed reference chain [ <a href="#">22.11</a> , <a href="#">22.12</a> , <a href="#">22.15</a> , <a href="#">22.17</a> ], 02 = frequency reference chain [ <a href="#">28.11</a> , <a href="#">28.12</a> ], 03 = torque reference chain [ <a href="#">26.11</a> , <a href="#">26.12</a> , <a href="#">26.16</a> ], 04 = other torque-related parameters [ <a href="#">26.25</a> , <a href="#">30.21</a> , <a href="#">30.22</a> , <a href="#">44.9</a> ], 05 = process PID control parameters [ <a href="#">40.16</a> , <a href="#">40.17</a> , <a href="#">40.50</a> , <a href="#">41.16</a> , <a href="#">41.17</a> , <a href="#">41.50</a> ]). "ZZ" indicates the conflicting reference source ( <a href="#">01...0E</a> = index in parameter group 3, <a href="#">33</a> = process PID control, <a href="#">3D</a> = motor potentiometer, <a href="#">65</a> = AI1, <a href="#">66</a> = AI2, <a href="#">6F</a> = frequency input).
A6E5	AI parametrization	The current/voltage hardware setting of an analog input does not correspond to parameter settings.	Check the auxiliary code. The code identifies the analog input whose settings are in conflict. Adjust either the hardware setting (on the drive control unit) or parameter <a href="#">12.15/12.25</a> .

## 606 Fault tracing

Code (hex)	Event name / Aux. code	Cause	What to do
			<b>Note:</b> Control board reboot (either by cycling the power or through parameter <a href="#">96.8 Control board boot</a> ) is required to validate any changes in the hardware settings.
A6E6	ULC configuration	User load curve configuration error.	Check the auxiliary code (format XXXX ZZZZ). "ZZZZ" indicates the problem (see actions for each code below).
	0000	Speed points inconsistent.	Check that each speed point (parameters <a href="#">37.11...37.15</a> ) has a higher value than the previous point.
	0001	Frequency points inconsistent.	Check that each frequency point ( <a href="#">37.16...37.20</a> ) has a higher value than the previous point.
	0002	Underload point above overload point.	Check that each overload point ( <a href="#">37.31...37.35</a> ) has a higher value than the corresponding underload point ( <a href="#">37.21...37.25</a> ).
	0003	Overload point below underload point.	Check that each overload point ( <a href="#">37.31...37.35</a> ) has a higher value than the corresponding underload point ( <a href="#">37.21...37.25</a> ).
A780	Motor stall	Motor is operating in stall region because of e.g. excessive load or insufficient motor power.	Check motor load and drive ratings. Check fault function parameters.
A781	Motor fan	No feedback received from external fan.	Check external fan (or other equipment controlled) by the logic. Check settings of parameters <a href="#">35.100...35.106</a> .
A782	FEN temperature	<ul style="list-style-type: none"> <li>Error in temperature measurement when temperature sensor (KTY or PTC) connected to encoder interface FEN-xx is used.</li> <li>Error in temperature measurement when KTY sensor connected to encoder interface FEN-01 is used.</li> </ul>	<ul style="list-style-type: none"> <li>Check that parameter <a href="#">35.11 Temperature 1 source</a> / <a href="#">35.21 Temperature 2 source</a> setting corresponds to actual encoder interface installation. Check the settings of parameters <a href="#">91.21</a> and <a href="#">91.24</a>. Check that the corresponding module is activated in parameters <a href="#">91.11...91.14</a>. Use parameter <a href="#">91.10 Encoder parameter refresh</a> to validate any changes in the settings.</li> <li>FEN-01 does not support temperature measurement with KTY sensor. Use PTC sensor or other encoder interface module.</li> </ul>
A783	Motor overload	Motor current is too high.	Check for overloaded motor. Adjust the parameters used for the motor overload function ( <a href="#">35.51...35.53</a> ) and <a href="#">35.55...35.56</a> .
A791	Brake resistor	Brake resistor broken or not connected.	Check that a brake resistor has been connected.

Code (hex)	Event name / Aux. code	Cause	What to do
			Check the condition of the brake resistor.
A793	BR excess temperature	Brake resistor temperature has exceeded warning limit defined by parameter <a href="#">43.12 Brake resistor warning limit</a> .	Stop drive. Let resistor cool down. Check resistor overload protection function settings (parameter group <a href="#">43 Brake chopper</a> ). Check warning limit setting, parameter <a href="#">43.12 Brake resistor warning limit</a> . Check that the resistor has been dimensioned correctly. Check that braking cycle meets allowed limits.
A794	BR data	Brake resistor data has not been given.	One or more of the resistor data settings (parameters <a href="#">43.8...43.10</a> ) is incorrect. The parameter is specified by the auxiliary code.
	0000 0001	Resistance value too low.	Check value of <a href="#">43.10</a> .
	0000 0002 0000 0003	Thermal time constant not given. Maximum continuous power not given.	Check value of <a href="#">43.8</a> . Check value of <a href="#">43.9</a> .
A797	Speed feedback configuration	Speed feedback configuration has changed.	Check the auxiliary code (format XXYY ZZZZ). "XX" specifies the number of the encoder interface module ( <b>01: <a href="#">91.11/91.12</a>, <b>02: <a href="#">91.13/91.14</a>, "YY" specifies the encoder (<b>01: <a href="#">92 Encoder 1 configuration</a>, <b>02: <a href="#">93 Encoder 2 configuration</a></b>). "ZZZZ" indicates the problem (see actions for each code below).</b></b></b>
	0001	Adapter not found in specified slot.	Check module location ( <a href="#">91.12</a> or <a href="#">91.14</a> ).
	0002	Detected type of interface module does not match parameter setting.	Check the module type ( <a href="#">91.11</a> or <a href="#">91.13</a> ) against status ( <a href="#">91.2</a> or <a href="#">91.3</a> ).
	0003	Logic version too old.	Contact your local ABB representative.
	0004	Software version too old.	Contact your local ABB representative.
	0006	Encoder type incompatible with interface module type.	Check module type ( <a href="#">91.11</a> or <a href="#">91.13</a> ) against encoder type ( <a href="#">92.1</a> or <a href="#">93.1</a> ).
	0007	Adapter not configured.	Check module location ( <a href="#">91.12</a> or <a href="#">91.14</a> ).
	0008	Speed feedback configuration has changed.	Use parameter <a href="#">91.10 Encoder parameter refresh</a> to validate any changes in the settings.
	0009	No encoders configured to encoder module.	Configure the encoder in group <a href="#">92 Encoder 1 configuration</a> or <a href="#">93 Encoder 2 configuration</a> .
	000A 000B	Non-existing emulation input. Echo not supported by selected input (for example, resolver or absolute encoder).	Check input selection ( <a href="#">91.31</a> or <a href="#">91.41</a> ). Check input selection ( <a href="#">91.31</a> or <a href="#">91.41</a> ), interface module type, and encoder type.
000C	Emulation in continuous mode not supported.	Check input selection ( <a href="#">91.31</a> or <a href="#">91.41</a> ) and serial link mode ( <a href="#">92.30</a> or <a href="#">93.30</a> ) settings.	

608 Fault tracing

Code (hex)	Event name / Aux. code	Cause	What to do
A798	Encoder option comm loss	Encoder feedback not used as actual feedback, or measured motor feedback lost (and parameter 90.45/90.55 is set to Warning).	<p>Check that the encoder is selected as feedback source in parameter 90.41 or 90.51.</p> <p>Check that the encoder interface module is properly seated in its slot. Check that the encoder interface module or slot connectors are not damaged. To pinpoint the problem, try installing the module into a different slot.</p> <p>If the module is installed on an FEA-03 extension adapter, check the fiber optic connections.</p> <p>Check the auxiliary code (format XXXX YYYY). "YYYY" indicates the problem (see actions for each code below).</p>
	0001	Failed answer to encoder configuration message.	Contact your local ABB representative.
	0002	Failed answer to adapter watchdog disable message.	Contact your local ABB representative.
	0003	Failed answer to adapter watchdog enable message.	Contact your local ABB representative.
	0004	Failed answer to adapter configuration message.	Contact your local ABB representative.
	0005	Too many failed answers inline to speed and position messages.	Contact your local ABB representative.
	0006	DDCS driver failed.	Contact your local ABB representative.
A799	Ext I/O comm loss	The I/O extension module types specified by parameters do not match the detected configuration.	<p>Check the auxiliary code (format XXYY YYYY). "XX" specifies the number of the I/O extension module (01: parameter group 14 I/O extension module 1, 02: 15 I/O extension module 2 2, 03: 16 I/O extension module 3).</p> <p>"YY YYYY" indicates the problem (see actions for each code below).</p>
	00 0001	Communication with module failed.	<p>Check that the module is properly seated in its slot.</p> <p>Check that the module and the slot connector is not damaged.</p> <p>Try installing the module into another slot.</p>
	00 0002	Module not found.	<p>Check the type and location settings of the modules (parameters 14.1/14.2, 15.1/15.2 or 16.1/16.2).</p> <p>Check that the module is properly seated in its slot.</p> <p>Check that the module and the slot connector is not damaged.</p> <p>Try installing the module into another slot.</p>
	00 0003	Configuration of module failed.	<p>Check the type and location settings of the modules (parameters 14.1/14.2, 15.1/15.2 or 16.1/16.2).</p>



Code (hex)	Event name / Aux. code	Cause	What to do
	00 0004	Configuration of module failed.	<p>Check that the module is properly seated in its slot.            Check that the module and the slot connector is not damaged.            Try installing the module into another slot.</p> <p>Check the type and location settings of the modules (parameters <a href="#">14.1/14.2</a>, <a href="#">15.1/15.2</a> or <a href="#">16.1/16.2</a>).            Check that the module is properly seated in its slot.            Check that the module and the slot connector is not damaged.            Try installing the module into another slot.</p>
A79B	BC short circuit	Short circuit in brake chopper IGBT.	<p>Replace brake chopper if external.            Drives with internal choppers will need to be returned to ABB.            Ensure brake resistor is connected and not damaged.</p>
A79C	BC IGBT excess temperature	Brake chopper IGBT temperature has exceeded internal warning limit.	<p>Let chopper cool down.            Check for excessive ambient temperature.            Check for cooling fan failure.            Check for obstructions in the air flow.            Check the dimensioning and cooling of the cabinet.            Check resistor overload protection function settings (parameters <a href="#">43.6...43.10</a>).            Check minimum allowed resistor value for the chopper being used.            Check that braking cycle meets allowed limits.            Check that drive supply AC voltage is not excessive.</p>
A7A1	Mechanical brake closing failed	Status of mechanical brake acknowledgement is not as expected during brake close.	<p>Check mechanical brake connection.            Check mechanical brake settings in parameter group <a href="#">44 Mechanical brake control</a>.            Check that acknowledgement signal matches actual status of brake.</p>
A7A2	Mechanical brake opening failed	Status of mechanical brake acknowledgement is not as expected during brake open.	<p>Check mechanical brake connection.            Check mechanical brake settings in parameter group <a href="#">44 Mechanical brake control</a>.            Check that acknowledgement signal matches actual status of brake.</p>
A7A5	Mechanical brake opening not allowed	Open conditions of mechanical brake cannot be fulfilled (for example, brake has been prevented from opening by parameter <a href="#">44.11 Keep brake closed</a> ).	<p>Check mechanical brake settings in parameter group <a href="#">44 Mechanical brake control</a> (especially <a href="#">44.11 Keep brake closed</a>).</p>

## 610 Fault tracing

Code (hex)	Event name / Aux. code	Cause	What to do
			Check that acknowledgement signal (if used) matches actual status of brake.
A7AA	Extension AI parameterization	The hardware current/voltage setting of an analog input (on an I/O extension module) does not correspond to parameter settings.	<p>Check the auxiliary code (format XX00 00YY). “XX” specifies the number of the I/O extension module (<b>01: parameter group 14 I/O extension module 1, 02: 15 I/O extension module 2, 03: 16 I/O extension module 3</b>). “YY” specifies the analog input on the module.</p> <p>For example, in case of I/O extension module 1, analog input AI1 (auxiliary code 0100 0000), the hardware current/voltage setting on the module is shown by parameter 14.29. The corresponding parameter setting is 14.30. Adjust either the hardware setting on the module or the parameter to solve the mismatch.</p> <p><b>Note:</b> Control board reboot (either by cycling the power or through parameter 96.8 Control board boot) is required to validate any changes in the hardware settings.</p>
A7AB	Extension I/O configuration failure	The I/O extension module types and locations specified by parameters do not match the detected configuration.	<p>Check the type and location settings of the modules (parameters 14.1, 14.2, 15.1, 15.2, 16.1 and 16.2).</p> <p>Check that the modules are properly installed.</p> <p>Check the auxiliary code. See <i>Drive application programming manual (IEC 61131-3)</i> (3AUA0000127808 [English]).</p>
A7B0	Motor speed feedback	No motor speed feedback is received.	Check the auxiliary code (format XXYY ZZZZ). “XX” specifies the number of the encoder interface module ( <b>01: 91.11/91.12, 02: 91.13/91.14</b> ), “YY” specifies the encoder ( <b>01: 92 Encoder 1 configuration, 02: 93 Encoder 2 configuration</b> ). “ZZZZ” indicates the problem (see actions for each code below).
	0001	Motor gear definition invalid or outside limits.	Check motor gear settings (90.43 and 90.44).
	0002	Encoder not configured.	Check encoder settings (92 Encoder 1 configuration or 93 Encoder 2 configuration). Use parameter 91.10 Encoder parameter refresh) to validate any changes in the settings.
	0003	Encoder stopped working.	Check encoder status.
	0004	Encoder drift detected.	Check for slippage between encoder and motor.

Code (hex)	Event name / Aux. code	Cause	What to do
A7B1	Load speed feedback	No load speed feedback is received.	Check the auxiliary code (format XXYY ZZZZ). "XX" specifies the number of the encoder interface module ( <b>01: 91.11/91.12, 02: 91.13/91.14</b> ), "YY" specifies the encoder ( <b>01: 92 Encoder 1 configuration, 02: 93 Encoder 2 configuration</b> ). "ZZZZ" indicates the problem (see actions for each code below).
	0001	Load gear definition invalid or outside limits.	Check load gear settings ( <b>90.53</b> and <b>90.54</b> ).
	0002	Feed constant definition invalid or outside limits.	Check feed constant settings ( <b>90.63</b> and <b>90.64</b> ).
	0003	Encoder stopped working.	Check encoder status.
	0004	Encoder drift detected.	Check for slippage between encoder and motor.
A7C1	FBA A communication	Cyclical communication between drive and fieldbus adapter module A or between PLC and fieldbus adapter module A is lost.	Check status of fieldbus communication. See user documentation of fieldbus interface. Check settings of parameter groups <b>50 Fieldbus adapter (FBA)</b> , <b>51 FBA A settings</b> , <b>52 FBA A data in</b> and <b>53 FBA A data out</b> . Check cable connections. Check if communication master is able to communicate.
	0002	Communication problem between adapter and drive.	Check communication connections between adapter and drive.
	0004	Communication problem between adapter and PLC or parameters refreshed using the parameter <b>51.27 FBA A par refresh</b> .	Check communication connections between adapter and PLC. Stop using parameter <b>51.27 FBA A par refresh</b> to refresh parameters.
	0005	Lost communication with fieldbus communication adapter.	Check fieldbus communication adapter.
	Other aux code value	Unknown internal issues.	Contact your local ABB representative.
A7C2	FBA B communication	Cyclical communication between drive and fieldbus adapter module B or between PLC and fieldbus adapter module B is lost.	Check status of fieldbus communication. See user documentation of fieldbus interface. Check settings of parameter group <b>50 Fieldbus adapter (FBA)</b> . Check cable connections. Check if communication master is able to communicate.
	0002	Communication problem between adapter and drive.	Check communication connections between adapter and drive.
	0004	Communication problem between adapter and PLC or parameters refreshed using the parameter <b>51.27 FBA A par refresh</b> .	Check communication connections between adapter and PLC. Stop using parameter <b>51.27 FBA A par refresh</b> to refresh parameters.

## 612 Fault tracing

Code (hex)	Event name / Aux. code	Cause	What to do
	0005  Other aux code value	Lost communication with fieldbus communication adapter. Unknown internal issues.	Check fieldbus communication adapter. Contact your local ABB representative.
A7CA	DDCS controller comm loss	DDCS (fiber optic) communication between drive and external controller is lost.	Check status of controller. See user documentation of controller. Check settings of parameter group <a href="#">60 DDCS communication</a> . Check cable connections. If necessary, replace cables.
A7CB	M/F comm loss	Master/follower communication is lost.	Check the auxiliary code. The code indicates which node address (defined by parameter <a href="#">60.2</a> in each drive) on the master/follower link is affected. Check settings of parameter group <a href="#">60 DDCS communication</a> . On the FDCO module (if present), check that the DDCS link switch is not set to 0 (OFF). Check cable connections. If necessary, replace cables.
A7CE	EFB comm loss	Communication break in embedded fieldbus (EFB) communication.	Check the status of the fieldbus master (online/offline/error etc.). Check cable connections to the XD2D connector on the control unit.
A7E1	Encoder	Encoder error.	Check the auxiliary code (format XXYY ZZZZ). "XX" specifies the number of the encoder interface module ( <b>01</b> : <a href="#">91.11/91.12</a> , <b>02</b> : <a href="#">91.13/91.14</a> ), "YY" specifies the encoder ( <b>01</b> : <a href="#">92 Encoder 1 configuration</a> , <b>02</b> : <a href="#">93 Encoder 2 configuration</a> ). "ZZZZ" indicates the problem (see actions for each code below).
	0001	Cable fault.	Check the conductor order at both ends of the encoder cable. Check the groundings of the encoder cable. If the encoder was working previously, check the encoder, encoder cable and encoder interface module for damage. See also parameter <a href="#">92.21 Encoder cable fault mode</a> .
	0002	No encoder signal.	Check the condition of the encoder.
	0003	Overspeed.	Contact your local ABB representative.
	0004	Overfrequency.	Contact your local ABB representative.
	0005	Resolver ID run failed.	Contact your local ABB representative.
	0006	Resolver overcurrent fault.	Contact your local ABB representative.
	0007	Speed scaling error.	Contact your local ABB representative.
	0008	Absolute encoder communication error.	Contact your local ABB representative.
	0009	Absolute encoder initialization error.	Contact your local ABB representative.

Code (hex)	Event name / Aux. code	Cause	What to do
	000A	Absolute SSI encoder configuration error.	Contact your local ABB representative.
	000B	Encoder reported an internal error.	See the documentation of the encoder.
	000C	Encoder reported a battery error.	See the documentation of the encoder.
	000D	Encoder reported overspeed or decreased resolution due to overspeed.	See the documentation of the encoder.
	000E	Encoder reported a position counter error.	See the documentation of the encoder.
	000F	Encoder reported an internal error.	See the documentation of the encoder.
A7EE	Control panel loss	Control panel (or PC tool) has stopped communicating.	Check PC tool or control panel connection. Check control panel connector. Check mounting platform if being used. Disconnect and reconnect the control panel.
A880	Motor bearing	Warning generated by an ontime timer or a value counter.	Check the auxiliary code. Check the source of the warning corresponding to the code: 0: <a href="#">33.13 On-time 1 source</a> 1: <a href="#">33.23 On-time 2 source</a> 4: <a href="#">33.53 Value counter 1 source</a> 5: <a href="#">33.63 Value counter 2 source</a> .
A881	Output relay	Warning generated by an edge counter. Programmable warnings: <a href="#">33.35 Edge counter 1 warn message</a> <a href="#">33.45 Edge counter 2 warn message</a>	Check the auxiliary code. Check the source of the warning corresponding to the code: 2: <a href="#">33.33 Edge counter 1 source</a> 3: <a href="#">33.43 Edge counter 2 source</a> .
A882	Motor starts	Warning generated by an edge counter. Programmable warnings: <a href="#">33.35 Edge counter 1 warn message</a> <a href="#">33.45 Edge counter 2 warn message</a>	Check the auxiliary code. Check the source of the warning corresponding to the code: 2: <a href="#">33.33 Edge counter 1 source</a> 3: <a href="#">33.43 Edge counter 2 source</a> .
A883	Power ups	Warning generated by an edge counter. Programmable warnings: <a href="#">33.35 Edge counter 1 warn message</a> <a href="#">33.45 Edge counter 2 warn message</a>	Check the auxiliary code. Check the source of the warning corresponding to the code: 2: <a href="#">33.33 Edge counter 1 source</a> 3: <a href="#">33.43 Edge counter 2 source</a> .
A884	Main contactor	Warning generated by an edge counter. Programmable warnings: <a href="#">33.35 Edge counter 1 warn message</a> <a href="#">33.45 Edge counter 2 warn message</a>	Check the auxiliary code. Check the source of the warning corresponding to the code: 2: <a href="#">33.33 Edge counter 1 source</a> 3: <a href="#">33.43 Edge counter 2 source</a> .
A885	DC charge	Warning generated by an edge counter. Programmable warnings: <a href="#">33.35 Edge counter 1 warn message</a> <a href="#">33.45 Edge counter 2 warn message</a>	Check the auxiliary code. Check the source of the warning corresponding to the code: 2: <a href="#">33.33 Edge counter 1 source</a> 3: <a href="#">33.43 Edge counter 2 source</a> .

## 614 Fault tracing

Code (hex)	Event name / Aux. code	Cause	What to do
A886	On-Time 1	Warning generated by on-time timer 1.	Check the source of the warning (parameter <a href="#">33.13 On-time 1 source</a> ).
A887	On-Time 2	Warning generated by on-time timer 2.	Check the source of the warning (parameter <a href="#">33.23 On-time 2 source</a> ).
A888	Edge counter 1	Warning generated by edge counter 1.	Check the source of the warning (parameter <a href="#">33.33 Edge counter 1 source</a> ).
A889	Edge counter 2	Warning generated by edge counter 2.	Check the source of the warning (parameter <a href="#">33.43 Edge counter 2 source</a> ).
A88A	Value counter 1	Warning generated by value counter 1.	Check the source of the warning (parameter <a href="#">33.53 Value counter 1 source</a> ).
A88B	Value counter 2	Warning generated by value counter 2.	Check the source of the warning (parameter <a href="#">33.63 Value counter 2 source</a> ).
A88C	Device clean	Warning generated by an ontime timer. Programmable warnings: <a href="#">33.14 On-time 1 warn message</a> <a href="#">33.24 On-time 2 warn message</a>	Check the auxiliary code. Check the source of the warning corresponding to the code: 0: <a href="#">33.13 On-time 1 source</a> 1: <a href="#">33.23 On-time 2 source</a> 10: <a href="#">5.4 Main fan on-time counter</a> .
A88D	DC capacitor	Warning generated by an ontime timer. Programmable warnings: <a href="#">33.14 On-time 1 warn message</a> <a href="#">33.24 On-time 2 warn message</a>	Check the auxiliary code. Check the source of the warning corresponding to the code: 0: <a href="#">33.13 On-time 1 source</a> 1: <a href="#">33.23 On-time 2 source</a> 10: <a href="#">5.4 Main fan on-time counter</a> .
A88E	Cabinet fan	Warning generated by an ontime timer. Programmable warnings: <a href="#">33.14 On-time 1 warn message</a> <a href="#">33.24 On-time 2 warn message</a>	Check the auxiliary code. Check the source of the warning corresponding to the code: 0: <a href="#">33.13 On-time 1 source</a> 1: <a href="#">33.23 On-time 2 source</a> 10: <a href="#">5.4 Main fan on-time counter</a> .
A88F	Cooling fan	Warning generated by an ontime timer. Programmable warnings: <a href="#">33.14 On-time 1 warn message</a> <a href="#">33.24 On-time 2 warn message</a>	Check the auxiliary code. Check the source of the warning corresponding to the code: 0: <a href="#">33.13 On-time 1 source</a> 1: <a href="#">33.23 On-time 2 source</a> 10: <a href="#">5.4 Main fan on-time counter</a> .
A890	Additional cooling fan	Warning generated by an ontime timer. Programmable warnings: <a href="#">33.14 On-time 1 warn message</a> <a href="#">33.24 On-time 2 warn message</a>	Check the auxiliary code. Check the source of the warning corresponding to the code: 0: <a href="#">33.13 On-time 1 source</a> 1: <a href="#">33.23 On-time 2 source</a> 10: <a href="#">5.4 Main fan on-time counter</a> .
A8A0	AI Supervised Warning	An analog signal is outside the limits specified for the analog input.	Check the auxiliary code (format XYY). "X" specifies the location of the input (0: AI on control unit; 1: I/O extension module 1, etc.), "YY" specifies the input and limit (01: AI1 under

Code (hex)	Event name / Aux. code	Cause	What to do
			<p>minimum, <b>02</b>: AI1 over maximum, <b>03</b>: AI2 under minimum, <b>04</b>: AI2 over maximum).</p> <p>Check signal level at the analog input. Check the wiring connected to the input.</p> <p>Check the minimum and maximum limits of the input in parameter group <a href="#">12 Standard AI</a>, <a href="#">14 I/O extension module 1</a>, <a href="#">15 I/O extension module 2</a> or <a href="#">16 I/O extension module 3</a>.</p>
A8B0	Signal supervision	Warning generated by the signal supervision 1 function.	Check the source of the warning (parameter <a href="#">32.7 Supervision 1 signal</a> ).
A8B1	Signal supervision 2	Warning generated by the signal supervision 2 function.	Check the source of the warning (parameter <a href="#">32.17 Supervision 2 signal</a> ).
A8B2	Signal supervision 3	Warning generated by the signal supervision 3 function.	Check the source of the warning (parameter <a href="#">32.27 Supervision 3 signal</a> ).
A8BE	ULC overload	Selected signal has exceeded the user overload curve.	<p>Check for any operating conditions increasing the monitored signal (for example, the loading of the motor if the torque or current is being monitored).</p> <p>Check the definition of the load curve (parameter group <a href="#">37 User load curve</a>).</p>
A8BF	ULC underload	Selected signal has fallen below the user underload curve.	<p>Check for any operating conditions decreasing the monitored signal (for example, loss of load if the torque or current is being monitored).</p> <p>Check the definition of the load curve (parameter group <a href="#">37 User load curve</a>).</p>
A8C0	Fan service counter	A cooling fan has reached the end of its estimated lifetime. See parameters <a href="#">5.41</a> and <a href="#">5.42</a> .	<p>Check the auxiliary code. The code indicates which fan is to be replaced.</p> <p>0: Main cooling fan 1: Auxiliary cooling fan 2: Auxiliary cooling fan 2 3: Cabinet cooling fan 4: PCB compartment fan</p> <p>Refer to the hardware manual of the drive for fan replacement instructions.</p>
A981	External warning 1	Fault in external device 1.	<p>Check the external device.</p> <p>Check setting of parameter <a href="#">31.1 External event 1 source</a>.</p>
A982	External warning 2	Fault in external device 2.	<p>Check the external device.</p> <p>Check setting of parameter <a href="#">31.3 External event 2 source</a>.</p>
A983	External warning 3	Fault in external device 3.	<p>Check the external device.</p> <p>Check setting of parameter <a href="#">31.5 External event 3 source</a>.</p>
A984	External warning 4	Fault in external device 4.	<p>Check the external device.</p> <p>Check setting of parameter <a href="#">31.7 External event 4 source</a>.</p>

## 616 Fault tracing

Code (hex)	Event name / Aux. code	Cause	What to do
A985	External warning 5	Fault in external device 5.	Check the external device. Check setting of parameter <a href="#">31.9 External event 5 source</a> .
AF80	INU-LSU comm loss	DDCS (fiber optic) communication between converters (for example, the inverter unit and the supply unit) is lost. Note that the inverter unit will continue operating based on the status information that was last received from the other converter.	Check status of other converter (parameters <a href="#">6.36</a> and <a href="#">6.39 Internal state machine LSU CW</a> ). Check settings of parameter group <a href="#">60 DDCS communication</a> . Check the corresponding settings in the control program of the other converter. Check cable connections. If necessary, replace cables.
AF85	Line side unit warning	The supply unit (or other converter) has generated a warning.	The auxiliary code specifies the original warning code in the supply unit control program. See section <a href="#">Auxiliary codes for line-side converter warnings (page 622)</a> .
AF8C	Process PID sleep mode	The drive is entering sleep mode.	Informative warning. See section <a href="#">Process PID control</a> , and parameters <a href="#">40.41...40.48</a> .
AF90	Speed controller autotuning	The speed controller autotune routine did not complete successfully.	Check the auxiliary code (format XXXX YYYY). "YYYY" indicates the problem (see actions for each code below).
	0000	The drive was stopped before the autotune routine finished.	Repeat autotune until successful.
	0001	The drive was started but was not ready to follow the autotune command.	Make sure the prerequisites of the autotune run are fulfilled. See section <a href="#">Speed controller autotune (page 48)</a> .
	0002	Required torque reference could not be reached before the drive reached maximum speed.	Decrease torque step (parameter <a href="#">25.38</a> ) or increase speed step ( <a href="#">25.39</a> ).
	0003	Motor could not accelerate/decelerate to maximum/minimum speed.	Increase torque step (parameter <a href="#">25.38</a> ) or decrease speed step ( <a href="#">25.39</a> ).
	0004	Motor could not decelerate with full autotune torque.	Decrease torque step (parameter <a href="#">25.38</a> ) or speed step ( <a href="#">25.39</a> ), or increase torque limits depending on limit source indicated in parameters <a href="#">30.1</a> and <a href="#">30.2</a> .
AFAA	Autoreset	A fault is about to be autoreset.	Informative warning. See the settings in parameter group <a href="#">31 Fault functions</a> .
AFE1	Emergency stop (off2)	<ul style="list-style-type: none"> <li>Drive has received an emergency stop (mode selection off2) command.</li> </ul>	<ul style="list-style-type: none"> <li>Check that it is safe to continue operation. Reset the source of the emergency stop signal (such as an emergency stop push button). Restart drive. If the emergency stop was unintentional, check the source of the stop signal (for example, <a href="#">21.5 Emergency stop source</a>, or control word received from an external control system).</li> </ul>



Code (hex)	Event name / Aux. code	Cause	What to do
		<ul style="list-style-type: none"> <li>(Follower drive in a master/follower configuration) Drive has received a stop command from the master.</li> </ul>	<ul style="list-style-type: none"> <li>Informative warning. After stopping on a ramp stop (Off1 or Off3) command, the master sends a short, 10-millisecond coast stop (Off2) command to the follower(s). The Off2 stop is stored in the event log of the follower.</li> </ul>
AFE2	Emergency stop (off1 or off3)	Drive has received an emergency stop (mode selection Off1 or Off3) command.	<p>Check that it is safe to continue operation. Reset the source of the emergency stop signal (such as an emergency stop push button). Restart drive.</p> <p>If the emergency stop was unintentional, check the source of the stop signal (for example, <a href="#">21.5 Emergency stop source</a>, or control word received from an external control system).</p>
AFE7	Follower	A follower drive has tripped.	<p>Check the auxiliary code. Add 2 to the code to find out the node address of the faulted drive.</p> <p>Correct the fault in the follower drive.</p>
AFEA	Enable start signal missing	No enable start signal received.	Check the setting of (and the source selected by) parameter <a href="#">20.19 Enable start command</a> .
AFEB	Run enable missing	No run enable signal is received.	Check setting of parameter <a href="#">20.12 Run enable 1 source</a> . Switch signal on (e.g. in the fieldbus Control Word) or check wiring of selected source.
AFEC	External power signal missing	<a href="#">95.4 Control board supply</a> is set to <a href="#">External 24V</a> but no voltage is connected to the XPOW connector of the control unit.	Check the external 24 V DC power supply to the control unit, or change the setting of parameter <a href="#">95.4</a> .
AFF6	Identification run selected	Motor ID run will occur at next start, or is in progress.	Informative warning.
AFF7	Autophasing	Autophasing will occur at next start.	Informative warning.
B5A0	STO event	Safe torque off function is active, i.e. safety circuit signal(s) connected to connector XSTO is lost.	Check safety circuit connections. For more information, see appropriate drive hardware manual and description of parameter <a href="#">31.22 STO indication run/stop</a> .
B5A2	Power up	The drive has been powered up.	Informative event.
B5F6	ID run done	ID run completed.	<p>Informative event.</p> <p>The auxiliary code specifies the type of ID run.</p> <p>0: None            1: Normal            2: Reduced            3: Standstill            4: Autophasing            5: Current measurement calibration            6: Advanced</p>

## 618 Fault tracing

Code (hex)	Event name / Aux. code	Cause	What to do
			7: Advanced standstill
B680	SW internal diagnostics	SW internal malfunction.	Contact your local ABB representative, quoting the auxiliary code. If the Drive Composer tool is available, also create and send a 'support package' (see Drive composer manual for instructions).
B686	Checksum mismatch	The calculated parameter checksum does not match any enabled reference checksum.	See <a href="#">A686 Checksum mismatch (page 603)</a> .
B68B	SW internal information	Software collects the information.	Informative event.
FA81	Safe torque off 1 loss	Safe torque off function is active, ie. STO circuit 1 is broken.	<p>Check safety circuit connections. For more information, see appropriate drive hardware manual and description of parameter <a href="#">31.22 STO indication run/stop (page 353)</a>.</p> <p>Check the auxiliary code, The code contains location information, especially with parallel-connected inverter modules.</p> <p>When converted into a 32-bit binary number, the bits of the code indicate the following:</p> <p>31...28: Number of faulty inverter module (0...11 decimal). 1111: STO_ACT states of control unit and inverter modules in conflict</p> <p>27: STO_ACT state of inverter modules</p> <p>26: STO_ACT state of control unit</p> <p>25: STO1 of control unit</p> <p>24: STO2 of control unit</p> <p>23...12: STO1 of inverter modules 12...1 (Bits of non-existing modules set to 1)</p> <p>11...0: STO2 of inverter modules 12...1 (Bits of non-existing modules set to 1)</p>
FA82	Safe torque off 2 loss	Safe torque off function is active, ie. STO circuit 2 is broken.	<p>Check safety circuit connections. For more information, see appropriate drive hardware manual and description of parameter <a href="#">31.22 STO indication run/stop (page 353)</a>.</p> <p>Check the auxiliary code, The code contains location information, especially with parallel-connected inverter modules.</p> <p>When converted into a 32-bit binary number, the bits of the code indicate the following:</p> <p>31...28: Number of faulty inverter module (0...11 decimal). 1111: STO_ACT states of control unit and inverter modules in conflict</p>

Code (hex)	Event name / Aux. code	Cause	What to do
			<p>27: STO_ACT state of inverter modules                      26: STO_ACT state of control unit                      25: STO1 of control unit                      24: STO2 of control unit                      23...12: STO1 of inverter modules 12...1 (Bits of non-existing modules set to 1)                      11...0: STO2 of inverter modules 12...1 (Bits of non-existing modules set to 1)</p>
FA90	STO diagnostics failure	SW internal malfunction.	Contact your local ABB representative.
FB11	Memory unit missing	<ul style="list-style-type: none"> <li>No memory unit is attached to the control unit.</li> <li>The memory unit attached to the control unit is empty.</li> </ul>	<ul style="list-style-type: none"> <li>Power down the control unit. Check that the memory unit is properly inserted into the control unit.</li> <li>Power down the control unit. Attach a memory unit (with the appropriate firmware) to the control unit.</li> </ul>
FB12	Memory unit incompatible	The memory unit attached to the control unit is incompatible.	Power down the control unit. Attach a compatible memory unit.
FB13	Memory unit FW incompatible	The firmware on the attached memory unit is incompatible with the drive.	Power down the control unit. Attach a memory unit with compatible firmware.
FB14	Memory unit FW load failed	The memory unit is empty, or contains incompatible or corrupted firmware.	<p>Recycle the power to the control unit. Check the sticker on the memory unit to confirm that the firmware is compatible with the control unit (ZCU-1x/BCU-x2). Connect Drive Composer PC tool (version 2.3 or later) to the drive. Select Tools - Recover drive. If the problem persists, replace the memory unit.</p>
FF61	ID run	Motor ID run was not completed successfully.	<p>Check the nominal motor values in parameter group <a href="#">99 Motor data</a>. Check that no external control system is connected to the drive. Cycle the power to the drive (and its control unit, if powered separately). Check that the motor shaft is not locked. Check the auxiliary code. The second number of the code indicates the problem (see actions for each code below).</p>
	0001	Maximum current limit too low.	<p>Check settings of parameters <a href="#">99.6 Motor nominal current</a> and <a href="#">30.17 Maximum current</a>. Make sure that <a href="#">30.17 Maximum current</a> &gt; <a href="#">99.6 Motor nominal current</a>.</p>

## 620 Fault tracing

Code (hex)	Event name / Aux. code	Cause	What to do
	0002	Maximum speed limit or calculated field weakening point too low.	<p>Check that the drive is dimensioned correctly according to the motor.</p> <p>Check settings of parameters</p> <ul style="list-style-type: none"> <li>• <a href="#">30.11 Minimum speed</a></li> <li>• <a href="#">30.12 Maximum speed</a></li> <li>• <a href="#">99.7 Motor nominal voltage</a></li> <li>• <a href="#">99.8 Motor nominal frequency</a></li> <li>• <a href="#">99.9 Motor nominal speed.</a></li> </ul> <p>Make sure that</p> <ul style="list-style-type: none"> <li>• <a href="#">30.12 Maximum speed</a> &gt; (0.55 × <a href="#">99.9 Motor nominal speed</a>) &gt; (0.50 × synchronous speed)</li> <li>• <a href="#">30.11 Minimum speed</a> &lt; 0, and</li> <li>• supply voltage &gt; (0.66 × <a href="#">99.7 Motor nominal voltage</a>).</li> </ul>
	0003	Maximum torque limit too low.	<p>Check settings of parameter <a href="#">99.12 Motor nominal torque</a>, and the torque limits in group <a href="#">30 Limits</a>.</p> <p>Make sure that the maximum torque limit in force is greater than 100%.</p>
	0004	Current measurement calibration did not finish within reasonable time.	Contact your local ABB representative.
	0005...0008	Internal error.	Contact your local ABB representative.
	0009	(Asynchronous motors only) Acceleration did not finish within reasonable time.	Contact your local ABB representative.
	000A	(Asynchronous motors only) Deceleration did not finish within reasonable time.	Contact your local ABB representative.
	000B	(Asynchronous motors only) Speed dropped to zero during ID run.	Contact your local ABB representative.
	000C	(Permanent magnet motors only) First acceleration did not finish within reasonable time.	Contact your local ABB representative.
	000D	(Permanent magnet motors only) Second acceleration did not finish within reasonable time.	Contact your local ABB representative.
	000E...0010	Internal error.	Contact your local ABB representative.
	0011	(SynRM only) Rotor orientation not correct during the pulse test.	Try to perform ID run again. Contact your local ABB representative.
	0012	Not possible to perform Advanced Standstill ID run.	Check that nominal power is as advised in Advanced Standstill ID run description. Contact your local ABB representative.
	0013	(Asynchronous motors only) Error in motor data.	Check name plate data. Contact your local ABB representative.

Code (hex)	Event name / Aux. code	Cause	What to do
	0014	Acceleration did not finish within reasonable time during Autophasing ID run.	Contact your local ABB representative.
	0015	Advanced standstill failure.	Contact your local ABB representative.
	0016	Rs estimation failure.	Check cabling. Check that switching frequency is high enough. Check sine filter settings if connected. Contact your local ABB representative.
FF7E	Follower	A follower drive has tripped.	Check the auxiliary code. Add 2 to the code to find out the node address of the faulted drive. Correct the fault in the follower drive.
FF81	FB A force trip	A fault trip command has been received through fieldbus adapter A.	Check the fault information provided by the PLC.
FF82	FB B force trip	A fault trip command has been received through fieldbus adapter B.	Check the fault information provided by the PLC.
FF8E	EFB force trip	A fault trip command has been received through the embedded fieldbus interface.	Check the fault information provided by the Modbus controller.

## Auxiliary codes for line-side converter warnings

The table below lists the auxiliary codes of [AF85 Line side unit warning](#). For advanced troubleshooting, see the firmware manual of the line converter.

Code (hex)	Event name / Aux. code	Cause	What to do
AE01	Overcurrent	Output current has exceeded internal fault limit.	Check supply voltage. Check that there are no power factor correction capacitors or surge absorbers in supply cable. Check motor load and acceleration times. Check power semiconductors (IGBTs) and current transducers.
AE02	Earth leakage	IGBT supply has detected load unbalance.	Check AC fuses. Check for earth leakages. Check supply cabling. Check power modules. Check there are no power factor correction capacitors or surge absorbers in supply cable.
AE04	IGBT overload	Excessive IGBT junction to case temperature.	Check supply cable.
AE05	BU current difference	Current difference detected by the branching unit (BU).	Check converter fuses. Check converter(s). Check inverter(s). Check LCL filter.
AE06	BU earth leakage	Earth leakage detected by the branching unit: sum of all currents exceeds the level.	Check AC fuses. Check for earth leakages. Check supply cabling. Check power modules. Check there are no power factor correction capacitors or surge absorbers in supply cable.
AE09	DC link overvoltage	Excessive intermediate circuit DC voltage.  <b>Note:</b> This warning can be shown only when the IGBT supply unit is not modulating.	Check that parameter <a href="#">95.1 Supply voltage</a> is set according to the supply voltage in use.
AE0A	DC link undervoltage	Intermediate circuit DC voltage is not sufficient due to missing phase in supply voltage, blown fuse or rectifier bridge internal fault.  <b>Note:</b> This warning can be shown only when the IGBT supply unit is not modulating.	Check supply and fuses. Check that parameter <a href="#">95.1 Supply voltage</a> is set according to the supply voltage in use.

Code (hex)	Event name / Aux. code	Cause	What to do
AE0B	DC not charged	The voltage of the intermediate DC circuit has not yet risen to operating level. One input phase could be disconnected.  <b>Note:</b> This warning can be shown only when the IGBT supply unit is not modulating.	Check the input voltage setting in parameter <a href="#">95.1 Supply voltage</a> . Check the input voltage. Check charging resistors. If the problem persists, contact your local ABB representative.
AE0C	BU DC link difference	DC link voltage difference detected by the branching unit.	Check DC fuses. Check converter module connections to DC link.
AE0D	BU voltage difference	Main voltage difference detected by the branching unit.	Check AC fuses. Check supply cable.
AE14	Excess temperature	Power unit module temperature is excessive.	Check ambient conditions. Check air flow and fan operation. Check heatsink fins for dust pick-up. Check motor power against IGBT supply unit power.
AE15	Excess temperature difference	High temperature difference between the IGBTs of different phases.	Check the cabling. Check cooling of power module(s).
AE16	IGBT temperature	IGBT temperature is excessive.	Check ambient conditions. Check air flow and fan operation. Check heatsink fins for dust pick-up. Check motor power against IGBT supply unit power.
AE24	Voltage category unselected	The supply voltage range has not been defined.	Define the supply voltage range (parameter <a href="#">95.1 Supply voltage</a> ).
AE58	Emergency stop (OFF2)	Supply unit has received an emergency stop (mode selection off2) command.	Check that it is safe to continue operation. Return emergency stop push button to normal position. Restart the drive.
AE5F	Temperature Warning	Supply module temperature is excessive due to eg, module overload or fan failure.	Check module cooling air flow and fan operation. Check ambient temperature. If it exceeds 40 °C (104 °F), ensure that load current does not exceed derated load capacity. See appropriate hardware manual. Check inside of cabinet and heatsink of supply module for dust pick-up. Clean whenever necessary.
AE73	Fan	Cooling fan is stuck or disconnected.	Check the auxiliary code in the line-side converter program to identify the fan. Check fan operation and connection. Replace fan if faulty.

## 624 Fault tracing

<b>Code (hex)</b>	<b>Event name / Aux. code</b>	<b>Cause</b>	<b>What to do</b>
AE78	Net lost	Net lost is detected.	Resynchronize the IGBT supply unit to the grid after net lost.
AE85	Charging count	There are too many DC link charging attempts.	Two attempts in five minutes is allowed to prevent charging circuit overheating.

---



## Auxiliary codes for line-side converter faults

The table below lists the auxiliary codes of [7583 Line side unit faulted](#). For advanced troubleshooting, see the firmware manual of the line converter.

Code (hex)	Event name / Aux. code	Cause	What to do
2E00	Overcurrent	Output current has exceeded internal fault limit.	Check supply voltage. Check that there are no power factor correction capacitors or surge absorbers in supply cable. Check motor load and acceleration times. Check power semiconductors (IGBTs) and current transducers.
2E01	Earth leakage	IGBT supply unit has detected an earth fault.	Check AC fuses. Check for earth leakages. Check supply cabling. Check power modules. Check there are no power factor correction capacitors or surge absorbers in supply cable. If no earth fault can be detected, contact your local ABB representative.
2E02	Short circuit	IGBT supply unit has detected short circuit.	Check supply cable. Check there are no power factor correction capacitors or surge absorbers in supply cable. After correcting the cause of the fault, reboot the control unit (using parameter <a href="#">96.8 Control board boot</a> or by cycling power).
2E04	IGBT overload	Excessive IGBT junction to case temperature.	Check the load.
2E05	BU current difference	Current difference detected by the branching unit (BU).	Check converter fuses. Check converter(s). Check inverter(s). Check LCL filter. Power off all boards. If the fault persists, contact your local ABB representative.
2E06	BU earth leakage	Earth leakage detected by the branching unit: sum of all currents exceeds the level.	Check AC fuses. Check for earth leakages. Check supply cabling. Check power modules. Check there are no power factor correction capacitors or surge absorbers in supply cable. If no earth fault can be detected, contact your local ABB representative.

## 626 Fault tracing

Code (hex)	Event name / Aux. code	Cause	What to do
3E00	Input phase loss	Input phase loss detected by the IGBT bridge.	Check the auxiliary code. Check the source of the fault corresponding to the code: 1: Phase A 2: Phase B 4: Phase C 8: Phase cannot be detected Check the AC fuses. Check for input power supply imbalance.
3E04	DC link overvoltage	Excessive intermediate circuit DC voltage.	Check that parameter <a href="#">95.1 Supply voltage</a> is set according to the supply voltage in use.
3E05	DC link undervoltage	Intermediate circuit DC voltage is not sufficient because of a missing supply phase or blown fuse.	Check supply cabling, fuses and switchgear. Check that parameter <a href="#">95.1 Supply voltage</a> is set according to the supply voltage in use.
3E06	BU DC link difference	Difference in DC voltages between parallel-connected supply modules.	Check the DC fuses. Check the connection to the DC bus. If the problem persists, contact your local ABB representative.
3E07	BU voltage difference	Difference in main voltages between parallel-connected supply modules.	Check the supply network connections. Check the AC fuses. If the problem persists, contact your local ABB representative.
3E08	LSU charging	DC link voltage is not high enough after charging.	Check parameter <a href="#">95.1 Supply voltage</a> . Check supply voltage and fuses. Check the connection from the relay output to the charging contactor. Check that the DC voltage measuring circuit is working correctly.
4E01	Cooling	Power module temperature is excessive.	Check ambient temperature. If it exceeds 40 °C (104 °F), ensure that load current does not exceed derated load capacity. See appropriate hardware manual. Check power module cooling air flow and fan operation. Check inside of cabinet and heatsink of power module for dust pick-up. Clean whenever necessary.
4E02	IGBT temperature	IGBT temperature is excessive.	Check ambient conditions. Check air flow and fan operation. Check heatsink fins for dust pick-up. Check motor power against IGBT supply unit power.
4E03	Excess temperature	Power unit module temperature is excessive.	See <a href="#">AE14 Excess temperature</a> (page 623).

Code (hex)	Event name / Aux. code	Cause	What to do
4E04	Excess temperature difference	High temperature difference between the IGBTs of different phases. The amount of available temperatures depends on the frame size.	See <a href="#">AE15 Excess temperature difference</a> .
4E06	Cabinet or LCL overtemperature	Overtemperature detected either in cabinet, LCL filter or auxiliary transformer.	Check the cooling of the cabinet, LCL filter and auxiliary transformer.
5E01	Auxiliary fan broken	An auxiliary cooling fan is stuck or disconnected.	Check the fan operation and connection. Replace the fan if faulty.
5E05	Rating ID mismatch	The hardware of the supply unit does not match the information stored in the memory unit. This may occur eg, after a firmware update or memory unit replacement.	Cycle the power to the supply unit. If the control unit is externally powered, reboot the control unit (using parameter <a href="#">96.108 LSU control board boot</a> ) or by cycling its power. If the problem persists, contact your local ABB representative.
5E06	Main contactor Fault	Control program does not receive main contactor on (1) acknowledgement through digital input even control program has closed the contactor control circuit with relay output. Main contactor / main breaker is not functioning properly, or there is a loose / bad connection.	Check main contactor / main breaker control circuit wiring. Check the status of other switches connected to contactor control circuit. See the delivery-specific circuit diagrams. Check main contactor operating voltage level (should be 230 V). Check digital input DI3 connections. Check related 48V power supply and connected fans.
6E19	Synchronization fault	Synchronization to supply network has failed.	Monitor possible network transients.
6E1A	Rating ID fault	Rating ID load error.	Contact your local ABB representative.
6E1F	Licensing fault	There are two types of licenses being used in ACS880 drives: licenses that need to be found from the unit which allow the firmware to be executed, and licenses that prevent the firmware from running. The license is indicated by the value of the auxiliary code field. The license is Nxxxx, where xxxx is indicated by the 4-digit value of the auxiliary code field. 8201: A restrictive license is found from the unit. The firmware on this inverter unit cannot be executed because a Low harmonic license is found from the unit. This unit is meant to be used with IGBT supply control program (2Q) only.	Check the line-converter control program. Record the auxiliary codes of all active licensing faults and contact your product vendor for further instructions. This fault requires a reboot of the control unit either by switching the power off and on, or using parameter <a href="#">96.108 LSU control board boot</a> . 8201: Contact your product vendor for further instructions.

## 628 Fault tracing

Code (hex)	Event name / Aux. code	Cause	What to do
6E21	Macro parameterization error	Macro file has a parameter defined in such a way that it cannot be written.	Check aux code for the exact parameter group and index. Check if the parameter exists in the drive. Check the parameter value from the macro file matches the parameter's minimum and maximum limits. If the aux code is zero, a generic file error occurs. Contact your local ABB representative. Aux-code in hexadecimal format contains an 8-bit Group, 8-bit Index, and 16-bit error code.
	0005	Parameter is not accessible from the macro file.	
	0009	Value written is below the parameter minimum limit.	
	000A	Value written is above the parameter maximum limit.	
	000B	Value written is not listed in the parameter selection list.	
	000C	Parameter function prevents to display the value.	
	000D	Parameter does not exist.	
	001F	Parameter in the macro file does not match the parameter in the drive. The unit or display format is different.	
0022	Pointer parameter is written to target a parameter or bit that does not exist or that is not available to be targeted from macro.		
7E01	Panel loss	Control panel or PC tool selected as active control location has ceased communicating.	Check PC tool or control panel connection. Check control panel connector. Replace control panel in mounting platform.
8E07	Net lost	Net lost is detected. Duration of net lost is too long.	Resynchronize the IGBT supply unit to the grid after net lost.



# Fieldbus control through the embedded fieldbus interface (EFB)

---

## What this chapter contains

The chapter describes how the drive can be controlled by external devices over a communication network (fieldbus) using the embedded fieldbus interface.


---

## System overview

The drive can be connected to an external control system through a communication link using either a fieldbus adapter or the embedded fieldbus interface.

The embedded fieldbus interface supports the Modbus RTU protocol. The drive control program can handle 10 Modbus registers in a 10-millisecond time level. For example, if the drive receives a request to read 20 registers, it will start its response within 22 ms of receiving the request – 20 ms for processing the request and 2 ms overhead for handling the bus. The actual response time depends on other factors as well, such as the baud rate (a parameter setting in the drive).

The drive can be set to receive all of its control information through the fieldbus interface, or the control can be distributed between the embedded fieldbus interface and other available sources, for example, digital and analog inputs.



## Connecting the fieldbus to the drive

Connect the fieldbus to terminal XD2D on the control unit of the drive. See the appropriate *Hardware Manual* for more information on the connection, chaining and termination of the link.

**Note:** If the XD2D connector is reserved by the embedded fieldbus interface (parameter [58.1 Protocol enable](#) is set to [Modbus RTU](#)), the drive-to-drive link functionality is automatically disabled.

## Setting up the embedded fieldbus interface

Set the drive up for the embedded fieldbus communication with the parameters shown in the table below. The **Setting for fieldbus control** column gives either the value to use or the default value. The **Function/Information column** gives a description of the parameter.

Parameter	Setting for fieldbus control	Function/Information
COMMUNICATION INITIALIZATION		
<a href="#">58.1 Protocol enable</a>	<a href="#">Modbus RTU</a>	Initializes embedded fieldbus communication. Drive-to-drive link operation is automatically disabled.
EMBEDDED MODBUS CONFIGURATION		
<a href="#">58.3 Node address</a>	1 (default)	Node address. There must be no two nodes with the same node address online.
<a href="#">58.4 Baud rate</a>	<a href="#">19.2 kbps</a> (default)	Defines the communication speed of the link. Use the same setting as in the master station
<a href="#">58.5 Parity</a>	<a href="#">8 EVEN 1</a> (default)	Selects the parity and stop bit setting. Use the same setting as in the master station.
<a href="#">58.14 Communication loss action</a>	Fault (default)	Defines the action taken when a communication loss is detected.
<a href="#">58.15 Communication loss mode</a>	<a href="#">Cw / Ref1 / Ref2</a> (default)	Enables/disables communication loss monitoring and defines the means for resetting the counter of the communication loss delay.
<a href="#">58.16 Communication loss time</a>	3.0 s (default)	Defines the time-out limit for the communication monitoring.
<a href="#">58.17 Transmit delay</a>	0 ms (default)	Defines a response delay for the drive.
<a href="#">58.25 Control profile</a>	<a href="#">ABB Drives</a> (default), <a href="#">Transparent</a>	Selects the control profile used by the drive.  See section <a href="#">Basics of the embedded fieldbus interface (page 634)</a> .

632 Fieldbus control through the embedded fieldbus interface (EFB)

Parameter	Setting for fieldbus control	Function/Information
58.26 EFB ref1 type ... .. 58.29 EFB act2 type	Auto, Transparent, General, Torque, Speed, Frequency	Selects the reference and actual value types.  With the <b>Auto</b> setting, the type is selected automatically according to the currently active drive control mode.
58.30 EFB status word transparent source	Other (see Terms and abbreviations)	Defines the source of status word when 58.25 Control profile = <b>Transparent</b> .
58.31 EFB act1 transparent source	Other (see Terms and abbreviations)	Defines the source of actual value 1 when 58.28 EFB act1 type = <b>Transparent</b> or <b>General</b> .
58.32 EFB act2 transparent source	Other (see Terms and abbreviations)	Defines the source of actual value 2 when 58.29 EFB act2 type = <b>Transparent</b> or <b>General</b> .
58.33 Addressing mode	eg. Mode 0 (default)	Defines the mapping between parameters and holding registers in the 40001...46536 (100...65535) Modbus register range.
58.34 Word order	LO-HI (default)	Defines the order of the data words in the Modbus message frame.
58.101 Data I/O 1 ... 58.124 Data I/O 24	For example, the default settings (I/Os 1...6 contain the control word, the status word, two references and two actual values)  RO/DIO control word, AO1 data storage, AO2 data storage, Feedback data storage, Setpoint data storage	Define the address of the drive parameter which the Modbus master accesses when it reads from or writes to the register address corresponding to Modbus In/Out parameters.  Select the parameters that you want to read or write through the Modbus I/O words.  These settings write the incoming data into storage parameters 10.99 RO/DIO control word, 13.91 AO1 data storage, 13.92 AO2 data storage, 40.91 Feedback data storage or 40.92 Setpoint data storage.
58.6 Communication control	Refresh settings	Validates the settings of the configuration parameters.

The new settings will take effect when the drive is powered up the next time, or when they are validated by parameter 58.6 Communication control.



## Setting the drive control parameters

After the embedded fieldbus interface has been set up, check and adjust the drive control parameters listed in the table below. The **Setting for fieldbus control** column gives the value or values to use when the embedded fieldbus signal is the desired source or destination for that particular drive control signal. The **Function/Information** column gives a description of the parameter.

Parameter	Setting for fieldbus control	Function/Information
CONTROL COMMAND SOURCE SELECTION		
<a href="#">20.1 Ext1 commands</a>	Embedded fieldbus	Selects fieldbus as the source for the start and stop commands when EXT1 is selected as the active control location.
<a href="#">20.2 Ext1 start trigger type</a>	Embedded fieldbus	Selects fieldbus as the source for the start and stop commands when EXT2 is selected as the active control location.
SPEED REFERENCE SELECTION		
<a href="#">22.11 Speed ref1 source</a>	EFB ref1 or EFB ref2	Selects a reference received through the embedded fieldbus interface as speed reference 1.
<a href="#">22.12 Speed ref2 source</a>	EFB ref1 or EFB ref2	Selects a reference received through the embedded fieldbus interface as speed reference 2.
TORQUE REFERENCE SELECTION		
<a href="#">26.11 Torque ref1 source</a>	EFB ref1 or EFB ref2	Selects a reference received through the embedded fieldbus interface as torque reference 1.
<a href="#">26.12 Torque ref2 source</a>	EFB ref1 or EFB ref2	Selects a reference received through the embedded fieldbus interface as torque reference 2.
FREQUENCY REFERENCE SELECTION		
<a href="#">28.11 Frequency ref1 source</a>	EFB ref1 or EFB ref2	Selects a reference received through the embedded fieldbus interface as frequency reference 1.
<a href="#">28.12 Frequency ref2 source</a>	EFB ref1 or EFB ref2	Selects a reference received through the embedded fieldbus interface as frequency reference 2.
OTHER SELECTIONS		
EFB references can be selected as the source at virtually any signal selector parameter by selecting Other (see <a href="#">Terms and abbreviations</a> ), then either <a href="#">3.9 EFB reference 1</a> or <a href="#">3.10 EFB reference 2</a> .		


634 Fieldbus control through the embedded fieldbus interface (EFB)

Parameter	Setting for fieldbus control	Function/Information
<b>CONTROL OF RELAY OUTPUTS, ANALOG OUTPUTS AND DIGITAL INPUT/OUTPUTS</b>		
10.24 RO1 source	RO/DIO control word bit0	Connects bit 0 of storage parameter 10.99 RO/DIO control word to relay output RO1.
10.27 RO2 source	RO/DIO control word bit1	Connects bit 1 of storage parameter 10.99 RO/DIO control word to relay output RO2.
10.30 RO3 source	RO/DIO control word bit2	Connects bit 2 of storage parameter 10.99 RO/DIO control word to relay output RO3.
11.5 DIO1 function 11.9 DIO2 function	Output (default)	Sets the digital input/output to output mode.
11.6 DIO1 output source	RO/DIO control word bit8	Connects bit 8 of storage parameter 10.99 RO/DIO control word to digital input/output DIO1.
11.10 DIO2 output source	RO/DIO control word bit9	Connects bit 9 of storage parameter 10.99 RO/DIO control word to digital input/output DIO2.
13.12 AO1 source	AO1 data storage	Connects storage parameter 13.91 AO1 data storage to analog output AO1.
13.22 AO2 source	AO2 data storage	Connects storage parameter 13.92 AO2 data storage to analog output AO2.
<b>PROCESS PID FEEDBACK AND SETPOINT</b>		
40.8 Set 1 feedback 1 source	Feedback data storage	Connect the bits of the storage parameter (10.99 RO/DIO control word) to the digital input/outputs of the drive.
40.16 Set 1 setpoint 1 source	Setpoint data storage	
<b>SYSTEM CONTROL INPUTS</b>		
96.7 Parameter save manually	Save (reverts to Done)	Saves parameter value changes (including those made through fieldbus control) to permanent memory.

## Basics of the embedded fieldbus interface

The cyclic communication between a fieldbus system and the drive consists of 16-bit data words or 32-bit data words (with the transparent control profiles).

The diagram below illustrates the operation of the embedded fieldbus interface. The signals transferred in the cyclic communication are explained further below the diagram.



### ■ Control word and Status word

The Control Word (CW) is a 16-bit or 32-bit packed boolean word. It is the principal means of controlling the drive from a fieldbus system. The CW is sent by the fieldbus controller to the drive. By drive parameters, the user selects the EFB CW

as the source of drive control commands (such as start/stop, emergency stop, selection between external control locations 1/2, or fault reset). The drive switches between its states according to the bit-coded instructions of the CW.

The fieldbus CW is either written to the drive as it is (see parameter [6.5 EFB transparent control word](#)), or the data is converted. See section [About the control profiles](#) (page 637).

The fieldbus Status Word (SW) is a 16-bit or 32-bit packed boolean word. It contains status information from the drive to the fieldbus controller. The drive SW is either written to the fieldbus SW as it is or the data is converted. See section [About the control profiles](#) (page 637).

### ■ References

EFB references 1 and 2 are 16-bit or 32-bit signed integers. The contents of each reference word can be used as the source of virtually any signal, such as the speed, frequency, torque or process reference. In embedded fieldbus communication, references 1 and 2 are displayed by [3.9 EFB reference 1](#) and [3.10 EFB reference 2](#) respectively. Whether the references are scaled or not depends on the settings of [58.26 EFB ref1 type](#) and [58.27 EFB ref2 type](#). See section [About the control profiles](#) (page 637).

### ■ Actual values

Fieldbus actual signals (ACT1 and ACT2) are 16-bit or 32-bit signed integers. They convey selected drive parameter values from the drive to the master. Whether the actual values are scaled or not depends on the settings of [58.28 EFB act1 type](#) and [58.29 EFB act2 type](#). See section [About the control profiles](#) (page 637).

### ■ Data input/outputs

Data input/outputs are 16-bit or 32-bit words containing selected drive parameter values. Parameters [58.101 Data I/O 1 ... 58.124 Data I/O 24](#) define the addresses from which the master either reads data (input) or to which it writes data (output).

### Control of drive outputs through EFB

The address selection parameters of the data input/outputs have a setting with which the data can be written into a storage parameter in the drive. These storage parameters are readily selectable as signal sources of the drive outputs.

The desired values of the relay outputs (RO) and digital input/outputs (DIO) can be written in a 16-bit word into [10.99 RO/DIO control word](#), which is then selected as the source of those outputs. Each of the analog outputs (AO) of the drive have a dedicated storage parameter ([13.91 AO1 data storage](#) and [13.92 AO2 data storage](#)), which are available in the source selection parameters [13.12 AO1 source](#) and [13.22 AO2 source](#).

---

## Sending process PID feedback and setpoint values through EFB

The drive also has storage parameters for incoming process PID feedback ([40.91 Feedback data storage](#)) as well as a process PID setpoint ([40.92 Setpoint data storage](#)). The feedback storage parameter is selectable in the source selection parameters [40.8 Set 1 feedback 1 source](#) and [40.9 Set 1 feedback 2 source](#).

The corresponding parameters in process PID control set 2 (group [41 Process PID set 2](#)) have the same selections.

### ■ Register addressing

The address field of Modbus requests for accessing holding registers is 16 bits. This allows the Modbus protocol to support addressing of 65536 holding registers.

Historically, Modbus master devices used 5-digit decimal addresses from 40001 to 49999 to represent holding register addresses. The 5-digit decimal addressing limited to 9999 the number of holding registers that could be addressed.

Modern Modbus master devices typically provide a means to access the full range of 65536 Modbus holding registers. One of these methods is to use 6-digit decimal addresses from 400001 to 465536. This manual uses 6-digit decimal addressing to represent Modbus holding register addresses.

Modbus master devices that are limited to the 5-digit decimal addressing may still access registers 400001 to 409999 by using 5-digit decimal addresses 40001 to 49999. Registers 410000 to 465536 are inaccessible to these masters.

**Note:** Register addresses of 32-bit parameters cannot be accessed by using 5-digit register numbers.


## About the control profiles

A control profile defines the rules for data transfer between the drive and the fieldbus master, for example:

- if packed boolean words are converted and how
- how drive register addresses are mapped for the fieldbus master.

You can configure the drive to receive and send messages according to the ABB Drives profile or the Transparent profile. With the ABB Drives profile, the embedded fieldbus interface of the drive converts the control word and status word to and from the native data used in the drive. The Transparent profile involves no data conversion. The figure below illustrates the effect of the profile selection.

---



Control profile selection with parameter **58.25 Control profile**:

- (0) **ABB Drives**
- (2) **Transparent**


Note that scaling of references and actual values can be selected independent of the profile selection by parameters **58.26...58.29**.

## The ABB Drives profile

### ■ Control Word

The table below shows the contents of the fieldbus Control Word for the ABB Drives control profile. The embedded fieldbus interface converts this word to the form in which it is used in the drive. The upper case boldface text refers to the states shown in [State transition diagram \(page 641\)](#).

Bit	Name	Value	STATE/Description
0	OFF1_CONTROL	1	Proceed to <b>READY TO OPERATE</b> .
		0	Stop along currently active deceleration ramp. Proceed to <b>OFF1 ACTIVE</b> ; proceed to <b>READY TO SWITCH ON</b> unless other interlocks ( <b>OFF2</b> , <b>OFF3</b> ) are active.
1	OFF2_CONTROL	1	Continue operation ( <b>OFF2</b> inactive).
		0	Emergency OFF, coast to stop. Proceed to <b>OFF2 ACTIVE</b> , proceed to <b>SWITCH-ON INHIBITED</b> .

Bit	Name	Value	STATE/Description
2	OFF3_CONTROL	1	Continue operation (OFF3 inactive).
		0	Emergency stop, stop within time defined by drive parameter. Proceed to OFF3 ACTIVE; proceed to SWITCH-ON INHIBITED.   <b>WARNING!</b> Ensure that the motor and driven machine can be stopped using this stop mode.
3	INHIBIT_OPERATION	1	Proceed to <b>OPERATION ENABLED</b> .  <b>Note:</b> Run enable signal must be active; see the drive documentation. If the drive is set to receive the Run enable signal from the fieldbus, this bit activates the signal.
		0	Inhibit operation. Proceed to <b>OPERATION INHIBITED</b> .
4	RAMP_OUT_ZERO	1	Normal operation. Proceed to <b>RAMP FUNCTION GENERATOR: OUTPUT ENABLED</b> .
		0	Force Ramp Function Generator output to zero. Drive ramps to stop (current and DC voltage limits in force).
5	RAMP_HOLD	1	Enable ramp function. Proceed to <b>RAMP FUNCTION GENERATOR: ACCELERATOR ENABLED</b> .
		0	Halt ramping (Ramp Function Generator output held).
6	RAMP_IN_ZERO	1	Normal operation. Proceed to <b>OPERATING</b> .  <b>Note:</b> This bit is effective only if the fieldbus interface is set as the source for this signal by drive parameters.
		0	Force Ramp Function Generator input to zero.
7	RESET	0=>1	Fault reset if an active fault exists. Proceed to <b>SWITCH-ON INHIBITED</b> .  <b>Note:</b> This bit is effective only if the fieldbus interface is set as the source for this signal by drive parameters.
		0	Continue normal operation.

640 Fieldbus control through the embedded fieldbus interface (EFB)

Bit	Name	Value	STATE/Description
8	JOGGING_1	1	Accelerate to jogging 1 reference. <b>Note:</b> <ul style="list-style-type: none"> <li>• Bits 4...6 must be 0.</li> <li>• See also section <a href="#">Jogging (page 60)</a>.</li> </ul>
		0	Jogging 1 disabled.
9	JOGGING_2	1	Accelerate to jogging 2 reference. See notes at bit 8.
		0	Jogging 2 disabled.
10	REMOTE_CMD	1	Fieldbus control enabled.
		0	Fieldbus control disabled (some bits still operate e.g. Reset).
11	EXT_CTRL_LOC	1	Select External Control Location EXT2. Effective if the control location is parameterized to be selected from the fieldbus.
		0	Select External Control Location EXT1. Effective if the control location is parameterized to be selected from the fieldbus.
12...15	Reserved		

■ **Status Word**

The table below shows the fieldbus Status Word for the ABB Drives control profile. The embedded fieldbus interface converts the drive Status Word into this form for the fieldbus. The upper case boldface text refers to the states shown in [State transition diagram \(page 641\)](#).

Bit	Name	Value	STATE/Description
0	RDY_ON	1	READY TO SWITCH ON.
		0	NOT READY TO SWITCH ON.
1	RDY_RUN	1	READY TO OPERATE.
		0	OFF1 ACTIVE.
2	RDY_REF	1	OPERATION ENABLED.
		0	OPERATION INHIBITED.
3	TRIPPED	1	FAULT.
		0	No fault.
4	OFF_2_STA	1	OFF2 inactive.
		0	OFF2 ACTIVE.




Bit	Name	Value	STATE/Description
5	OFF_3_STA	1	OFF3 inactive.
		0	OFF3 ACTIVE.
6	SWC_ON_INHIB	1	SWITCH-ON INHIBITED.
		0	-
7	ALARM	1	Warning/Alarm.
		0	No warning/alarm.
8	AT_SETPOINT	1	OPERATING. Actual value equals Reference = is within tolerance limits, i.e. in speed control, speed error is 10% max. of nominal motor speed.
		0	Actual value differs from Reference = is outside tolerance limits.
9	REMOTE	1	Drive control location: REMOTE (EXT1 or EXT2).
		0	Drive control location: LOCAL.
10	ABOVE_LIMIT	1	Actual frequency or speed equals or exceeds supervision limit (set by drive parameter). Valid in both directions of rotation.
		0	Actual frequency or speed within supervision limit.
11	USER_0		Status bits that can be combined with drive logic for application-specific 12 USER_1 functionality.
12	EXT_RUN_ENABLE	1	External Run enable signal received.
		0	No external Run enable signal received.
13...15	Reserved		

■ **State transition diagram**

The diagram below shows the state transitions in the drive when the drive is using the ABB Drives profile, and configured to follow the commands of the control word from the embedded fieldbus interface. The upper case texts refer to the states which are used in the tables representing the fieldbus Control and Status words. See sections [Control Word \(page 638\)](#) and [Status Word \(page 640\)](#).


# 642 Fieldbus control through the embedded fieldbus interface (EFB)



## ■ References

The ABB drives profile supports the use of two references, EFB reference 1 and EFB reference 2. The references are 16-bit words each containing a sign bit and a 15-bit integer. A negative reference is formed by calculating the two's complement from the corresponding positive reference.

The references are scaled as defined by parameters [46.01...46.07](#); which scaling is in use depends on the setting of [58.26 EFB ref1 type](#) and [58.27 EFB ref2 type](#) (page 465).




The scaled references are shown by parameters [3.9 EFB reference 1](#) and [3.10 EFB reference 2](#).

■ **Actual values**

The ABB Drives profile supports the use of two fieldbus actual values, ACT1 and ACT2. The actual values are 16-bit words each containing a sign bit and a 15-bit integer. A negative value is formed by calculating the two's complement from the corresponding positive value.

The actual values are scaled as defined by parameters 46.01...46.04; which scaling is in use depends on the setting of parameters 58.28 EFB act1 type and 58.29 EFB act2 type (page 465).



## ■ Modbus holding register addresses

The table below shows the default Modbus holding register addresses for drive data.

This profile provides a converted 16-bit access to the data.

Register address	Register data (16-bit words)
400001	Control word. See section <a href="#">Control Word (page 638)</a> . The selection can be changed using parameter <a href="#">58.101 Data I/O 1</a> .
400002	Reference 1 (REF1). The selection can be changed using parameter <a href="#">58.102 Data I/O 2</a> .
400003	Reference 2 (REF2). The selection can be changed using parameter <a href="#">58.103 Data I/O 3</a> .
400004	Status Word (SW). See section <a href="#">Status Word (page 640)</a> . The selection can be changed using parameter <a href="#">58.104 Data I/O 4</a> .
400005	Actual value 1 (ACT1). The selection can be changed using parameter <a href="#">58.105 Data I/O 5</a> .
400006	Actual value 2 (ACT2). The selection can be changed using parameter <a href="#">58.106 Data I/O 6</a> .
400007...400024	Data in/out 7...24. Selected by parameters <a href="#">58.107 Data I/O 7 ... 58.124 Data I/O 24</a> .
400025...400089	Unused
400090...400100	Error code access. See section <a href="#">Error code registers (holding registers 400090...400100) (page 651)</a> .
400101...465536	Parameter read/write. Parameters are mapped to register addresses according to parameter <a href="#">58.33 Addressing mode</a> .

## The Transparent profile

The Transparent profile enables a customizable access to the drive.

The contents of the control word are user-definable. The control word received from the fieldbus is visible in parameter [6.5 EFB transparent control word](#), and can be used to control the drive using pointer parameters and/or application programming.

The status word to be sent to the fieldbus controller is selected by parameter [58.30 EFB status word transparent source](#). This can be, for example, the user-configurable status word in [6.50 User status word 1](#).

The Transparent profile involves no data conversion of the control or status word. Whether references or actual values are scaled depends on the setting of parameters 58.26...58.29. The references received from the fieldbus are visible in parameters 3.9 EFB reference 1 and 3.10 EFB reference 2.

The Modbus holding register addresses for the Transparent profile are as with the ABB Drives profile (see page 645).

## Modbus function codes

The table below shows the Modbus function codes supported by the embedded fieldbus interface.

Code	Function name	Description
01h	Read Coils	Reads the 0/1 status of coils (0X references).
02h	Read Discrete Inputs	Reads the 0/1 status of discrete inputs (1X references).
03h	Read Holding Registers	Reads the binary contents of holding registers (4X references).
05h	Write Single Coil	Forces a single coil (0X reference) to 0 or 1.
06h	Write Single Register	Writes a single holding register (4X reference).
08h	Diagnostics	Provides a series of tests for checking the communication, or for checking various internal error conditions. Supported subcodes: <ul style="list-style-type: none"> <li>• 00h Return Query Data: Echo/loopback test.</li> <li>• 01h Restart Comm Option: Restarts and initializes the EFB, clears communications event counters.</li> <li>• 04h Force Listen Only Mode</li> <li>• 0Ah Clear Counters and Diagnostic Register</li> <li>• 0Bh Return Bus Message Count</li> <li>• 0Ch Return Bus Comm. Error Count</li> <li>• 0Dh Return Bus Exception Error Count</li> <li>• 0Eh Return Slave Message Count</li> <li>• 0Fh Return Slave No Response Count</li> <li>• 10h Return Slave NAK (negative acknowledge) Count</li> <li>• 11h Return Slave Busy Count</li> <li>• 12h Return Bus Character Overrun Count</li> <li>• 14h Clear Overrun Counter and Flag</li> </ul>
0Bh	Get Comm Event Counter	Returns a status word and an event count.

Code	Function name	Description
0Fh	Write Multiple Coils	Forces a sequence of coils (0X references) to 0 or 1.
10h	Write Multiple Registers	Writes the contents of a contiguous block of holding registers (4X references).
16h	Mask Write Register	Modifies the contents of a 4X register using a combination of an AND mask, an OR mask, and the register's current contents.
17h	Read/Write Multiple Registers	Writes the contents of a contiguous block of 4X registers, then reads the contents of another group of registers (the same or different than those written) in a server device.
2Bh/0Eh	Encapsulated Interface Transport	<p>Supported subcodes:</p> <ul style="list-style-type: none"> <li>• 0Eh Read Device Identification: Allows reading the identification and other information.</li> </ul> <p>Supported ID codes (access type):</p> <ul style="list-style-type: none"> <li>• 00h: Request to get the basic device identification (stream access)</li> <li>• 04h: Request to get one specific identification object (individual access)</li> </ul> <p>Supported Object IDs:</p> <ul style="list-style-type: none"> <li>• 00h: Vendor Name ("ABB")</li> <li>• 01h: Product Code (for example, "AINFX")</li> <li>• 02h: Major Minor Revision (combination of contents of parameters <a href="#">7.5 Firmware version</a> and <a href="#">58.2 Protocol ID</a>).</li> <li>• 03h: Vendor URL ("www.abb.com")</li> <li>• 04h: Product name (for example, "ACS880")</li> </ul>

## Exception codes

The table below shows the Modbus exception codes supported by the embedded fieldbus interface.

Code	Name	Description
01h	ILLEGAL FUNCTION	The function code received in the query is not an allowable action for the server.
02h	ILLEGAL DATA ADDRESS	The data address received in the query is not an allowable address for the server.

Code	Name	Description
03h	ILLEGAL DATA VALUE	The requested Quantity of Registers is larger than the drive can handle.  <b>Note:</b> This error does not mean that a value written to a drive parameter is outside the valid range.
04h	SLAVE DEVICE FAILURE	The value written to a drive parameter is outside the valid range. See section <a href="#">Error code registers (holding registers 400090...400100)</a> (page 651).
06h	SLAVE DEVICE BUSY	The server is engaged in processing a long-duration program command.

### Coils (0xxxx reference set)

Coils are 1-bit read/write values. Control Word bits are exposed with this data type. The table below summarizes the Modbus coils (0xxxx reference set).

Reference	ABB drives profile	Transparent profile
00001	OFF1_CONTROL	Control Word bit 0
00002	OFF2_CONTROL	Control Word bit 1
00003	OFF3_CONTROL	Control Word bit 2
00004	INHIBIT_OPERATION	Control Word bit 3
00005	RAMP_OUT_ZERO	Control Word bit 4
00006	RAMP_HOLD	Control Word bit 5
00007	RAMP_IN_ZERO	Control Word bit 6
00008	RESET	Control Word bit 7
00009	JOGGING_1	Control Word bit 8
00010	JOGGING_2	Control Word bit 9
00011	REMOTE_CMD	Control Word bit 10
00012	EXT_CTRL_LOC	Control Word bit 11
00013	User-defined (0)	Control Word bit 12
00014	User-defined (1)	Control Word bit 13
00015	User-defined (2)	Control Word bit 14
00016	User-defined (3)	Control Word bit 15
00017	Reserved	Control Word bit 16
00018	Reserved	Control Word bit 17
00019	Reserved	Control Word bit 18



Reference	ABB drives profile	Transparent profile
00020	Reserved	Control Word bit 19
00021	Reserved	Control Word bit 20
00022	Reserved	Control Word bit 21
00023	Reserved	Control Word bit 22
00024	Reserved	Control Word bit 23
00025	Reserved	Control Word bit 24
00026	Reserved	Control Word bit 25
00027	Reserved	Control Word bit 26
00028	Reserved	Control Word bit 27
00029	Reserved	Control Word bit 28
00030	Reserved	Control Word bit 29
00031	Reserved	Control Word bit 30
00032	Reserved	Control Word bit 31
00033	Reserved	10.99 RO/DIO control word, bit 0
00034	Reserved	10.99 RO/DIO control word, bit 1
00035	Reserved	10.99 RO/DIO control word, bit 2
00036	Reserved	10.99 RO/DIO control word, bit 3
00037	Reserved	10.99 RO/DIO control word, bit 4
00038	Reserved	10.99 RO/DIO control word, bit 5
00039	Reserved	10.99 RO/DIO control word, bit 6
00040	Reserved	10.99 RO/DIO control word, bit 7
00041	Reserved	10.99 RO/DIO control word, bit 8
00042	Reserved	10.99 RO/DIO control word, bit 9

## Discrete inputs (1xxxx reference set)

Discrete inputs are 1-bit read-only values. Status Word bits are exposed with this data type. The table below summarizes the Modbus discrete inputs (1xxxx reference set).

Reference	ABB drives profile	Transparent profile
10001	RDY_ON	Status Word bit 0
10002	RDY_RUN	Status Word bit 1
10003	RDY_REF	Status Word bit 2

650 Fieldbus control through the embedded fieldbus interface (EFB)

Reference	ABB drives profile	Transparent profile
10004	TRIPPED	Status Word bit 3
10005	OFF_2_STA	Status Word bit 4
10006	OFF_3_STA	Status Word bit 5
10007	SWC_ON_INHIB	Status Word bit 6
10008	ALARM	Status Word bit 7
10009 10009	AT_SETPOINT	Status Word bit 8
10010	REMOTE	Status Word bit 9
10011	ABOVE_LIMIT	Status Word bit 10
10012	User-defined (0)	Status Word bit 11
10013	User-defined (1)	Status Word bit 12
10014	User-defined (2)	Status Word bit 13
10015	User-defined (3)	Status Word bit 14
10016	Reserved	Status Word bit 15
10017	Reserved	Status Word bit 16
10018	Reserved	Status Word bit 17
10019	Reserved	Status Word bit 18
10020	Reserved	Status Word bit 19
10021	Reserved	Status Word bit 20
10022	Reserved	Status Word bit 21
10023	Reserved	Status Word bit 22
10024	Reserved	Status Word bit 23
10025	Reserved	Status Word bit 24
10026	Reserved	Status Word bit 25
10027	Reserved	Status Word bit 26
10028	Reserved	Status Word bit 27
10029	Reserved	Status Word bit 28
10030	Reserved	Status Word bit 29
10031	Reserved	Status Word bit 30
10032	Reserved	Status Word bit 31
10033	Reserved	<a href="#">10.2 DI delayed status</a> , bit 0
10034	Reserved	<a href="#">10.2 DI delayed status</a> , bit 1

Reference	ABB drives profile	Transparent profile
10035	Reserved	10.2 DI delayed status, bit 2
10036	Reserved	10.2 DI delayed status, bit 3
10037	Reserved	10.2 DI delayed status, bit 4
10038	Reserved	10.2 DI delayed status, bit 5
10039	Reserved	10.2 DI delayed status, bit 6
10040	Reserved	10.2 DI delayed status, bit 7
10041	Reserved	10.2 DI delayed status, bit 8
10042	Reserved	10.2 DI delayed status, bit 9
10043	Reserved	10.2 DI delayed status, bit 10
10044	Reserved	10.2 DI delayed status, bit 11
10045	Reserved	10.2 DI delayed status, bit 12
10046	Reserved	10.2 DI delayed status, bit 13
10047	Reserved	10.2 DI delayed status, bit 14
10048	Reserved	10.2 DI delayed status, bit 15

## Error code registers (holding registers 400090...400100)

These registers contain information about the last query. The error register is cleared when a query has finished successfully.

Reference	Name	Description
90	Reset Error Registers	1 = Reset internal error registers (91...95).
91	Error Function Code	Function code of the failed query.
92	Error Code	Set when exception code 04h is generated (see table above). <ul style="list-style-type: none"> <li>• 00h No error</li> <li>• 02h Low/High limit exceeded</li> <li>• 03h Faulty Index: Unavailable index of an array parameter</li> <li>• 05h Incorrect Data Type: Value does not match the data type of the parameter</li> <li>• 65h General Error: Undefined error when handling query</li> </ul>
93	Failed Register	The last register (discrete input, coil, or holding register) that failed to be read or written.
94	Last Register Written Successfully	The last register that was written successfully.

## 652 Fieldbus control through the embedded fieldbus interface (EFB)

<b>Reference</b>	<b>Name</b>	<b>Description</b>
95	Last Register Read Successfully	The last register that was read successfully.

9

# Fieldbus control through a fieldbus adapter

---

## What this chapter contains

This chapter describes how the drive can be controlled by external devices over a communication network (fieldbus) through an optional fieldbus adapter module.

The fieldbus control interface of the drive is described first, followed by a configuration example.

## System overview

The drive can be connected to an external control system through an optional fieldbus adapter mounted onto the control unit of the drive. The drive actually has two independent interfaces for fieldbus connection, called “fieldbus adapter A” (FBA A) and “fieldbus adapter B” (FBA B). The drive can be configured to receive all of its control information through the fieldbus interface(s), or the control can be distributed between the fieldbus interface(s) and other available sources such as digital and analog inputs, depending on how control locations EXT1 and EXT2 are configured.

**Note:** The text and examples in this chapter describe the configuration of one fieldbus adapter (FBA A) by parameters [50.01...50.21](#) and parameter groups 51...53. The second adapter (FBA B), if present, is configured in a similar fashion by parameters [50.31...50.51](#) and parameter groups 54...56. It is recommended that the FBA B interface is only used for monitoring.


---

## 654 Fieldbus control through a fieldbus adapter

Fieldbus adapters are available for various communication systems and protocols, for example

- CANopen (FCAN-01 adapter)
- ControlNet (FCNA-01 adapter)
- DeviceNet (FDNA-01 adapter)
- EtherCAT® (FECA-01 adapter)
- EtherNet/IP™ (FENA-11 or FENA-21 adapter)
- Modbus/RTU (FSCA-01 adapter)
- Modbus/TCP (FENA-11 or FENA-21 adapter)
- POWERLINK (FEPL-02 adapter)
- PROFIBUS DP (FPBA-01 adapter)
- PROFINET IO (FENA-11 or FENA-21 adapter).


**Note:** Fieldbus adapters with the suffix “M” (eg. FPBA-01-M) are not supported.



## Basics of the fieldbus control interface

The cyclic communication between a fieldbus system and the drive consists of 16- or 32-bit input and output data words. The drive is able to support a maximum of 12 data words (16 bits) in each direction.

Data transmitted from the drive to the fieldbus controller is defined by parameters [52.1 FBA A data in1 ... 52.12 FBA A data in12](#). The data transmitted from the fieldbus controller to the drive is defined by parameters [53.1 FBA data out1 ... 53.12 FBA data out12](#).



3)	Profile/instance selection parameters. Fieldbus module specific parameters. For more information, see the <i>User's Manual</i> of the appropriate fieldbus adapter module.
4)	With DeviceNet, the control part is transmitted directly.
5)	With DeviceNet, the actual value part is transmitted directly.

■ **Control word and Status word**

The Control word is the principal means for controlling the drive from a fieldbus system. It is sent by the fieldbus master station to the drive through the adapter module. The drive switches between its states according to the bit-coded instructions in the Control word, and returns status information to the master in the Status word.

For the ABB Drives communication profile, the contents of the Control word and the Status word are detailed on pages 573 and 574 respectively. The drive states are presented in the state diagram (page 575).

When a transparent communication profile is selected eg. by parameter group 51 [FBA A settings](#), the control word received from the PLC is available in [6.3 FBA A transparent control word](#). The individual bits of the word can then be used for drive control through bit pointer parameters. The source of the status word, for example [6.50 User status word 1](#), can be selected in [50.9 FBA A SW transparent source](#).

**Debugging the network words**

If parameter [50.12 FBA A debug mode](#) is set to [Fast](#), the Control word received from the fieldbus is shown by parameter [50.13 FBA A control word](#), and the Status word transmitted to the fieldbus network by [50.16 FBA A status word](#). This “raw” data is very useful to determine if the fieldbus master is transmitting the correct data before handing control to the fieldbus network.



## ■ References

References are 16-bit words containing a sign bit and a 15-bit integer. A negative reference (indicating reversed direction of rotation) is formed by calculating the two's complement from the corresponding positive reference.

ABB drives can receive control information from multiple sources including analog and digital inputs, the drive control panel and a fieldbus adapter module. In order to have the drive controlled through the fieldbus, the module must be defined as the source for control information such as reference. This is done using the source selection parameters in groups [22 Speed reference selection](#), [26 Torque reference chain](#) and [28 Frequency reference chain](#).


## Debugging the network words

If parameter [50.12 FBA A debug mode](#) is set to **Fast**, the references received from the fieldbus are displayed by [50.14 FBA A reference 1](#) and [50.15 FBA A reference 2](#).

## Scaling of references

**Note:** The scalings described below are for the ABB Drives communication profile. Fieldbus-specific communication profiles may use different scalings. For more information, see the manual of the fieldbus adapter

The references are scaled as defined by parameters [46.01...46.07](#); which scaling is in use depends on the setting of [50.4 FBA A ref1 type](#) and [50.5 FBA A ref2 type](#).



The scaled references are shown by parameters [3.5 FB A reference 1](#) and [3.6 FB A reference 2](#).

■ **Actual values**

Actual values are 16-bit words containing information on the operation of the drive. The types of the monitored signals are selected by parameters [50.7 FBA A actual 1 type](#) and [50.8 FBA A actual 2 type](#).


**Debugging the network words**

If parameter [50.12 FBA A debug mode](#) is set to **Fast**, the actual values sent to the fieldbus are displayed by [50.17 FBA A actual value 1](#) and [50.18 FBA A actual value 2](#).

**Scaling of actual values**


**Note:** The scalings described below are for the ABB Drives communication profile. Fieldbus-specific communication profiles may use different scalings. For more information, see the manual of the fieldbus adapter.

The actual values are scaled as defined by parameters [46.01...46.04](#); which scaling is in use depends on the setting of parameters [50.7 FBA A actual 1 type](#) and [50.8 FBA A actual 2 type](#).



## ■ Contents of the fieldbus Control word (ABB Drives profile)

The upper case boldface text refers to the states shown in the state diagram (page 575).

Bit	Name	Value	STATE/Description
0	Off1 control	1	Proceed to <b>READY TO OPERATE</b> .
		0	Stop along currently active deceleration ramp. Proceed to <b>OFF1 ACTIVE</b> ; proceed to <b>READY TO SWITCH ON</b> unless other interlocks (OFF2, OFF3) are active.
1	Off2 control	1	Continue operation (OFF2 inactive).
		0	Emergency OFF, coast to a stop. Proceed to <b>OFF2 ACTIVE</b> , proceed to <b>SWITCH-ON INHIBITED</b> .
2	Off3 control	1	Continue operation (OFF3 inactive).
		0	Emergency stop, stop within time defined by drive parameter. Proceed to <b>OFF3 ACTIVE</b> ; proceed to <b>SWITCH-ON INHIBITED</b> .   <b>WARNING!</b> Ensure motor and driven machine can be stopped using this stop mode.
3	Run	1	Proceed to <b>OPERATION ENABLED</b> .  <b>Note:</b> Run enable signal must be active. If the drive is set to receive the Run enable signal from the fieldbus, this bit activates the signal. See also parameters <a href="#">6.18 Start inhibit status word</a> and <a href="#">6.25 Drive inhibit status word 2</a> .
		0	Inhibit operation. Proceed to <b>OPERATION INHIBITED</b> .
4	Ramp out zero	1	Normal operation. Proceed to <b>RAMP FUNCTION GENERATOR: OUTPUT ENABLED</b> .
		0	Force Ramp function generator output to zero. The drive will immediately decelerate to zero speed (observing the torque limits).
5	Ramp hold	1	Enable ramp function. Proceed to <b>RAMP FUNCTION GENERATOR: ACCELERATOR ENABLED</b> .
		0	Halt ramping (Ramp Function Generator output held).

660 Fieldbus control through a fieldbus adapter


Bit	Name	Value	STATE/Description
6	Ramp in zero	1	Normal operation. Proceed to <b>OPERATING</b> .  <b>Note:</b> This bit is effective only if the fieldbus interface is set as the source for this signal by drive parameters.
		0	Force Ramp function generator input to zero.
7	Reset	0=>1	Fault reset if an active fault exists. Proceed to <b>SWITCH-ON INHIBITED</b> .  <b>Note:</b> This bit is effective only if the fieldbus interface is set as the source of the reset signal by drive parameters.
		0	Continue normal operation.
8	Inching 1	1	Accelerate to inching (jogging) setpoint 1.  <b>Note:</b> <ul style="list-style-type: none"> <li>• Bits 4...6 must be 0.</li> <li>• See also section <a href="#">Jogging (page 60)</a>.</li> </ul>
		0	Inching (jogging) 1 disabled.
9	Inching 2	1	Accelerate to inching (jogging) setpoint 2. See notes at bit 8.
		0	Inching (jogging) 2 disabled.
10	Remote cmd	1	Fieldbus control enabled.
		0	Control word and reference not getting through to the drive, except for bits 0...2.
11	Ext ctrl loc	1	Select External Control Location EXT2. Effective if control location is parameterized to be selected from fieldbus.
		0	Select External Control Location EXT1. Effective if control location is parameterized to be selected from fieldbus.
12 to 15	Reserved.		

## ■ Contents of the fieldbus Status word (ABB Drives profile)

The upper case boldface text refers to the states shown in the state diagram (page 575).

Bit	Name	Value	STATE/Description
0	Ready to switch ON	1	<b>READY TO SWITCH ON.</b>
		0	<b>NOT READY TO SWITCH ON.</b>
1	Ready run	1	<b>READY TO OPERATE.</b>
		0	<b>OFF1 ACTIVE.</b>
2	Ready ref	1	<b>OPERATION ENABLED.</b>
		0	<b>OPERATION INHIBITED.</b> See parameters 6.18 Start inhibit status word and 6.25 Drive inhibit status word 2 for the inhibiting condition.
3	Tripped	1	<b>FAULT.</b>
		0	No fault.
4	Off 2 inactive	1	OFF2 inactive.
		0	<b>OFF2 ACTIVE.</b>
5	Off 3 inactive	1	OFF3 inactive.
		0	<b>OFF3 ACTIVE.</b>
6	Switch-on inhibited	1	<b>SWITCH-ON INHIBITED.</b>
		0	–
7	Warning	1	Warning active.
		0	No warning active.
8	At setpoint	1	<b>OPERATING.</b> Actual value equals reference = is within tolerance limits (see parameters 46.21...46.23).
		0	Actual value differs from reference = is outside tolerance limits.
9	Remote	1	Drive control location: REMOTE (EXT1 or EXT2).
		0	Drive control location: LOCAL.
10	Above limit	-	See parameter 6.29 MSW bit 10 sel.
11	User bit 0	-	See parameter 6.30 MSW bit 11 sel.
12	User bit 1	-	See parameter 6.31 MSW bit 12 sel.
13	User bit 2	-	See parameter 6.32 MSW bit 13 sel.
14	User bit 3	-	See parameter 6.33 MSW bit 14 sel.
15	Reserved.		

■ The state diagram (ABB Drives profile)



## Setting up the drive for fieldbus control

1. Install the fieldbus adapter module mechanically and electrically according to the instructions given in the *User's manual* of the module.
2. Power up the drive.
3. Enable the communication between the drive and the fieldbus adapter module with parameter [50.1 FBA A enable](#).
4. With [50.2 FBA A comm loss func](#), select how the drive should react to a fieldbus communication break.

**Note:** This function monitors both the communication between the fieldbus master and the adapter module and the communication between the adapter module and the drive.

5. With [50.3 FBA A comm loss t out](#), define the time between communication break detection and the selected action.
6. Select application-specific values for the rest of the parameters in group [50 Fieldbus adapter \(FBA\)](#), starting from [50.04](#). Examples of appropriate values are shown in the tables below.
7. Set the fieldbus adapter module configuration parameters in group [51 FBA A settings](#). As a minimum, set the required node address and the control profile.
8. Define the process data transferred to and from the drive in parameter groups [52 FBA A data in](#) and [53 FBA A data out](#).

**Note:** Depending on the communication protocol and profile being used, the Control word and Status word may already be configured to be sent/received by the communication system.

9. Save the valid parameter values to permanent memory by setting parameter [96.7 Parameter save manually](#) to [Save](#).
  10. Validate the settings made in parameter groups 51, 52 and 53 by setting parameter [51.27 FBA A par refresh](#) to [Refresh](#).
  11. Configure control locations EXT1 and EXT2 to allow control and reference signals to come from the fieldbus. Examples of appropriate values are shown in the tables below.
-

■ **Parameter setting example: FPBA (PROFIBUS DP)**

This example shows how to configure a basic speed control application that uses the PROFIdrive communication profile with PPO Type 2. The start/stop commands and reference are according to the PROFIdrive profile, speed control mode.

The reference values sent over the fieldbus have to be scaled within the drive so they have the desired effect. The reference value ±16384 (4000h) corresponds to the range of speed set in parameter [46.1 Speed scaling](#) (both forward and reverse directions). For example, if [46.01](#) is set to 480 rpm, then 4000h sent over fieldbus will request 480 rpm.

Direction	PZD1	PZD2	PZD3	PZD4	PZD5	PZD6
Out	Control word	Speed reference	Acc time 1		Dec time 1	
In	Status word	Speed actual value	Motor current		DC voltage	

The table below gives the recommended drive parameter settings.

Drive parameter	Setting for ACS880 drives	Description
<a href="#">50.1 FBA A enable</a>	<b>1...3</b> = [slot number]	Enables communication between the drive and the fieldbus adapter module.
<a href="#">50.4 FBA A ref1 type</a>	<b>4</b> = Speed	Selects the fieldbus A reference 1 type and scaling.
<a href="#">50.7 FBA A actual 1 type</a>	<b>0</b> = Auto	Selects the actual value type/source and scaling according to the currently active control mode (as displayed by parameter <a href="#">19.01</a> ).
<a href="#">51.1 FBA A type</a>	<b>1</b> = FPBA <sup>1)</sup>	Displays the type of the fieldbus adapter module.
<a href="#">51.02 Node address</a>	<b>3</b> <sup>2)</sup>	Defines the PROFIBUS node address of the fieldbus adapter module.
<a href="#">51.03 Baud rate</a>	<b>12000</b> <sup>1)</sup>	Displays the current baud rate on the PROFIBUS network in kbit/s.
<a href="#">51.04 MSG type</a>	<b>1</b> = PPO1 <sup>1)</sup>	Displays the telegram type selected by the PLC configuration tool.
<a href="#">51.05 Profile</a>	<b>0</b> = PROFIdrive	Selects the Control word according to the PROFIdrive profile (speed control mode).
<a href="#">51.07 RPBA mode</a>	<b>0</b> = Disabled	Disables the RPBA emulation mode.
<a href="#">52.01 FBA data in1</a>	<b>4</b> = SW 16bit <sup>1)</sup>	Status word
<a href="#">52.02 FBA data in2</a>	<b>5</b> = Act1 16bit	Actual value 1



Drive parameter	Setting for ACS880 drives	Description
52.03 FBA data in3	01.07 <sup>2)</sup>	Motor current
52.05 FBA data in5	01.11 <sup>2)</sup>	DC voltage
53.01 FBA data out1	<b>1</b> = CW 16bit <sup>1)</sup>	Control word
53.02 FBA data out2	<b>2</b> = Ref1 16bit	Reference 1 (speed)
53.03 FBA data out3	23.12 <sup>2)</sup>	Acceleration time 1
53.05 FBA data out5	23.13 <sup>2)</sup>	Deceleration time 1
51.27 FBA A par refresh	<b>1</b> = Refresh	Validates the configuration parameter settings.
19.12 Ext1 control mode	<b>2</b> = Speed	Selects speed control as the control mode 1 for external control location EXT1.
20.1 Ext1 commands	<b>12</b> = Fieldbus A	Selects fieldbus adapter A as the source of the start and stop commands for external control location EXT1.
20.2 Ext1 start trigger type	<b>1</b> = Level	Selects a level-triggered start signal for external control location EXT1.
22.11 Speed ref1 source	<b>4</b> = FB A ref1	Selects fieldbus A reference 1 as the source for speed reference 1.

1) Read-only or automatically detected/set


2) Example

The start sequence for the parameter example above is given below.

#### Control word

- after power-on, fault or emergency stop:
  - 476h (1142 decimal) → NOT READY TO SWITCH ON
- in normal operation:
  - 477h (1143 decimal) → READY TO SWITCH ON (stopped)
  - 47Fh (1151 decimal) → OPERATING (running)





# Control chain diagrams

---

## What this chapter contains


The chapter presents the reference chains of the drive. The control chain diagrams can be used to trace how parameters interact and where parameters have an effect within the drive parameter system.

For a more general diagram, see section [Operating modes of the drive \(page 26\)](#).


---

## Drive control diagrams


### ■ Speed reference source selection I




■ Speed reference source selection II




■ Speed reference ramping and shaping



■ Motor feedback configuration




■ Load feedback and position counter configuration







■ Speed error calculation




■ Speed controller




■ Torque reference source selection and modification




■ Operating mode selection




■ Reference selection for torque controller



## Torque limitation




■ Torque controller









## ■ Frequency reference modification




■ DC voltage reference selection



■ DC voltage reference modification




■ Process PID setpoint and feedback source selection






■ Master/Follower communication I (Master)



■ Master/Follower communication II (Follower)







---

## Further information

### Product and service inquiries

Address any inquiries about the product to your local ABB representative, quoting the type designation and serial number of the unit in question. A listing of ABB sales, support and service contacts can be found by navigating to [www.abb.com/contact-centers](http://www.abb.com/contact-centers).

### Product training

For information on ABB product training, navigate to [new.abb.com/service/training](http://new.abb.com/service/training).

### Providing feedback on ABB manuals

Your comments on our manuals are welcome. Navigate to [new.abb.com/drives/manuals-feedback-form](http://new.abb.com/drives/manuals-feedback-form).

### Document library on the Internet

You can find manuals and other product documents in PDF format on the Internet at [www.abb.com/drives/documents](http://www.abb.com/drives/documents).



[www.abb.com/drives](http://www.abb.com/drives)



3AUA0000085967Y