

# **NPort S9000 Series Command Line Interface**

---

**Edition 1.0, March 2017**

[www.moxa.com/product](http://www.moxa.com/product)

**MOXA<sup>®</sup>**

© 2017 Moxa Inc. All rights reserved.

# NPort S9000 Series Command Line Interface

The software described in this manual is furnished under a license agreement and may be used only in accordance with the terms of that agreement.

## Copyright Notice

© 2017 Moxa Inc. All rights reserved.

## Trademarks

The MOXA logo is a registered trademark of Moxa Inc.  
All other trademarks or registered marks in this manual belong to their respective manufacturers.

## Disclaimer

Information in this document is subject to change without notice and does not represent a commitment on the part of Moxa.

Moxa provides this document as is, without warranty of any kind, either expressed or implied, including, but not limited to, its particular purpose. Moxa reserves the right to make improvements and/or changes to this manual, or to the products and/or the programs described in this manual, at any time.

Information provided in this manual is intended to be accurate and reliable. However, Moxa assumes no responsibility for its use, or for any infringements on the rights of third parties that may result from its use.

This product might include unintentional technical or typographical errors. Changes are periodically made to the information herein to correct such errors, and these changes are incorporated into new editions of the publication.

## Technical Support Contact Information

[www.moxa.com/support](http://www.moxa.com/support)

### **Moxa Americas**

Toll-free: 1-888-669-2872  
Tel: +1-714-528-6777  
Fax: +1-714-528-6778

### **Moxa Europe**

Tel: +49-89-3 70 03 99-0  
Fax: +49-89-3 70 03 99-99

### **Moxa India**

Tel: +91-80-4172-9088  
Fax: +91-80-4132-1045

### **Moxa China (Shanghai office)**

Toll-free: 800-820-5036  
Tel: +86-21-5258-9955  
Fax: +86-21-5258-5505

### **Moxa Asia-Pacific**

Tel: +886-2-8919-1230  
Fax: +886-2-8919-1231

# Table of Contents

<b>1. Command Modes</b> .....	<b>1-1</b>
CLI (Command Line Interface) .....	1-1
Configuring the NPort S9000 to CLI Mode .....	1-1
Basic Operation .....	1-2
Useful Interactive "Help" Features .....	1-3
<b>2. Commands</b> .....	<b>2-1</b>
2.1 Root Layer Commands .....	2-1
2.1.1 quit .....	2-1
2.1.2 exit .....	2-1
2.1.3 reload .....	2-2
2.1.4 terminal .....	2-2
2.1.5 login .....	2-3
2.1.6 copy .....	2-3
2.1.7 save .....	2-4
2.1.8 ping .....	2-4
2.1.9 clear .....	2-4
2.1.10 show .....	2-5
2.1.11 configure .....	2-7
2.1.12 sslcertgen .....	2-8
2.1.13 sshkeygen .....	2-8
2.2 Configuration Mode Commands .....	2-9
2.2.1 password-policy minimum-length .....	2-9
2.2.2 password-policy complexity-check .....	2-9
2.2.3 password-policy complexity-check .....	2-10
2.2.4 password-policy password-lifetime .....	2-10
2.2.5 login-lockout retry-threshold .....	2-11
2.2.6 login-lockout lockout-time .....	2-11
2.2.7 logging-capacity .....	2-12
2.2.8 hostname .....	2-12
2.2.9 snmp-server location .....	2-13
2.2.10 snmp-server description .....	2-13
2.2.11 snmp-server contact .....	2-14
2.2.12 snmp-server community .....	2-14
2.2.13 snmp-server version .....	2-14
2.2.14 snmp-server read-write-user .....	2-15
2.2.15 snmp-server read-only-user .....	2-15
2.2.16 snmp-server host .....	2-16
2.2.17 snmp-server trap-mode .....	2-16
2.2.18 interface .....	2-17
2.2.19 clock set .....	2-17
2.2.20 clock timezone .....	2-18
2.2.21 clock summer-time .....	2-18
2.2.22 ntp remote-server .....	2-19
2.2.23 ntp refresh-time .....	2-19
2.2.24 ntp server .....	2-19
2.2.25 irig-b .....	2-20
2.2.26 time-source .....	2-20
2.2.27 logging .....	2-20
2.2.28 line-swap-fast-recover .....	2-21
2.2.29 ip auto-logout .....	2-21
2.2.30 ip http-server .....	2-21
2.2.31 ip http-server login-message .....	2-22
2.2.32 ip http-server login-failure-message .....	2-22
2.2.33 ip telnet .....	2-23
2.2.34 ip ssh .....	2-23
2.2.35 ip snmp-agent .....	2-23
2.2.36 ip moxa-service .....	2-24
2.2.37 ip mms-service .....	2-24
2.2.38 ip igmp-snooping .....	2-24
2.2.39 ip igmp-snooping vlan .....	2-25
2.2.40 ip igmp-snooping querier vlan .....	2-25
2.2.41 ip igmp-snooping query-interval .....	2-26
2.2.42 ip igmp-snooping enhanced .....	2-26
2.2.43 ip igmp static-group .....	2-27
2.2.44 ip dhcp-relay server .....	2-27
2.2.45 ip dhcp-relay option82 .....	2-28
2.2.46 ip dhcp-relay option82 remote-id-type .....	2-28
2.2.47 serial .....	2-29

2.2.48	vlan create .....	2-29
2.2.49	vlan mode .....	2-29
2.2.50	gvrp.....	2-30
2.2.51	redundancy.....	2-30
2.2.52	redundancy mode.....	2-30
2.2.53	auth mode.....	2-31
2.2.54	auth tacacs+.....	2-31
2.2.55	auth tacacs+ server-ip.....	2-31
2.2.56	auth tacacs+ server-port.....	2-32
2.2.57	auth tacacs+ shared-key.....	2-32
2.2.58	auth tacacs+ auth-type.....	2-33
2.2.59	auth tacacs+ timeout.....	2-33
2.2.60	lldp enable.....	2-34
2.2.61	lldp timer .....	2-34
2.2.62	dot1x auth.....	2-34
2.2.63	dot1x reauth.....	2-35
2.2.64	dot1x radius .....	2-35
2.2.65	monitor.....	2-36
2.2.66	email-warning server.....	2-36
2.2.67	email-warning mail-address.....	2-37
2.2.68	email-warning account.....	2-37
2.2.69	email-warning send test email.....	2-38
2.2.70	email-warning event.....	2-38
2.2.71	relay-warning override.....	2-39
2.2.72	relay-warning config relay.....	2-39
2.2.73	relay-warning event.....	2-40
2.2.74	garp.....	2-40
2.2.75	ptp enable .....	2-41
2.2.76	ptp mode.....	2-41
2.2.77	ptp log-sync-interval.....	2-42
2.2.78	ptp log-announce-interval.....	2-42
2.2.79	ptp announce-receipt-timeout.....	2-42
2.2.80	ptp log-min-delay-req-interval.....	2-43
2.2.81	ptp log-min-pdelay-req-interval.....	2-43
2.2.82	ptp domain-number.....	2-43
2.2.83	ptp transport .....	2-44
2.2.84	ptp priority1.....	2-44
2.2.85	ptp priority2.....	2-44
2.2.86	ptp utc-offset.....	2-45
2.2.87	loopprotection.....	2-45
2.2.88	qos mode .....	2-45
2.2.89	qos mapping.....	2-46
2.2.90	account add.....	2-46
2.2.91	account edit.....	2-47
2.2.92	system-log system .....	2-47
2.2.93	system-log network .....	2-48
2.2.94	system-log config.....	2-48
2.2.95	system-log opmode .....	2-49
2.2.96	reset-button .....	2-49
2.2.97	console auth.....	2-49
2.2.98	console try-next-auth.....	2-50
2.3	Commands for Configuring Interface .....	2-50
2.3.1	Ethernet Interface Commands .....	2-50
2.3.2	VLAN Interface Commands.....	2-61
2.3.3	Serial Interface Commands .....	2-64
2.3.4	Protocol Modbus Interface Commands .....	2-78
2.3.5	Protocol DNP3 Interface Commands .....	2-83

# Command Modes

---

## Command Line Interface (CLI)

The command line interface (CLI) for the NPort S9000 series can be accessed through either the serial console or Telnet console. For either type of connection, access to the command line interface is generally referred to as an EXEC session.

The commands are separated into several tiers for different type of commands. The first tier commands are the root-layer commands, which should be executed under the root directory for some major function categories. These commands include view the settings, configuring the settings, etc. Other commands for different tiers should be executed in their relative folders. Please find all the details in Chapter 2, which explains how to use the commands to configure or monitor the NPort S9000 series.

## Configuring the NPort S9000 to CLI Mode

The default configuration mode for both the serial, Telnet, and SSH console is MENU mode. To change the NPort S9000 to CLI configuration mode, log in the NPort S9000's serial, Telnet or SSH console and go to **Login Mode** under **Basic Settings** and then press **y** to activate the change. You will then be able to view the CLI display in the console. (Note that the default login username is **admin**, and the password is **moxa**.)

1. Select **Basic Settings**.

```
-----
NPort S9450I-2S-SC-HV V1.0
-----
[Basic] [Serial] [Ethernet] [Eth. Adv.] [Management] [Monitor] [Restart] [Exit]
Basic settings for network and system parameter.
ESC: Previous menu  Enter: Select
```

2. Select **Login mode**.

```
NPort S9450I-2S-SC-HV V1.0
Basic
[General] [Time Settings] [Network] [GARP] [Login Mode] [Activate] [Quit]
Login Mode Setting
ESC: Previous menu  Enter: Select
```

3. Press **y** to activate.

```

NPort S9450I-2S-SC-HV V1.0
Basic
[General] [Time Settings] [Network] [GARP] [Login Mode] [Activate] [Quit]
Login Mode Setting
ESC: Previous menu Enter: Select

Current login mode: Menu
Press Y to change to CLI mode? (Y/N)

```

4. Now log in to access CLI display mode.

```
login as:
```

```

NPort S9450I-2S-SC-HV V1.0
-----
NPort S9450I-2S-SC-HV#

```

After changing to CLI mode, the CLI mode will be the default setting for the next reboot.

## Basic Operation

The CLI is organized in different configuration levels. When you first enter CLI mode, type **?** to view a quick help panel that shows the basic commands of the first configuration level. Type any of the commands shown on the screen to access the next configuration level. The quick help panel, accessed from any level by typing **?**, is a useful tool for understanding the commands in any level.

```

NPort S9450I-2S-SC-HV V1.0
-----
NPort S9450I-2S-SC-HV#
quit          - Exit command line interface
exit          - Exit command line interface
reload        - Halt and perform a cold restart
terminal      - Configure terminal page length
login         - Change login mode
copy          - Copy from one file to another
save          - Save running configuration to flash
ping          - Send echo messages
clear         - Clear information
show          - Show running system information
configure     - Enter configuration mode
sslcertgen   - Generate SSL certificate.
sshkeygen     - Generate SSH host key.
NPort S9450I-2S-SC-HV#

```

To enter the next level, type the commands shown in the console.

```

NPort S9450I-2S-SC-HV# configure
NPort S9450I-2S-SC-HV(config)#

```

To access the next higher level, type **exit**.

```

NPort S9450I-2S-SC-HV(config)# exit
NPort S9450I-2S-SC-HV#

```

To go directly back to the first level, type **Ctrl + z**.

```
NPort S9450I-2S-SC-HV(config)#  
NPort S9450I-2S-SC-HV# █
```

## Useful Interactive “Help” Features

The CLI includes several types of interactive commands. The **Help** commands are listed in the following table:

Command	Purpose
?	Provides a brief description of the Help feature in any command level.
Partial command?	Provides a list of commands that begin with the character string (no space between the command and the question mark).
Partial command<Tab>	Completes a partial command name (no space between the command and <Tab>).
Command?	Lists the keywords, arguments, or both associated with the command (type a space between the command and the question mark).
Command keyword?	Lists the arguments that are associated with the keyword (type a space between the keyword and the question mark).

## 2.1 Root Layer Commands

After logging in to the CLI console, users will be at the root folder of the CLI console. In the root folder, users can see the system settings, ping other devices, upgrade firmware and so on.

### 2.1.1 quit

Use **quit** to quit the current configuration mode.

#### **Commands**

##### **quit**

Syntax	<b>quit</b>	Exit command line interface
Description		
Defaults	N/A	
Permission	Admin group, User group	
Usage	N/A	
Guidelines		
Examples	NPort S9450I-2S-SC-HV# quit	

### 2.1.2 exit

Use **exit** to exit the current configuration mode.

#### **Commands**

##### **exit**

Syntax Description	<b>exit</b>	Exit from configure mode
		Exit from port setting mode
		Exit command line interface
		Exit from management interface setting
Defaults	N/A	
Permission	Admin group, User group	
Usage	N/A	
Guidelines		
Examples	NPort S9450I-2S-SC-HV(config)# exit NPort S9450I-2S-SC-HV#	



## 2.1.3 reload

Use the **reload** privileged command on the switch to restart the Moxa Switch. Use the **reload factory-default** privileged command to restore the switch configuration to the factory default values.

### Commands

**reload [factory-default]**

**reload [serial] {p1 | p2 | p3 | p4 | all}**

Syntax Description	<b>reload</b>	Halt and perform a cold restart
	<b>factory-default</b>	Halt and perform a cold restart with factory default
	<b>serial</b>	Restart a serial port.
	<b>p1</b>	Serial port 1.
	<b>p2</b>	Serial port 2.
	<b>p3</b>	Serial port 3.
	<b>p4</b>	Serial port 4.
	<b>all</b>	All serial ports.
Defaults	N/A	
Permission	Admin group	
Usage Guidelines	N/A	
Examples	NPort S9450I-2S-SC-HV# reload NPort S9450I-2S-SC-HV# reload factory-default NPort S9450I-2S-SC-HV# reload serial p1 p3 NPort S9450I-2S-SC-HV# reload serial all	

## 2.1.4 terminal

Use the **terminal** privileged command on the device server to Configure terminal page length. Use **terminal default** to set the terminal length to default value.

### Commands

**terminal terminal-length**

**terminal default length**

Syntax Description	<b>terminal</b>	Configure terminal page length
	<i>terminal-length</i>	Terminal page length
	<b>default length</b>	Reset the terminal length to the default
Defaults	20	
Permission	Admin group	
Usage Guidelines	terminal-length: 20 – 100, or set 0 to prevent pagination	
Examples	NPort S9450I-2S-SC-HV# terminal 20 NPort S9450I-2S-SC-HV# terminal default length	

## 2.1.5 login

Use the **login** privileged command on the device server to configure default login console.

### Commands

**login mode { menu | cli }**

Syntax	<b>login</b>	Change login mode
Description	<b>mode</b>	Login modes
	<b>menu</b>	Legacy menu mode
	<b>cli</b>	Command line interface
Defaults	menu	
Permission	Admin group	
Usage	N/A	
Guidelines		
Examples	NPort S9450I-2S-SC-HV# login mode cli	

## 2.1.6 copy

Use the **copy** privileged command on the device server to copy an image or configuration file from a remote server to the Flash memory or copy the running configuration, startup configuration, or event log to a remote server via TFTP.

### Commands

**copy tftp device-firmware**

**copy xmodem device-firmware**

**copy tftp running-config**

**copy {running-config|event-log|startup-config} tftp [tftp-address]**

Syntax	<b>copy</b>	Copy from one file to another
Description	<b>tftp</b>	Remote server through TFTP
	<b>xmodem</b>	Copy from xmodem
	<b>device-firmware</b>	System firmware
	<b>running-config</b>	Current running configuration of system
	<b>startup-config</b>	System startup configuration
	<b>event-log</b>	Event log file
	<i>tftp-address</i>	TFTP address. E.g., tftp://192.168.127.1/abc.txt
Defaults	N/A	
Permission	Admin group	
Usage	N/A	
Guidelines		
Examples	<pre>NPort S9450I-2S-SC-HV# copy tftp   device-firmware      - System firmware   running-config       - Current running configuration of system NPort S9450I-2S-SC-HV# copy tftp running-config Address or name of remote host [192.168.127.1]? 192.168.127.95 Source file name? cli.ini Save import config to flash? [Y/n] Saving configuration ...Success</pre>	

## 2.1.7 save

Use the **save** privileged command on the device server to save the configuration to the flash rom.

### Commands

#### save config

Syntax	<b>save config</b>	Save running configuration to flash
Description		
Defaults	N/A	
Permission	Admin group	
Usage	N/A	
Guidelines		
Examples	<pre>NPort S9450I-2S-SC-HV# save config  Saving configuration ... Success</pre>	

## 2.1.8 ping

Use the **ping** user EXEC command on the device server to diagnose the remote host if it is alive.

### Commands

#### ping destaddr

Syntax	<b>ping</b>	Send echo messages
Description	<i>destaddr</i>	Ping destination address or hostname
Defaults	N/A	
Permission	Admin group, User group	
Usage	N/A	
Guidelines		
Examples	<pre>NPort S9450I-2S-SC-HV# ping 192.168.127.1  PING 192.168.127.1, Send/Recv/Lost = 4/4/0</pre>	

## 2.1.9 clear

Use the **clear** privileged command on the device server to clear the information.

### Commands

#### clear { logging event-log | counters }

Syntax	<b>clear</b>	Clear information
Description	<b>logging event-log</b>	System event logs
	<b>counters</b>	Clear statistic counters
Defaults	N/A	
Permission	Admin group	
Usage	N/A	
Guidelines		
Examples	<pre>NPort S9450I-2S-SC-HV# clear loggin event-log NPort S9450I-2S-SC-HV# clear counters</pre>	

## 2.1.10 show

Use the **show** user EXEC command on the device server to display the system informations.

### Commands

**show** { **version** | **running-config** | **startup-config** | **system** | **users** | **ip** | **serial** | **clock** | **snmp** | **gmrp** | **password-policy** | **login-lockout** | **logging-capacity** | **qos** | **loopprotection** | **s2n-conn** | **serial-status** | **serial-error** | **serial-setting** | **serial-alias** | **serial-param** | **system-info** | **network-conn** | **accounts** }

**show auth** { **mode** | **tacacs+** | **radius**}

**show interface ethernet** *mod\_port* [{ **config** | **rate-limit** | **counters** }]

**show interface trunk** [ *trunk\_id\_range* [**counters**]]

**show interface mgmt** [**access-ip**]

**show interface serial** *port* { **opmode** | **data-packing** }

**show interface serial protocol** { **modbus** | **dnp3** }

**show redundancy** { **turbo-ring-v1** | **turbo-ring-v2** | **turbo-chain** | **spanning-tree** }

**show redundancy mst** { **configuration** | **cist** | **instance** *instid* }

**show mac-address-table** { **static** | **learned** | **interface ethernet** *mod\_port* | **trunk** *trunk\_id* }

**show logging** [**event-log**]

**show vlan** [**config**]

**show port-security** *mod\_port*

**show dot1x** { **local-userdb** | **radius** }

**show lldp** [**entry**]

**show port** [**monitor**]

**show email-warning** [**config**]

**show relay-warning** [{**config** | **status** }]

**show garp** [**timer**]

**show ptp** {**settings** | **status** | **port** [*mod\_port*] }

**show qos** [{**cos-to-queue** | **dscp-to-queue** }]

Syntax Description	<b>show</b>	Show running system information
	<b>version</b>	System version information
	<b>running-config</b>	Current running configuration of system
	<b>startup-config</b>	System startup configuration
	<b>system</b>	System hardware and software status
	<b>users</b>	Display login user settings
	<b>auth</b>	Display authentication settings
	<b>mode</b>	Display current server mode authentication settings
	<b>tacacs+</b>	TACACS+ authentication
	<b>radius</b>	RADIUS authentication
	<b>ip</b>	Display IP information
	<b>serial</b>	Show serial console setting
	<b>interfaces</b>	Interface status and configuration
	<b>ethernet</b>	IEEE 802.3/IEEE 802.3z
	<i>mod_port</i>	Port ID or list. Ex. 1/1,2,3,2/1-3,5,...
	<b>config</b>	Show interface module/port settings
	<b>rate-limit</b>	Rate limiting configuration
	<b>counters</b>	Display counters in detail
	<b>counters</b>	Display counters
	<b>trunk</b>	Show interface trunk information
<i>trunk_id_range</i>	Trunk ID (or list)	
<b>counters</b>	Display counters in detail	
<b>mgmt</b>	Display management VLAN information	
<b>access-ip</b>	Display accessible IP list	

<b>serial</b>	Show serial info
<i>port</i>	Serial port 1 - n
<b>opmode</b>	Show serial port opmode
<b>data-packing</b>	Show serial port data-packing
<b>protocol</b>	Show serial protocol
<b>modbus</b>	Show Modbus protocol settings
<b>dnp3</b>	Show DNP3 protocol settings
<b>clock</b>	Display the system clock
<b>snmp</b>	Display SNMP configuration
<b>redundancy</b>	Display redundancy protocol status
<b>turbo-ring-v1</b>	Display turbo ring v1 status
<b>turbo-ring-v2</b>	Display turbo ring v2 status
<b>turbo-chain</b>	Display turbo chain status
<b>spanning-tree</b>	Display spanning tree settings
<b>mst</b>	Display multiple spanning tree settings
<b>configuration</b>	Display multiple spanning tree global settings
<b>cist</b>	Display MSTP cist status
<b>instance</b>	Display MSTP msti status
<i>instid</i>	MSTP instance ID
<b>mac-address-table</b>	Display MAC address forwarding table
<b>static</b>	Retrieve static MAC addresses
<b>learned</b>	Retrieve learned MAC addresses
<b>interface</b>	Retrieve MAC address by interface
<b>ethernet</b>	Ethernet Port interface
<i>mod_port</i>	Port ID. Ex. 1/3, 2/1,...
<b>trunk</b>	Trunk interface
<i>trunk_id</i>	Trunk ID. From 1 to 2
<b>logging</b>	Display syslog information
<b>event-log</b>	Display system event logs
<b>vlan</b>	Display VLAN status
<b>config</b>	Display VLAN configuration
<b>gvrp</b>	Display GVRP configuration
<b>port-security</b>	Display port access control table
<i>mod_port</i>	Port ID or list. Ex. 1/1,2,3,2/1-3,5,...
<b>dot1x</b>	Display 802.1x settings
<b>local-userdb</b>	Display current local database
<b>radius</b>	Display 802.1x radius settings
<b>gmrp</b>	Display 802.1x radius settings
<b>lldp</b>	Display LLDP information
<b>entry</b>	LLDP entries
<b>email-warning</b>	Display Email warning configuration
<b>config</b>	Email warning configuration
<b>relay-warning</b>	Display relay warning configuration
<b>config</b>	Relay warning configuration
<b>status</b>	Current relay warning list
<b>garp</b>	Display GARP information
<b>timer</b>	Display GARP timer information
<b>ptp</b>	
<b>settings</b>	Display current PTP configuration
<b>status</b>	Display current PTP port state
<b>port</b>	Display PTP port disable/enable state
<i>mod_port</i>	Display PTP port disable/enable state

	<b>password-policy</b>	Display password policy settings
	<b>login-lockout</b>	Display login lockout settings
	<b>logging-capacity</b>	Display logging capacity settings
	<b>qos</b>	Display QoS configuration
	<b>cos-to-queue</b>	CoS to traffic queue mappings
	<b>dscp-to-queue</b>	DSCP to traffic queue mappings
	<b>loopprotection</b>	Display loop protection settings
	<b>s2n-conn</b>	Display the running serial to network connections
	<b>serial-status</b>	Display the running serial port current status
	<b>serial-error</b>	Display the running serial port error count
	<b>serial-setting</b>	Display the running serial port settings
	<b>serial-alias</b>	Display serial port alias name
	<b>serial-param</b>	Display serial port parameters
	<b>system-info</b>	Display system related status
	<b>network-conn</b>	Display network connection information
	<b>accounts</b>	Show current account informations
Defaults	N/A	
Permission	Admin group, User group	
Usage Guidelines	N/A	
Examples	<pre> NPort S9650I-16-2HV# show version Model Name           : NPort S9650I-16-2HV Firmware Version     : V1.0  NPort S9650I-16-2HV# show interfaces serial protocol modbus Serial protocol Modbus setting :  Initial delay : 0 Send TCP exception : disable Modbus TCP listen port : 502 Modbus TCP response timeout : 1000 Slave ID Map : Channel No.  Type          Definition          Modbus Address Range ----- 1           Modbus Serial Port 1  00001 - 00005                     </pre>	

### 2.1.11 configure

Use the **configure** privileged command on the device server to enter configuration mode.

**Commands**

**configure { terminal }**

Syntax	<b>configure</b>	Enter configuration mode
Description	<b>terminal</b>	Configure from the terminal
Defaults	N/A	
Permission	Admin group	
Usage Guidelines	N/A	
Examples	<pre> NPort S9450I-2S-SC-HV# configure NPort S9450I-2S-SC-HV(config)#                     </pre>	

## 2.1.12 sslcertgen

Use the **sslcertgen** privileged command on the device server to generate SSL certificate.

### Commands

#### sslcertgen

Syntax Description	<b>sslcertgen</b>	Generate SSL certificate
Defaults	N/A	
Permission	Admin group	
Usage Guidelines	N/A	
Examples	<pre>NPort S9450I-2S-SC-HV#sslcertgen Generating... it may take a few minutes... generating ssl certificate : done NPort S9450I-2S-SC-HV#</pre>	

## 2.1.13 sshkeygen

Use the **sshkeygen** privileged command on the device server to generate SSH host key.

### Commands

#### sshkeygen

Syntax Description	<b>sshkeygen</b>	Generate SSH host key
Defaults	N/A	
Permission	Admin group	
Usage Guidelines	N/A	
Examples	<pre>NPort S9450I-2S-SC-HV# sshkeygen Generating... it may take a few minutes... generating ssh host key : done NPort S9450I-2S-SC-HV#</pre>	

## 2.2 Configuration Mode Commands

In the root layer, use the "configure" command to enter configuration mode. In the configuration mode, user could set all system related settings of the device server.

### 2.2.1 password-policy minimum-length

Use **password-policy minimum-length** global password-policy configuration commands on the device server to configure the minimum password-length with specified characters. Use the **no** form of this command to return to the default.

#### Commands

**password-policy minimum-length** characters

**no password-policy minimum-length**

Syntax	<b>password-policy</b>	Global password-policy configuration subcommands
Description	<b>minimum-length</b>	Password minimum length
	characters	4 to 16 characters
Defaults	Password minimum length is 4 by default	
Permission	Admin group	
Usage	N/A	
Guidelines		
Examples	NPort S9450I-2S-SC-HV(config)# password-policy minimum-length 8 NPort S9450I-2S-SC-HV(config)# no password-policy minimum-length	

### 2.2.2 password-policy complexity-check

Use **password-policy complexity-check** global password-policy configuration commands on the device server to enable the password policy. Use the **no** form of this command to disable complexity-check.

#### Commands

**password-policy complexity-check**

**no password-policy complexity-check**

Syntax	<b>password-policy</b>	Global password-policy configuration subcommands
Description	<b>complexity-check</b>	Complexity check
Defaults	Password complexity-check is disable by default	
Permission	Admin group	
Usage	N/A	
Guidelines		
Examples	NPort S9450I-2S-SC-HV(config)# password-policy complexity-check	



## 2.2.3 password-policy complexity-check

Use **password-policy complexity-check** global password-policy configuration commands on the device server to enable the password policy check. Use the **no** form of this command to disable complexity-check.

### Commands

**password-policy complexity-check { digit | alphabet | special-characters }**

**no password-policy complexity-check { digit | alphabet | special-characters }**

Syntax	<b>password-policy</b>	Global password-policy configuration subcommands
Description	<b>complexity-check</b>	Complexity check
	<b>digit</b>	Enable password policy : at least one digit check
	<b>alphabet</b>	Enable password policy : mixed upper and lower case letters check
	<b>special-character</b> <b>s</b>	Enable password policy : at least one special character check
Defaults	Password complexity-check is disable by default Password complexity-check alphabet is disable by default Password complexity-check special-characters is disable by default	
Permission	Admin group	
Usage	N/A	
Guidelines		
Examples	NPort S9450I-2S-SC-HV(config)# password-policy complexity-check digit NPort S9450I-2S-SC-HV(config)# no password-policy complexity-check alphabet	

## 2.2.4 password-policy password-lifetime

Use **password-policy lifetime** global password-policy configuration commands on the device server to enable the password lifetime and the password lifetime with specified days. Use the **no** form of this command to disable password-lifetime check.

### Commands

**password-policy password-lifetime [days]**

**no password-policy password-lifetime**

Syntax	<b>password-policy</b>	Global password-policy configuration subcommands
Description	<b>password-lifetim</b> <b>e</b>	Password lifetime
	<i>days</i>	90 to 180 days
Defaults	Password lifetime is disable by default Password lifetime is 90 days by default	
Permission	Admin group	
Usage	N/A	
Guidelines		
Examples	NPort S9450I-2S-SC-HV(config)# password-policy password-lifetime NPort S9450I-2S-SC-HV(config)# password-policy password-lifetime 100	

## 2.2.5 login-lockout retry-threshold

Use **login-lockout retry-threshold** global login-lockout configuration commands on the device server to configure the login-lockout retry-threshold with specified times. Use the **no** form of this command to return to the default.

### Commands

**login-lockout retry-threshold** *retry*

**no login-lockout retry-threshold**

Syntax	<b>login-lockout</b>	Global login-lockout configuration subcommands
Description	<b>retry-threshold</b>	Login retry threshold
	<i>retry</i>	0 to 10 times(0 to disable)
Defaults	Login retry-threshold is 0 by default	
Permission	Admin group	
Usage Guidelines	N/A	
Examples	<pre>NPort S9450I-2S-SC-HV(config)# login-lockout retry-threshold 5 NPort S9450I-2S-SC-HV(config)# no login-lockout retry-threshold</pre>	

## 2.2.6 login-lockout lockout-time

Use **login-lockout lockout-time** global login-lockout configuration commands on the device server to configure the login-lockout lockout-time with specified minutes. Use the **no** form of this command to return to the default.

### Commands

**login-lockout lockout-time** *minutes*

**no login-lockout lockout-time**

Syntax	<b>login-lockout</b>	Global login-lockout configuration subcommands
Description	<b>lockout-time</b>	Login lockout time
	<i>minutes</i>	1 to 60 minutes
Defaults	Login lockout-time is 5 minutes by default	
Permission	Admin group	
Usage Guidelines	N/A	
Examples	<pre>NPort S9450I-2S-SC-HV(config)# login-lockout lockout-time 10 NPort S9450I-2S-SC-HV(config)# no login-lockout lockout-time</pre>	

## 2.2.7 logging-capacity

Use the **logging-capacity** privileged command on the device server to set logging capacity related settings.

### Commands

**logging-capacity over-size-action { overwrite-oldest | stop-recording }**

Syntax	<b>logging-capacity</b>	Set logging capacity related settings.
Description	<b>over-size-action</b>	Set logging capacity oversize-action.
	<b>overwrite-oldest</b>	Set logging capacity oversize-action : Overwrite oldest event logs
	<b>stop-recording</b>	Set logging capacity oversize-action : Stop recording event logs
Defaults	overwrite-oldest	
Permission	Admin group	
Usage	N/A	
Guidelines		
Examples	<pre>NPort S9650I-16-2HV(config)# logging-capacity over-size-action stop-recording NPort S9650I-16-2HV(config)# logging-capacity over-size-action overwrite-oldest</pre>	

## 2.2.8 hostname

To specify or modify the host name for the device server, use the **hostname** global configuration command. To return to the default, use the **no** form of this command.

### Commands

**hostname** *name*

**no hostname**

Syntax	<b>hostname</b>	Set system's network name (maximum 30 characters)
Description	<b>no</b>	Negate a command or set its defaults
Defaults	Name is the default device server name with the serial number	
Permission	Admin group	
Usage	Maximum string tokens are 5.	
Guidelines	Maximum device server name length is 30 characters.	
Examples	<pre>NPort S9650I-16-2HV(config)# hostname MOXA Nport device server NPort S9650I-16-2HV(config)# no hostname</pre>	

## 2.2.9 snmp-server location

To set the system location string, use the **snmp-server location** global configuration command. To remove the location string, use the **no** form of this command.

### Commands

**snmp-server location** *text*

**no snmp-server location**

Syntax	<b>snmp-server</b>	Configure SNMP server
Description	<b>location</b>	Device server location
	<i>text</i>	Location string
Defaults	N/A	
Permission	Admin group	
Usage	N/A	
Guidelines		
Examples	<pre>NPort S9650I-16-2HV(config)# snmp-server location moxacorp NPort S9650I-16-2HV(config)# no snmp-server location</pre>	

## 2.2.10 snmp-server description

To set the system description string, use the **snmp-server description** global configuration command. To remove the description string, use the **no** form of this command.

### Commands

**snmp-server description** *text*

**no snmp-server description**

Syntax	<b>snmp-server</b>	Configure SNMP server
Description	<b>description</b>	Device server description
	<i>text</i>	Description string
Defaults	The default description is the model name.	
Permission	Admin group	
Usage	"text" parameter can be set as string separated by space.	
Guidelines	Maximum string tokens are 5.	
	Maximum length of device server maintainer contact info is 40.	
Examples	<pre>NPort S9650I-16-2HV(config)# snmp-server description MOXA nport device NPort S9650I-16-2HV(config)# no snmp-server description</pre>	

## 2.2.11 snmp-server contact

To set the system contact string, use the **snmp-server contact** global configuration command. To remove the contact string, use the **no** form of this command.

### Commands

**snmp-server contact** *text*

**no snmp-server contact**

Syntax	<b>snmp-server</b>	Configure SNMP server
Description	<b>contact</b>	Device server maintainer contact information
	<i>text</i>	Maintainer contact information
Defaults	N/A	
Permission	Admin group	
Usage	"text" parameter can be set as string separated by space.	
Guidelines	Maximum string tokens are 5. Maximum length of maintainer contact info is 40.	
Examples	NPort S9650I-16-2HV(config)# snmp-server contact james NPort S9650I-16-2HV(config)# no snmp-server contact	

## 2.2.12 snmp-server community

To set up the community access string to permit access to the Simple Network Management Protocol (SNMP), use the **snmp-server community** global configuration command.

### Commands

**snmp-server community** *community\_str*

Syntax	<b>snmp-server</b>	Configure SNMP server
Description	<b>community</b>	SNMP community setting
	<i>community_str</i>	SNMP community string
Defaults	overwrite-oldest	
Permission	Admin group	
Usage	N/A	
Guidelines		
Examples	NPort S9650I-16-2HV(config)# snmp-server community public	

## 2.2.13 snmp-server version

To set up the snmp version, use the **snmp-server version** global configuration command.

### Commands

**snmp-server version** [**v1-v2c-v3** | **v1-v2c** | **v3**]

Syntax	<b>snmp-server</b>	Configure SNMP server
Description	<b>version</b>	SNMP version setting
	<b>v1-v2c-v3</b>	Version 1, 2C and 3 support
	<b>v1-v2c</b>	Version 1 and 2C support
	<b>v3</b>	Only version 3 support
Defaults	Default version is v1-v2c	
Permission	Admin group	
Usage	N/A	
Guidelines		
Examples	NPort S9650I-16-2HV(config)# snmp-server version v1-v2c-v3	

## 2.2.14 snmp-server read-write-user

To configure a read-write privileged user and its authentication type and password to a Simple Network Management Protocol (SNMP), use the **snmp-server read-write-user** global configuration command.

### Commands

**snmp-server read-write-user** *username* **auth** {no-auth|md5|sha} *password*

Syntax	<b>snmp-server</b>	Configure SNMP server
Description	<b>read-write-user</b>	SNMP read-write privileged user setting
	<i>username</i>	The name of the read-write privileged user
	<b>auth</b>	Specifies which authentication level should be used
	<i>auth-type</i>	no-auth   md5   sha
	<i>password</i>	Password (maximum 30 characters)
Defaults	N/A	
Permission	Admin group	
Usage	Username: max 16 characters	
Guidelines	Password: max 16 characters	
Examples	NPort S9650I-16-2HV(config)# snmp-server read-write-user admin auth md5 moxacli	

## 2.2.15 snmp-server read-only-user

To configure a read-write privileged user and its authentication type and password to a Simple Network Management Protocol (SNMP), use the **snmp-server read-only-user** global configuration command.

### Commands

**snmp-server read-only-user** *username* **auth** {no-auth|md5|sha} *password*

Syntax	<b>snmp-server</b>	Configure SNMP server
Description	<b>read-only-user</b>	SNMP read-write privileged user setting
	<i>username</i>	The name of the read-only privileged user
	<b>auth</b>	Specifies which authentication level should be used
	<i>auth-type</i>	no-auth   md5   sha
	<i>password</i>	Password (maximum 30 characters)
Defaults	N/A	
Permission	Admin group	
Usage	Username: max 16 characters	
Guidelines	Password: max 16 characters	
Examples	NPort S9650I-16-2HV(config)#snmp-server read-only-user user auth md5 moxacli	

## 2.2.16 snmp-server host

To specify the recipient of a Simple Network Management Protocol (SNMP) notification operation, use the **snmp-server host** global configuration command. To remove the specified host, use the **no** form of this command

### Commands

**snmp-server host** *host-addr* *community-string*

**no snmp-server host** [*host-addr*]

Syntax	<b>snmp-server</b>	Configure SNMP server
Description	<b>host</b>	SNMP host setting
	<i>host-addr</i>	SNMP host address
	<i>community-string</i>	SNMP Community string
Defaults	N/A	
Permission	Admin group	
Usage Guidelines	N/A	
Examples	<pre>NPort S9650I-16-2HV(config)# snmp-server host 192.168.127.254 moxacli NPort S9650I-16-2HV(config)# no snmp-server host</pre>	

## 2.2.17 snmp-server trap-mode

To enable all Simple Network Management Protocol (SNMP) notifications (traps or informs) available on your system, use the **snmp-server trap-mode** global configuration command. To disable all available SNMP notifications, use the **no** form of this command

### Commands

**snmp-server trap-mode trap**

**snmp-server trap-mode inform** [*retry times* *timeout seconds*]

**no snmp-server trap-mode**

Syntax	<b>snmp-server</b>	Configure SNMP server
Description	<b>trap-mode</b>	SNMP Trap/Inform mode setting
	<b>trap</b>	SNMP Trap
	<b>inform</b>	SNMP Inform
	<b>retry</b>	Inform retries times
	<i>times</i>	1 to 99
	<b>timeout</b>	Timeout timer
	<i>seconds</i>	1 to 300 seconds
Defaults	The default mode is "trap"	
Permission	Admin group	
Usage Guidelines	N/A	
Examples	<pre>NPort S9650I-16-2HV(config)# snmp-server trap-mode trap NPort S9650I-16-2HV(config)# snmp-server trap-mode inform retry 3 timeout 10</pre>	

## 2.2.18 interface

Use the **interface** privileged command on the device server to select an interface to configure.

### Commands

**interface mgmt**

**interface trunk** *trunk\_id\_range*

**interface ethernet** *mod\_port*

**interface serial** *ser\_id*

**interface serial protocol { modbus | dnp3 }**

Syntax	<b>interface</b>	Select an interface to configure
Description	<b>mgmt</b>	Configure management VLAN
	<b>trunk</b>	Configure trunk interface
	<i>trunk_id_range</i>	Trunk ID (or list)
	<b>ethernet</b>	IEEE 802.3/IEEE 802.3z
	<i>mod_port</i>	Port ID or list. Ex. 1/1,2,3,2/1-3,5,...
	<b>serial</b>	Serial port interface
	<i>ser_id</i>	Serial port index (1 to n)
	<b>protocol</b>	Configure serial interface protocols
	<b>modbus</b>	Configure Modbus protocol settings
	<b>dnp3</b>	Configure DNP3 protocol settings
Defaults	N/A	
Permission	Admin group	
Usage Guidelines	N/A	
Examples	<pre>NPort S9650I-16-2HV(config)# interface serial 1 NPort S9650I-16-2HV(config-serif) #  NPort S9650I-16-2HV(config)# interface ethernet 1/1 NPort S9650I-16-2HV(config-if) #  NPort S9650I-16-2HV(config)# interface mgmt NPort S9650I-16-2HV(config-vlan) #</pre>	

## 2.2.19 clock set

Use the **clock set** global configuration command on the device server to set the current device server time.

### Commands

**clock set** *hh:mm:ss month day year*

Syntax	<b>clock</b>	Configure time-of-day clock
Description	<b>set</b>	Adjust the clock
	<i>hh:mm:ss</i>	hh:mm:ss
	<i>month</i>	1 to 12
	<i>day</i>	1 to 31
	<i>year</i>	2000 to 2037
Defaults	N/A	
Permission	Admin group	
Usage Guidelines	N/A	
Examples	<pre>NPort S9650I-16-2HV(config)# clock set 11:11:11 1 1 2010</pre>	



## 2.2.20 clock timezone

Use the **clock timezone** global configuration command on the device server to set the current time zone.

### Commands

**clock timezone** *gmt* *offset-hour* *offset\_minutes*

Syntax	<b>clock</b>	Configure time-of-day clock
Description	<b>timezone</b>	Time zone hour shifting
	<b>gmt</b>	Greenwich Mean Time
	<i>offset-hour</i>	-12 to 12
	<i>Half an hour</i>	Only type 30
Defaults	N/A	
Permission	Admin group	
Usage	N/A	
Guidelines		
Examples	NPort S9650I-16-2HV(config)# clock timezone gmt 5 30	

## 2.2.21 clock summer-time

Use the **clock summer-time** global configuration command on the device server to enable the daylight saving time offset and set the apply duration. Use the **no** form of this command to disable it.

### Commands

**clock summer-time** *start-date* *month* *week* *day* *hour*

**clock summer-time** *end-date* *month* *week* *day* *hour*

**clock summer-time** *offset* *offset-hour*

Syntax	<b>clock</b>	Configure time-of-day clock
Description	<b>summer-time</b>	Configure Summer time parameter
	<b>start-date</b>	The date when summer time offset start
	<b>end-date</b>	The date when summer time offset end
	<i>month</i>	From 'Jan', 'January' or '1' to 'Dec', 'December', or '12'
	<i>week</i>	From '1st' or '1' to 'Last' or '6'
	<i>day</i>	From 'Sun', 'Sunday' or '1' to 'Sat', 'Saturday' or '7'
	<i>hour</i>	0 to 23
	<b>offset</b>	Summer time offset
	<i>offset-hour</i>	1 to 12
Defaults	N/A	
Permission	Admin group	
Usage	When configuring the summer time offset, the start-date and end-date must be configured correctly first.	
Guidelines		
Examples	NPort S9650I-16-2HV(config)# clock summer-time start-date Jan 1 Saturday 12 NPort S9650I-16-2HV(config)# clock summer-time end-date Feb 1 Sun 13	

## 2.2.22 ntp remote-server

Use the **ntp remote-server** global configuration command on the device server to configure the remote NTP server. Use the **no** form of this command to return to the default.

### Commands

**ntp remote-server** server-addr-1 [server-addr-2]

**no ntp remote-server**

Syntax	<b>ntp</b>	Configure Network Time Protocol
Description	<b>remote-server</b>	Configure NTP server for time query
	server-addr-1	IP address or DNS name
	server-addr-2	IP address or DNS name
Defaults	The default configuration contains one time server "time.nist.gov"	
Permission	Admin group	
Usage Guidelines	N/A	
Examples	NPort S9650I-16-2HV(config)# ntp remote-server 192.168.127.1 time.stdtime.gov.tw	

## 2.2.23 ntp refresh-time

Use the **ntp refresh-time** global configuration command on the device server to configure the interval of each NTP query. Use the **no** form of this command to return to the default.

### Commands

**ntp refresh-time** seconds

**no ntp refresh-time**

Syntax	<b>ntp</b>	Configure Network Time Protocol
Description	<b>refresh-time</b>	Configure NTP query intervals
	seconds	1-9999 seconds
Defaults	Default query interval is 600 sec	
Permission	Admin group	
Usage Guidelines	N/A	
Examples	NPort S9650I-16-2HV(config)# ntp refresh-time 600	

## 2.2.24 ntp server

Use the **ntp server** global configuration command on the device server to enable the device server as an NTP server. Use the **no** form of this command to return to disable it.

### Commands

**ntp server**

**no ntp server**

Syntax	<b>ntp</b>	Configure Network Time Protocol
Description	<b>server</b>	Enable NTP server
Defaults	Default is disabled	
Permission	Admin group	
Usage Guidelines	N/A	
Examples	NPort S9650I-16-2HV(config)# ntp server	

## 2.2.25 irig-b

Use the **irig-b** privileged command on the device server to configure the global irig-b settings and serial interface irig-b settings.

### Commands

**irig-b output { off|pwm|pps }**

Syntax	<b>irig-b</b>	Configure irig-b for system irig-b output.
Description	<b>off</b>	Set the irig-b to off.
	<b>pwm</b>	Set the irig-b to pwm.
	<b>pps</b>	Set the irig-b to pps.
Defaults	The default is off	
Permission	Admin group	
Usage Guidelines	N/A	
Examples	<pre>NPort S9650I-16-2HV(config)# irig-b pwm  NPort S9650I-16-2HV(config)# interface serial 1 NPort S9650I-16-2HV(config-serif)# irig-b pps</pre>	

## 2.2.26 time-source

Use the **time-source** privileged command on the device server to configure time source.

### Commands

**time-source { local|ntp|irig-b|ptp }**

Syntax	<b>time-source</b>	Configure the time source of the device server.
Description	<b>local</b>	Time source from local.
	<b>ntp</b>	Time source from ntp.
	<b>irig-b</b>	Time source from irig-b.
	<b>ptp</b>	Time source from ptp.
Defaults	The default is local	
Permission	Admin group	
Usage Guidelines	N/A	
Examples	<pre>NPort S9650I-16-2HV(config)# time-source ntp</pre>	

## 2.2.27 logging

Use the **logging** global configuration command on the device server to configure the remote SYSLOG server. Use the **no** form of this command to remove the server.

### Commands

**logging ip-address**

**no logging ip-address**

Syntax	<b>logging</b>	Syslog server setting
Description	ip-address	IP or DNS name w/wo. port, Ex:1.2.3.4 or 1.2.3.4:5678
Defaults	N/A	
Permission	Admin group	
Usage Guidelines	N/A	
Examples	<pre>NPort S9650I-16-2HV(config)# logging 192.168.1.1</pre>	

## 2.2.28 line-swap-fast-recover

Use the **line-swap-fast-recovery** global configuration command on the device server to enable the fast recovery feature of the MAC address table when line swapping. Use the **no** form of this command to disable it.

### Commands

**line-swap-fast-recovery**

**no line-swap-fast-recovery**

Syntax	<b>line-swap-fast-recovery</b>	Enable Line Swap Fast Recovery feature
Description		
Defaults	This feature is enabled by default.	
Permission	Admin group	
Usage	N/A	
Guidelines		
Examples	NPort S9650I-16-2HV(config)# line-swap-fast-recovery	

## 2.2.29 ip auto-logout

Use **ip auto-logout** global configuration commands on the device server to configure the auto-logout for the consoles with specified minutes.

### Commands

**ip auto-logout** *minutes*

Syntax	<b>ip</b>	Global IP configuration subcommands
Description	<b>auto-logout</b>	Auto-logout timer
	<i>minutes</i>	1 to 1440 minutes
Defaults	Auto-logout is 5 minutes by default.	
Permission	Admin group	
Usage	N/A	
Guidelines		
Examples	NPort S9650I-16-2HV(config)# ip auto-logout 120	

## 2.2.30 ip http-server

Use **ip http-server** global configuration commands on the device server to enable HTTP/HTTPS service. Use the **no** form of this command to disable HTTP/HTTPS service.

### Commands

**ip http-server**

**ip http-server secure**

**no ip http-server**

**no ip http-server secure**

Syntax	<b>ip</b>	Global IP configuration subcommands
Description	<b>http-server</b>	Enable
	<b>secure</b>	Enable HTTP/HTTPS web service
Defaults	HTTP/HTTPS service is enabled.	
Permission	Admin group	
Usage	N/A	
Guidelines		
Examples	NPort S9650I-16-2HV(config)# ip http-server NPort S9650I-16-2HV(config)# ip http-server secure NPort S9650I-16-2HV(config)# no ip http-server	

## 2.2.31 ip http-server login-message

Use **ip http-server login-message** global configuration commands on the device server to configure the login message. Use the **no** form of this command to return to the default.

### Commands

**ip http-server login-message** *login\_string*

**no ip http-server login-message**

Syntax Description	<b>ip</b>	Global IP configuration subcommands
	<b>http-server</b>	http-server
	<b>login-message</b>	Configure HTTP/HTTPS login message
	<i>login_string</i>	Login message
Defaults	Login-message is "You are accessing a specific industrial automation control system.\r\nThe system usage is monitored, recorded, and subject to audit." by default.	
Permission	Admin group	
Usage Guidelines	N/A	
Examples	NPort S9650I-16-2HV(config)# ip http-server login-message Welcome NPort S9650I-16-2HV(config)# no ip http-server login-message	

## 2.2.32 ip http-server login-failure-message

Use **ip http-server login-failure-message** global configuration commands on the device server to configure the login fail message. Use the **no** form of this command to return to the default.

### Commands

**ip http-server login-failure-message** *login\_fail\_string*

**no ip http-server login-failure-message**

Syntax Description	<b>ip</b>	Global IP configuration subcommands
	<b>http-server</b>	http-server
	<b>login-failure-message</b>	Configure HTTP/HTTPS login fail message
	<i>login_fail_string</i>	Login message
Defaults	Login-failure-message is "The account or password you entered is incorrect.\r\n(Your account will be temporarily locked if excessive tried.)" by default.	
Permission	Admin group	
Usage Guidelines	N/A	
Examples	NPort S9650I-16-2HV(config)# ip http-server login-failure-message Login fail! NPort S9650I-16-2HV(config)# no ip http-server login-failure-message	

## 2.2.33 ip telnet

Use **ip telnet** global configuration commands on the device server to enable telnet service. Use the **no** form of this command to disable telnet service.

### Commands

**ip telnet**

**no ip telnet**

Syntax	<b>ip</b>	Global IP configuration subcommands
Description	<b>telnet</b>	telnet service
Defaults	Telnet service is enable.	
Permission	Admin group	
Usage Guidelines	N/A	
Examples	NPort S9650I-16-2HV(config)# ip telnet NPort S9650I-16-2HV(config)# no ip telnet	

## 2.2.34 ip ssh

Use **ip ssh** global configuration commands on the device server to enable ssh service. Use the **no** form of this command to disable ssh service.

### Commands

**ip ssh**

**no ip ssh**

Syntax	<b>ip</b>	Global IP configuration subcommands
Description	<b>ssh</b>	ssh service
Defaults	SSH service is enable.	
Permission	Admin group	
Usage Guidelines	N/A	
Examples	NPort S9650I-16-2HV(config)# ip ssh NPort S9650I-16-2HV(config)# no ip ssh	

## 2.2.35 ip snmp-agent

Use **ip snmp-agent** global configuration commands on the device server to enable snmp agent. Use the **no** form of this command to disable snmp agent.

### Commands

**ip snmp-agent**

**no ip snmp-agent**

Syntax	<b>ip</b>	Global IP configuration subcommands
Description	<b>snmp-agent</b>	SNMP agent
Defaults	SNMP agent is enable.	
Permission	Admin group	
Usage Guidelines	N/A	
Examples	NPort S9650I-16-2HV(config)# ip snmp-agent NPort S9650I-16-2HV(config)# no ip snmp-agent	

## 2.2.36 ip moxa-service

Use **ip moxa-service** global configuration commands on the device server to enable moxa-service. Use the **no** form of this command to disable moxa-service.

### Commands

**ip moxa-service**

**no ip moxa-service**

Syntax	<b>ip</b>	Global IP configuration subcommands
Description	<b>moxa-service</b>	Enable Moxa service
Defaults	Moxa service enable.	
Permission	Admin group	
Usage Guidelines	N/A	
Examples	<pre>NPort S9650I-16-2HV(config)# ip moxa-service NPort S9650I-16-2HV(config)# no ip moxa-service</pre>	

## 2.2.37 ip mms-service

Use **ip mms-service** global configuration commands on the device server to enable mms-service. Use the **no** form of this command to disable mms-service.

### Commands

**ip mms-service**

**no ip mms-service**

Syntax	<b>ip</b>	Global IP configuration subcommands
Description	<b>mms-service</b>	Enable MMS service
Defaults	MMS enable.	
Permission	Admin group	
Usage Guidelines	N/A	
Examples	<pre>NPort S9650I-16-2HV(config)# ip mms-service NPort S9650I-16-2HV(config)# no ip mms-service</pre>	

## 2.2.38 ip igmp-snooping

Use the **ip igmp-snooping** global configuration command on the device server to globally enable Internet Group Management Protocol (IGMP) snooping on the device server. Use the command with keywords to enable IGMP snooping. Use the **no** form of this command to disable IGMP snooping.

### Commands

**ip igmp-snooping**

**no ip igmp-snooping**

Syntax	<b>ip</b>	Global IP configuration subcommands
Description	<b>igmp-snooping</b>	IGMP snooping
Defaults	IGMP snooping is globally disable.	
Permission	Admin group	
Usage Guidelines	N/A	
Examples	<pre>NPort S9650I-16-2HV(config)# ip igmp-snooping NPort S9650I-16-2HV(config)# no ip igmp-snooping</pre>	

## 2.2.39 ip igmp-snooping vlan

Use the **ip igmp-snooping vlan** global configuration command on the device server to globally enable Internet Group Management Protocol (IGMP) snooping on a VLAN. Use the **no** form of this command to disable IGMP snooping on a vlan.

### Commands

**ip igmp-snooping vlan** *vlan-id* [**mrouter** *module/port*]

**no ip igmp-snooping vlan** *vlan-id* [**mrouter** *module/port*]

Syntax	<b>ip</b>	Global IP configuration subcommands
Description	<b>igmp-snooping</b>	IGMP snooping
	<b>vlan</b>	VLAN parameters
	<i>vlan-id</i>	1 to 4094
	<b>mrouter</b>	IGMP snooping query port enable
	<i>module/port</i>	Port(Trunk) ID or list. E.g., 1/1,2,4-5,2/1,Trk1,Trk2-Trk4
Defaults	N/A	
Permission	Admin group	
Usage Guidelines	N/A	
Examples	<pre>NPort S9650I-16-2HV(config)# ip igmp-snooping vlan 1 mrouter 1/1 NPort S9650I-16-2HV(config)# no ip igmp-snooping vlan 1 mrouter 1/1</pre>	

## 2.2.40 ip igmp-snooping querier vlan

Use the **ip igmp-snooping querier** global configuration command to enable and configure the IGMP querier feature on a VLAN interface. Use the **no** form of this command to disable the IGMP querier feature.

### Commands

**ip igmp-snooping querier vlan** *vlan-id*

**no ip igmp-snooping querier vlan** *vlan-id*

Syntax	<b>ip</b>	Global IP configuration subcommands
Description	<b>igmp-snooping</b>	IGMP snooping
	<b>querier</b>	IGMP snooping query enable
	<b>vlan</b>	VLAN parameters
	<i>vlan-id</i>	1 to 4094
Defaults	The IGMP snooping querier feature is globally disabled	
Permission	Admin group	
Usage Guidelines	The IGMP snooping function must be enabled first	
Examples	<pre>NPort S9650I-16-2HV(config)# ip igmp-snooping querier vlan 1 NPort S9650I-16-2HV(config)# no ip igmp-snooping querier vlan 1</pre>	



## 2.2.41 ip igmp-snooping query-interval

Use the **ip igmp-snooping query-interval** global configuration command on the device server to configure the interval between IGMP queries. Use the **no** form of this command to return to the default.

### Commands

**ip igmp-snooping query-interval** interval

Syntax	<b>ip</b>	Global IP configuration subcommands
Description	<b>igmp-snooping</b>	IGMP snooping
	<b>query-interval</b>	IGMP snooping query interval
	<i>interval</i>	20 to 600 seconds
Defaults	Query interval default value is 125 seconds	
Permission	Admin group	
Usage	The IGMP snooping function must be enabled first	
Guidelines		
Examples	NPort S9650I-16-2HV(config)# ip igmp-snooping query-interval 100	

## 2.2.42 ip igmp-snooping enhanced

Use the **ip igmp-snooping enhanced** global configuration command on the device server to enable the enhanced mode. Use the **no** form of this command to disable the enhanced mode.

### Commands

**ip igmp-snooping enhanced**

**no ip igmp-snooping enhanced**

Syntax	<b>ip</b>	Global IP configuration subcommands
Description	<b>igmp-snooping</b>	IGMP snooping
	<b>enhanced</b>	IGMP snooping enhanced mode
Defaults	Enhanced mode is globally disabled.	
Permission	Admin group	
Usage	The IGMP snooping function must be enabled first	
Guidelines		
Examples	NPort S9650I-16-2HV(config)# ip igmp-snooping enhanced NPort S9650I-16-2HV(config)# no ip igmp-snooping enhanced	

## 2.2.43 ip igmp static-group

Use the **ip igmp static-group** global configuration command on the device server to add a static multicast MAC address and its member ports. Use the **no** form of this command to remove the static multicast group or just its member ports.

### Commands

**ip igmp static-group** *MAC-address* **interface** *module/port*

**no ip igmp static-group** [*MAC-address*] [ **interface** *module/port*]

Syntax	<b>ip</b>	Global IP configuration subcommands
Description	<b>igmp</b>	IGMP
	<b>static-group</b>	Add New Static Multicast MAC Address
	<i>MAC-address</i>	MAC address XX:XX:XX:XX:XX:XX
	<b>interface</b>	Binding ports
	<i>module/port</i>	Port(Trunk) ID or list. E.g., 1/1,2,4-5,2/1,Trk1,Trk2-Trk
Defaults	N/A	
Permission	Admin group	
Usage	N/A	
Guidelines		
Examples	<pre>NPort S9650I-16-2HV(config)# ip igmp static-group 01:00:00:00:00:01 interface 1/2-3 NPort S9650I-16-2HV(config)# no ip igmp static-group</pre>	

## 2.2.44 ip dhcp-relay server

Use **ip dhcp-relay server** to configure the DHCP server address that the device server will forward DHCP messages to. To remove the DHCP server address, use the **no** form of this command.

### Commands

**ip dhcp-relay server** *serverIndex* *serverAddr*

**no ip dhcp-relay server** *serverIndex*

Syntax	<b>ip</b>	Global IP configuration subcommands
Description	<b>dhcp-relay</b>	Configure DHCP relay agent parameter
	<b>server</b>	DHCP server IP address
	<i>serverIndex</i>	DHCP server address index, 1 to 4
	<i>serverAddr</i>	DHCP server IP address
Defaults	N/A	
Permission	Admin group	
Usage	N/A	
Guidelines		
Examples	<pre>NPort S9650I-16-2HV(config)# ip dhcp-relay server 1 192.168.127.100 NPort S9650I-16-2HV(config)# no ip dhcp-relay server 3</pre>	

## 2.2.45 ip dhcp-relay option82

Use the **ip dhcp-relay option82** global and interface configuration command to enable DHCP Relay with Option 82 messages. To disable it, use the **no** form of this command.

### Commands

**ip dhcp-relay option82**

**no ip dhcp-relay option82**

Syntax	<b>ip</b>	Configure IP parameters
Description	<b>dhcp-relay</b>	Configure DHCP relay agent parameter
	<b>option82</b>	Option 82
Defaults	Default is disabled.	
Permission	Admin group	
Usage	N/A	
Guidelines		
Examples	<pre>NPort S9650I-16-2HV(config)# ip dhcp-relay option82  NPort S9650I-16-2HV(config)# interface ethernet 1 NPort S9650I-16-2HV(config-if)# ip dhcp-relay option82</pre>	

## 2.2.46 ip dhcp-relay option82 remote-id-type

Use the **ip dhcp-relay option82 remote-id-type** global configuration command to select the remote ID information of DHCP option82 messages. Use **ip dhcp-relay option82 man-id** to manually set the remote id instead of the predefined ones.

### Commands

**ip dhcp-relay option82 remote-id-type** *remoteIdType*

**ip dhcp-relay option82 man-id** *manualId*

Syntax	<b>ip</b>	Global IP configuration subcommands
Description	<b>dhcp-relay</b>	Configure DHCP relay agent parameter
	<b>option82</b>	Option 82
	<b>remote-id-type</b>	Remote Id type
	<i>remoteIdType</i>	ip   mac   client-id   other
	<b>man-id</b>	Manual remote ID
	<i>manualId</i>	Manual remote ID, maximum 15 characters
Defaults	DHCP-relay option82 is disable in factory default. Default remote-id-type is IP.	
Permission	Admin group	
Usage	N/A	
Guidelines		
Examples	<pre>NPort S9650I-16-2HV(config)# ip dhcp-relay option82 remote-id-type mac</pre>	

## 2.2.47 serial

Use the **serial** global command to enable serial console. To disable it, use the **no** form of this command.

### Commands

**serial**

**no serial**

Syntax	<b>serial</b>	Enable serial console
Description		
Defaults	Default is enabled.	
Permission	Admin group	
Usage	N/A	
Guidelines		
Examples	NPort S9650I-16-2HV(config)# serial NPort S9650I-16-2HV(config)# no serial	

## 2.2.48 vlan create

Use the **vlan create** global configuration command on the device server to create a VLAN in the VLAN database. Use the **no** form of this command to delete a VLAN.

### Commands

**vlan create** *vlan-id-list*

**no vlan create** *vlan-id-list*

Syntax	<b>vlan</b>	Configure VLAN parameters
Description	<b>create</b>	Configure VLAN parameters
	<i>vlan-id-list</i>	VLAN IDs of the VLANs
Defaults	N/A.	
Permission	Admin group	
Usage	You can only use this command mode for configuring normal-range VLANs, that is, VLAN IDs 1 to 4094.	
Guidelines		
Examples	NPort S9650I-16-2HV(config)# vlan create 1,3-5,7	

## 2.2.49 vlan mode

Use the **vlan mode** configuration command on the device server to change current VLAN mode operated on the device server. Use the **no** form of this command to return to the default.

### Commands

**vlan mode** { **1qvlan** | **pvlan** | **unaware** }

**no vlan mode**

Syntax	<b>vlan</b>	Configure VLAN parameters
Description	<b>mode</b>	Set (default) vlan mode
	<b>1qvlan</b>	IEEE 802.1Q
	<b>pvlan</b>	Port-based vlan
	<b>unaware</b>	Unaware vlan
Defaults	The default mode is 802.1Q mode in the product with 802.1Q supported; otherwise is port-based VLAN mode.	
Permission	Admin group	
Usage	N/A	
Guidelines		
Examples	NPort S9650I-16-2HV(config)# vlan mode 1qvlan	

## 2.2.50 gvrp

Use the **gvrp** global configuration command on the device server to enable GVRP. Use the **no** form of this command to disable it.

### Commands

**gvrp**

**no gvrp**

Syntax Description	<b>gvrp</b>	Enable/Disable GVRP
Defaults	The feature is enabled by default.	
Permission	Admin group	
Usage Guidelines	N/A	
Examples	NPort S9650I-16-2HV(config)# gvrp	

## 2.2.51 redundancy

Use the **redundancy** global configuration command on the device server to enter the redundancy configuration mode.

### Commands

**redundancy**

Syntax Description	<b>redundancy</b>	Enter redundancy configuration mode
Defaults	The feature is enabled by default.	
Permission	Admin group	
Usage Guidelines	N/A	
Examples	NPort S9650I-16-2HV(config)# redundancy	

## 2.2.52 redundancy mode

Use the **redundancy mode** global configuration command on the device server to change the redundancy protocol mode.

### Commands

**redundancy mode { mst | rstp | turbo-ring-v1 | turbo-ring-v2 | turbo-chain }**

Syntax Description	<b>redundancy</b>	Enter redundancy configuration mode
	<b>mode</b>	Specify the redundancy protocol
	<b>mst</b>	MSTP
	<b>rstp</b>	Rapid Spanning Tree
	<b>turbo-ring-v1</b>	Turbo ring version 1
	<b>turbo-ring-v2</b>	Turbo ring version 2
	<b>turbo-chain</b>	Turbo chain
Defaults	The default redundancy protocol mode is RSTP.	
Permission	Admin group	
Usage Guidelines	N/A	
Examples	NPort S9650I-16-2HV(config)# redundancy mode turbo-ring-v2	

## 2.2.53 auth mode

Use the **auth mode** global configuration command on the device server to change the authentication login option.

### Commands

**auth mode { tacacs+ | radius }**  
**no auth mode**

Syntax	<b>auth</b>	Configure authentication mechanism
Description	<b>mode</b>	Authentication login option
	<b>tacacs+</b>	TACACS+ authentication
	<b>radius</b>	RADIUS authentication
Defaults	N/A.	
Permission	Admin group	
Usage Guidelines	N/A	
Examples	NPort S9650I-16-2HV(config)# auth mode radius	

## 2.2.54 auth tacacs+

Use the **auth tacacs+** global configuration command on the device server to enable TACACS+ authentication. Use the **no** form of this command to return to the default setting.

### Commands

**auth tacacs+**  
**no auth tacacs+**

Syntax	<b>auth</b>	Configure authentication mechanism
Description	<b>tacacs+</b>	TACACS+ authentication
Defaults	The default setting is disabled.	
Permission	Admin group	
Usage Guidelines	N/A	
Examples	NPort S9650I-16-2HV(config)# auth tacacs+	

## 2.2.55 auth tacacs+ server-ip

Use the **auth tacacs+ server-ip** global configuration command on the device server to set the TACACS+ authentication server address. Use the **no** form of this command to set to default.

### Commands

**auth tacacs+ server-ip server-address**  
**no auth tacacs+ server-ip**

Syntax	<b>auth</b>	Configure authentication mechanism
Description	<b>tacacs+</b>	TACACS+ authentication
	<b>server-ip</b>	TACACS+ authentication server
	<i>server-address</i>	IP or DNS name, Ex:1.2.3.4
Defaults	N/A	
Permission	Admin group	
Usage Guidelines	N/A	
Examples	NPort S9650I-16-2HV(config)# auth tacacs+ server-ip 192.168.1.1	

## 2.2.56 auth tacacs+ server-port

Use the **auth tacacs+ server-port** global configuration command on the device server to set the TACACS+ authentication server port. Use the **no** form of this command to set to default.

### Commands

**auth tacacs+ server-port** *server-port*

**no auth tacacs+ server-port**

Syntax Description	<b>auth</b>	Configure authentication mechanism
	<b>tacacs+</b>	TACACS+ authentication
	<b>server-port</b>	TACACS+ authentication server
	<i>server-port</i>	1 - 65535
Defaults	N/A	
Permission	Admin group	
Usage Guidelines	N/A	
Examples	NPort S9650I-16-2HV(config)# auth tacacs+ server-port 1234	

## 2.2.57 auth tacacs+ shared-key

Use the **auth tacacs+ shared-key** global configuration command on the device server to set the TACACS+ authentication server shared key information. Use the **no** form of this command to remove the settings.

### Commands

**auth tacacs+ shared-key** **key**

**no auth tacacs+ shared-key**

Syntax Description	<b>auth</b>	Configure authentication mechanism
	<b>tacacs+</b>	TACACS+ authentication
	<b>shared-key</b>	Configure the shared key
	<i>key</i>	Key string, max 15 characters
Defaults	N/A	
Permission	Admin group	
Usage Guidelines	N/A	
Examples	NPort S9650I-16-2HV(config)# auth tacacs+ shared-key 1234	

## 2.2.58 auth tacacs+ auth-type

Use the **auth tacacs+ auth-type** global configuration command on the device server to specify the type of TACACS+ authentication. Use the **no** form of this command to return to the default setting.

### Commands

**auth tacacs+ auth-type { ascii | pap | chap | arap | mschap }**  
**no auth tacacs+ auth-type**

Syntax Description	<b>auth</b>	Configure authentication mechanism
	<b>tacacs+</b>	TACACS+ authentication
	<b>auth-type</b>	Specify the authentication type
	<b>ascii</b>	Normal ASCII code authentication
	<b>pap</b>	Password Authentication Protocol
	<b>chap</b>	Challenge-handshake authentication protocol
	<b>arap</b>	AppleTalk Remote Access Protocol
	<b>mschap</b>	Microsoft Challenge-handshake authentication protocol
Defaults	Default type is ASCII code authentication.	
Permission	Admin group	
Usage Guidelines	To enable the TACACS+ authentication, the command "auth tacacs+" must be executed first.	
Examples	NPort S9650I-16-2HV(config)# auth tacacs+ auth-type pap	

## 2.2.59 auth tacacs+ timeout

Use the **auth tacacs+ timeout** global configuration command on the device server to set the TACACS+ authentication server timeout. Use the **no** form of this command to set the setting back to default value.

### Commands

**auth tacacs+ timeout seconds**  
**no auth tacacs+ timeout**

Syntax Description	<b>auth</b>	Configure authentication mechanism
	<b>timeout</b>	Configure server timeout
	<i>seconds</i>	1 to 255 sec.
Defaults	N/A	
Permission	Admin group	
Usage Guidelines	N/A	
Examples	NPort S9650I-16-2HV(config)# auth tacacs+ timeout 30	



## 2.2.60 lldp enable

Use the **lldp enable** global configuration command to enable LLDP. To stop LLDP, use the **no** form of this command.

### Commands

**lldp enable**

**no lldp enable**

Syntax	<b>lldp</b>	Configure LLDP parameters
Description	<b>enable</b>	Start up
Defaults	LLDP is enable in factory default	
Permission	Admin group	
Usage	N/A	
Guidelines		
Examples	NPort S9650I-16-2HV(config)# lldp enable	

## 2.2.61 lldp timer

Use the **lldp timer** global configuration command to configure the transmission frequency of LLDP messages. To reset the timer to default, use the **no** form of this command.

### Commands

**lldp timer transFreq**

**no lldp timer**

Syntax	<b>lldp</b>	Configure LLDP parameters
Description	<b>timer</b>	Transmission frequency of LLDP updates
	<i>transFreq</i>	5 to 32768 seconds
Defaults	Transmission frequency of LLDP updates is 30 seconds	
Permission	Admin group	
Usage	N/A	
Guidelines		
Examples	NPort S9650I-16-2HV(config)# lldp timer 50	

## 2.2.62 dot1x auth

Use the **dot1x auth** global configuration command to set dot1x authentication type.

### Commands

**dot1x auth { local | radius | radius-local }**

Syntax	<b>dot1x</b>	802.1x setting
Description	<b>auth</b>	802.1x auth type
	<b>local</b>	802.1x authentication uses local database
	<b>radius</b>	802.1x authentication uses radius server
	<b>radius-local</b>	802.1x authentication uses both local and radius server
Defaults	802.1x local authentication	
Permission	Admin group	
Usage	N/A	
Guidelines		
Examples	NPort S9650I-16-2HV(config)# dot1x auth local	

## 2.2.63 dot1x reauth

Use the **dot1x reauth** global configuration command on the device server to globally enable periodic re-authentication of the client. Use the **no** form of this command to return to the default setting.

### Commands

**dot1x reauth** [period *period*]

**no dot1x reauth** [period *period*]

Syntax	<b>dot1x</b>	802.1x setting
Description	<b>reauth</b>	802.1x reauth enable
	<b>period</b>	802.1x reauth period
	<i>period</i>	60 to 65535 seconds
Defaults	802.1x reauth default enable and period 3600 seconds	
Permission	Admin group	
Usage	N/A	
Guidelines		
Examples	NPort S9650I-16-2HV(config)# dot1x reauth period 3600	

## 2.2.64 dot1x radius

Use the **dot1x radius** global configuration command on the device server to globally configure 802.1x radius setting. Use the **no** form of this command to return to the default setting.

### Commands

**dot1x radius server** [same]

**dot1x radius 1stServer server-ip** *server\_ip*

**dot1x radius 1stServer server-port** *server\_port*

**dot1x radius 1stServer shared-key** *server\_key*

**dot1x radius 2ndServer server-ip** *server\_ip*

**dot1x radius 2ndServer server-port** *server\_port*

**dot1x radius 2ndServer shared-key** *server\_key*

**no dot1x radius** {1stServer | 2ndServer | both}

Syntax	<b>dot1x</b>	802.1x setting
Description	<b>radius</b>	802.1x radius setting
	<b>server</b>	802.1x radius setting
	<b>same</b>	The same configuration as radius auth server setting
	<b>1stServer</b>	802.1x 1st radius setting
	<b>2ndServer</b>	802.1x 2nd radius setting
	<b>server-ip</b>	Configure server IP or DNS name
	<i>server_ip</i>	IP or DNS name, Ex:1.2.3.4
	<b>server-port</b>	Configure the server port
	<i>server_port</i>	1 ~ 65535
	<b>shared-key</b>	Configure the shared key
	<i>server_key</i>	Key string, max 15 characters
	<b>both</b>	Set default radius setting
Defaults	802.1x reauth default enable and period 3600 seconds	
Permission	Admin group	
Usage	N/A	
Guidelines		
Examples	NPort S9650I-16-2HV(config)# dot1x reauth period 3600 NPort S9650I-16-2HV(config)# no dot1x radius both	

## 2.2.65 monitor

Use **monitor** global configuration commands to enable the monitoring of data transmitted/received by a specific port. Use the **no** form of this command to disable the monitoring.

### Commands

**monitor source interface** *mod\_port* [**direction**]

**no monitor source interface**

**monitor destination interface** *mod\_port*

**no monitor destination interface**

Syntax	<b>monitor</b>	Configure Port mirror
Description	<b>source</b>	Monitored port
	<b>interface</b>	Port
	<b>destination</b>	Mirror port
	<i>modPort</i>	Port ID. E.g., 1/3, Trk2,...
	<b>direction</b>	both   tx   rx
Defaults	N/A	
Permission	Admin group	
Usage Guidelines	Traffic send/receive by a source port (Monitored port) will be mirrored to the destination port(Mirror port)	
Examples	<pre>NPort S9650I-16-2HV(config)# monitor source interface 3/1 both NPort S9650I-16-2HV(config)# no dot1x radius both</pre>	

## 2.2.66 email-warning server

Use **email-warning server** to configure Mail Server IP/Name (IP address or name) for the device server. To clear the setting, use the **no** form of this command.

### Commands

**email-warning server** *smtpServerIp* [*smtpPort*]

**no email-warning server**

Syntax	<b>email-warning</b>	Email warning setting
Description	<b>server</b>	Email Server
	<i>smtpServerIp</i>	Email Server name/address
	<i>smtpPort</i>	SMTP Port, 1 to 65535
Defaults	N/A	
Permission	Admin group	
Usage Guidelines	N/A	
Examples	<pre>NPort S9650I-16-2HV(config)# email-warning server mail.hinet.net 25 NPort S9650I-16-2HV(config)# email-warning server ms1.hinet.net</pre>	

## 2.2.67 email-warning mail-address

Use **email-warning mail-address** to configure the email address(es) to which warning messages will be sent. To clear the setting, use **no** form of this command.

### Commands

**email-warning mail-address mailIndex mailAddress**

**no email-warning mail-address mailIndex**

Syntax	<b>email-warning</b>	Email warning setting
Description	<b>mail-address</b>	Target email address
	<i>mailIndex</i>	1 to 4
	<i>mailAddress</i>	Email address
Defaults	N/A	
Permission	Admin group	
Usage Guidelines	N/A	
Examples	NPort S9650I-16-2HV(config)# email-warning mail-address 1 test2@moxa.com	

## 2.2.68 email-warning account

Use **email-warning account** to configure the account and the password to log in to the remote Mail Server. To clear the setting, use the **no** form of this command.

### Commands

**email-warning account name password**

**no email-warning account**

Syntax	<b>email-warning</b>	Email warning setting
Description	<b>account</b>	Email account on server
	<i>name</i>	User name
	<i>password</i>	User password
Defaults	N/A	
Permission	Admin group	
Usage Guidelines	N/A	
Examples	NPort S9650I-16-2HV(config)# email-warning account test1 1234 NPort S9650I-16-2HV(config)# no email-warning account test1	

## 2.2.69 email-warning send test email

Use **email-warning send test email** to send a test email.

### Commands

#### email-warning send test email

Syntax	<b>email-warning</b>	Email warning setting
Description	<b>send</b>	Send test email
	<b>test</b>	Test email
	<b>email</b>	Test email address
Defaults	N/A	
Permission	Admin group	
Usage Guidelines	The test email will be sent to the mail address that "email-warning mail-address" command configured.	
Examples	<pre>NPort S9650I-16-2HV(config)# email-warning send test email Sending test email ... You may check if your dedicated email addresses have received this email!</pre>	

## 2.2.70 email-warning event

Use the **email-warning event** global configuration command to enable the system warning events to send through the email if the event occurs. Use the **no** form of this command to disable the specified warning event notifications.

### Commands

**email-warning event { all | cold-start | warm-start | power-trans-off | power-trans-on | config-change | auth-fail | topology-change }**

**no email-warning event { cold-start | warm-start | power-trans-off | power-trans-on | config-change | auth-fail | topology-change }**

Syntax	<b>email-warning</b>	Email warning setting
Description	<b>event</b>	System events
	<b>all</b>	Enable all events
	<b>cold-start</b>	Device server cold start
	<b>warn-start</b>	Device server warm start
	<b>power-trans-off</b>	Power transition (on->off)
	<b>power-trans-on</b>	Power transition (off->on)
	<b>config-change</b>	Configuration changed
	<b>auth-fail</b>	Authentication failed
	<b>topology-change</b>	Topology changed (from redundant protocols)
Defaults	All system events are disabled by default.	
Permission	Admin group	
Usage Guidelines	N/A	
Examples	<pre>NPort S9650I-16-2HV(config)# email-warning event cold-start NPort S9650I-16-2HV(config)# email-warning event topology-change NPort S9650I-16-2HV(config)# email-warning event auth-fail</pre>	

## 2.2.71 relay-warning override

Use **relay-warning override** *relay* to override the relay warning setting temporarily. Releasing the relay output will allow administrators to fix any problems with the warning condition. Use the **no** form of this command to disable the override.

### Commands

**relay-warning override relay** [ *relayId* ]

**no relay-warning override relay** [ *relayId* ]

Syntax	relay-warning	Configure relay warning
Description	override	Override the relay warning setting
	relay	Relay
	<b>relayId</b>	Relay's ID = 1 or 2
Defaults	N/A	
Permission	Admin group	
Usage Guidelines	relayId will only be used on the product that have multiple relays.	
Examples	NPort S9650I-16-2HV (config)# relay-warning override relay	

## 2.2.72 relay-warning config relay

Use **relay-warning config relay** to select relay to trigger when a warning event occurs.

### Commands

**relay-warning config relay** [ *relayId* ]

Syntax	<b>relay-warning</b>	Configure relay warning
Description	<b>config</b>	Choose which relay to configure
	<b>relay</b>	Relay
	<i>relayId</i>	Relay's ID = 1 or 2
Defaults	N/A	
Permission	Admin group	
Usage Guidelines	These commands only existed in device with multiple relays.	
Examples	NPort S9650I-16-2HV (config)# relay-warning config relay 1	

## 2.2.73 relay-warning event

Use **relay-warning event** global configuration commands to enable the warning events to trigger relay. Use the **no** form of this command to disable it.

### Commands

**relay-warning event { power-input1-fail | power-input2-fail | turbo-ring-break }**

**no relay-warning event { power-input1-fail | power-input2-fail | turbo-ring-break }**

Syntax	<b>relay-warning</b>	Configure relay warning
Description	<b>event</b>	System events
	<b>power-input1-fail</b>	Power input 1 failure (On->Off)
	<b>power-input2-fail</b>	Power input 2 failure (On->Off)
	<b>turbo-ring-break</b>	Turbo Ring break
Defaults	All system events are disabled by default.	
Permission	Admin group	
Usage	N/A	
Guidelines		
Examples	NPort S9650I-16-2HV(config)# relay-warning event turbo-ring-break	

## 2.2.74 garp

Use **garp** global configuration commands to configure GARP parameters.

### Commands

**garp join-time time**

**garp leave-time time**

**garp leaveall-time time**

Syntax	<b>garp</b>	Configure GARP parameters
Description	<b>join-time</b>	Configure GARP join timer parameters
	<b>leave-time</b>	Configure GARP leave timer parameters
	<b>leaveall-time</b>	Configure GARP leaveall timer parameters
	<i>time</i>	timer parameters
Defaults	N/A	
Permission	Admin Group	
Usage	N/A	
Guidelines		
Examples	NPort S9650I-16-2HV(config)# garp join-time 33	

## 2.2.75 ptp enable

Use the **ptp enable** command on the device server to enable the PTP operation. Use the **no** form of this command to disable the PTP operation on the device server.

### Commands

**ptp enable**

**no ptp**

Syntax	<b>ptp</b>	Configure PTP
Description	<b>enable</b>	Enable the ptp operation
Defaults	ptp is default disable	
Permission	Admin group	
Usage Guidelines	Ethernet port interface can only be set when system PTP configure is enabled.	
Examples	<pre>NPORT S9650I-16-2HV(config)# ptp enable NPORT S9650I-16-2HV(config)# no ptp NPORT S9650I-16-2HV(config-if)# ptp enable NPORT S9650I-16-2HV(config-if)# no ptp</pre>	

## 2.2.76 ptp mode

Use the **ptp mode** global configuration command on the device server to set the PTP operation mode.

### Commands

**ptp mode e2e-bc**

**ptp mode p2p-bc**

**ptp mode e2e-oc**

**ptp mode p2p-oc**

Syntax	<b>ptp</b>	Configure PTP
Description	<b>mode</b>	Set the ptp operation mode
	<b>e2e-bc</b>	ptp v2 end-to-end boundary clock mode, this mode can only be set when time source is set to PTP.
	<b>p2p-bc</b>	ptp v2 peer-to-peer boundary clock mode, this mode can only be set when Time source is PTP.
	<b>e2e-oc</b>	ptp v2 end-to-end ordinary clock mode, this mode can only be set when time source not PTP.
	<b>p2p-oc</b>	ptp v2 peer-to-peer ordinary clock mode, this mode can only be set when time source not PTP.
Defaults	Default setting of ptp is mode	
Permission	Admin group	
Usage Guidelines	N/A	
Examples	<pre>NPORT S9650I-16-2HV(config)# ptp mode v2-e2e-bc</pre>	



## 2.2.77 ptp log-sync-interval

Use the **ptp log-sync-interval** global configuration command on the device server to set the *log-sync-interval* parameter.

### Commands

**ptp log-sync-interval** *interval*

Syntax	<b>ptp</b>	Configure PTP
Description	<b>log-sync-interval</b>	Set the logarithm to the base 2 of the mean SyncInterval
	<i>interval</i>	-3 to 1
Defaults	default is 0	
Permission	Admin group	
Usage	N/A	
Guidelines		
Examples	NPORT S9650I-16-2HV(config)# ptp log-sync-interval	

## 2.2.78 ptp log-announce-interval

Use the **ptp log-announce-interval** global configuration command on the device server to set the *log-announce-interval* parameter.

### Commands

**ptp log-announce-interval** *interval*

Syntax	<b>ptp</b>	Configure PTP
Description	<b>log-announce-interval</b>	Set the logarithm to the base 2 of the mean AnnounceInterval
	<i>interval</i>	0 to 4
Defaults	default is 1	
Permission	Admin group	
Usage	N/A	
Guidelines		
Examples	NPORT S9650I-16-2HV(config)# ptp log-announce-interval	

## 2.2.79 ptp announce-receipt-timeout

Use the **ptp announce-receipt-timeout** configuration command on the device server to set the *announce-receipt-timeout* parameter.

### Commands

**ptp announce-receipt-timeout** *interval*

Syntax	<b>ptp</b>	Configure PTP
Description	<b>announce-receipt-timeout</b>	Set the integral multiple of announceInterval
	<i>interval</i>	2 to 10
Defaults	default is 3	
Permission	Admin group	
Usage	N/A	
Guidelines		
Examples	NPORT S9650I-16-2HV(config)# ptp announce-receipt-timeout	

## 2.2.80 ptp log-min-delay-req-interval

Use the **ptp log-min-delay-req-interval** global configuration command on the device server to set the *log-min-delay-req-interval* parameter.

### Commands

**ptp log-min-delay-req-interval** *interval*

Syntax	<b>ptp</b>	Configure PTP
Description	<b>log-min-delay-req-interval</b>	Set the logarithm to the base 2 of the mean minDelayReqInterval
	<i>interval</i>	0 to 5
Defaults	default is 0	
Permission	Admin group	
Usage	Only E2E mode can set this value.	
Guidelines		
Examples	NPORT S9650I-16-2HV(config)# ptp log-min-delay-req-interval	

## 2.2.81 ptp log-min-pdelay-req-interval

Use the **ptp log-min-pdelay-req-interval** global configuration command on the device server to set the *log-min-pdelay-req-interval* parameter.

### Commands

**ptp log-min-pdelay-req-interval** *interval*

Syntax	<b>ptp</b>	Configure PTP
Description	<b>log-min-pdelay-req-interval</b>	Set the logarithm to the base 2 of the mean minPDelayReqInterval
	<i>interval</i>	-1 to 5
Defaults	default is 0	
Permission	Admin group	
Usage	Only P2P mode can set this value.	
Guidelines		
Examples	NPORT S9650I-16-2HV(config)# ptp log-min-pdelay-req-interval 3	

## 2.2.82 ptp domain-number

Use the **ptp domain-number** configuration command on the device server to set the domain number of the local clock.

### Commands

**ptp domain-number** *interval*

Syntax	<b>ptp</b>	Configure PTP
Description	<b>domain-number</b>	Set the domain number of the local clock
	<i>interval</i>	0 to 3
Defaults	default is 0	
Permission	Admin group	
Usage	N/A	
Guidelines		
Examples	NPORT S9650I-16-2HV(config)# ptp domain-number	

## 2.2.83 ptp transport

Use the **ptp transport** configuration command on the device server to set the transport type of the ptp domain.

### Commands

**ptp transport [802\_3|ipv4]**

Syntax	<b>ptp</b>	Configure PTP
Description	<b>transport</b>	Set the transport type of the ptp domain
	<b>802_3</b>	Set the transport type of the PTP domain to 802.3/Ethernet
	<b>Ipv4</b>	Set the transport type of the PTP domain to IPv4
Defaults	default is ipv4	
Permission	Admin group	
Usage	N/A	
Guidelines		
Examples	NPORT S9650I-16-2HV(config)# ptp transport 802_3 NPORT S9650I-16-2HV(config)# ptp transport ipv4	

## 2.2.84 ptp priority1

Use the **ptp priority1** configuration command on the device server to set the priority1 parameter of the local clock.

### Commands

**ptp priority1** priority

Syntax	<b>ptp</b>	Configure PTP
Description	<b>priority1</b>	Set the priority1 parameter of the local clock
	priority	0 to 255
Defaults	default is 128	
Permission	Admin group	
Usage	N/A	
Guidelines		
Examples	NPORT S9650I-16-2HV(config)# ptp priority1 128	

## 2.2.85 ptp priority2

Use the **ptp priority2** configuration command on the device server to set the priority2 parameter of the local clock.

### Commands

**ptp priority2** priority

Syntax	<b>ptp</b>	Configure PTP
Description	<b>Priority2</b>	Set the priority2 parameter of the local clock
	priority	0 to 255
Defaults	default is 128	
Permission	Admin group	
Usage	N/A	
Guidelines		
Examples	NPORT S9650I-16-2HV(config)# ptp priority2 128	

## 2.2.86 ptp utc-offset

Use the **ptp utc-offset** configuration command on the device server to set the PTP utc-offset field.

### Commands

**ptp utc-offset** *interval*

Syntax	<b>ptp</b>	Configure PTP
Description	<b>utc-offset</b>	sets the offset between TAI and UTC
	<i>interval</i>	0 to 65535
Defaults	default is 0	
Permission	Admin group	
Usage	N/A	
Guidelines		
Examples	NPORT S9650I-16-2HV(config)# ptp utc-offset 0	

## 2.2.87 loopprotection

Use the **loopprotection** configuration command on the device server to enable loop protection.

### Commands

**loopprotection**

**no loopprotection**

Syntax	<b>loopprotection</b>	Enable loop protection
Description		
Defaults	N/A	
Permission	Admin group	
Usage	N/A	
Guidelines		
Examples	NPORT S9650I-16-2HV(config)# loopprotection	

## 2.2.88 qos mode

Use the **qos mode** global configuration command on the device server to configure the current QoS strategy.  
Use the **no** form of this command to return to the default.

### Commands

**qos mode { weighted-fair | strict }**

**no qos mode**

Syntax	<b>qos</b>	Configure QoS
Description	<b>mode</b>	Configure queuing mechanism
	<b>weighted-fair</b>	Weighted fair queuing
	<b>strict</b>	Strict queuing
Defaults	N/A	
Permission	Admin group	
Usage	N/A	
Guidelines		
Examples	NPORT S9650I-16-2HV(config)# qos mode strict	

## 2.2.89 qos mapping

Use the **qos mapping** global configuration command on the device server to configure the CoS and DSCP mappings. Use the **no** form of this command to return to the default.

### Commands

**qos mapping cos-to-queue** *cos-value queue*  
**no qos mapping cos-to-queue**  
**qos mapping dscp-to-cos** *dscp-value cos-value*  
**no qos mapping dscp-to-cos**  
**qos mapping dscp-to-queue** *dscp-value queue*  
**no qos mapping dscp-to-queue**

Syntax Description	<b>qos</b>	Configure QoS
	<b>mapping</b>	Configure QoS mapping
	<b>cos-to-queue</b>	CoS to traffic queue
	<i>cos-value</i>	CoS value (0 to 7)
	<i>queue</i>	Traffic queue
	<b>dscp-to-cos</b>	DSCP to CoS mapping
	<i>dscp-value</i>	DSCP value (0 to 63)
	<b>dscp-to-queue</b>	DSCP to traffic queue
Defaults	Cos (queue): 0 (0), 1(0), 2(1), 3(1), 4(2), 5(2), 6(3), 7(3) DSCP(Cos): 0-7(0), 8-15(1), 16-23(2), 24-31(3), 32-39(4), 40-47(5), 48-55(6), 56-63(7)	
Permission	Admin group	
Usage Guidelines	N/A	
Examples	NPORT S9650I-16-2HV(config)# qos mapping cos-to-queue 7 3 NPORT S9650I-16-2HV(config)# qos mapping dscp-to-cos 23 7	

## 2.2.90 account add

To configure the user account name and its group to log in to this device.

### Commands

**account add name** *name* **new\_password** *new\_password* **group** {**admins** | **users** | **guests** } [**note** *note*]

Syntax Description	<b>account</b>	To manage the user account database
	<b>add</b>	To add a new user account to a given group
	<b>name</b>	Account name
	<b>new_password</b>	The password for the new created account or for an existing account whose password need to be changed.
	<b>old_password</b>	The password of an existing account.
	<b>group</b>	The device provides 3 levels of access privileges: admins, users, and guests.
	<b>note</b>	The user could note anything in this field.
Defaults	N/A	
Permission	Admin group	
Usage Guidelines	The minimum length of account name is 1 character and the maximum length is 16 characters. The default minimum length of password is 1 character, and the maximum length is fixed to 16 characters. The maximum length of note field is 40 characters.	
Examples	Model(config)# account add name Tom new_password 12345 group users note "for maintenance engineer"	

## 2.2.91 account edit

To configure the user account name and its group to log in to this device.

### Commands

**account edit name** *name* **old\_password** *old\_password* **new\_password** *new\_password*

**account edit name** *name* [ **group** {**admins** | **users** | **guest** } ] [ **note** *note* ]

Syntax Description	<b>account</b>	To manage the user account database
	<b>edit</b>	To edit the attributes of an existing user
	<b>name</b>	Account name
Defaults	N/A	
Permission	Admin group	
Usage Guidelines	The minimum length of account name is 1 character and the maximum length is 16 characters. The default minimum length of password is 1 character, and the maximum length is fixed to 16 characters. The maximum length of note field is 40 characters.	
Examples	Model(config)# account edit name Tom group guests Model(config)# account edit name Tom old_password 12345 new_password 13579	

## 2.2.92 system-log system

To configure which events will be logged locally and/or remotely by the device server.

### Commands

**system-log system local**

**no system-log system local**

**system-log system remote**

**no system-log system remote**

Syntax Description	<b>system-log</b>	To enable the system log according to different event group.
	<b>system</b>	This event group includes: System Cold Start, System Warm Start, Power Transition, DI On/Off.
	<b>local</b>	The events will be logged in device server's local database.
	<b>remote</b>	The events will be logged to remote sys-log server.
Defaults	The default settings are all disabled	
Permission	Admin group	
Usage Guidelines	To enable remote log function, the user also has to configure SysLog Server Settings.	
Examples	Model(config)# system-log system local	

## 2.2.93 system-log network

To configure which events will be logged locally and/or remotely by the device server.

### Commands

**system-log network local**

**no system-log network local**

**system-log network remote**

**no system-log network remote**

Syntax Description	<b>system-log</b>	To enable the system log according to different event group.
	<b>network</b>	This event group includes: DHCP/BOOTP/PPPoE Get IP/Renew, NTP, Mail Fail, NTP Connect Fail, DHCP Fail, IP Conflict, Ethernet Link Down.
	<b>local</b>	The events will be logged in device server's local database.
	<b>remote</b>	The events will be logged to remote sys-log server.
Defaults	The default settings are all disabled	
Permission	Admin group	
Usage Guidelines	To enable remote log function, the user also has to configure SysLog Server Settings.	
Examples	Model(config)# system-log network local Model(config)# no system-log network remote	

## 2.2.94 system-log config

To configure which events will be logged locally and/or remotely by the device server.

### Commands

**system-log config local**

**no system-log config local**

**system-log config remote**

**no system-log config remote**

Syntax Description	<b>system-log</b>	To enable the system log according to different event group.
	<b>config</b>	This event group includes: Login Fail, IP Changed, Password Changed, Config Changed, Firmware Upgrade, SSL Key Import, Config Import, Config Export.
	<b>local</b>	The events will be logged in device server's local database.
	<b>remote</b>	The events will be logged to remote sys-log server.
Defaults	The default settings are all disabled	
Permission	Admin group	
Usage Guidelines	To enable remote log function, the user also has to configure SysLog Server Settings.	
Examples	Model(config)# system-log config local Model(config)# no system-log config remote	

## 2.2.95 system-log opmode

To configure which events will be logged locally and/or remotely by the device server.

### Commands

system-log opmode local  
no system-log opmode local  
system-log opmode remote  
no system-log opmode remote

Syntax	system-log	To enable the system log according to different event group.
Description	opmode	This event group includes: Connect, Disconnect, Authentication Fail, Restart.
	local	The events will be logged in device server's local database.
	remote	The events will be logged to remote sys-log server.
Defaults	The default settings are all disabled	
Permission	Admin group	
Usage Guidelines	To enable remote log function, the user also has to configure SysLog Server Settings.	
Examples	Model(config)# system-log opmode local Model(config)# no system-log opmode remote	

## 2.2.96 reset-button

To configure the reset button auto disable after device bootup.

### Commands

**reset-button**

**no reset-button**

Syntax	<b>reset-button</b>	To enable the reset button auto disable after 60 sec when bootup done.
Description		
Defaults	The default settings are no	
Permission	Admin group	
Usage Guidelines	To disable the reset button after 60 seconds of device boot up.	
Examples	Model(config)#reset-button-disable Model(config)#no reset-button-disable	

## 2.2.97 console auth

To configure the authentication type of the web/telnet/ssh/cli console.

### Commands

**console auth {local | radius | radius-local | tacasplus | tacasplus-local}**

Syntax	<b>console</b>	Set the parameters of the console.
Description	<b>auth</b>	Set the login authentication type
Defaults	The default settings are local	
Permission	Admin group	
Usage Guidelines	N/A.	
Examples	Model(config)# console auth radius Model(config)#no reset-button-disable	



## 2.2.98 console try-next-auth

To enable or disable try next authentication type when console auth is radius-local and tacas+-local mode.

### Commands

**console try-next-auth**

**no console try-next-auth**

Syntax	<b>console</b>	Set the parameters of the console.
Description	<b>try-next-auth</b>	Try next authentication type when the first authentication type fail
Defaults	The default settings are disabled.	
Permission	Admin group	
Usage Guidelines	This command only work only when console login mode is radius-local or tacas+-local.	
Examples	Model(config)# console try-next-auth Model(config)# no console try-next-auth	

## 2.3 Commands for Configuring Interface

These commands can only be executed under each interface folder of the CLI console, such as Ethernet interface, serial interface etc. They are used to set all the related settings of the interface of the device server.

### 2.3.1 Ethernet Interface Commands

From the CLI root, use "configure" command to enter configure mode, then input "interface Ethernet" command to enter the Ethernet interface folder.

#### 2.3.1.1 email-warning event

Use the **email-warning event** interface configuration command to allow interface warning events to be sent through the email if the event occurs. Use the **no** form of this command to disable the specified warning event notifications.

### Commands

**email-warning event { link-on | link-off }**

**no mail-warning event { link-on | link-off }**

**email-warning event traffic-overload [rxThreshold duration]**

**no email-warning event traffic-overload**

Syntax	<b>email-warning</b>	Configure email warning
Description	<b>event</b>	Port events
	<b>link-on</b>	Link ON
	<b>link-off</b>	Link OFF
	<b>traffic-overload</b>	Traffic overloading
	<i>rxThreshold</i>	0 to 100
	<i>duration</i>	1 to 300
Defaults	All port events are disabled by default.	
Permission	Admin group	
Usage Guidelines	N/A	
Examples	NPort S9650I-16-2HV(config)# interface ethernet 3/1 NPort S9650I-16-2HV(config-if)# email-warning event link-on NPort S9650I-16-2HV(config-if)# email-warning event traffic-overload 80 20	

### 2.3.1.2 relay-warning event

Use **relay-warning event** interface configuration commands to enable the warning events to trigger the relay. Use the **no** form of this command to disable it.

#### Commands

**relay-warning event { link-on | link-off }**

**relay-warning event traffic-overload [ rxThreshold duration]**

**no relay-warning event { link | traffic-overload }**

Syntax	<b>relay-warning</b>	Configure relay warning
Description	<b>event</b>	Port events
	<b>link-on</b>	Link ON
	<b>link-off</b>	Link OFF
	<b>traffic-overload</b>	Traffic overloading
	<i>rxThreshold</i>	0 to 100
	<i>duration</i>	1 to 300
	<b>link</b>	All link events
Defaults	All interface events are disabled by default.	
Permission	Admin group	
Usage Guidelines	N/A	
Examples	<pre>NPort S9650I-16-2HV(config)# interface ethernet 3/1 NPort S9650I-16-2HV(config-if)# relay-warning event traffic-overload</pre>	

### 2.3.1.3 trunk-group

Use the **trunk-group** interface configuration command on the device server to assign an Ethernet port to a trunk group. Use the **no** form of this command to remove an Ethernet port from a trunk group.

#### Commands

**trunk-group trunk\_id**

**no trunk-group**

Syntax	<b>trunk-group</b>	Join trunk group as members
Description	<i>trunk_id</i>	Trunk ID. From 1 to 4
Defaults	N/A	
Permission	Admin group	
Usage Guidelines	N/A	
Examples	<pre>NPORT S9650I-16-2HV(config-if)# trunk-group 1</pre>	

### 2.3.1.4 trunk-mode

Use the **trunk-mode** interface configuration command on the device server to set the trunk mode of the specified trunk group. Use the **no** form of this command to return to the default setting.

#### Commands

**trunk-mode { static | lacp }**

**no trunk-mode**

Syntax	<b>trunk-mode</b>	Trunk mode configuration
Description	<b>static</b>	Configure as static trunk
	<b>lacp</b>	Configure as LACP trunk
Defaults	The default trunk mode of creating trunk manually is static.	
Permission	Admin group	
Usage	N/A	
Guidelines		
Examples	NPORT S9650I-16-2HV(config-if)# trunk-mode static	

### 2.3.1.5 shutdown

To disable an interface, use the **shutdown** interface configuration command. To restart a disabled interface, use the **no** form of this command.

#### Commands

**shutdown**

**no shutdown**

Syntax	<b>shutdown</b>	Shutdown the selected interface
Description		
Defaults	N/A	
Permission	Admin group	
Usage	N/A	
Guidelines		
Examples	NPORT S9650I-16-2HV(config-if)# shutdown NPORT S9650I-16-2HV(config-if)# no shutdown	

### 2.3.1.6 name

Use the **name** interface configuration command to configure the interface name. To remove the configuration, use the **no** form of this command.

#### Commands

**name**

**no name**

Syntax	<b>name</b>	Port name
Description		
Defaults	N/A	
Permission	Admin group	
Usage	N/A	
Guidelines		
Examples	NPORT S9650I-16-2HV(config)# interface ethernet 1/1 NPORT S9650I-16-2HV(config-if)# name interfacel_port1 NPORT S9650I-16-2HV(config-if)# no name	

### 2.3.1.7 speed-duplex

Use the **speed-duplex** interface configuration command to specify the speed of the interface and its duplex mode. Use the **no** form of this command to return the interface to its default value.

#### Commands

**speed-duplex {10M-Full | 10M-Half | 100M-Full| 100M-Half | 1G-Full | Auto}**

**no speed-duplex**

Syntax	<b>speed-duplex</b>	Configure speed and duplex operation
Description	<b>10M-Full</b>	Speed 10M-full
	<b>10M-Half</b>	Speed 10M-Half
	<b>100M-Full</b>	Speed 100M-Full
	<b>100M-Half</b>	Speed 100M-Half
	<b>1G-Full</b>	Speed 1G-Full
	<b>Auto</b>	Speed Auto
Defaults	The default is Auto	
Permission	Admin group	
Usage	N/A	
Guidelines		
Examples	<pre>NPORT S9650I-16-2HV(config)# interface ethernet 1/1 NPORT S9650I-16-2HV(config-if)# speed-duplex 100M-Full</pre>	

### 2.3.1.8 flowcontrol

To set the method of data flow control between the terminal or other device, use the **flowcontrol** interface configuration command. Use the **no** form of this command to disable flow control

#### Commands

**flowcontrol**

**no flowcontrol**

Syntax	<b>flowcontrol</b>	Configure flowcontrol
Description		
Defaults	The default is disable	
Permission	Admin group	
Usage	N/A	
Guidelines		
Examples	<pre>NPORT S9650I-16-2HV(config)# interface ethernet 1/1 NPORT S9650I-16-2HV(config-if)# flowcontrol NPORT S9650I-16-2HV(config-if)# no flowcontrol</pre>	

### 2.3.1.9 media cable-mode

Use the **media cable-mode** interface configuration command on the device server to enable the medium-dependent interface crossover feature on the interface. Use the **no** form of this command to disable Auto-MDIX.

#### Commands

**media cable-mode [mdi | mdix | auto]**

**no media cable-mode**

Syntax Description	<b>media</b>	Select a media
	<b>cable-mode</b>	Select cable mode
	<b>mdi</b>	MDI
	<b>mdix</b>	MDIX
	<b>auto</b>	Auto select MDI/MDIX
Defaults	The default is auto	
Permission	Admin group	
Usage Guidelines	N/A	
Examples	NPort S9650I-16-2HV(config-if)# media cable-mode auto NPort S9650I-16-2HV(config-if)# no media cable-mode	

### 2.3.1.10 switchport access vlan

Use the **switchport access vlan** interface configuration command on the device server to configure a port as a static-access or dynamic-access port. If the switchport mode is set to access, the port operates as a member of the specified VLAN. If set to dynamic, the port starts discovery of VLAN assignment based on the incoming packets it receives. Use the **no** form of this command to reset the access mode to the default VLAN for the device server.

#### Commands

**switchport access vlan *vlan-id***

**no switchport access vlan**

Syntax Description	<b>switchport</b>	Set switching mode characteristics
	<b>access</b>	Set access mode characteristics of the interface
	<b>vlan</b>	Set (default) pvid in access mode
	<i>vlan-id</i>	1 to 4094
Defaults	vlan-id = 1	
Permission	Admin group	
Usage Guidelines	You can only use this command mode for configuring normal-range VLANs, that is, VLAN IDs 1 to 4094.	
Examples	NPort S9650I-16-2HV(config-if)# switchport access vlan 2	

### 2.3.1.11 switchport trunk fixed vlan add

Use the **switchport trunk fixed vlan add** interface configuration command on the device server to add the trunk characteristics when the interface is in trunking mode. Use the **no** form of this command to reset a trunking characteristic to the default.

#### Commands

**switchport trunk fixed vlan add** *vlan-id-list*

**no switchport trunk fixed vlan**

Syntax	<b>switchport</b>	Set switching mode characteristics
Description	<b>trunk</b>	Set trunking mode characteristics of the interface
	<b>fixed</b>	Set fixed VLAN characteristics
	<b>vlan</b>	1 to 4094
	<b>add</b>	Add VLANs to the current list
	<i>vlan-id-list</i>	VLAN IDs of the VLANs
Defaults	N/A	
Permission	Admin group	
Usage Guidelines	You can only use this command mode for configuring normal-range VLANs, that is, VLAN IDs 1 to 4094.	
Examples	NPort S9650I-16-2HV(config-if)# switchport trunk fixed vlan add 1,3-5,7	

### 2.3.1.12 switchport trunk fixed vlan remove

Use the **switchport trunk fixed vlan remove** configuration command on the device server stack to remove the trunk characteristics when the interface is in trunking mode. Use the **no** form of this command to reset a trunking characteristic to the default.

#### Commands

**switchport trunk fixed vlan remove** *vlan-id-list*

**no switchport trunk fixed vlan**

Syntax	<b>switchport</b>	Set switching mode characteristics
Description	<b>trunk</b>	Set trunking mode characteristics of the interface
	<b>fixed</b>	Set fixed VLAN characteristics
	<b>vlan</b>	1 to 4094
	<b>remove</b>	Remove VLANs from the current list
	<i>vlan-id-list</i>	VLAN IDs of the VLANs
Defaults	N/A	
Permission	Admin group	
Usage Guidelines	You can only use this command mode for configuring normal-range VLANs, that is, VLAN IDs 1 to 4094.	
Examples	NPort S9650I-16-2HV(config-if)# switchport trunk fixed vlan remove 1,3-5,7	

### 2.3.1.13 switchport trunk forbidden vlan add

Use the **switchport trunk forbidden vlan add** configuration command on the device server to add the trunk forbidden characteristics when the interface is in trunking mode. Use the **no** form of this command to reset a trunking characteristic to the default.

#### Commands

**switchport trunk forbidden vlan add** *vlan-id-list*

**no switchport trunk forbidden vlan**

Syntax Description	<b>switchport</b>	Set switching mode characteristics
	<b>trunk</b>	Set trunking mode characteristics of the interface
	<b>forbidden</b>	Set forbidden VLAN characteristics
	<b>vlan</b>	1 to 4094
	<b>add</b>	Add VLANs to the current list
	<i>vlan-id-list</i>	VLAN IDs of the VLANs
Defaults	N/A	
Permission	Admin group	
Usage Guidelines	You can only use this command mode for configuring normal-range VLANs, that is, VLAN IDs 1 to 4094.	
Examples	NPort S9650I-16-2HV(config-if)# switchport trunk forbidden vlan add 1,3-5,7	

### 2.3.1.14 switchport trunk forbidden vlan remove

Use the **switchport trunk forbidden vlan remove** configuration command on the switch stack or on a standalone switch to remove the trunk forbidden characteristics when the interface is in trunking mode. Use the **no** form of this command to reset a trunking characteristic to the default.

#### Commands

**switchport trunk forbidden vlan remove** *vlan-id-list*

**no switchport trunk forbidden vlan**

Syntax Description	<b>switchport</b>	Set switching mode characteristics
	<b>trunk</b>	Set trunking mode characteristics of the interface
	<b>forbidden</b>	Set forbidden VLAN characteristics
	<b>vlan</b>	1 to 4094
	<b>remove</b>	Remove VLANs from the current list
	<i>vlan-id-list</i>	VLAN IDs of the VLANs
Defaults	N/A	
Permission	Admin group	
Usage Guidelines	You can only use this command mode for configuring normal-range VLANs, that is, VLAN IDs 1 to 4094.	
Examples	NPort S9650I-16-2HV(config-if)# switchport trunk forbidden vlan remove 1,3-5,7	

### 2.3.1.15 switchport trunk native vlan

Use the **switchport trunk native vlan** interface configuration command on the device server to configure PVID of a port as a trunking port. Use the **no** form of this command to return to the default.

#### Commands

**switchport trunk native vlan** *vlan-id*

**no switchport trunk native vlan**

Syntax Description	<b>switchport</b>	Set switching mode characteristics
	<b>trunk</b>	Set trunking mode characteristics of the interface
	<b>native</b>	Set trunking native characteristics
	<b>vlan</b>	Set pvid vlanid in trunk mode
	<i>vlan-id</i>	1 to 4094
Defaults	vlan-id = 1	
Permission	Admin group	
Usage Guidelines	You can only use this command mode for configuring normal-range VLANs, that is, VLAN IDs 1 to 4094.	
Examples	NPort S9650I-16-2HV(config-if)# switchport trunk native vlan 2	

### 2.3.1.16 switchport pvlan

Use the **switchport pvlan** interface configuration command on the switch stack to define a port-based VLAN association for an isolated or community port or a mapping for a promiscuous port. Use the **no** form of this command to remove the port-based VLAN association or mapping from the port.

#### Commands

**switchport pvlan** *vlan-groups*

**no switchport pvlan** *vlan-groups*

Syntax Description	<b>switchport</b>	Set switching mode characteristics
	<b>pvlan</b>	Configure port-based vlan
	<i>vlan-groups</i>	Set/unset port-based vlan group
Defaults	N/A	
Permission	Admin group	
Usage Guidelines	N/A.	
Examples	NPort S9650I-16-2HV(config-if)# switchport pvlan 2,3,4	



### 2.3.1.17 switchport hybrid fixed vlan add

Use the **switchport hybrid fixed vlan add** interface configuration command on the device server to add the trunk hybrid characteristics when the interface is in hybrid mode. Use the **no** form of this command to reset to the default.

#### Commands

**switchport hybrid fixed vlan add** *vlan-id-list* **tag**  
**switchport hybrid fixed vlan add** *vlan-id-list* **untag**  
**no switchport hybrid fixed vlan tag**  
**no switchport hybrid fixed vlan untag**

Syntax	<b>switchport</b>	Set switching mode characteristics
Description	<b>hybrid</b>	Set hybrid mode characteristics of the interface
	<b>fixed</b>	Set fixed VLAN characteristics
	<b>vlan</b>	1 to 4094
	<b>add</b>	Add VLANs to the current list
	<i>vlan-id-list</i>	VLAN IDs of the VLANs
	<b>untag</b>	Configure egress traffic as VLAN untagged traffic
	<b>tag</b>	Configure egress traffic as VLAN tagged traffic
Defaults	N/A	
Permission	Admin group	
Usage Guidelines	You can only use this command mode for configuring normal-range VLANs, that is, VLAN IDs 1 to 4094.	
Examples	NPort S9650I-16-2HV(config-if)# switchport hybrid forbidden vlan add 1,3-5,7 tag	

### 2.3.1.18 switchport hybrid forbidden vlan add

Use the **switchport hybrid forbidden vlan add** interface configuration command on the device server to add the trunk forbidden characteristics when the interface is in hybrid mode. Use the **no** form of this command to reset to the default.

#### Commands

**switchport hybrid forbidden vlan add** *vlan-id-list*  
**no switchport hybrid forbidden vlan**

Syntax	<b>switchport</b>	Set switching mode characteristics
Description	<b>hybrid</b>	Set hybrid mode characteristics of the interface
	<b>forbidden</b>	Set forbidden VLAN characteristics
	<b>vlan</b>	1 to 4094
	<b>add</b>	Add VLANs to the current list
	<i>vlan-id-list</i>	VLAN IDs of the VLANs
Defaults	N/A	
Permission	Admin group	
Usage Guidelines	You can only use this command mode for configuring normal-range VLANs, that is, VLAN IDs 1 to 4094.	
Examples	NPort S9650I-16-2HV(config-if)# switchport hybrid forbidden vlan add 1,3-5,7	

### 2.3.1.19 switchport hybrid forbidden vlan remove

Use the **switchport hybrid forbidden vlan remove** interface configuration command on the device server to remove the trunk forbidden characteristics when the interface is in hybrid mode. Use the **no** form of this command to reset to the default.

#### Commands

**switchport hybrid forbidden vlan remove** *vlan-id-list*

**no switchport hybrid forbidden vlan**

Syntax Description	<b>switchport</b>	Set switching mode characteristics
	<b>hybrid</b>	Set hybrid mode characteristics of the interface
	<b>forbidden</b>	Set forbidden VLAN characteristics
	<b>vlan</b>	1 to 4094
	<b>remove</b>	Remove VLANs from the current list
	<i>vlan-id-list</i>	VLAN IDs of the VLANs
Defaults	N/A	
Permission	Admin group	
Usage Guidelines	You can only use this command mode for configuring normal-range VLANs, that is, VLAN IDs 1 to 4094.	
Examples	NPort S9650I-16-2HV(config-if)# switchport hybrid forbidden vlan remove 1,3-5,7	

### 2.3.1.20 switchport hybrid native vlan

Use the **switchport hybrid native vlan** interface configuration command on the device server to configure the PVID of a port. Use the **no** form of this command to return to the default PVID.

#### Commands

**switchport hybrid native vlan** *vlan-id*

**no switchport hybrid native vlan**

Syntax Description	<b>switchport</b>	Set switching mode characteristics
	<b>hybrid</b>	Set hybrid mode characteristics of the interface
	<b>native</b>	Set trunking native characteristics
	<b>vlan</b>	Set pvid vlanid in hybrid mode
	<i>vlan-id</i>	1 to 4094
Defaults	vlan-id = 1	
Permission	Admin group	
Usage Guidelines	You can only use this command mode for configuring normal-range VLANs, that is, VLAN IDs 1 to 4094.	
Examples	NPort S9650I-16-2HV(config-if)# switchport hybrid native vlan 2	

### 2.3.1.21 port-security

Use the **port-security** interface configuration command on the device server to add a static unicast MAC-address on a specified port. Use the **no** form of this command to remove the specified MAC address.

#### Commands

**port-security** MAC-address

**no port-security** MAC-address

Syntax	<b>port-security</b>	Set port security
Description	MAC-address	MAC address XX:XX:XX:XX:XX:XX
Defaults	N/A	
Permission	Admin group	
Usage Guidelines	N/A	
Examples	NPort S9650I-16-2HV(config-if)# port-security 00:00:00:00:00:01	

### 2.3.1.22 dot1x auth

Use the **dot1x auth** interface configuration command on the device server to enable port 802.1x authenticate. Use the **no** form of this command to return to the default setting.

#### Commands

**dot1x auth**

**no dot1x auth**

Syntax	<b>dot1x</b>	802.1x setting
Description	<b>auth</b>	802.1x port authentication enable/disable
Defaults	802.1x port authentication default disable	
Permission	Admin group	
Usage Guidelines	N/A	
Examples	NPort S9650I-16-2HV(config-if)# dot1x auth	

### 2.3.1.23 gmrp

Use the **gmrp** interface configuration command on the device server to active the IEEE 802.1D-1998 GMRP (GARP Multicast Registration Protocol). Use the **no** form of this command to stop this function.

#### Commands

**gmrp**

**no gmrp**

Syntax	<b>gmrp</b>	Enable GMRP (GARP Multicast Registration Protocol)
Description		
Defaults	gmrp is default disable	
Permission	Admin group	
Usage Guidelines	N/A	
Examples	NPort S9650I-16-2HV(config-if)# gmrp	

### 2.3.1.24 ip auto-assign

Use the **ip auto-assign** interface configuration command on the device server to enable and set the auto IP assignment of specified interfaces. Use the **no** form of this command to remove an Ethernet port from a trunk group.

#### Commands

**ip auto-assign** *ipaddr*

**no ip auto-assign**

Syntax	<b>ip</b>	Configure IP paramters
Description	<b>auto-assign</b>	Automatic port IP assignment through DHCP/BootP/RARP
	<i>ipaddr</i>	E.g., 11.22.33.44
Defaults	N/A	
Permission	Admin group	
Usage Guidelines	This specified IP address must be in the same subnet of the system IP address.	
Examples	NPort S9650I-16-2HV(config-if)# ip auto-assign 192.168.1.1	

## 2.3.2 VLAN Interface Commands

From the CLI root directory, use the "configure" command to enter configure mode, and use the "interface mgmt " command to enter the VLAN configure folder. In this folder, user could set all LAN management settings.

### 2.3.2.1 ip address

Use the **ip address** VLAN configuration command on the device server to configure the IP retrieve mechanism of the device server. Use **no** form of this command to return to the default.

#### Commands

**ip address** {**static** *ip-address netmask* | **dhcp** | **bootp** }

**no ip address**

Syntax Description	<b>ip</b>	Configure IP paramters
	<b>address</b>	Congiure IP address
	<b>static</b>	E.g., 11.22.33.44
	<i>ip-address</i>	IP address
	<i>netmask</i>	Subnet mask
	<b>dhcp</b>	Use DHCP to retrieve IP setting automatically
	<b>bootp</b>	Use BOOTP to retrieve IP setting automatically
Defaults	N/A	
Permission	Admin group	
Usage Guidelines	N/A	
Examples	NPORT S9650I-16-2HV(config)# interface mgmt NPORT S9650I-16-2HV(config-vlan)# ip address static 192.168.1.1 255.255.255.0	

### 2.3.2.2 ip default-gateway

Use the **ip default-gateway** VLAN configuration command on the device server to configure the IP default gateway address. Use the **no** form of this command to return to the default.

#### Commands

**ip default-gateway** *ip-address*  
**no default-gateway**

Syntax	<b>ip</b>	Configure IP parameters
Description	<b>default-gateway</b>	Configure default gateway address
	<i>ip-address</i>	IP address
Defaults	N/A	
Permission	Admin group	
Usage	N/A	
Guidelines		
Examples	<pre>NPORT S9650I-16-2HV(config)# interface mgmt NPORT S9650I-16-2HV(config-vlan)# ip default-gateway 192.168.1.1</pre>	

### 2.3.2.3 ip name-server

Use the **ip name-server** VLAN configuration command on the device server to configure the DNS server for the device server. Use the **no** form of this command to return to the default.

#### Commands

**ip name-server** *dns-ip-address1* [*dns-ip-address2*]  
**no ip name-server**

Syntax	<b>ip</b>	Configure IP parameters
Description	<b>name-server</b>	Configure DNS server address
	<i>dns-ip-address1</i>	IP address
	<i>dns-ip-address2</i>	IP address
Defaults	N/A	
Permission	Admin group	
Usage	N/A	
Guidelines		
Examples	<pre>NPORT S9650I-16-2HV(config)# interface mgmt NPORT S9650I-16-2HV(config-vlan)# ip name-server 192.168.1.1 255.255.255.0</pre>	

### 2.3.2.4 bind vlan

Use the **bind vlan** configuration command on the device server to bind the management address with a specified VLAN ID. Use the **no** form of this command to return to the default.

#### Commands

**bind vlan** *VLAN-ID*

Syntax	<b>bind</b>	Bind VLAN as management VLAN
Description	<b>vlan</b>	VLAN parameters
	<i>VLAN-ID</i>	1 to 4094
Defaults	Default management VLAN ID is 1	
Permission	Admin group	
Usage Guidelines	N/A	
Examples	<pre>NPORT S9650I-16-2HV(config)# interface mgmt NPORT S9650I-16-2HV(config-vlan)# bind vlan 1</pre>	

### 2.3.2.5 access-ip

Use **access-ip** in the configuration command as to restrict access to the serial to specified IP addresses. Use the **no** form of this command to disable this feature or to remove the IP addresses from access list.

#### Commands

**access-ip** [*ip-address netmask*]

**no access-ip** [*ip-address netmask*]

Syntax	<b>access-ip</b>	Enable the accessible IP list
Description	<i>ip-address</i>	IP address
	<i>netmask</i>	IP netmask
Defaults	The feature is disabled by default.	
Permission	Admin group	
Usage Guidelines	This feature will take effect when the access-ip command is executed.	
Examples	<pre>NPORT S9650I-16-2HV(config)# interface mgmt NPORT S9650I-16-2HV (config-vlan)# access-ip 10.10.10.10 255.255.255.0 NPORT S9650I-16-2HV (config-vlan)# no access-ip</pre>	

## 2.3.3 Serial Interface Commands

From the CLI root directory, use the “configure” command to enter configure mode, and use the “interface serial ” command to enter the serial interface folder. In the folder, users can set all serial-related settings.

### 2.3.3.1 email-warning event

Use the **email-warning event** serial interface configuration command to allow interface warning events to be sent through the email if the event occurs. Use the **no** form of this command to disable the specified warning event notifications.

#### Commands

**email-warning event {dcd-changed | dsr-changed}**

**no email-warning event {dcd-changed | dsr-changed}**

Syntax	<b>email-warning</b>	Configure email warning.
Description	<b>event</b>	Port events.
	<b>dcd-changed</b>	DCD changed
	<b>dsr-changed</b>	DSR changed
Defaults	All serial port events are disabled by default.	
Permission	Admin group	
Usage Guidelines	N/A	
Examples	NPort S9650I-16-2HV(config)# email-warning event dcd-changed NPort S9650I-16-2HV(config)# no email-warning event dsr-changed	

### 2.3.3.2 port-alias

To configure the alias name for specified serial port.

#### Commands

**port-alias** *alias-string*

**no port-alias**

Syntax	<b>port-alias</b>	Configure alias name for serial port
Description		
Defaults	N/A	
Permission	Admin group	
Usage Guidelines	Alias: 1 – 16 characters	
Examples	NPort S9650I-16-2HV(config)# interface serial 1 NPort S9650I-16-2HV(config-serif)# port-alias dev_serial_port1 NPort S9650I-16-2HV(config-serif)# no port-alias	

### 2.3.3.3 baud-rate

To configure the baudrate for specified serial port.

#### Commands

**baud-rate** *rate*

Syntax Description	<b>baud-rate</b>	Configure baud rate for serial port
Defaults	The default is 115200	
Permission	Admin group	
Usage Guidelines	Baud-rate: 50, 75, 110, 134, 150, 300, 600, 1200, 1800, 2400, 4800, 7200, 9600, 19200, 38400, 57600, 115200, 230400, 460800, 921600, or user specific baud-rate value	
Examples	<pre>NPort S9650I-16-2HV(config)# interface serial 1 NPort S9650I-16-2HV(config-serif)# baud-rate 9600</pre>	

### 2.3.3.4 parity

To configure the serial parity for specified serial port.

#### Commands

**parity** {**none** | **odd** | **even** | **mark** | **space**}

Syntax Description	<b>parity</b>	Configure parity for serial port
Defaults	The default is none	
Permission	Admin group	
Usage Guidelines	N/A	
Examples	<pre>NPort S9650I-16-2HV(config)# interface serial 1 NPort S9650I-16-2HV(config-serif)# parity odd</pre>	

### 2.3.3.5 data-bit

To configure the data-bit for specified serial port.

#### Commands

**data-bit** {**5** | **6** | **7** | **8**}

Syntax Description	<b>data-bit</b>	Configure data-bit for serial port
Defaults	The default is 8	
Permission	Admin group	
Usage Guidelines	N/A	
Examples	<pre>NPort S9650I-16-2HV(config)# interface serial 1 NPort S9650I-16-2HV(config-serif)# data-bit 6</pre>	



### 2.3.3.6 stop-bit

To configure the stop-bit for specified serial port.

#### Commands

**stop-bit {1 | 1.5 | 2}**

Syntax Description	<b>stop-bit</b>	Configure stop-bit for serial port
Defaults	The default is 1	
Permission	Admin group	
Usage Guidelines	N/A	
Examples	<pre>NPort S9650I-16-2HV(config)# interface serial 1 NPort S9650I-16-2HV(config-serif)# stop-bit 2</pre>	

### 2.3.3.7 flowctrl

To configure the flow control for specified serial port.

#### Commands

**flowcontrol {none | rtscts | xonxoff }**

Syntax Description	<b>flowctrl</b>	Configure flow control for serial port
Defaults	The default is rtscts	
Permission	Admin group	
Usage Guidelines	N/A	
Examples	<pre>NPort S9650I-16-2HV(config)# interface serial 1 NPort S9650I-16-2HV(config-serif)# flowctrl xonxoff</pre>	

### 2.3.3.8 fifo

To configure the flow control for specified serial port.

#### Commands

**fifo**

**no fifo**

Syntax Description	<b>fifo</b>	Enable fifo for serial port
Defaults	The default is enable	
Permission	Admin group	
Usage Guidelines	N/A	
Examples	<pre>NPort S9650I-16-2HV(config)# interface serial 1 NPort S9650I-16-2HV(config-serif)# fifo NPort S9650I-16-2HV(config-serif)# no fifo</pre>	

### 2.3.3.9 port-type

To configure the flow control for specified serial port.

#### Commands

**port-type {232 | 422 | 485-2w | 485-4w }**

Syntax	<b>port-type</b>	Configure interface for serial port
Description		
Defaults	The default is 232	
Permission	Admin group	
Usage	N/A	
Guidelines		
Examples	<pre>NPort S9650I-16-2HV(config)# interface serial 1 NPort S9650I-16-2HV(config-serif)# port-type 485-2w</pre>	

### 2.3.3.10 opmode

To configure the operation mode for specified serial port.

#### Commands

**opmode {disable | realcom | rfc2217 | tcpserver | tcpclient | udp | modbus | dnp3 | dnp3-raw-socket}**

Syntax	<b>opmode</b>	Configure operation mode for serial port
Description		
Defaults	The default is realcom	
Permission	Admin group	
Usage	N/A	
Guidelines		
Examples	<pre>NPort S9650I-16-2HV(config)# interface serial 1 NPort S9650I-16-2HV(config-serif)# opmode modbus</pre>	

### 2.3.3.11 realcom

To configure the parameters of RealCOM mode for specified serial port.

#### Commands

**realcom alive-check** *minute*

**realcom** [**max-conn** *maxconn*] [**ignore-jammed-ip** {**enable** | **disable**} ] [**allow-driver-ctrl** {**enable** | **disable**}]

**realcom conn-down-rts** {**low** | **high**}

**realcom conn-down-dtr** {**low** | **high**}

Syntax	<b>realcom</b>	To configure the parameters of RealCOM mode.
Description	<b>alive-check</b>	TCP alive check time specifies how long the device server will wait for a response to "keep alive" packets before closing the TCP connection.
	<b>max-conn</b>	Max connection is used if you need to receive data from different hosts simultaneously.
	<b>ignore-jammed-ip</b>	When in multiple connection, if there are any remote sides happen connection problem, the device should ignore these sides and keep send serial-to-Ethernet data or stop send, this setting only work when max connection is not 1.
	<b>allow-driver-ctrl</b>	Allow driver control determines how the port will proceed if driver control commands are received from multiple hosts that are connected to the port, this setting only work when max connection is not 1.
	<b>conn-down-rts</b>	Set the RTS signal to high/low when the connection is down.
	<b>conn-down-dtr</b>	Set the DTR signal to high/low when the connection is down.
Defaults	The default settings for each parameter are: TCP alive check time: 7 min Max connection: 1 Ignore jammed IP: disable Allow driver control: disable Connection goes down - RTS: always high Connection goes down - DTR: always high	
Permission	Admin group	
Usage	alive-check: 0 – 99 min	
Guidelines	max-conn: 1 – 8	
Examples	<pre>NPort S9650I-16-2HV(config)# interface serial 1 NPort S9650I-16-2HV(config-serif)# realcom alive-check 5 NPort S9650I-16-2HV(config-serif)# realcom max-conn 8 ignore-jammed-ip enable allow-driver-ctrl disable NPort S9650I-16-2HV(config-serif)# realcom conn-down-rts low</pre>	

### 2.3.3.12 rfc2217

To configure the parameters of RFC 2217 mode for specified serial port.

#### Commands

**rfc2217 alive-check** *minute*

**rfc2217 tcp-port** *tcp-port*

Syntax	<b>rfc2217</b>	To configure the parameters of RFC 2217 mode.
Description	<b>alive-check</b>	TCP alive check time specifies how long the device server will wait for a response to "keep alive" packets before closing the TCP connection.
	<b>tcp-port</b>	This is the TCP port number assignment for the serial port on the device server.
Defaults	The default settings for each parameter are: TCP alive check time: 7 min TCP port: 4001	
Permission	Admin group	
Usage	Alive-check: 0 - 99 min	
Guidelines	Tcp-port: 1 - 65535	
Examples	<pre>NPort S9650I-16-2HV(config)# interface serial 1 NPort S9650I-16-2HV(config-serif)# rfc2217 alive-check 5 NPort S9650I-16-2HV(config-serif)# rfc2217 tcp-port 3456</pre>	

### 2.3.3.13 tcpserver

To configure the parameters of TCP Server mode for specified serial port.

#### Commands

**tcpserver alive-check** *minute*

**tcpserver inactivity** *milli-second*

**tcpserver** [**max-conn** *maxconn*] [**ignore-jammed-ip** {**enable** | **disable**}] [**allow-driver-ctrl** {**enable** | **disable**} ]

**tcpserver conn-down-rts** {**low** | **high**}

**tcpserver conn-down-dtr** {**low** | **high**}

**tcpserver local-tcp-port** *tcp-port*

**tcpserver local-cmd-port** *tcp-port*

Syntax Description	<b>tcpserver</b>	To configure the parameters of TCP Server mode.
	<b>alive-check</b>	TCP alive check time specifies how long the device server will wait for a response to "keep alive" packets before closing the TCP connection.
	<b>inactivity</b>	Inactivity time specifies how long the device server will wait for incoming and outgoing data through the serial port before closing the TCP connection.
	<b>max-conn</b>	Max connection is used if you need to receive data from different hosts simultaneously.
	<b>ignore-jammed-ip</b>	When in multiple connection, if there are any remote sides happen connection problem, the device should ignore these sides and keep send serial-to-Ethernet data or stop send, this setting only work when max connection is not 1.
	<b>allow-driver-ctrl</b>	Allow driver control determines how the port will proceed if driver control commands are received from multiple hosts that are connected to the port, this setting only work when max connection is not 1.
	<b>conn-down-rts</b>	Set the RTS signal to high/low when the connection is down.
	<b>conn-down-dtr</b>	Set the DTR signal to high/low when the connection is down.
	<b>local-tcp-port</b>	Specific the local TCP port for TCP server use.
	<b>local-cmd-port</b>	Specific the local CMD port for TCP server use.
<b>no</b>	Clear the setting to empty	
Defaults	The default settings for each parameter are: TCP alive check time: 7 min Inactivity time: 0 ms (disable) Max connection: 1 Ignore jammed IP: disable Allow driver control: disable Connection goes down - RTS: always high Connection goes down - DTR: always high Local TCP port: 4001 Local CMD port: 966	
Permission	Admin group	
Usage Guidelines	Alive-check: 0 – 99 min Inctivict time: 0 – 65535 ms Max connection: 1 - 8 Tcp-port: 1 – 65535	
Examples	<pre>NPort S9650I-16-2HV(config)# interface serial 1 NPort S9650I-16-2HV (config-serif)# tcpclient alive-check 5 NPort S9650I-16-2HV (config-serif)# tcpserver alive-check 5 NPort S9650I-16-2HV (config-serif)# tcpserver inactivity 5000 NPort S9650I-16-2HV(config-serif) # tcpserver max-conn 8 ignore-jammed-ip enable allow-driver-ctrl disable</pre>	

```
NPort S9650I-16-2HV(config-serif) # tcpserver local-tcp-port 4005
```

### 2.3.3.14 tcpclient

To configure the parameters of TCP Client mode for specified serial port.

#### Commands

**tcpclient alive-check** *minute*

**tcpclient inactivity** *milli-second*

**tcpclient ignore-jammed-ip** {**enable**|**disable**}

**tcpclient [dest-ip1** *ip-address*] [**dest-port1** *tcp-port* ]

**tcpclient [dest-ip2** *ip-address*] [**dest-port2** *tcp-port* ]

**tcpclient [dest-ip3** *ip-address*] [**dest-port3** *tcp-port* ]

**tcpclient [dest-ip4** *ip-address*] [**dest-port4** *tcp-port* ]

**tcpclient local-port1** *tcp-port*

**tcpclient local-port2** *tcp-port*

**tcpclient local-port3** *tcp-port*

**tcpclient local-port4** *tcp-port*

**no tcpclient dest-ip1**

**no tcpclient dest-ip2**

**no tcpclient dest-ip3**

**no tcpclient dest-ip4**

**tcpclient conn-ctrl** {**startup-none** | **anychar-none** | **anychar-inactivity** | **dsron-off** | **dsron-none** | **dcdon-off** | **dcdon-none**}

Syntax Description	<b>tcpclient</b>	To configure the parameters of TCP Client mode.
	<b>alive-check</b>	TCP alive check time specifies how long the device server will wait for a response to "keep alive" packets before closing the TCP connection.
	<b>inactivity</b>	Inactivity time specifies how long the device server will wait for incoming and outgoing data through the serial port before closing the TCP connection.
	<b>ignore-jammed-ip</b>	When in multiple connection, if there are any remote sides happen connection problem, the device should ignore these sides and keep send serial-to-Ethernet data or stop send.
	<b>dest-ip1</b>	1st destination IP address specifies an IP address allows the device server to connect actively to the remote host.
	<b>dest-ip2</b>	2nd destination IP address specifies an IP address allows the device server to connect actively to the remote host.
	<b>dest-ip3</b>	3rd destination IP address specifies an IP address allows the device server to connect actively to the remote host.
	<b>dest-ip4</b>	4th destination IP address specifies an IP address allows the device server to connect actively to the remote host.
	<b>dest-port1</b>	1st destination port specifies the TCP port number allows the device server to connect actively to the remote host.
	<b>dest-port2</b>	2nd destination port specifies the TCP port number allows the device server to connect actively to the remote host.
	<b>dest-port3</b>	3rd destination port specifies the TCP port number allows the device server to connect actively to the remote host.
	<b>dest-port4</b>	4th destination port specifies the TCP port number allows the device server to connect actively to the remote host.
	<b>local-port1</b>	1st designated local port specifies the desired local port number of the device server for this TCP connection.
	<b>local-port2</b>	2nd designated local port specifies the desired local port number of the device server for this TCP connection.
<b>local-port3</b>	3rd designated local port specifies the desired local port number of the	

		device server for this TCP connection.
	<b>local-port4</b>	4th designated local port specifies the desired local port number of the device server for this TCP connection.
	<b>conn-ctrl</b>	Connection control determines the parameters under which a TCP connection is established or disconnected
	<b>no</b>	Clear the setting to empty
Defaults	<p>The default settings for each parameter are:</p> <p>TCP alive check time: 7 min</p> <p>Inactivity time: 0 ms (disable)</p> <p>Max connection: 1</p> <p>Ignore jammed IP: disable</p> <p>Destination IP address 1: blank</p> <p>Destination port 1: 4001</p> <p>Destination IP address 2: blank</p> <p>Destination port 2: 4001</p> <p>Destination IP address 3: blank</p> <p>Destination port 3: 4001</p> <p>Destination IP address 4: blank</p> <p>Destination port 4: 4001</p> <p>Designated local port 1: 5011</p> <p>Designated local port 2: 5012</p> <p>Designated local port 3: 5013</p> <p>Designated local port 4: 5014</p> <p>Connection control: Startup/None</p>	
Permission	Admin group	
Usage	Alive-check: 0 – 99 min	
Guidelines	<p>Inactivity time: 0 – 65535 ms</p> <p>IP address : IPv4 address or DNS name</p> <p>Tcp-port: 1 – 65535</p>	
Examples	<pre> NPort S9650I-16-2HV(config)# interface serial 1 NPort S9650I-16-2HV (config-serif)# tcpclient alive-check 5 NPort S9650I-16-2HV (config-serif)# tcpclient ignore-jammed-ip enable NPort S9650I-16-2HV (config-serif)# tcpclient dest-ip1 192.168.1.100 dest-port1 4001 NPort S9650I-16-2HV (config-serif)# tcpclient dest-ip2 192.168.1.101 NPort S9650I-16-2HV (config-serif)#dest-port2 4002 NPort S9650I-16-2HV (config-serif)# no tcpclient dest-ip3 NPort S9650I-16-2HV (config-serif)# tcpclient local-port1 5011 NPort S9650I-16-2HV (config-serif)# tcpclient conn-ctrl anychar-none </pre>	

### 2.3.3.15 udp

To configure the parameters of UDP mode for specified serial port.

#### Commands

```

udp [dest-ip1-begin ip-address] [dest-ip1-end ip-address] [dest-port1 port]
udp [dest-ip2-begin ip-address] [dest-ip2-end ip-address] [dest-port2 port]
udp [dest-ip3-begin ip-address] [dest-ip3-end ip-address] [dest-port3 port]
udp [dest-ip4-begin ip-address] [dest-ip4-end ip-address] [dest-port4 port]
udp local-port udp-port
no udp dest-ip1-begin
no udp dest-ip1-end
no udp dest-ip2-begin
no udp dest-ip2-end
no udp dest-ip3-begin
no udp dest-ip3-end
no udp dest-ip4-begin
no udp dest-ip4-end

```

Syntax Description	<b>udp</b>	To configure the parameters of dnp3 mode.
	<b>dest-ip1-begin</b>	1st start ranges of IP addresses for the serial port to connect to.
	<b>dest-ip1-end</b>	1st end ranges of IP addresses for the serial port to connect to.
	<b>dest-ip2-begin</b>	2nd start ranges of IP addresses for the serial port to connect to.
	<b>dest-ip2-end</b>	2nd end ranges of IP addresses for the serial port to connect to.
	<b>dest-ip3-begin</b>	3rd start ranges of IP addresses for the serial port to connect to.
	<b>dest-ip3-end</b>	3rd end ranges of IP addresses for the serial port to connect to.
	<b>dest-ip4-begin</b>	4th start ranges of IP addresses for the serial port to connect to.
	<b>dest-ip4-end</b>	4th end ranges of IP addresses for the serial port to connect to.
	<b>dest-port1</b>	1st destination port specifies the UDP port number allows the device server to connect actively to the remote host
	<b>dest-port2</b>	2nd destination port specifies the UDP port number allows the device server to connect actively to the remote host
	<b>dest-port3</b>	3rd destination port specifies the UDP port number allows the device server to connect actively to the remote host
	<b>dest-port4</b>	4th destination port specifies the UDP port number allows the device server to connect actively to the remote host
	<b>local-port</b>	This is the UDP port that the device server listens to and that other devices must use to contact the device server.
<b>no</b>	Clear the setting to empty	
Defaults	The default settings for each parameter are: Destination IP address 1 begin: blank Destination IP address 1 end: blank Destination port 1: 4001 Destination IP address 2 begin: blank Destination IP address 2 end: blank Destination port 2: 4001 Destination IP address 3 begin: blank Destination IP address 3 end: blank Destination port 3: 4001 Destination IP address 4 begin: blank Destination IP address 4 end: blank Destination port 4: 4001 Local listen port: 4001	
Permission	Admin group	



Usage	IP address: IPv4 address
Guidelines	Tcp-port: 1 – 65535
Examples	<pre>NPort S9650I-16-2HV(config)# interface serial 1 NPort S9650I-16-2HV(config-serif)# udp dest-ip1-begin 192.168.1.100 dest-ip1-end 192.168.1.105 dest-port1 4001 NPort S9650I-16-2HV(config-serif)# udp dest-ip2-begin 192.168.1.200 dest-ip2-end 192.168.1.205 NPort S9650I-16-2HV(config-serif)# udp local-port 4001 NPort S9650I-16-2HV(config-serif)# udp dest-port3 4003</pre>

### 2.3.3.16 dnp3

To configure the parameters of Modbus mode for specified serial port.

**Commands**

**dnp3 mode {outstation|master}**

Syntax Description	<b>dnp3</b>	To configure the parameters of dnp3 mode.
	<b>mode</b>	Set the mode of the device which the serial port acted.
	<b>outstation</b>	Outstation mode
	<b>master</b>	Master mode
Defaults	The default settings for dnp3 mode is outstation	
Permission	Admin group	
Usage Guidelines	N/A	
Examples	<pre>NPort S9650I-16-2HV(config)# interface serial 1 NPort S9650I-16-2HV(config-serif)# dnp3 mode master</pre>	

### 2.3.3.17 dnp3-raw-socket

To configure the parameters of Modbus mode for specified serial port.

**Commands**

**dnp3-raw-socket local-tcp-port tcp-port**

**dnp3-raw-socket [remote-ip ip-address] [ remote-tcp-port tcp-port]**

Syntax Description	<b>dnp3-raw-socket</b>	To configure the parameters of dnp3-raw-socket mode.
	<b>local-tcp-port</b>	Set the local tcp port which device used for the serial.
	<b>remote-ip</b>	Set the remote IP address
	<b>remote-tcp-port</b>	Set the remote TCP port
Defaults	The default settings for each parameter are: local-tcp-port: 4001 remote-ip: empty remote-tcp-port: 20000	
Permission	Admin group	
Usage Guidelines	Ip-address: IPv4 address TCP port: 1 – 65535	
Examples	<pre>NPort S9650I-16-2HV(config)# interface serial 1 NPort S9650I-16-2HV(config-serif)# dnp3-raw-socket remote-ip 1.2.3.4 remote-tcp-port 20001 NPort S9650I-16-2HV(config-serif)# dnp3-raw-socket local-tcp-port 1234</pre>	

### 2.3.3.18 modbus

To configure the parameters of Modbus mode for specified serial port.

#### Commands

**modbus** [ **connected-dev** { **rtu-master** | **rtu-slave** | **ascii-master** | **ascii-slave** } ] [ **resp-timeout** *milli-second*] [ **inter-char-timeout** *milli-second*] [ **inter-frame-delay** *milli-second*] [ **designated-tcp-port** *tcp-port* ]

Syntax Description	<b>modbus</b>	To configure the parameters of Modbus mode.
	<b>connected-dev</b>	Set the type of the device type and role which the serial port connected.
	<b>response-timeout</b>	Set the Modbus response time out of the serial port. Only valid when connected-dev is RTU-slave or ascii-slave
	<b>Inter-char-timeout</b>	Set the inter-character timeout of the serial port. Only valid when connected-dev is RTU-slave .
	<b>Inter-frame-delay</b>	Set the inter-frame delay of the serial port. Only valid when connected-dev is RTU-slave .
	<b>Designated-tcp-port</b>	Set the designated TCP port of the serial port. Only valid when connected-dev is RTU-slave or ascii-slave
Defaults	The default settings for each parameter are: Connected device type: RTU Slave Response timeout: 1000 Inter-character timeout: 0 Inter-frame delay: 0 Designated TCP port: 0	
Permission	Admin group	
Usage Guidelines	Response timeout: 10 - 120000 ms Inter-character timeout: 10 - 500 ms, 0 for disable Inter-frame delay: 10 - 500 ms, 0 for disable Designated TCP port: 1024 - 65535, 0 for disable	
Examples	<pre>NPort S9650I-16-2HV(config)# interface serial 1 NPort S9650I-16-2HV(config-serif)# modbus connected-device-type RTU-slave NPort S9650I-16-2HV(config-serif)# modbus response-timeout 2000 inter-char-timeout 10 inter-frame-delay 10 NPort S9650I-16-2HV(config-serif)# modbus designated-tcp-port 4001</pre>	

### 2.3.3.19 data-packing

To configure the data packing settings in different operation mode for specified serial port.

#### Commands

**data-packing length** *packet-length*

**data-packing deli1-char** *delimiter1-character* [**deli2-char** *delimiter2-character* ]

**data-packing deli1** {**enable**|**disable**} [**deli2** {**enable**|**disable**} ]

**data-packing process** {**nothing** | **plus1** | **plus2** | **strip**}

**data-packing force-transmit** *millisecond*

Syntax Description	<b>data-packing</b>	To configure the data packing behavior.
	<b>length</b>	It refers to the maximum amount of data that is allowed to accumulate in the serial port buffer before sending.
	<b>deli1</b>	Enable or disable the delimiter 1 functionality.
	<b>deli1-char</b>	To configure the delimiter 1 character.
	<b>deli2</b>	Enable or disable the delimiter 2 functionality, this function could be set only when deli1 was set; If the deli1 is disable, this value must be disable.
	<b>deli2-char</b>	To configure the delimiter 2 character, this function could be set only when deli1-char was set.
	<b>process</b>	The delimiter proces determines how the data is handled when a delimiter is received.
	<b>force-transmit</b>	This parameter defines how large a gap in serial communication the device server will allow before packing the serial data in its internal buffer for network transmission.
Defaults	The default settings for each parameter are: packet length: 0 delimiter 1: disable delimiter 1 character: 0x00 delimiter 2: disable delimiter 2 character: 0x00 delimiter process: nothing force transmit: 0 ms	
Permission	Admin group	
Usage Guidelines	Data-packing length: 0 - 1024 deli1-char: HEX value(length: 1 - 2) deli2-char: HEX value(length: 1- 2 ) force-transmit: 0 - 65535 ms	
Examples	<pre>NPort S9650I-16-2HV(config)# interface serial 1 NPort S9650I-16-2HV(config-serif)# data-packing length 100 NPort S9650I-16-2HV(config-serif)# data-packing deli-char 0x55 deli2-char 0xff NPort S9650I-16-2HV(config-serif)# data-packing force-transmit 1000</pre>	

### 2.3.3.20 email-warning event

Use the **email-warning event** serial interface configuration command to allow interface warning events to be sent through the email if the event occurs. Use the **no** form of this command to disable the specified warning event notifications.

#### Commands

**email-warning event {dcd-changed | dsr-changed}**

**no email-warning event {dcd-changed | dsr-changed}**

Syntax	<b>email-warning</b>	Configure email warning.
Description	<b>event</b>	Port events.
	<b>dcd-changed</b>	DCD changed
	<b>dsr-changed</b>	DSR changed
Defaults	All serial port events are disabled by default.	
Permission	Admin group	
Usage	N/A	
Guidelines		
Examples	<pre>NPort S9650I-16-2HV(config)# interface serial 1 NPort S9650I-16-2HV(config-serif)# email-warning event dcd-changed</pre>	

### 2.3.3.21 irig-b

To configure the *irig-b* setting for specified serial port.

#### Commands

**irig-b output { off|pwm|pps }**

Syntax	<b>init-delay</b>	Configure initial delay for the modbus protocol
Description		
Defaults	The default is off	
Permission	Admin group	
Usage	listen-tcp-port: 0 - 30000	
Guidelines		
Examples	<pre>NPort S9650I-16-2HV(config)# interface serial 1 NPort S9650I-16-2HV(config-serif)# irig-b pwm</pre>	

## 2.3.4 Protocol Modbus Interface Commands

From the CLI root directory, use the "configure" command to enter configure mode, and use the "interface serial protocol modbus " command to enter the Modbus protocol folder. In this folder, user can set all Modbus protocol settings.

### 2.3.4.1 init-delay

To configure the initial delay of the Modbus.

#### Commands

**init-delay** *mili-seconds*

Syntax	<b>init-delay</b>	Configure initial delay for the Modbus protocol
Description		
Defaults	The default is 0	
Permission	Admin group	
Usage	listen-tcp-port: 0 - 30000	
Guidelines		
Examples	<pre>NPort S9650I-16-2HV(config)# interface serial protocol modbus NPort S9650I-16-2HV(config-modbus)# init-delay 1000</pre>	

### 2.3.4.2 send-tcp-exception

To configure the send TCP exception of the Modbus.

#### Commands

**send-tcp-exception**

**no send-tcp-exception**

Syntax	<b>send-tcp-exception</b>	Configure enable or disable send TCP exception for the Modbus protocol
Description	<b>on</b>	
Defaults	The default is disable	
Permission	Admin group	
Usage	listen-tcp-port: 1 - 65535	
Guidelines		
Examples	<pre>NPort S9650I-16-2HV(config)# interface serial protocol modbus NPort S9650I-16-2HV(config-modbus)# send-tcp-exception NPort S9650I-16-2HV(config-modbus)# no send-tcp-exception</pre>	

### 2.3.4.3 tcp-listen-port

To configure the listen TCP port of the Modbus protocol.

#### Commands

**tcp-listen-port** *listen-tcp-port*

Syntax	<b>tcp-listen-port</b>	Configure the listen TCP port for the Modbus protocol
Description		
Defaults	The default is 502	
Permission	Admin group	
Usage	listen-tcp-port: 1 - 65535	
Guidelines		
Examples	<pre>NPort S9650I-16-2HV(config)# interface serial protocol modbus NPort S9650I-16-2HV(config-modbus)# tcp-listen-port 1234</pre>	

### 2.3.4.4 tcp-response-timeout

To configure the listen TCP response timeout of the Modbus protocol.

**Commands**

**tcp-response-timeout** *milli-seconds*

Syntax Description	<b>tcp-response-timeout</b>	Configure the TCP client response time out for the Modbus protocol
Defaults	The default is 1000	
Permission	Admin group	
Usage Guidelines	milli-seconds: 10 - 120000 ms	
Examples	<pre>NPort S9650I-16-2HV(config)# interface serial protocol modbus NPort S9650I-16-2HV(config-modbus)# tcp-response-timeout 3000</pre>	

### 2.3.4.5 sid-map

To display the slave id mapping table of the Modbus protocol.

**Commands**

**sid-map**

Syntax Description	<b>sid-map</b>	To configure the slave-id mapping of Modbus mode.
Defaults	N/A	
Permission	Admin group	
Usage Guidelines	N/A	
Examples	<pre>NPort S9650I-16-2HV(config)# interface serial protocol modbus NPort S9650I-16-2HV(config-modbus)# sid-map Slave ID Map : Channel no.      Type                Definition                Modbus Address Range ----- 1                Modbus Serial      Port 1                    00001 - 00005 2                Modbus Serial      Port 2                    00006 - 00010 3                Modbus Serial      Port 3                    00011 - 00015 4                Modbus Serial      Port 4                    00016 - 00020 5                Modbus TCP         192.168.1.1: 502         00100 - 00150</pre>	

## 2.3.4.6 sid-map add remote-ip

To configure the slave id mapping table of the Modbus protocol.

### Commands

**sid-map add remote-ip** *ip-address* **remote-tcp-port** *tcp-port* **sid-start** *slave-id* **sid-end** *slave-id*

Syntax	<b>sid-map</b>	To configure the slave-id mapping of Modbus mode.
Description	<b>remote-ip</b>	The destination is Modbus tcp IP address.
	<b>remote-tcp-port</b>	The remote TCP port
	<b>sid-start</b>	Set the mapping start slave id.
	<b>sid-end</b>	Set the mapping end slave id.
Defaults	N/A	
Permission	Admin group	
Usage	Ip-address: IPv4 address	
Guidelines	Tcp-port: 1 - 65535 Slave-id: 1 - 255	
Examples	<pre>NPort S9650I-16-2HV(config)# interface serial protocol modbus NPort S9650I-16-2HV(config-modbus)# sid-map add remote-ip 1.2.3.4 remote-tcp-port 502 sid-start 1 sid-end 5</pre>	

### 2.3.4.7 sid-map edit

To configure the slave id mapping table of the Modbus protocol.

**Commands**

**sid-map edit channel id [remote-ip remote-ip] [ remote-tcp-port remote-port ] [sid-start slave-id-start][ sid-end slave-id-end]**

Syntax Description	<b>sid-map</b>	To configure the slave-id mapping of Modbus mode.		
	<b>channel</b>	The channel ID of the slave ID map		
	<b>remote-ip</b>	The destination is Modbus tcp IP address, this parameter is work only when channel is Modbus TCP.		
	<b>remote-tcp-port</b>	The remote TCP port, this parameter is work only when channel is Modbus TCP.		
	<b>sid-start</b>	Set the mapping start slave id.		
	<b>sid-end</b>	Set the mapping end slave id.		
Defaults	N/A			
Permission	Admin group			
Usage Guidelines	Ip-address: IPv4 address Tcp-port: 1 - 65535 slave-id-start/slave-id-end: 1 - 255 Channel index: 1 - n			
Examples	<pre> NPort S9650I-16-2HV(config)# interface serial protocol modbus NPort S9650I-16-2HV(config-modbus)# sid-map Slave ID Map : Channel number      Type                Definition          Modbus Address Range ----- 1                   Modbus Serial      Port 1              00001 - 00005 2                   Modbus Serial      Port 2              00006 - 00010 3                   Modbus Serial      Port 3              00011 - 00015 4                   Modbus Serial      Port 4              00016 - 00020 5                   Modbus TCP         192.168.1.1: 502   00100 - 00150  NPort S9650I-16-2HV (config-modbus)#sid-map edit channel 1 sid-start 3 sid-end 5 NPort S9650I-16-2HV (config-modbus)#sid-map edit channel 5 remote-tcp-port 505 NPort S9650I-16-2HV (config-modbus)#sid-map edit channel 5 remote-ip 1.2.3.4 remote-tcp-port 1234 NPort S9650I-16-2HV (config-modbus)#sid-map edit channel 5 remote-ip 1.2.3.4 remote-tcp-port 1234 sid-start 101 sid-end 110                 </pre>			



### 2.3.4.8 no sid-map

To remove an entry of the slave id mapping table of the Modbus protocol.

**Commands**

**no sid-map channel id**

Syntax Description	<b>sid-map</b>	To configure the slave-id mapping of Modbus mode.
	<b>channel</b>	The channel ID of the slave ID map
	<b>id</b>	The channel id
Defaults	N/A	
Permission	Admin group	
Usage Guidelines	id: 1 - n	
Examples	<pre> NPort S9650I-16-2HV(config)# interface serial protocol modbus NPort S9650I-16-2HV (config-modbus)# sid-map Slave ID Map : Channel number      Type              Definition          Modbus Address Range ----- 1                   Modbus Serial    Port 1              00001 - 00005 2                   Modbus Serial    Port 2              00006 - 00010 3                   Modbus Serial    Port 3              00011 - 00015 4                   Modbus Serial    Port 4              00016 - 00020 5                   Modbus TCP       192.168.1.1: 502   00100 - 00150  NPort S9650I-16-2HV (config-modbus)# no sid-map channel 5 NPort S9650I-16-2HV (config-modbus)# sid-map  Slave ID Map : Channel number      Type              Definition          Modbus Address Range ----- 1                   Modbus Serial    Port 1              00001 - 00005 2                   Modbus Serial    Port 2              00006 - 00010 3                   Modbus Serial    Port 3              00011 - 00015 4                   Modbus Serial    Port 4              00016 - 00020                 </pre>	

## 2.3.5 Protocol DNP3 Interface Commands

From the CLI root directory, use the "configure" command to enter the configure mode, and use the "interface serial protocol dnp3 " command to enter the DNP3 protocol folder. In this folder, user could set all DNP3 protocol settings.

### 2.3.5.1 listen-port

To configure the initial delay of the modbus.

#### Commands

**listen-port** *tcp-port*

Syntax Description	<b>listen-port</b>	Configure listen TCP port for the DNP3 protocol
Defaults	The default is 20000	
Permission	Admin group	
Usage Guidelines	tcp-port: 1 - 65535	
Examples	NPort S9650I-16-2HV(config)# interface serial protocol dnp3 NPort S9650I-16-2HV (config-dnp3)# listen-port 20001	

### 2.3.5.2 address-table

To configure the address table of the DNP3 protocol.

#### Commands

**address-table**

Syntax Description	<b>address-table</b>	To configure the address table of DNP3 mode.																																								
Defaults	N/A																																									
Permission	Admin group																																									
Usage Guidelines	N/A																																									
Examples	NPort S9650I-16-2HV(config)# interface serial protocol dnp3 NPort S9650I-16-2HV (config-dnp3)# address-table Address table : <table border="1"> <thead> <tr> <th>Channel number</th> <th>Type</th> <th>Definition</th> <th>DNP3 Address</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>DNP3 Serial</td> <td>Port 1</td> <td>00001 -</td> </tr> <tr> <td>00005</td> <td></td> <td></td> <td></td> </tr> <tr> <td>2</td> <td>DNP3 Serial</td> <td>Port 2</td> <td>00006 -</td> </tr> <tr> <td>00010</td> <td></td> <td></td> <td></td> </tr> <tr> <td>3</td> <td>DNP3 Serial</td> <td>Port 3</td> <td>00011 -</td> </tr> <tr> <td>00015</td> <td></td> <td></td> <td></td> </tr> <tr> <td>4</td> <td>DNP3 Serial</td> <td>Port 4</td> <td>00016 -</td> </tr> <tr> <td>00020</td> <td></td> <td></td> <td></td> </tr> <tr> <td>5</td> <td>DNP3 TCP</td> <td>192.168.1.1 : 502</td> <td>10000 - 11000</td> </tr> </tbody> </table>		Channel number	Type	Definition	DNP3 Address	1	DNP3 Serial	Port 1	00001 -	00005				2	DNP3 Serial	Port 2	00006 -	00010				3	DNP3 Serial	Port 3	00011 -	00015				4	DNP3 Serial	Port 4	00016 -	00020				5	DNP3 TCP	192.168.1.1 : 502	10000 - 11000
Channel number	Type	Definition	DNP3 Address																																							
1	DNP3 Serial	Port 1	00001 -																																							
00005																																										
2	DNP3 Serial	Port 2	00006 -																																							
00010																																										
3	DNP3 Serial	Port 3	00011 -																																							
00015																																										
4	DNP3 Serial	Port 4	00016 -																																							
00020																																										
5	DNP3 TCP	192.168.1.1 : 502	10000 - 11000																																							

### 2.3.5.3 address-table add

To configure the address table of the DNP3 protocol.

#### Commands

**address-table add remote-ip** *ip-address* **remote-tcp-port** *tcp-port* **addr-start** *addr-start* **addr-end** *addr-end*

Syntax Description	<b>address-table</b>	To configure the address table of DNP3 mode.
	<b>remote-ip</b>	The destination is tcp.
	<b>remote-tcp-port</b>	Remote side TCP port
	<b>addr-start</b>	Set the start address.
	<b>addr-end</b>	Set the end address.
Defaults	N/A	
Permission	Admin group	
Usage Guidelines	Ip-address: IPv4 address tcp-port: 1 - 65535 address: 1 to 65519	
Examples	<pre>NPort S9650I-16-2HV(config)# interface serial protocol dnp3 NPort S9650I-16-2HV (config-dnp3)# address-table remote-ip 192.168.1.1 remote-tcp-port 20000 addr-start 1 addr-end 5</pre>	

### 2.3.5.4 address-table edit

To configure the address table of the DNP3 protocol.

**Commands**

**address-table edit channel id [ remote-ip ip-address][ remote-tcp-port tcp-port ][addr-start addr-start ][addr-end addr-end]**

Syntax Description	<b>address-table</b>	To configure the address table of DNP3 mode.
	<b>channel</b>	The channel ID of DNP3 address table
	<b>remote-ip</b>	The destination IP address, this setting only works when the channel type is DNP3 TCP.
	<b>remote-tcp-port</b>	Remote side TCP port, this setting only works when the channel type is DNP3 TCP.
	<b>addr-start</b>	Set the start address.
	<b>addr-end</b>	Set the end address.
Defaults	N/A	
Permission	Admin group	
Usage Guidelines	Ip-address: IPv4 address tcp-port: 1 - 65535 address: 1 to 65519	
Examples	<pre> NPort S9650I-16-2HV(config)# interface serial protocol dnp3 NPort S9650I-16-2HV (config-dnp3)# address-table Address table : Channel number      Type              Definition          DNP3 Address Range ----- 1                   DNP3 Serial      Port 1              00001 - 00005 2                   DNP3 Serial      Port 2              00006 - 00010 3                   DNP3 Serial      Port 3              00011 - 00015 4                   DNP3 Serial      Port 4              00016 - 00020 5                   DNP3 TCP         192.168.1.1 : 502  10000 - 11000 NPort S9650I-16-2HV (config-dnp3)# address-table edit channel 1 sid-start 3 sid-end 5 NPort S9650I-16-2HV (config- dnp3)# address-table edit channel 5 remote-tcp-port 505 NPort S9650I-16-2HV (config- dnp3)# address-table edit channel 5 remote-ip 1.2.3.4 remote-tcp-port 1234 NPort S9650I-16-2HV (config- dnp3)# address-table edit channel 5 remote-ip 1.2.3.4 remote-tcp-port 1234 sid-start 101 sid-end 110                 </pre>	

### 2.3.5.5 no address-table

To remove an entry of the address table of the DNP3 protocol.

**Commands**

**no address-table channel *id***

Syntax	<b>address-table</b>	To configure the address table of DNP3 mode.
Description	<b>channel</b>	The channel ID of DNP3 address table
	<i>id</i>	DNP3 channel id
Defaults	N/A	
Permission	Admin group	
Usage Guidelines	N/A	
Examples	<pre> NPort S9650I-16-2HV(config)# interface serial protocol dnp3 NPort S9650I-16-2HV (config-dnp3)# address-table Address table : Channel number      Type                Definition          DNP3 Address Range ----- 1                   DNP3 Serial        Port 1              00001 - 00005 2                   DNP3 Serial        Port 2              00006 - 00010 3                   DNP3 Serial        Port 3              00011 - 00015 4                   DNP3 Serial        Port 4              00016 - 00020 5                   DNP3 TCP           192.168.1.1 : 502  10000 - 11000 NPort S9650I-16-2HV (config-dnp3)# no address-table edit channel 5                     </pre>	