

Compumotor

Model 301 Indexer User Guide

Compumotor Division
Parker Hannifin Corporation
p/n 88-011728-01 A



Table Of Contents

| | |
|--|-----------|
| How To Use This User Guide | iii |
| Assumptions | iii |
| Contents of This User Guide | iii |
| Installation Process Overview | iii |
| Developing Your Application | iv |
| Installation Preparation | iv |
| Conventions | iv |
| Commands | v |
| Warnings & Cautions | v |
| Related Publications | v |
| Chapter 1. Introduction | 1 |
| Product Description | 1 |
| Product Features | 2 |
| Chapter 2. Getting Started | 3 |
| What You Should Have | 3 |
| Basic System Configuration | 3 |
| Indexer Setting | 4 |
| Establish Communications | 4 |
| Drive/Indexer Connection | 6 |
| Making an Open Loop Move | 6 |
| Making a Closed Loop Move | 7 |
| 8-Bit Outputs | 8 |
| 8-Bit Inputs | 8 |
| Sample Program for 5-Slot Rack | 10 |
| Chapter 3. Installation | 15 |
| Environmental Considerations | 15 |
| Complete System Configuration | 15 |
| PLC Port Addressing | 15 |
| Indexer Insertion | 16 |
| System Connections | 16 |
| Verifying Proper Installation | 17 |
| Inputs & Outputs | 19 |
| Chapter 4. Application Design | 21 |
| Motion Control Concepts | 21 |
| Move Profiles | 21 |
| Incremental vs. Absolute Positioning | 22 |
| Modes Of Operation | 23 |
| Immediate RS-232C Mode | 23 |
| Interactive Edit Mode | 24 |
| modes of operation | 27 |
| Program Design | 27 |
| Sequences | 27 |
| Trigger Inputs | 28 |
| Programmable Outputs | 29 |
| Time Delays | 29 |
| Branching | 29 |
| Limits | 29 |
| Chapter 5. Software Reference | 31 |
| Description of Format | 31 |
| Special Commands | 33 |
| General Command Listing | 34 |
| Chapter 6. Hardware Reference | 65 |
| Environmental Specifications | 65 |
| Electrical Specifications | 65 |
| Power Supply Requirements | 65 |
| Serial Communications(RS-232C) | 65 |
| 10-Pin Screw Terminal Connections | 66 |
| LEDs | 67 |
| System Specifications | 67 |
| I/O Specifications | 67 |
| Memory | 67 |
| Chapter 7. Troubleshooting | 69 |
| Troubleshooting | 69 |
| Problem Isolation | 69 |
| Reducing Electrical Noise | 69 |
| RS-232C Communications | 69 |
| Encoder Feedback | 71 |
| Appendices | 73 |
| Command Listing | 73 |
| Warranty | 74 |
| Glossary | 77 |
| Index | 81 |

List Of Figures

| | |
|---|----|
| Figure 1-1. Model 301—Front Panel | 1 |
| Figure 1-2. Sample Model 301 Configuration | 2 |
| Figure 2-1. Basic System Wiring Diagram | 3 |
| Figure 2-2. Location of Jumper for Standard Card Cage | 4 |
| Figure 2-3. Inserting a Model 301 into a Rack | 4 |
| Figure 2-4. RS-232C Connection | 5 |
| Figure 2-5. Model 301/Drive Connections | 6 |
| Figure 2-6. 5-Slot Rack Component Arrangement | 10 |
| Figure 3-1. PLC Port Addresses | 15 |
| Figure 3-2. Location of Jumper for Standard Card Cage | 16 |
| Figure 3-3. Complete Configuration | 16 |
| Figure 3-4. Homing Operation | 18 |
| Figure 4-1. | 21 |
| Figure 5-1. Open-Loop Homing Operation | 48 |
| Figure 5-2. Closed-Loop Homing Operation | 48 |
| Figure 6-1. RS-232C Serial Communications | 65 |
| Figure 6-2. 12 Pin I/O Connector | 66 |
| Figure 6-3. Typical Input Circuit | 66 |
| Figure 6-4. Typical Output Circuits | 67 |

List Of Tables

| | |
|--|----|
| Table 2-1. Model 301 Ship Kit List | 3 |
| Table 2-2. Input Bit Command Structure | 8 |
| Table 3-1. RS-232C Pin-Out | 17 |

How To Use This User Guide

This user guide is designed to help you install, develop, and maintain your system. Each chapter begins with a list of specific objectives that should be met after you have read the chapter. This section is intended to help you find and use information in this user guide.

Assumptions

To use this user guide effectively, you should have a fundamental understanding of the following information.

- IBM (or IBM-compatible) computer experience
- Basic electronics concepts (voltage, switches, current, etc.)
- Basic motion control concepts (torque, velocity, distance, force, etc.)
- Basic serial communication concepts (e.g., RS-232C)
- PLC programming

With this level of understanding, you can effectively use this user guide to install, develop, and maintain your system.

Contents of This User Guide

This user guide contains the following information.

Chapter 1: Introduction

This chapter provides a description of the product and a brief review of its specific features.

Chapter 2: Getting Started

This chapter contains a list of items you should have received with your shipment. It will help you become familiar with the system and ensure that each component functions properly. You will configure the system properly in this chapter.

Chapter 3: Installation

This chapter will help you properly mount the system and make all electrical connections. Upon completion of this chapter, your system should be completely installed and ready to perform basic operations.

Chapter 4: Application Design

This chapter will help you customize the system to meet your application's needs. Important application considerations are discussed. Sample applications are provided.

Chapter 5: Software Reference

This chapter explains Compumotor's X-Series programming language in detail. It describes command syntax and system parameters that affect command usage. An alphabetical list of all commands, with a syntax and command description for each command is included.

Chapter 6: Hardware Reference

This chapter contains information on system specifications (dimensions and performance).

Chapter 7: Maintenance & Troubleshooting

This chapter describes Compumotor's recommended system maintenance procedures. It also provides methods for isolating and resolving hardware and software problems.

Installation Process Overview

To ensure trouble-free operation, you should pay special attention to the environment in which the Model 301 will operate, the layout and mounting, and the wiring and grounding practices used. These recommendations are intended to help you easily and safely integrate the Model 301 into your manufacturing facility. Industrial environments often contain conditions that may adversely affect solid state equipment. Electrical noise or atmospheric contamination, may also affect the Model 301.

Developing Your Application

Before you develop and implement your application, there are several issues that you should consider and address.

1. Clarify the requirements of your application. Clearly define what you expect the system to do.
2. Assess your resources and limitations. This will help you find the most efficient and effective means of developing and implementing your application.
3. Follow the guidelines and instructions outlined in this user guide. Do not skip any steps or procedures. Proper installation and implementation can only be ensured if all procedures are completed in the proper sequence.

Installation Preparation

Before you attempt to install this product, you should complete the following steps:

1. Review this entire user guide. Become familiar with the user guide's contents so that you can quickly find the information you need.
2. Develop a basic understanding of all system components, their functions, and interrelationships.
3. Complete the basic system configuration and wiring instructions (in a simulated environment, not a permanent installation) provided in *Chapter 2, Getting Started*.
4. Perform as many basic moves and functions as you can with the preliminary configuration. You can only perform this task if you have reviewed the entire user guide. You should try to simulate the task(s) that you expect to perform when you permanently install your application (however, do not attach a load at this time). This will give you a realistic preview of what to expect from the complete configuration.
5. After you have tested the system's functions and used or become familiar with the system's features, carefully read *Chapter 3, Installation*.
6. After you have read Chapter 3 and clearly understand what must be done to properly install the system, you should begin the installation process. Do not deviate from the sequence or installation methods provided.
7. Before you begin to customize your system, check all of the system functions and features to ensure that you have completed the installation process correctly.

The successful completion of these steps will prevent subsequent performance problems and allow you to isolate and resolve any potential system difficulties before they affect your system's operation.

Conventions

To help you understand and use this user guide effectively, the conventions used throughout this user guide are explained in this section.

Commands

All commands that you are instructed to enter are displayed in all capital letters, just as they appear on the terminal (vertically). A one-line explanation of the command is provided next to each example. The command is displayed in boldface. Be sure to separate each command with a space (press the space bar). Press the carriage return key to execute the commands on a specific line. In this user guide, commands are often shown in a vertical fashion so that a short explanation of each command can be provided. Refer to the example below.

| <u>Command</u> | <u>Description</u> |
|----------------|---|
| > A5 | Sets acceleration to 5 rps ² |
| > V5 | Sets velocity to 5 rps |
| > D1000 | Sets distance to 1,000 steps |
| > G | Executes the move (Go) |

On your computer screen or terminal, the command string shown above would actually look like the example shown below.

```
> A5 V5 D1000 G<cr>
```

Responses are set in all capital letters, as they are on the terminal. An example is provided below.

| <u>Command</u> | <u>Response</u> |
|----------------|-----------------|
| > RV | *92-011006-01A4 |

The system generally ignores command syntax that is not within the valid range for a specific command (valid ranges are provided in *Chapter 5, Software Reference*). Compumotor does not guarantee system performance when the system executes commands that contain invalid syntax or are outside of the valid range.

Warnings & Cautions

Warning and caution notes alert you to possible dangers that may occur if you do not follow instructions correctly. Situations that may cause bodily injury are presented as warnings. Situations that may cause system damage are presented as cautions. These notes will appear in bold face and the word warning or caution will be centered and in all capital letters. Refer to the examples shown below.

WARNING

Do not touch the motor immediately after it has been in use for an extended period of time. The unit will be hot.

CAUTION

System damage will occur if you power up the system improperly.

Related Publications

The following publications may be helpful resources.

Seyer, Martin. *RS-232C Made Easy: Connecting Computers, Printers, Terminals and Modems*. Englewood Cliffs, New Jersey: Prentice Hall, Inc., 1984

Current Parker Compumotor Motion Control Catalog

Schram, Peter (editor). *The National Electric Code Handbook (Third Edition)*. Quincy, MA: National Fire Protection Association

Operations manual for the PLC that you will use with the Model 301 Indexer

Chapter 1. Introduction

Chapter Objectives

The information in this chapter will enable you to understand the product's basic functions & features.

Product Description

The Model 301 Indexer is designed for plug-in compatibility with the Texas Instruments' Series 305™ PLC and the GE Fanuc Series One™ PLC. Conservative electrical design and complete optical isolation of external signals maintain the industrial ruggedness of the PLC. The Model 301 is a single axis controller that accepts quadrature encoder feedback. Figure 1-1 shows the Model 301's front panel.

With a standard 3-wire RS-232C interface, the Model 301 uses an extended form of Compumotor's X Series Language for ease of programming and flexibility of interactive control with the PLC rack. The Model 301 has an on-board editor that provides complete program creation, modification, and monitoring through a remote terminal. As programs are written, they are automatically stored in nonvolatile memory. Execution may begin at any point in the stored program as designated by the PLC program or through the RS-232C port. The point at which motors are commanded to move depends on PLC contacts, time, and position information. You can even program the Model 301 to turn on and off outputs of the PLC within the execution of its own program. This bus-compatible product provides complete backplane integration between the PLC and the motor.




Figure 1-1. Model 301—Front Panel

There is a home input line for the axis to decouple the scan time of the PLC for sensing motor home positions.

The Model 301 controls a motor axis independent of the PLC's CPU. The indexer is not burdened by PLC scan time limitations. The scan time of the PLC is only pertinent in the communication between the Model 301 and the PLC through the backplane. Figure 1-2 is an example of a Model 301 configuration.




Figure 1-2. Sample Model 301 Configuration

Product Features

- Single-axis control with incremental encoder feedback
- Plug-in bus compatibility with the TI Series 305™ or GE Fanuc One™ PLC
- Standard RS-232C programming interface and complete online editing of the stored program
- Programmable position, direction, velocity, and acceleration for precise motion control
- 5VDC optically isolated inputs and outputs provide high electrical noise immunity
- 2K or 8K battery-backed RAM memory to store multiple programs
- Up to 63 separate indexer program entry points may be defined—complete flexibility of indexer program execution from the PLC program
- Integral high-speed inputs for accurate home sensor and sensor-interactive control
- Commands support complex move profiles; velocity changes on-the-fly triggered by time, position, or PLC contacts
- Conditional control of program flow with **IF** statements based on the state of PLC contacts
- On-line debugging with the Trace (**XTR**) command
- PLC output contacts may be set or cleared from the Model 301's programs

Chapter 2. Getting Started

Chapter Objectives

The information in this chapter will enable you to:

- Verify that each component of your system has been delivered safely
- Become familiar with system components and their interrelationships
- Bench test the system

What You Should Have

Inspect your Model 301 shipment upon receipt for damage to its shipping container. Report any damage to the shipping company immediately. Parker Compumotor cannot be held responsible for damage incurred in shipment. The items listed in Table 2-1 should be present and in good condition.

| Part/Quantity | Part Number |
|--------------------------|----------------|
| Model 301 | MODEL 301 |
| Model 301 User Guide (1) | 88-011728-01 A |
| Indexer/Drive Cables (1) | 71-011159-10 |
| Connector (1) | 43-011058-01 |
| RS-232C Cable (1) | 71-011319-10 |

Table 2-1. Model 301 Ship Kit List

Basic System Configuration

Figure 2-1 provides an overview of the connections you will have to make to operate the Model 301. Each of the connections will be discussed in detail in this chapter.




Figure 2-1. Basic System Wiring Diagram

Indexer Setting

Before you insert the Model 301 into one of the PLC's available ports, you must check the following indexer setting:

- In a standard rack system, the jumper (refer to Figure 2-2) must be placed over pins **1 and 2**.
- In an extended PLC cage, the jumper (refer to Figure 2-2) must be placed over pins **2 and 3**. The jumper disables the 1XX (octal) addresses on the card. Figure 2-2 shows the location of the jumper.

Push in the buttons at the top and bottom of the Model 301's front panel to insert/remove the unit from the rack.




Figure 2-2. Location of Jumper for Standard Card Cage




Figure 2-3. Inserting a Model 301 into a Rack

Establish Communications

You can program the Model 301 with any ASCII device that communicates via standard RS-232C. The terminal's parameters for RS-232C communications should be:

- Baud Rate: 9,600
- Stop Bit: 1
- Data Bits: 8
- Echo: Off

The Model 301's echo function is always on. Attach the RS-232C connection from your ASCII device to the 9-pin D connector on the front panel of the Model 301 (refer to Figure 2-4). If you are using an IBM PC, an RS-232C cable is provided.




Figure 2-4. RS-232C Connection

Testing RS-232C

To ensure that the RS-232C connection is operating properly, complete the following steps.

1. Apply power to PLC. If your terminal is already on, you will see a message indicating that the indexer is ready. Below the message, a prompt (>) should be present. Press the Return key. A new prompt should appear. If you powered up your terminal after the Model 301, press the Return key. The terminal should display a prompt (>).
2. Type **R** and press the Return key. The Model 301 will display the Dynamic Data, Registered Data, and Active Parameters. A sample Status Report (**R**) command's response is shown below.

```
*DYNAMIC DATA
* INPUT BYTE (B0 - B7) = 00000000
* OUTPUT BYTE (B0 - B7) = 00000000
* HOME: = 1
*REGISTERED DATA
* Inputs: I1=0 I2=0 I3=0 I4=0 I5=0
* Outputs: O1=0 O2=0 O3=0 O4=0 O5=0 O6=0
* Motor Position =+0
* Encoder Position =+0
*ACTIVE PARAMETERS:
* MR25000 GHV 1 GHF 0.1
* FR00000000
* ER 4000 DB5 DW250 CG8
* VS0 V0 A0
* MPI D+0 T0.5 L0
```

If you receive the data listed above, your RS-232C connection is working properly. If you do not receive any response, check your wiring, and perform the steps again. Some set-up values may be different. **Before proceeding, remove power from the PLC.**

Drive/Indexer Connection

Connect the external power (EXT. V+), external ground (EXT. GND), and drive outputs as shown in Figure 2-5. **Compumotor recommends that you make multiple connections to a terminal block and a single connection to the Model 301.**




Figure 2-5. Model 301/Drive Connections

Setting Drive Functions

Refer to the manual that accompanied the drive you are using with the Model 301 Indexer. **Follow the instructions provided in the manual to configure the motor and drive and complete any settings** (e.g., motor current). Before proceeding, be sure that you have properly made all connections and settings:

- Indexer Settings
- RS-232C Connection
- Indexer/Drive Connection
- Drive Functions
- Drive/Motor Connections

Making an Open Loop Move

To ensure that you have wired the Model 301 and the other components of your system properly, use the following instructions to perform a move.

Step 1

Apply power to the PLC, external power supply, and the drive.

Step 2

The motor resolution must be set to the same resolution as the drive. This example assumes 25,000 steps per rev. Use the **MR** command to set the motor resolution to 25,000 motor steps/rev (**MR25000**). To ensure that the motor resolution is properly set, issue the Status Report (**R**) command. Under the Active Parameters portion of this report, the current motor resolution is shown. The motor resolution is highlighted in the example below. This is only part of the report. Refer to the **R** command description in *Chapter 5, Software Reference* for the entire report.

```
*ACTIVE PARAMETERS:
* MR25000 GHV1      GHF0.1
* FR 00000000
* ER 4000 DB 5 DW 250 CG 8
* VS0      V0      A0
* MPI      D+      T0.5 L0
```

Step 3

Using the terminal, enter the following commands:

```
> MPI
> FR00000000
> A5 V5 D25000 G<cr>
```

Please note the spaces between the commands and the carriage return after the Go (G) command. A description of each command is given below.

| Command | Description |
|--------------|---|
| > MPI | Sets to Incremental mode |
| > FR00000000 | Clear any saved FS parameters |
| > A5 | Sets acceleration to 5 rps ² |
| > V5 | Sets velocity to 5 rps |
| > D25000 | Sets distance to 25,000 steps |
| > G | Executes the command (Go) |

The motor should move 25,000 steps in the CW direction. The moving (Red) LED will be on while steps are being sent. If the motor does not move, check the wiring and refer to *Chapter 7, Troubleshooting*.

To make the motor move in the CCW direction, enter the following commands:

| Command | Description |
|---------|-----------------------------------|
| > H | Changes the direction of movement |
| > G | Executes the command (Go) |

The previous acceleration, velocity, and distance parameters are used in this move. It is simply performed in the CCW direction.

Making a Closed Loop Move

To make a closed-loop move a 1,000 line (4,000 pulse post-quadrature) encoder must be wired to the Model 301. When ready, enter the following commands.

| Command | Description |
|-----------------|--|
| > PZ | Zero motor and encoder positions |
| > FSB1 | Enter closed loop mode |
| > FSC1 | Enable position maintenance |
| > FSD1 | Enable stop on stall |
| > FSE1 | Enable stall detect |
| > ER4000 | Set encoder resolution to 4,000 pulses/rev |
| > A5 V5 D4000 G | Motor should move 1 rev CW |

When the move is complete enter R.

The partial response from the terminal should be:

```
REGISTERED DATA
  Inputs:
  Outputs:
  Motor Position = +25000
  Encoder Position = +4000
```

If the encoder position is 0 or a message is sent indicating that the motor stalled, the encoder is not properly connected (refer to *Chapter 7, Maintenance and Troubleshooting*).

If the encoder position is negative (-), the encoder phases are reversed (refer to *Chapter 7, Maintenance and Troubleshooting*).

When the motor is finished moving enter:

```
> H G
> R
```

The motor and encoder positions should both be at 0 again.

8-Bit Outputs

The Model 301 Indexer has outputs to the PLC. These outputs are transmitted on the *upper octal addresses*. If the card is in the slot to the left of the Series One™ CPU, the outputs from the indexer card (which are inputs to the PLC) would occupy an address space from 100 to 107. The address 100 corresponds to B0 and 107 corresponds to B7. Refer to the example below (refer to Figure 3-1 for more information on rack addresses). *If you are using an extended card cage, the output bit addresses are not available (refer to the **Indexer Setting** section earlier in this chapter).*

The PLC may use the most significant two output bits (B7 & B6) to determine indexer status. These two bits indicate whether the indexer is executing a user program (i.e., **Program Busy**) or if the indexer is sending pulses (i.e., **Motor Busy**). The other bits are general-purpose outputs that are controlled by the indexer and its program. The protocol of these outputs is shown below:

| B7 | B6 | B5 | B4 | B3 | B2 | B1 | B0 |
|------|--------------|----|----|----|----|----|----|
| Busy | Program Busy | O6 | O5 | O4 | O3 | O2 | O1 |

B7 = 1: The motor is moving, the indexer is sending pulses.

B6 = 1: A sequence is being executed.

B5 - B0 = 1: You can set these general outputs to any logic level in immediate mode or under program control. *Outputs are labeled from 1 to 6. Zero (0) is not used.*

The outputs are initialized to a logic zero on power up. If the PLC is turned from RUN mode to PROGRAM mode or LOAD mode, all of the outputs will go to a logic one (1) and the execution of any commands will be disengaged. When the unit is returned to RUN mode, the outputs will be reset to a zero state.

8-Bit Inputs

The Model 301 Indexer card looks like an 8-bit output card to the Series One™ PLC. If the card is in the slot to the left of the Series One™ CPU, the eight inputs (which are outputs from the PLC) would have the address space from 00 to 07. The PLC output at address 00 is the B0 input bit to the indexer card and address 07 corresponds to B7. The input addresses that correspond to B0 - B4 are shown below.

| B4 | B3 | B2 | B1 | B0 |
|----|----|----|----|----|
| I5 | I4 | I3 | I2 | I1 |

You must use the command structure shown in Table 2-2 to issue commands to the indexer card. The most significant bit (MSB)—B7—is the command valid strobe line. When this line is toggled from low to high, the other 7 bits have valid data. The strobe line must stay high for at least 1 ms.

| COMMAND | B7 | B6 | B5 | B4 | B3 | B2 | B1 | B0 |
|----------------------|-------|----|----|----|----|----|----|----|
| XG# | 0 → 1 | 0 | A5 | A4 | A3 | A2 | A1 | A0 |
| KILL | 0 → 1 | 1 | 0 | 0 | 0 | 0 | 0 | 1 |
| KILL & RESET OUTPUTS | 0 → 1 | 1 | 0 | 1 | 0 | 0 | 0 | 1 |
| STOP | 0 → 1 | 1 | 0 | 0 | 0 | 0 | 1 | 0 |
| STOP & RESET OUTPUTS | 0 → 1 | 1 | 0 | 1 | 0 | 0 | 1 | 0 |
| HOME (+) | 0 → 1 | 1 | 0 | 0 | 0 | 1 | x | x |
| HOME (-) | 0 → 1 | 1 | 0 | 0 | 1 | 0 | x | x |
| PAUSE | 0 → 1 | 1 | 0 | 0 | 1 | 1 | 1 | 1 |
| RESUME | 0 → 1 | 1 | 0 | 0 | 1 | 1 | 0 | 0 |
| R | 0 → 1 | 1 | 0 | 1 | 1 | 0 | 0 | 0 |
| PR | 0 → 1 | 1 | 0 | 1 | 1 | 0 | 0 | 1 |
| PR | 0 → 1 | 1 | 0 | 1 | 1 | 0 | 1 | 0 |
| PR | 0 → 1 | 1 | 0 | 1 | 1 | 0 | 1 | 1 |
| RESET OUTPUTS | 0 → 1 | 1 | 0 | 1 | 0 | 0 | x | x |
| GENERAL INPUTS | x | 1 | 1 | I5 | I4 | I3 | I2 | I1 |

→ = logic transition x = don't care

Table 2-2. Input Bit Command Structure

The following section defines each of the commands shown in Table 2-2.

XG# This command executes a user program beginning from the sequence that you define (#0 - #63). The least six bits (A0 - A5) are the program sequence pointer.

The address lines have the following weights:

| A5 | A4 | A3 | A2 | A1 | A0 |
|----|----|----|----|----|----|
| 32 | 16 | 8 | 4 | 2 | 1 |

To run sequence #35; A0, A1, and A5 ($1 + 2 + 32 = 35$) must be active. If you instruct the indexer to execute a program that does not exist, it will respond with a question mark (?). Instructing the indexer to execute sequence 0 will run the first program in its memory.

KILL This command allows you to terminate an output pulse train immediately, with no deceleration.

KILL & RESET OUTPUTS This command allows you to terminate an output pulse train immediately (with no deceleration) and reset all six of the general programmable outputs to a logic low. Outputs are cleared at start of deceleration.

STOP This command allows you to decelerate the motor to a stop.

STOP & RESET OUTPUTS This command allows you to decelerate the motor to a stop and reset all six of the general programmable outputs to a logic low. Outputs are cleared at the start of deceleration.

HOME+ The Home+ command searches for the home switch in the CW direction. When the home switch for the axis goes low, the indexer searches for the CW edge of the home switch (see Figure 3-5).

HOME- The Home- command searches for the home switch in the CCW direction. When the home switch for the motor goes low, the indexer searches for the CW edge of the home switch (see Figure 3-5).

PAUSE This command allows you to interrupt program execution. Motion will be decelerated (the same as an S command).

RESUME The Resume command continues the execution of an interrupted sequence.

PR — POSITION REPORT This is a Position Report command. It provides axis encoder and motor position information. The information to be transmitted is selected by setting appropriate bits:

- B0 - Motor Position
- B1 - Encoder Position

If both positions are requested, motor position is sent first.

R — DISPLAY STATUS Report current indexer status over RS-232C port

RESET OUTPUTS This command allows you to reset all six of the general programmable outputs to a logic low.

GENERAL INPUTS

You can use these inputs as end-of-travel limits or for program conditional branching. Note that the I's are labeled from 1 to 5. Zero (Ø) is not used. Upon power up, the inputs are initialized low (logic Ø). Information from the PLC may be dynamically transmitted to the indexer card via the general inputs when B5 and B6 are both high (logic 1). If either B5 or B6 go low, the last state of the inputs are saved in the indexer card. The strobe line is not used to latch the state of these inputs.

When you switch the PLC from Run mode to the Program or Load modes, the general inputs are reset to logic Ø until the PLC re-programs a specific input.

Sample Program for 5-Slot Rack

If you use the Model 301 in a 5-slot rack, you can use the following program example. The program can be used with an input simulator, output module, the Model 301, and a PLC programmer. The program allows the Model 301 to control the output module's outputs or enables external devices to send commands to the Model 301 via the input module. The modules must be arranged in the rack as shown in Figure 2-6.




Figure 2-6. 5-Slot Rack Component Arrangement

Enter the following program with the PLC programmer. **Be sure the PLC's key is set to PROG.**

| Line | Program | Description |
|------|--------------------------------------|--|
| 1 | CLR, SHF, 348, DEL, NXT | Clears PLC memory |
| 2 | STR, SHF, 10, ENT, OUT, SHF, 30, ENT | Writing from input module to indexer module. The PLC reads the status of the input module and sends the command inputs to the Model 301. |
| 4 | STR, SHF, 11, ENT, OUT, SHF, 31, ENT | |
| 6 | STR, SHF, 12, ENT, OUT, SHF, 32, ENT | |
| 8 | STR, SHF, 13, ENT, OUT, SHF, 33, ENT | |
| 10 | STR, SHF, 14, ENT, OUT, SHF, 34, ENT | |
| 12 | STR, SHF, 15, ENT, OUT, SHF, 35, ENT | |
| 14 | STR, SHF, 16, ENT, OUT, SHF, 36, ENT | |
| 16 | STR, SHF, 17, ENT, OUT, SHF, 37, ENT | Writing from indexer module to output module. The PLC reads the Model 301's outputs and sets the appropriate outputs on the output module. |
| 18 | STR, SHF, 130, ENT, OUT, SHF, 0, ENT | |
| 20 | STR, SHF, 131, ENT, OUT, SHF, 1, ENT | |
| 22 | STR, SHF, 132, ENT, OUT, SHF, 2, ENT | |
| 24 | STR, SHF, 133, ENT, OUT, SHF, 3, ENT | |
| 26 | STR, SHF, 134, ENT, OUT, SHF, 4, ENT | |
| 28 | STR, SHF, 135, ENT, OUT, SHF, 5, ENT | |
| 30 | STR, SHF, 136, ENT, OUT, SHF, 6, ENT | |
| 32 | STR, SHF, 137, ENT, OUT, SHF, 7, ENT | |

Turning On Outputs

Turn the PLC's key to the RUN position.
 To turn on outputs 1, 3, and 5, enter: > **01Ø1Ø1Ø**
 To turn on outputs 2, 4, and 6, enter: > **ØØ1Ø1Ø1**

Controlling the Indexer With Remote Inputs

This exercise will teach you how to program and store motion sequences and activate the sequences from a remote input. **First, you must use the terminal to create the sequences. You should enter the boldface and underlined instructions.**

```

> FR00000000 (Turn off closed loop functions)
> CLR
* Are You Sure (Y/N)? Y
> EXR1
* (.1) 1: ...

Inserting Sequence 1

* 1: >A5 V5 D25000 G XT (Press Enter Key)
* >(Press Enter Key Again to Exit Edit Mode)
> EXR5
* (.1) 5: ...

Inserting Sequence 5

* 5: >A1 V1 D-25000 G XT (Press Enter Key)
* >(Press Enter Key Again to Exit Edit Mode)
> LST
1: A5 V5 D25000 G XT
5: A1 V1 D-25000 G XT
* 1259 BYTES FREE. *
> PZ Zero Position
> MPI Incremental move mode

```

The commands are described in detail below.

| <u>Command</u> | <u>Description</u> |
|----------------|---|
| > CLR | Clears the indexer's memory |
| > EXR1 | Begins definition of Sequence #1 |
| A5 | Sets acceleration to 5 rps ² |
| V5 | Sets velocity to 5 rps |
| D25000 | Sets distance to 25,000 steps |
| G | Executes the sequence |
| XT | Ends Sequence #1 definition |
| > EXR5 | Begins definition of Sequence #1 |
| A1 | Sets acceleration to 1 rps ² |
| V1 | Sets velocity to 1 rps |
| D-25000 | Sets distance to 25,000 steps |
| G | Executes the sequence |
| XT | Ends Sequence #5 definition |
| > LST | Lists current sequences #1 & #5 |
| > PZ | Sets the current position to zero |
| > MPI | Sets the indexer to Incremental mode |

We will now use the input simulator to execute these two sequences and to execute other commands. Refer to Table 2-2 for a complete list of the input bit command structure.

First, you will ensure that the motor is set to position 0. This should have been done with the Set Position Zero (PZ) command you issued earlier. Set the switches on the input simulator to the following settings to execute the Position Report (PR) command:

| | |
|----|---|
| B0 | 1 |
| B1 | 0 |
| B2 | 0 |
| B3 | 1 |
| B4 | 1 |
| B5 | 0 |
| B6 | 1 |
| B7 | 0 |

Toggle B7 input (turn the input on and then off). The screen should display the axis' motor position as +0. Now you can execute sequence #1. Remember the weights of the address lines:

| A5 | A4 | A3 | A2 | A1 | A0 |
|----|----|----|----|----|----|
| 32 | 16 | 8 | 4 | 2 | 1 |

Set the switches on the input simulator to the following settings to execute sequence #1 (XG1):

| | |
|----|---|
| B0 | 1 |
| B1 | 0 |
| B2 | 0 |
| B3 | 0 |
| B4 | 0 |
| B5 | 0 |
| B6 | 0 |
| B7 | 0 |

Toggle B7 input. The X axis should turn 25,000 steps in the **CW** direction when sequence #1 is run. Now you will check the axis' position again to determine if it made the move properly. Since it started at 0, it should be at position **25,000** now. Set the input simulator to the following settings to execute the Position Report (PR) command:

| | |
|----|---|
| B0 | 1 |
| B1 | 0 |
| B2 | 0 |
| B3 | 1 |
| B4 | 1 |
| B5 | 0 |
| B6 | 1 |
| B7 | 0 |

Toggle B7 input. The axis's position should be displayed on the screen as +25000 steps.

You will now execute sequence #5. Set the switches on the input simulator to the following settings to execute sequence #5 (XG5):

| | |
|----|---|
| B0 | 1 |
| B1 | 0 |
| B2 | 1 |
| B3 | 0 |
| B4 | 0 |
| B5 | 0 |
| B6 | 0 |
| B7 | 0 |

Toggle B7 input. Toggle Switch B7. The axis should turn 25,000 steps in the **CCW** direction when sequence #5 is executed. Now check the axis' position again. Since it moved 25,000 steps in the **CCW** direction, it should be at position 0 again. Set the input simulator to the following settings to execute the Position Report (PR) command:

| | |
|----|---|
| B0 | 1 |
| B1 | 0 |
| B2 | 0 |
| B3 | 1 |
| B4 | 1 |
| B5 | 0 |
| B6 | 1 |
| B7 | 0 |

Toggle B7 input. Axis X's position should be +0 steps. Enter the following commands through the terminal:

| <u>Command</u> | <u>Description</u> |
|----------------|-------------------------------------|
| > MC | Sets the indexer to Continuous mode |
| > G | Executes the move (Go) |

The axis should begin moving **CCW**. The indexer executes the command parameters that were last used—*sequence #5*. The motor continues to move beyond the -25,000 distance defined in *sequence #5* because you are operating in Continuous mode (the distance value has no meaning in this mode). To stop the axis, you will set the input simulator to perform the Stop (S) command, which will decelerate the motor to a stop. Set the input simulator as follows:

| | |
|----|---|
| B0 | 0 |
| B1 | 1 |
| B2 | 0 |
| B3 | 0 |
| B4 | 0 |
| B5 | 0 |
| B6 | 1 |
| B7 | 0 |

Toggle B7 input. Toggle Switch B7. The axis should stop. You can try other patterns with the input simulator. Refer to Table 2-2 for additional remote input commands.

Chapter 3. Installation

Chapter Objectives

The information in this chapter will enable you to:

- Insert the unit into the PLC properly
- Connect all electrical system inputs and outputs properly
- Ensure that the complete system is installed properly
- Perform basic system operations

Environmental Considerations

Parker Compumotor recommends that you operate and store your Model 301 under the following conditions:

- Ambient Operating Temperature: 32°F - 122°F (0°C - 50°C)
- Storage Temperature: -22°F - 185°F (-30°C - 85°C)
- Humidity: 0 to 95% non-condensing

The Model 301 is protected against short circuit and over temperature. Compumotor does not recommend that you test these features or operate your system in such a way as to induce short circuiting or overtemperature situations.

Complete System Configuration

Before you proceed with this section, you should have completed all of the steps and procedures contained in *Chapter 2, Getting Started*. You should already be familiar with the set-up procedures for communications, and power.

PLC Port Addressing

Each PLC port has a unique device address. The Model 301 will assume the device address of the port in which it is inserted. You can insert the Model 301 Indexer into any available port. Figure 3-1 shows the standard addresses given to PLC ports.

| | | | | | | |
|---------|------------------|------------------|------------------|------------------|-----|--------------|
| Outputs | 130-137 B0-B7 | 120-127 B0-B7 | 110-117 B0-B7 | 100-107 B0-B7 | CPU | Power Supply |
| Inputs | B0-B7 30-37 | B0-B7 20-27 | B0-B7 10-17 | B0-B7 00-07 | | |

Figure 3-1. PLC Port Addresses

Extended PLC Cages

- In a standard rack system, the jumper (refer to Figure 3-2) must be placed over pins **1 and 2**.
- In an extended PLC cage, the jumper (refer to Figure 3-2) must be placed over pins **2 and 3**.

If you intend to insert the Model 301 into a PLC with an extended cage, you must place the jumper on pins 2 and 3 of the indexer board before inserting the indexer into the port. Figure 3-2 shows the location the jumper. Push in the buttons at the top and bottom of the Model 301's front panel to remove the unit from the rack.




Figure 3-2. Location of Jumper for Standard Card Cage

**Indexer
Insertion**

After you have properly set the jumper (*if necessary*), you can insert the Model 301 Indexer into any available port of the PLC. You may now begin the system connections.

**System
Connections**

This section will help you properly wire the Model 301. Specifically, the following procedures and information will be addressed:

- Wiring Guidelines
- Establishing communications (RS-232C)
- Wiring the external 5VDC power supply
- Wiring the indexer to the drive




Figure 3-3. Complete Configuration

Wiring Guidelines

Proper grounding of electrical equipment is essential to ensure the safety of personnel. You can reduce the effects of electrical noise due to electromagnetic interference (EMI) by grounding. All Compumotor equipment should be properly grounded. A good source of information on grounding requirements is the National Electrical Code published by the National Fire Protection Association of Boston, MA.

For grounding follow PLC manufacturers recommendations.

Communications You can program the Model 301 with any ASCII device that communicates via standard RS-232C. The terminal's parameters for RS-232C communications should be:

- Baud Rate: 9,600 (fixed)
- Stop Bit: 1
- Data Bits: 8
- Echo: Off

The Model 301's echo function is always on. The 9-pin D connector on the Model 301's front panel provides the RS-232C connections. The pin out for this connector is defined in Table 3-1.

| Pin # | Function |
|-------|-------------------------------|
| Pin 1 | Not Used |
| Pin 2 | TXD, Transmit Signal |
| Pin 3 | RXD, Receive Signal |
| Pin 4 | DTR/CTS, Always set at +10VDC |
| Pin 5 | Signal Ground |
| Pin 6 | Not Used |
| Pin 7 | Signal Ground |
| Pin 8 | Not Used |
| Pin 9 | Not Used |

Table 3-1. RS-232C Pin-Out

Refer to *Chapter 2, Getting Started* for communications testing procedures that you can use to ensure proper operation.

External Power Supply

The indexer card is powered by the PLC's rack power supply. The indexer card uses a maximum of 150 mA of the PLC's +9V supply. This is equal to 15 units of load as described in the Series One™ Programmable Controllers Manual (distributed by GE/Fanuc).

To use the Model 301's inputs and outputs (on external connector), you must provide an external +5V power supply. Figure 3-3 illustrates the +5V wiring configuration.

Wiring the Indexer to the Drive

Connect the external power (EXT. V+), external ground (EXT. GND), and drive outputs as shown in Figure 3-3. **Compumotor recommends that you make multiple connections to a terminal block and a single connection to the Model 301.**

Verifying Proper Installation

You should have completely configured your system. This section will help you verify that you have wired the system properly and ensure that it is fully operational. You should have completed testing the RS-232C Communications already (the steps for this test were first discussed in *Chapter 2, Getting Started*).

Homing The Motor

You can initiate the Go Home function by issuing the Go Home (GH) command. When you issue the GH command, you must include the direction that the motor should use to search for home. The home limit input on the Model 301 is optically isolated, and is normally off. You must use a normally open, load-activated switch to ground to determine the home position.

When you command the motor to go home, it begins to move in the direction you specified. It performs this move at the last defined acceleration and velocity rates, and looks for the home limit input to go active. The indexer searches for home to the CW edge. The CW edge of the home switch is defined as the first switch transition that occurs if it is traveling in the CCW direction).

To test the Model 301's homing function, connect a N.O. switch between HOME and EXT GND. Enter the following command string.

| <u>Command</u> | <u>Description</u> |
|----------------|--|
| > GHV5 | Set go home velocity to 5 rps |
| > GHF .2 | Sets final go home velocity to 0.2 rps |
| > GE+ | Instructs the motor to go home in the CW direction |

The following events occur when you go home in the CW direction (refer to Figure 3-4):

1. The motor moves in the CW direction at 5 rps.
2. When the home switch is closed and opened, the motor decelerates to a stop, then moves in the CCW direction at the velocity you specified with the Go Home Final Speed (GHF) command.
3. Momentarily close the home switch again to stop the motor.

The following events occur when you go home in the CCW direction (refer to Figure 3-5):

1. The motor moves in the CCW direction until the home switch becomes active.
2. The motor decelerates to a stop and moves in the CW direction until the home switch becomes inactive.
3. The motor creeps to the CW edge of the switch at the velocity you set with the GHF command. The motor stops when the switch becomes active.




Figure 3-4. Homing Operation

Inputs & Outputs

This section discusses the Model 301's inputs and outputs.

Inputs

The Model 301 has eight inputs, five of which can be used for program control. *Chapter 2, Getting Started* contains a functional description of these inputs. General programmable inputs may be used for conditional branching. The inputs are labeled from 1 to 5 (Ø is not used). Upon power-up, the inputs are initialized to a logic zero state until the PLC reprograms an input specifically. Data from the PLC may be dynamically transmitted to the indexer card via the general inputs when B5 and B6 are both high (logic 1). If either B5 or B6 go low, the last state of the inputs are saved to the indexer card. The strobe line (B7) is not used to latch the state of these inputs. You can also set the state of the inputs with the **TEST** command through the RS-232C port.

Programmable Outputs

The Model 301 has eight output bits. The indexer card's outputs to the PLC are transmitted on the upper octal address (1XX addresses). If the card is in the slot to the left of the Series One™ CPU, the outputs from the indexer card (which are inputs to the PLC) will occupy addresses 100 to 107. Address 100 corresponds to BØ and address 107 is B7. *If you are using an extended rack system, the output bits are not usable.*

The PLC uses the most significant two bits of the outputs to determine indexer status (B6 & B7). **You cannot define or program these bits.** These two bits indicate whether the indexer is busy executing a user program (*Program Busy*), or whether it is currently sending out pulses (*Motor Busy*). The protocol of these outputs is shown below:

| Address | B7 | B6 | B5 | B4 | B3 | B2 | B1 | BØ |
|---------|------|--------|----|----|----|----|----|----|
| Status | Busy | P.Busy | O6 | O5 | O4 | O3 | O2 | O1 |

Chapter 4. Application Design

Chapter Objectives

The information in this chapter will enable you to:

- Recognize and understand important considerations that must be addressed before you implement your application
- Understand the capabilities of the system
- Use examples to help you develop your application

Motion Control Concepts

This section discusses basic motion control concepts that you should be familiar with as you develop your application.

Move Profiles

In any motion control application, the most important requirement is precise position, whether it be with respect to time or velocity. A motion profile represents the velocity of the motor during a period of time in which the motor changes position. The type of motion profile that you need depends upon the motion control requirement that you specify. The basic types of motion profiles are described below.

Triangular and Trapezoidal Profiles

For indexing systems, you must define velocity, acceleration, and distance parameters before the system can execute a preset move. The value of these parameters determines the motion profile as either triangular or trapezoidal. A triangular profile results when the velocity and acceleration are set such that the defined velocity is not attained before the motor travels half of the specified distance. This results from either a relatively low acceleration, a relatively high velocity, or both. A triangular profile is shown in Figure 4-1.




Figure 4-1. Triangular and Trapezoidal Profiles

A trapezoidal move profile results when the defined velocity is attained before the motor has moved half of the specified distance. A trapezoidal move may occur if you specify a low velocity with a high acceleration or a long distance. The resulting motion profile will resemble the profile shown in Figure 4-1.

Incremental vs. Absolute Positioning

A preset move is a move in which you specify the distance (in motor steps). You can select preset moves by putting the indexer into Normal mode (**MN** command). Preset moves allow you to position the motor in relation to the motor's previous stopped position (incremental moves) or in relation to a defined zero reference position (absolute moves). You can select incremental moves with the Mode Position Incremental (**MPI**) command. You can select absolute moves with the Mode Position Absolute (**MPA**) command.

Incremental Preset Mode Moves

When you are in the Incremental mode (**MPI**), a preset move moves the motor the specified distance from its starting position. You specify the direction with the optional (\pm) sign (**D+20000** or **D-10000**), or you can define it separately with the Set Direction (**H+** or **H-**) command.

| <u>Command</u> | <u>Description</u> |
|-----------------|---|
| > MPI | Sets unit to Incremental Position Mode |
| > A2 | Sets acceleration to 2 rps ² |
| > V5 | Sets velocity to 5 rps |
| > D25000 | Sets distance to 25,000 steps |
| > G | Executes the move (Go) |
| > G | Repeats the move (Go) |
| > H | Reverses direction of next move |
| > G | Executes the move (Go) |

Absolute Preset Mode Moves

A preset move in the Absolute mode (**MPA**) moves the motor the distance that you specify from the absolute zero position. You can set the absolute position to zero with the Position Zero (**PZ**) command, successfully completing a go home move, or by cycling the power to the drive.

The direction of an absolute preset move depends upon the motor position at the beginning of the move and the position you command it to move to. For example, if the motor is at absolute position +12,800, and you instruct the motor to move to position +5,000, the motor will move in the negative direction a distance of 7,800 steps to reach the absolute position of +5,000.

When you issue the Mode Position Absolute (**MPA**) command, it sets the mode to absolute. When you issue the Mode Position Incremental (**MPI**) command, the unit switches to Incremental mode. The indexer retains the absolute position, even while the unit is in Incremental mode. You can use the Position Report (**PRA**) or Status Request (**R**) commands to read the absolute position.

| <u>Command</u> | <u>Description</u> |
|-----------------|---|
| > MPA | Sets unit to Absolute Position mode |
| > A2 | Sets acceleration to 2 rps ² |
| > V10 | Sets velocity to 10 rps |
| > PZ | Sets the current position to zero |
| > D10000 | Sets position to 10,000 steps |
| > G | Executes the move (Go) |
| > D20000 | Sets position to 20,000 steps |
| > H | Reverses the position of next move to -20,000 steps |
| > G | Moves the motor to absolute position -20,000 (Go) |
| > D0 | Sets the move position to 0 |
| > G | Executes the move (Go) |
| > MPI | Sets indexer to Incremental Position mode |

Continuous Mode Moves

In the Continuous mode (**MC**), the motor will accelerate to its constant velocity when you issue a **G** (Go) command, the distance command is ignored. The motor will run at constant velocity until you issue a Stop or Kill command (a command that interrupts motion).

| <u>Command</u> | <u>Description</u> |
|----------------|--|
| > FSB0 | Sets unit to motor step mode |
| > MC | Sets unit to Continuous mode |
| > A10 | Sets acceleration to 10 rps ² |
| > V10 | Sets velocity to 10 rps |
| > G | Executes the move (Go) |

In the example above, the motor will ramp up to 10² rps and continue to run. You can command a new velocity while the motor is running with the following commands.

| <u>Command</u> | <u>Description</u> |
|----------------|------------------------|
| > V5 | Sets velocity to 5 rps |
| > G | Decelerates to 5 rps |

The motor will decelerate from 10 rps to 5 rps using the previously specified acceleration rate.

Modes Of Operation

This section discusses the three modes of operation that are applicable to the Model 301:

- Immediate RS-232C
- Interactive Editing
- PLC Operation

Immediate RS-232C Mode

The Model 301's RS-232C interface port allows you to send motion commands for immediate execution. You can also use this port to interactively edit motion programs and sequences that are stored in the Model 301's internal, nonvolatile memory. You can enter and edit sequences from any RS-232C terminal or computer.

Being able to execute commands as soon as they are received is especially useful during set-up and debugging when you are installing the system or if an application requires data from a remote computer or programmable controller. All commands are composed of simple ASCII characters.

In Immediate mode, the indexer responds with a prompt (>) when it receives a valid command and a question mark (?) when it receives an invalid command. If you enter a valid command, but enter an invalid range (e.g., **A20**), the Model 301 will respond with a question mark (?). The interactive responses are preceded with a carriage return and a line feed.

In Interactive Edit mode, the Model 301 does not check syntax, command validity, or ranges. You must **execute** a defined sequence to determine if it is interpreted properly. Use the Trace (**XTR**) command to see where question mark (?) appears to find invalid commands.

Sending Characters

When the Model 301 is connected to a terminal, and you issue a carriage return <cr>, a prompt will be provided (>). The Model 301 is now ready to receive commands. The following commands demonstrate what you would type to perform an incremental move.

| <u>Command</u> | <u>Description</u> |
|----------------|--|
| > MPI | Sets unit to Incremental mode |
| > A10 | Sets acceleration to 10 rps ² |
| > V1 | Sets velocity to 1 rps |
| > D25000 | Sets distance to 25,000 steps |
| > G | Executes the move (Go) |

All commands listed in *Chapter 5, Software Reference* that are categorized as immediate can be executed in this fashion.

Requesting Status

There are several commands that you can use to request status information from the Model 301's RS-232C port. You can also obtain this information from a terminal or computer and use the data to debug the system. One example of such a command is the Status Report (R) command. A sample response from the R command is shown below.

```
*DYNAMIC DATA
* INPUT BYTE (B7 - B0) = 00000110
* OUTPUT BYTE (B7 - B0) = 00000000
* HOME: = 1
*REGISTERED DATA
* Inputs: I1=0 I2=0 I3=0 I4=0 I5=0
* Outputs: O1=0 O2=0 O3=0 O4=0 O5=0 O6=0
* Motor Position =+0
* Encoder Position =+0
*ACTIVE PARAMETERS:
* MR25000 GHV 1 GHF 0.1
* FR01100000
* ER 4000 DB5 DW250 CG8
* VS0 V0 A0
* MPI D+0 T0.5 L0
```

Refer to Chapter 5, Software Reference for more information on status commands (i.e., PRA, PRX, PX, and FR).

Interactive Edit Mode

You can also use the Model 301's RS-232C interface to enter and edit sequences. A sequence consists of several Model 301 commands. You should be sure to enter the commands in the order that you intend them to be executed. When the sequence is run, the system executes the commands in exactly the order that they appear in the sequence.

You can store up to 63 sequences in the Model 301's battery-backed RAM memory. There is no limit to the size of each sequence as long as the combined total of all sequences does not exceed the available memory. All stored sequences do not have to be the same size (e.g., two 50-byte sequences and four 250-byte sequences). For applications that require additional memory storage capacity, the Model 301-M offers 8K of battery-backed RAM memory.

To begin entering a sequence, you must issue the Edit Sequence (EXR) command. At the prompt, enter EXR followed by the sequence # that you want to create. Refer to the following example. The commands that you enter are shown in **boldface** and underlined. The interactive responses from the system are shown in plain type.

```

> EXR10
*(.1) 10:...
Inserting Sequence 10
*.10 >A10
* >V10
* >D250000
* >G
* >XT
>

```

At this point, you can begin to enter the commands for sequence #10. Notice that the Model 301 prompts you with an asterisk (*) and a bracket (>) in the Interactive Edit mode. To exit the Edit mode press the carriage return key on an empty line [cr] or press the [esc] key.

Within the Interactive Edit mode, there are two editing sub-modes:

- Fill mode
- Edit mode

Fill Mode

This mode is used when no sequence exists—you are creating the sequence. You can *fill* line after line, just as in the example above

Edit Mode

You will automatically enter this mode whenever you edit an existing sequence. The sequence and its line numbers will be displayed. You must use the line-editor commands that allow you to insert, edit, or delete a line.

The following example demonstrates how to edit an existing sequence. When you issue the **EXR** command, the Model 301 lists the sequence along with the line numbers. You may now edit (**E**), insert (**I**), or delete(**D**).

```

> EXR10
*(.1) 10: A10
*(.2)      V10
*(.3)      D250000
*(.4)      G
*(.5)      XT

Editing Sequence 10
* >

```

Edit a Line

To edit a line, enter **E** . followed by the line number that you want to modify.

```

* >E.3
*(.3) D250000
* >> >D500000

```

The Model 301 lists the line to be edited directly above the asterisk prompt. This allows you to see what is currently stored in the line as you prepare to edit it. To edit a line, you must re-enter the entire line (including the change you want to make). When the entire line is re-written press the return key. The Model 301 will automatically re-list the entire sequence so that you can review the changes.

```

* (.1) 10: A10
* (.2)      V10
* (.3)      D500000
* (.4)      G
* (.5)      XT

Editing Sequence 10
* >

```

- Exiting Edit Mode** If you press the Enter key while the cursor is on a blank line, the currently stored line will remain unchanged. You can press the Escape <ESC> key at any time to abort the editing session without changing the current line.
- You can also exit the Edit mode by typing **Q** (Quit Editing Mode) on a blank line and pressing the Return key or by pressing the return on a blank line.
- Listing Sequences** You can list sequences with the **LST** command. This command lets you list the entire contents of memory, specified sequences, or ranges of sequences.
- LST** This command lists the entire nonvolatile sequence memory.
- LSTnn** This command allows you to list the designated sequence.
- LSTnn-*nnn*** This command allows you to list all sequences within a specified block (e.g., 15 - 30).
- LSTnn-** This command allows you to list all sequences from a specified sequence to the end of the program.
- LST-*nn*** This command allows you to list all sequences from the beginning of the program to a specified sequence of the program.
- When you list multiple sequences or enter **LST63** the number of bytes of program memory that are available will be displayed after the contents of the sequences are displayed.
- Inserting and Deleting Lines** When you are in the Edit mode, you can insert and delete lines in a sequence. To insert a line, type the **I** command followed by the line number that follows the point where you want to insert a new line. For example, if you wanted to insert a line between lines #3 and #4, you would specify line #4 as the point of insertion. Refer to the following example.

```
> EXR10
* (.1) 10: A10
* (.2)   V10
* (.3)   D25000
* (.4)   G
* (.5)   XT

Editing Sequence 10

* >I.4
* (.4) Inserting
* >> >H+

* (.1) 10: A10
* (.2)   V10
* (.3)   D50000
* (.4)   H+
* (.5)   G
* (.6)   XT

Editing Sequence 10
* >D.4
* (.4) H+ Deleted

* (.1) 10: A10
* (.2)   V10
* (.3)   D50000
* (.4)   G
* (.5)   XT

> Editing Sequence 10
* >
```


Deleting A Sequence

If you want to delete an entire sequence from memory, use the following steps.

1. Enter the Edit Sequence (**EXRnn**) command.
2. At the edit prompt (*** >**), type **D** and press the carriage return key.
3. The system will ask you to verify your request before the sequence is deleted.

```
* >D
Are You Sure (Y/N)? Y
Sequence nn Deleted
```

nn refers to the sequence # to be deleted

Clearing Memory

Occasionally, you may want to clear the entire contents of the battery-backed RAM memory. To do this, use the Clear (**CLR**) command. The system will ask you to verify your request to clear the memory before performing the task. Refer to the example below.

```
> CLR
Are You Sure (Y/N)? N (Enter Y to clear)
>
```

PLC Operation

The Model 301 also communicates with the PLC processor (GE Fanuc One™ and TI Series 305™) over the backplane communication bus. The PLC program can instruct the Model 301 to execute a pre-programmed sequence, monitor the status of the indexer, and synchronize the motion program with the rest of the machine it is controlling. (Table 2-2 contains a list of PLC backplane commands.)

Program Design

This section discusses the basic elements and issues of program design for the Model 301. The issues addressed are:

- Sequences
- Trigger Inputs
- Programmable Outputs
- Time Delays
- Branching
- Limits

Sequences

Sequences are the building blocks of motion programs in the Model 301. You can store up to 63 individual sequences in the indexer's nonvolatile battery-backed RAM. A sequences can be as small as a single command or as large as the available memory.

Sequences can also be thought of as subroutines within a larger program. A sequence is a list of commands that are executed one at a time when you run the sequence.

The Model 301 has commands that allow you to branch to sequences based on conditions within a sequence. The indexer also provides the ability to **GOTO** a different sequence, or **GOSUB** to another sequence, returning to the original point after execution is complete. Refer to *Chapter 5, Software Reference* for detailed descriptions of the following commands.

| Sequence Programming/Editing Commands | |
|---------------------------------------|------------------|
| EXR | Edit a sequence |
| I | Insert a line |
| E | Edit a line |
| D | Delete a line |
| Q | Quit Edit mode |
| LST | List sequence(s) |
| CLR | Clear memory |

| Sequence Execution Commands | |
|-----------------------------|---|
| XR | Runs a sequence. When used within a sequence, it jumps to execute another sequence, then returns to the original point, like a GOSUB command. |
| XG | Exits the current sequence and executes the specified sequence, like a GOTO command. |

| Sequence Debugging Commands | |
|-----------------------------|--|
| XTR | Enables/Disables the Sequence Trace mode |
| TEST | Simulates the PLC inputs |
| R | Provides a status report of the indexer |

| Special Sequence Commands | |
|---------------------------|-----------------------------------|
| XT | Ends the definition of a sequence |

A sequence is a series of commands. These commands are executed in the order in which they are programmed (entered). Refer to the *Interactive Edit Mode* section earlier in this chapter for an explanation of how to enter and edit sequences. Two examples sequences are shown below.

| Command | Description |
|-----------|--|
| > LST1-2 | Lists sequences 1 & 2 |
| 1: A1Ø | Sets acceleration to 10 rps ² |
| V1Ø | Sets velocity to 10 rps |
| D25ØØØ | Sets the distance to 25,000 distance |
| G | Executes the move (Go) |
| 2: D5ØØØØ | Sets the distance to 50,000 distance |
| H- | Sets axis to the CCW direction |
| G | Executes the move (Go) |
| XT | Ends the sequence |

The commands that you enter to define a sequence are presented vertically in the previous example above. This was done to provide descriptions of each command. You can actually enter as many commands as you wish on each line, separated by a space:

```
> LST1-2
  1: A1Ø V1Ø D25ØØØ G
  2: D5ØØØØ H- G XT
```

In the two example sequences, only sequence #2 has an XT command at the end. In this example, if you execute sequence #1, the Model 301 will execute sequence #2 after sequence #1 is completed. If you execute only sequence #2, the indexer will stop after the sequence is completed.

Trigger Inputs

The Model 301 has 5 trigger inputs that are controlled by the host PLC. To recognize trigger inputs, the eight inputs from the PLC bus must be set by the PLC program as follows.

| B7 | B6 | B5 | B4 | B3 | B2 | B1 | BØ |
|----|----|----|----|----|----|----|----|
| X | 1 | 1 | I5 | I4 | I3 | I2 | I1 |

X = Don't Care

Bits #5 & #6 must be ON for the Model 301 to recognize bits Ø - 4 as trigger inputs 1 - 5 respectively.

You can use the Trigger (**TR**) command to instruct your program to wait for the correct combination of inputs to be turned on before it proceeds with the next command. This is one way in which you can synchronize the Model 301's motion program with the PLC program. Refer to the following example.

| <u>Command</u> | <u>Description</u> |
|----------------|--|
| > A10 | Sets acceleration to 10 rps ² |
| > V10 | Sets velocity to 10 rps |
| > D25000 | Sets the distance to 25,000 steps |
| > TR00001 | The move cannot be made until inputs #1 - #4 are off, and #5 is on |
| > G | Executes the move (Go) |

Programmable Outputs

The Model 301 has eight programmable outputs to the PLC bus. Two are dedicated — Busy and Program Busy. With the Output (**O**) command, you can use the Model 301 to turn the other six general programmable outputs on and off within a sequence. The **O** command signals the PLC when some part of your motion program is or has been executed.

| <u>Command</u> | <u>Description</u> |
|----------------|--|
| > MN | Sets indexer to normal preset mode |
| > A10 | Sets acceleration to 10 rps ² |
| > V10 | Sets velocity to 10 rps |
| > D25000 | Sets distance to 25,000 steps |
| > TR00001 | The move cannot be made until inputs #1 - #4 are off, and #5 is on |
| > O10000 | Turns output #1 on |
| > G | Executes the move (Go) |

Time Delays

You can use the Time (**T**) command to delay execution of a sequence for a preset period of time.

| <u>Command</u> | <u>Description</u> |
|------------------|------------------------------------|
| > MN | Sets indexer to normal preset mode |
| > A10 V10 D25000 | Sets the move parameters |
| > G | Executes the move (Go) |
| > T10 | Sets a time delay of 10 seconds |
| > G | Executes the move (Go) |
| > XT | Ends the sequence |

Branching

You can use the Conditional If (**IF**) command for conditional branching within a program. This command tests the input conditions. If the condition is true, all commands that follow the **IF** statement are executed. If the conditions are not true, the Model 301 will skip all of the commands associated with the condition, until it reaches an End of If Statement (**NIF**) command.

You can use the Conditional If statement in conjunction with the **XG** (GOTO sequence) and the **XR** (GOSUB) sequence commands for flexible program development.

Limits

The Model 301 does not have dedicated limit inputs. These can be implemented by using a separate input card and moving the input status to the Model 301 input data registers. The Model 301 can act upon the inputs using the **IF (IXXXX) . . . NIF** procedure or activating the Stop-on-input3 (**FSF1**) feature.

Chapter 5. Software Reference

Chapter Objectives

The information in this chapter will enable you to:

- Identify the five types of commands in Compumotor's X-Series Language
- Use this chapter as a reference for the function, range, default, and sample use of each command

Description of Format

| | | | | |
|---------------------------------------|-----------------------------|----------------------------------|--------------------------|---|
| ① PRA ② Status | ③ Position Request | | | ④ VALID Software Version A |
| ⑤ SYNTAX PRA | ⑥ UNITS X = steps | ⑦ RANGE None | ⑧ DEFAULT None | ⑨ ATTRIBUTES Sequence/Immediate |
| ⑩ EXECUTION TIME <10 ms | | ⑪ SEE ALSO PZ, SP, R, PRX | | |
| ⑫ RESPONSE TO PRA IS See Below | | | | |

1. **Mnemonic Code** This box contains the command's mnemonic code and the command type. The command types are described below.
 - Edit** You can use edit commands to create or modify sequences.
 - Motion** Motion commands affect motor motion (i.e., accelerate, velocity, distance, go home, stop, direction, mode, etc.).
 - Programming** Programming commands affect programming and program flow. For example, output, all sequence commands, time delays, loop and end loop, and triggers.
 - Set-Up** Set-up commands define set-up conditions for the application. Set-up commands include the following types of commands:
 - **FSA, FSB**, etc.
 - Status** Status commands respond (report back) with information.
3. **Full Name** This field contains the full command name.

4. **Valid Revision Level** This field contains the revision history of the command. It includes the revision of software when the command was added or modified. If the revision level of the software you are using is equal to or greater than the revision level listed in this field, your software will contain the commands as described.
5. **Syntax** The proper syntax for the command is shown here. The specific parameters associated with the command are also shown. Definitions of the parameters are described below.
- n This represents an integer. You may use an integer to specify a variety of values (acceleration, velocity, etc.).
 - s This represents a sign character (+ or -). This variable allows you to specify direction (CCW or CW) or a positive or negative value.
6. **Units** This field describes what unit of measurement the parameter is using.
7. **Range** This is the range of valid values that you can specify for n (or any other parameter specified).
8. **Default** The default setting for the command is shown in this box. A command will perform its function with the default setting if you do not provide a value.
9. **Attributes** This box indicates if the command is **immediate**, **sequence** or **sequence/immediate**. The system executes immediate commands as soon as it receives them. You will enter **immediate** commands via an RS-232C terminal (you must enter a carriage return after these commands to execute them). With the Model 301, sequence commands are only executable in a sequence, and in the order that they are received.
- Commands that are classified as **sequence** can only be executed in a sequence. Commands that are classified as **sequence/immediate** may be executed in the Immediate mode as well as within sequences.
10. **Execution Time** The execution time is the span of time that passes from the moment you issue a command to the moment the system begins to execute it.
11. **See Also** Commands that are related or similar to the command described are listed here.
12. **Response** A sample status command is given (next to **RESPONSE TO**) and the system response is shown. **This box will only be provided if the system provides a response to the command. If no response is provided, this box will not be included with the description.**

Special Commands

You can use the following special commands with the Model 301.

| | | | | |
|------------------------------|----------------------|----------------------|------------------------|------------------------------------|
| ESC Edit/Motion | ESC Key | | | VALID Software Version A |
| SYNTAX e | UNITS None | RANGE None | DEFAULT None | ATTRIBUTES Immediate |
| EXECUTION TIME <10 ms | | SEE ALSO S, K | | |

Description The ESC (escape) key terminates motion. During a move, this key will terminate motion. The user program, in addition to the motion, is terminated with the ESC key.

If you press the ESC key while you are editing a program, you will exit from the Edit mode without changing the current line. If you press the ESC key two times, the terminal screen will clear (VT100 must be emulated).

| | | | | |
|------------------------------|---------------------------|---------------------------------|------------------------|------------------------------------|
| @ Edit | Comments Delimiter | | | VALID Software Version A |
| SYNTAX e | UNITS None | RANGE None | DEFAULT None | ATTRIBUTES Sequence |
| EXECUTION TIME <10 ms | | SEE ALSO D, E, EXR, I, Q | | |

Description When you edit a program in the Edit mode, you may place comments on any line after you enter the @ delimiter. Comments can be useful when you need to briefly describe the procedure that a statement line will perform.

Example

```
L
IF(I00XXX) XR5 NIF @ Run Set-Up
IF(I01XXX) XR10 NIF @ Index 1
IF(I10XXX) XR15 NIF @ Index 2
IF(I11XXX) XR20 NIF @ Go-Home
N
```

General Command Listing

| | | | | |
|------------------------------|--------------------------------------|--------------------------------|--|---|
| A Motion | Set Acceleration | | | VALID Software Version A |
| SYNTAX Annn.nn | UNITS n = rps ² | RANGE 0.03 to 999.99 | DEFAULT 0 (motor dependent) | ATTRIBUTES Sequence/Immediate |
| EXECUTION TIME <10 ms | | SEE ALSO D, V, G, R | | |

Description The Acceleration command specifies the acceleration rate to be used upon executing the next Go (G) command. The acceleration remains set until you change it. You do not need to reissue this command for subsequent G commands. If you enter an acceleration rate that is outside the valid range, the indexer will maintain the previous valid setting.

| | | |
|----------------|--|---|
| Example | <u>Command</u> > MN > A5 > V10 > D10000 > G | <u>Description</u> Sets the moves to mode normal (preset moves) Sets acceleration to 5 rps ² Sets velocity to 10 rps Sets distance to 10,000 steps Executes the move (Go) |
|----------------|--|---|

| | | | | |
|-----------------------------|--|---------------------------------|---|---|
| CG Set-Up | Correction Gain | | | VALID Software Version A |
| SYNTAX <a>CGn | UNITS n = amount of error to correct | RANGE 1-8 | DEFAULT saved in non-volatile RAM | ATTRIBUTES Sequence/Immediate |
| EXECUTION TIME <10ms | | SEE ALSO FSB, FSC, DB, R | | |

Description This command allows you to set the amount of error (steps) that should be corrected on the initial position maintenance (FSC1) command correction move (which takes place whenever the motor is stationary and outside the dead-band [DB] region).

The percentage of error that the Position Maintenance function will attempt to correct on its correction moves is $n/8 \cdot 100\%$. If you set n to 1, the system will correct the error slowly (1/8 of the error is corrected on the first try). This type of correction is performed smoothly. If you set n to 8, the system will correct the error faster. However, there may be more overshoot and ringing at the end of this type of correction move.

| | | |
|----------------|-----------------------|--|
| Example | <u>Command</u> CG3 | <u>Description</u> The system corrects 3/8 of the final-position error on the initial correction move |
|----------------|-----------------------|--|

| | | | | |
|------------------------------|-----------------------------|-----------------------------------|------------------------|------------------------------------|
| CLR Edit | Clear Entire Program | | | VALID Software Version A |
| SYNTAX CLR | UNITS None | RANGE None | DEFAULT None | ATTRIBUTES Immediate |
| EXECUTION TIME <10 ms | | SEE ALSO D, E, EXR, I, LST | | |

Description This command clears (erases) the entire user program. The Model 301 will prompt you to enter **Y** or **N** to verify your intentions before it erases the memory. You can use the Delete (**D**) command to delete individual sequences.

| | | | | |
|------------------------------|-------------------------------------|---|---------------------|---|
| D Motion | Set Direction & Distance | | | VALID Software Version A |
| SYNTAX D±nnnnnnnn | UNITS n = steps | RANGE ±99,999,999 | DEFAULT 0 | ATTRIBUTES Sequence/Immediate |
| EXECUTION TIME <10 ms | | SEE ALSO A, G, V, MN, MPA, MPI, SP, FSB, R | | |

Description The Distance (**D**) command defines either the number of steps the motor will move or the absolute position it will seek after you enter a Go (**G**) command. In Incremental mode (**MPI**), the value set with the **D** command will be the distance (in steps) that the motor will travel on all subsequent **G** commands.

In Absolute mode (**MPA**), the distance that the motor moves is the difference between the current position and the zero position. The **D** command does not affect continuous mode moves (**MC**). The **D** command specifies either motor steps or encoder steps, depending on the mode (**FSB**).

| | | |
|-------------------|----------------|---|
| Example #1 | <u>Command</u> | <u>Description</u> |
| | MN | Sets unit to Normal mode (preset) |
| | A 5 | Sets acceleration to 5 rps ² |
| | V 10 | Sets velocity to 10 rps |
| | D 50000 | Sets distance to 50,000 steps |
| | G | Executes the move (Go) |
| | G | Executes the move, moves another 50,000 steps |

| | | |
|-------------------|----------------|---|
| Example #2 | <u>Command</u> | <u>Description</u> |
| | MPA | Sets unit to Absolute Position mode |
| | P Z | Sets current axis position as zero |
| | A 5 | Sets acceleration to 5 rps ² |
| | V 5 | Sets velocity to 5 rps |
| | D 50000 | Sets distance to 50,000 steps |
| | G | Executes the move (Go) |
| | G | No motion , because the axis has already traveled the 50,000 steps commanded with the 1st Go command |

| | | | | |
|------------------------------|------------------------------------|---------------------------------|------------------------|------------------------------------|
| D Edit | Delete | | | VALID Software Version A |
| SYNTAX D.nnn | UNITS n = line number | RANGE 1 - 999 | DEFAULT None | ATTRIBUTES Immediate |
| EXECUTION TIME <10 ms | | SEE ALSO E, EXR, I, Q, @ | | |

Description

In the Edit mode, the D command lets you delete an entire sequence. You can also use a variation of this command (D.nnn) to delete one line in a sequence. The stored sequence is:

```
10: V5 A5 D50000
    O111111
    G
    T2 O11111Ø
    XT
```

You can enter the Edit mode for sequence #10 with the following command:

```
> EXR10<cr>
```

Sequence #10 will be listed.

```
*(.1) 10: V5 A5 D50000
*(.2)      O111111
*(.3)      G
*(.4)      T2 O11111Ø
*(.5)      XT
Editing Sequence 10
```

To delete just one *line* in the sequence, you can use the D.nnn command in the manner shown below. This command will remove the third line from the sequence.

```
* D.3<cr>
```

The Model 301 will respond with the following prompt:

```
*(.3)      G.. Deleted
*(.1) 10: V5 A5 D50000
*(.2)      O111111
*(.3)      T2 O11111Ø
*(.4)      XT
Editing Sequence 10
```

To delete the *entire* sequence, you can use the D<cr> command. The following prompt will appear:

```
Are you sure (Y/N) Enter Y
Sequence 1Ø.. DELETED
```

| | | | | |
|------------------------------|------------------------------------|-------------------------------|--|---|
| DB Set-Up | Deadband | | | VALID Software Version A |
| SYNTAX <a>DBn | UNITS n = motor steps | RANGE n 0 - 999,999 | DEFAULT saved in non-volatile RAM | ATTRIBUTES Immediate/ Sequence |
| EXECUTION TIME < 10ms | | SEE ALSO FS, CG, R, DW | | |

Description This command specifies a positioning range (in encoder steps) that the motor may not exceed after completing a move. If the motor's position is closer to the desired position than the number specified, no position maintenance correction will be performed. If the motor's position is not within the allowable range, position maintenance is performed (if enabled by the Enable Position Maintenance (FSC1) command). The purpose of the DB command is to prevent the motor from searching for a set position when it is within an allowable dead band range.

Example

| | |
|----------------|--|
| <u>Command</u> | <u>Description</u> |
| DB100 | Sets Position Maintenance to activate if the motor's end-of-move position is off by more than 100 encoder steps. |

| | | | | |
|-------------------------------|---|---|--------------------------|------------------------------------|
| DLY Motion | Delay Before Changing Output or Velocity | | | VALID Software Version A |
| SYNTAX DLYnnnnnnnn | UNITS n = motor steps | RANGE 0 - 99,999,999 0,1, or X | DEFAULT 0 0 | ATTRIBUTES Sequence |
| EXECUTION TIME < 10 ms | | SEE ALSO G, T | | |

Description The DLY command delays program execution based on position counts that you specify. A DLY command must follow a G command in a sequence. The number of steps that you specify as the DLY variable represents the count of relative steps (from the initiation of the previous Go command) that program execution will be delayed. This command is similar to the Time Delay (T) command, except that the T command delays execution according to a specified time. *This command only works in Continuous mode.*

| | | |
|---|----------------|---|
| Changing Velocity After Position Delay | <u>Command</u> | <u>Description</u> |
| | 5: A50 V1 MC G | Begins continuous move at 1 rps |
| | DLY100000 V3 G | Ramps motor to 3 rps after 100,000 steps |
| | DLY100000 V5 G | Ramps motor to 5 rps after 100,000 more steps |
| | DLY100000 S | Stops the motor after 100,000 more steps |
| | XT | End sequence |

| | | |
|--|---------------------|---|
| Changing Outputs After Position Delay | <u>Command</u> | <u>Description</u> |
| | 6: A50 V1 MC G | Begins continuous move at 1 rps |
| | DLY100000 0111000 G | Ramps motor to 3 rps after 100,000 steps |
| | DLY100000 000111 G | Ramps motor to 5 rps after 100,000 more steps |
| | DLY100000 S | Stops the motor after 100,000 more steps |
| | XT | End sequence |

| | | | | |
|-----------------------------|---------------------------------|------------------------------------|---|--|
| DW Set-Up | Deadband Window | | | VALID Software Version A |
| SYNTAX <a>DWn | UNITS n = motor steps | RANGE 0 - 999,999 | DEFAULT saved in non-volatile RAM | ATTRIBUTES Buffered Savable in Sequence |
| EXECUTION TIME <10ms | | SEE ALSO FS commands, R, DB | | |

Description This command allows precise deadband specification in motor pulses. The backlash deadband allows systems with backlash to use stall detect features. Stall detection will not occur until the error exceeds the deadband window.

Compumotor recommends a DW value of 250 if you are using a Motor Resolution (MR) of 25,000 and an Encoder Resolution(ER) of 4,000. If using low acceleration values this value may be reduced. There will always be some lag between the motor steps sent out and encoder steps received. This value should never be zero.

If you set DW to 50 a position maintenance move of less than 50 steps the Model 301 will not be able to detect a stall

Example

| | |
|-------------------------|---|
| <u>Command</u> DW100 | <u>Description</u> 100 motor steps of Backlash are expected by the indexer. A stall will not be detected until the encoder lags the motor position by more than 100 motor steps. |
|-------------------------|---|

| | | | | |
|------------------------------|-----------------------------------|------------------------------|------------------------|------------------------------------|
| E Edit | Edit a Line in a Sequence | | | VALID Software Version A |
| SYNTAX E.nnn | UNITS nnn = line number | RANGE 1 - 999 | DEFAULT None | ATTRIBUTES Immediate |
| EXECUTION TIME <10 ms | | SEE ALSO D, EXR, I, Q | | |

Description This command allows you to edit a single line within a sequence. The value that you specify with the E.nn command is the nth line counted from the beginning of that block. You can only use this command in the Edit mode. After you edit the line, enter a carriage return <cr> to mark the end of the line. The entire block is rewritten to include the change. You will be prompted to enter your next Edit mode command by an asterisk (*).

To exit the Edit mode, you must enter Q (Quit Edit Mode) and press the carriage return <cr>. This keystroke combination terminates the editing session. You may also press <cr> on an empty line or the ESC key while you are in the Edit mode to terminate an editing session. Pressing the return key on an empty line also exits the Edit mode.

| | | | | |
|-----------------------------|--|---------------------------|--|---|
| ER Set-Up | Encoder Resolution | | | VALID Software Version A |
| SYNTAX <a>ERn | UNITS n = post- quadrature encoder steps | RANGE 1 - 5000 | DEFAULT saved in non-volatile RAM | ATTRIBUTES Immediate/ Sequence |
| EXECUTION TIME <10ms | | SEE ALSO FS, DW, R | | |

Description The encoder resolution defines the number of encoder steps the indexer will see per revolution (or per inch for linear motors) of the motor. The number of lines on an encoder should be multiplied by 4 to arrive at the correct ER value per revolution (per inch) of the motor .

In other words one line of an encoder will product 4 encoder steps.

NOTE: A 4:1 ratio of motor steps to encoder steps or a 16:1 ratio of motor step: encoder lines is proper closed loop operation. If a lower ratio is used it may be difficult to tune the position maintenance (Servoing) feature of your indexer.

Example Command Description
ER4000 (Encoder resolution is set to 4000 steps per motor revolution)

| | | | | |
|------------------------------|-----------------------------------|---|------------------------|------------------------------------|
| EXR Edit | Edit Sequence in a Program | | | VALID Software Version A |
| SYNTAX EXRnn | UNITS n = sequence # | RANGE 1 - 63 | DEFAULT None | ATTRIBUTES Immediate |
| EXECUTION TIME <10 ms | | SEE ALSO D, E, I, Q, XG, XR, XT, @ | | |

Description This command enables you to edit an existing sequence of commands or write a new sequence of commands into the user program. A sequence may contain many single-line commands. An asterisk (*) will appear before the command line prompt when you are in Edit mode.

If you specify a new sequence, enter the commands after the indented prompt appears. If you specify an existing sequence, the sequence is listed and you may only enter line-edit commands. Line-edit commands are E.nn, I.nn, and D.nn, which you may use to create, insert, or delete single lines within an existing block.

A single line may not exceed 40 characters. You must use the ENTER key or <cr> (carriage return) to terminate the line. The number of lines within a program block is limited only by the size of the nonvolatile memory.

To exit the Edit mode, enter Q (Quit Edit Mode) and press the carriage return <cr>. You may also press <cr> on an empty line or the ESC key to end an editing session.

If you do not complete the edited sequence with an End Sequence (XT) command, the sequence that follows the edited sequence in the program's memory will be executed when you run the edited sequence. Sequence numbers can serve as labels for subroutines or branches. Refer to the following example.

```

Ø5: A5 V5 D25000
    G
    T2
Ø6: A10 V2 D5000
    G
    XT
    
```

When sequence #6 is called, a move of 5,000 steps will be performed. When sequence #5 is called, a move of 25,000 steps will be executed, followed by a wait (delay) of two seconds. After the two seconds have elapsed, the 5,000-step move of sequence #6 will be executed.

| | | | | |
|---|------------------------------------|--|--|---|
| FR Status/ Set-Up | Report/Change Set-Up Status | | | VALID Software Version A |
| SYNTAX <a>FRn | UNITS n = status | RANGE 0, 1 | DEFAULT Saved in non-volatile RAM | ATTRIBUTES Immediate/ Sequence |
| EXECUTION TIME <10ms | | SEE ALSO FS commands, R, MPI, MPA | | |
| RESPONSE TO aFR IS aFR nnnnnnnn | | | | |

Description

This command allows you to request the status of functions set by FS commands. The response contains one ASCII digit per function set by the FS command, each of which is a zero or a one. The digits correspond to the functions, left to right, A through H. The digit 1 corresponds to a function that is on. A Ø corresponds to an FS command that is off. The command can also be used to modify the FS set-up commands (See Example).

- A Incremental = OFF (Ø), Absolute = ON (1):Defines the move distance (D) as either incremental from current position, or as absolute (referenced to the absolute zero position).
- B Motor step mode = OFF (Ø)/Encoder step mode = ON (1):Defines the distance (D) parameter in units of motor steps or encoder steps
- C Position Maintenance Ø = OFF, 1 = ON:Enables position maintenance. This will cause the indexer to servo the motor to the desired position if not in the correct position at the end of a move, or, if the motor is forced out of position while at rest.
- D Terminate move on Stall Detect Ø = OFF, 1 = ON:Instructs the indexer to abort any move if a stall is detected.

- E Turn on Output #1 on Stall Detect \emptyset = OFF, 1 = ON: Instructs the indexer to set output #1 on if a stall is detected.
- F Terminate move if Input 3 is active \emptyset = OFF, 1 = ON: Instructs the indexer to abort any move if a signal is received on the Input #3. If output on stall is enabled (**FSE1**), the indexer will also turn on an output when the input is active.
- G Turn on Output #2 when in deadband
- H Enable Stall Detect \emptyset = disabled, 1 = enabled

Example

| <u>Command</u> | <u>Description</u> |
|------------------------|---|
| FR<cr> | Indexer response = 11000000. The indexer is in absolute encoder step mode with all other FS encoder functions turned OFF. |
| FR111 \emptyset 0000 | Position Maintenance (FSC1) is enabled |
| FR<cr> | Indexer response is 11100000 |

| FSA Set-Up | | Set Indexer to Incremental/Absolute Mode | | | VALID Software Version A |
|--------------------------------------|--------------------------|---|---|---|------------------------------------|
| SYNTAX <a>FSA _n | UNITS n = mode | RANGE 0, 1 | DEFAULT Saved in non-volatile RAM | ATTRIBUTES Immediate/ Sequence | |
| EXECUTION TIME <10ms | | SEE ALSO MPI, MPA, FR, F | | | |
| RESPONSE TO aFSA IS aFSA *nnn | | | | | |

Description

This command sets the indexer to perform its moves in either absolute or incremental positioning mode.

FSA \emptyset (Incremental mode)

FSA1 (Absolute mode)

In Incremental mode (**FSA1**), all moves are made with respect to the position at the beginning of the move. This mode is useful for repeating moves of the same distance.

In Absolute mode (**FSA1**), all moves are made with respect to the absolute zero position. The absolute zero position is set to zero when you power up the indexer, successfully complete a go home, or execute the Position Zero (**PZ**) command.

FSA \emptyset is the same as the **MPI** command

FSA1 is the same as the **MPA** command

The Absolute mode is useful when you need to move to specific locations.

Example

| <u>Command</u> | <u>Description</u> |
|---|---|
| FSA1 | Sets indexer to Absolute mode |
| PZ | Resets the absolute counter to zero |
| A1 \emptyset | Sets acceleration to 10 units |
| V5 | Sets velocity to 5 units |
| D25 $\emptyset\emptyset\emptyset$ | Moves motor to absolute position 25,000 |
| G | Executes the move (Go) |
| D5 $\emptyset\emptyset\emptyset\emptyset$ | Move motor to absolute position 50,000 |
| G | Executes the move (Go) |

The motor moves 25,000 steps, then moves an additional 25,000 steps to reach the absolute position of 50,000.

| | | | | |
|-----------------------------|---|---------------------------|---|---|
| FSB Set-Up | Set Indexer to Motor/Encoder Step Mode | | | VALID Software Version A |
| SYNTAX <a>FSBn | UNITS n = mode | RANGE 0, 1 | DEFAULT saved in non-volatile RAM | ATTRIBUTES Immediate/ Sequence |
| EXECUTION TIME <10ms | | SEE ALSO ER, D, FR | | |

Description This command sets up the indexer to perform moves in either motor steps or encoder steps.

FSB0: (Motor steps)
FSB1: (Encoder steps)

In Motor Step mode, the distance command (D) defines moves in motor steps.

In Encoder Step mode, the distance command defines moves in encoder steps.

You must set up the indexer for the correct encoder resolution. The Encoder Resolution (ER) command is used to define the encoder resolution.

Enabling Encoder Step Moves does not guarantee that your moves will position to the exact encoder step commanded. Position maintenance (FSC) must be enabled to activate closed loop servoing.

Example

| <u>Command</u> | <u>Description</u> |
|----------------|--|
| ER4000 | Set up encoder. 4,000 encoder pulses (1,000 lines) are produced per unit of the motor. |
| FSB1 | Set moves to encoder step mode |
| A10 | Set acceleration to 10 units/sec ² |
| V5 | Set velocity to 5 units/sec |
| D4000 | Set distance to 4,000 encoder steps |
| G | Executes the move (Go) |

The motor will turn in the CW direction until 4,000 encoder pulses are received.

| | | | | |
|------------------------------|--|---|--|---|
| FSC Set-Up | Enable/Disable Position Maintenance | | | VALID Software Version |
| SYNTAX <a>FSCn | UNITS n = on/off | RANGE 0, 1 | DEFAULT Saved in non-volatile RAM | ATTRIBUTES Immediate/ Sequence |
| EXECUTION TIME <10 ms | | SEE ALSO FSB, ER, DB, FR, FSH, FSD, DW, CG | | |

Description **FSC1** = Enable Position Maintenance
FSC0 = Disable Position Maintenance

Enabling position maintenance will cause the indexer to servo the motor until the correct encoder position is achieved. This occurs at the end of a move (if the final position is incorrect) or any time the indexer senses a change in position while the motor is at zero velocity. You must have an encoder connected in order to enable position maintenance. The indexer will maintain position in both Encoder and Motor Step mode.

Position maintenance will be disabled (turned OFF) (**FSC0**) automatically if a stall is detected while running position maintenance.

When position maintenance is on a correction at the end of the move may be executed. If running a sequence including the commands **L5 G H N** there may seem to be delays between the moves.

| | | |
|----------------|----------------|----------------------------------|
| Example | <u>Command</u> | <u>Description</u> |
| | ER4000 | Set encoder resolution to 4,000. |
| | FSB1 | Set encoder step mode. |
| | FSC1 | Enable position maintenance |

| | | | | |
|------------------------------|----------------------------|-------------------------------------|--|---|
| FSD Set-Up | Stop on Stall | | | VALID Software Version |
| SYNTAX <a>FSDn | UNITS n = on/off | RANGE 0, 1 | DEFAULT Savable in non-volatile RAM | ATTRIBUTES Immediate/ Sequence |
| EXECUTION TIME <10 ms | | SEE ALSO DW, ER, FR, FSH, RE | | |

Description Entering **FSD0** will cause the indexer to attempt to finish the move when a stall is detected, even if the load is jammed.

Entering **FSD1** will cause the indexer to stop the move in progress when a stall is detected. This command is only valid if stall detection (**SSH1**) has been enabled. It will have no effect otherwise. A move stopped by a stall can be resumed.

| | | |
|----------------|----------------|--|
| Example | <u>Command</u> | <u>Description</u> |
| | DW100 | Set backlash value to 100 steps. |
| | ER4000 | Set encoder resolution to 4,000 steps/rev. |
| | FSH1 | Enable stall detect. |
| | FSD1 | Enable stop on stall. |

| | | | | |
|------------------------------|-----------------------------------|---------------------------------|---|---|
| FSE Set-Up | Turn on Output #1 on Stall | | | VALID Software Version |
| SYNTAX <a>FSEn | UNITS n = output | RANGE 0, 1 | DEFAULT Saved in non-volatile RAM | ATTRIBUTES Immediate/Sequence |
| EXECUTION TIME <10 ms | | SEE ALSO DW, ER, FSF, FR | | |

Description
FSE0 - Do not turn on output #1 on stall
FSE1 - Turn on output #1 on stall

Entering **FSE1** will cause the indexer to turn on output number 1 when a stall is detected. This is useful for signaling other components in your system that a stall has occurred. This command will only be valid if Stall Detect (**FSH1**) has been enabled.

Output number 1 is unaffected by a stall when **FSE0** is entered.

This output will also turn on if **FSE1** and Terminate Motion On Input (**FSF**) is enabled.

| | | |
|----------------|----------------|---|
| Example | <u>Command</u> | <u>Description</u> |
| | ER4000 | Set encoder resolution to 4,000 steps/rev. |
| | DW200 | Set backlash deadband to 200 motor steps. |
| | FSH1 | Enable stall detect. |
| | FSE1 | Turn on output number 1 when a stall is detected. |

| | | | | |
|------------------------------|--------------------------------|------------------------------|---|---|
| FSF Set-Up | Stop Motion on Input #3 | | | VALID Software Version |
| SYNTAX <a>FSFn | UNITS n = on/off | RANGE 0, 1 | DEFAULT Saved in non-volatile RAM | ATTRIBUTES Immediate/Sequence |
| EXECUTION TIME < 10ms | | SEE ALSO TR, FR, S, K | | |

Description
FSF0 - Do not terminate move on Input #3
FSF1 - Terminate move when Input #3 is active.

Entering **FSF1** will cause any move in progress to be stopped whenever Input #3 (Bit #2) is active. Setting up another unit to turn on Output #1 when it detects a stall with the Turn on Output on Stall (**FSE**) command, enables the user to implement a multi-axes stop on stall by connecting the output of one axis to the input on the other. The move will be decelerated at the rate last set with the acceleration (**A**) command. A terminated move can be resumed (**RE**). If the move is in a sequence the sequence will also be stopped.

Enabling this function dedicates input #3 to a stop input. Thus it will disallow many of the 8-bit PLC interface commands.

| | | |
|----------------|----------------|--|
| Example | <u>Command</u> | <u>Description</u> |
| | FSF1 | Input #3 is now dedicated as a remote terminate input. |

| | | | | |
|------------------------------|--|------------------------|---|---|
| FSG Set-Up | Turn on Output 2 when within Deadband | | | VALID Software Version A |
| SYNTAX <a>FSGn | UNITS n = on/off | RANGE 0, 1 | DEFAULT Saved in non-volatile RAM | ATTRIBUTES Immediate/ Sequence |
| EXECUTION TIME < 10ms | | SEE ALSO DB, FR | | |

Description **FSG0** - Do not turn on output #2 when the motor is within deadband.
FSG1 - Turn on output #2 when the motor is within deadband.

This output is cleared at the beginning of a move and updated at the end of the move.

Example

| <u>Command</u> | <u>Description</u> |
|----------------|--|
| DB20 | Define deadband as 20 steps |
| FSG1 | Turn on output 2 while within deadband |

| | | | | |
|-----------------------------|----------------------------|---------------------------------|---|---|
| FSH Set-Up | Enable Stall Detect | | | VALID Software Version |
| SYNTAX <a>FSHn | UNITS n = on/off | RANGE 0, 1 | DEFAULT Saved in non-volatile RAM | ATTRIBUTES Immediate/ Sequence |
| EXECUTION TIME <10ms | | SEE ALSO DW, ER, FR, FSD | | |

Description **FSH0** Disable Stall Detect
FSH1 Enable Stall Detect

This command must be used to detect a stall condition. After enabling stall detection, stop on stall (**FSD1**) and output on stall (**FSE1**) can be used.

It is necessary to define the Deadband Window (**DW**) command and the Encoder Resolution (**ER**) command before this feature will operate properly. Stall Detection is only possible when an encoder is being used.

Example

| <u>Command</u> | <u>Description</u> |
|----------------|---|
| DW1000 | Set deadband window to 1,000 steps |
| ER4000 | Set encoder resolution to 4,000 steps (500 lines) |
| FSH1 | Enable stall detection |
| FSD1 | Stop motor movement if stall detected. |

| | | | | |
|------------------------------|----------------------|---|------------------------|---|
| G Motion | Go | | | VALID Software Version A |
| SYNTAX G | UNITS None | RANGE None | DEFAULT None | ATTRIBUTES Sequence/Immediate |
| EXECUTION TIME <10 ms | | SEE ALSO A, D, K, MC, MPA, MPI, MN, S, V | | |

Description The Go (G) command instructs the axis to make a move using motion parameters that you have previously entered. You do not have to re-enter Acceleration (A), Velocity (V), Distance (D), or mode (MN or MC) commands with each G command.

A G command in the Absolute mode (MPA) will cause motion to the position you specify with the Distance (D) command.

In Continuous mode (MC), you only need to enter the acceleration and velocity commands prior to the G command. The system ignores the distance command in this mode. No motor motion occurs until you enter the G command.

| | | |
|----------------|----------------|---|
| Example | <u>Command</u> | <u>Description</u> |
| | MN | Sets mode to Normal (preset) |
| | A 5 | Sets acceleration to 5 rps ² |
| | V 5 | Sets velocity to 5 rps |
| | D 25000 | Sets distance to 25,000 steps |
| | G | Executes the move (Go) |
| | A 1 | Sets acceleration to 1 rps ² |
| | G | Executes the move (Go) |

| | | | | |
|------------------------------|---|---|---------------------|---|
| GH Motion | Go Home | | | VALID Software Version A |
| SYNTAX GH±(n) | UNITS n = direction (velocity) | RANGE + or - (.01 - 99.99) | DEFAULT + | ATTRIBUTES Sequence/Immediate |
| EXECUTION TIME <10 ms | | SEE ALSO GHF, GHV, FSB | | |

Description This command instructs the indexer to search for home in the CW or CCW direction, depending on your instruction (±). The speed is the previously entered Go Home Velocity (GHV).

The home limit input on the Model 301 is optically isolated, and is normally off. You must use a normally open, load-activated switch to ground to determine the home position.

The indexer searches for home to the CW edge. The CW edge of the home switch is defined as the first switch transition that occurs when the motor reaches the home switch if it is traveling in the CCW direction.

If the indexer is in encoder mode (FSB1) it will search for the Z-channel as the home position. **A home switch is required to home to the Z channel. The home switch must be active in order for the Z-channel pulse to be recognized.**

You can also execute the Go Home commands with the 8-bit interface (refer to *Chapter 2, Getting Started*).

The Model 301 will zero the motor and encoder position at the end of the go home move. To test the Model 301's homing function, enter the following command string.

| <u>Command</u> | <u>Description</u> |
|----------------|--|
| > GHV5 | Set go home velocity to 5 rps ² |
| > GHF.2 | Sets final go home velocity to 0.2 rps |
| > GH+ | Instructs the motor to go home at 5rps |

The **GHV** and **GH±** commands can be combined if desired. **GH+3** instructs the motor to search for the home limit in the CW direction at 3 rps.

The following events occur when you go home in the CW direction (refer to Figure 5-1):

Open-Loop Go-Home Move

1. The motor moves in the CW direction until the home switch becomes active.
2. When the home switch is closed, the motor decelerates to the velocity you specified with the **GHF** command.
3. When the switch becomes inactive the direction is reversed. The motor creeps in the CW direction until the home switch becomes active.

The following events occur when you go home in the CCW direction (refer to Figure 5-1):

1. The motor moves in the CCW direction until the home switch becomes active.
2. The motor decelerates to a stop and moves in the CW direction at the **GHF** velocity until the home switch becomes inactive.
3. The motor creeps to the CW edge of the switch at the velocity you set with the **GHF** command. The motor stops when the switch becomes active.

The absolute position counters are set to zero at the end of a go home move.




Figure 5-1. Open-Loop Homing Operation

**Closed-Loop
Go-Home Move**

1. The motor moves in the CW direction until the home switch becomes active.
2. When the home switch is closed, the motor decelerates to the velocity you specified with the **GHF** command.
3. When the switch becomes inactive the direction is reversed. The motor creeps in the CW direction until the Z channel becomes active.

The following events occur when you go home in the CCW direction (refer to Figure 5-2):

1. The motor moves in the CCW direction until the home switch becomes active.
2. The motor decelerates to a stop and moves in the CW direction at the **GHF** velocity until the home switch becomes inactive.
3. The motor creeps at the velocity you set with the **GHF** command. The motor stops when the Z channel becomes active.

The absolute position counters are set to zero at the end of a go home move.




Figure 5-2. Closed-Loop Homing Operation

If the Home switch becomes inactive without finding the Z-channel, the Go-Home will stop and the Model 301 will send the following message:

* Marker not in home active region

| | | | | |
|------------------------------|----------------------------|------------------------------|---|---|
| GHF Motion | Go Home Final Speed | | | VALID Software Version A |
| SYNTAX GHF±nn.nn | UNITS n = rps | RANGE 0.01 - 99.99 | DEFAULT Saved in non-volatile RAM | ATTRIBUTES Sequence/Immediate |
| EXECUTION TIME <10 ms | | SEE ALSO GH, GHV, R | | |

Description This command allows you to set the speed at which the indexer instructs an axis to creep to a home switch during the final part of the HOME routine. The value (nn.nn) that you specify should be small (see GHV command) to ensure a repeatable and accurate homing routine. This is the portion of the HOME move that finds the precise edge of the limit switch that defines home in the system.

Example

| | |
|----------------|---|
| <u>Command</u> | <u>Description</u> |
| GHF.04 | Sets velocity for go home final to 0.04 rps |

| | | | | |
|------------------------------|-------------------------|------------------------------|---|---|
| GHV Motion | Go Home Velocity | | | VALID Software Version A |
| SYNTAX GHV±nn.nn | UNITS n = rps | RANGE 0.01 - 99.99 | DEFAULT Saved in non-volatile RAM | ATTRIBUTES Sequence/Immediate |
| EXECUTION TIME <10 ms | | SEE ALSO GH, GHF, R | | |

Description This command allows you to set the speed at which an axis will seek its home position. After the switch is detected, the system will use the final go home speed (refer to the GHF command) to find the final home switch edge.

| | | | | |
|------------------------------|-------------------------------|------------------------|------------------------|---|
| H± Motion | Toggle Direction | | | VALID Software Version A |
| SYNTAX Hx | UNITS x = direction | RANGE + or - | DEFAULT None | ATTRIBUTES Sequence/Immediate |
| EXECUTION TIME <10 ms | | SEE ALSO | | |

Description The commanded direction will be used when the indexer receives this command. A plus sign (+) represents a CW motion. A minus sign (-) represents a CCW motion. If you do not specify a + or -, the direction will be toggled.

Example

| | |
|----------------|--|
| <u>Command</u> | <u>Description</u> |
| MN | Sets unit to Normal mode |
| A5 | Sets acceleration to 5 rps ² |
| V5 | Sets velocity to 5 rps |
| D25000 | Sets distance to 25,000 steps |
| G | Executes the move (Go) |
| H | Changes the direction of the move |
| G | Executes the move in opposite direction (Go) |

| | | | | |
|------------------------------|--|---------------------------------|------------------------|------------------------------------|
| I Edit | Insert a Line Within a Sequence | | | VALID Software Version A |
| SYNTAX I.nnn | UNITS nnn = line number | RANGE 1 - 999 | DEFAULT None | ATTRIBUTES Immediate |
| EXECUTION TIME <10 ms | | SEE ALSO D, E, EXR, Q, @ | | |

Description The **I** command is an Edit mode command that is valid only after you have entered an **EXR** (Edit a Sequence in a Program) command. The **I** command variable (**nn**) allows you to insert a new line (counted from the beginning of the block). After you insert the line and press the carriage return to mark the end of the line, the entire block is rewritten to include the change. You will be prompted to enter your next edit mode command by an asterisk (*).

To exit the Edit mode, you must enter **Q** (Quit Edit Mode) and press the carriage return <cr>. You may also press <cr> on an empty line or the ESC key while you are in the Edit mode to terminate an editing session.

| | | | | |
|------------------------------|--|------------------------------|------------------------|------------------------------------|
| IF Programming | Conditional IF | | | VALID Software Version A |
| SYNTAX IF(Innnnn) | UNITS n = input bit pattern | RANGE 0, 1, or X | DEFAULT None | ATTRIBUTES Sequence |
| EXECUTION TIME <10 ms | | SEE ALSO NIF, R, TEST | | |

Description The **IF** command tests the input bit pattern. If the statement is true, the commands between **IF** and **NIF** will be executed. If the statement is not true, the indexer resumes executing at the line that follows the **NIF** statement. The condition is checked against the saved input state (registered input data of **R** report). Refer to *Chapter 2, Getting Started* or the **TEST** command description in this chapter. The conditional **IF** command can be used to implement limits.

| | | |
|----------------|--|---|
| Example | <p><u>Command</u></p> <p>IF(I0011X)</p> <p>G</p> <p>NIF</p> | <p><u>Description</u></p> <p>Sets IF condition</p> <p>Executes a move when inputs #1 and #2 are low and #3 and #4 are high</p> <p>Ends IF condition</p> |
|----------------|--|---|

| | | | | |
|------------------------------|-------------------------------|----------------------------|------------------------|------------------------------------|
| K Motion | Kill Program Execution | | | VALID Software Version A |
| SYNTAX K | UNITS None | RANGE None | DEFAULT None | ATTRIBUTES Immediate |
| EXECUTION TIME <10 ms | | SEE ALSO S, ESC Key | | |

Description The **K** command is an emergency stop command and should only be used as such. This command stops indexing immediately. There is no deceleration of the motor. If the Kill command causes the motor to slip (i.e., large loads at high speed), the load could be driven past limit switches and cause damage to the mechanism and possibly the operation.

In addition to stopping the motor, the **K** command will terminate a loop, end a time delay, terminate program execution, and kill a trigger. You can also execute the Kill command with the 8-bit interface (refer to *Chapter 2, Getting Started*).

| | | |
|----------------|----------------|---|
| Example | <u>Command</u> | <u>Description</u> |
| | A5 | Sets acceleration to 5 rps ² |
| | V2 | Sets velocity to 2 rps |
| | MC | Sets unit to Continuous mode |
| | G | Executes the move (Go) |
| | . | |
| | . | |
| | K | Stops the motor instantly |

| | | | | |
|------------------------------|--------------------------------|--------------------------------|---------------------|----------------------------------|
| L Programming | Loop | | | VALID Software Version |
| SYNTAX Ln | UNITS n = # of loops | RANGE 0 - 65,535 | DEFAULT 0 | ATTRIBUTES Sequence |
| EXECUTION TIME <10 ms | | SEE ALSO N, Y, XG, R, K | | |

Description When you combine the Loop (**L**) command with the End-of-Loop (**N**) command, all of the commands between **L** and **N** will be repeated the number of times indicated by **n**. The **L** command, without a value specified for **n**, or with a \emptyset , will create an infinite loop.

The End-of-Loop command prompts the controller to proceed with further commands after the designated number of loops have been executed. The Stop Loop (**X**) command ends execution of the loop.

| | | |
|----------------|------------------------------------|--|
| Example | <u>Command</u> | <u>Description</u> |
| | > MN | Sets indexer to Normal mode |
| | > L5 | Loops 5 times |
| | > A5 | Sets acceleration to 5 rps ² |
| | > V1 \emptyset | Sets velocity to 10 rps |
| | > D1 $\emptyset\emptyset\emptyset$ | Sets distance to 10,000 steps |
| | > G | Executes the move (Go) |
| | > N | Specifies the above 10,000-step move to be repeated five times |
| | > XT | End of sequence |

| | | | | |
|------------------------------|----------------------------|--------------------------|------------------------|------------------------------------|
| LST Edit | List Program | | | VALID Software Version A |
| SYNTAX See Below | UNITS n = line # | RANGE 1 - 63 | DEFAULT None | ATTRIBUTES Immediate |
| EXECUTION TIME <10 ms | | SEE ALSO CLR, EXR | | |

Description You can use the List command in a variety of ways. This command allows you to display all of the sequences in the unit's memory. Listing multiple sequences also shows how much memory is available for further sequences.

LST This command lists the entire nonvolatile sequence memory.

LSTnn This command allows you to list the designated sequence.

LSTnn-*nnn* This command allows you to list all sequences within a specified block (e.g., 15 - 30).

LSTnn- This command allows you to list all sequences from a specified sequence to the end of the program.

LST-*nn* This command allows you to list all sequences from the beginning of the program to a specified sequence of the program.

Example

| | |
|---------------------------|-----------------------------|
| <u>Command</u> | <u>Description</u> |
| > LST | Lists all current sequences |
| 5: MPI MN D+10000 V11 A80 | |
| 6: IF (1000000) S NIF | |
| 0111111 | |
| L10 T.5 G H N | |
| T1 | |
| RG7 | |
| XT | |

| | | | | |
|------------------------------|------------------------|--|------------------------|---|
| MC Motion | Mode Continuous | | | VALID Software Version A |
| SYNTAX MC | UNITS None | RANGE None | DEFAULT None | ATTRIBUTES Sequence/Immediate |
| EXECUTION TIME <10 ms | | SEE ALSO A, G, MN, T, TR, V, DLY, R | | |

Description The Mode Continuous (MC) command causes subsequent moves to ignore any distance parameter and move continuously. You can clear the MC command with the Mode Normal (MN) command. *MN is the default mode*

The controller uses the Acceleration (A) and Velocity (V) commands to reach continuous velocity. Using the Time Delay (T), Trigger (TR), or Delay (DLY) with Velocity (V) commands, you can achieve basic velocity profiling.

Example

| | |
|----------------|---|
| <u>Command</u> | <u>Description</u> |
| > MC | Sets mode to continuous |
| > A5 | Sets acceleration to 5 rps ² |
| > V5 | Sets velocity to 5 rps |
| > G | Executes the move (Go) |

The motor turns at 5 rps until it is halted by the Stop (S) command, Kill (K) command, a limit switch, or by a new velocity specification.

To change velocity after a certain time has passed, use the following procedure.

| Example | Command | Description |
|---------|---------|---|
| | > MC | Sets mode to continuous |
| | > A1 | Sets acceleration to 1 rps ² |
| | > V5 | Sets velocity to 5 rps |
| | > G | Executes the move (Go) |
| | > T5 | Wait 5 seconds after velocity of 5rps is reached |
| | > V6 | Sets velocity to 6 rps |
| | > G | Executes the move to 6rps |
| | > T5 | Wait 5 seconds after velocity of 5rps is reached |
| | > V4 | Sets velocity to 4 rps |
| | > G | Executes the move to 4rps |
| | > T10 | Wait 10 seconds after velocity of 5rps is reached |
| | > V0 | Sets velocity to 0 rps |
| | > G | Decelerates to a stop |

To change velocities after a certain distance see the Delay (DLY) command.

| MN | Mode Normal | | | VALID |
|-----------------------|-------------|--------------------------------------|---------|--------------------|
| Motion | | | | Software Version |
| SYNTAX | UNITS | RANGE | DEFAULT | ATTRIBUTES |
| MN | None | None | None | Sequence/Immediate |
| EXECUTION TIME <10 ms | | SEE ALSO A, D, G, MC, MPA, MPI, V, R | | |

Description The Mode Normal (MN) command sets the Positioning mode to preset. In Mode Normal, the motor will move the distance specified with the distance (D) command. To define the complete move profile, you must define Acceleration (A), Velocity (V), and the Distance (D). The MN command changes the mode of operation from Mode Continuous (MC) to Preset mode.

| Example | Command | Description |
|---------|---------|--|
| | > MN | Set positioning mode to preset |
| | > A5 | Set acceleration to 5 rps ² |
| | > V5 | Set velocity to 5 rps |
| | > D1000 | Set distance to 1,000 steps |
| | > G | Executes the move (Go) |

The motor turns 1,000 steps in the CW direction after the G command is issued. The motor comes to a stop after the move. **Normal mode is the default operating mode.** It is in effect upon power up.

| MPA | Absolute Position Mode | | | VALID |
|-----------------------|------------------------|---------------------------------------|---------------------------|--------------------|
| Motion | | | | Software Version A |
| SYNTAX | UNITS | RANGE | DEFAULT | ATTRIBUTES |
| MPA | None | None | Saved in non-volatile RAM | Sequence/Immediate |
| EXECUTION TIME <10 ms | | SEE ALSO MC, MN, MPI, FSB, FSA, FR, R | | |

Description The MPA command sets the indexer to Absolute Position mode. In this mode, the Distance command (D) serves as an absolute position command. To return to Incremental mode, use the MPI command. MPA is the same as the FSA1 command.

| | | | | |
|------------------------------|----------------------------------|---|---|---|
| MPI Motion | Incremental Position Mode | | | VALID Software Version A |
| SYNTAX MPI | UNITS None | RANGE None | DEFAULT Saved in non-volatile RAM | ATTRIBUTES Sequence/Immediate |
| EXECUTION TIME <10 ms | | SEE ALSO MC, MN, MPA, FSA, FR, R | | |

Description The **MPI** command sets the indexer to the Incremental Position mode. In this mode, the Distance command (**D**) serves as an incremental position command. **MPI** is the same as the **FSA0** command.

| | | |
|----------------|----------------|---|
| Example | <u>Command</u> | <u>Description</u> |
| | > MN | Sets indexer to Normal mode |
| | > MPI | Sets positioning mode Incremental |
| | > A5 | Sets acceleration to 5 rps ² |
| | > V5 | Sets velocity to 5 rps |
| | > D50000 | Sets distance to 50,000 steps |
| | > G | Executes the move (Go) |

| | | | | |
|------------------------------|--------------------------------|------------------------------|---|---|
| MR Set-Up | Motor Resolution | | | VALID Software Version |
| SYNTAX MRn | UNITS n = steps/rev. | RANGE 100 - 65,535 | DEFAULT Saved in non-volatile RAM | ATTRIBUTES Sequence/Immediate |
| EXECUTION TIME <10 ms | | SEE ALSO A, V, ER, R | | |

Description The Motor Resolution (**MR**) command sets the number of steps per revolution. This command allows the indexer to control drives of different resolutions while maintaining the commanded acceleration and velocity. *This variable is not reset with the Software Reset (Z) command.* The **MR** command will be ignored if the **A** or **V** parameters are invalid for the new resolution.

| | | |
|----------------|----------------|---|
| Example | <u>Command</u> | <u>Description</u> |
| | > MN | Sets positioning mode to preset |
| | > MR400 | Sets motor resolution to 400 steps/rev |
| | > A5 | Sets acceleration to 5 rps ² |
| | > V10 | Sets velocity to 10 rps |
| | > D800 | Sets distance of move to 800 steps |
| | > G | Executes the move (Go) |

A 400-step-per-revolution motor/drive will turn 800 steps (two revs) CW at an acceleration of 10 rps² and a velocity of 10 rps after the **G** command.

If this same command set is sent to a motor/drive with a resolution of 4,000, the motor will still turn 800 steps (1/5 of a revolution). However, the actual acceleration would only be 0.5 rps² and the actual velocity would only be 1 rps. The controller resolution and motor/drive resolution must match to get the commanded velocity and acceleration. *This command does not affect distance. This command does not set the drive resolution.*

| | | | | |
|------------------------------|----------------------|----------------------|------------------------|------------------------------------|
| N Programming | End of Loop | | | VALID Software Version A |
| SYNTAX N | UNITS None | RANGE None | DEFAULT None | ATTRIBUTES Sequence |
| EXECUTION TIME <10 ms | | SEE ALSO L, Y | | |

Description The **N** command marks the end of a loop. You can use this command in conjunction with the **Loop (L)** command. All *sequence* commands that you enter between the **L** and the **N** commands are executed as many times as you specify with the **L** command's variable (**nn**).

Example

| <u>Command</u> | <u>Description</u> |
|-----------------|---|
| > MN | Sets the unit to Normal mode |
| > A5 | Sets acceleration to 5 rps ² |
| > V5 | Sets velocity to 5 rps |
| > D10000 | Sets distance to 10,000 steps |
| > L5 | Loops or repeats the move 5 times |
| > G | Executes the move (Go) |
| > N | Ends the loop |
| > XT | Ends sequence definition |

| | | | | |
|------------------------------|---------------------------|----------------------|------------------------|------------------------------------|
| NIF Programming | End of IF Commands | | | VALID Software Version A |
| SYNTAX NIF | UNITS None | RANGE None | DEFAULT None | ATTRIBUTES Sequence |
| EXECUTION TIME <10 ms | | SEE ALSO IF | | |

Description The **NIF** command marks the end of an **IF** statement.

Example

| <u>Command</u> | <u>Description</u> |
|----------------------|---|
| > IF (I00001) | Perform the following sequence when input values match the IF statement |
| MN | Sets to mode normal |
| A5 | Sets acceleration to 5 rps ² |
| V1 | Sets velocity to 1 rps |
| D10000 | Sets distance to 10,000 steps |
| L10 | Loops 10 times |
| T.5 | Pause for 5 seconds |
| G | Execute the move (Go) |
| R | Change the direction of the move |
| N | End the loop |
| NIF | End the IF condition |

| | | | | |
|------------------------------|---|---|------------------------|---|
| O Programming | Set Programmable Outputs | | | VALID Software Version A |
| SYNTAX O n n n n n | UNITS n = output on or off | RANGE 0 = off 1 = on X = don't care | DEFAULT None | ATTRIBUTES Sequence/Immediate |
| EXECUTION TIME <10 ms | | SEE ALSO DLY, I, O, FSG, FSE | | |

Description The Output (O) command turns the programmable output bits on and off. The output can indicate that the motor is in position, about to begin its move, or is at constant velocity, etc. The PLC can read the 6 outputs as the least significant bits of the upper address. If the Model 301 is in slot address 00 to 07, the 6 outputs can be read at address 100 to 105. The O command cannot be used with an extended card cage.

| | | |
|----------------|----------------|--|
| Example | <u>Command</u> | <u>Description</u> |
| | > A5 | Set acceleration to 15 rps ² |
| | > V5 | Sets velocity to 5 rps |
| | > D20000 | Set move distance to 20,000 steps |
| | > O01 | Set programmable output 1 off and output 2 on |
| | > G | Executes the move (Go) |
| | > O00 | After the move ends, turn off outputs 1 and 2—outputs 3 - 6 are not affected |

| | | | | |
|------------------------------------|------------------------------------|------------------------------------|------------------------|-------------------------------------|
| PR Status | Position Request | | | VALID Software Version A3 |
| SYNTAX P R | UNITS n = motor steps | RANGE None | DEFAULT None | ATTRIBUTES Immediate |
| EXECUTION TIME <10 ms | | SEE ALSO PZ, R, PX, FSB, SP | | |
| RESPONSE TO PR IS See Below | | | | |

Description The PR command is a status request command that provides current motor absolute position information. You can also execute position requests with the 8-bit interface (refer to *Chapter 2, Getting Started*).

| | | |
|----------------|----------------|--------------------------------------|
| Example | <u>Command</u> | <u>Response</u> |
| | P R | +500—The position is 500 motor steps |

| | | | | |
|--------------------------------|---|---------------------------|------------------------|---|
| PX Status | Report Absolute Encoder Position | | | VALID Software Version A |
| SYNTAX <a>PX | UNITS n = encoder steps | RANGE None | DEFAULT None | ATTRIBUTES Immediate/ Sequence |
| EXECUTION TIME < 10 ms | | SEE ALSO PX, R, PR | | |
| RESPONSE TO aPX IS aPXn | | | | |

Description This command returns a decimal value indicating the absolute position of the incremental encoder. The absolute position is based on the zero position. The zero position is established when you power up the system. The zero position can also be established after the indexer performs a Go Home (GH) command or a Position Zero (PZ) command. Whether in Motor Step mode or Encoder Step mode, the position is reported in encoder steps.

| | | |
|----------------|----------------|------------------------------------|
| Example | <u>Command</u> | <u>Description</u> |
| | 1PX +4000 | The encoder step position is 4,000 |

| | | | | |
|------------------------------|--------------------------|---------------------------------|------------------------|---|
| PZ Programming | Set Position Zero | | | VALID Software Version A |
| SYNTAX PZ | UNITS None | RANGE None | DEFAULT None | ATTRIBUTES Sequence/Immediate |
| EXECUTION TIME <10 ms | | SEE ALSO SP, GH, PR, PX0 | | |

Description This command allows you to set the absolute position register for the motor and encoder to zero.

| | | |
|----------------|----------------|-------------------------------|
| Example | <u>Command</u> | <u>Description</u> |
| | PR +25,000 | Set motor position to +25,000 |
| | PX +4,000 | Sets motor to +4,000 |
| | PZ | Sets motor to zero |
| | PR 0+ | Requests absolute positions |
| | PX +0 | |

| | | | | |
|------------------------------|--------------------------|---------------------------------------|------------------------|----------------------------------|
| Q Edit | Quit Editing Mode | | | VALID Software Version |
| SYNTAX Q | UNITS None | RANGE None | DEFAULT None | ATTRIBUTES Immediate |
| EXECUTION TIME <10 ms | | SEE ALSO D, E, EXR, I, ESC Key | | |

Description You can use this command to exit the Editing mode. Pressing the carriage return key <cr> on an empty line also exits from the Editing mode. You can also press the Escape key (esc) to exit from the editing mode.

| | | | | |
|-----------------------------------|----------------------|------------------------------|------------------------|------------------------------------|
| R Status | Status Report | | | VALID Software Version A |
| SYNTAX R | UNITS None | RANGE None | DEFAULT None | ATTRIBUTES Immediate |
| EXECUTION TIME <10 ms | | SEE ALSO PRA, PRX, FR | | |
| RESPONSE TO R IS See Below | | | | |

Description This command provides you with a report of the indexer's current status. The status report includes the following information:

- PLC input values
- Indexer output values
- Current position count
- Last operating parameters

A sample response from the R command is shown below.

```
*DYNAMIC DATA
* INPUT BYTE (B0 - B7) = 00000110
* OUTPUT BYTE (B0 - B7) = 00000000
* HOME: = 1
*REGISTERED DATA
* Inputs: I1=0 I2=0 I3=0 I4=0 I5=0
* Outputs: O1=0 O2=0 O3=0 O4=0 O5=0 O6=0
* Motor Position =+0
* Encoder Position =+0
*ACTIVE PARAMETERS:
* MR25000 GHV 1 GHF 0.1
* FR01100000
* ER 4000 DB5 DW250 CG8
* VS0 V0 A0
* MPI D+0 T0.5 L0
```

| | | | | |
|------------------------------|----------------------|-----------------------------|------------------------|------------------------------------|
| RE Motion | Resume | | | VALID Software Version A |
| SYNTAX RE | UNITS None | RANGE None | DEFAULT None | ATTRIBUTES Immediate |
| EXECUTION TIME <10 ms | | SEE ALSO S, FSF, FSD | | |

Description The Resume (RE) command continues the execution of an interrupted sequence. The indexer recognizes this command after you issue a Stop (S) command. It enables the Model 301 to complete a move that was stopped. After you initiate a pause, you can clear it with an RE command. You can also execute Pause and Resume commands with the 8-bit interface (refer to Chapter 2, Getting Started).

| | | |
|----------------|----------------|---|
| Example | <u>Command</u> | <u>Description</u> |
| | MN | Sets move to Normal mode |
| | D5000000 | Sets distance to 500,000 steps |
| | A5 | Sets acceleration to 5 rps ² |
| | V5 | Sets velocity to 5 rps |
| | G | Executes the move (Go) |
| | S | Interrupts execution of move |
| | RE | Resumes execution of move |

| | | | | |
|--|---------------------------------|----------------------|------------------------|------------------------------------|
| RV Status | Report Software Revision | | | VALID Software Version A |
| SYNTAX RV | UNITS None | RANGE None | DEFAULT None | ATTRIBUTES Immediate |
| EXECUTION TIME <10 ms | | SEE ALSO | | |
| RESPONSE TO RV IS *92-011006-01A4 | | | | |

Description The RV command reports the version of software in the indexer.

| | | | | |
|------------------------------|----------------------|--------------------------------|------------------------|---|
| S Motion | Stop | | | VALID Software Version A |
| SYNTAX S | UNITS None | RANGE None | DEFAULT None | ATTRIBUTES Sequence/Immediate |
| EXECUTION TIME <10 ms | | SEE ALSO K, ESC Key, RE | | |

Description This command allows you to stop axis motion. When the indexer receives the S command, it immediately initiates a ramped deceleration. You can also execute a stop with the 8-bit interface (refer to Chapter 2, Getting Started).

| | | | | |
|------------------------------|---------------------------------|-------------------------------|------------------------|---|
| SP Programming | Set Position Counter | | | VALID Software Version A |
| SYNTAX SP±nnnnnnnn | UNITS n = motor steps | RANGE 0 - ±nnnnnnnn | DEFAULT None | ATTRIBUTES Sequence/Immediate |
| EXECUTION TIME <10 ms | | SEE ALSO PRX, PZ, PR | | |

Description This command allows you to set the motor position counter to the specified value.

Example

| | |
|----------------|---|
| <u>Command</u> | <u>Description</u> |
| SP - 5000 | Sets the motor position to -5,000 steps |

| | | | | |
|------------------------------|-----------------------------|-------------------------------|------------------------|------------------------------------|
| T Programming | Time Delay | | | VALID Software Version A |
| SYNTAX Tnnn.nn | UNITS n = seconds | RANGE 0.01 - 999.99 | DEFAULT None | ATTRIBUTES Sequence |
| EXECUTION TIME <10 ms | | SEE ALSO MC, DLY, R | | |

Description The T command delays program execution for a number of seconds based on the value that you specify.

Example

| | |
|----------------|-------------------------------|
| <u>Command</u> | <u>Description</u> |
| > T5.5 | Delays motion for 5.5 seconds |
| > G | Executes the move (Go) |

| | | | | |
|------------------------------|---------------------------------|---------------------------|------------------------|------------------------------------|
| TEST Programming | Test Simulate | | | VALID Software Version A |
| SYNTAX TESTnnnnn | UNITS n = bit pattern | RANGE 0 or 1 | DEFAULT None | ATTRIBUTES Immediate |
| EXECUTION TIME <10 ms | | SEE ALSO IF, R, TR | | |

Description The TEST command allows you to simulate the inputs from the PLC bus. This command is useful when you want to test a sequence, but the PLC program is not yet finished. You can also use this command to debug sequence commands. Assume the inputs are all 0's. Use the Status Request (R) command to review *registered data* and determine current input status.

The TEST command will be ignored if bits 5 and 6 of the PLC 8-bit interface are active.

Example

| | |
|----------------|-----------------------------------|
| <u>Command</u> | <u>Description</u> |
| 5: V5 A5 MC G | Begins continuous motion at 5 rps |
| TR00001 | Waits until inputs match |
| V10 G | Slew to 10 rps |
| TR10000 | Waits until inputs match |
| S | Stops the motor |
| XT | Ends sequence #5 definition |

Use **XG5** to execute sequence #5. The motor will begin to move at 5 rps. Use the **TEST** command to force the inputs to match the **TR** command values.

```
> TEST00001
```

This will allow the motor to continue program execution. The motor will accelerate to 10 rps. Now use the **TEST** command to force the inputs to match the values of the second **TR** command.

```
> TEST10000
```

This will stop the motor. You can also see the impact of the **TEST** command by using the **R** command to review the state of the *registered data*.

| | | | | |
|------------------------------|--|--|---------------------|------------------------------------|
| TR Programming | Trigger | | | VALID Software Version A |
| SYNTAX TRnnnnn | UNITS n = input bit pattern | RANGE 0, 1, or X | DEFAULT 0 | ATTRIBUTES Sequence |
| EXECUTION TIME <10 ms | | SEE ALSO IF, R (check reg. data), TEST, K | | |

Description The **TR** command is only valid in a sequence. Commands that follow the **TR** command will not be executed until the PLC or the **TEST** command make the inputs match the **TR** command's value (nnnn). Refer to *Chapter 2, Getting Started* for more information on hardware latching of inputs. Refer to the **TEST** command description for more information on setting inputs through the serial port.

| | | |
|----------------|----------------|---|
| Example | <u>Command</u> | <u>Description</u> |
| | 5: V5 A5 MC G | Begins continuous motion at 5 rps |
| | TR10111 | Sequence execution stops here until the registered inputs match the TR command's values |
| | V10 G | Accelerates to 10 rps |

| | | | | |
|------------------------------|-------------------------|--------------------------------|-------------------------|---|
| V Motion | Velocity | | | VALID Software Version A |
| SYNTAX Vnn.nn | UNITS n = rps | RANGE 0.01 - 99.99 | DEFAULT 0 rps | ATTRIBUTES Sequence/Immediate |
| EXECUTION TIME <10 ms | | SEE ALSO A, D, G, VS, R | | |

Description This command allows you to set the maximum speed that an axis may reach during a move. The maximum step output rate is 325 KHz.

| | | |
|----------------|----------------|---|
| Example | <u>Command</u> | <u>Description</u> |
| | MC | Sets unit to Continuous mode |
| | A1 | Sets acceleration to 1 rps ² |
| | V5 | Sets velocity to 5 rps |
| | D25000 | Sets distance to 25,000 steps |
| | G | Executes the move (Go) |

| | | | | |
|------------------------------|-------------------------|-------------------------------|-------------------------|---|
| VS Motion | Initial Velocity | | | VALID Software Version A |
| SYNTAX VSnn.nn | UNITS n = rps | RANGE 0.01 - 99.99 | DEFAULT 0 rps | ATTRIBUTES Sequence/Immediate |
| EXECUTION TIME <10 ms | | SEE ALSO A, D, G, V, R | | |

Description At the outset of a move, this command sets the initial velocity. This command allows you to avoid specific low-frequency ranges that might stall or resonate step motors.

| | | |
|----------------|----------------|---|
| Example | <u>Command</u> | <u>Description</u> |
| | MC | Sets unit to Continuous mode |
| | A1 | Sets acceleration to 1 rps ² |
| | V5 | Sets velocity to 1 rps |
| | VS1 | Sets initial velocity at 1 rps |
| | G | Executes the move (Go) |

The initial velocity will be 1rps and will ramp up to 5rps.

| | | | | |
|------------------------------|-----------------------------------|-----------------------------|------------------------|---|
| XG Programming | Execute Sequence | | | VALID Software Version A |
| SYNTAX XGnn | UNITS n = sequence # | RANGE 0 - 63 | DEFAULT None | ATTRIBUTES Sequence/Immediate |
| EXECUTION TIME <10 ms | | SEE ALSO EXR, XR, XT | | |

Description The XG command begins the execution of a program starting at the sequence # that you specify (nn). You may also use this command within a sequence to begin executing another sequence. You can execute a sequence with the 8-bit interface (refer to *Chapter 2, Getting Started*). Executing sequence 0 will cause execution to begin at the first program in memory.

| | | |
|----------------|----------------|--------------------------------------|
| Example | <u>Command</u> | <u>Description</u> |
| | XG7 | Executes the commands in sequence #7 |

| | | | | |
|------------------------------|---------------------------------------|------------------------------|----------------------------|---|
| XR Programming | Execute Sequence w/Return | | | VALID Software Version A |
| SYNTAX XRnn | UNITS n = sequence # | RANGE 0 - 63 | DEFAULT None | ATTRIBUTES Sequence/Immediate |
| EXECUTION TIME <10 ms | | SEE ALSO EXR, XG , XT | | |

Description When you use the **XR** command within a sequence, it begins the execution of a program starting at the sequence # that you specify (nn). When the indexer reaches the End Sequence (**XT**) command, execution is returned to the command line that follows the **XRnn** command. This command is especially useful when you want to use subroutine sequences. This command works just like the **XG** command in Immediate mode. Executing sequence 0 will start program execution at the beginning of memory

ExampleCommand

```

1: D1000 G XT
2: D2000 G XT
3: D3000 G XT
4: D4000 G XT
20:A5 V5 MN
   IF (I00001) XR1 NIF
   IF (I00010) XR2 NIF
   IF (I00011) XR3 NIF
   IF (I00100) XR4 NIF
   XG20
   XT

```

Enter **XG20**. Motor will move different distances based upon inputs.

| | | | | |
|------------------------------|--------------------------|-----------------------------|----------------------------|------------------------------------|
| XT Programming | End Sequence | | | VALID Software Version A |
| SYNTAX XT | UNITS None | RANGE None | DEFAULT None | ATTRIBUTES Sequence |
| EXECUTION TIME <10 ms | | SEE ALSO EXR, XG, XR | | |

Description The **XT** command ends a sequence. If the sequence is called from an **XG** command, program execution stops when the indexer reaches an **XT** command. If the sequence is initiated with an **XR** command, program execution returns to the line that follows the **XRnn** command when the indexer reaches an **XT** command. If the sequence does not contain an **XT** command, program execution will move on to the next sequence.

| | | | | |
|------------------------------|--|---|---------------------|------------------------------------|
| XTR Programming | Enable/Disable Trace Mode | | | VALID Software Version A |
| SYNTAX XTRn | UNITS n = enable/ disable | RANGE 1 = Trace mode On 0 = Trace mode Off | DEFAULT 0 | ATTRIBUTES Immediate |
| EXECUTION TIME <10 ms | | SEE ALSO | | |

Description When you set the **XTR** command to 1, the Trace mode is enabled. As a debugging tool, the Trace mode sends user programs one character at a time (as the indexer reads it). This mode tends to slow down program execution slightly. The **XTR** command is displayed before it is executed.

Example

| | |
|----------------|--|
| <u>Command</u> | <u>Description</u> |
| XTR1 | Instructs the Model 301 to send the executed command to the terminal |

| | | | | |
|------------------------------|-----------------------|----------------------|------------------------|------------------------------------|
| Y Programming | Terminate Loop | | | VALID Software Version A |
| SYNTAX Y | UNITS None | RANGE None | DEFAULT None | ATTRIBUTES Immediate |
| EXECUTION TIME <10 ms | | SEE ALSO L, N | | |

Description The **Y** command terminates loop execution at the end of the loop that is currently being executed. The sequence being run will be terminated.

| | | | | |
|------------------------------|-----------------------|----------------------|------------------------|------------------------------------|
| Z Set-Up | Software Reset | | | VALID Software Version A |
| SYNTAX Z | UNITS None | RANGE None | DEFAULT None | ATTRIBUTES Immediate |
| EXECUTION TIME <10 ms | | SEE ALSO None | | |

Description The **Z** command resets the Model 301. Many parameters are reset to their default values.

Chapter 6. Hardware Reference

Chapter Objectives

The information in this chapter will enable you to:

- Use this chapter as a quick-reference tool for most system specifications
- Use this chapter as a quick-reference tool for proper I/O connections

Environmental Specifications

Ambient Operating Temperature: 32°F - 140°F (0°C - 60°C)
Storage Temperature: 40°F - 185°F (-40°C - 85°C).
Humidity: 5 - 95%

Electrical Specifications

This section summarizes the power supply requirements and electrical characteristics of the available interfaces.

Power Supply Requirements

The Model 301 card requires only the +9V supply provided by the PLC rack power supply. The Model 301 uses a maximum of 150 mA of the +9V supply. This is equivalent to 15 units of the load described in the PLC user manual.

To interface the Model 301 to the drive and encoder a separate +5V supply is required.

Serial Communications (RS-232C)

The 9-pin female D-shell connector on the Model 301 front panel provides the connection for RS-232C communications. Figure 6-1 shows the pin assignments for the serial communications port. The indexer's serial communications parameters are listed below:

Baud Rate: 9,600
Data Bits: 8
Stop Bits: 1
Parity: None
XON/XOFF: Not used
Echo: On

SuperPaint!Pat:User Guides:Model 303 Indexer:Model 303 Figures:Fig. 6-1!Draw(154,88:381,186)




Figure 6-1. RS-232C Serial Communications

Cable Pin Outs

The pinout for the RS-232C 9-pin D connector on the Model 301 is provided below. Compumotor provides a cable for this connector (**part number 71-011319-10**).

| Model 301 9-Pin Connector | Function | Color | Terminal 25-Pin Connector |
|---------------------------|----------|-------|---------------------------|
| Pin #2 | Tx | RED | Pin #3 |
| Pin #3 | Rx | GREEN | Pin #2 |
| Pin #5 | Shield | - | No Connection |
| Pin #7 | GND | WHITE | Pin #7 |

The pin out for the 25-pin D motor/driver cable (**part number 71-011159-10**) for connection between the Model 301 and a *Compumotor drive* is provided below.

| Compumotor Indexer 25-Pin Connector | Color | Function |
|-------------------------------------|-------|-----------|
| Pin #1 | RED | +5V |
| Pin #2 | RED | +5V |
| Pin #14 | WHITE | STEP- |
| Pin #15 | GREEN | DIR- |
| Pin #16 | RED | +5V |
| Pin #17 | WHITE | SHUTDOWN- |

10-Pin Screw Terminal Connections

The pin connections for the inputs and outputs on the 12-pin screw terminal are shown in Figure 6-2.




Figure 6-2. 12 Pin I/O Connector

The typical output circuit is used for the step & direction signals (Figure 6-3).




Figure 6-3. Typical Input Circuit




Figure 6-4. Typical Output Circuits

This input circuit is used for the home input. The encoder inputs use 26LS32 line driver receivers.

All of the inputs and outputs as well as the RS-232C interface are optically isolated.

LEDs

The busy LED indicates that a sequence is currently running. The moving LED indicates that steps are being sent to the drive.

System Specifications

The following performance specifications apply to the Model 301 indexer.

I/O Specifications

Maximum Step Output Frequency: 325,000 pulses/second

Memory

Nonvolatile Memory: 2 K bytes
Expanded Memory Option: 8 K bytes

Chapter 7. Troubleshooting

Chapter Objectives

The information in this chapter will enable you to:

- Maintain the system's components to ensure smooth, efficient operation
- Isolate and resolve system hardware problems
- Isolate and resolve system software problems

Troubleshooting

This section discusses methods to identify, isolate, and resolve problems that may occur with the Model 301.

Problem Isolation

If your system malfunctions, you must identify and isolate the problem. When you accomplish this, you can begin to resolve the problem.

The first step is to isolate each system component and ensure that each component functions properly when it is run independently. You may have to dismantle your system and put it back together piece by piece to detect the problem. If you have additional units available, you may want to use them to replace existing components in your system to help identify the source of the problem.

Try to determine if the problem is mechanical, electrical, or software-related. Can you repeat or re-create the problem? Do not attempt to make quick rationalizations about problems. Random events may appear to be related, but they are not necessarily contributing factors to your problem. You must carefully investigate and decipher the events that occurred before the subsequent system problem.

You may be experiencing more than one problem. You must solve one problem at a time. Log (document) all testing and problem isolation procedures. You may need to review and consult these notes later. This will also prevent you from duplicating your testing efforts.

Once you isolate the problem, take the necessary steps to resolve it. If your system's problem persists, contact Compumotor's Applications Department.

Reducing Electrical Noise

For detailed information on reducing electrical noise in your system, refer to the current Compumotor Catalog.

RS-232C Communications

If you are having problems communicating with the Model 301 indexer, use the following procedure to troubleshoot the RS-232C communications interface.

1. Configure the terminal and the Model 301 to the same baud rate, number of data bits, number of stop bits, and parity.
2. Ensure that the transmit connection (Tx) of the terminal is wired to the receive connection (Rx) of the Model 301, and that the receive connection (Rx) of the terminal is wired to transmit connection (Tx) of the Model 301.

Try switching the receive and transmit wires on either the terminal or the Model 301 if communication fails.

Verify that you have wired RS-232C on the Model 301 to the port selected.

3. Some serial ports require handshaking. If so, you may establish three-wire communication by connecting RTS to CTS (usually pins #4 and #5) and DSR to DTR (usually pins #6 to #20) at the Model 301 end.
4. If you receive double characters, for instance typing **A** and receiving **AA**, your computer is set for half duplex.
5. Use DC common or signal ground as your reference, **not earth ground**.
6. Cable lengths should not exceed 50 ft. unless you are using some form of line driver, optical coupler, or shield. As with any control signal, **shield the cable to earth ground at one end only**.
7. To test your terminal for proper three wire communication, unhook your peripheral device and transmit a character. You should not receive an echoed character. If you do, you are in half duplex mode. Change the setup to full duplex. Connect the host's transmit and receive lines and send another character. You should receive the echoed character. If you do not receive the echoed character, consult the terminal manufacturer for the unit's serial interface and proper pin outs.

Motor Fails to Move

Test the motor to see if it has holding torque. If there is no holding torque, here are some probable causes.

- There is no AC power.
- There are bad connections or bad cables. Disconnect the power connector, then use an ohm meter to monitor continuity between the motor-to-drive cable.

If the unit has holding torque and the motor shaft still fails to move, here are some probable causes:

- The load is jammed. You should hear the drive attempting to move the motor. Remove AC power from the drive and verify that you can move the load manually away from the point of the jam.
- The +5V supply is improperly connected
- Indexer parameters are incorrectly set up. If certain parameters are out of range or are missing, the motor will not move when you issue the Go (G) command.

Use the R status command to determine what is preventing the move. Check **A**, **V**, and **D** commands to make sure that all the parameters are set properly. *The Model 301's busy (Green) LED will be on if steps are being sent out.*

The following are additional troubleshooting techniques:

- Check the motor for damage. Also check the motor cable to see if it is damaged or shortened. These conditions may cause the drive to fault.
- Ohm the motor and cables to make sure that short-circuits do not exist between phases or to earth ground. On your most sensitive scale, the resistance across each motor phase should be consistently low (but not zero) and similar to each other. On your highest scale, the resistance between motor phases and between each phase and earth ground should be infinite.

**Encoder
Feedback**

Check wiring between Model 301 and the Encoder. If no encoder pulses are received, there may be no power to the encoder or the phases are not wired properly.

If the encoder counts are in the wrong direction, the phases need to be reversed.

Connect the following:

- Phase A+ to Phase B+
- Phase A- to Phase B-
- Phase B+ to Phase A+
- Phase B- to Phase A-

Appendices

Command Listing

ESC (Escape Key)
@ (Comments Delimiter—*Edit Mode*)

A (Acceleration)

CG (Correction Gain)
CLR (Clear)

D (Distance)
D (Delete—*Edit Mode*)
DB (Deadband)
DLY (Delay)
DW (Deadband Window)

E (Edit)
ER (Encoder Resolution)
EXR (Edit a Sequence in a Program)

FR (Report Setup Status)
FSA (Set Indexer to Incremental/Absolute Mode)
FSB (Set Indexer to Motor/Encoder Step Mode)
FSC (Enable/Disable Position Maintenance)
FSD (Stop on Stall)
FSE ()Turn on Output #1 on Stall)
FSF (Kill Motion on Trigger)
FSG (Turn on Output 2 When Within Deadband)
FSH (Enable Stall Detection)

G (Go)
GH (Go Home)
GHF (Go Home Final Speed)
GHV (Go Home Velocity)

H± (Set Direction)

I (Insert a Line in a Sequence)
IF (Conditional IF)

K (Kill)

L (Loop)
LST (List Program)

MC (Mode Continuous)
MN (Mode Normal)
MPA (Mode Position Absolute)
MPI (Mode Position Incremental)
MR (Motor Resolution)

N (End of Loop)
NIF (End of IF Commands)

O (Set Programmable Outputs)

PR (Position Request)
PX (Report Absolute Encoder Position)
PZ (Set Position Zero)

Q (Quit Editing Mode)

R (Status Report)
RE (Resume)
RV (Revision)

S (Stop)
SP (Set Position Counter)

T (Time Delay)
TEST (Test Simulate)
TR (Trigger)

V (Velocity)
VS (Initial Velocity)

XG (Execute Sequence)
XR (Execute Sequence w/Return)
XT (End Sequence)
XTR (Enable/Disable Trace Mode)

Y (Terminate Loop)

Z (Reset Software)

Glossary

Absolute Positioning

Refers to a motion control system employing position feedback devices (absolute encoders) to maintain a given mechanical location.

Absolute Programming

A positioning coordinate reference wherein all positions are specified relative to some reference, or *home* position. This is different from incremental programming, where distances are specified relative to the current position.

Acceleration

The change in velocity as a function of time. Acceleration usually refers to increasing velocity and deceleration describes decreasing velocity.

Accuracy

A measure of the difference between expected position and actual position of a motor or mechanical system. Motor accuracy is usually specified as an angle representing the maximum deviation from expected position.

Address

Multiple devices, each with a separate address or unit number, can be controlled on the same bus. The address allows the host to communicate individually to each device.

Ambient Temperature

The temperature of the cooling medium, usually air, immediately surrounding the motor or another device.

ASCII

American Standard Code for Information Interchange. This code assigns a number to each numeral and letter of the alphabet. In this manner, information can be transmitted between machines as a series of binary numbers.

Bandwidth

The frequency range in which the magnitude of the system gain expressed in dB is greater than -3 dB.

Baud Rate

The number of bits transmitted per second. Typical rates include 300; 600; 1,200; 2,400; 4,800; 9,600; 19,200. This means at 9,600 baud, one character can be sent nearly every millisecond.

BCD

Binary Coded Decimal is an encoding technique used to describe the numbers 0 - 9 with four digital (on or off) signal lines. Popular in machine tool equipment, BCD interfaces are now giving way to interfaces requiring fewer wires—such as RS-232C.

Bit

Abbreviation of Binary Digit, the smallest unit of memory equal to 1 or 0.

Block Diagram

A simplified schematic representing components and signal flow through a system.

Bode Plot

A graph of system gain and phase versus input frequency that graphically illustrates the steady state characteristics of the system.

Break Frequency

Frequency(ies) at which the gain changes slope on a Bode plot. (Break frequencies correspond to the poles and zeroes of the system.)

Byte

A group of 8 bits treated as a whole, with 256 possible combinations of ones and zeros, each combination representing a unique piece of information.

Closed Loop

A term relating to any system where the output is measured and compared to the input. The output is adjusted to reach the desired condition. In motion control, the term is used to describe a system wherein a velocity or position (or both) transducer is used to generate correction signals by comparison to desired parameters.

Critical Damping

A system is critically damped when the response to a step change in desired velocity or position is achieved in the minimum possible time with little or no overshoot.

Crossover Frequency

The frequency at which the gain intercepts the 0 dB point on a Bode Plot. (Used in reference to the open-loop gain plot.)

Daisy-Chain

A term used to describe the linking of several RS-232C devices in sequence such that a single data stream flows through one device and on to the next. Daisy-chained devices usually are distinguished by device addresses, which serve to indicate the desired destination for data in the stream.

Damping

An indication of the rate of decay of a signal to its steady state value. Related to settling time.

Damping Ratio

Ratio of actual damping to critical damping. Less than one is an underdamped system and greater than one is an overdamped system.

Data Bits

Since the ASCII character set consists of 128 characters, computers may transmit only seven bits of data. However, most computers support an eight bit extended ASCII character set.

Dead Band

A range of input signals for which there is no system response.

Decibel

A logarithmic measurement of gain. If G is a system gain (ratio of output to input), then $20 \log G$ equals gain in decibels (dB).

Detent Torque

The minimal torque present in an unenergized motor. The detent torque of a Compumotor or step motor is typically about one percent of its static energized torque.

DTE

Data Communications Equipment transmits on pin #2 and receives on pin #3.

Duty Cycle

For a repetitive cycle, the ratio of on time to total cycle time.

$$\text{Duty Cycle} = \frac{\text{On Time}}{\text{On Time} + \text{Off Time}}$$

Efficiency

The ratio of power output to power input.

Encoder

A device that translates mechanical motion into electronic signals used for monitoring position or velocity.

Friction

A resistance to motion caused by surfaces rubbing together. Friction can be constant with varying speed (Coulomb friction) or proportional to speed (viscous friction).

Full Duplex

The terminal will display only received or echoed characters.

Gain

The ratio of system output signal to system input signal.

Half Duplex

In half duplex mode, a terminal will display every character transmitted. It may also display the received character.

Hand Shaking Signals

RST: Request To Send
 CTS: Clear To Send
 DSR: Data Set Ready
 DTR: Data Terminal Ready
 IDB: Input Data Buffer
 ODB: Output Data Buffer

Holding Torque

Sometimes called static torque, it specifies the maximum external force or torque that can be applied to a stopped, energized motor without causing the rotor to rotate continuously.

Home

A reference position in a motion control system, usually derived from a mechanical datum. Often designated as the *zero* position.

Hysteresis

The difference in response of a system to an increasing or a decreasing input signal.

IEEE-488

A digital data communications standard popular in instrumentation electronics. This parallel interface is also known as GPIB, or General Purpose Interface Bus.

Incremental Motion

One step of motion for each step command (usually a pulse) received.

Incremental Programming

A coordinated system where position or distances are specified relative to the current position.

Inertia

A measure of an object's resistance to a change in velocity. The larger an object's inertia, the larger the torque that is required to accelerate or decelerate it. Inertia is a function of an object's mass and its shape.

Inertial Match

For most efficient operation, the system coupling ratio should be selected so that the reflected inertia of the load is equal to the rotor inertia of the motor.

Lead Compensation Algorithm

A mathematical equation implemented by a computer to decrease the delay between the input and output of a system.

Limits

Properly designed motion control systems have sensors called limits that alert the control electronics that the physical end of travel is being approached and that motion should stop.

Logic Ground

An electrical potential to which all control signals in a particular system are referenced.

Microstepping

An electronic control technique that proportions the current in a step motor's windings to provide additional intermediate positions between poles. Produces smooth rotation over a wide speed range and high positional resolution.

Null Modem

A simple device or set of connectors which switches the receive and transmit lines of a three wire RS-232C connector.

Open Collector

A term used to describe a signal output that is performed with a transistor. An open collector output acts like a switch closure with one end of the switch at ground potential and the other end of the switch accessible.

Open Loop

Refers to a motion control system where no external sensors are used to provide position or velocity correction signals.

OPTO-isolated

A method of sending a signal from one piece of equipment to another without the usual requirement of common ground potentials. The signal is transmitted optically with a light source (usually a Light Emitting Diode) and a light sensor (usually a photosensitive transistor). These optical components provide electrical isolation.

Parallel

Refers to a data communication format wherein many signal lines communicate more than one piece of data at the same time.

Parity

An RS-232C error detection scheme that can detect an odd number of transmission errors.

Phase Angle

The angle at which the steady state input signal to a system leads the output signal.

Phase Margin

The difference between 180° and the phase angle of a system at its crossover frequency.

Pole

A frequency at which the transfer function of a system goes to infinity.

Pulse Rate

The frequency of the step pulses applied to a motor driver. The pulse rate multiplied by the resolution of the motor/drive combination (in steps per revolution) yields the rotational speed in rps.

Ramping

The acceleration and deceleration of a motor. May also refer to the change in frequency of the applied step pulse train.

Rated Torque

The torque producing capacity of a motor at a given speed. This is the maximum torque the motor can deliver to a load and is usually specified with a torque/speed curve.

Relative Accuracy

Also referred to as *Step-to-Step Accuracy*. This specification tells how microsteps can change in size. In a perfect system, microsteps would all be exactly the same size, but drive characteristics and the absolute accuracy of the motor cause the steps to expand and contract by an amount up to the relative accuracy figure. The error is not cumulative.

Repeatability

The degree to which the positioning accuracy for a given move performed repetitively can be duplicated.

Resolution

The smallest positioning increment that can be achieved. Frequently defined as the number of steps required for a motor's shaft to rotate one complete revolution.

Ringing

Oscillation of a system following a sudden change in state.

RMS Torque

For an intermittent duty cycle application, the RMS Torque is equal to the steady state torque which would produce the same amount of motor heating over long periods of time.

Where:

T_i = Torque during interval i
t = Time of interval i

RS-232C

A data communications standard that encodes a string of data on one line in a time sequential format. The standard specifies the proper voltage and timing requirements so that different manufacturers' devices are compatible.

Slew

In motion control, the portion of a move made at a constant non-zero velocity.

Speed

Describes the linear or rotational velocity of a motor or other object in motion.

Start Bits

RS-232C character transmissions begin with a bit which signals the receiver that data is now being transmitted.

Static Torque

The maximum torque available at zero speed.

Step Angle

The angle the shaft rotates upon receipt of a single step command.

Stiffness

The ability to resist movement induced by an applied torque. Is often specified as a torque displacement curve, indicating the amount a motor shaft will rotate upon application of a known external force when stopped.

Stop Bits

When using RS-232C, one or two bits are added to every character to signal the end of a character.

Synchronism

A motor rotating at a speed correctly corresponding to the applied step pulse frequency is in *synchronism*. Load torques in excess of the motor's capacity (rated torque) cause a loss of synchronism. This condition does not damage step motors.

Text/Echo (Off/On)

This setup allows received characters to be re-transmitted back to the original sending device. Echoing characters can be used to verify or *close the loop* on a transmission.

Torque

Force tending to produce rotation.

Torque-to Inertia Ratio

Defined as a motor's holding torque divided by the inertia of its rotor. The higher the ratio, the higher a motor's maximum acceleration capability will be.

Transfer Function

A mathematical means of expressing the output to input relationship of a system.

TTL

Transistor-Transistor Logic. Describes a common digital logic device family that is used in most modern digital electronics.

TTL signals have two distinct states that are described with a voltage—a logical **zero** or **low** is represented by a voltage of less than 0.8V and a logical **one** or **high** is represented by a voltage from 2.5V to 5V.

XON/XOFF

Two ASCII characters supported in some serial communication programs. If supported, the receiving device transmits an XOFF character to the host when its character buffer is full. The XOFF character directs the host to stop transmitting characters to the device. Once the buffer empties the device will transmit an XON character to signal the host to resume transmission.

Zero

A frequency at which the transfer function of a system goes to zero.

Index

ABSOLUTE MODE 22
AMBIENT OPERATING TEMPERATURE 15

BASIC SYSTEM WIRING DIAGRAM 3
BRANCHING 29

CONTINUOUS MODE 23

DEVICE ADDRESS 15
DRIVE CONNECTIONS 6

EDITING 25
 CLEARING MEMORY 27
 DELETING A SEQUENCE 27
 EDIT A LINE 25
 EXITING EDIT MODE 26
 INSERTING AND DELETING LINES 26
 LISTING SEQUENCES 26

EXTENDED PLC CAGE 4
EXTERNAL POWER SUPPLY 17

GROUNDING 17

HOMING FUNCTION 18
 HOMING OPERATION 18

HUMIDITY 15

INCREMENTAL MODE 22
INDEXER INSERTION 16
INPUT CIRCUIT 66
INPUTS 8, 19
 COMMAND VALID STROBE LINE 8
 INPUT BIT COMMAND STRUCTURE 8
 PROGRAMMABLE INPUTS 19
 TRIGGER INPUTS 28

LIMITS 29

MODES OF OPERATION 23
 IMMEDIATE MODE 23
 INTERACTIVE EDIT MODE 23
 PLC OPERATION 27

MOTION PROFILE 21
 TRIANGULAR AND TRAPEZOIDAL PROFILES 21

NORMAL MODE 22

OUTPUT CIRCUITS 67
OUTPUTS 8, 29
 PROGRAMMABLE OUTPUTS 19

POWER SUPPLY 65
PRESET MOVE 22

RS-232C COMMUNICATIONS 4, 17, 65, 69
RS-232C CONNECTION 5

SEQUENCES 27
SHIP KIT LIST 3
STORAGE TEMPERATURE 15

TIME DELAYS 29