

P1HZ X1




Safety relays

This document is the original document.

All rights to this documentation are reserved by Pilz GmbH & Co. KG. Copies may be made for the user's internal purposes. Suggestions and comments for improving this documentation will be gratefully received.

Source code from third-party manufacturers or open source software has been used for some components. The relevant licence information is available on the Internet on the Pilz homepage.

Pilz®, PIT®, PMI®, PNOZ®, Primo®, PSEN®, PSS®, PVIS®, SafetyBUS p®, SafetyEYE®, SafetyNET p®, the spirit of safety® are registered and protected trademarks of Pilz GmbH & Co. KG in some countries.



Introduction	4
Validity of documentation	4
Using the documentation	4
Definition of symbols	4
Safety	5
Intended use	5
Safety regulations	5
Safety assessment	
Use of qualified personnel	
Warranty and liability	
Disposal	
For your safety	6
Unit features	6
Safety features	7
Block diagram/terminal configuration	7
Function Description	7
Operating modes	8
Timing diagram	8
Installation	8
Wiring	9
Preparing for operation	10
Operation	
Status indicators	11
Faults - Interference	11
Dimensions in mm	12
Table to Literature	46
Technical details	
Safety characteristic data	15
Cumplementers data	
Supplementary data	
Service life graph	16
Order reference	4-
Order reference	17
EC declaration of conformity	17
EV UECIALALION OI COMOTHILLY	17

## Introduction

#### Validity of documentation

This documentation is valid for the product P1HZ X1. It is valid until new documentation is published.

This operating manual explains the function and operation, describes the installation and provides guidelines on how to connect the product.

#### Using the documentation

This document is intended for instruction. Only install and commission the product if you have read and understood this document. The document should be retained for future reference.

## **Definition of symbols**

Information that is particularly important is identified as follows:



#### **DANGER!**

This warning must be heeded! It warns of a hazardous situation that poses an immediate threat of serious injury and death and indicates preventive measures that can be taken.



#### **WARNING!**

This warning must be heeded! It warns of a hazardous situation that could lead to serious injury and death and indicates preventive measures that can be taken.



#### **CAUTION!**

This refers to a hazard that can lead to a less serious or minor injury plus material damage, and also provides information on preventive measures that can be taken.



#### **NOTICE**

This describes a situation in which the product or devices could be damaged and also provides information on preventive measures that can be taken. It also highlights areas within the text that are of particular importance.



#### **INFORMATION**

This gives advice on applications and provides information on special fea-

## Safety

#### Intended use

The two-hand control relay P1HZ X1 meets the requirements of EN 574 Type IIIA. It forces the operator to keep his hands outside the hazardous area during the hazardous movement. It is designed for use in two-hand control devices. Please note the type of two-hand control devices as stated in the relevant C standard.



#### **NOTICE**

The two-hand control relay may **not** be used on **press controllers**. It is only suitable for use where the risk analysis has established a low level of risk (e.g. PL c (Cat. 1) in accordance with EN ISO 13849-1).

The following is deemed improper use in particular

- Any component, technical or electrical modification to the product,
- Use of the product outside the areas described in this manual,
- ▶ Use of the product outside the technical details (see Technical details [ 12]).



#### NOTICE

#### **EMC-compliant electrical installation**

The product is designed for use in an industrial environment. The product may cause interference if installed in other environments. If installed in other environments, measures should be taken to comply with the applicable standards and directives for the respective installation site with regard to interference.

#### Safety regulations

#### Safety assessment

Before using a device, a safety assessment in accordance with the Machinery Directive is required.

The product as an individual component fulfils the functional safety requirements in accordance with EN ISO 13849 and EN 62061. However, this does not guarantee the functional safety of the overall plant/machine. To achieve the relevant safety level of the overall plant/machine's required safety functions, each safety function needs to be considered separately.

#### Use of qualified personnel

The products may only be assembled, installed, programmed, commissioned, operated, maintained and decommissioned by persons who are competent to do so.

A competent person is a qualified and knowledgeable person who, because of their training, experience and current professional activity, has the specialist knowledge required. To be able to inspect, assess and operate devices, systems and machines, the person has to be informed of the state of the art and the applicable national, European and international laws, directives and standards.

It is the company's responsibility only to employ personnel who

- Are familiar with the basic regulations concerning health and safety / accident prevention,
- Have read and understood the information provided in the section entitled Safety
- ▶ Have a good knowledge of the generic and specialist standards applicable to the specific application.

#### Warranty and liability

All claims to warranty and liability will be rendered invalid if

- ▶ The product was used contrary to the purpose for which it is intended,
- Damage can be attributed to not having followed the guidelines in the manual,
- ▶ Operating personnel are not suitably qualified,
- ▶ Any type of modification has been made (e.g. exchanging components on the PCB boards, soldering work etc.).

#### **Disposal**

- ▶ In safety-related applications, please comply with the mission time T<sub>M</sub> in the safety-related characteristic data.
- ▶ When decommissioning, please comply with local regulations regarding the disposal of electronic devices (e.g. Electrical and Electronic Equipment Act).

#### For your safety

The unit meets all the necessary conditions for safe operation. However, please note the following:

Note for overvoltage category III: If voltages higher than low voltage (>50 VAC or >120 VDC) are present on the unit, connected control elements and sensors must have a rated insulation voltage of at least 250 V.

#### **Unit features**


- ▶ Positive-guided relay outputs:
  - 2 safety contacts (N/O), instantaneous
- ▶ Connection options for:
  - 2 control elements (pushbuttons)
- LED display for:
  - Supply voltage
  - Switch status of the safety contacts

## Safety features

The two-hand control relay meets the following safety requirements:

- ▶ The two-hand control relay prevents the plant from being enabled in the following cases:
  - Power supply failure
  - Component failure
  - Short circuit on an input circuit
  - Coil defect
  - Open circuit
  - Earth fault
- In each on-off cycle, the output relays on the safety device are tested to ensure they open and close correctly

# Block diagram/terminal configuration



\*Insulation between the non-marked area and the relay contacts: Basic insulation (over-voltage category III), Protective separation (overvoltage category II)

# **Function Description**

The two-hand control relay is activated by simultaneously operating the two operator elements (simultaneity see Technical details [ 12]). If one or both of the operator elements are released, the device interrupts the control command for the hazardous movement. The device is ready for operation when the supply voltage is applied and the feedback loop Y1-Y2 is closed. The "POWER" LED lights up.


- ▶ Both operator elements are operated within the simultaneity:
  - Safety contacts 13-14 and 23-24 close, the device is active.
  - LEDs "CH1" and "CH2" will light.
- ▶ One operator element is released following simultaneous operation:
  - Safety contacts 13-14 and 23-24 are opened

- The LED "CH1" or "CH2" goes out.
- ▶ To activate the device again, both operator elements have to be released and then operated again within the simultaneity.

#### **Operating modes**

- Dual-channel operation with detection of shorts across contacts: Redundant input circuit, P1HZ X1 detects
  - earth faults in the start and input circuit,
  - short circuits in the input circuit,
  - shorts across contacts in the input circuit.

## **Timing diagram**



#### Legend

▶ POWER: Supply voltage

▶ Button 1/Button 2: Pushbutton in the input circuit

▶ Feedback loop: Feedback loop

▶ Output safe: Safety contacts

▶ t₀: Recovery time after power on

▶ t₁: Simultaneity, channel 1 and 2

▶ t₂: Operating cycle ended through pushbutton 1 or 2

▶ t<sub>3</sub>: Feedback loop must be closed before the pushbutton is operated (recovery time)

Shaded area: State irrelevant

#### Installation

- ▶ The unit should be installed in a control cabinet with a protection type of at least IP54.
- ▶ Use the notch on the rear of the unit to attach it to a DIN rail (35 mm).
- ▶ When installed vertically: Secure the unit by using a fixing element (e.g. retaining bracket or end angle).



#### **WARNING!**

Loss of the safety function due to too short distance of the operator elements to the hazardous area!

The distance of the two-hand control relay to the nearest hazardous area must be large enough so that if one of the operator elements is released, the hazardous movement is interrupted before the operator reaches the hazardous area or can reach into the hazardous area. You must maintain the minimum distance in accordance with EN ISO 13855.

Depending on the application, serious injury or death may result.

# Wiring

Please note:


- Information given in the "Technical details [ 12] must be followed.
- ▶ The outputs 13-14, 23-24 are safety contacts.
- ▶ To prevent contact welding, a fuse should be connected before the output contacts (see Technical details [☐ 12]).
- ▶ Fit the input terminal block of the control cabined with additional terminals for the supply voltage.
- ▶ Calculation of the max. cable length I<sub>max</sub> in the input circuit:

$$I_{max} = \frac{R_{lmax}}{R_l / km}$$

 $R_{lmax}$  = max. overall cable resistance (see Technical details [ 12])  $R_{l}$  / km = cable resistance/km

- ▶ Use copper wiring with a temperature stability of 60/75 °C.
- ▶ To prevent EMC interferences (particularly common-mode interferences) the measures described in EN 60204-1 must be executed. This includes the separate routing of cables of the control circuits (input, start and feedback loop) from other cables for energy transmission or the shielding of cables, for example.
- ▶ The supply voltage must be switched off with the operating energy of the machine.
- Adequate protection must be provided on all output contacts with capacitive and inductive loads.
- ▶ Do not switch low currents using contacts that have been used previously with high currents.
- ▶ The power supply must comply with the regulations for extra low voltages with protective electrical separation (SELV, PELV) in accordance with VDE 0100, Part 410.

# **Preparing for operation**



# Legend

▶ S1/S2: Two-hand pushbuttons

# Operation



#### **NOTICE**

The safety function should be checked after initial commissioning and each time the plant/machine is changed. The safety functions may only be checked by qualified personnel.

#### **Status indicators**

LEDs indicate the status and errors during operation:



POWER

Supply voltage is present and E-STOP pushbutton not operated.


CH.1
Safety contacts of channel 1 are closed.

Safety contacts of channel 2 are closed.

#### Faults - Interference

- ▶ Earth fault: When in accordance with EN 60204 T 9.4.3.1 the phase L (-) of the supply voltage is connected to the earth potential, earth faults are detected. In case of earth faults in the input circuit or feedback loop, the internal supply voltage fails and the safety contacts open or they will not be closed in the following start. Once the cause of the respective fault has been removed and the supply voltage is switched off for approx. 1 minute, the device is ready for operation again.
- ▶ Contact malfunctions: If the contacts have welded, reactivation will not be possible after the input circuit has opened.

# **Dimensions in mm**



# **Technical details**

CCC, CE, EAC (Eurasian), TÜV, cULus Listed
24 V
DC
-15 %/+10 %
2 W
10 %
100 %
10 mA
14 Ohm
1 A
Max. conductor cross section
EN 574
III A
2
24 V
24 V
40 mA

Relay outputs	
Number of output contacts	
Safety contacts (N/O), instantaneous	2
Max. short circuit current IK	1 kA
Utilisation category	
In accordance with the standard	EN 60947-4-1
Utilisation category of safety contacts	
AC1 at	240 V
Min. current	0,01 A
Max. current	6 A
Max. power	1500 VA
DC1 at	24 V
Min. current	0,01 A
Max. current	6 A
Max. power	150 W
Utilisation category	
In accordance with the standard	EN 60947-5-1
Utilisation category of safety contacts	
AC15 at	230 V
Max. current	5 A
DC13 (6 cycles/min) at	24 V
Max. current	2,5 A
Utilisation category in accordance with UL	
Voltage	240 V AC G. P.
With current	6 A
Voltage	24 V DC Resistive
With current	6 A
Pilot Duty	C300, R300
External contact fuse protection, safety contacts	
In accordance with the standard	EN 60947-5-1
Max. melting integral	240 A²s
Blow-out fuse, quick	6 A
Blow-out fuse, slow	4 A
Blow-out fuse, gG	6 A
Circuit breaker 24V AC/DC, characteristic B/C Conventional thermal current	4 A 6 A
Contact material	AgSnO2 + 0,2μ Au
Times	
Delay-on de-energisation (response time in accordance with EN 574)	
Normally open contact	15 ms
Recovery time	150 ms
Simultaneity, channel 1 and 2 max.	500 ms
Environmental data	
Climatic suitability	EN 60068-2-78

Fundamental data	
Environmental data	
Ambient temperature	
Temperature range	-25 - 55 °C
Storage temperature	
Temperature range	-40 - 85 °C
Climatic suitability	
Humidity	93 % r. h. at 40 °C
Condensation during operation	Not permitted
EMC	EN 60947-5-1, EN 61000-6-2
Vibration	
In accordance with the standard	EN 60068-2-6
Frequency	10 - 55 Hz
Amplitude	0,35 mm
Airgap creepage	
In accordance with the standard	EN 60947-1
Overvoltage category	III / II
Pollution degree	2
Rated insulation voltage	250 V
Rated impulse withstand voltage	4 kV
Protection type	
Housing	IP40
Terminals	IP20
Mounting area (e.g. control cabinet)	IP54
Mechanical data	
Mounting position	Any
Mechanical life	10,000,000 cycles
Material	•
Bottom	PPO UL 94 V0
Front	ABS UL 94 V0
Тор	PPO UL 94 V0
Connection type	Screw terminal
Mounting type	Fixed
Conductor cross section with screw terminals	
1 core flexible	0,2 - 4 mm², 24 - 10 AWG
2 core with the same cross section, flexible with	0,2 + mm , 2+ 10 AVIO
crimp connectors, no plastic sleeve	0,2 - 2,5 mm², 24 - 14 AWG
2 core with the same cross section, flexible without	• • •
crimp connectors or with TWIN crimp connectors	0,2 - 2,5 mm², 24 - 14 AWG
Torque setting with screw terminals	0,6 Nm
Stripping length with screw terminals	8 mm
Dimensions	
Height	87 mm
Width	22,5 mm
Depth	121 mm
Weight	200 g
	-

Where standards are undated, the 2020-07 latest editions shall apply.

#### Safety characteristic data



#### **NOTICE**

You must comply with the safety characteristic data in order to achieve the required safety level for your plant/machine.

Operating mode	EN ISO 13849-1:	EN ISO 13849-1:	EN 62061 SIL CL	EN 62061 PFH <sub>D</sub> [1/h]	IEC 61511	IEC 61511 PFD	EN ISO 13849-1:
	2015	2015	0.12 02		0.12	5	2015
	PL	Category					T <sub>м</sub> [year]
_	PL c	Cat. 1	SIL CL 1	8,53E-08	SIL 1	7,27E-03	20

Explanatory notes for the safety-related characteristic data:

- ▶ The SIL CL value in accordance with EN 62061 corresponds to the SIL value in accordance with EN 61508.
- ▶ T<sub>M</sub> is the maximum mission time in accordance with EN ISO 13849-1. The value also applies as the retest interval in accordance with EN 61508-6 and IEC 61511 and as the proof test interval and mission time in accordance with EN 62061.

All the units used within a safety function must be considered when calculating the safety characteristic data.



#### **INFORMATION**

A safety function's SIL/PL values are **not** identical to the SIL/PL values of the units that are used and may be different. We recommend that you use the PAScal software tool to calculate the safety function's SIL/PL values.

# Supplementary data




#### **CAUTION!**

It is essential to consider the relay's service life graphs. The relay outputs' safety-related characteristic data is only valid if the values in the service life graphs are met.

The PFH value depends on the switch frequency and the load of the relay output. If the service life graphs are not accessible, the stated PFH value can be used irrespective of the switch frequency and the load, as the PFH value already considers the relay's B10d value as well as the failure rates of the other components.

## Service life graph

The service life graphs indicate the number of cycles from which failures due to wear must be expected. The wear is mainly caused by the electrical load; the mechanical load is negligible.



#### **Example**

Inductive load: 0.2 A

▶ Utilisation category: AC15

▶ Contact service life: 4 000 000 cycles

Provided the application to be implemented requires fewer than 4 000 000 cycles, the PFH value (see Technical details) can be used in the calculation.

To increase the service life, sufficient spark suppression must be provided on all output contacts. With capacitive loads, any power surges that occur must be noted. With DC contactors, use flywheel diodes for spark suppression.

# Order reference

Product type	Features	Connection type	Order no.
P1HZ X1	24 V DC	Screw terminals	774360

# EC declaration of conformity

This product/these products meet the requirements of the directive 2006/42/EC for machinery of the European Parliament and of the Council. The complete EC Declaration of Conformity is available on the Internet at www.pilz.com/support/downloads.

Representative: Norbert Fröhlich, Pilz GmbH & Co. KG, Felix-Wankel-Str. 2, 73760 Ostfildern, Germany



Technical support is available from Pilz round the clock.

Americas
Brazil
+55 11 97569-2804
Canada
+1 888 315 7459
Mexico
+52 55 5572 1300
USA (toll-free)
+1 877-PILZUSA (745-9872)

Asia
China
+86 21 60880878-216
Japan
+81 45 471-2281
South Korea
+82 31 778 3300

# Australia +61 3 95600621 Europe Austria +43 1 7986263-0 Belgium, Luxembourg +32 9 3217570 France +33 3 88104003 Germany +49 711 3409-444 Ireland +353 21 4804983 Italy, Malta +39 0362 1826711

Scandinavia +45 74436332 Spain +34 938497433 Switzerland +41 62 88979-32 The Netherlands +31 347 320477 Turkey +90 216 5775552 United Kingdom +44 1536 462203

You can reach our international hotline on: +49 711 3409-444 support@pilz.com

Pilz develops environmentally-friendly products using ecological materials and energy-saving technologies.

Offices and production facilities are ecologically designed, environmentally-aware and energy-saving. So Pilz offers sustainability, plus the security of using energy-efficient products and environmentally-friendly solutions.









CECE®, CHRE®, CMSE®, InduraNET p®, Leansafe®, Master of Safety®, Master of Security®, PAS4000®, PAScal®, PASconifg®, PIL®, PILD®, PMCprino®, PMCprotego®, PMCtendo®, PMD®, PMOS®, PRBT®, PROM®, Primo®, PRTM®, PSEN®, PSS®, PVIS®, SafetyBUS p®, SafetyBYE®, SafetyNET p®, THE SPIRIT OF SAFETY® are registered and protected trademark of PIz GmbH & Co. KG in some countries. We would point out that product features may vary from the details stated in this document, depending on the status at the time of publication and the scope of the equipment. We accept no responsibility for the validity, accuracy and entirety of the text and graphics presented in this information. Please contact our Technical Sup it you have any questions.

We are represented internationally. Please refer to our homepage www.pilz.com for further details or contact our headquarters.

