

PNOZ X3.10P

PILZ THE SPIRIT OF SAFETY


Safety relays

This document is the original document.

All rights to this documentation are reserved by Pilz GmbH & Co. KG. Copies may be made for the user's internal purposes. Suggestions and comments for improving this documentation will be gratefully received.

Source code from third-party manufacturers or open source software has been used for some components. The relevant licence information is available on the Internet on the Pilz homepage.

Pilz®, PIT®, PMI®, PNOZ®, Primo®, PSEN®, PSS®, PVIS®, SafetyBUS p®, SafetyEYE®, SafetyNET p®, the spirit of safety® are registered and protected trademarks of Pilz GmbH & Co. KG in some countries.



Introduction	4
Validity of documentation	4
Using the documentation	4
Definition of symbols	4
D _f_t_t_	_
Safety	
Intended use	
Safety regulations	
Safety assessment	
Use of qualified personnel	
Warranty and liability	
Disposal	
For your safety	6
Unit features	7
	_
Safety features	7
Block diagram/terminal configuration	7
	_
Function Description	
Operating modes	
Timing diagram	9
Installation	9
Wiring	10
Preparing for operation	11
Operation	13
Status indicators	
Faults – Interference	14
Dimensions in mm	14
Technical details	15
Safety characteristic data	
Supplementary data	21
Service life graph	21
Remove plug-in terminals	22
Order reference	. 22
EC declaration of conformity	22
······································	

Introduction

Validity of documentation

This documentation is valid for the product PNOZ X3.10P. It is valid until new documentation is published.

This operating manual explains the function and operation, describes the installation and provides guidelines on how to connect the product.

Using the documentation

This document is intended for instruction. Only install and commission the product if you have read and understood this document. The document should be retained for future reference.

Definition of symbols

Information that is particularly important is identified as follows:



DANGER!

This warning must be heeded! It warns of a hazardous situation that poses an immediate threat of serious injury and death and indicates preventive measures that can be taken.



WARNING!

This warning must be heeded! It warns of a hazardous situation that could lead to serious injury and death and indicates preventive measures that can be taken.



CAUTION!

This refers to a hazard that can lead to a less serious or minor injury plus material damage, and also provides information on preventive measures that can be taken.



NOTICE

This describes a situation in which the product or devices could be damaged and also provides information on preventive measures that can be taken. It also highlights areas within the text that are of particular importance.



INFORMATION

This gives advice on applications and provides information on special features.

Safety

Intended use

The safety relay PNOZ X3.10P provides a safety-related interruption of a safety circuit.

The safety relay meets the requirements of EN 60947-5-1 and EN 60204-1 and may be used in applications with:

- E-STOP pushbuttons
- Safety gates
- Light grids and safety switches with detection of shorts across contacts

The following is deemed improper use in particular

- Any component, technical or electrical modification to the product,
- Use of the product outside the areas described in this manual,
- ▶ Use of the product outside the technical details (see Technical details [^[] 15]).



NOTICE

EMC-compliant electrical installation

The product is designed for use in an industrial environment. The product may cause interference if installed in other environments. If installed in other environments, measures should be taken to comply with the applicable standards and directives for the respective installation site with regard to interference.

Safety regulations

Safety assessment

Before using a device, a safety assessment in accordance with the Machinery Directive is required.

The product as an individual component fulfils the functional safety requirements in accordance with EN ISO 13849 and EN 62061. However, this does not guarantee the functional safety of the overall plant/machine. To achieve the relevant safety level of the overall plant/ machine's required safety functions, each safety function needs to be considered separately.

Use of qualified personnel

The products may only be assembled, installed, programmed, commissioned, operated, maintained and decommissioned by persons who are competent to do so.

A competent person is a qualified and knowledgeable person who, because of their training, experience and current professional activity, has the specialist knowledge required. To be able to inspect, assess and operate devices, systems and machines, the person has to be informed of the state of the art and the applicable national, European and international laws, directives and standards.

It is the company's responsibility only to employ personnel who

- Are familiar with the basic regulations concerning health and safety / accident prevention,
- Have read and understood the information provided in the section entitled Safety
- Have a good knowledge of the generic and specialist standards applicable to the specific application.

Warranty and liability

All claims to warranty and liability will be rendered invalid if

- > The product was used contrary to the purpose for which it is intended,
- Damage can be attributed to not having followed the guidelines in the manual,
- Operating personnel are not suitably qualified,
- Any type of modification has been made (e.g. exchanging components on the PCB boards, soldering work etc.).

Disposal

- ▶ In safety-related applications, please comply with the mission time T_M in the safety-related characteristic data.
- When decommissioning, please comply with local regulations regarding the disposal of electronic devices (e.g. Electrical and Electronic Equipment Act).

For your safety

The unit meets all the necessary conditions for safe operation. However, please note the following:

Note for overvoltage category III: If voltages higher than low voltage (>50 VAC or >120 VDC) are present on the unit, connected control elements and sensors must have a rated insulation voltage of at least 250 V.

Unit features


- Positive-guided relay outputs:
 - 3 safety contacts (N/O), instantaneous
 - 1 auxiliary contact (N/C), instantaneous
- 1 semiconductor output
- Connection options for:
 - E-STOP pushbuttons
 - Safety gate limit switches
 - Start button
 - Light guards and safety switches
- LED display for:
 - Supply voltage
 - Switch status of the safety contacts
- Semiconductor output signals:
 - Switch state of the safety contacts
- Plug-in connection terminals (either spring-loaded terminal or screw terminal)
- See order reference for unit types

Safety features

The safety relay meets the following safety requirements:

- > The circuit is redundant with built-in self-monitoring.
- > The safety function remains effective in the case of a component failure.
- The correct opening and closing of the safety function relays is tested automatically in each on-off cycle.

Block diagram/terminal configuration



*Insulation between the non-marked area and the relay contacts: Basic insulation (overvoltage category III), Protective separation (overvoltage category II)

Function Description

The safety relay PNOZ X3.10P provides a safety-oriented interruption of a safety circuit. When supply voltage is supplied the "POWER" LED is lit. The unit is ready for operation when the start circuit S13-S14 is closed.

- Input circuit is closed (e.g. E-STOP pushbutton not operated):
 - Safety contacts 13-14, 23-24 and 33-34 are closed, auxiliary contact 41-42 is open. The unit is active.
 - The LEDs "CH.1" and "CH.2" are lit.
 - A high signal is present at the semiconductor output switch state Y32.


Input circuit is opened (e.g. E-STOP pushbutton operated):

- Safety contacts 13-14, 23-24 and 33-34 are opened redundantly, auxiliary contact 41-42 is closed.
- The LEDs "CH.1" and "CH.2" go out.
- A low signal is present at the semiconductor output switch state Y32.

Operating modes

- Single-channel operation: No redundancy in the input circuit, earth faults in the start and input circuit are detected.
- Dual-channel operation with detection of shorts across contacts: Redundant input circuit, PNOZ X3.10P detects
 - earth faults in the start and input circuit,
 - short circuits in the input circuit,
 - shorts across contacts in the input circuit.
- Automatic start: Unit is active once the input circuit has been closed.
- Manual start: Unit is active once the input circuit and the start circuit are closed.
- Monitored start: Unit is active once the input circuit is closed and once the start circuit is closed after the waiting period has elapsed (see Technical details [11] 15]).
- Increase in the number of available contacts by connecting contact expandsion modules or external contactors/relays.

Timing diagram



Legend

- Power: Supply voltage
- Start: Start circuit
- Input: Input circuit
- Output safe: Safety contacts
- Output aux: Auxiliary contact
- > Out semi OUT: Semiconductor output switch state
- ▶ [1]: Automatic start
- ▶ [2]: Manual start
- ▶ [3]: Monitored start
- > a: Input circuit closes before start circuit
- b: Start circuit closes before input circuit
- ▶ t₁: Switch-on delay
- ▶ t₂: Delay-on de-energisation
- ▶ t₃: Recovery time
- ▶ t₄: Waiting period with a monitored start

Installation

- The unit should be installed in a control cabinet with a protection type of at least IP54.
- Use the notch on the rear of the unit to attach it to a DIN rail (35 mm).
- When installed vertically: Secure the unit by using a fixing element (e.g. retaining bracket or end angle).

Wiring

Please note:

- ▶ Information given in the "Technical details [↓↓ 15]" must be followed.
- Outputs 13-14, 23-24, 33-34 are safety contacts; output 41-42 is an auxiliary contact (e.g. for display).
- Auxiliary contact 41-42 should not be used for safety circuits!
- > Do not connect undesignated terminals.
- Delivery status of units with screw terminals: Link between S11-S12 (dual-channel input circuit) and link between S15-S16 (safety gate with start-up test)
- ▶ To prevent contact welding, a fuse should be connected before the output contacts (see Technical details [□ 15]).
- Calculation of the max. cable length I_{max} in the input circuit:

$$I_{max} = \frac{R_{lmax}}{R_l / km}$$

 R_{imax} = max. overall cable resistance (see Technical details [44] 15]) R_i / km = cable resistance/km

- ▶ Use copper wiring with a temperature stability of 60/75 °C.
- To prevent EMC interferences (particularly common-mode interferences) the measures described in EN 60204-1 must be executed. This includes the separate routing of cables of the control circuits (input, start and feedback loop) from other cables for energy transmission or the shielding of cables, for example.
- Do not switch low currents using contacts that have been used previously with high currents.
- Adequate protection must be provided on all output contacts with capacitive and inductive loads.
- When connecting magnetically operated, reed proximity switches, ensure that the max. peak inrush current (on the input circuit) does not overload the proximity switch.
- ▶ The power supply must comply with the regulations for extra low voltages with protective electrical separation (SELV, PELV) in accordance with VDE 0100, Part 410.

Important for detection of shorts across contacts:

As this function for detecting shorts across contacts is not failsafe, it is tested by Pilz during the final control check. If there is a danger of exceeding the cable length, we recommend the following test once the unit is installed:

- 1. Unit ready for operation (output contacts closed)
- 2. Short circuit the test terminals S22, S32 for detecting shorts across the inputs.
- 3. The unit's fuse must be triggered and the output contacts must open. Cable lengths in the scale of the maximum length can delay the fuse triggering for up to 2 minutes.
- Reset the fuse: Remove the short circuit and switch off the supply voltage for approx. 1 minute.

Preparing for operation

Supply voltage	AC	DC
	L1 A1 L1 A1 L1 A2 N	L+
Input circuit	Single-channel	Dual-channel
E-STOP without detection of shorts across contacts	$\begin{array}{c c} & & & \text{S12} \\ & & & \text{S12} \\ & & & \text{S21} \\ & & & \text{S22} \\ & & & \text{S32} \\ & & & & \text{S31} \\ \end{array}$	$\begin{array}{c c} & S1 & F_{\rm f} \\ & S11 & F_{\rm f} \\ & S21 & F_{\rm f} \\ & S22 & S12 \\ & S32 \\ & S32 \\ \end{array}$
E-STOP with detection of shorts across contacts		$\begin{array}{c c} & & & \text{S1} & & \\ & & & \text{S22} \\ & & & \text{S11} & & \\ & & & \text{S32} \\ & & & \text{S12} & & \\ & & & \text{S21} \\ & & & & \text{S21} \\ & & & & & \\ & & & & & \\ & & & & & & $
Safety gate without detection of shorts across contacts	$\begin{array}{c c} & & & & \\ & & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & \\ & & \\ & & \\ & & \\ & & \\ & & \\ & & \\ & & \\ & & \\ & & \\ & \\ & & \\$	$\begin{array}{c c} & & & \\ \hline \\ & & \\ & \\ & \\ & \\ & \\ & \\ &$
Safety gate with detection of shorts across contacts		$\begin{array}{c c} & & & & \\ \hline & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & \\ & & \\ & & \\ & & \\ & & \\ & & \\ & & \\ & & \\ & & \\ & & \\ & & \\ & & \\ & & \\ & \\ & & \\ &$
Light guard or safety switch, de- tection of shorts across contacts via ESPE		↓ ↓



NOTICE

With single-channel wiring the safety level of your machine/plant may be lower than the safety level of the unit (see Safety characteristic data [20]).



NOTICE

Operation with a light guard or safety switch

It must not be possible to switch off the supply voltage for the PNOZ X3.10P separately from the supply voltage for the light guard or safety switch.

Start circuit	E-STOP wiring Safety gate without start-up test	Safety gate (dual-channel) with start-up test
Automatic start	, S33 ↔ ↔S15 S34 ↔ ↔S16 S13 ↔ , S14 ↔	$\begin{array}{c c} & & & & \\ \hline 1 & & & \\ \hline 1 & & & \\ \hline 533 & & \\ \hline 534 & & \\ \hline \\ 1 & & \\ \hline \\ 1 & & \\ \hline \\ 1 & \\ 1 & \\ \hline \end{array}$
Manual start	$ \begin{array}{cccccccccccccccccccccccccccccccccccc$	
Monitored start	$\begin{array}{c ccccccccccccccccccccccccccccccccccc$	



NOTICE

In the event of an automatic start or manual start with bridged start contact (fault):

The unit starts up automatically when the safeguard is reset, e.g. when the E-STOP pushbutton is released. Use external circuit measures to prevent an unexpected restart.

Feedback loop	Automatic start	Monitored start
Contacts from external contactors	S13 K5 K6 S14 K5 K6 13 (23, 33) L1 L1 L1 L1 K5 N K6	S33 S33 K5 K6 S34 S34 K5 K6 L1 L1 L1 L1 K6 K6 N

Semiconductor output Y31 0 24 V DC Y32 0 PLC Input Y30 0 0 V

Legend

- S1/S2: E-STOP/safety gate switch
- S3: Reset button
- ▶ 1: Switch operated
- Gate open
- : Gate closed



INFORMATION

With automatic start and manual start, S33 and S34 must not be linked; with monitored start, S13 and S14 must not be linked. S15 and S16 may only be linked on a safety gate with start-up test.

Operation

When the relay outputs are switched on, the mechanical contact on the relay cannot be tested automatically. Depending on the operational environment, measures to detect the non-opening of switching elements may be required under some circumstances.

When the product is used in accordance with the European Machinery Directive, a check must be carried out to ensure that the safety contacts on the relay outputs open correctly. Open the safety contacts (switch off output) and start the device again, so that the internal diagnostics can check that the safety contacts open correctly

for SIL CL 3/PL e at least 1x per month

▶ for SIL CL 2/PL d at least 1x per year



NOTICE

The safety function should be checked after initial commissioning and each time the plant/machine is changed. The safety functions may only be checked by qualified personnel.

Status indicators

LEDs indicate the status and errors during operation:

–o– POWER

Supply voltage is present.

-0-	CH.1 Safety contacts of channel 1 are closed.
-0-	CH.2


Safety contacts of channel 2 are closed.

Faults – Interference

- Earth fault: The supply voltage fails and the safety contacts open. Once the cause of the respective fault has been rectified and the supply voltage is switched off for approx.
 1 minute, the unit is ready for operation again.
- Contact malfunctions: If the contacts have welded, reactivation will not be possible after the input circuit has opened.
- LED "POWER" does not light: Short circuit or no supply voltage.

Dimensions in mm

* with spring-loaded terminals



Technical details

General	777314	787314	
	CCC, CE, EAC (Eurasian), TÜV, CCC, CE, EAC (Eurasian), TÜ ^v		
Certifications	cULus Listed	cULus Listed	
Electrical data	777314	787314	
Supply voltage			
Voltage	24 V	24 V	
Kind	AC/DC	AC/DC	
Voltage tolerance	-15 %/+10 %	-15 %/+10 %	
Output of external power supply (AC)	5 VA	5 VA	
Output of external power supply (DC)	2,5 W	2,5 W	
Frequency range AC	50 - 60 Hz	50 - 60 Hz	
Residual ripple DC	160 %	160 %	
Duty cycle	100 %	100 %	
Max. inrush current impulse			
Current pulse, A1	1,7 A	1,7 A	
Pulse duration, A1	7 ms	7 ms	
Inputs	777314	787314	
Number	2	2	
Voltage at			
Input circuit DC	24 V	24 V	
Start circuit DC	24 V	24 V	
Feedback loop DC	24 V	24 V	
Current at			
Input circuit DC	40 mA	40 mA	
Start circuit DC	70 mA	70 mA	
Feedback loop DC	20 mA	20 mA	
Min. input resistance at power-on	90 Ohm	90 Ohm	
Max. overall cable resistance RI- max			
Single-channel at UB DC	150 Ohm	150 Ohm	
Single-channel at UB AC	180 Ohm	180 Ohm	
Dual-channel without detection of shorts across contacts at UB DC	300 Ohm	300 Ohm	
Dual-channel without detection of shorts across contacts at UB AC	360 Ohm	360 Ohm	
Dual-channel with detection of shorts across contacts at UB DC	15 Ohm	15 Ohm	
Dual-channel with detection of shorts across contacts at UB AC	30 Ohm	30 Ohm	
Semiconductor outputs	777314	787314	
Number	1	1	
	•	•	

Semiconductor outputs	777314	787314
Voltage	24 V	24 V
Current	20 mA	20 mA
External supply voltage	24 V	24 V
Voltage tolerance	-20 %/+20 %	-20 %/+20 %
Residual current at "0" signal	0,1 mA	0,1 mA
Max. internal voltage drop	4 V	4 V
Conditional rated short circuit cur-		
rent	100 A	100 A
Lowest operating current	0 mA	0 mA
Utilisation category in accordance with EN 60947-1	DC-12	DC-12
Relay outputs	777314	787314
Number of output contacts		
Safety contacts (N/O), instant-		
aneous	3	3
Auxiliary contacts (N/C)	1	1
Max. short circuit current IK	1 kA	1 kA
Utilisation category		
In accordance with the standard	EN 60947-4-1	EN 60947-4-1
Utilisation category of safety con- tacts		
AC1 at	240 V	240 V
Min. current	0,01 A	0,01 A
Max. current	8 A	8 A
Max. power	2000 VA	2000 VA
DC1 at	24 V	24 V
Min. current	0,01 A	0,01 A
Max. current	8 A	8 A
Max. power	200 W	200 W
Utilisation category of auxiliary con tacts	-	
AC1 at	240 V	240 V
Min. current	0,01 A	0,01 A
Max. current	8 A	8 A
Max. power	2000 VA	2000 VA
DC1 at	24 V	24 V
Min. current	0,01 A	0,01 A
Max. current	8 A	8 A
Max. power	200 W	200 W
Utilisation category In accordance with the standard		EN 60947-5-1

Relay outputs	777314	787314	
Utilisation category of safety con-			
tacts			
AC15 at	230 V 230 V		
Max. current	5 A	5 A	
DC13 (6 cycles/min) at	24 V	24 V	
Max. current	6 A	6 A	
Utilisation category of auxiliary con-	-		
tacts			
AC15 at	230 V	230 V	
Max. current	5 A	5 A	
DC13 (6 cycles/min) at	24 V	24 V	
Max. current	6 A	6 A	
Utilisation category in accordance with UL			
Voltage	240 V AC G. P.	240 V AC G. P.	
With current	8 A	8 A	
Voltage	24 V DC Resistive	24 V DC Resistive	
With current	5 A	5 A	
Pilot Duty	B300, R300	B300, R300	
External contact fuse protection, safety contacts			
In accordance with the standard	EN 60947-5-1	EN 60947-5-1	
Max. melting integral	240 A²s	240 A²s	
Blow-out fuse, quick	10 A	10 A	
Blow-out fuse, slow	6 A	6 A	
Blow-out fuse, gG	10 A	10 A	
Circuit breaker 24V AC/DC, characteristic B/C	6 A	6 A	
External contact fuse protection, auxiliary contacts			
Max. melting integral	240 A²s	240 A²s	
Blow-out fuse, quick	10 A	10 A	
Blow-out fuse, slow	6 A	6 A	
Blow-out fuse, gG	10 A	10 A	
Circuit breaker 24 V AC/DC,			
characteristic B/C	6 A	6 A	
Contact material	AgSnO2 + 0,2 μm Au	AgSnO2 + 0,2 μm Au	
Conventional thermal current while loading several contacts	777314	787314	
Ith per contact at UB AC; AC1: 240 V, DC1: 24 V			
Conv. therm. current with 1 con- tact	8 A	8 A	
Conv. therm. current with 2 con- tacts		7 A	
Conv. therm. current with 3 con-			
tacts	6 A	6 A	

Conventional thermal current	777314	787314
while loading several contacts	111314	101314
Ith per contact at UB DC;		
AC1: 240 V, DC1: 24 V		
Conv. therm. current with 1 con-		
tact	8 A	8 A
Conv. therm. current with 2 con- tacts	8 A	8 A
Conv. therm. current with 3 con-		
tacts	7 A	7 A
Times	777314	787314
Switch-on delay		
With automatic start typ.	250 ms	250 ms
With automatic start max.	500 ms	500 ms
With automatic start after power		
on typ.	280 ms	280 ms
With automatic start after power	550 ms	550 ms
on max.	200 ms	200 ms
With manual start typ. With manual start max.	200 ms 500 ms	500 ms
With monitored start typ.	35 ms	35 ms
With monitored start max.	50 ms	50 ms
Delay-on de-energisation		
With E-STOP typ.	15 ms	15 ms
With E-STOP max.	30 ms	30 ms
With power failure typ.	180 ms	180 ms
With power failure max.	260 ms	260 ms
Recovery time at max. switching		
frequency 1/s		
After E-STOP	50 ms	50 ms
After power failure	350 ms	350 ms
Waiting period with a monitored		
start	300 ms	300 ms
Min. start pulse duration with a monitored start	30 ms	30 ms
Supply interruption before de-ener-		
gisation	150 ms	150 ms
Simultaneity, channel 1 and 2 max.	∞	∞
Environmental data	777314	787314
Climatic suitability	EN 60068-2-78	EN 60068-2-78
Ambient temperature		
Temperature range	-20 - 55 °C	-20 - 55 °C
Storage temperature		
Temperature range	-40 - 85 °C	-40 - 85 °C
Climatic suitability		
Humidity	93 % r. h. at 40 °C	93 % r. h. at 40 °C
Condensation during operation	Not permitted	Not permitted

Environmental data	777314	787314		
EMC	EN 60947-5-1, EN 61000-6-2, EN EN 60947-5-1, EN 61000-6 61326-3-1 61326-3-1			
Vibration				
In accordance with the standard	EN 60068-2-6	EN 60068-2-6		
Frequency	10 - 55 Hz	10 - 55 Hz		
Amplitude	0,35 mm	0,35 mm		
Airgap creepage				
In accordance with the standard	EN 60947-1	EN 60947-1		
Overvoltage category	111 / 11	111 / 11		
Pollution degree	2	2		
Rated insulation voltage	250 V	250 V		
Rated impulse withstand voltage	4 kV	4 kV		
Protection type				
Housing	IP40	IP40		
Terminals	IP20	IP20		
Mounting area (e.g. control cab-				
inet)	IP54	IP54		
Mechanical data	777314	787314		
Mounting position	Any	Any		
Mechanical life	10,000,000 cycles	10,000,000 cycles		
Material				
Bottom	PPO UL 94 V0	PPO UL 94 V0		
Front	ABS UL 94 V0	ABS UL 94 V0		
Тор	PPO UL 94 V0	PPO UL 94 V0		
Connection type	Screw terminal	Spring-loaded terminal		
Mounting type	plug-in	plug-in		
Conductor cross section with screw terminals	1			
1 core flexible	0,25 - 2,5 mm², 24 - 12 AWG	-		
2 core with the same cross sec-				
tion, flexible with crimp connect- ors, no plastic sleeve	0,25 - 1 mm², 24 - 16 AWG	-		
2 core with the same cross sec-				
tion, flexible without crimp con-				
nectors or with TWIN crimp con-				
nectors	0,2 - 1,5 mm², 24 - 16 AWG			
Torque setting with screw terminals	0,3 MIII			
Stripping length with screw terminals	8 mm			
Conductor cross section with				
spring-loaded terminals: Flexible with/without crimp connector	_	0,2 - 1,5 mm², 24 - 16 AWG		
Spring-loaded terminals: Terminal		0,2 - 1,0 mm , 24 - 10 AWG		
points per connection	_	2		
Stripping length with spring-loaded				
terminals		8 mm		

Mechanical data	777314	787314	
Dimensions			
Height	94 mm	101 mm	
Width	45 mm	45 mm	
Depth	121 mm	121 mm	
Weight	290 g	290 g	

Where standards are undated, the 2020-07 latest editions shall apply.

Safety characteristic data



NOTICE

You must comply with the safety characteristic data in order to achieve the required safety level for your plant/machine.

Operating mode	EN ISO 13849-1: 2015	EN ISO 13849-1: 2015	EN 62061 SIL CL	EN 62061 PFH _D [1/h]	IEC 61511 SIL	IEC 61511 PFD	EN ISO 13849-1: 2015
	PL	Category					T _м [year]
-	PL e	Cat. 4	SIL CL 3	2,31E-09	SIL 3	2,03E-06	20

Explanatory notes for the safety-related characteristic data:

- The SIL CL value in accordance with EN 62061 corresponds to the SIL value in accordance with EN 61508.
- ▶ T_M is the maximum mission time in accordance with EN ISO 13849-1. The value also applies as the retest interval in accordance with EN 61508-6 and IEC 61511 and as the proof test interval and mission time in accordance with EN 62061.

All the units used within a safety function must be considered when calculating the safety characteristic data.



INFORMATION

A safety function's SIL/PL values are **not** identical to the SIL/PL values of the units that are used and may be different. We recommend that you use the PAScal software tool to calculate the safety function's SIL/PL values.

Supplementary data




CAUTION!

It is essential to consider the relay's service life graphs. The relay outputs' safety-related characteristic data is only valid if the values in the service life graphs are met.

The PFH value depends on the switch frequency and the load of the relay output. If the service life graphs are not accessible, the stated PFH value can be used irrespective of the switch frequency and the load, as the PFH value already considers the relay's B10d value as well as the failure rates of the other components.

Service life graph

The service life graphs indicate the number of cycles from which failures due to wear must be expected. The wear is mainly caused by the electrical load; the mechanical load is negligible.



Example

- Inductive load: 0.2 A
- Utilisation category: AC15
- Contact service life: 4 000 000 cycles


Provided the application to be implemented requires fewer than 4 000 000 cycles, the PFH value (see Technical details) can be used in the calculation.

To increase the service life, sufficient spark suppression must be provided on all output contacts. With capacitive loads, any power surges that occur must be noted. With DC contactors, use flywheel diodes for spark suppression.

Remove plug-in terminals

Procedure: Insert the screwdriver into the housing recess behind the terminal and lever the terminal out.

Do not remove the terminals by pulling the cables!



Order reference

Product type	Features	Connection type	Order no.
PNOZ X3.10P C	24 VAC/DC	Spring-loaded terminals	787314
PNOZ X3.10P	24 VAC/DC	Screw terminals	777314

EC declaration of conformity

This product/these products meet the requirements of the directive 2006/42/EC for machinery of the European Parliament and of the Council. The complete EC Declaration of Conformity is available on the Internet at www.pilz.com/support/downloads. Representative: Norbert Fröhlich, Pilz GmbH & Co. KG, Felix-Wankel-Str. 2, 73760 Ostfildern, Germany



Technical support is available from Pilz round the clock.

Pilz develops environmentally-friendly products using ecological materials and energy-saving technologies. Offices and production facilities are ecologically designed,

environmentally-aware and energy-saving. So Pilz offers

sustainability, plus the security of using energy-efficient

products and environmentally-friendly solutions.

Americas

Brazil +55 11 97569-2804 Canada +1 888 315 7459 Mexico +52 55 5572 1300 USA (toll-free) +1 877-PILZUSA (745-9872)

Asia

China +86 21 60880878-216 Japan +81 45 471-2281 South Korea +82 31 778 3300 Australia

+61 3 95600621

Europe

Austria +43 1 7986263-0 Belgium, Luxembourg +32 9 3217570 France +33 3 88104003 Germany +49 711 3409-444 Ireland +353 21 4804983 Italy, Malta +39 0362 1826711 Scandinavia +45 74436332 Spain +34 938497433 Switzerland +41 62 88979-32 The Netherlands +31 347 320477 Turkey +90 216 5775552 United Kingdom +44 1536 462203

You can reach our international hotline on: +49 711 3409-444 support@pilz.com



BLUECOMPETENCE Alliance Member Partner of the Engineering Industry Sustainability Initiative

Partner of: <u>The Best of German</u> Engineering **Co.No. Ket**

rwur, rwur, rwurk, rHBI, ", rHCM", Primo", PRTM", PSEN®, PSIS®, PVIS®, SafetyBUS p[®], SafetyBEYE[®], SafetyNET p[®], THE SPIRT OF SAFETY[®] are registered and protected trademark of PIz GmbH & Co. KG in some countries. We would point out that product features may vary from the details stated in this document, depending on the status at the fine of publication and the scope of the equipment. We accept no responsibility for the validity, accuracy and entirety of the text and graphics presented in this information. Please contact our Technical Sup if you have any questions. , CHRE®, CMSE®, InduraNET p°, Leansafe®, Master of Safety®, Master of Security®, PASc000°, PAScafe, PASconfig®, Pilz®, PIL®, PMCprimo®, PMCpriotego®, PMCtendo®, PMN PNOZ®, PART®, PRNT OF SAFETY® are registered and protected tradema CECE®.

We are represented internationally. Please refer to our homepage www.pilz.com for further details or contact our headquarters.

Headquarters: Pilz GmbH & Co. KG, Felix-Wankel-Straße 2, 73760 Ostfildern, Germany Telephone: +49 711 3409-0, Telefax: +49 711 3409-133, E-Mail: info@pilz.com, Internet: www.pilz.com

