



PILZ THE SPIRIT OF SAFETY

Operating Manual-1003203-EN-11 - Safety relays



This document is the original document.

Where unavoidable, for reasons of readability, the masculine form has been selected when formulating this document. We do assure you that all persons are regarded without discrimination and on an equal basis.

All rights to this documentation are reserved by Pilz GmbH & Co. KG. Copies may be made for the user's internal purposes. Suggestions and comments for improving this documentation will be gratefully received.

Pilz®, PIT®, PMI®, PNOZ®, Primo®, PSEN®, PSS®, PVIS®, SafetyBUS p®, SafetyEYE®, SafetyNET p®, the spirit of safety® are registered and protected trademarks of Pilz GmbH & Co. KG in some countries.



Introduction	5
Validity of documentation	5
Using the documentation	5
Definition of symbols	5
Safety	6
Intended use	6
Safety regulations	7
Safety assessment	
Use of qualified personnel	
Warranty and liability	
Disposal	
For your safety	8
Unit features	8
	-
Safety features	8
	~
Block diagram/terminal configuration	
Type: AC/DC	9
Function description	10
Installation	10
Wiring	.10
Preparing for operation	11
	- 1 7
Operation	
Operation Status indicators.	
Status indicators	. 12
•	. 12
Status indicators	. 12 . <b>12</b>
Status indicators	. 12 . <b>12</b>
Status indicators	. 12 . <b>12</b> . <b>13</b>
Status indicators Faults – Interference Dimensions in mm Technical details	12 <b>12</b> 13
Status indicators	12 <b>12</b> 13
Status indicators         Faults – Interference         Dimensions in mm         Technical details         Safety characteristic data	12 <b>12</b> <b>13</b> <b>13</b> 21
Status indicators Faults – Interference Dimensions in mm Technical details	12 <b>12</b> <b>13</b> 21 21

Remove plug-in terminals	23
Order reference	24
EC declaration of conformity	24
UKCA-Declaration of Conformity	24

# Introduction

#### Validity of documentation

This documentation is valid for the product PZE X4.1P. It is valid until new documentation is published.

This operating manual explains the function and operation, describes the installation and provides guidelines on how to connect the product.

#### Using the documentation

This document is intended for instruction. Only install and commission the product if you have read and understood this document. The document should be retained for future reference.

#### **Definition of symbols**

Information that is particularly important is identified as follows:



## DANGER!

This warning must be heeded! It warns of a hazardous situation that poses an immediate threat of serious injury and death and indicates preventive measures that can be taken.



## WARNING!

This warning must be heeded! It warns of a hazardous situation that could lead to serious injury and death and indicates preventive measures that can be taken.



## CAUTION!

This refers to a hazard that can lead to a less serious or minor injury plus material damage, and also provides information on preventive measures that can be taken.



## NOTICE

This describes a situation in which the product or devices could be damaged and also provides information on preventive measures that can be taken. It also highlights areas within the text that are of particular importance.



#### INFORMATION

This gives advice on applications and provides information on special features.

## Safety

#### Intended use

The contact expansion module PZE X4.1P meets the requirements of EN 60947-5-1 and EN 60204-1. It is an expansion module for increasing the number of contacts available on a base unit. Base units are all

- Safety relays with feedback loop
- programmable safety systems with feedback loop
- Units with OSSD semiconductor outputs and feedback loop

The max. achievable safety level depends on the base unit. The expansion module may not exceed this. The safety-related characteristic values stated under safety-related characteristic data [22] can only be achieved if the base unit also exhibits these safety characteristic values.

#### Improper use

The following is deemed improper use in particular:

- Any component, technical or electrical modification to the product,
- > Use of the product outside the areas described in this operating manual,
- Use of the product outside the technical details (see chapter entitled Technical Details [2] 13]).



## NOTICE

#### **EMC**-compliant electrical installation

The product is designed for use in an industrial environment. The product may cause interference if installed in other environments. If installed in other environments, measures should be taken to comply with the applicable standards and directives for the respective installation site with regard to interference.

## Safety regulations

#### Safety assessment

Before using a device, a safety assessment in accordance with the Machinery Directive is required.

The product as an individual component fulfils the functional safety requirements in accordance with EN ISO 13849 and EN IEC 62061. However, this does not guarantee the functional safety of the overall plant/machine. To achieve the relevant safety level of the overall plant/machine's required safety functions, each safety function needs to be considered separately.

#### Use of qualified personnel

The products may only be assembled, installed, programmed, commissioned, operated, maintained and decommissioned by persons who are competent to do so.

A competent person is a qualified and knowledgeable person who, because of their training, experience and current professional activity, has the specialist knowledge required. To be able to inspect, assess and operate devices, systems and machines, the person has to be informed of the state of the art and the applicable national, European and international laws, directives and standards.

It is the company's responsibility only to employ personnel who

- > Are familiar with the basic regulations concerning health and safety / accident prevention,
- Have read and understood the information provided in the section entitled Safety
- Have a good knowledge of the generic and specialist standards applicable to the specific application.

#### Warranty and liability

All claims to warranty and liability will be rendered invalid if

- > The product was used contrary to the purpose for which it is intended,
- > Damage can be attributed to not having followed the guidelines in the manual,
- > Operating personnel are not suitably qualified,
- Any type of modification has been made (e.g. exchanging components on the PCB boards, soldering work etc.).

#### Disposal

- ▶ In safety-related applications, please comply with the mission time T<sub>M</sub> in the safety-related characteristic data.
- When decommissioning, please comply with local regulations regarding the disposal of electronic devices (e.g. Electrical and Electronic Equipment Act).

## For your safety

The unit meets all the necessary conditions for safe operation. However, please note the following:

Note for overvoltage category III: If voltages higher than low voltage (>50 VAC or >120 VDC) are present on the unit, connected control elements and sensors must have a rated insulation voltage of at least 250 V.

## **Unit features**

- Positive-guided relay outputs:
  - 4 safety contacts (N/O), instantaneous
- LED display for:
  - Supply voltage
  - Switch status of the safety contacts
- Connection for feedback loop
- Suitable to be driven via OSSD
- Operation: Single or dual-channel
- > Plug-in connection terminals (either spring-loaded terminal or screw terminal)
- See order reference for unit types

## **Safety features**


The unit meets the following safety requirements:

- The contact expansion module expands an existing circuit. As the output relays are monitored via the base unit's feedback loop, the safety functions on the existing circuit are transferred to the contact expandsion module.
- > The safety function remains effective in the case of a component failure.
- Earth fault in the feedback loop: Detected, depending on the base unit that is used.
- Earth fault in the input circuit: The output relays de-energise and the safety contacts open.


# Block diagram/terminal configuration

## Type: DC

▶ U<sub>B</sub>: 24 DC; Order no. 777587, 787587



\*Safe separation from non-marked area in accordance with EN 60947-1, 6 kV, basic insulation between all safety contacts.



\*Insulation between the non-marked area and the relay contacts: Basic insulation (overvoltage category III), Protective separation (overvoltage category II)

## Type: AC/DC

▶ U<sub>B</sub>: 24 - 240 VAC/DC; Order no. 777588, 787588

## **Function description**

The contact expansion module PZE X4.1P is an add-on device without delay-on de-energisation. It is used to expand a safety circuit. The contact expansion module is driven by a base unit (e. g. emergency stop relay). When operating voltage is supplied the "POWER" LED will light.

- Functional procedure once the input circuit is closed (e.g. safety contacts on the base unit are closed):
  - The safety contacts 13-14, 23-24, 33-34 and 43-44 close.
  - The LEDs "CH.1" and "CH.2" are lit.
- Functional procedure once the input circuit is opened (e.g. safety contacts on the base unit are opened):
  - Safety contacts 13-14, 23-24, 33-34 and 43-44 are opened redundantly.
  - The LEDs "CH.1" and "CH.2" go out.

## Installation

- > The unit should be installed in a control cabinet with a protection type of at least IP54.
- ▶ Use the notch on the rear of the unit to attach it to a DIN rail (35 mm).
- When installed vertically: Secure the unit by using a fixing element (e.g. retaining bracket or end angle).

## Wiring

Please note:

- ▶ Information given in the "Technical details [□ 13]" must be followed.
- The outputs 13-14, 23-24, 33-34 and 43-44 are safety contacts.
- Do not connect undesignated terminals.
- To prevent contact welding, a fuse should be connected before the output contacts (see Technical details [13]).
- $\blacktriangleright$  Calculation of the max. cable length  $I_{\rm max}$  in the input circuit:

$$I_{max} = \frac{R_{lmax}}{R_l / km}$$

 $R_{imax}$  = max. overall cable resistance (see Technical details [ $\square$  13])  $R_i / km$  = cable resistance/km


- ▶ Use copper wiring with a temperature stability of 60/75 °C.
- To prevent EMC interferences (particularly common-mode interferences) the measures described in EN 60204-1 must be executed. This includes the separate routing of cables of the control circuits (input, start and feedback loop) from other cables for energy transmission or the shielding of cables, for example.
- Adequate protection must be provided on all output contacts with capacitive and inductive loads.
- Do not switch low currents using contacts that have been used previously with high currents.

On 24 VDC devices:

The power supply must comply with the regulations for extra low voltages with protective electrical separation (SELV, PELV) in accordance with VDE 0100, Part 410.

# Preparing for operation

Supply voltage	24 - 240 VAC/DC	24 VDC
Only when driven via safety relay with safety contacts	$ \begin{array}{cccccccccccccccccccccccccccccccccccc$	L+



Feedback loop	Base unit: Safety relay PNOZ X	Base unit: PNOZelog safety relay, programmable safety system or PNOZmulti
Y1, Y2 and Input are inputs on the base unit; they evaluate the feedback loop	Y1 0 Y1 Y2 0 Y2 Y2 0 Y2 PZE	24 V DC 24 V DC 24 V DC V1 Input 0 Y2 PZE

# Operation

When the relay outputs are switched on, the mechanical contact on the relay cannot be tested automatically. Depending on the operational environment, measures to detect the non-opening of switching elements may be required under some circumstances.

When the product is used in accordance with the European Machinery Directive, a check must be carried out to ensure that the safety contacts on the relay outputs open correctly. Open the safety contacts of the contact expansion module (switch off outputs of the base unit) and start the base unit again so that the internal diagnostics can check that the safety contacts open correctly

for SIL CL 3/PL e at least 1x per month

▶ for SIL CL 2/PL d at least 1x per year



## NOTICE

The safety functions should be checked after initial commissioning and each time the plant/machine is changed. The safety functions may only be checked by qualified personnel.

## **Status indicators**

LEDs indicate the status and errors during operation:



-Ò(-POWER

Supply voltage is present.



Safety contacts of channel 1 are closed.

-)\_\_\_\_\_\_\_ CH.2

Safety contacts of channel 2 are closed.

## Faults – Interference


By closing or interrupting the input circuit you can check whether the unit switches on or off correctly.

For safety reasons, the unit cannot be started if the following faults are present:

- Contact malfunction: As the contact block is connected to a base unit, reactivation will not be possible if the contacts have welded after the input circuit has opened.
- > Open circuit, short circuit or earth fault (e.g. in the input circuit)

# Dimensions in mm

\* with spring-loaded terminals



# **Technical details**

## Order no. 777587 – 787587

See below for more order numbers

General	777587	787587
Certifications	CCC, CE, EAC, TÜV, UKCA, cULus Listed	CCC, CE, EAC, TÜV, UKCA, cULus Listed
Electrical data	777587	787587
Supply voltage		
Voltage	24 V	24 V
Kind	DC	DC
Voltage tolerance	-15 %/+10 %	-15 %/+10 %
Output of external power supply (DC)	2,5 W	2,5 W
Residual ripple DC	20 %	20 %
Duty cycle	100 %	100 %
Max. inrush current impulse		
Current pulse, A1	1,7 A	1,7 A
Pulse duration, A1	1,5 ms	1,5 ms
Inputs	777587	787587
Quantity	2	2
Voltage at		
Input circuit DC	24 V	24 V
Current at		
Input circuit DC	35 mA	35 mA

777587	787587
30 Ohm	30 Ohm
60 Ohm	60 Ohm
111301	787587
4	4
	1 kA
EN 60947-4-1	EN 60947-4-1
240 V	240 V
0,01 A	0,01 A
6 A	6 A
1500 VA	1500 VA
24 V	24 V
0,01 A	0,01 A
6 A	6 A
150 W	150 W
EN 60947-5-1	EN 60947-5-1
230 V	230 V
3 A	3 A
24 V	24 V
4 A	4 A
250 V AC G.U. (same polarity)	250 V AC G.U. (same polarity)
6 A	6 A
	24 V DC G. U.
• • •	6 A
B300, R300	B300, R300
	EN 60947-5-1
66 A²s	66 A²s
	6 A
	4 A
6 A	6 A
	60 Ohm 777587 4 1 kA EN 60947-4-1 240 V 0,01 A 6 A 1500 VA 24 V 0,01 A 6 A 1500 VA 24 V 0,01 A 6 A 150 W EN 60947-5-1 230 V 3 A 24 V 4 A 250 V AC G.U. (same polarity) 6 A 24 V 4 A EN 60947-5-1

Relay outputs	777587	787587
Contact material	AgCuNi + 0,2 μm Au	AgCuNi + 0,2 μm Au
Conventional thermal current	777587	787587
while loading several contacts		
Ith per contact at UB DC;		
AC1: 240 V, DC1: 24 V		
Conv. therm. current with 1 con- tact	6 A	6 A
Conv. therm. current with 2 con- tacts	6 A	6 A
Conv. therm. current with 3 con- tacts	4,5 A	4,5 A
Conv. therm. current with 4 con-	•	-,
tacts	3,5 A	3,5 A
Times	777587	787587
Switch-on delay		
with automatic start typ.	15 ms	15 ms
with automatic start max.	20 ms	20 ms
with automatic start after power		
on typ.	15 ms	15 ms
with automatic start after power on max.	30 ms	30 ms
Delay-on de-energisation		
with E-STOP typ.	10 ms	10 ms
with E-STOP max.	20 ms	20 ms
with power failure typ.	60 ms	60 ms
with power failure max.	80 ms	80 ms
Supply interruption before de-ener- gisation in the input circuit	2 ms	2 ms
Supply interruption before de-ener-		
gisation	20 ms	20 ms
Environmental data	777587	787587
Climatic suitability	EN 60068-2-78	EN 60068-2-78
Ambient temperature		
Temperature range	-10 - 55 °C	-10 - 55 °C
Storage temperature		
Temperature range	-40 - 85 °C	-40 - 85 °C
Climatic suitability		
Humidity	93 % r. h. at 40 °C	93 % r. h. at 40 °C
Condensation during operation	Not permitted	Not permitted
EMC	EN 60947-5-1, EN 61000-6-2, EN 61326-3-1	EN 60947-5-1, EN 61000-6-2, EN 61326-3-1
Vibration		
in accordance with the standard	EN 60068-2-6	EN 60068-2-6
Frequency	10 - 55 Hz	10 - 55 Hz
Amplitude	0,35 mm	0,35 mm
	0,35 mm	0,35 mm

Environmental data	777587	787587
Airgap creepage		
in accordance with the standard	EN 60947-1	EN 60947-1
Overvoltage category	111	III
Pollution degree	2	2
Rated insulation voltage	250 V	250 V
Rated impulse withstand voltage	6 kV	6 kV
Protection type		
Housing	IP40	IP40
Terminals	IP20	IP20
Mounting area (e.g. control cab-		
inet)	IP54	IP54
Mechanical data	777587	787587
Mounting position	Any	Any
Mechanical life	10,000,000 cycles	10,000,000 cycles
Material		
Bottom	PPO UL 94 V1	PPO UL 94 V1
Front	ABS UL 94 V0	ABS UL 94 V0
Тор	PPO UL 94 V1	PPO UL 94 V1
Connection type	Screw terminal	Spring-loaded terminal
Mounting type	plug-in	plug-in
Conductor cross section with screw terminals	1	
1 core flexible	0,25 - 2,5 mm², 24 - 12 AWG	_
2 core with the same cross sec- tion, flexible with crimp connect- ors, no plastic sleeve	0,25 - 1 mm², 24 - 16 AWG	_
2 core with the same cross sec- tion, flexible without crimp con- nectors or with TWIN crimp con-		
nectors	0,2 - 1,5 mm², 24 - 16 AWG	
Torque setting with screw terminals Stripping length with screw termin-	, , , , , , , , , , , , , , , , , , ,	
als	8 mm	_
Conductor cross section with		
spring-loaded terminals: Flexible with/without crimp connector		0,2 - 1,5 mm², 24 - 16 AWG
Spring-loaded terminals: Terminal points per connection	_	2
Stripping length with spring-loaded terminals	_	8 mm
Dimensions		
Height	94 mm	101 mm
Width	22,5 mm	22,5 mm
Depth	121 mm	121 mm
Weight	185 g	185 g

Where standards are undated, the 2022-09 latest editions shall apply.

## Order no. 777588 – 787588

777588	787588
CCC, CE, EAC, TÜV, UKCA, cULus Listed	CCC, CE, EAC, TÜV, UKCA, cULus Listed
777588	787588
24 - 240 V	24 - 240 V
AC/DC	AC/DC
-15 %/+10 %	-15 %/+10 %
4 VA	4 VA
2 W	2 W
50 - 60 Hz	50 - 60 Hz
20 %	20 %
100 %	100 %
777588	787588
2	2
24 V	24 V
30 mA	30 mA
70 Ohm	70 Ohm
70 Ohm	70 Ohm
140 Ohm	140 Ohm
140 Ohm	140 Ohm
	787588
4	4
1 kA	1 kA
	CCC, CE, EAC, TÜV, UKCA, CULus Listed 777588 24 - 240 V AC/DC -15 %/+10 % 4 VA 2 W 50 - 60 Hz 20 % 100 % 777588 2 2 24 V 30 mA 70 Ohm 70 Ohm 70 Ohm 70 Ohm 7140 Ohm

Relay outputs	777588	787588
Utilisation category of safety con-		
tacts		
AC1 at	240 V	240 V
Min. current	0,01 A	0,01 A
Max. current	6 A	6 A
Max. power	1500 VA	1500 VA
DC1 at	24 V	24 V
Min. current	0,01 A	0,01 A
Max. current	6 A	6 A
Max. power	150 W	150 W
Utilisation category		
in accordance with the standard	EN 60947-5-1	EN 60947-5-1
Utilisation category of safety con- tacts		
AC15 at	230 V	230 V
Max. current	3 A	3 A
DC13 (6 cycles/min) at	24 V	24 V
Max. current	4 A	4 A
Utilisation category in accordance with UL		
Voltage	250 V AC G.U. (same polarity)	250 V AC G.U. (same polarity)
with current	6 A	6 A
Voltage	24 V DC G. U.	24 V DC G. U.
with current	6 A	6 A
Pilot Duty	B300, R300	B300, R300
External contact fuse protection, safety contacts		
in accordance with the standard	EN 60947-5-1	EN 60947-5-1
Max. melting integral	66 A²s	66 A²s
Blow-out fuse, quick	6 A	6 A
Blow-out fuse, slow	4 A	4 A
Blow-out fuse, gG	6 A	6 A
Circuit breaker 24V AC/DC,		
characteristic B/C	4 A	4 A
Contact material	AgCuNi + 0,2 μm Au	AgCuNi + 0,2 μm Au
Conventional thermal current while loading several contacts	777588	787588
Ith per contact at UB AC; AC1: 240 V, DC1: 24 V		
Conv. therm. current with 1 con- tact	6 A	6 A
Conv. therm. current with 2 con- tacts	6 A	6 A
Conv. therm. current with 3 con- tacts	4,5 A	4,5 A
Conv. therm. current with 4 con- tacts	3,5 A	3,5 A

	777500	707500
Conventional thermal current while loading several contacts	777588	787588
Ith per contact at UB DC;		
AC1: 240 V, DC1: 24 V		
Conv. therm. current with 1 con- tact	6 A	6 A
Conv. therm. current with 2 con- tacts	6 A	6 A
Conv. therm. current with 3 con- tacts	4,5 A	4,5 A
Conv. therm. current with 4 con- tacts	3,5 A	3,5 A
Times	777588	787588
Switch-on delay		
with automatic start typ.	15 ms	15 ms
with automatic start max.	20 ms	20 ms
with automatic start after power on typ.	230 ms	230 ms
with automatic start after power on max.	360 ms	360 ms
Delay-on de-energisation		
with E-STOP typ.	10 ms	10 ms
with E-STOP max.	20 ms	20 ms
with power failure typ. UB 240 V	1300 ms	1300 ms
with power failure max. UB 240 V	1900 ms	1900 ms
with power failure typ. UB 24 V	270 ms	270 ms
with power failure max. UB 24 V	350 ms	350 ms
Supply interruption before de-ener- gisation in the input circuit	2 ms	2 ms
Supply interruption before de-ener-		
gisation	20 ms	20 ms
Environmental data	777588	787588
Climatic suitability	EN 60068-2-78	EN 60068-2-78
Ambient temperature		
Temperature range	-10 - 55 °C	-10 - 55 °C
Storage temperature		
Temperature range	-40 - 85 °C	-40 - 85 °C
Climatic suitability		
Humidity	93 % r. h. at 40 °C	93 % r. h. at 40 °C
Condensation during operation	Not permitted	Not permitted
EMC	EN 60947-5-1, EN 61000-6-2, EN 61000-6-4, EN 61326-3-1	EN 60947-5-1, EN 61000-6-2, EN 61000-6-4, EN 61326-3-1
Vibration		
in accordance with the standard	EN 60068-2-6	EN 60068-2-6
Frequency	10 - 55 Hz	10 - 55 Hz
Amplitude	0,35 mm	0,35 mm
		•

Environmental data	777588	787588
Airgap creepage		
in accordance with the standard	EN 60947-1	EN 60947-1
Overvoltage category	111 / 11	111 / 11
Pollution degree	2	2
Rated insulation voltage	250 V	250 V
Rated impulse withstand voltage	4 kV	4 kV
Protection type		
Housing	IP40	IP40
Terminals	IP20	IP20
Mounting area (e.g. control cab-		
inet)	IP54	IP54
Mechanical data	777588	787588
Mounting position	Any	Any
Mechanical life	10,000,000 cycles	10,000,000 cycles
Material		
Bottom	PPO UL 94 V1	PPO UL 94 V1
Front	ABS UL 94 V0	ABS UL 94 V0
Тор	PPO UL 94 V1	PPO UL 94 V1
Connection type	Screw terminal	Spring-loaded terminal
Mounting type	plug-in	plug-in
Conductor cross section with screw terminals	1	
1 core flexible	0,25 - 2,5 mm², 24 - 12 AWG	_
2 core with the same cross sec- tion, flexible with crimp connect- ors, no plastic sleeve	0,25 - 1 mm², 24 - 16 AWG	_
2 core with the same cross sec- tion, flexible without crimp con- nectors or with TWIN crimp con-		
	0,2 - 1,5 mm <sup>2</sup> , 24 - 16 AWG	
Torque setting with screw terminals	5 U,Ə NM	
Stripping length with screw terminals	8 mm	_
Conductor cross section with		
spring-loaded terminals: Flexible		
with/without crimp connector		0,2 - 1,5 mm², 24 - 16 AWG
Spring-loaded terminals: Terminal points per connection	-	2
Stripping length with spring-loaded terminals	_	8 mm
Dimensions		
Height	94 mm	101 mm
Width	22,5 mm	22,5 mm
Depth	121 mm	121 mm
Weight	215 g	215 g

Where standards are undated, the 2022-09 latest editions shall apply.

## Safety characteristic data



#### NOTICE

You must comply with the safety characteristic data in order to achieve the required safety level for your plant/machine.

Operating mode	EN ISO 13849-1: 2015 PL	EN ISO 13849-1: 2015 Category	EN IEC 62061 SIL CL/ maximum SIL	EN IEC 62061 PFH <sub>D</sub> [1/h]	EN/IEC 61511 SIL	EN/IEC 61511 PFD	EN ISO 13849-1: 2015 T <sub>M</sub> [year]
_	PL e	Cat. 4	SIL 3	2,31E-09	SIL 3	2,03E-06	20

Explanatory notes for the safety-related characteristic data:

- Safety characteristic data in accordance with EN IEC 62061 and EN/IEC 61511 was calculated based on EN/IEC 61508.
- T<sub>M</sub> is the maximum mission time in accordance with EN ISO 13849-1. The value also applies as the retest interval in accordance with EN/IEC 61508-6 and EN/IEC 61511 and as the proof test interval and mission time in accordance with EN IEC 62061.

All the units used within a safety function must be considered when calculating the safety characteristic data.



#### INFORMATION

A safety function's SIL/PL values are **not** identical to the SIL/PL values of the units that are used and may be different. We recommend that you use the PAScal software tool to calculate the safety function's SIL/PL values.

## Supplementary data



#### **CAUTION!**

It is essential to consider the relay's service life graphs. The relay outputs' safety-related characteristic data is only valid if the values in the service life graphs are met.

The PFH value depends on the switch frequency and the load of the relay output. If the service life graphs are not accessible, the stated PFH value can be used irrespective of the switch frequency and the load, as the PFH value already considers the relay's B10d value as well as the failure rates of the other components.

## Service life graph

The service life graphs indicate the number of cycles from which failures due to wear must be expected. The wear is mainly caused by the electrical load; the mechanical load is negligible.




Fig.: Service life graphs at 24 VDC and 230 VAC




Fig.: Service life graphs at 110 VDC

#### Example

- Inductive load: 0.2 A
- Utilisation category: AC15
- Contact service life: 1 000 000 cycles

Provided the application to be implemented requires fewer than 1 000 000 cycles, the PFH value (see Technical details [ 13]) can be used in the calculation.

To increase the service life, sufficient spark suppression must be provided on all relay contacts. With capacitive loads, any power surges that occur must be noted. With DC contactors, use flywheel diodes for spark suppression.


## **Remove plug-in terminals**

#### Procedure

Insert a suitable screwdriver into the housing recess behind the terminal.

Do not remove the terminals by pulling the cables!

Lever the terminal out.



Product type	Features	Connection type	Order no.
PZE X4.1P	24 V DC	Screw terminals, plug-in	777587
PZE X4.1P C	24 V DC	Spring-loaded terminals, plug-in	787587
PZE X4.1P	24-240 V AC/DC	Screw terminals, plug-in	777588
PZE X4.1P C	24-240 V AC/DC	Spring-loaded terminals, plug-in	787588

## **Order reference**

# EC declaration of conformity

This product/these products meet the requirements of the directive 2006/42/EC on machinery of the European Parliament and of the Council. The complete EC Declaration of Conformity is available on the Internet at www.pilz.com/downloads.

Representative: Hansjürgen Horter, Pilz GmbH & Co. KG, Felix-Wankel-Straße 2, 73760 Ostfildern, Germany

# **UKCA-Declaration of Conformity**

This product(s) complies with following UK legislation: Supply of Machinery (Safety) Regulation 2008.

The complete UKCA Declaration of Conformity is available on the Internet at www.pilz.com/ downloads.

Representative: Pilz Automation Technology, Pilz House, Little Colliers Field, Corby, Northamptonshire, NN18 8TJ United Kingdom, eMail: mail@pilz.co.uk

# Support

Technical support is available from Pilz round the clock.

#### Americas

Brazil +55 11 97569-2804 Canada +1 888 315 7459 Mexico +52 55 5572 1300 USA (toll-free) +1 877-PILZUSA (745-9872)

#### Asia

China +86 21 60880878-216 Japan +81 45 471-2281 South Korea +82 31 778 3300

#### Australia and Oceania

Australia +61 3 95600621 New Zealand +64 9 6345350

#### Europe

Austria +43 1 7986263-0 Belgium, Luxembourg +32 9 3217570 France +33 3 88104003 Germany +49 711 3409-444 Ireland +353 21 4804983 Italy, Malta +39 0362 1826711

Pilz develops environmentally-friendly products using ecological materials and energy-saving technologies. Offices and production facilities are ecologically designed, environmentally-aware and energy-saving. So Pilz offers sustainability, plus the security of using energy-efficient products and environmentally-friendly solutions.









Scandinavia +45 74436332 Spain +34 938497433 Switzerland +41 62 88979-32 The Netherlands +31 347 320477 Turkey +90 216 5775552 United Kingdom +44 1536 462203

## You can reach our international hotline on: +49 711 3409-222 support@pilz.com

003203-EN-11, 2023-06 Printed in Germany © Pilz GmbH & Co. KG, 2019

CECE®, CHRE®, CMSE®, InduraNET p<sup>®</sup>, Leansate®, Master of Safety®, Master of Security®, PAScoal®, PASconfig®, Pitz®, PTB, PLID®, PMCprimo®, PMCprotego®, PMCtendo®, PMCP, PMMS, PRIM®, PSRIM®, PRIM®, PSRIM®, PSRIM PSRIM®, PSRI%, PSRIM®, PSRIM®, PSRIM®, PSRI%, PSRI and the scope of the equipment. f you have any questions.

We are represented internationally. Please refer to our homepage www.pilz.com for further details or contact our headquarters.

Headquarters: Pilz GmbH & Co. KG, Felix-Wankel-Straße 2, 73760 Ostfildern, Germany Telephone: +49 711 3409-0, Telefax: +49 711 3409-133, E-Mail: info@pilz.com, Internet: www.pilz.com

