

Wonderware®

GESRTP DAServer User's Guide

Invensys Systems, Inc.

Revision 1.5

Last Revision: 2/19/07



Copyright

© 2006, 2007 Invensys Systems, Inc. All Rights Reserved.

All rights reserved. No part of this documentation shall be reproduced, stored in a retrieval system, or transmitted by any means, electronic, mechanical, photocopying, recording, or otherwise, without the prior written permission of Invensys Systems, Inc. No copyright or patent liability is assumed with respect to the use of the information contained herein. Although every precaution has been taken in the preparation of this documentation, the publisher and the author assume no responsibility for errors or omissions. Neither is any liability assumed for damages resulting from the use of the information contained herein.

The information in this documentation is subject to change without notice and does not represent a commitment on the part of Invensys Systems, Inc. The software described in this documentation is furnished under a license or nondisclosure agreement. This software may be used or copied only in accordance with the terms of these agreements.

Invensys Systems, Inc.
26561 Rancho Parkway South
Lake Forest, CA 92630 U.S.A.
(949) 727-3200

<http://www.wonderware.com>

Trademarks

All terms mentioned in this documentation that are known to be trademarks or service marks have been appropriately capitalized. Invensys Systems, Inc. cannot attest to the accuracy of this information. Use of a term in this documentation should not be regarded as affecting the validity of any trademark or service mark.

Alarm Logger, ActiveFactory, ArcestrA, Avantis, DBDump, DBLoad, DT Analyst, FactoryFocus, FactoryOffice, FactorySuite, FactorySuite A², InBatch, InControl, IndustrialRAD, IndustrialSQL Server, InTouch, MaintenanceSuite, MuniSuite, QI Analyst, SCADAAlarm, SCADASuite, SuiteLink, SuiteVoyager, WindowMaker, WindowViewer, Wonderware, and Wonderware Logger are trademarks of Invensys plc, its subsidiaries and affiliates. All other brands may be trademarks of their respective owners.

Contents

Welcome.....	7
About this Book	7
Documentation Conventions.....	8
Technical Support	8
Chapter 1 Introduction	9
Overview	9
Communications Protocols.....	10
Application Communications Protocols.....	10
Device Communications Protocols.....	11
Accessing Items via the DAServer	12
Accessing Items Using the OPC Communications Protocol	12
Accessing Items Using the DDE/SuiteLink Communications Protocol	14
Features	15
Demo Mode	15
Windows Firewall Considerations.....	16
Chapter 2 Configuration.....	19
Getting Started Quickly with the GESRTP DAServer ...	19
Configuring the GESRTP DAServer	21
GESRTP Hierarchy in the DAServer Manager	23
Defining Poke Modes.....	28
Defining Device Groups and Device Items.....	28
Device Group Definitions	29
Device Item Definitions.....	30
Scan-Based Message Handling.....	34

Unsolicited Message Handling	35
Archiving Configuration Sets	36
Hot Configuration	37
Chapter 3 Item Naming	39
Suffixes to Explicitly Control Data Type	39
F Suffix.....	40
M Suffix.....	40
S Suffix.....	40
L Suffix.....	41
A Suffix	41
B or BCD Suffix.....	42
Status Items	43
Base Item Names	46
Conversions and Suffixes of Items	48
Suffix B or BCD	48
Suffix F.....	49
Suffix M.....	49
Suffix S.....	49
Suffix L.....	49
Suffix A	49
DAServer Standard System Items	49
DAServer Global System Item	51
DAServer Device-Specific System Items.....	52
DAServer Device-Group-Specific System Items	54
DAServer-Specific System Items.....	57
Generic OPC Syntax	58
Chapter 4 Troubleshooting	61
Finding the DAServer Version Number	61
Monitoring Connectivity Status with the PLC	62
Monitoring the Status of DAS Conversations	63
Using DDEStatus and IOStatus in Excel	63
Reading Values from the DAServer into Excel.....	63
Writing Values to the DAServer from Excel.....	64
Diagnostics and Error Tracing	65
Error Tracing with the Wonderware Logger	65
Error Messages, Codes, and Warnings	66
Data Conversion	80
Quality Settings	80

Chapter 5	Reference	85
	DAServer Architecture.....	85
	DAServers	86
	Component Environments	87
Appendix A	Supported DAServer Hardware and Firmware	89
	Index	91

Welcome

This documentation describes how to use and customize the GESRTP DAServer application.

You can view this document online or you can print it using Adobe Acrobat Reader.

It is assumed that you know how to use Microsoft Windows, including navigating menus, moving from application to application, and moving objects on the screen. If you need help with these tasks, see the Microsoft online Help.

In some areas of the GESRTP DAServer, you can also right-click to open a menu. The items listed on this menu change, depending on where you are in the product. All items listed on this menu are available as items on the main menus.

About this Book

This documentation is organized as follows:

- **Contents**
- **Introduction.** Contains overview information about the GESRTP DAServer, its features, and the environment in which it works.
- **Configuration.** Contains a detailed description of the DAServer user-interface elements and functionality.
- **Item Names.** Describes the item-naming conventions for targeted devices.
- **Troubleshooting.** Provides information about error messages displayed by this DAServer, monitoring connectivity status with the device or the status of DAS conversations, and debugging communications between the DAServer and the targeted device.

- **Reference.** Describes the DAServer architecture in general.
- **Index**

Documentation Conventions

This documentation uses the following conventions:

Convention	Used for
Initial Capitals	Paths and filenames.
Bold	Menus, commands, dialog box names, and dialog box options.
Monospace	Code samples and display text.

Technical Support

Wonderware Technical Support offers a variety of support options to answer any questions on Wonderware products and their implementation.

Before you contact Technical Support, refer to the relevant section(s) in this documentation for a possible solution to any problem you have. If you need to contact technical support for help, have the following information ready:

- The type and version of the operating system you are using. For example, Microsoft Windows XP, SP1.
- Details of how to recreate the problem.
- The exact wording of the error messages you saw.
- Any relevant output listing from the Log Viewer or any other diagnostic applications.
- Details of what you did to try to solve the problem(s) and your results.

If known, the Wonderware Technical Support case number assigned to your problem, if this is an ongoing problem.

Chapter 1

Introduction

This section describes the Wonderware® GESRTP (GE Service Request Transfer Protocol) DAServer (Data Access Server), including the application-level and bus-level communications protocols, item naming conventions, and server features.

Overview

The GESRTP DAServer is a Microsoft® Windows® application program that acts as a communications protocol server. It provides other Windows application programs with access to data within the GE Fanuc family of PLCs. The GESRTP DAServer provides access to a GE Fanuc PLC through a standard Ethernet network interface card in the computer.

Note The GESRTP DAServer supports multiple network interface cards in the computer. The network card that the server uses depends on the operating system.

The GESRTP DAServer supports the GE Fanuc family of hardware and firmware listed in Supported DAServer Hardware and Firmware on page 89.

The GESRTP DAServer is primarily intended for use with the Wonderware InTouch® software (version 7.11 Patch 02, 8.0, 9.0, or 9.5). However, the DAServer can be used by any Microsoft Windows program capable of acting as a DDE, FastDDE, SuiteLink™, or OPC client.

Communications Protocols

The GESRTP DAServer communicates with clients and PLCs using different communications protocols. The DAServer uses application protocols such as OPC, DDE, and SuiteLink to communicate with the clients, and TCP bus protocols over the Ethernet to communicate with the PLCs.

Note This DAServer is compliant with the OPC Data Access (DA) 2.05a specifications.

The GESRTP DAServer can have a maximum of 75 outstanding OPC/DDE/SuiteLink transactions.

For more information about the DAServer architecture, see Reference on page 85.

Application Communications Protocols

This section describes the application communications protocols that can communicate with the clients.

Note SuiteLink, DDE, and OPC clients coexist with FactorySuite A².

OPC

OPC (OLE for Process Control) is a non-proprietary set of standard interfaces based upon the OLE/COM technology developed by Microsoft. This standard enables interoperability between automation/control applications, field systems/devices, and business/office applications.

Avoiding the traditional requirement of software/application developers to write custom drivers to exchange data with field devices, OPC defines a common, high-performance interface that permits custom drivers to be written one time and then easily reused by HMI, SCADA, control, and custom applications.

Over the network, OPC uses DCOM (Distributed COM) for remote communications.

SuiteLink

SuiteLink uses a TCP/IP-based protocol to meet industrial needs such as data integrity, high throughput, and easier diagnostics. This TCP/IP standard is supported on Windows NT and Windows NT-technology-based operating systems including Windows 2000 Professional, Windows 2000 Server, Windows 2000 Advanced Server, Windows 2003 Server, and Windows XP Pro.

SuiteLink is not a replacement for DDE or FastDDE. The protocol used between a client and a server depends on your network connections and configurations.

SuiteLink provides the following features:

- Value Time Quality (VTQ) places a timestamp and quality indicator on all data values delivered to VTQ-aware clients.
- Extensive diagnostics of the data throughput, server loading, computer resource consumption, and network transport are made accessible through the operating system's performance monitor. This feature is critical for the operation and maintenance of distributed industrial networks.
- Consistent high data volumes can be maintained between applications if the applications are on a single node or distributed over a large node count.
- The network transport protocol is TCP/IP using the Microsoft standard WinSock interface.

FastDDE

FastDDE packs many proprietary Wonderware Dynamic Data Exchange messages into a single Microsoft DDE message. This improves efficiency and performance by reducing the total number of DDE transactions required between a client and a server. Although the Wonderware FastDDE extends the usefulness of DDE for our industry, this extension is being pushed to its performance constraints in distributed environments.

DDE

DDE is a communications protocol developed by Microsoft to allow applications in the Windows environment to send and receive data and instructions to and from each other. It implements a Client/Server relationship between two concurrently running applications. The server application provides the data and accepts requests from any other application interested in its data. Requesting applications are called clients. Some applications, such as InTouch or Microsoft Excel, can simultaneously be both a client and a server.

Device Communications Protocols

The GESRTP DAServer uses only the GE Service Request Transfer Protocol, which is a TCP bus communications protocol over Ethernet, to communicate with the GE Fanuc family of controllers.

Accessing Items via the DAServer

The method for accessing items through the DAServer depends on the communications protocol used. This section describes accessing items using the OPC and DDE/SuiteLink communications protocols.

Accessing Items Using the OPC Communications Protocol

In the case of OPC communications, the protocol addresses an element of data in a conversation with six characteristics: node name, program name, group name, device group, link name, and item name.

The node name and device group are optional. A fully qualified OPC item name (ItemID) is composed of the link name and item name. All other characteristics are specified through separate DAServer means.

To access an OPC item, the OPC client connects to the DAServer, either in-process or out-of-process, and creates an OPC group defining the data-acquisition properties for the collection of items to be added. OPC groups can be either public or private. Public OPC groups are shared across multiple clients. Private OPC groups are local to a single client.

Note Wonderware DAServers only support private OPC groups.

Optionally a device group, which indicates the access path to the items for Read/Write, can be specified from the DAServer.

The following briefly describes each characteristic of the OPC protocol.

- **node name**
Computer (host) name identifying a specific node on the network. This node name is required for remote access and is optional for local access.
- **program name**
The registered OPC server name uniquely identifying a specific server (ProgID).

For this DAServer, the program name is ArchestrA.DASGESRTP.1. The version independent ProgID is ArchestrA.DASGESRTP.

- **group name**
The OPC group created from the client for logically organizing a collection of items with the same data-acquisition properties between the client and the server, such as update rate.
- **device group**
Meaningful names configured in the DAServer under a specific controller for the common custom attributes between the DAServer and the device, such as update interval.

If not specified from the client, the default device group using the global-configuration attribute values from the DAServer is assumed.

Functionally, a device group is equivalent to an access path (optional).
- **link name**
The set of hierarchy node names separated by delimiters. Link names represent the specific devices on a communications path link from the hierarchy root to a specific controller as configured for this DAServer under the DAServer Manager.
- **item name**
A specific data element, the leaf of the hierarchy tree of this DAServer, within the specified group.
For example, when using this DAServer, an item can be a relay, timer, counter, register, and so on, in the controller.

Connecting to the DAServer from OPC Client

If you connect to the DAServer using either a VB OPC client or a C OPC client with the option **All** selected, the DAServer is loaded in-process. This in-process connection prevents a SuiteLink client from connecting to the DAServer after the VB client is already connected. To enable a SuiteLink client to connect to the DAServer when a VB client is already connected, the DAServer needs to start in an out-of-process mode when the VB client first connects to it.

To fix this in-process connection problem, make sure that the OPCDAAuto.dll installed in your computer is the Wonderware OPCDAAuto.dll. If your computer also has another OPCDAAuto.dll installed (for example, a .dll file distributed by the OPC Foundation or other organization), the change made in the Wonderware OPCDAAuto.dll to specifically fix the problem becomes ineffective, and the in-process connection problem cannot be solved.

To find and use the Wonderware OPCDAAuto.dll File

- 1 Perform a global search on your computer to find the number of copies of OPCDAAuto.dll files installed.
- 2 Verify the version used is from Wonderware by right-clicking on the **OPCDAAuto.dll** file and selecting the **Properties** option and the **Version** tab.
The normal or default installation directory of the OPCDAAuto.dll is C:\Program Files\Common Files\ArchestrA.
- 3 Register the Wonderware OPCDAAuto.dll file by running: regsvr32 C:\Program Files\Common Files\ArchestrA\OPCDAAuto.dll.

Accessing Items Using the DDE/SuiteLink Communications Protocol

For DDE/SuiteLink communications, the protocol addresses an element of data in a conversation that uses a four-part naming convention. The naming convention includes the node name, application name, topic name, and item name. The fully qualified DDE/SuiteLink naming convention includes all four parts, although the optional node-name is only required for remote access.

The following briefly describes each portion of this naming convention.

- **node name**
Computer name or host name identifying a specific node on the network. This node name is required for remote access and is optional for local access.
- **application name**
The name of the Windows program (this DAServer) that accesses the data element. For data coming from or going to the GE Fanuc devices via the DDE/SuiteLink plugin of this DAServer, the application name portion of the address is DASGESRTP.
- **topic name**
Meaningful names configured in the DAServer to identify specific devices. These names are used as the topic names in all conversations with that device.
For example, **FASTPOLL**.
Topic names map to a device group defined in the DAServer.

Note You can define multiple device group (topic) names for the same device (PLC) to poll different points or items at different rates.

- **item name**
A specific data element within the specified topic.
For example, when using this DAServer, an item can be a relay, timer, counter, register, and so on, in the PLC.

For more information on item names, see Item Naming on page 39.

Features

The GESRTP DAServer provides the following features:

- Fully implemented DAServer with plugins capable for OPC/DDE/SuiteLink connections
- Stand-alone configuration
- Remote configuration
- Adds new application-level protocols on the fly
- Robust diagnostic abilities
- XML storage
- Full, existing item name space to accommodate the legacy GEHCS (GE Fanuc Host Communications) I/O Server, where appropriate. Additional item names are added for any functionality the SRTP (GE Service Request Transfer Protocol) adds beyond the HCS.
- Log of errors, warnings, and traces
- OPC browsing of preconfigured device items, complete with their aliases, at run time
 - The DAServer provides browsing for a few predefined status items.
 - The DAServer does **not** provide browsing items online from the PLC using the SRTP protocol or the GE Fanuc programming software.

For more in-depth information about the DAServer architecture, see Reference on page 85.

Demo Mode

You can install a fully functioning version of this GESRTP DAServer for demonstration purposes without a license. Demo mode allows you to test the functionality of the server for 120 minutes. After that time, you must install a license to continue using the DAServer.

When you first start this GESRTP DAServer, it checks for a license. If the DAServer cannot find a valid license installed on the local computer, it logs a warning message indicating a valid license cannot be retrieved and enters Demo mode. Thereafter, the GESRTP DAServer repeats its request for the license every 30 seconds. If no licenses are found, the DAServer again logs a warning message on the issue.

This process is repeated for 120 minutes, after which the DAServer stops updating read/write on all device items. Read from cache is allowed, but all non-system data receives Bad quality status. The GESRTP DAServer continues to request a license and clients continue to function normally. For example, you can still add or remove an item, but its quality is set to Bad until a license is obtained.

Note Use the `$$SYS$$Licensed` system item, a read-only Boolean item, to check the status of your license: True for Licensed and False for Not Licensed.

If you subsequently add a license to the License Manager, the DAServer logs a message acknowledging the license, switches out of Demo mode, and runs normally.

After a DAServer obtains a valid license, it no longer checks for a license. If your license expires while the DAServer is running, the DAServer continues to function normally until it is stopped.

After a DAServer obtains a valid license, it no longer checks for a license. If your license expires, your DAServer stops functioning. This condition is not logged until the next restart of the DAServer.

Windows Firewall Considerations

If the DAServer runs on a computer with a firewall enabled, there is a list of application names or port numbers that must be put in the firewall exception list so the DAServer can function correctly.

By default, the DAServer installation program makes the required entries in the firewall exception list. If you do not want the installation program to make entries in the firewall exception list, you must add the entries manually. For information on how make entries in the firewall exception list, see your firewall or Windows security documentation.

Whether you let the install process add the entries, or add them manually, the following applications must be put in the firewall exception list on the computer running the DAServer:

- DASGESRTP.exe
- aaLogger.exe
- DASAgent.exe
- dllhost.exe
- mmc.exe
- OPCEnum.exe

Whether you let the install process add the entries, or add them manually, the following port numbers must be put in the firewall exception list on the computer running the DAServer:

- 5413 a TCP port for slssvc.exe
- 445 a TCP port for file and printer sharing
- 135 a TCP port for DCOM

The following applications must be in the firewall exception list on the computer where the DAServer Manager is installed:

- aaLogger.exe
- dllhost.exe
- mmc.exe

The following port numbers must be in the firewall exception list on the computer where the DAServer Manager is installed:

- 445 a TCP port for file and printer sharing
- 135 a TCP port for DCOM

Un-installing the DAServer does not remove the firewall exception list entries. You must delete the firewall exception list entries manually. For more information on how to do this, see your firewall or Windows security documentation.

Chapter 2

Configuration

After you install the Wonderware GESRTP DAServer, configure it using the DAServer Manager hosted in the **ArchestrA System Management Console**.

Before you activate the DAServer, you must first build the device hierarchy, simulating the physical hardware layout, to establish communications to each of the controllers. After you add the GESRTP_PORT hierarchy, you can configure the respective GEFANUC_PLC devices for communications.

Finally, you can create the desired device groups for each controller.

Getting Started Quickly with the GESRTP DAServer

If you are familiar with DAServers, follow the instructions in this section to prepare the GESRTP DAServer for use. If you are not familiar with DAServers, follow the detailed procedures in Configuring the GESRTP DAServer on page 21.

To prepare the GESRTP DAServer

- 1 Install the Wonderware GESRTP DAServer by running the **Setup.exe** program and accepting all the default settings during installation. For more information on installation, see the installation Help file (Install-GESRTP.chm).

Important Because there are no default values for security settings, note the User Name and password selected during the install.

- 2 Start the Wonderware DAServer Manager. Click **Start**, point to **Programs**, point to **Wonderware**, and then click **System Management Console**.
- 3 Expand the **ArchestrA System Management Console** and find the GESRTP DAServer in the **DAServer Manager** tree. Under the **Local** node, the DAServer name is **ArchestrA.DASGESRTP.1**.

Note For information about working in this DAServer Manager, see the DAServer Manager Online Help.

- 4 Determine the hierarchical structure of the network/PLC environment to which you plan to connect.
- 5 Configure the new GESRTP DAServer. In the console tree, right-click **Configuration** and then click **Add GESRTP_PORT Object**. The GESRTP DAServer only allows a single instance of the GESRTP_Port object in the hierarchy.
Edit the object name to appropriately describe components of your specific hardware environment. If you do not rename the object at this time, a numeric sequencing system is applied. You can rename the hierarchy entry later.
- 6 Right-click the **New_GESRTP_Port_000** object you created in the tree and then click **Add GEFANUC_PLC Object** to create a GE Fanuc PLC object.
You can add up to 128 GEFANUC_PLC objects in the hierarchy.
- 7 Optionally create device groups for each logical end-point object.

Important When the DAServer or any of its configuration views is selected and you open multiple instances of the DAServer Manager, the DAServer Manager places the configuration views from the subsequent instances of the same DAServer into read-only mode. Access to the second instance of the DAServer resumes after the first one has been deselected or closed. Likewise, access to the DAServer configuration will be unlocked for the next instance in this order.

Your GESRTP DAServer is now ready to use. To use the DAServer, you must activate it.

To activate the DAServer

- ◆ Right-click on **ArchestrA.DASGESRTP.1** and click **Activate Server**.
 - If you use an OPC Client, the GESRTP DAServer auto-starts.

- If you use DDE/SuiteLink, start the GESRTP DAServer either as a manual or automatic service.

Note Run the GESRTP DAServer as a service if the SuiteLink plugin is installed and used. Run the GESRTP DAServer as a Windows service using the SYSTEM account when you use the DDE connectivity to the DAServer.

To run the GESRTP DAServer as a service

- ◆ Right-click on the **ArchestrA.DASGESRTP.1** and click **Configure As Service**. You can configure the DAServer as an auto service or manual service.

For more information about configuring your GESRTP DAServer as a service, see Activation/Deactivation/Service Component in the DAServer Manager documentation.

Configuring the GESRTP DAServer

The GESRTP DAServer is hosted by the DAServer Manager, a Microsoft Management Console (MMC) snap-in. Many high-level functions and user-interface elements of the DAServer Manager are universal to all DAServers. **Only** the documentation for the DAServer Manager contains descriptions of those universal functions/UI elements.

Reading the documentation for both the MMC and the DAServer Manager is critical to understanding this DAServer documentation. To read the documentation about the MMC and DAServer Manager, click the Help topics on the MMC **Help** menu. Both the MMC and DAServer Manager Help are opened. An Adobe Acrobat version of the DAServer Manager documentation (DAServerManager.pdf) is provided.

Note Most items in each shortcut menu are standard Windows commands. See the **Help** menu of the MMC for more information about those commands.

Before you can configure the GESRTP DAServer, you need to install it and run it.

To install and run the DAServer

- 1 Run the **Setup.exe** program and accept all of the default settings. For more information on installation, see DAServer installation Help (Install-GESRTP.chm).


Important There are no default values for security settings. Be sure to note the user name and password you use during the install.

2 Run the DAServer Manager on at least one computer. After you install the GES RTP DAServer, you need to configure it.

To prepare the GES RTP DAServer

- 1 On the Windows **Start** menu, point to **Programs**, point to **Wonderware** and then click System Management Console.
- 2 In the console, expand **ArchestrA System Management Console**, and then expand **DAServer Manager**.
- 3 Expand **Default Group**, and then click **Local**. The name of the DAServer is **ArchestrA.DASGES RTP.1**.

Note For general information about working in this snap-in, see the DAServer Manager documentation.



- 4 Before starting the DAServer, build the device hierarchy to establish communications to each of the controllers. For step-by-step procedures on how to build the device hierarchy, see GES RTP Hierarchy in the DAServer Manager on page 23.

Important When you select the **Configuration** object in the console tree, the **Global Parameters** configuration view for this GES RTP DAServer opens. Configure all other global parameters as required for this GES RTP DAServer. For more information about the **Global Parameters** dialog box, including descriptions of the different poke modes, see the DAServer Manager documentation. Any global parameters that appear dimmed are not available.

- 5 After you build the GES RTP hierarchy, you can start configuring the devices for communications.

- 6 Finally, create the device groups for each controller. Navigate to the object in the **DAServer Manager** console tree view and click the **Device Groups** tab.

For step-by-step procedures on configuring device groups, see *Defining Device Groups and Device Items* on page 28.

Important When the DAServer or any of its configuration views is selected and you open multiple instances of the DAServer Manager, the DAServer Manager places the configuration views from the subsequent instances of the same DAServer into read-only mode. Access to the second instance of the DAServer resumes after the first one has been deselected or closed. Likewise, access to the DAServer configuration will be unlocked for the next instance in this order.

GESRTP Hierarchy in the DAServer Manager

The GESRTP DAServer uses a single-tier hierarchy for modeling the GEFANUC_PLC objects and a custom device group configuration.

Before configuring your GESRTP DAServer, determine the hierarchical structure of your network/PLC environment.


GESRTP_PORT Object

The server-specific configuration portion of the GESRTP DAServer hierarchy tree under the DAServer Manager starts at the GESRTP_PORT object. This object represents a port number for the installed DAServer system and is used by the GESRTP DAServer to communicate with PLCs lower in the hierarchy tree.

You can only create a single GESRTP_Port object under the **Configuration** node in the console tree.

To add GESRTP_PORT object to your GESRTP hierarchy

- 1 In the console tree, right-click **Configuration** and then click **Add GESRTP_PORT Object**. The **New_GESRTP_PORT_000** object appears.



Edit the object name to appropriately describe components of your specific hardware environment. If you do not rename the object at this time, a numeric sequencing system is applied. You can rename the hierarchy entry later.

- 2 Rename this object as needed.
- 3 In the **Port Number** box verify the port number. The port number is 18245.

Important If you subsequently clear your configuration hierarchy, you must create this GESRTP_PORT object by right-clicking **Configuration** and then clicking **Add GESRTP_PORT Object**. An object called **New_GESRTP_PORT_000** is created. Rename as appropriate. From this point, all of the following instructions apply.


GEFANUC_PLC Object

The GESRTP DAServer can connect to different GE Fanuc PLCs. Each of the PLC node models the end-point of the communications path.

From the **New_GESRTP_PORT_000** branch of the DAServer hierarchy, create the GEFANUC_PLC object.

To add GEFANUC_PLC object to your GESRTP hierarchy

- 1 In the console tree, right-click the **New_GESRTP_PORT_000** object, and then click **Add GEFANUC_PLC Object**. The **New_GEFANUC_PLC_000 Parameters** configuration view appears.



You can create a maximum of 128 GEFANUC_PLC objects from the **New_GESRTP_PORT** branch. This maximum number can be of a single type of PLC or a combination of several types of PLCs.

- 2 Rename this object as needed.
- 3 Configure the PLC.
 - In the **PLC Type** list, click the PLC type from the list of supported GE Fanuc PLCs.

Series 90-30

Series 90-70

Series 90 Micro

VersaMax

VersaMax Micro

VersaMax Nano

PACSystems RX3i

PAC Systems RX7i

The default PLC is the GE Fanuc Series 90-70 PLC. You can use this PLC-type selection to determine the PLC-variable quantities, such as the number of items in a given item name space.

- In the **Host Name** box, type the TCP/IP address, IP address, or node name of the remote GE Fanuc PLC. Type in the network address where the PLC is located or a host name if one is defined in the local hostlist. For example, "127.0.0.1"

Note The Host Name is defined in the system Host file, usually found in: \WINNT\system32\drivers\etc\hosts folder.

The address must be 255 or fewer characters. Only the following non-alphanumeric (special) characters are valid: @ # \$ % ^ & () - _ ' { } . ~

The first and last characters of the address must be alphanumeric characters. They cannot be special characters. IP address formatting is not enforced.

- In the **Connection Timeout** box, type a value, in milliseconds, beyond which a pending request to initiate a connection times out. The allowable range is 1,000 to 600,000 milliseconds. The default value is 3,000 milliseconds.
- In the **Reply Timeout** box, type a value, in milliseconds, beyond which messages time out. The allowable range is 200 to 60,000 milliseconds. The default value is 5,000 milliseconds.

If you decrease this value, the GESRTP DAServer reacts faster to a communications failure.

For Versamax Nano and Versamax Micro PLCs that are communicating using an Ethernet-to-serial adapter, you may need to increase the reply timeout to 10 seconds or longer. A reply timeout that is set too low causes the topic to enter into slow poll mode due to hardware limitations.

- In the **Maximum Outstanding Messages** box, type the maximum number of outstanding messages allowed per PLC. The allowable range is one (1) to twenty (20) messages. The default value is four (4) messages.
- In the **Program Name** box, type the name of the program running in the PLC. This program name is used to advise %P and %L items.

The **Program Name** box is only available if the PLC type is Series 90-70. The program name must be seven or fewer characters. The program name must begin with a letter and can only contain letters, numbers, and underscores. You cannot use consecutive underscores. If the program name you type does not match the actual program name running in the PLC, then the DAServer logs a warning message in the Logger and the item is set to bad quality.

4 Save your changes.

The logical endpoint for each branch of the GESRTP hierarchy tree is a hardware device (PLC).

Note When adding a hierarchy object, the default name is in the format of **New_ObjectName_###**. ObjectName is the name of the object type and ### is a numeric value starting from "000" sequentially per hierarchy object. The link name for the OPC items is constructed by assembling the respective object names of the nodes along the hierarchy tree in the logical order, starting from the GESRTP_PORT root of this DAServer down to the leaf. This creates a link name that is always unique for the DAServer.

To use the DAServer, you must activate it.

To activate the DAServer

- ◆ In the console tree, right-click **Archestra.DASGESRTP.1** and then click **Activate Server**.
 - If you use an OPC Client, the GESRTP DAServer auto-starts.
 - If you use DDE/SuiteLink, start the DAServer either as a manual or automatic service.

For information about activating and deactivating the DAServer, see the DAServer Manager documentation.

Note Run the GESRTP DAServer as a service if the SuiteLink plugin is installed and used. Run the GESRTP DAServer as a Windows service using the SYSTEM account when you use the DDE connectivity to the DAServer.

To run the GESRTP DAServer as a service

- ◆ In the console tree, right-click **ArchestrA.DASGESRTP.1** and then click **Configure As Service**. You can configure the DAServer as an auto service or manual service.

For more information about configuring your GESRTP DAServer as a service, see *Activation/Deactivation/Service Component in the DAServer Manager documentation*.

Defining Poke Modes

The GESRTP DAServer has three poke modes for tuning the poking behavior to the PLC.

- **Control mode**
This mode preserves the poke order and does not fold Write values. Select this mode when using a device group with control clients such as the InBatch and InControl applications. If you select this mode, the server processes all poked values in the order they are received from a client and does not discard any poke values even when several values are poked to the same item.
- **Transition mode**
This is the default poke mode. This mode preserves the poke order but allows folding of poke values in the following way: if the server receives more than one value per item it may discard poke values except for the first, second, and last value for this item.
Transition mode prevents InTouch sliders from stuttering.
- **Full optimization mode**
This mode allows changing the poke order and folding of poke values by poking the last value of a series of pokes to one item only. This minimizes bus traffic and poke duration. Use this mode for high volume pokes such as recipe downloads where the sequence of pokes does not matter.

Note Use the full optimization mode to achieve the highest performance. You need to consider your data consistency requirements with respect to poke order and folding.

Defining Device Groups and Device Items

You can create new, modify, or delete device group and device item definitions for an object.

To delete device groups

- ◆ Right-click on the device group to be deleted from the list and select **Delete**.

To make edits on device groups

- ◆ Use the **Edit** option from the **Device Groups** tab **only** for configuring the DAServer's unsolicited message handling. For detailed information about unsolicited message handling and configuring it, see Unsolicited Message Handling on page 35.

To configure default update intervals

- ◆ To configure a default update interval for the object, right-click in the **Device Groups** box and then click **Config Default Update Interval**.

To edit update intervals

- ◆ To edit the update interval for an object, double-click its value in the **Update Interval** column and make the edits.

OR

Right-click its value in the **Update Interval** column and then click **Modify Update Interval**.

- The update interval is the frequency, in milliseconds, that the GESRTP DAServer acquires data from the topics associated with that device group.
- Different topics can be polled at different rates from a PLC by defining multiple device group names for the same PLC and setting a different update interval for each device group.


Note When you select another part of the GESRTP DAServer tree hierarchy, you are prompted to save the modifications to the configuration set.

Device Item Definitions

You cannot change the predefined item syntax/name for the GE Fanuc PLC. However, to make it easier to remember item names, you can create aliases for these item names. For example, it may be easier for you to remember the item syntax "R4087" as "Temperature."

The GESRTP DAServer supports a maximum of 1,000 aliases.

Select the **Device Items** tab in the DAServer Manager user interface to create new, modify, delete, export, or import device item definitions for an object. Configure the device item names using the **Device Items** dialog box, which appears when you click the **Device Items** tab in the **New_GEFANUC_PLC_000 Parameters** configuration view.



After you configure item names, the DAServer can perform OPC item browsing. When the DAServer is running and an OPC client requests item information, the configured items appear under the PLC hierarchy node. User-defined data types appear with a flat address space when browsed through OPC.

Note The DAServer does **not** provide run-time browsing of PLC items using the SRTP protocol or the GE Fanuc programming software.

To create or add device items

- 1 Right-click in the **Device Items** box and click **Add**.
- 2 In the **Name** column, type a unique item name. The maximum is 32 characters. For example, "Temperature."
- 3 Double-click the line in the **Item Reference** column and enter the correlated item reference for the name you created. For example, "R4087."

Note If the name and the item reference are the same, it is only necessary to enter a name. The DAServer assumes that the item reference is the same. This is necessary if you want to add some items for browsing via the OPC, even if they do not have a symbolic name.

To rename device items

- ◆ Right-click the device item to be renamed and click **Rename**. Make the changes.

To delete device items

- ◆ Right-click the device item to be deleted from the list and click **Delete**.

To clear all device items

- ◆ Right-click in the **Device Items** box and click **Clear All**. All the device items listed are cleared after you confirm their deletion.


Exporting and Importing DAServer Item Data

After you configure device items, you can export and import the DAServer item data to and from a CSV file. This lets you perform an off-line, large-scale edit on the item data configured for a PLC and import that data back into the PLC configuration.


To export DAServer item data to a CSV file

- 1 Right-click in the **Device Items** box and click **Export**. The **Save As** dialog box appears. The file name defaults to "PLC Hierarchyname.csv" within the default directory.

- 2 Accept the defaults to save the file. The file is saved as New_GEFANUC_PLC_000.csv and is editable in Microsoft Excel.



The file contains one row for each item configured with two columns: Name and Item Reference.



- 3 Make your edits to the CSV file.

After you are done editing, you are ready to import the edited file into the DAServer Manager.

To import DAServer item data from a CSV file

- 1 Right-click in the **Device Items** box.
- 2 Click **Import** on the menu. The **Open** dialog box appears.

Because you more than likely want very fast response, the temptation is to set the update interval to a value close to 0 seconds. However, if every item is polled at this rate, the entire system suffers due to slow response time. Therefore, compromise and set the update interval to a more reasonable value.

You could also create multiple device groups for each device, setting the update interval to different values, then assigning different items to different device groups, depending on how quickly the values change and how quickly you want to see an update of those changes.

Some items, like alarms, change very infrequently but because of their importance require very fast updates. For those kinds of items, you can set the update interval at a very small value. If you want an immediate response, set the update interval to 1.

Unsolicited Message Handling

A PLC can detect when a critical event occurs before the DAServer has a chance to poll for that data. If a PLC determines that a critical condition exists, it can generate a message and immediately send it to the DAServer. This type of message is called an unsolicited message. The GESRTP DAServer supports unsolicited messages from the PLCs.

The following is required to support unsolicited messaging:

- The messaging instructions are properly programmed in the PLC logic.
- The device group is appropriately configured in the DAServer.

To use unsolicited messaging for the GESRTP DAServer, you must set up unsolicited messaging from the PLCs. For more information, see the GE Fanuc Automation documentation.

To configure the GESRTP DAServer to receive unsolicited messages

- 1 Click on the target PLC node under the PLC branch of the DAServer hierarchy.
- 2 Select the **Device Group** tab and add a new device group or select an existing device group that needs to be configured to receive unsolicited messages.

- 3 Right-click on the device group name and then click **Edit**. The **Device Group Parameters** dialog box appears.



- 4 Select the **Support Unsolicited Messages** check box to have the DAServer process unsolicited messages for the device group selected.
- 5 Click **OK**.

Note Because you cannot view the status of **Support Unsolicited Messages** check box from the **Device Groups** tab, proper naming of device groups which support unsolicited messages is strongly recommended.

To enhance performance in message handling, the device group is to not provide unsolicited message data. By default the **Support Unsolicited Messages** check box is selected. The setting of this check box is hot-configurable. Unsolicited message handling takes effect in the DAServer as soon as you save the change made in the configuration view.

To receive unsolicited messages

- 1 Activate the DAServer.
- 2 Under the device group set up for receiving unsolicited messages, add the items, defined in the PLC for unsolicited messages.

Archiving Configuration Sets

After you configure your DAServer, you can archive that specific configuration. You can archive more than one configuration set and select different configurations for different purposes.

To archive configuration sets

- 1 In the DAServer Manager console tree, right-click **Configuration** and then click **Archive Configuration Set**.
- 2 In the **Archive Configuration Set** dialog box, provide a configuration set name.
- 3 Click **Archive**. All current configuration values are saved to the archived set.

After you archive at least one configuration set, you can select it for use.

To use different configuration sets from the current one

- ◆ In the DAServer Manager console tree, right-click **Configuration**, point to **Use Another Configuration Set**, and then click on a configuration set. All parameters in the DAServer configuration hierarchy change to the selected configuration set.

Note If you do not explicitly archive the current configuration, it is automatically saved in a default configuration called "dasgesrtp."

Hot Configuration

Value changes for hot-configurable parameters take effect immediately while the DAServer is running. The GESRTP DAServer supports hot configuration for the following actions:

- Modifying global configuration parameters.
- Adding, deleting, or modifying device nodes without affecting any other device nodes, excluding the children of the modified device nodes.
- Adding, deleting, or modifying device groups including unsolicited message handling, the **Update Interval** column in the **Device Groups** tab, and device items.
- Modifying server-specific configuration parameters, except **NodeAddress** and **PLCType**, in the configuration view.

All other parameters are not hot-configurable. To make those changes take effect, restart the DAServer.

Note If changes are made to server-specific parameters while the server is active, the DAServer issues a warning message to the logger.

Chapter 3

Item Naming

The Wonderware GESRTP DAServer uses an item-naming convention based on the single-letter data-type identifiers used in programming the GE Fanuc PLCs.

The tables in this documentation describe the item naming convention for the GESRTP DAServer. The ranges specified in those tables vary according to the type of the controller used.

If you advise an out-of-range variable for an item, all items in the same packet return bad quality.

Suffixes to Explicitly Control Data Type

This section describes the single-letter suffixes used to explicitly control data type. The following conditions apply to these suffixes:

- You can universally apply suffixes to all supported item names.
- You can either have a single suffix or a combination of the suffix and the A suffix. The A and M suffixes cannot be used together.
- Each suffix applied must be preceded by a space:
R77-R100 A (BCD)

The following sections summarize the suffix group, suffix, restrictions, description, and result for Suffixes to Explicitly Control Data Type.

F Suffix

You can interpret a pair of analog or block registers as a floating point number by adding a blank space and an F to the item name for the lower-numbered register of the pair. For example, R1001 F.

This notation causes the server to treat R1001 and R1002 as IEEE 32-bit floating point numbers. The resulting type is a VT_R4. This suffix can only be used with suffix A.

Supported base items are: %AI, %AO or %AQ, %P, %R, %L, %W

M Suffix

You can treat a series of consecutive analog or block registers as an ASCII character string by adding a blank space and an M following the item name. For example, R101-R150 M.

This item name indicates that registers R101 through R150 contain a string of 100 ASCII characters.

Each register contains two characters with the low-order byte first. A zero byte in any register is treated as the end of the string. A single register followed by the M suffix is treated as a 4-byte long register string. For example, assume the following values are in the PLC: R1 = 54, R2 = 55, R3 = 69, R4=72, R5 = 73, R1-R5 M = 67EHI. For example, R101 M is the same as R101-R102 M.

For a single register, specify R101-R101 M.

The server reads R100 and R101 register values in ASCII with a space in between.

The resulting type is a VT_BSTR.

This suffix cannot be used with any other suffix.

Supported base items are: %AI, %AO or %AQ, %P, %R, %L, %W

Note For Micro and Nano PLCs, a maximum of 100 elements are allowed for items with suffix M. For all other PLCs, the maximum is 1000.

S Suffix

Reads the specified register(s) as a signed value. For example R001 S. The resulting type is a VT_I2.

This suffix can only be used with suffix A.

Supported base items are: %AI, %AO or %AQ, %P, %R, %L, %W

L Suffix

You can interpret a pair of analog or block registers as a long integer or double-precision integer by adding a blank space and an L after the item name. For example, WIDGETS^%L95 L.

This notation causes the server to treat L95 and L96 in sub-program block WIDGETS as a signed 32-bit number with L95 being the least significant half. The resulting type is a VT_I4.

This suffix can only be used with suffix A.

Supported base items are: %AI, %AO or %AQ, %P, %R, %L, %W

A Suffix

You can interpret consecutive PLC register values as an ASCII string of values separated by spaces by specifying a register range followed by a blank space and an A. For example, R501-R510 A.

This item name indicates that registers R501 through R510 should be read and written as a unit. This technique is useful to load a group of registers with a new set of control values. For example, a recipe.

You can assume registers to be unsigned, unless otherwise specified.

R100 A is the same as R100-R101 A.

In addition to the A, by further suffixing a blank space and an S (signed), or L (long integer), or F (floating point), or (BCD), the string can be interpreted as a string of signed / long / floating point / BCD.

The resulting data type is a VT_BSTR.

For example,

R1-R6 A (BCD)

P1-P10 A

AI1-AI10 A

R1000-R1099 A S

WIDGETS^%L1-L20 A S

AO1-AO10 A.

example:

1.

R1 = 54, R2 = 55, R3 = 69, R4=72, R5 = 73

R1-R5 A = 54 55 69 72 73

The following point names support register arrays (blocks): %AI, %AO or %AQ, %P, %R and BLOCKNAME^%L, %W.

When you write or poke a new value for the Register Array from the client, it must be in the form of a character string containing a value for each register. The register values can be separated by any combination of commas, tabs, spaces, carriage returns, and line feeds.

For example, if the item is R1-R6 A, you poke the following values: 1,2,3,4,5,6 or 1<tab>2<tab>3<tab>4<tab>5<tab>6 or 1 2 3 4 5 6, and so on.

When the server returns a new value for a Register Array to the client, it is in the form a character string containing a value for each register separated by carriage return and line feed.

For example, if the item is R1-R6 A, the value returned is 50<cr><lf> 17<cr><lf> 0<cr><lf> 5<cr><lf> 1007<cr><lf> 20<cr><lf>.

Supported base items are: %AI, %AO or %AQ, %P, %R, %L, %W

Note For Micro and Nano PLCs, a maximum of 100 elements are allowed for items with suffix A. For all other PLCs, the maximum is 1000.

B or BCD Suffix

You can interpret a register as a BCD (Binary Coded Decimal) by adding a blank space and BCD following the item name. For example, R4087 (BCD) or R4087 B or R4087 BCD.

This causes the server to convert the register contents to BCD before sending it to the client application.

This suffix can only be used with suffix A.

Supported base items are: %AI, %AO or %AQ, %P, %R, %L, %W

Status Items

The GESRTP DAServer provides a number of status items. The following conditions apply to these status items:

- Optionally, ‘%’ precedes the status items.
- Item names are not case-sensitive.

The following table summarizes the base name, description, data type, Read/Write designation, and offset for Status Items.

Base Name	Description	Data Type	Access Rights	Offset
EnSwitch	The status of the Enable switch on the PLC front panel.	VT_BOOL	Read-Only (R/O)	None
Run	The PLC run state. 0 = Stop; 1 = Run.	VT_BOOL	R/O	None
IOStatus	The Status bit that is piggybacked on the Fault table.	VT_BOOL	R/O	None
FTStatus	The Fault table status.	VT_BOOL	R/O	None
Interval	The update interval of the topic.	VT_UI4	R/O	None
Time	The PLC Time string reads the PLC clock as a 14-digit string: SSMMHHDDMoYYWd. Where: SS = Seconds [00-59] MM = Minutes [00-59] HH = Hours [00-23] DD = Day of Month [01-31] Mo = Month of Year [01-12] YY = Year of Century [00-99] Wd = Day of the Week [1- Sunday, 2 - Monday... 7 - Saturday]	VT_BSTR	R/O	None
Note The GE Fanuc Nano PLCs do not support Time items. Do not follow the above Time string format when advising Time items for Nano PLCs.				
OverSweep	The PLC scan fails to keep up.	VT_BOOL	R/O	None
OEMProt	The OEM Protect bit.	VT_BOOL	R/O	None
SNum_Progs	The number of programs in the PLC.	VT_UI1	R/O	None
SProg_Flags	Program flags.	VT_UI1	R/O	None
SPrgChg	Program change flags.	VT_BOOL	R/O	None

Base Name	Description	Data Type	Access Rights	Offset
SweepTime	The PLC sweep time in increments of 100 microseconds.	VT_UI2	R/O	None
State	The current PLC state. 0 = Run I/O enabled. 1 = Run I/O disabled. 2 = Stop I/O disabled. 3 = CPU stop faulted. 4 = CPU halted. 5 = CPU suspended. 6 = stop I/O enabled.	VT_UI1	R/O	None
SNPID	The PLC ID on the SNP bus.	VT_BSTR	R/O	None
NewIOFT	The new I/O Fault since last reset.	VT_BOOL	R/O	None
NewFT	The new PLC Fault since last reset.	VT_BOOL	R/O	None
ProgName	The name of the current program.	VT_BSTR	R/O	None
ProgAttach	The program attached.	VT_BOOL	R/O	None
PrivLevel	The current Privilege Level. Level-0 - (Series 90-70 PLC only.) Read and write of the PLC. Level-1 - Read any data memory. Write to memory is prohibited. The PLC cannot be started or stopped. Level 2 - Write to any data memory, except for overriding discrete I/O. The PLC can be started or stopped. PLC and I/O fault tables can be cleared. Level 3 - Write to any configuration or logic, including word-for-word changes, the addition/deletion of program logic, and the overriding of discrete I/O. Level 4 - Write to all configuration or logic. Configuration may only be written in STOP mode; logic may be written in STOP or RUN mode. Display, set, or delete passwords for any level.	VT_UI1	R/O	None
ConSweep	The constant Sweep Mode flag.	VT_BOOL	R/O	None
SY_Full	Set when the PLC Fault table fills up.	VT_BOOL	R/O	None

Base Name	Description	Data Type	Access Rights	Offset
IO_Full	Set when the I/O Fault table fills up.	VT_BOOL	R/O	None
OVR_PRE	Set when an override exists in %I, %Q, %M, or %G memory.	VT_BOOL	R/O	None
PLC_BAT	Set to indicate the bad battery in the CPU.	VT_BOOL	R/O	None
USR_SW	Set to indicate the CPU mode switch. 1: Run/On 0: Stop/Off	VT_BOOL	R/O	None
CFG_MM	Set when a configuration mismatch is detected during a power-up or a configuration store.	VT_BOOL	R/O	None
HRD_CPU	Set when diagnostics detects problems with the CPU hardware.	VT_BOOL	R/O	None
LOW_BAT	Set when a low battery fault occurs.	VT_BOOL	R/O	None
BAD_PWD	Set when a password violation occurs.	VT_BOOL	R/O	None
SFT_CPU	Set when the CPU detects an error in the CPU operating system.	VT_BOOL	R/O	None
ANY_FLT	Set when any fault occurs. 1 = Fault is present (either PLC fault or I/O fault) 0 = No fault	VT_BOOL	R/O	None
SY_FLT	Set when any fault occurs and results in an entry to the PLC Fault table.	VT_BOOL	R/O	None
IO_FLT	Set when any fault occurs and results in an entry to the I/O Fault table.	VT_BOOL	R/O	None
SY_PRES	Set as long as there is at least one entry in the PLC Fault table.	VT_BOOL	R/O	None
IO_PRES	Set as long as there is at least one entry in the I/O Fault table.	VT_BOOL	R/O	None
HRD_FLT	Set when a hardware fault occurs.	VT_BOOL	R/O	None
SFT_FLT	Set when a software fault occurs.	VT_BOOL	R/O	None
PLCFTCOUNT	The number of faults present in the PLC Fault table.	VT_UI1	R/O	None
IOFTCOUNT	The number of faults present in the I/O Fault table.	VT_UI1	R/O	None

Base Name	Description	Data Type	Access Rights	Offset
PLCFT_n	The fault entry n of the PLC Fault table. The maximum number of PLC fault entries is 16.	VT_BSTR	R/O	None
IOFT_n	The fault entry n of the I/O Fault table. The maximum number of I/O fault entries is 32.	VT_BSTR	R/O	None

Base Item Names

This section describes the base item names and the conditions applicable to them:

- Item names must begin with base name strings and optionally preceded by "%."
- Item names are not case-sensitive.

The following table summarizes the base name, description, data type, read/write (R/W) designation, and offset for base item names.

Base Name	Description	Data Type	Access Rights	Offset
<i>In</i>	Discrete inputs	VT_BOOL	R/W	<i>n</i> = 1-65535
<i>On</i> or <i>Qn</i>	Discrete outputs	VT_BOOL	R/W	<i>n</i> = 1-65535
<i>Tn</i>	Discrete temporary	VT_BOOL	R/W	<i>n</i> = 1-65535
<i>Mn</i>	Discrete internal	VT_BOOL	R/W	<i>n</i> = 1-65535
<i>Gn</i>	Genius global data	VT_BOOL	R/W	<i>n</i> = 1-65535
<i>GAn</i>	Genius seamless A table*	VT_BOOL	R/W	<i>n</i> = 1-64255
<i>GBn</i>	Genius seamless B table*	VT_BOOL	R/W	<i>n</i> = 1-62975
<i>GCn</i>	Genius seamless C table*	VT_BOOL	R/W	<i>n</i> = 1-61695
<i>GDn</i>	Genius seamless D table*	VT_BOOL	R/W	<i>n</i> = 1-60415
<i>GE_n</i>	Genius seamless E table*	VT_BOOL	R/W	<i>n</i> = 1-59135

Base Name	Description	Data Type	Access Rights	Offset
Wn	PLC WORD register	VT_UI2 or forced by suffix	R/W	$n =$ 1-2147483647
Rn	PLC register	VT_UI2 or forced by suffix	R/W	$n =$ 1-65535
$Rn:b$	PLC register bit	VT_BOOL	Read-Only (R/O)	$b =$ 0-15
Similarly for data types %AI, %AO or %AQ, %P, BLOCKNAME^%L, %W				
$Rn-Rm M$	String contained in consecutive bytes in the PLC registers	VT_BSTR	R/W	1 $n,m =$ 1-65535 2 $m \geq n$ 3 For Micro and Nano PLCs, (m-n) < 100 For all other PLCs, (m-n) < 1000
Similarly for data types %AI, %AO or %AQ, %P, %W. For %L, the syntax is BLOCKNAME^%Ln-Lm M				
$Rn-Rm A$	String contained in consecutive PLC registers	VT_BSTR	R/W	1 $n,m =$ 1-65535 2 $m \geq n$ 3 For Micro and Nano PLCs, (m-n) < 100 For all other PLCs, (m-n) < 1000
Similarly for data types %AI, %AO or %AQ, %P, %W. For %L, the syntax is BLOCKNAME^%Ln-Lm A				
AI_n	Analog inputs	VT_UI2 or forced by suffix	R/W	$n =$ 1-65535
AO_n or AQ_n	Analog outputs	VT_UI2 or forced by suffix	R/W	$n =$ 1-65535
Sn	System discretetes	VT_BOOL	R/O	$n =$ 1-128
SA_n	System discretetes	VT_BOOL	R/O	$n =$ 1-128
SB_n	System discretetes	VT_BOOL	R/O	$n =$ 1-128

Base Name	Description	Data Type	Access Rights	Offset
SC n	System discretes	VT_BOOL	R/O	$n = 1-128$
BLOCKNAME^ %L n	Sub-program block registers**	VT_UI2 or forced by suffix	R/W	BLOCKNAME = corresponding blockname in the control program of the PLC. $n = 1-8192$
%P n	Task memory of the PLC control program**	VT_UI2 or forced by suffix	R/W	$n = 1-8192$
%W n	Retentive Bulk Memory Area, which is referenced as %W (WORD memory).	VT_UI2 or forced by suffix	R/W	$n = 1-2147483647$ (which is a 4 byte address range/2).

* Items GA, GB, GC, GD, and GE are supported **only** by the Series 90-70 PLCs.

** Items %P and %L are supported only for Series 90-70 PLCs.

If the number of values written to a string item (for example, R1-R20 M or R1-R20 A) is greater than the number of elements in the string or if the item value is out of range, then the transaction is shown as Error with a description of Write Result as Error[The value is out of range.].

Conversions and Suffixes of Items

This section describes what data-format items and suffixes are converted and what they are converted into.

All items marked "Forced by suffix" in the Data Type column of the Status Items and Base Item Names tables are affected by any of these suffixes. For acceptable combinations of suffixes, see the table in Suffixes to Explicitly Control Data Type on page 39.

Suffix B or BCD

All items with suffix B or BCD are converted from the BCD format into the integer and back.

Suffix F

All items with suffix F are converted to type VT_R4 on Read and require type VT_R4 on Write.

Suffix M

All items with suffix M are converted to type VT_BSTR (consecutive bytes of the specified registers) on Read and require type VT_BSTR on Write.

Suffix S

All items with suffix S are forced to a signed representation on Read and accept signed values on Write.

Suffix L

All items with data format integer and with suffix L read and write twice the number of PLC registers as their normal format does.

Suffix A

All items with data format integer and with suffix A represent an ASCII string of values stored in consecutive PLC registers. The values are separated by spaces.

By default data format of each element in the string is an integer and is forced by the additional suffix applied on it (F-float, S-signed, L-long, B-bcd). The data type is always VT_BSTR for read/write.

DAServer Standard System Items

System items supply you with easy access to the DAServer status and diagnostic information. They are treated just like ordinary items with respect to the client. However, in most cases these items are not directly acquired via the communications layer. System item values are usually generated through internal calculations, measurements, and tracking of the DAS Engine.

No DAServer-specific system items are provided in this GESRTP DAServer.

System items, like ordinary items, are defined by name in the following context:

- **Group** (client group/OPC group)
Arbitrary collection of items, not correlated.

- **Hierarchical location** (link name/OPC path: Hierarchical node section of the fully qualified OPC item ID)
The device the item is attached to.
- **Device group** (OPC access path/topic, or a Scan Group on a hierarchical branch)
Collection of items on the same physical location with the same protocol update rate.

To check the status of an external device, the reference can be:

```
<GESRTP_Port name>.<GEFANUC_PLC>.$SYS$Status
```

Example:

```
TCPIP.PLC1.$SYS$Status
```

In this example, the scope of the item is not limited to a specific access path/device group. As long as the data requested is from the same external device specified by the same hierarchical location, the value is always the same.

Note For DDE/SuiteLink clients, \$SYS\$Status always comes from the leaf level of a DAServer hierarchy branch, which is defined by the unique device group. For OPC clients, \$SYS\$Status can be accessed at all hierarchy levels. \$SYS\$Status at the root level of the whole hierarchy tree is always good, as it represents the quality status of the local computer itself. For practical application, OPC clients should reference \$SYS\$Status at hierarchy levels other than the root.

In the ArchestrA context, the device group plays the most important role of identifying the scope of any item. The device group defines the hierarchical location implicitly when using globally unique device group names, which is required for DDE/SuiteLink compatibility.

All system items follow the same naming convention:

- All system items start with \$SYS\$.
- Parsing of the name is case-insensitive.
The DAS Engine scans and parses the name for system items.

All system items can be accessed through subscriptions to a device group. However, while some system items return data for that device group, others are server-wide.

DAServer Global System Item

The following system item refers to specific information regarding a global condition of the DAServer.

System Item Name	Type/ Access Rights	Description	Values
\$SYS\$Licensed	Boolean/ Read	The Binary status indication of the existence of a valid license for the DAServer. If FALSE, this item causes the DAServer to stop updating existing tags, to refuse activation of new tags, and to reject write requests as well as setting quality for all items to BAD. If TRUE, the DAServer functions as configured. All instances have the same value.	RANGE: 0, 1 1: Valid license exists. 0: No valid licenses exist.

DAServer Device-Specific System Items

The following system items refer to specific information regarding the device(s) the DAServer is connected to.

System Item Name (Type)	Type/ Access Rights	Description	Values
\$SYS\$Status	Boolean/ Read	<p>The Binary status indication of the connection state to the device (hierarchy level) the item is attached to.</p> <p>The device group (OPC access path/topic) does not affect the value. The status can be good even if individual items have errors.</p> <p>For DDE/SuiteLink clients, \$SYS\$Status always comes from the leaf level of a DAServer hierarchy branch, which is the destination PLC node.</p> <p>For OPC clients, \$SYS\$Status can be accessed at all hierarchy levels. \$SYS\$Status at the root level of the whole hierarchy tree is always good, as it represents the quality status of the local computer itself. Hence, for practical application, OPC clients should reference \$SYS\$Status at any hierarchy levels other than the root.</p>	<p>RANGE: 0, 1</p> <p>1: DAServer connection to the device is intact.</p> <p>0: Error communicating with the device.</p>
\$SYS\$ErrorCode	Longint/ Read	<p>Detailed error code of the communications state to the device.</p> <p>The device group (OPC access path/topic) does not affect the value.</p>	<p>>=0: Good status (0 is the default state – connected.</p> <p>>0: is some device state such as, connecting, initializing, and so on.</p> <p><0: Error status (value indicates the error).</p>

System Item Name (Type)	Type/ Access Rights	Description	Values
\$SYS\$errorText	String/ Read	<p>Detailed error string of the communications state of the device.</p> <p>The device group (OPC access path/topic) does not affect the value.</p>	Descriptive text for the communications state corresponding to the error code.
\$SYS\$StoreSettings	Integer/ Read/ Write	<p>Make the temporary update interval changes via the \$SYS\$updateInterval item permanent.</p> <p>If the client pokes a value of 1 into this system item, the currently set update interval is written to the servers configuration file. The value of this system item clears to 0 after being set if the configuration file write is successful. If the write fails, then the value is set to -1.</p> <p>If the update interval is changed via the \$SYS\$updateInterval item and this item is not poked to 1, the DAServer uses the original update interval for that topic the next time it is started.</p> <p>Reading the item always provides 0. Read/Write values are persisted only if you set this system item. The values other than this persist only for the life of the DAServer.</p>	<p>RANGE: -1, 0, 1</p> <p>-1: Error occurred during saving the configuration file.</p> <p>0: Always Read value if status is OK.</p> <p>1: Persist settings (cleared immediately).</p>

DAServer Device-Group-Specific System Items

The following system items refer to specific information regarding device groups that are configured in the DAServer.

System Item Name (Type)	Type/ Access Rights	Description	Values
\$SYS\$updateInterval	Dword/ Read/ Write	Accesses the currently set update interval. It is the current update interval of the device group in milliseconds. A client can poke new values into this item. The value of zero indicates that no non-system items on that topic are updated (data for these items are not acquired from the device).	RANGE: 0...2147483647 0: Topic inactive, no items are updated. Data acquisition is stopped. >0: Expected updated interval for the set of all items in the device group.
\$SYS\$maxInterval	Dword/ Read	Accesses the currently measured maximum update interval in milliseconds of all items of the corresponding device group. This item is read-only. The time between two consecutive updates on the item that is updating the slowest is shown.	RANGE: 0...2147483647 0: If update interval is 0 or if the status is false. >0: Measured update interval.

System Item Name (Type)	Type/ Access Rights	Description	Values
\$SYS\$WriteComplete	Integer/ Read/ Write	<p>Accesses the state of pending write activities on the corresponding device group.</p> <p>On device group creation (adding items to an OPC group) the value of this system item is initially 1, indicating all write activities are complete – no pokes are pending.</p> <p>If values are poked into any items of the device group, the value of this item changes to 0, indicating write activity is currently in progress.</p> <p>If the server completes all write activities, the value of this item changes to 1 if all pokes were successful or to -1 if at least one poke failed.</p> <p>If the value of this item is not zero, the client can poke 1 or -1 to it (poke a 1 to clear errors, or a -1 to test a client reaction on write errors).</p> <p>If the value of this item is zero, it cannot be poked.</p>	<p>RANGE: -1, 0, 1</p> <p>1: Write complete (no writes are pending – initial state).</p> <p>0: Writes are pending.</p> <p>-1: Writes completed with errors.</p>

System Item Name (Type)	Type/ Access Rights	Description	Values
\$SYS\$ReadComplete	Integer/ Read/ Write	<p>Accesses the state of reads on all items in the corresponding device group.</p> <p>The value is unequal 0 if all active items in a device group are read.</p> <p>If at least one item in the device group is activated, this item changes to 0. It changes to 1 if all newly activated items are read successfully or to -1 if at least one item has a non-good quality.</p> <p>Poking a 0 to this item resets the internal-read states of all items in this device group. This resets this item to 0. If all items are read again after this poke, this item changes back to 1 or -1.</p>	<p>RANGE: -1, 0, 1</p> <p>1: Read complete (all values have been read).</p> <p>0: Not all values have been read.</p> <p>-1: All values have been read but some have a non-good quality.</p>
\$SYS\$ItemCount	Dword/ Read	<p>Accesses the number of items in the corresponding device group. This item is read-only.</p>	<p>RANGE: 0...2147483647</p> <p>>=0: Number of active items.</p>
\$SYS\$ActiveItemCount	Dword/ Read	<p>Accesses the number of active items in the corresponding device group.</p> <p>This item is read-only.</p>	<p>RANGE: 0...2147483647</p> <p>>=0: Number of active items.</p>

System Item Name (Type)	Type/ Access Rights	Description	Values
\$SYS\$errorCount	Dword/ Read	Accesses the number of all items (active and inactive) with errors (non-good OPC quality) in the corresponding topic. If the communications status of a device group is bad, all items have errors. This item is read-only.	RANGE: 0...2147483647 >=0: Number of all items (active and inactive) with errors.
\$SYS\$PollNow	Boolean /Read/ Write	Poking a 1 to this item forces all items in the corresponding device group to be read immediately (all messages in this device group become due). This is useful if you want to force getting the newest values from the device, regardless of its update interval. This also works on device groups with a zero update interval (manual protocol triggering).	RANGE: 0, 1

DAServer-Specific System Items

The following system items refer to specific information regarding the DAServer, the DAServer Manager, and the controllers.

System Item Name	Description	Data Type	Type/ Access Rights
\$SYS\$requestSent	Returns the number of message requests originating from the communications module.	VT_UI4	Read-Only
\$Sys\$ReplyReceived	Returns the number of reply packets received.	VT_UI4	Read-Only
\$Sys\$UnsolReceived	Returns the number of unsolicited messages received by the communications module.	VT_UI4	Read-Only
\$Sys\$UnsolReplied	Returns the number of replies sent in response to the unsolicited messages.	VT_UI4	Read-Only

System Item Name	Description	Data Type	Type/ Access Rights
\$Sys\$RequestErrors	Returns the number of errors for the requests sent.	VT_UI4	Read-Only
\$Sys\$RequestTimeout	Returns the number of requests that time out.	VT_UI4	Read-Only
\$Sys\$ResetStatistics	Resets the statistics in the associated hierarchy node.	VT_BOOL	Read-Write
\$Sys\$TotalPackets Sent	Returns the number of data packets sent.	VT_UI4	Read-Only
\$Sys\$TotalPackets Received	Returns the number of replies received.	VT_UI4	Read-Only
\$Sys\$RateSent	Returns the number of packets sent per second.	VT_UI4	Read-Only
\$Sys\$RateReceived	Returns the number of packets received per second.	VT_UI4	Read-Only
\$Sys\$ItemUpdateRate	Returns the number of Read items received per second.	VT_UI4	Read-Only
\$Sys\$ItemWriteRate	Returns the number of Write items sent out per second.	VT_UI4	Read-Only
\$Sys\$PlcType	Returns the type of the PLC.	VT_BSTR	Read-Only

Generic OPC Syntax

A DAServer is a container for OPC Groups, providing the mechanism for containing and logically organizing OPC items. Within each OPC Group, an OPC-compliant client can register OPC items, which represent connections to data sources in the field device. All access to OPC items is maintained through the OPC Group.

The fully qualified name for an OPC item is the Item ID, equivalent to Item Name. The syntax for specifying a unique Item ID is DAServer-dependent. In OPC data acquisition DAServers, the syntax can be as follows:

```
TCPIP.PLC1.R0001
```

Where each component (delimited by a period) represents a branch or leaf of the field device's hierarchy.

In this example:

- PLC1 is the name of the target PLC.
- R0001 is the specific data point or item desired.

An item is typically a single value such as an analog, digital, or string value, where:

- Item ID describes the syntax for defining the data point.
- OPC provides another parameter, called Access Path, that defines optional specifications for obtaining that data.

In DAServers, Access Paths are equivalent to Device Groups. This parameter defines the update interval between the DAServer and the field device for accessing the values of data points in the PLC.

Chapter 4

Troubleshooting

This chapter describes the troubleshooting tools that can be used to deal with GESRTP DAServer problems.

The DAServer Manager provides access to diagnostics and other statistical data. The Log Viewer provides access to event messages logged during the operation of the GESRTP DAServer. Your client, for example, the InTouch software, can also monitor connectivity with the PLC through the `SYSStatus` item. Use these tools together with the information in this chapter to troubleshoot your GESRTP DAServer.

Finding the DAServer Version Number

This section describes finding the version number of your DAServer.

To find the version number using Control Panel

- 1 On the Windows **Start** menu, point to **Settings**, and then click **Control Panel**.
- 2 Double-click **Add or Remove Programs**.
- 3 In the **Currently installed programs** list, click **Wonderware GESRTP DAServer**.
- 4 Click the **Click here for support information** hyperlink. The release version of the DAServer appears in the **Support Info** dialog box.

To find the version number using DAServer Manager

- ◆ Click on the DAServer node in the console tree. The build version numbers of the respective DAServer components appear in the details pane.

To find the version number using Windows Explorer

- 1 Search for **DASGESRTP.dll**.
- 2 Right-click on the file name and then click **Properties**. The **Properties** dialog box appears.
- 3 Click the **Version** tab. The build version number of your DAServer is listed under **File Version**.

Monitoring Connectivity Status with the PLC

You can use the built-in discrete item, `$$SYS$$Status`, to monitor the status of communications with the PLC. This item is set to:

- 0 when communications with the PLC fails.
- 1 when communications is successful.

For DDE/SuiteLink clients, `$$SYS$$Status` always comes from the leaf level of a DAServer hierarchy branch, which is the destination PLC node. For OPC clients, `$$SYS$$Status` can be accessed at all hierarchy levels. `$$SYS$$Status` at the root level of the whole hierarchy tree is always good, as it represents the quality status of the local computer itself. For practical application, OPC clients should reference `$$SYS$$Status` at any hierarchy levels other than the root.

Enter the following DDE reference formula in the appropriate place in your client:

=DASGESRTP | GE9030PLC!\$\$SYS\$\$Status

where:

- | | |
|--------------------------|---|
| DASGESRTP | is the name of the DAServer application. |
| GE9030PLC | is the exact device group defined in the DAServer for the PLC. |
| \$\$SYS\$\$Status | is the discrete item that monitors the status of connectivity with the PLC. |

Enter the following OPC item reference syntax when adding the item in your OPC client:

YourOPCAccessPath.\$\$SYS\$\$Status

where:

YourOPCAccessPath	is the assembly of hierarchy node names leading to a specific device (controller).
\$\$SYS\$Status	is the discrete item used to monitor the status of connectivity with the device (controller).

Monitoring the Status of DAS Conversations

The **InTouch WindowsViewer** supports built-in topic names, **DDEStatus** and **IOStatus**, that can monitor the status of specific DAS conversations.

For example, assume that **WindowViewer (VIEW)** is communicating with the GESRTP DAServer to a PLC. The PLC is defined in the DAServer with the topic name **GE9030PLC**. The discrete items, **DDEStatus** and **IOStatus**, are set to 0 when this DAS conversation failed, and to 1 when this DAS conversation is successful.

Using DDEStatus and IOStatus in Excel

The status of communications between the PLC and InTouch software can be read into Excel by entering the following DDE reference formula in a cell on a spreadsheet:

```
=view | DDEStatus!GE9030PLC
```

or

```
=view | IOStatus!GE9030PLC
```

where:

view	is the name of the InTouch application.
[DDE][IO] Status	is the built-in topic name that monitors the status of communications between the DAServer and the InTouch software.
GE9030PLC	is the exact topic name defined in the server for the PLC.

Reading Values from the DAServer into Excel

Values can be read directly into Excel spreadsheets from the DAServer by entering a DDE formula into a cell using the following format:

```
=applicationname | <devicegroup>!itemname
```

Example formula:

```
=DASGESRTP|GE9030PLC!'R0001'
```

where:

DASGESRTP	is the name of the DAServer application.
GE9030PLC	is the exact device group name defined in the DAServer for the PLC.
R0001	is the actual location in the PLC that contains the data value. This is the item name.

In this example, each time the value of <**R0001**> changes in the PLC, the DAServer automatically sends the new value to the cell containing the formula in Excel.

Note See the Microsoft Excel manual for complete details on entering Remote Reference formulas for cells.

Writing Values to the DAServer from Excel

You can write values from Microsoft Excel to the DAServer by creating an Excel macro that uses the **POKE** command.

The proper command is entered in Excel as follows:

```
channel=INITIATE("applicationname","topicname")
=POKE(channel,"itemname", Data_Reference)
=TERMINATE (channel)
=RETURN()
```

The following describes each of the above **POKE** macro statements:

```
channel=INITIATE("applicationname","topicname")
```

- Opens a channel to a specific topic name that is defined in the DAServer in a particular application name (the executable name without the .exe).
- Assigns the number of that opened channel to **channel**.

Note When using the **channel=INITIATE** statement, the word **channel** must be used in the **=POKE** statement instead of the actual cell reference. The "**application name**" and "**topic name**" portions of the formula must be enclosed in quotation marks.

```
=POKE(channel,"itemname", Data_Reference)
```

- Pokes the value contained in the **Data_Reference** to the specified item name or the actual location in the PLC, via the **channel** number that is returned by the previously executed **INITIATE** function.
- **Data_Reference** is the row/column ID of the cell containing the data value.

=TERMINATE(channel)

- Closes the channel at the end of the macro.
- **Channel** is the channel number returned by the previously executed **INITIATE** function.
- Some applications have a limited number of channels, therefore they should be closed when finished.

=RETURN()

- Marks the end of the macro.

Note See the **.xlm** sample Excel poke macro provided on the DAServer CD. Also see the Microsoft Excel manual for complete details on entering Remote Reference formulas for cells.

Diagnostics and Error Tracing

The GESRTP DAServer uses the standard diagnostic information provided by the DAS Toolkit. Access to other internal diagnostic registers of the PLC is performed through reads and writes via the syntax used in item naming.

Error Tracing with the Wonderware Logger

The GESRTP DAServer supports error messages, controller-specific error messages, and error codes. Use the Log Flag data to customize the type of messages logged to the Log Viewer.

Note See the Log Viewer online documentation for more information about using log flags.

GESRTP DAServer Logger Flags

The GESRTP DAServer supports the following server-specific DAS logger flags.

- **Errors**
General errors from the DAServer have the prefix "ERROR." They are highlighted in red so that you can find them quickly. Log flags for GESRTP-specific errors have the suffix "_ERROR." They include CONNECTION_ERROR, POLL_ERROR, and POKE_ERROR.

- Trace
General traces from the DAServer have the suffix "_TRACE." The sever-specific trace log flags include CONNECTION_TRACE, POLL_TRACE, and POKE_TRACE.

The following table lists all the available logger flags and their meanings.

Type	Name	Description
Server Flag	ERROR	Shows general server errors.
	TRACE	Shows general server traces.
Transaction Flag	CONNECTION_ERROR	Shows connection errors.
	POLL_ERROR	Shows errors of poll messages.
	POKE_ERROR	Shows errors of poke messages.
	CONNECTION_TRACE	Shows connection traces.
	POLL_TRACE	Shows traces of poll messages.
	POKE_TRACE	Shows traces of poke messages.

Error Messages, Codes, and Warnings

In addition to the GESRTP DAServer error and warning messages, generic DAServer error codes are supported. Use these messages together with the DAServer Manager Diagnostic root data to troubleshoot GESRTP DAServer problems.

Note The logger messages use the following codes: %s to represent strings and %d to represent numbers (integer).

You can also use the Log Flag data to customize the type of messages logged to the Log Viewer. For more information about using log flags, see the Log Viewer online Help.

GESRTP DAServer Error Messages

The following list contains error messages produced by the DAServer that are logged to the Log Viewer with the DASProtFail, DASProtWarn, DASReceiveMessage, and DASSendMessage log flags. These logger messages occur in error situations if the log flag for errors is on.

Logger messages can be useful for debugging communications problems.

Error Message	Explanation	Probable Cause	Solution
DASProtFail Messages			
DASGESRTP Server creation failed.	The GESRTP DAServer cannot create an object.	The DAServer is not properly installed or it may be a memory-related issue.	Reinstall the DAServer.
Demo license mode for DASGESRTP Server expired.	The DASGESRTP Server was running in demo mode and the time expired.	The demo license time period expired.	Purchase a license.
Failed to initialize listen socket. Hence no unsolicited messages will be received.	The Unsolicited Listen socket failed to initialize.	The socket initialization could not be done properly.	Check the connection and re-start the server.
Attempt to resolve remote hostname "<host_name>" failed.	The hostname could not be resolved.	The hostname specified is not a valid hostname.	Verify the correct IP address of the PLC and the hostname in the hosts file.
Connection attempt for the PLC:<plc_name> has timed out, closing socket at <time>.	The connection attempt to the PLC has timed out.	Network problem.	Check the network connection and try again.
Connection socket to the PLC:<plc_name> failed at <time>.	The socket connection failed.	Network problem.	Check the network connection and try again.
Poke value string length to the Item:'<item_name>' is exceeding 2000 characters. values cannot be processed.	The poke value to the string item is exceeding the protocol limit.	The poke value to the string item is exceeding the protocol limit.	The client must write a smaller value.

Error Message	Explanation	Probable Cause	Solution
<item_name> : Bad Poll Response Received::Error Codes Major:"<major_code >" Minor:"<minor_code >".	The poll operation to an item has a bad response.	The poll could not be done properly.	Check the major and minor code information for more details.
Fault Table: Response packet received from the PLC has insufficient data.	The response packet for the fault number is bad.	The request packet was not sent properly or the fault does not exist in the PLC.	Retry the operation. If the problem persists, contact Technical Support.
Bool items: Response packet from the PLC has insufficient data.	The response packet from the PLC has insufficient data for the advised Boolean items.	The request packet was not sent properly.	Retry the operation. If the problem persists, contact Technical Support.
Insufficient response packet received from the PLC while advising an item.	The response packet from the PLC after advise is bad.	The packet information is lost.	Un-advise and advise again. If the problem persists, contact Technical Support.
Poke operation failed for the item:'<item_name>.	The poke could not be done to the PLC item.	Could not get the poked value from the client.	Retry the poke to the item. If the problem persists, contact Technical Support.
<item_name> : Bad Poke Response Received:: Error Codes Major:<major_code > Minor:<minor_code >	The poke response for the poke operation to an item has a bad response.	The poke could not be done properly.	Check the major and minor code information for more details.
Insufficient response packet received from the PLC while poking to an item.	The response packet from the PLC after the poke is bad.	The packet information is lost.	Retry the poke.

Error Message	Explanation	Probable Cause	Solution
Failed to retrieve host information from a host database. Error code = <error_code>.	The hostname configured for the PLC could not be resolved.	N/A	Use a valid hostname for the PLC.
The socket is marked as nonblocking and the connection cannot be completed immediately for host <host_name>.	A connection could not be established.	The socket could not get the connection established.	Check the network connection and try again.
Socket Read failed with errorcode <error_code>.	The socket read failed while reading a value from the PLC item.	Network problem.	Check the network connection and try again.
SocketWrite failed with errorcode <error_code>.	The socket write failed while updating a value to an item.	Network problem.	Check the network connection and try again.
Unsolicited socket read failed with errorcode <error_code>.	The read from the unsolicited socket failed.	Network problem.	Check the network connection and try again.
Unsolicited socket write failed with errorcode <error_code>.	The write to the unsolicited socket failed.	Network problem.	Check the network connection and try again.

DASProtWarn Messages

PLC Type configured for the host::%s is not matching with the actual PLC type, this may affect the PLC Type dependent items.	The PLC type selected does not match the actual connected PLC.	Either the wrong PLC type is selected or the specified host name is wrong.	Select the correct setting and re-start the server.
--	--	--	---

Error Message	Explanation	Probable Cause	Solution
Reply Timeout is hot-configured to <new_value> millisecs for PLC node '<plc_name>'.	The Reply Timeout parameter is changed while server is running.	You changed the parameter. The change takes effect immediately.	N/A
Connection Timeout is hot-configured to <new_value> millisecs for PLC node '<plc_name>'.	The Connection Timeout parameter is changed while server is running.	You changed the parameter. The change takes effect immediately.	N/A
Max outstanding messages is hot-configured to <new_value> messages for PLC node '<plc_name>'.	The Max outstanding messages parameter is changed while server is running.	You changed the parameter. The change takes effect immediately.	N/A
Program Name is hot-configured to <new_value> for PLC node '<plc_name>'.	The Program Name parameter is changed while server is running.	You changed the parameter. The change takes effect immediately.	N/A
Value of attribute '<attribute_name>' for PLC node '<plc_name>' has changed - Need to restart the server to make the changed value affective.	The attribute is changed while the server is running and the attribute is not hot configurable.	The value change does not go into effect until the server is restarted.	Restart the server.
'<item_name>' is not a valid item name for this PLC<plc_name>.	The item is not supported by the connected PLC.	The wrong item name was specified.	Specify the correct item name.
Read value of element <register_number> in the Item:'<item_name>' is clamped to BCD value 9999.	The value of the register in the register array is clamped to 9999 BCD value.	The BCD limit was reached.	N/A

Error Message	Explanation	Probable Cause	Solution
ServiceRequest code didn't not match the Code:<service_code >,while updating the data to items.	The service request code did not match the supported items service request code in the response packet.	N/A	If the problem persists, contact Technical Support.
Program Name in the PLC<plc_name> is not matching with the Program Name configured in the PLC faceplate; Hence %P and %L items can't be accessed.	The configured program name does not match the program name running in the PLC.	The wrong program name was specified.	Change (hot configure) the program name.
Mixed Suffix: It is not allowed to mix suffix M with suffix A(Register Array).	An unsupported suffix combination is used.	Suffix M and A are used for a single item. This is not supported.	Un-advise the item.
Mixed Suffix: It is not allowed to mix more than one suffix with suffix A(Register Array).	An unsupported suffix combination is used.	More than one suffix is used with suffix A while advising an item as a register array. This is not supported.	Un-advise the item.
Mixed Suffix: Multiple suffixes to an item are not allowed except with suffix A(Register Array).	An unsupported suffix combination is used.	More than one suffix is used while advising an item and one of the suffixes is not suffix A.	Un-advise the item.
Sub-ProgramName supplied along with %L is not a valid name.	The sub-program name is wrong.	N/A	Check the PLC program and correctly specify the sub-program name.

Error Message	Explanation	Probable Cause	Solution
Item <item_name> cannot be added to the PLC <plc_name> due to invalid range, valid range is between 1 to 65535.	The item could not be advised to the PLC because it is not supported by the PLC.	Either the wrong syntax or an invalid range is specified while advising an item.	Check the valid syntax and ranges of the items supported by the PLC.
Invalid suffix type for ASCII string or Register array type item.	The suffixes specified for the ASCII string or register array items are wrong.	Invalid suffixes are applied for the items.	For a detailed explanation of the items advised with suffixes, see the item reference in this documentation.
Item <item_name> cannot be added to the PLC <plc_name>, because range specified are not registers.	The array registers specified are not valid registers.	The array registers specified are not valid registers.	Advise the item with correct registers.
Item:<item_name> cannot be added, Range specified is more than <packet_size>.	The register array or ASCII item specified is more than the protocol limit data size.	The protocol packet limit is exceeded for the advised item.	Advise the item within the supported limit.
Sub-BlockName for the %L item cannot be more than eight characters.	The wrong sub-block specified is.	The sub-block name specified in the item syntax does not match the sub-block constraints.	Check the sub-block naming constraints in the item reference.
Not a valid bit specification in advising Item as discrete, please specify a valid bit number between 0 and 15.	An invalid bit specification is specified.	An invalid bit specification is specified.	Check the item syntax. The valid bit specification to read is from 0 to 15.

Error Message	Explanation	Probable Cause	Solution
Item <item_name> cannot be added as the Item name is invalid for PLC<plc_name>.	The item specified is not supported by the PLC in advise.	An invalid item is advised to the PLC.	Check the item syntax.
PLC Fault Number is out-of-range, please specify valid PLC fault number between 1 and 16.	The PLC fault table fault number advised is not supported.	The PLC fault table fault number advised is not supported.	Retry with a valid fault number. The supported PLC faults range from 1 to 16.
IO Fault number is out-of-range, please specify the valid IO fault number between 1 and 32.	The IO fault table fault number advised is not supported.	The IO fault table fault number advised is not supported.	Retry with a valid fault number. The supported IO faults range from 1 to 32.
Item <item_name> cannot be added to the PLC <plc_name>, Invalid system item.	An invalid system item is advised.	An invalid system item is advised.	Retry with correct item syntax.
Invalid item name <item_name> for the PLC <plc_name>, Unknown Memory Type.	An unknown item type is advised.	An item type unknown by the server is advised.	Retry with correct item syntax.
Specifying bit position is not valid for boolean items.	A Boolean item is advised for a specific bit position.	It is not allowed to read the bit positions in the Boolean items.	Retry with correct item syntax.
No suffix is allowed with boolean Items.	A Boolean item is advised with a suffix.	Boolean items do not support the item suffixes.	Check the suffix constraints specified in this documentation.
Sub-BlockName for %L items cannot be more than eight characters or NULL.	The specified sub-block is wrong.	The sub-block name specified in the item syntax does not match the sub-block constraints.	Check the sub-block naming constraints in the item reference in this documentation.

Error Message	Explanation	Probable Cause	Solution
Sub-Block Name for %L item provided is more than eight characters.	The specified sub-block is wrong.	The sub-block name specified in the item syntax does not match the sub-block constraints.	Check the sub-block naming constraints in the item reference in this documentation.
Poke value to the item '<register_no>' is clamped to <clamped_val>(<actual_val>).	The Modulo-10000 point output value overflowed. The value is clamped.	The Modulo-10000 value written to the PLC exceeded the maximum limit.	The client must write a smaller value.
Poke value to item '<item_name>' is clamped to BCD value 9999(<Poked_value >)	The Modulo-10000 point output value overflowed. The value is clamped.	The Modulo-10000 value written to the PLC exceeded the maximum limit.	The client must write a smaller value.
Poke value to item '<item_name>' is clamped to value <clamped_value>(<poked_value>).	The Modulo-10000 point output value overflowed. The value is clamped.	The Modulo-10000 value written to the PLC exceeded the maximum limit.	The client must write a smaller value.
Poke value to element <register_number> of item '<item_name>' is clamped to value <clamped_value>(<poked_value>).	The Modulo-10000 point output value overflowed. The value is clamped.	The Modulo-10000 value written to the PLC exceeded the maximum limit.	The client must write a smaller value.
Poke value to element <register_number> of item '<item_name>' is clamped to BCD value 9999(<poked_value >).	The Modulo-10000 point output value overflowed. The value is clamped.	The Modulo-10000 value written to the PLC exceeded the maximum limit.	The client must write a smaller value.

Error Message	Explanation	Probable Cause	Solution
Number of values poked to array item '<item_name>' exceeds its size, hence limited to <clamped_value>(<poked_value>).	The values poked to an item exceeded the size of the array item. The value is clamped.	Too many values were poked to an array item.	N/A
Poke value to the item: '<item_name>' is clamped <clamped_val>(<actual_val>).	The value poked to an item exceeds its capacity. The value is clamped.	A value larger than the data type was poked.	Poke a value within the valid range.
%P item is supported by 'Series 9070' PLCs only. Hence item <item_name> cannot be added to PLC<plc_name>	%P item is advised to an unsupported PLC type.	%P and %L items are supported only by Series 90-70 PLCs	Advise the items %P and %L to Series 90-70 PLCs.
%L item is supported by 'Series 9070' PLCs only. Hence item <item_name> cannot be added to PLC<plc_name>	%L item is advised to an unsupported PLC type.	%P and %L items are supported only by Series 90-70 PLCs	Advise the items %P and %L to Series 90-70 PLCs.
DASReceive Messages			
Data socket handling reply '%s	This is a data reply from the Read socket.	N/A	N/A
DASSend Messages			
Unsolicited response send() - operation not complete, wait for event	The socket Write operation for the unsolicited message fails to complete.	The Send operation fails to complete.	Wait for the Send event to complete.

Error Message	Explanation	Probable Cause	Solution
Unsolicited response send() - WSAGetLastError = %d	The socket Write operation for the unsolicited message fails.	The acknowledgement packet for the unsolicited message cannot be sent.	Check the network connection. If the problem persists, contact Technical Support.
Info Messages			
Re-trying connection for the PLC:<plc_name> after slowpoll interval.	The PLC connection failed, so a retry occurs after the specified slow poll interval.	The connection to the PLC failed.	Wait for the connection until the server comes out of slow poll mode.

Wonderware DAServer Error Codes

The following table lists the Wonderware DAServer error codes and the error messages that appear with the codes, and their descriptions.

Code	Error Message	Description
C004D000L	Invalid item name	The requested item name has bad syntax.
C004D001L	Item name not exist	The requested item name has good syntax, but it does not exist.
C004D002L	Device not connect	The device is not connected, so data cannot be acquired.
C004D100L	Device off scan	The device is communicating, but it cannot accept queries for data items.
C004D101L	Timeout	A message transaction with the device timed out.

GESRTP DAServer Error Codes

The following table lists the exception codes that the DAServer generates through the SRTP protocol. These error codes, with their server-specific strings, are logged to the Wonderware Logger. The log flag for all these error codes is DASProtFail.

SRTP Error Code	Logger Message
DASProtFail Messages	
1	Illegal Service Request: either not defined or not supported.
2	Insufficient Privilege: the minor status field contains the privilege level required for the service request.
4	Protocol Sequence Error: the CPU has received a message that is out of order.
5	Service Request Error: Minor status field contains the request specific error code. See table of Minor Error Status Codes below.
6	Illegal Mailbox Type: Service request mailbox type is either undefined or unexpected.
7	The PLC CPU's Service Request Queue is full. The master should retry later. It is recommended that the master wait a minimum of 10 ms before sending another service request.
178	Program block already exists and cannot be replaced.
179	Length limit exceeded; includes read past end of transferred data, writes past end of program block.
180	Attempt to alter interrupt list in MAIN DECL BLOCK during RUN MODE.
181	Additive checksum comparison in Verify failed.
182	Cyclic Redundancy Check (CRC) checksum comparison in Verify failed.
183	Segment length in Verify not equal to the segment length of block in the PLC.
184	Size of the Segment Selector Table in TYPDEF record is not correct.
185	Executable flag in TYPDEF record not set.
186	Block Set already exists, cannot create.
187	Maximum length of a partial store exceeded.
188	Block Type (e.g., data) not found.

SRTP Error Code	Logger Message
189	Block Set (subblock name) not found.
190	Bad Block Type given in Load/Store.
191	Illegal OMF record type/data contents.
192	Bad OMF record checksum in store.
193	Invalid block state transition.
194	The OEM key is NULL (inactive).
195	Text length does not match traffic type.
196	Verify with FA Card or EEPROM failed.
197	No task-level Rack/Slot configuration to read or delete.
198	Control Program (CP) tasks exist but requestor not logged into main CP.
199	Password(s) already enabled and cannot be forced inactive.
200	Password(s) already enabled and cannot be forced inactive.
201	Login using non-zero buffer size required for block commands.
202	Device is write protected.
203	A comm or write verify error occurred during save or restore.
204	Data stored on device has been corrupted and is no longer reliable.
205	Attempt was made to read a device but no data has been stored on it.
206	Specified device has insufficient memory to handle request.
207	Specified device is not available in the system (not present).
208	One or more PLC modules configured have unsupported revision.
209	Packet size or total program size does not match input.
210	Invalid write mode parameter.
211	User Program Module (UPM) read or write exceeded block end.
212	Mismatch of configuration checksum.
213	Invalid block name specified in Datagram.
214	Datagram connection boundary exceeded.

SRTP Error Code	Logger Message
215	Invalid Datagram type specified.
216	Point length not allowed.
217	Transfer type invalid for this selector.
218	Null pointer to data in segment selector.
219	Invalid segment selector in Datagram.
220	Unable to find connection address.
221	Unable to locate given connection ID.
222	Size of Datagram connection invalid.
223	Invalid Datagram connection address.
224	Service in process cannot login.
225	No I/O configuration to read or delete.
226	IOS could not delete configuration or bad type.
227	CPU revision number does not match.
228	Segment for this selector does not exist.
229	DOS file area not formatted.
230	CPU model number does not match.
231	Configuration is not valid.
232	No user memory is available to allocate.
233	Segment selector not valid in context.
234	Not logged in to process service request.
235	Task unable to be deleted.
236	Task unable to be created.
237	VMEbus error encountered.
238	Could not return block sizes.
239	Programmer is already attached.
240	Request only valid in stop mode.
241	Request only valid from programmer.
242	Invalid program cannot log in.
243	I/O configuration mismatch.
244	Invalid input parameter in request.
245	Invalid password.
246	Invalid sweep state to set.
247	Required to log in to a task for service.
248	Invalid task name referenced.
249	Task address out of range.
250	Cannot replace I/O module
251	Cannot clear I/O configuration.

SRTP Error Code	Logger Message
252	I/O configuration is invalid.
253	Unable to perform auto configuration.
254	No privilege for attempted operation.
255	Service request has been aborted.

Data Conversion

The following table describes how the GESRTP DAServer handles values that cannot be converted or do not meet the limit specifications.

Conversion	Description
NONSPECIFIC	If a value cannot be converted, the quality of the item goes to NONSPECIFIC.
Uncertain-HIGHLIMITED	If a value is greater than the upper limit, the quality of the item goes to uncertain-HIGHLIMITED.
Uncertain-LOWLIMITED	If a value is smaller than the lower limit, the quality of the item goes to uncertain-LOWLIMITED.

Quality Settings

The GESRTP DAServer uses the general OPC-defined quality settings. An item can have six basic data quality states.

Quality Code	Quality State	Description
00C0	Data quality good	Data communications is good and the data is good. The register is read or written to without any problems converting the data.

Quality Code	Quality State	Description
0055	Clamp low	<p>Data communications is good but the data is uncertain.</p> <p>The data is clamped at a low limit.</p> <p>The register is correctly read or written to, but it is necessary to clamp its value to a limit.</p> <p>The value is smaller than the minimum allowed.</p>
0056	Clamp high	<p>Data communications is good but the data is uncertain.</p> <p>The data is clamped at a high limit.</p> <p>The register is read or written to, but it is necessary to clamp its value to a limit.</p> <p>The value is larger than the maximum allowed.</p> <p>A string is truncated.</p> <p>For example, a floating point value is clamped to FLT_MAX.</p>
0040	Quality uncertain/No convert	<p>Data communications is good but the data is uncertain.</p> <p>The data cannot be converted.</p> <p>The server may return either a constant in place of the data or return quality information alone.</p> <p>The data is useable. However, it is not known whether the value is too large or too small.</p> <p>Incorrect data type.</p> <p>Floating point is not a number.</p> <p>For example, 0x000a in a PLC BCD register.</p>

Quality Code	Quality State	Description
0004	Bad configure/No access	<p>This is a bad configuration error.</p> <hr/> <p>Data communications is good but the data cannot be sent and/or received. The data is bad and cannot be used.</p> <hr/> <p>Item cannot be accessed.</p> <hr/> <p>The item does not exist or is not available.</p> <hr/> <p>The server can communicate with the PLC but cannot access the register.</p> <hr/> <p>The server determined the point is not valid.</p> <hr/> <p>The PLC responds that the register does not exist, cannot be read, or cannot be written to.</p> <hr/> <p>The server cannot access a fenced, write-protected, or read-only item.</p> <hr/> <p>The PLC is in a mode that does not permit access to this item.</p> <hr/> <p>The number of data bytes is incorrect but the message is otherwise good.</p> <hr/> <p>The command or op code is invalid but the message is otherwise good.</p> <hr/> <p>The PLC is busy. The server has given up retrying.</p>

Quality Code	Quality State	Description
0018	No communications	<p>Data communications is down.</p> <p>Cannot access the PLC due to a communications error.</p> <p>The data is bad and cannot be used.</p> <p>The device group is in a slow poll or equivalent mode.</p> <p>The PLC does not exist and/or is not responding.</p> <p>There is no link validating the message.</p> <p>There is a lack of resources in the server. A TSR or driver cannot allocate memory.</p> <p>There is a lack of resources in the communications link.</p> <p>The communications link is off-line.</p> <p>All communications channels are in use.</p> <p>The network cannot route the message to the PLC.</p>

Chapter 5

Reference

This section describes the architecture of the DAServer, its collection of components, and the environments in which the components work.

DAServer Architecture

The GESRTP DAServer is supported on Microsoft Windows XP Pro, Windows 2003 Server, Windows 2000 Professional, Windows 2000 Server, and Windows 2000 Advanced Server. NetDDE protocol is not supported by DAServers.


This DAServer is a collection of components that work together to provide communications access to the hardware field devices. These components include:

- **DAServer Manager**
The Microsoft Management Console (MMC) snap-in environment, supplied with the DAServer, that provides the necessary user-interface for diagnostics, configuration, and activation.
- **Client Plugins**
The components that are added to a DAServer to enable communications with clients. Examples are OPC, DDE/Suitelink, and so on.
- **DAS Engine**
The library that contains all the common logic to drive data access.
- **Device Protocol**
The custom code provided by the DAServer to define the communications with a particular device.

DAServers

A DAServer consists of the following three physical parts:

- **Plugin Component(s)**
This component is responsible for communicating with clients.
- **DAS Engine**
This common component is used by all DAServers.
- **PLC Protocol Layer, DAServer-specific**
This component is responsible for communicating with the hardware.



DAServer Architecture

Each physical part of a DAServer consists of a set of .exe and/or .dll modules. Wonderware provides the plugins and the DAS Engine. Using the DAS Toolkit, you create the PLC Protocol Layer (DAServer-specific) modules. All three sets of modules are required for a fully functioning DAServer.

Plugins

Plugins provide a protocol translation function for device integration clients. Typical plugins communicate in DDE, SuiteLink, or OPC protocol, and serve as interfaces between their clients and the DAS Engine.

Note Items in an array are not supported in the DDE/SL plugin. Arrays are converted to HEXASCII strings, which provide legacy behavior for DAServers that support this in the DAServer-specific code.

DAS Engine

The DAS Engine is a middleware component that exposes two sets of interfaces, one for communicating with the plugins and the other one for communicating with the PLC Protocol Layer components.

PLC Protocol Layer

The PLC Protocol Layer provides a protocol translation function for specific hardware such as ModBus, and serves as an interface between the DAS Engine and the hardware.

Component Environments

Stand-alone DAServers have the following characteristics:

- The DAS Engine is dynamically linked to the other DAServer components. A new DAS Engine such as feature enhancements or bug fixes do not require relinking to the other components nor re-QA of those other components. When deployed to the system, the new DAS Engine attaches to all existing DAServer components.
- Newly deployed plugins such as feature enhancements or bug fixes do not require relinking nor re-QA of associated components. Even new plugins (for example, OPC Alarm & Events) do not require any development changes to the other components, and require no relinking in a customer-installed base. In fact, you can implement new functionality in a plugin to enhance the DAServer without involving the code of the other components.
- DAServers can be configured in one stand-alone configuration utility (DAServer Manager) capable of showing specific configuration pages for all DAServers. This utility allows the browsing and editing of DAServers on different nodes.
- The DAServer Manager diagnostics tool shows generic diagnostic objects common to all DAServers, as well as DAServer-specific/DAServer-developer-defined diagnostic data.

The DAServer data configuration format is XML. Any XML Editor can read this format.

Appendix A

Supported DAServer Hardware and Firmware

The GESRTP DAServer operates only with a standard network interface card in the computer on which it is installed. The supported GE Fanuc PLCs must include Ethernet modules or controllers (CPUs) with built-in Ethernet ports.

The following table lists the hardware and firmware supported by the GESRTP DAServer Version 1.5.

Device	Description	Hardware and Firmware
Series 90-30 PLC	Controller	TCP/IP Ethernet Interface module (catalog number IC693CMM321) OR Controller (CPU) with built-in 10/100Mbps Ethernet port (catalog number IC693CPU364/IC693CPU374)

Device	Description	Hardware and Firmware
Series 90-70 PLC	Controller	MMS-Ethernet Controller module (catalog number IC697CMM741/IC697CMM742) You must properly configure and download device IC697CMM741 using the Series 90-70 Ethernet TCP/IP software (catalog number IC651ENS042).
Versamax	Controller	CPU with Ethernet port (catalog number IC200CPUE05)
VersamaxMicro PLC	Controller	Ethernet Interface, a Bridge from RS-232 or RS-485
VersamaxNano PLC		Serial to Ethernet 10 BaseT (catalog number IC200SET001)
Rx7i PacSystem	Controller	TCP/IP Ethernet Interface module (catalog number IC698ETM001) OR Controller (CPU) with Embedded 10/100Mbps Ethernet port (catalog number IC698CPE010/IC698CPE020)
Rx3i PacSystem	Controller	TCP/IP Ethernet Interface module (catalog number IC695ETM001)

Index

Symbols

\$Sys\$ItemUpdateRate 58
 \$Sys\$ItemWriteRate 58
 \$Sys\$PlcType 58
 \$Sys\$RateReceived 58
 \$Sys\$RateSent 58
 \$Sys\$ReplyReceived 57
 \$Sys\$RequestErrors 58
 \$SYS\$RequestSent 57
 \$Sys\$RequestTimeout 58
 \$Sys\$ResetStatistics 58
 \$Sys\$TotalPacketsReceived 58
 \$Sys\$TotalPacketsSent 58
 \$Sys\$UnsolReceived 57
 \$Sys\$UnsolReplied 57

A

access path 59
 activating
 the DAServer 27
 adding a GEFANUC_PLC object 20, 25
 adding a GESRTP_PORT object 20, 24
 aliases 30
 application name 14
 application protocols 10
 ArchestrA 50
 ArchestrA System Management
 Console 19, 20

ArchestrA.DASGESRTP.1 12, 20, 22
 archiving
 configuration sets 36, 37
 arrays 87

B

base item names 46
 BCD format 48
 bus protocols 10

C

clearing
 all device items 32
 client plugins 85
 command
 import 33
 communication protocols 10
 communications protocol server 9
 configuration
 branch 20, 24
 node 37
 set name 37
 configuring
 default update intervals 30
 device group definition 28
 device item definition 28
 the DAServer 21
 configuring as a service 21, 28

creating or adding
 device groups 29
 device items 31
CSV file 32

D

DAS Engine 85, 86, 87
DAS logger flags 65
DAS Server Manager 21
DAS Toolkit 65, 86
DAServer architecture 10, 15
DAServer Manager 13, 22, 85
 diagnostics tool 87
 documentation 21, 22
 online Help 20
 tree 20
 tree view 23
DASGESRTP.dll 62
Data Access Server 9
data-type identifiers 39
DCOM 10
DDE 9, 11
DDE/SuiteLink clients 62
DDEStatus 63
deactivating
 the DAServer 27
default group 22
default update interval 30
deleting
 device groups 30
 device items 32
demo mode 15
device group 13, 50
device groups 23, 59
device hierarchy 19, 22
device item definitions 30
device protocol 85
diagnostics 11
Dynamic Data Exchange 11

E

edit mode 20, 24
editing
 update intervals 30
editing item data 32
Excel 63
Excel macro 64
exporting

 DAServer item data to a CSV file 32

F

FastDDE 9, 11
FASTPOLL 14
features 15

G

GESRTP DAServer 9
GESRTP_PORT root 27
global parameters 22
group 49
group name 13

H

HEXASCII strings 87
hierarchical location 50
hierarchy 23
HMI 10
host 12

I

importing
 DAServer item data from a CSV file 33
Industrial Ethernet 10
intervals
 update 29
IOStatus 63
item
 ID 58
 name 15, 58
item name 13, 31
item reference 31
ItemID 12

L

license 15
License Manager 16
link name 13
local node 22
Log Flag data 65, 66
Log Viewer 61, 66

M

making edits
 device groups 30
Microsoft Management Console 21
middleware component 87

MMC 21

N

network transport protocol 11

node name 12, 14

O

object name 27

off-line editing 32

OLE/COM technology 10

OPC 10

- clients 62

- item browsing 31

- item name 12

- protocol 12

OPC client 9, 31

P

PLC hierarchy node 31

PLC Hierarchyname.csv file 32

PLC protocol layer 86, 87

PLC type 25

plugin component 86

port number 24

predefined item syntax 30

preparing

- the GESRTP DASServer 19, 22

ProgID 12

program name 12

Q

quality settings 80

R

rate

- update 13

read/write 12

remote access 12

remote communications 10

remote reference formulas 65

renaming

- device items 32

S

SCADA 10

scan group 50

service

- automatic 27

- manual 27

Setup.exe 19, 21

snap-in environment 20, 22

status items 43

status of connectivity 62

suffixes 39

SuiteLink 10

SuiteLink client 9

system items

- DASServer device-group-specific 54

- DASServer device-specific 52

- DASServer global 51

System Management Console 22

T

TCP 10

TCP/IP 10

topic name 14

U

unsolicited messages 35

update

- intervals 29

- rate 13

update interval 13

- parameter 34

using

- different configuration sets 37

V

Value Time Quality (VTQ) 11

values

- converting 80

version 61

VIEW (WindowViewer) 63

W

WindowViewer 63

WinSock 11

Wonderware InTouch software 9

X

XML 87

XML Editor 87

