



- NOTES:
1. PROGRAMMING: DRIVE MACRO = HVAC DEFAULT.
 2. DASH LINES INDICATE CUSTOMER INSTALLED DEVICES AND WIRING
 3. COPPER WIRE RATED FOR 60°C INSULATION IF RATED LESS THAN 100A OR 75°C IF RATED 100A OR MORE MUST BE USED.
 4. REFER TO USER MANUAL FOR OPERATION, CONNECTIONS AND TIGHTENING TORQUE VALUES.
 5. FUSE RATING LABEL IS NEAR DEVICE.
 6. CUSTOMER REQUIRED TO PROVIDE BRANCH CIRCUIT PROTECTION AND DISCONNECT MEANS PER NEC AND LOCAL CODE.
 7. SHDRT CIRCUIT CURRENT: 100kA RMS SYMMETRICAL 480V MAXIMUM.

Rev	SEE ECN 10003203	06/23/09	DC	ACX550	Power Wiring Diagram	ACH550 PACKAGED DRIVE INPUT SWITCH AND FUSES	J. Truettner	ABB	ABB Inc.	9/19/2007	PD00R046PW-A	Sheet A
Based On	Description	Date	Appd	Discription	Project Name	Project Name	Checked	Responsible	Date	Document Number	Sheet	
							J. Brenner	AJ		3AUAD000014954	Cont. B	