

1	2	3	4	5	6	7	8
<p>Original drawing made with Pro/ENGINEER. Set the correct scale factor. When adding dimensions after DWG/DXF conversion.</p> <p>First angle projection.</p>							
A	B	C	D	E	F		
<p>We reserve all rights in this document and in the information contained therein. Reproduction, use or disclosure to third parties without express authority is strictly forbidden.</p> <p>ABB Oy</p>							
A2+	A1						
<p>RECD_R2 (ASSM)</p>							
<p>3AUAA0000051090</p>							
<p>Initial approval</p>							
<p>23-jou-09 MPellikka</p>							
<p>Based on Customer</p>							
<p>Prepared MPELLIKKA</p>							
<p>Check. MUIPPINEN</p>							
<p>Appr. YPALOJOKI</p>							
<p>Cust. Doc. No.</p>							
<p>ABB Ref. No.</p>							
<p>Project name</p>							
<p>Weight kg</p>							
<p>589092890</p>							
<p><b>ABB</b> DRIVES</p>							
<p>Doc. No. 3AUAA0000051090</p>							
<p>Doc. des. DIMENSION DRAWING</p>							
<p>Scale 1:4</p>							
<p>Form A4</p>							
<p>Lang. EN</p>							
<p>Sheet 1</p>							
<p>Total 1</p>							

