



HPD-N Series Do's and Don'ts

Do...

1. Follow the *HPD-N Quick Reference Guide* for all wiring and parameter configuration.
2. Supply the recommended input voltage of 90 - 480VAC, 3-phase input power.
3. Always issue a Pb99.11 = 1 after changing the SLVD Operating Mode (Pr.31).
4. Always save your parameter modifications (Pr99.15 = 1).
5. Refer to the *HPD-N Quick Reference Guide*, HPD-N User's Manual or contact Compumotor's Application Department for assistance at 1-800-358-9070.

Do Not...

1. Connect a voltage greater than 240VAC to the control power.
2. Modify the Resolver Offset parameter (Pr. 30) while the drive is enabled. Only modify this parameter when the drive is *disabled* (to prevent damaging the drive).