
Capacitive sensor BC5-S18-RZ3X





Switching state

LED, Yellow


Capacitive sensor BC5-S18-RZ3X




Mounting instructions/Description	minimum distances
Distance D	36 mm
Distance W	15 mm
Distance S	27 mm
Distance G	30 mm

Diameter active area B

Ø 18 mm



The given minimum distances have been checked against the standard switching distance. Should the sensitivity of the sensors be changed via potentiometer, the data sheet specifications no longer apply.



Capacitive sensor BC5-S18-RZ3X



Accessories

Type code	Ident-No.	Description	
BS-18	69471	Mounting bracket for threaded barrel devices; material: PA66-GF	e 18.2 40 7.5, 22,5 22, 45 6 5,5 (2x)
BSN 18	69472	Fixing clamp; material: PA66-GF	20 32 0 18 40 0 50 50 50 50 50 50 50 50 50 50 50 50
BST-18B	6947214	Fixing clamp for threaded barrel devices, with dead-stop; ma- terial: PA6	
MAP-M18	6950012	Mounting adapter; material: Polypropylene; sensor replace- ment with filled container possible (adapter remains in con- tainer during sensor replacement)	0 36 R 3/4 M18 x 1 0 19 42,5