

OM414 Setpoint/ Display Panel

The OM414 Setpoint/Display Panel is a low cost/high performance man/machine interface with a broad range of operator input and display capabilities. The panel includes six field points which can be used for either setpoint entry or data display.

The eight digit numeric LED display is associated with six field points. The user can select which field point to project on the display by use of the SELECT button. The LEDs adjacent to the user defined field point labels highlight which field point is active. Once selected, the display will either show the related data or project the current setpoint value.

Setpoint adjustment can be performed by use of the arrow keys to move the value up or down. Once set, the value is saved into nonvolatile memory. It is permanently stored, whether power remains on or not, until the next time it is changed by the operator.

Each field point can be custom labeled by the user with plastic inserts. The inserts can be custom legended with text and/or graphics, and slip into a protective pocket behind the faceplate.

The OM414 Setpoint/Display Panel is part of Optimization's **OptiMate**® series. Each OptiMate module is designed to connect to a PLC with a single cable connection. OptiMate 400 Series panels can be used individually with a PLC or in a Microprocessor system.

When used with a PLC, operation is transparent to the user. Panel functions tie directly into your PLC ladder logic program. The OM414 takes care of the rest.

Applications

- Machine control
- Process control
- Security systems
- HVAC
- Plant monitoring/control
- PLC applications
- Microprocessor applications

Features

- 6 Setpoints or display points
- Eight digit numeric display
- BCD "Double" capability
- Pushbutton item selection
- PLC compatible
- RS232 communications
- Stand alone operation capable

Contents

Configuration Options

- Stand Alone
- Microprocessor

Use with a PLC

- Examples with PLC Direct
- Examples with Allen-Bradley

Microprocessor Based Systems

- OptiMate Hex Protocol

SetUp and Interconnect

- Legending the Field Points
- Connection to the System

Configuration


- Configuration Selections

Label Templates Specifications

OptiMate is a registered trademark of Optimization, Inc.

copyright ©1998, Optimization, Inc.

Configuration Options



PLC Stand Alone

OptiMate panels plug directly into most PLCs. A cable connection allows you to interface and control the OptiMate panel via PLC data registers and ladder logic.

The OM414 Setpoint/Display Panel uses a bank of PLC registers. Complete operator interface is performed with 15 PLC registers for data entry and display. The OM414 continuously accesses these PLC registers and performs operations under ladder logic control on a real time basis.

PLCs are slave devices on their standard communications ports. This means that a panel attached to the standard port must control the transfer of information by reading and writing the PLC registers. OptiMate panels will perform this communications for most major PLC protocols. Configuration for particular PLC protocols and interconnect cabling is covered in the following pages.


Microprocessor Based Systems

OptiMate 400 Series modules can interface directly to most computers or microcontrollers. The modules communicate over RS232 serial communications. All that is required to interface OptiMate modules is an RS232 serial port and the ability to send and receive Hex numbers. The OptiMate Hex communications protocol, detailed in this document, allows the user to directly read setpoint values and write data to display points.

Since the OptiMate 400 Series panels can only communicate on RS232, only 1 panel can be interfaced on each serial communications port.

In a microprocessor based system, the host microprocessor is the system master. The OptiMate modules are slave devices that respond to commands from the host. In the case of the OM414, these commands are requests for setpoint values and messages that update display points.


Use with a PLC



Memory Mapping

Memory mapping is a technique that “maps” the memory of an OptiMate panel into the registers of the programmable controller. By knowing where the data of the specific OptiMate panel is mapped, this data can be moved, changed or monitored using ladder logic.

The term PLC register is used for the area of memory within the programmable controller used for data exchange with the OM414. PLC registers are sometimes know as data registers or internal registers.




The OM414 Setpoint/Display Panel uses a bank of 15 contiguous PLC registers. The register set definition is shown in the table below

OM414 Panel PLC Register Map	
PLC Register	Register Function
X	Field point 1 data cell
X+1	Field point 1 data cell 2 (long BCD)
X+2	Field point 2 data cell
X+3	Field point 2 data cell 2 (long BCD)
X+4	Field point 3 data cell
X+5	Field point 3 data cell 2 (long BCD)
X+6	Field point 4 data cell
X+7	Field point 4 data cell 2 (long BCD)
X+8	Field point 5 data cell
X+9	Field point 5 data cell 2 (long BCD)
X+10	Field point 6 data cell
X+11	Field point 6 data cell 2 (long BCD)
X+12	Field point force data cell
X+13	Field point force data cell 2 (long BCD)
X+14	Force control

Register Definition

The following describes the function of the registers shown in the table.

- Register X - Field point 1 data. Either setpoint or display, as configured. Numeric data is either a Binary value or the four least significant digits of the BCD long number in field point 1.
- Register X+1 - Field point 1 data cell 2 (used for long BCD numbers only). Either setpoint or display, as configured. Numeric value is the four most significant BCD digits of data for field point 1.
- Register X+2 - Field point 2 data.
- Register X+3 - Field point 2 data cell 2 (used for long BCD numbers only).
- Register X+4 - Field point 3 data.
- Register X+5 - Field point 3 data cell 2 (used for long BCD numbers only).
- Register X+6 - Field point 4 data.
- Register X+7 - Field point 4 data cell 2 (used for long BCD numbers only).
- Register X+8 - Field point 5 data.
- Register X+9 - Field point 5 data cell 2 (used for long BCD numbers only).
- Register X+10 - Field point 6 data.
- Register X+11 - Field point 6 data cell 2 (used for long BCD numbers only).
- Register X+12 - Field point force data. Value to force setpoint equal to when force operation is initiated by the PLC program.
- Register X+13 - Field point force data cell 2 (used for long BCD numbers only). Four most significant digits of BCD long value to force setpoint equal to when force operation is initiated by the PLC program.
- Register X+14 - Force control. Controls the forcing of setpoints.
 - > FSP bit - When set, the field point force data (X+12 and/or X+13) will be forced into the field points that are set to be forced by setting the bits FP1 - FP6. Once the force is finished, the OM414 will clear X+12, X+13 and X+14.
 - > FP1-FP6 - Identifies which setpoints must be forced.



Force Register Bit Association

Operational Overview

Reading a Setpoint

Setpoint data is continuously and transparently written to the associated PLC register(s). To access and use the setpoint data, simply reference the relevant PLC register(s) (X through X+11) in your PLC program.

Writing a Display Point

Writing a display value simply requires writing data into the associated PLC register(s) (X through X+11). The OM414 will automatically retrieve and display the data.

Forcing a Setpoint

There are times when it is necessary for the PLC program to initialize or override a setpoint. The capability to do so is provided as the Force Setpoint function.

To force a setpoint to a given value, the value should be placed in register(s) X+12 (and X+13 for BCD long numbers). Next the bit(s) (FP1 - FP6) corresponding to the setpoint(s) to be forced must be set and the FSP bit must also be set. When the OM414 panel has forced the setpoint to the required value, it will clear registers X+12, X+13 and X+14.

Note: If the Force Setpoint option is not selected in the OM-WINEDIT Configuration Software, the setpoints cannot be forced. Also, the registers X+12, X+13 and X+14 will not be used by the OM414 and can be used in your PLC program.

Numeric Data Types

There are two types of data that the OM414 can display. They are BCD long (also known as BCD Double) and Binary.

BCD Long Data

BCD long (or BCD double) data has a range of 0 - 99999999.

To display a BCD long number, place the least significant four digits of the number into the field point data cell. Next, place the most significant four digits into the field point data cell 2.

To read a setpoint BCD long setpoint value, the OM414 continuously places the least significant four digits into the corresponding field point data cell and the most significant four digits into the corresponding field point data cell 2. Simply reference both registers in your PLC program to use the setpoint value.

If the displayed value or the setpoint value is 92345678, the PLC register will display the following: (shown in BCD/Hex format)

BCD Long Data	PLC Register
Field point data cell	5678
Field point data cell 2	9234

Binary Data

Binary data has a range of 0 - 65535 (0 - FFFF in HEX format).

To display a Binary number in a display point, simply place the Binary value in the appropriate data cell.

To read a Binary setpoint value, reference the appropriate PLC register in your PLC program.

If the displayed value or the setpoint value is 40500, the PLC register will display the following: (shown in BCD/Hex format)

Binary Data	PLC Register
Field point data cell	9E34
Field point data cell 2	XXXX (Don't care)

Note: When configuring the setpoint ranges, ensure that the High Limit is at least one number greater than the Low Limit or the panel will not work properly. This is true for all data types.

Decimal point

The number of digits displayed after the decimal point is configured in the OM-WINEDIT Configuration Software. The decimal point location is configured separately for each field point.

The decimal point is for displaying purposes only and cannot be changed by or written to a PLC register for use in the program. Once configured, it is fixed and cannot be changed without re-configuring the OM414.

For BCD long numbers, the number of digits that can be displayed after the decimal varies from 0 to 7.

For Binary numbers, the number of digits that can be displayed after the decimal varies from 0 to 7 but the highest number that can be displayed is 65535 (i.e. 0.0065535).

Examples of Use with a PLC Direct PLC

Register Usage

The OM-WINEDIT Configuration Editor allows you to configure a module to use a block of registers at a starting value that you define. For a PLC Direct 105, 205, 350 or 405 PLC the recommended memory to use is the general purpose data words starting at V2000 and V4000. For the 305 family, except for the DL350, the recommended memory is the registers beginning at R400. Any block of registers within the data word range can be used.

All of the examples that follow assume that the OM414 module has been configured, through the OptiMate Configuration Editor, for a base register address of V2000.


Setpoint & Display Operations

Displaying Numeric Data

Displaying numeric data in one of the 6 field points is a very simple process. During the initial configuration, make sure you define the point as a display point, not a setpoint. When this is done, the PLC program must simply put data to be displayed into the register(s) associated with the display data field.

The figure at right illustrates a numeric display application with a PLC Direct 105,205,350 or 405 series PLC. In this application, the OM414 is configured for a base address of V2000 and field point 2 for display, BCD long and 7 digits after the decimal. A BCD long value, held in V2106 and V2107 must be displayed in field point 2, V2002 and V2003, as long as X5 is active. The example shows the value transferred from V2106 and V2107 to V2002 and V2003. It will be displayed as field point 2.

To display a Binary number, simply configure the field point for display, Binary, and the required number of digits after the decimal. Next, use the LD and OUT instructions instead of the LDD and OUTD since the Binary data type only uses 1 register.




Reading a Setpoint

The OM414 continuously updates the registers of all setpoints with each setpoints current value. To read a setpoint, simply access the register(s) that correspond to each setpoint. The data can be copied to another register for manipulation or it can be accessed in its field point register(s).

The following example uses an OM414 at base address V2000. Field point 1 has been configured as a setpoint, BCD long and 2 digits after the decimal point. In the example program, field point 1 is a High Limit setpoint. Whenever C71 is active, the program shown checks a value, held in V4065 and V4066, against the setpoint value, held in V2000 and V2001. If the value exceeds the setpoint, Y10 will be turned on.

To read a setpoint configured as Binary, simply configure the field point for setpoint, Binary, and the required number of digits after the decimal point. Next, use the LD and CMP instructions instead of the LDD and CMPD instructions since the Binary data type only uses 1 register.



Forcing Setpoints

The OM414 gives you the capability to force a setpoint to a value from the PLC.


To force a setpoint to a value, the value(s) should be placed in register X+12 (and X+13 if BCD long). Next the force setpoint bit FSP and the bit(s) corresponding to the setpoint(s) to force to this value must be set in the force control register (X+14). When the OM414 completes the force operation, it will clear registers X+12, X+13, and X+14.

The following example shows setpoint 4, a BCD long, being forced to 87654321 when C75 is active.

Notice that C75 is used as a set/reset type relay. The force command should be written to the force register once. The OM414 will automatically clear this register when the force is complete. This will normally happen very quickly (less than a second). The fact that the OM414 clears the force control and data registers when the operation is done can be used by the PLC program to verify operation. However, this is generally not necessary.

To force a setpoint that is configured for Binary, only the field point force data cell is used. The field point force data cell 2 is ignored by the panel.

Note: To force setpoints, the Force Enable option must be selected in the OM-WINEDIT software.



Examples of Use with an Allen-Bradley PLC

Interfacing to A-B Memory

OptiMate modules interface to Allen-Bradley SLC 5/03, SLC 5/04 and Micrologix PLCs via integer file type N. The 5/03 and 5/04 have file type N7 as standard. Other "N" type files can be created. The Micrologix has a fixed file type N7. Please refer to Allen-Bradley documentation for information on setting up and using "N" type files.

All of the examples that follow assume that the OM414 module has been configured, through the OptiMate Configuration Editor, for a file number 7 and base register address 0.

Note: To ensure proper communications between an OM414 and an A-B PLC, always verify that at least 15 words of memory have been allocated in the integer file type that your using.


Setpoint & Display Operations

Displaying Numeric Data

Displaying numeric data in one of the 6 field points is a very simple process. During the initial configuration, make sure you define the point as a display point, not a setpoint. When this is done, the PLC program must simply put data to be displayed into the register associated with the display data field.

The figure on the right illustrates a numeric display application with an Allen-Bradley PLC. In this application, the OM414 is configured for a base address of N7:0. Field point 2 is configured for display, BCD long data and 4 digits after the decimal. A value, held in N7:45 and N7:46 will be displayed in field point 2 as long as B3:22/3 is active. The example shows the value transferred from N7:45 and N7:46 to N7:2 and N7:3. It will be displayed as field point 2.

To display a Binary number, simply configure the field point for display, Binary, and the required number of digits after the decimal point. Next, only use 1 move instruction to move the data into the field point data cell since the Binary data type only uses 1 register.




Reading a Setpoint

The OM414 continuously updates the registers of all setpoints with each setpoints current value. To read a setpoint, simply access the register(s) that correspond to each setpoint. The data can be copied to another register for manipulation or it can be accessed in its field point register(s).


The following example uses an OM414 at base address N7:0. Field point 3 has been configured as a setpoint, BCD long and 0 digits after the decimal point. In the example program, field point 3 is a Target value setpoint. The program shown below checks a value, held in N7:51 and N7:52 against the setpoint. If the value exceeds the setpoint, O:0.0 will be turned on.

The greater than comparison of a BCD long number is done by comparing the 4 most significant digits of the setpoint (N7:5) with the 4 most significant digits of the value that the setpoint is to be compared to (N7:52). If the comparison value is greater (N7:52 > N7:5), then the entire 8 digit value is greater. Else if the 4 most significant digits of both values are equal (N7:52 = N7:5) and the 4 least significant digits of the comparison value are greater than the 4 least significant digits of the setpoint (N7:51 > N7:4), then the entire 8 digit number is greater. If none of this is true, then the value in N7:51 and N7:52 is less than the setpoint and O:0.0 will not be energized.

To read a setpoint that has been configured as Binary, simply configure the field point as a setpoint, Binary, and the required number of digits after the decimal point. Next, only 1 comparison statement (GRT, EQU, LES, ...) is needed since the Binary data type only uses 1 register.



Register	MSB	LSB
X	Field Point 1 data cell	
X+1	Field Point 1 data cell 2 (long BCD)	
X+2	Field Point 2 data cell	
X+3	Field Point 2 data cell 2 (long BCD)	
X+4	Field Point 3 data cell	
X+5	Field Point 3 data cell 2 (long BCD)	
X+6	Field Point 4 data cell	
X+7	Field Point 4 data cell 2 (long BCD)	
X+8	Field Point 5 data cell	
X+9	Field Point 5 data cell 2 (long BCD)	
X+10	Field Point 6 data cell	
X+11	Field Point 6 data cell 2 (long BCD)	
X+12	Field Point force data cell	
X+13	Field Point force data cell 2 (long BCD)	
X+14	FSP	FP6FP5FP4FP3FP2FP1



Forcing Setpoints

The OM414 gives you the capability to force a setpoint to a value from the PLC.


To force a setpoint to a value, the value should be placed in register X+12 (and X+13 if BCD long). Next the force setpoint bit FSP and the bit(s) corresponding to the setpoint(s) to force to this value must be set in the force control register (X+14). When the OM414 completes the force operation, it will clear the force control and data registers (X+12, X+13 and X+14).

The following example shows setpoint 4 being forced to 87654321 when B3:4/2 is active.

Notice that B3:4/2 is a latch/unlatch type relay. The force command should be written to the force register once. The OM414 will automatically clear this register when the force is complete. This will normally happen very quickly (less than a second). The fact that the OM414 clears the force control register when the operation is done can be used by the PLC program to verify operation. However, this is generally not necessary.

To force a setpoint that is configured for Binary, only the field point force data cell is used. The field point force data cell 2 is ignored by the panel.

Note: To force setpoints, the Force Enable option must be selected in the OM-WINEDIT software.



Use in a Microprocessor Based System

OptiMate modules can interface a microprocessor based controller over a serial link. For the 400 Series line of OptiMate modules, this link is only RS232.

The microprocessor acts as the master. It can write data to the module or read data from the module.

The OM414 uses the OptiMate Hex protocol for fast and easy communications. The OptiMate Hex protocol is defined on the following page.

Module Address

In a microprocessor based system, each module must have its own unique address. You define this address (between 0 and 30) during configuration. For the OptiMate 400 Series, the module address is normally 0. The module will respond to the host only if it is properly addressed.

Communications Protocol

To use an OptiMate module as a slave device in a microprocessor based system, the module must be configured for the OptiMate Hex protocol. The other options that must be set are module address, baud rate, parity and number of stop bits. If parity is set to even or odd, only one stop bit is allowed. Once selected, it must be downloaded to the module.

Computer Based Operation

The OM414 protocol for computer based operation is the OptiMate Hex protocol.

All of the basic functionality described for PLC operation is also available to computer or microprocessor based applications.

The details of messages involved are covered in the protocol documentation on the following page.

Reading a Setpoint

Under computer based operation, each of the OM414's field points can either be configured for setpoint operation or display. If a field point(s) is/are configured for a setpoint, the value of each field point can be read individually. The "Read Setpoint Data" message (0xA8), detailed on the next page, is transmitted to the panel in hex format. The panel will respond with that particular field points setpoint data in the hex format.

Writing a Display Point

If a field point or multiple field points are configured for data display, the data can be sent to each field point individually using the "Write Display Point" message (0xA9). The message including the data is sent in the hex format.

Forcing a Setpoint

In some instances, it may be necessary to "force" a setpoint to a particular value to override its current value. That can be done by sending the "Force Setpoint" message (0xAA). The message and data should be sent in the hex format.

OM414 OptiMate Hex Protocol

General Format

STX Module function ftn_data checksum
address

Where STX = 0x02
Module address = 0 to 30
Function = 0xA8 ; Read setpoint
= 0xA9 ; Write display point
= 0xAA ; Force setpoint
ftn_data = Data specific to the function
Checksum = 8 bit sum of all characters after address
until checksum

Note : Spaces are shown for readability only. There no spaces between message fields. 0xXX denotes a hex number.

Read Setpoint Data

STX Module 0xA8 setpt_no checksum
address

where setpt_no = number (0-5) of setpoint data to returned. Numbered 0 - 5 from top to bottom, left to right.

Response

STX high_data_MSB high_data_LSB lo_data_MSB lo_data_LSB checksum
if message received and processed OK

where high_data = high word of data format, MSB first
Lo_data = low word of data format, MSB first
> For an integer type data message, the first two bytes (high_data) are not used (send as 0's). The third byte (lo_data_MSB) is the high 8 bits of the 16 bit integer data. The low byte (lo_data_LSB) is the low 8 bits.
> For BCD data type message, the data is sent high_data_MSB through lo_data_LSB with high_data_MSB being the upper 8 bits of the data and lo_data_LSB being the last 8 bits of the data.

or

NAK if any errors in message
Where NAK = 0x15

Write Display Point

STX Module 0xA9 displaypt_no high_data_MSB high_data_LSB lo_data_MSB lo_data_LSB checksum
address

where displaypt_no = 0 - 5 corresponding to field points in module. Points are numbered 0-5 from top to bottom, left to right.

high_data = high word of data format, MSB first
Lo_data = low word of data format, MSB first
> For an integer type data message, the first two bytes (high_data) are not used (send as 0's). The third byte (lo_data_MSB) is the high 8 bits of the 16 bit integer data. The low byte (lo_data_LSB) is the low 8 bits.
> For BCD data type message, the data is sent high_data_MSB through lo_data_LSB with high_data_MSB being the upper 8 bits of the data and lo_data_LSB being the last 8 bits of the data.

Response

ACK if message received and processed OK
Where ACK = 0x06

or

NAK if any errors in message

Force Setpoint

STX Module 0xAA setpt_no high_data_MSB high_data_LSB lo_data_MSB lo_data_LSB checksum
address

where setpt_no = number (0-5) of setpoint data to returned. Numbered 0 - 5 from top to bottom, left to right.

high_data = high word of data format, MSB first
Lo_data = low word of data format, MSB first
> For an integer type data message, the first two bytes (high_data) are not used (send as 0's). The third byte (lo_data_MSB) is the high 8 bits of the 16 bit integer data. The low byte (lo_data_LSB) is the low 8 bits.
> For BCD data type message, the data is sent high_data_MSB through lo_data_LSB with high_data_MSB being the upper 8 bits of the data and lo_data_LSB being the last 8 bits of the data.

Response

ACK if message received and processed OK

or

NAK if any errors in message

Broadcast message (sent to all modules, no response)

STX Broadcast function
address



where Broadcast address = 99
Function = 0 ; Synchronize lamp flash timing

Set Up and Interconnect


Legending the Field Points

Legending the OM414 module is a relatively simple process that basically involves sliding a legend transparency into a pocket in the panel overlay. Use the following procedure.

- Remove the bezel from the module. The bezel snaps to the module box along the top and bottom edges. Pull the bezel out and over the snaps to remove.
- Create legend transparencies. There are a number of available options for doing so. Patterns are provided on the next to last sheet of this document.
 - > Use the built in label making capability of the OM-WINEDIT software to create labels. Either print on the transparency directly or print on paper and photocopy onto the transparency. The figure below is a screen from OM-WINEDIT which illustrates the process.
 - > Use a computer graphics program and a laser printer to create the transparency directly. Alternately print on paper and photocopy to a transparency.



Label Insert



- > Use press on letters onto a transparency sheet.
- > Use a typewriter or lettering machine to letter onto paper, then photocopy.

- Cut along outline. Slide into overlay pocket. The legend slides in from the bottom.
- Re-attach bezel. Push bezel onto box until it snaps together. Ensure that the bezel covers all the housing snaps before installing the panel.


Connection to the System

OptiMate modules are designed for communications connection to system devices. The module can be connected to a computer or PLC over the serial port (RS232).

Connection to a Computer for Configuration

Connection of a 400 Series OptiMate module to a computer for configuration can be accomplished over an RS232 link. RS232 is limited to one OptiMate module to a computer serial port. See the figure below for 400 Series OptiMate Module pinouts.

Refer to manufacturer's documentation for computer serial link connector pinouts.




Configuration cables are available for connection to IBM PC-AT compatible ports.

Run Mode Connection to a Computer or PLC


Connection of a 400 Series OptiMate module to a computer or PLC can be accomplished over an RS232 link. RS232 is limited to one OptiMate module to one computer serial port. Since PLCs are slave devices, the RS232 link for a PLC is limited to one OptiMate module. See the figure below for 400 Series OptiMate Module pinouts.

Refer to manufacturer's documentation for PLC or computer serial link connector pinouts.



Standard cables are available for connection to several different PLCs as well as to IBM PC-AT compatible ports.

The figure below shows the RJ12 connector pinout for connection to an OptiMate 400 series module.



Power

The OM414 Setpoint/Display Panel will operate only on a DC voltage of 5VDC. Steady state current is listed on the specification page.

The OM414 panel can draw power from its communications cable making a single 6 wire phone type cable the only cable necessary for installation. PLC Direct DL105, DL205, DL350, or DL405 CPUs are the only PLC CPUs that can connect to the OM414 in this manner. Microprocessor based devices can also be used in this way if they have a 5VDC connection in their comm ports.

The OM414 panel can be powered from a 5VDC adapter for panel configuration or connection to PLCs or microprocessor based devices that do not have a 5VDC connection in their communication ports. Examples are the PLC Direct DL340 and the Allen-Bradley 5/03, 5/04 and Micrologix CPUs. A description of the DC power connector is listed on the specification page.

Note: Only use an Optimization approved 5VDC power supply or equivalent that contains a center negative DC power jack.

There is a very brief (0.1 - 1 millisecond) power on surge up to 0.35 amps. This is typical of nearly any type of electronic equipment and is due to the initial charging of power capacitors. This surge is not normally a problem for a commercial power supply.

Configuration

Configuration of the OM414 Setpoint/Display Panel is performed via an IBM PC compatible computer. The OM-WINEDIT configuration software allows you to select panel type, panel application and PLC protocol definition.

If the OM414 is to be operated with a PLC, the configuration selection must be made to select the proper PLC protocol information.

Specific configuration of the OM414 begins with defining the block of PLC registers to be used. Next, each of the field points must be configured for setpoint or display. Additional options exist for setpoint range limits and force enable/disable.

Note : When configuring an OM414, always remember to use the programming cable that connects the OM414 to an IBM PC compatible computer's serial communications port. Also, always insert the programming cable into the panel to place it into configuration mode.

When you are finished downloading the configuration, wait at least 5 seconds before removing the programming cable. This will return the panel to PLC run mode.

OM414 Configuration

Panel:

Panel Address: 0

PLC Base Register Address: V2000

Force Option:

Buttons: Close, Labels, Write to Panel

Configure Field Points:

To modify a field point, type the point number in the box below or select the point from the list, then press the "Modify" button.

Configure Field Point#:

Point	Type	Format	Digits	Range
1:	Setpoint	BCD	0	1-1 2345678
2:	Setpoint	BCD	0	0-99999999
3:	Display	BCD	2	
4:	Display	BCD	7	
5:	Setpoint	Binary	0	10- 65535
6:	Setpoint	BCD	4	5000-10000000

Configuration Selections

OptiMate modules can be configured for a specific application by using the OptiMate Configuration Editor (OM-WINEDIT). The Configuration Editor runs on any IBM PC compatible computer. It allows the user to select the exact functionality to meet application requirements.

For the OM414 module, the following are important configuration parameters.

Microprocessor Based Systems

Decision	Selection
Single/Multi Module	Choose Single module even if the system will contain several modules. The Multi module selection applies only to systems using a communications master. In computer based systems, each module is configured independently.
Configuration starting point	First time configuration, start with defaults for module. Subsequent configurations can utilize disk files you create.
PLC Type	Select OptiMate Hex
Address	Each module must have a unique address. Normally 0 for the OM414.
Protocol	Select appropriate baud rate, 8 data bits, #stop bits & parity. Note that if even or odd parity selected, only 1 stop bit is available.
Field Points	Define as setpoints or display points as required. Define number format (binary or BCD) and # digits after decimal. For setpoints, define limits.
Force option	If you intend to force setpoint values, enable the force option.

Single Panel PLC Based Systems


Decision	Selection
Single/ Multi Module	Choose single module configuration
Configuration starting point	First time configuration start with defaults for module. Subsequent configurations can utilize disk files you create
PLC Type	Select appropriate PLC type
Protocol	Select appropriate baud rate, # data bits, # stop bits & parity. Note that if 8 data bits and even or odd parity selected, only 1 stop bit is available
Field Points	Define as setpoints or display points as required. Define number format in PLC (binary or BCD) and # digits after decimal. For setpoints, define limits.
Force option	If you intend to force setpoint values, enable the force option.

Multi Panel PLC Applications (Uses Communications Master)

Not applicable with the 400 Series Modules.

Note: Configuration must be downloaded from an IBM PC compatible computer to each module. This is done over the serial link. Always insert the programming cable into the panel to place it into configuration mode. When you are finished downloading the configuration, wait 5 seconds before removing the programming cable. This will return the panel to PLC run mode. Then insert the proper cable into the panel and the PLC for the panel to operate with the selected host. Communication cables are available from Optimization.


Field Point Label Insert Template



Specifications

Physical


- Recessed Mount Housing: 6.00"L x 3.50"H x 1.25"D
- Cutout size: 3.20"H x 5.10"L
- Panel Fasteners: Four, 6x32 threaded studs, shown at right (on ends, symmetrical about center line)
- Weight : 8 ounces
- Colors : Dark gray housing with dark gray panel. Keypad keys; white with gray letters.
- Numeric LED height : 0.35 inch
- Pushbutton life : 1,000,000 switch cycles




Panel Mounting Dimensions

Electrical

- Power: 5VDC @ 0.85Watts
170 mA @ 5VDC
- Power On Surge (see figure below)
0.35A for 1 millisecond max



- Power connector :
DC power plug, center negative (see figure below)
DC power plug is necessary for panel configuration and for connection to PLCs that do not have a 5VDC connection in their communication ports.



Always use an Optimization approved 5VDC power supply with a center negative plug.

Communications

- RS232
- 4800 to 19200 baud
- Compatible with major PLC protocols
- Microprocessor compatible OptiMate Hex protocol
- 6 pin RJ12 phone jack type connector

Communications Failure Operation

Should the panel (when not selected for configuration) ever fail to communicate successfully for a period of 12 seconds, the LEDs on the panel front will flash rapidly.

Environmental

- Enclosure - NEMA 4 (when properly installed)
- Temperature - 0 to 50 C
- Humidity - 95% Non-condensing