

ioThinX 4510 Series Quick Installation Guide

Edition 1.0, August 2018

Technical Support Contact Information **www.moxa.com/support**

Moxa Americas:

Toll-free: 1-888-669-2872

Tel: 1-714-528-6777

Fax: 1-714-528-6778

Moxa China (Shanghai office):

Toll-free: 800-820-5036

Tel: +86-21-5258-9955

Fax: +86-21-5258-5505

Moxa Europe:

Tel: +49-89-3 70 03 99-0

Fax: +49-89-3 70 03 99-99

Moxa Asia-Pacific:

Tel: +886-2-8919-1230

Fax: +886-2-8919-1231

Moxa India:

Tel: +91-80-4172-9088

Fax: +91-80-4132-1045




© 2018 Moxa Inc. All rights reserved.

P/N: 1802045101010



Introduction

The ioThinX 4510 is an advanced modular remote I/O device with a unique hardware and software design that makes it ideal for a variety of industrial data acquisition applications.




Package Checklist


- 1 ioThinX 4510 product
- Quick installation guide (printed)
- 2 side cover plates

Installation

Connecting System Power

Connect your 12 to 48 VDC power source to the terminal block SP+ and SP- terminals on the ioThinX 4510. The ground connector of the system is on the back of the unit, which will connect to the DIN-rail when the product is attached to it.






Connecting Field Power

The ioThinX 4510 can receive field power through a 12/24 VDC power input. Field power can be used to supply power for some I/O modules, such as digital input and analog output modules.

Front View




Field Power

Connecting the Field Power Ground

Connect the Field Ground pin (\equiv) to the field power ground.

Front View



Protective Ground

Connecting to the Network


Ethernet Communication

The ioThinX 4510 is equipped with dual unmanaged LAN ports (RJ45). Connect a network Ethernet cable to either port to provide an Ethernet connection to the unit.

Serial Communication

The ioThinX 4510 is equipped with a 3-in-1 serial interface, which supports 1 RS-232 port, or 1 RS-422 port, or 2 RS-485 ports. Follow the pin assignment table below to set up serial connection to the unit.

Front View




PIN	RS-232 (P1)	RS-422 (P1)	RS-485 (P1/P2)
1	TXD	TXD+	DATA 1+
2	RXD	TXD-	DATA 1-
3	RTS	RXD+	DATA 2+
4	CTS	RXD-	DATA 2-
5	GND	GND	GND

45M Module Wiring


For detailed 45M module wiring, refer to the ioThinX 4510 User Manual on the official website.

Installing the System on a DIN-Rail

Step 1: Hook the mounting clip of the unit onto the DIN-rail and lower the clip onto the DIN-rail. Reserve at least 5.5 cm of space above the DIN-rail to ensure that there is enough room to install the unit.




Step 2: Push the unit toward the DIN-rail until the mounting clip snaps in place.




Installing a 45M Module on a DIN-Rail

Step 1: Align the 45M module side by side with the head/CPU module, making sure that the upper and lower rails are hooked together.




Step 2: Align the 45M module side by side with the head/CPU module and then push the 45M module until it touches the DIN-rail. Next, apply more force until the module clips to the DIN-rail.




NOTE After the module is firmly attached to the DIN-rail, the module connections to the internal bus will be established.

Removing a 45M Module from a DIN-Rail

Step 1: Use your finger to lift the release tab on the lower part of the module.



Step 2: Push the top of the release tab to latch it, and then pull the module out.



NOTE Electrical connections for internal bus will be disconnected when removing the 45M module.




WARNING

Be sure the power is off before removing modules to avoid unexpected damage.

Installing the Covers on the First and Last Module

Attach the covers to the first and last module to cover the modules' contacts.



NOTICE

Be sure to attach the covers to provide electrostatic discharge protection.

LED Indicators

Name	Indication	LED Qty	Description
SP	System Power	1	On: Power on Off: Power off
FP	Field Power	1	On: Power on Off: Power off
RDY	System (Kernel) Ready	1	Green: System ready Green Slow Blinking: Booting up Red: System error Red Slow Blinking: Loading Factory Default Recovery/Upgrading firmware/Backup mode Red Fast Blinking: Safe mode Off: Power off
LAN	Ethernet Connection	1 for each port	Green: 100Mb connection Amber: 10Mb connection Blinking: Data transmitting Off: Disconnected
Px	Serial Connection	1 for each port	Green: Tx Amber: Rx Non-simultaneous Blinking: Data transmitting Off: Disconnected

System Configuration

1. Configuration via Web Console

Main configuration of the unit is done through the web console.

- Default IP Address: 192.168.127.254
- Subnet Mask: 255.255.255.0

NOTE Be sure to configure the host PC's IP address to use the same subnet as the unit. For example, 192.168.127.253

2. IOxpress Utility

IOxpress is a utility that helps users with mass deployment of, searching for, and locating units on the local network. This utility can be downloaded from Moxa's website.

3. Loading the Factory Default Settings

There are three ways to restore the unit to the factory default settings:

- I. Hold the Reset button inside the front door of the unit for 10 seconds while it is powered on.
- II. In the IOxpress utility's Device Library page, select the unit and choose Load Factory Default.
- III. Go to the System tab on the unit's web console and choose Load Factory Default in the Configuration section.

NOTE Please refer to the user's manual for information on detailed configuration and settings.

How to Download the Software


Related software packages can be downloaded from the Moxa website.

Step 1: Go to the following address to open the Support & Downloads search tool:

http://www.moxa.com/support/support_home.aspx?isSearchShow=1

Step 2: Type the model name in the search box or select a product from the drop-down box and then click Search. The ioLogik E1210 is used for the examples below.


Support & Downloads



The screenshot shows a search interface with a magnifying glass icon on the left. A text input field contains the text "ioLogik E1210". To the right of the input field is a blue button labeled "Search", which is highlighted with a red rectangular border. Below the input field, the word "OR" is displayed in blue. Underneath "OR" is a dropdown menu with the text "select product" and a downward-pointing arrow.

Step 3: Go to the Software page to download the latest software for the product.

ioLogik E1210



The screenshot shows a navigation menu with four main categories: Documentation, Software, FAQs, and Other. Each category has a list of sub-items. The 'Software' category is highlighted with a red rectangular border. The sub-items for 'Software' are: Firmware, Libraries, Software Packages (highlighted in orange), and Utilities.

Documentation <ul style="list-style-type: none">• Datasheets• Manuals	Software <ul style="list-style-type: none">• Firmware• Libraries• Software Packages• Utilities	FAQs <ul style="list-style-type: none">• Security Advisory	Other <ul style="list-style-type: none">• Product Page
--	---	--	--

Specifications

Input Current	800 mA @ 12 VDC
Input Voltage	12 to 48 VDC Field Power: 12/24 VDC
Operating Temperature	Standard Models: -20 to 60°C (-4 to 140°F) Wide Temp. Models: -40 to 75°C (-40 to 167°F)
Storage Temperature	-40 to 85°C (-40 to 185°F)