



- NOTES:
1. PROGRAMMING: DRIVE MACRO = HVAC DEFAULT.
 2. DASH LINES INDICATE CUSTOMER INSTALLED DEVICES AND WIRING
 3. COPPER WIRE RATED FOR 60°C INSULATION IF RATED LESS THAN 100A OR 75°C IF RATED 100A OR MORE MUST BE USED.
 4. REFER TO USER MANUAL FOR OPERATION, CONNECTIONS AND TIGHTENING TORQUE VALUES.
 5. FUSE RATING LABEL IS NEAR DEVICE.
 6. CUSTOMER REQUIRED TO PROVIDE BRANCH CIRCUIT PROTECTION AND DISCONNECT MEANS PER NEC AND LOCAL CODE.
 7. SHORT CIRCUIT CURRENT: 5KA RMS SYMMETRICAL 600V MAXIMUM.
 8. TRANSFORMER IT IS WIRED FOR APPROPRIATE PRIMARY VOLTAGE.

1	A	B	C	D	E	F	G	H	J	K	L	M	N	P	R	S	T	W	X	Y
2																				
3																				
4																				
5																				
6																				
7																				
8																				
9																				
10																				
11																				
12																				
13																				
14																				
15																				
16																				
17																				
18																				
19																				
20																				
21																				
22																				
23																				
24																				
25																				
26																				
27																				
28																				
29																				
30																				
31																				
32																				
33																				
34																				
35																				
36																				
37																				
38																				
39																				
40																				
41																				
42																				
43																				
44																				
45																				
46																				
47																				

Rev	1	06/23/09	DC	ACX550	Power Wiring Diagram	Project Name	ACH550 PACKAGED DRIVE INPUT SWITCH AND FUSES	Approved By	J. Truettner	Responsible	ABBB	ABB Inc.	Date	9/19/2007	Reference number	PD00R734PW-A	Sheet	A
Based On								Checked By	J. Brenner	Prepared By	Sch Gen					Cont.	B	