Specifications / Installation



## **SmartRail**


# 0-10V or 4-20mA Analog Output Modules

### HE599DAC101 (voltage) & HE599DAC106 (current) 12-Bit Resolution

#### **Specifications**

Specifications			
	DAC101	DAC106	
Number of Channels	4		
Output Range(s)	0-10V	0-20mA, 4-20mA	
Absolute Maximum Output	DC ±15V	DC ±25mA	
Resolution	12-Bit (2.5mV)	12-bit (5uA, 4uA)	
Maximum Load	>2kΩ	<510Ω	
Accuracy	< +/-0.5%		
Isolation	500V (backplane)		
Conversion Time	1mS/ch		
Backplane Power Consumed	110mA @ 5V		
External Power Required		120mA @ 24V	
Terminal Type	Screw Type, Removable 11-posn		
Optional Spring-clamp Plug	HE599TRM011		
Storage Temp.	-25° to 70° Celsius		
Operating Temp.	-0° to 55° Celsius		
Relative Humidity	5 to 95% Non-condensing		
Dimensions WxHxD	20mm x 90mm x 60mm		
	0.79" x 3.54" x 2.36"		
Weight	64g (2.3 oz.)	70g (2.5oz.)	
CE & UL Compliance	CE, UL & C-UL		

#### Wiring - I/O



DAC LED Status Indication		
LED	Meaning	
RUN	ON = Normal Operation	
	FLASH = I/O Error	
	OFF = No Power or I/O Error	

#### **Configuration DATA**

The SmartRail Analog Output modules have a variety of parameters configured on a channel-bychannel basis. These parameters are set using Cscape (9.1 or later), and are listed below:

Cscape Configuration Data – Selectable per channel			
Parameter	DAC101	DAC106	
Hold Last State	Hold Last State		
	Go to Minimum		
	Go to Mid-range		
	Go to Maximum		
Analog Output Range	0-10V	4-20mA	
		0-20mA	

#### 3.1 **Output Scaling**

The SmartRail Analog Outputs scale digital values from 0-4000, to the analog value (0-10V, 0-20mA, or 4-20mA). For every digital count the output is incremented, the analog output value will increment an appropriate amount (2.5mV for 0-10V, 5uA for 0-20mA, 4uA for 4-20mA).


#### Installation / safety


Warning: Remove power from the OCS controller and any peripheral equipment connected to this local system before adding or replacing this or any module.

- a. All applicable codes and standards should be followed in the installation of this product.
- b. Shielded, twisted-pair wiring should be used for best performance.c. Shields should be grounded at one end only, preferably at the end providing the best noise shunting
- d. Use the following wire type or equivalent: Belden 8441.

For detailed installation and a <u>handy checklist</u> that covers panel box layout requirements and minimum clearances, refer to the hardware manual of the controller you are using.

When found on the product, the following symbols specify:





### **Technical Support**

Technical Support at the following locations:

North America: Europe:

Tel: 317 916-4274 Tel: +353-21-4321266 Fax: 317 639-4279 Fax: +353-21-4321826

http://www.heapg.com Web: http://www.horner-apg.com Email: techsppt@heapq.com Email: tech.support@horner-apq.com

No part of this publication may be reproduced without the prior agreement and written permission of Horner APG, Inc. Information in this document is subject to change without



#### **Prefer Spring-clamps?**

Optional Spring-clamp style plugs are available as economical wiring accessories. See specification table for part number(s). Representative 10-position plug shown.

1/3/2011 Page 1 of 1