
XL4 OCS

Datasheet for HE-XC1E0, HE-XC1E2, HE-XC1E3, HE-XC1E4, HE-XC1E5 HEXT251C100, HEXT251C112, HEXT251C113, HEXT251C114, HEXT251C115

1 Specifications

General Specifications							Control & Logic Specifications						
Required Power					@ 24 VDC			Co	Control Language Support		Advanced Ladder Logic		
(Steady state)			190 mA @ 12 VDC			Full If			ull IEC 1131-3 Languages				
Required Power		er		2A for <1	ms @ 24 V	DC		Logic Program Size			1MB, maximum		
	(Inrush)			DC	Switched				& Logic \$	Scan Rate 0.013mS/K		S/K	
Primary	Power Ra	inge		10 -	- 30 VDC			Online Programming Changes Supported in A		rted in Adva	nced Ladder		
Relat	ive Humid	ity	5 to 95% Non-condensing				I/O Support		Digital	Inputs	2048		
Clor	k Accurac	v	+/- 20 ppm maximum at 25° C				1				Outputs	2048	
		, 	(+/- 1 Minutes per Month)				Analog		512				
	rating Tem				C to +60°C							Outputs	512
Sto	rage Temp		-30°C to +70°C			Ge	General Purpose Registers 50,000 (words) Retentive			Retentive			
	Weight				z. (340 g)						16,384 (bits) Retentive		
UL/CE						oductCert.htm	-					84 (bits) No	n-retentive
021 02	Europe: h		p://www.horn		n/support/cert	tification.aspx							
Display Specifications							Connectivity						
	splay Type		:	3.5" TFT Tra		Color			ial Ports	1 RS-232 & 1 RS-485 on single Modular Jac			
R	esolution				(320x240)				3 mini-B	USB 2.0 (480MHz) Programming & Data Acces			
	Color				t (65,535)			-	ISB A	USB 2.0 (480MHz) for USB FLASH Drives (2T			()
	en Memor			(64MB				CAN Remote I/O, Peer-to-Peer Comms, Csca			s, Cscape	
	User-Programmable		1023			Et	hernet						
	Screens		LED – 50.000 hour life			Bon	noto I/O	Modbus TCP C/S, HTTP, FTP, SMTP, Cscape SmartRail, SmartStix, SmartBlock, SmartMod					
C	Backlight		Lloor	Configurabl	,	-			Remote I/O SmartRail, SmartStix, SmartBlock, Sn Removable MicroSD, support for >32GB ma				
Screer	n Update R	late					c)			Updates, Datalogging, more			
(perceived as instantaneous in many cases) Memory Application Updates, Datalogging, more Input / Output Specifications													
					mA/V	High-Speed Counters							
Model	DC In	Out	Relays	HS In	HS Out	In	RTE	D/Tc	Out	Number of Counters 2		2	
Model 2	12		6	4		4				Maximum Frequ	uency	>500k	Hz each
Model 3	12	12		4	2	2				Accumulator S	Size	32-bi	ts each
Model 4	24	16		4	2	2				Modes Supported			
Model 5	12	12		4	2			2 2		Totalizer Quadrat			
There are 4 high-speed inputs of the total DC Inputs. There are 2 high-speed outp						Pulse Meas. Frequency Meas.							
	DC outputs. Model 2, 3 & 4 feature 12-bit Analog I/O. Model 5 features 14/16-bit												
High-spe	High-speed Outputs can be used for PWM and Pulse Train Outputs, currently limited to				<65kHz.	1 ON/C	OFF Setp	oint per Out	put				


2 Dimensions & Panel Cutout




3 Installation Procedures

- Carefully locate an appropriate place to mount the XL4. Be sure to leave enough room at the top of the unit for insertion and removal of the microSD card. Also leave enough room at the bottom for the insertion and removal of USB FLASH drives
- 2. Carefully cut the host panel per the diagram on Page 1, creating a 92mm x 92mm ±0.1mm opening into which the XL4 may be installed. If the opening is too large, water may leak into the enclosure, potentially damaging the XL4. If the opening is too small, the OCS may not fit through the hole without damage.
- 3. Remove all Removable Terminals from the XL4. Insert the XL4 through the panel cutout (from the front). The gasket needs to be between the host panel and the XL4.
- 4. Install and tighten the four mounting clips (provided in the box) until the gasket forms a tight seal (max torque 1.5Nm / 13.2Lb-in).
- 5. Reinstall the XL4 I/O Removable Terminal Blocks. Connect communications cables to the serial port, USB ports, Ethernet port, and CAN port as required.

4 Ports and Connectors





5 Safety

WARNING: Only qualified electrical personnel familiar with the construction and operation of this equipment and the hazards involved should install, adjust, operate, or service this equipment. Read and understand this manual and other applicable manuals in their entirety before proceeding. Failure to observe this precaution could result in severe bodily injury or loss of life.

WARNING: To avoid the risk of electric shock or burns, always connect the earth ground before making any other connections.

WARNING: To reduce the risk of fire, electrical shock, or physical injury it is strongly recommended to fuse all Power Sources connected to the OCS. Be sure to locate fuses as close to the source as possible.

WARNING: Replace fuse with the same type and rating to provide protection against risk of fire and shock hazards.

WARNING: In the event of repeated failure, do not replace the fuse again as a repeated failure indicates a defective condition that will not clear by replacing the fuse.

WARNING: Battery may explode if Mistreated. Do Not Recharge, Disassemble or Dispose Of in Fire.

WARNING: EXPLOSION HAZARD – BATTERIES MUST ONLY BE CHANGED IN AN AREA KNOWN TO BE NON-HAZARDOUS

6 Technical Support

For assistance and manual updates, contact Technical Support at the following locations:

North America

(317) 916-4274 877-665-5666 <u>http://www.heapg.com</u> e-mail: techsppt@heapg.com

Europe (+) 353-21-4321-266 http://www.horner-apg.com e-mail: techsupport@hornerirl.ie

7 Built-in I/O (Model 2, 3, 4 & 5)

All XL4 models (except the HE-XCE0) feature built-in I/O. The I/O is mapped into OCS Register space, in three separate areas – Digital/Analog I/O, High-Speed Counter I/O, and High-speed Output I/O. Digital/Analog I/O location is fixed starting at 1, but the High-speed Counter and High-speed Output references may be mapped to any open register location. For more details on using the High-Speed Counter and High-Speed Outputs, see the **XL4 OCS User's Manual** (MAN0964).


Fixed	Digital/Analog	XL4 Model				
Address	I/O Function	2	3	4	5	
	Digital Inputs	1-12	1-12	1-24	1-12	
%I1	Reserved	13-32	13-31	25-31	13-31	
	ESCP Alarm	n/a	32	32	32	
%Q1	Digital Outputs	1-6	1-12	1-16	1-12	
70021	Reserved	7-24	13-24	17-24	13-24	
%AI1	Analog Inputs	1-4	1-2	1-2	1-2	
%ATT	Reserved	5-12	3-12	3-12	3-12	
%AQ1	Reserved	n/a	1-8	1-8	1-8	
%AQ1	Analog Outputs	n/a	n/a	n/a	9-10	
Reserved areas maintain backward compatibility with other XL Series OCS models						

Default Address*	High-Speed Counter Function	XL4 Models 2-5		
%I1601	Status Bits	1-8		
%Q1601	Command Bits	1-32		
%AI0401	Accumulator 1 & 2	1-8		
%AQ0401	Preload & Match Values	1-12		
*Starting Address locations for %I, %Q, %AI & %AQ may				
be re-mapped by user				

Default Address*	High-Speed Output Function	XL4 Models 2-5		
%I1617	%I1617 Status Bits			
%Q1**	Command Bits	1-2		
n/a	n/a	n/a		
%AQ421	PWM or Pulse-Train Parameters	1-20		
*Starting Address locations for %I & %AQ may be remapped by user				
**Q1-Q2 are part of the Fixed I/O Map. In High-Speed Output mode they can be used to initiate a Stepper/PTO Move				

Model 2 I/O

The XL4 model 2 (HE-XC1E2) features 12 DC Inputs, 6 Relay outputs, and 4 Analog Inputs. The DC Inputs are 12/24Vdc compatible, and can be jumpered for Positive Logic (sinking), or Negative Logic (sourcing). Four of the inputs (H1-H4) can be used for high-speed functions up to 500kHz. The 12-bit Analog Inputs can be jumpered for voltage (0-10V) or current (4-20mA) on a channel by channel basis. The Relay outputs are isolated, supporting AC and DC voltages, with output currents of up to 3A/relay, 5A total.




Model 3 & Model 4 I/O

The XL4 model 3 (HE-XC1E3) features 12 DC Inputs, 12 DC outputs, and 2 Analog Inputs. The XL4 model 4 (HE-XC1E4) increases the I/O count up to 24 DC Inputs, and 16 DC Outputs and 2 Analog Inputs. The DC Inputs are 12/24Vdc compatible, and can be jumpered for Positive Logic (sinking), or Negative Logic (sourcing). Four of the inputs (H1-H4) can be used for high-speed functions up to 500kHz. The 12-bit Analog Inputs can be jumpered for voltage (0-10V) or current (4-20mA) on a channel by channel basis. The 12/24VDC Outputs feature Electronic Short Circuit protection, and support currents up to 0.5A per point, and 4A total. Two of the DC Outputs can be used for high speed functions (PWM or PTO). The output frequency is limited by the switching capability of the output drivers (about 10kHz), although an optional accessory (HE-XHSQ) can be added to provide parallel output drivers supporting frequencies up to 200kHz.


J1	Model 3 & 4	
(Orange)	Signal Name	
l1	IN1	
12	IN2	
13	IN3	
14	IN4	
15	IN5	
16	IN6	
17	IN7	
18	IN8	
H1	HSC1 / IN9	
H2	HSC2 / IN10	
H3	HSC3 / IN11	
H4	HSC4 / IN12	
A1	Analog IN1	
A2	Analog IN2	
0V	Common	

J1 Orange Positive Logic Digital & Analog In					
•		11	\triangleleft		
+		12			
+		13			
+		14			
)12-24VDC		15			
		16			
		17			
-		18			
		H1			
-		H2			
		H3			
		H4			
20mA	·+	A1			
	O+	A2			
	0-10VDC	0V			



Jumper Setting Details

J1



Model 4

Name

OUT16

OUT15

OUT14

Positive Logic Digital Out				
	0V			
10 - 30VDC	V+			
+	Q13			
- +	Q12			
LOAD +	Q11			
LOAD +	Q10			
- +	Q9			
- +	Q8			
LOAD +	Q7			
LOAD +	Q6			
- +	Q5			
LOAD +	Q4			
LOAD +	Q3			
- +	Q2			
LOAD +	Q1			
00)1XLE024			

J2 Black

001XI E046

J4 Orange **Positive Logic** Digital Out

	J2
	0V
10-30YDC	V+
	J4
LOAD	Q16
- +	Q15
LOAD +	Q14

JP1 Digital DC Inputs Positive Logic Negative Logic 14 (🛛 🗖 JP1 Default .12 JP3 Analog Inputs JP3 10VDC 20mA A1 1 2 A1 0 0 2 J3 A2 3 A2 З Location of I/O jumpers 001XLE043-R (JP1 & JP3) and Note: The Cscape Module Setup configuration wiring connectors (J1, J2, J3 & J4) with back must match the selected I/O (JP) jumper settings. cover removed. Note: When using JP3 (A1-A2), each channel can be independently configured.

> Note: Model 3 uses J1 & and J2 only.

Model 4 uses J1, J2, J3 & J4.

J4

(Orange)

Q16


Q15

Q14

Model 5 I/O

The XL4 model 5 (HE-XC1E5) features 12 DC Inputs, 12 DC outputs, with high performance, highly configurable Analog Inputs (2) and Analog Outputs (2). , The DC Inputs are 12/24Vdc compatible, and can be jumpered for Positive Logic (sinking), or Negative Logic (sourcing). Four of the inputs (H1-H4) can be used for high-speed functions up to 500kHz. The 12/24VDC Outputs feature Electronic Short Circuit protection, and support currents up to 0.5A per point, and 4A total. Two of the DC Outputs can be used for high speed functions (PWM or PTO). The output frequency is limited by the switching capability of the output drivers (about 10kHz), although an optional accessory (HE-XHSQ) can be added to provide parallel output drivers supporting frequencies up to 200kHz.

The two high resolution Analog Inputs can be configured for 4-20mA, 0-10V, or 0-100mV at 14-bit resolution. They also can be configured for 16-bit temperature measurement – supporting Thermocouples or RTDs with 0.05°C resolution. The Analog Outputs are sourcing, and can be configured for 4-20mA or 0-10V at 14-bit resolution. Each Analog Input or Output channel can be configured independently for maximum flexibility.



wiring connectors (J1-J4) with back cover removed.

Default