

**PNOZ 10** 




Safety relays

This document is the original document.

All rights to this documentation are reserved by Pilz GmbH & Co. KG. Copies may be made for the user's internal purposes. Suggestions and comments for improving this documentation will be gratefully received.

Source code from third-party manufacturers or open source software has been used for some components. The relevant licence information is available on the Internet on the Pilz homepage.

Pilz®, PIT®, PMI®, PNOZ®, Primo®, PSEN®, PSS®, PVIS®, SafetyBUS p®, SafetyEYE®, SafetyNET p®, the spirit of safety® are registered and protected trademarks of Pilz GmbH & Co. KG in some countries.



Introduction	4
Validity of documentation	4
Using the documentation	4
Definition of symbols	
•	
Safety	5
Intended use	
Safety regulations	
Safety assessment	
Use of qualified personnel	
Warranty and liability	
Disposal	
For your safety	
, or your outer,	
Unit features	7
One routures	
Safety features	7
Outoty leatures	
Block diagram/terminal configuration	7
Types: AC	
Type: DC	
туре. БО	0
Function Description	8
Operating modes	
Timing diagram	
Tilling diagram	9
Installation	۵
installation	
Wiring	10
vviiiig	
Preparing for operation	11
r repairing for operation	· · · · · · · · · · · · · · · · · · ·
Operation	13
Status indicators	
Faults - Interference	14
i dulto – interiorence	
Dimensions in mm	14
Technical details	15
Safety characteristic data	
Outoty offuracionatio data	20
Supplementary data	24
Service life graph	
Oct vice ine graph	Δ1
Order reference	27
Order reference	
EC declaration of conformity	28
Ly application of community	

## Introduction

### Validity of documentation

This documentation is valid for the product PNOZ 10. It is valid until new documentation is published.

This operating manual explains the function and operation, describes the installation and provides guidelines on how to connect the product.

### Using the documentation

This document is intended for instruction. Only install and commission the product if you have read and understood this document. The document should be retained for future reference.

## **Definition of symbols**

Information that is particularly important is identified as follows:



#### **DANGER!**

This warning must be heeded! It warns of a hazardous situation that poses an immediate threat of serious injury and death and indicates preventive measures that can be taken.



#### **WARNING!**

This warning must be heeded! It warns of a hazardous situation that could lead to serious injury and death and indicates preventive measures that can be taken.



### **CAUTION!**

This refers to a hazard that can lead to a less serious or minor injury plus material damage, and also provides information on preventive measures that can be taken.



#### **NOTICE**

This describes a situation in which the product or devices could be damaged and also provides information on preventive measures that can be taken. It also highlights areas within the text that are of particular importance.



#### **INFORMATION**

This gives advice on applications and provides information on special fea-

# Safety

#### Intended use

The safety relay PNOZ 10 provides a safety-related interruption of a safety circuit.

The safety relay meets the requirements of EN 60947-5-1 and EN 60204-1 and may be used in applications with:

- ▶ E-STOP pushbuttons
- Safety gates

The following is deemed improper use in particular

- Any component, technical or electrical modification to the product,
- ▶ Use of the product outside the areas described in this manual,
- ▶ Use of the product outside the technical details (see Technical details [ 15]).



#### **NOTICE**

### **EMC-compliant electrical installation**

The product is designed for use in an industrial environment. The product may cause interference if installed in other environments. If installed in other environments, measures should be taken to comply with the applicable standards and directives for the respective installation site with regard to interference.

# Safety regulations

## Safety assessment

Before using a device, a safety assessment in accordance with the Machinery Directive is required.

The product as an individual component fulfils the functional safety requirements in accordance with EN ISO 13849 and EN 62061. However, this does not guarantee the functional safety of the overall plant/machine. To achieve the relevant safety level of the overall plant/machine's required safety functions, each safety function needs to be considered separately.

### Use of qualified personnel

The products may only be assembled, installed, programmed, commissioned, operated, maintained and decommissioned by persons who are competent to do so.

A competent person is a qualified and knowledgeable person who, because of their training, experience and current professional activity, has the specialist knowledge required. To be able to inspect, assess and operate devices, systems and machines, the person has to be informed of the state of the art and the applicable national, European and international laws, directives and standards.

It is the company's responsibility only to employ personnel who

- Are familiar with the basic regulations concerning health and safety / accident prevention,
- Have read and understood the information provided in the section entitled Safety
- ▶ Have a good knowledge of the generic and specialist standards applicable to the specific application.

#### Warranty and liability

All claims to warranty and liability will be rendered invalid if

- ▶ The product was used contrary to the purpose for which it is intended,
- ▶ Damage can be attributed to not having followed the guidelines in the manual,
- Operating personnel are not suitably qualified,
- ▶ Any type of modification has been made (e.g. exchanging components on the PCB boards, soldering work etc.).

#### **Disposal**

- ▶ In safety-related applications, please comply with the mission time T<sub>M</sub> in the safety-related characteristic data.
- ▶ When decommissioning, please comply with local regulations regarding the disposal of electronic devices (e.g. Electrical and Electronic Equipment Act).

#### For your safety

The unit meets all the necessary conditions for safe operation. However, please note the following:

Note for overvoltage category III: If voltages higher than low voltage (>50 VAC or >120 VDC) are present on the unit, connected control elements and sensors must have a rated insulation voltage of at least 250 V.

## **Unit features**

- ▶ Positive-guided relay outputs:
  - 6 safety contacts (N/O), instantaneous
  - 4 auxiliary contacts (N/C), instantaneous
- ▶ Connection options for:
  - E-STOP pushbutton
  - Safety gate limit switch
  - Start button
- LED display for:
  - Supply voltage
  - Switch status of the safety contacts
- ▶ See order reference for unit types

# Safety features

The safety relay meets the following safety requirements:


- ▶ The circuit is redundant with built-in self-monitoring.
- ▶ The safety function remains effective in the case of a component failure.
- ▶ The correct opening and closing of the safety function relays is tested automatically in each on-off cycle.

# Block diagram/terminal configuration

Types: AC

U<sub>B</sub>: 24 VAC; Order no. 774000
 U<sub>B</sub>: 48 VAC; Order no. 774002


U<sub>B</sub>: 110 - 120 VAC; Order no. 774003
 U<sub>B</sub>: 230 - 240 VAC; Order no. 774006



<sup>\*</sup>Insulation between the non-marked area and the relay contacts: Basic insulation (over-voltage category III), Protective separation (overvoltage category II)

Type: DC

▶ U<sub>B</sub>: 24 VDC; Order no. 774009



<sup>\*</sup>Insulation between the non-marked area and the relay contacts: Basic insulation (over-voltage category III), Protective separation (overvoltage category II)

# **Function Description**

The safety relay PNOZ 10 provides a safety-oriented interruption of a safety circuit. When supply voltage is supplied the "POWER" LED is lit. The unit is ready for operation when the feedback loop Y1-Y2 and the start circuit S12-S34 are closed.


- ▶ Input circuit is closed (e.g. E-STOP pushbutton not operated):
  - The LEDs "CH.1" and "CH.2" are lit.
  - Safety contacts 13-14, 23-24, 33-34, 43-44, 53-54 and 63-64 are closed, auxiliary contacts 71-72, 81-82, 91-92 and 01-02 are opened. The unit is active.
- ▶ Input circuit is opened (e.g. E-STOP pushbutton operated):
  - The LEDs "CH.1" and "CH.2" go out.
  - Safety contacts 13-14, 23-24, 33-34, 43-44, 53-54 and 63-64 are opened redundantly, auxiliary contacts 71-72, 81-82, 91-92 and 01-02 are closed.

### **Operating modes**

- Single-channel operation: No redundancy in the input circuit, earth faults in the start and input circuit are detected.
- Dual-channel operation with detection of shorts across contacts: Redundant input circuit, PNOZ 10 detects
  - earth faults in the start and input circuit,
  - short circuits in the input circuit,
  - shorts across contacts in the input circuit.
- Dual-channel operation without detection of shorts across contacts: Redundant input circuit, detects PNOZ 10
  - earth faults in the start and input circuit,
  - short circuits in the input circuit.
- Automatic start: Unit is active once the input circuit has been closed.
- Manual start: Unit is active once the input circuit and the start circuit are closed.

Increase in the number of available contacts by connecting contact expandsion modules or external contactors/relays.

## **Timing diagram**



### Legend

▶ Power: Supply voltage

Start: Start circuitInput: Input circuit

Output safe: Safety contactsOutput aux: Auxiliary contacts

[1]: Automatic start[2]: Manual start

a: Input circuit closes before start circuit

b: Start circuit closes before input circuit

▶ t₁: Switch-on delay

▶ t₂: Delay-on de-energisation

▶ t<sub>3</sub>: Recovery time

### Installation

- ▶ The unit should be installed in a control cabinet with a protection type of at least IP54.
- ▶ Use the notch on the rear of the unit to attach it to a DIN rail (35 mm).
- ▶ When installed vertically: Secure the unit by using a fixing element (e.g. retaining bracket or end angle).

## Wiring

Please note:

- ▶ Information given in the "Technical details [ 15] must be followed.
- ▶ Outputs 13-14, 23-24, 33-34, 43-44, 53-54, 63-64 are safety contacts; outputs 71-72, 81-82, 91-92, 01-02 are auxiliary contacts (e.g. for display).
- Do not use auxiliary contacts 71-72, 81-82, 91-92, 01-02 for safety circuits!
- Do not connect undesignated terminals.
- ▶ To prevent contact welding, a fuse should be connected before the output contacts (see Technical details [☐ 15]).
- ▶ Calculation of the max. cable length I<sub>max</sub> in the input circuit:

$$I_{max} = \frac{R_{lmax}}{R_{l} / km}$$

 $R_{lmax}$  = max. overall cable resistance (see Technical details [ 15])  $R_{l}$  / km = cable resistance/km

- ▶ Use copper wiring with a temperature stability of 60/75 °C.
- ▶ To prevent EMC interferences (particularly common-mode interferences) the measures described in EN 60204-1 must be executed. This includes the separate routing of cables of the control circuits (input, start and feedback loop) from other cables for energy transmission or the shielding of cables, for example.
- Do not switch low currents using contacts that have been used previously with high currents
- Adequate protection must be provided on all output contacts with capacitive and inductive loads.
- ▶ On 24 VDC devices:


The power supply must comply with the regulations for extra low voltages with protective electrical separation (SELV, PELV) in accordance with VDE 0100, Part 410.

#### Important for detection of shorts across contacts:

As this function for detecting shorts across contacts is not failsafe, it is tested by Pilz during the final control check. If there is a danger of exceeding the cable runs, we recommend the following test after the installation of the device:

- 1. Unit ready for operation (output contacts closed)
- 2. Short circuit the test terminals S12, S22 for detecting shorts across the inputs.
- 3. The unit's fuse must be triggered and the output contacts must open. Cable lengths in the scale of the maximum length can delay the fuse triggering for up to 2 minutes.
- 4. Reset the fuse: remove the short circuit and switch off the supply voltage for approx. 1 minute.

# **Preparing for operation**



Input circuit	Single-channel	Dual-channel
E-STOP without detection of shorts across contacts	S12 \$ S1 7 \$ S12 \$ S12 \$ S12 \$ S12 \$ S12 \$ S12 \$ S22 \$ S22 \$ S12 \$ S22 \$	S11 0 S1 74 S11 0 S21 S22 S12 O S1
E-STOP with detection of shorts across contacts		S11 ¢
Safety gate without detection of shorts across contacts	S12 \$ S1 \$ S1 \$ S22 \$ S2	S11 0 S1 S2 S22 S12 O Y3 0
Safety gate with detection of shorts across contacts		S11 \$\frac{1}{\sqrt{S1}}\$ \$\frac{1}{\sqrt{S2}}\$ \$\frac{1}{S2



# **NOTICE**

With single-channel wiring the safety level of your machine/plant may be lower than the safety level of the unit (see Safety characteristic data [ 26]).

Start circuit	E-STOP/safety gate wiring (single-channel and dual-channel without detection of shorts across contacts)	E-STOP/safety gate wiring (dual-channel with detection of shorts across contacts)
Automatic start	S33 \$\displays \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\	S12 0
Manual start	S33 \$ S34 \$	S12 0 S34



### **NOTICE**

In the event of an automatic start or manual start with bridged start contact (fault):

The unit starts up automatically when the safeguard is reset, e.g. when the E-STOP pushbutton is released. Use external circuit measures to prevent an unexpected restart.

Feedback loop	Without feedback loop monitoring	With feedback loop monitoring
Link or contacts from external contactors	Y1 \$\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\	Y1

# Legend

▶ S1/S2: E-STOP/safety gate switch

▶ S3: Reset button

▶ 1: Switch operated

▶ **1**: Gate open

▶ **1**: Gate closed

# Operation

When the relay outputs are switched on, the mechanical contact on the relay cannot be tested automatically. Depending on the operational environment, measures to detect the non-opening of switching elements may be required under some circumstances.

When the product is used in accordance with the European Machinery Directive, a check must be carried out to ensure that the safety contacts on the relay outputs open correctly. Open the safety contacts (switch off output) and start the device again, so that the internal diagnostics can check that the safety contacts open correctly

- ▶ for SIL CL 3/PL e at least 1x per month
- ▶ for SIL CL 2/PL d at least 1x per year



#### **NOTICE**

The safety function should be checked after initial commissioning and each time the plant/machine is changed. The safety functions may only be checked by qualified personnel.

#### **Status indicators**

LEDs indicate the status and errors during operation:



POWER

Supply voltage is present.

CH.1
Safety contacts of channel 1 are closed.


CH.2
Safety contacts of channel 2 are closed.

## Faults - Interference

- ▶ Earth fault: The supply voltage fails and the safety contacts open. Once the cause of the respective fault has been rectified and the supply voltage is switched off for approx.

  1 minute, the unit is ready for operation again.
- ▶ Contact malfunctions: If the contacts have welded, reactivation will not be possible after the input circuit has opened.
- ▶ LED "POWER" does not light: Short circuit or no supply voltage.

## Dimensions in mm



# **Technical details**

# Order no. 774000 - 774003

See below for more order numbers

General	774000	774002	774003
Certifications	CCC, CE, EAC (Euras- ian), TÜV, cULus Listed	CCC, CE, EAC (Euras- ian), TÜV, cULus Listed	CCC, CE, EAC (Euras- ian), TÜV, cULus Listed
Electrical data	774000	774002	774003
Supply voltage			
Voltage	24 V	48 V	110 - 120 V
Kind	AC	AC	AC
Voltage tolerance	-15 %/+10 %	-15 %/+10 %	-15 %/+10 %
Output of external			
power supply (AC)	10 VA	10 VA	10 VA
Frequency range AC	50 - 60 Hz	50 - 60 Hz	50 - 60 Hz
Duty cycle	100 %	100 %	100 %
Inputs	774000	774002	774003
Number	2	2	2
Voltage at			
Input circuit DC	24 V	24 V	24 V
Start circuit DC	24 V	24 V	24 V
Feedback loop DC	24 V	24 V	24 V
Current at			
Input circuit DC	50 mA	50 mA	50 mA
Start circuit DC	100 mA	100 mA	100 mA
Feedback loop DC	100 mA	100 mA	100 mA
Max. overall cable resist- ance Rlmax			
Single-channel at UB AC	45 Ohm	45 Ohm	45 Ohm
Dual-channel without detection of shorts			
across contacts at UB AC	90 Ohm	90 Ohm	90 Ohm
Dual-channel with de- tection of shorts across			
contacts at UB AC	15 Ohm	15 Ohm	15 Ohm
Relay outputs	774000	774002	774003
Number of output contacts			
Safety contacts (N/O), instantaneous	6	6	6
Auxiliary contacts (N/C)	4	4	4
Max. short circuit current			
IK	1 kA	1 kA	1 kA

Relay outputs	774000	774002	774003
Utilisation category			
In accordance with the			
standard	EN 60947-4-1	EN 60947-4-1	EN 60947-4-1
Utilisation category of safety contacts			
AC1 at	400 V	400 V	400 V
Min. current	0,01 A	0,01 A	0,01 A
Max. current	5 A	5 A	5 A
Max. power	2000 VA	2000 VA	2000 VA
AC1 at	240 V	240 V	240 V
Min. current	0,01 A	0,01 A	0,01 A
Max. current	8 A	8 A	8 A
Max. power	2000 VA	2000 VA	2000 VA
DC1 at	24 V	24 V	24 V
Min. current	0,01 A	0,01 A	0,01 A
Max. current	8 A	8 A	8 A
Max. power	200 W	200 W	200 W
Utilisation category of auxiliary contacts			
AC1 at	240 V	240 V	240 V
Min. current	0,01 A	0,01 A	0,01 A
Max. current	8 A	8 A	8 A
Max. power	2000 VA	2000 VA	2000 VA
DC1 at	24 V	24 V	24 V
Min. current	0,01 A	0,01 A	0,01 A
Max. current	8 A	8 A	8 A
Max. power	200 W	200 W	200 W
Utilisation category			
In accordance with the standard	EN 60947-5-1	EN 60947-5-1	EN 60947-5-1
Utilisation category of safety contacts			
AC15 at	230 V	230 V	230 V
Max. current	5 A	5 A	5 A
DC13 (6 cycles/min) at	24 V	24 V	24 V
Max. current	7 A	7 A	7 A
Utilisation category of auxiliary contacts			
AC15 at	230 V	230 V	230 V
Max. current	5 A	5 A	5 A
DC13 (6 cycles/min) at		24 V	24 V
Max. current	7 A	7 A	7 A

Relay outputs	774000	774002	774003
Utilisation category in accordance with UL			
Voltage	240 V AC G.U. (same polarity)	- 240 V AC G.U. (same po- larity)	· 240 V AC G.U. (same polarity)
With current	8 A	8 A	8 A
Voltage	24 V DC Resistive	24 V DC Resistive	24 V DC Resistive
With current	5 A	5 A	5 A
Pilot Duty	B300, R300	B300, R300	B300, R300
External contact fuse protection, safety contacts			
In accordance with the standard	EN 60947-5-1	EN 60947-5-1	EN 60947-5-1
Max. melting integral	240 A <sup>2</sup> s	240 A <sup>2</sup> s	240 A <sup>2</sup> s
Blow-out fuse, quick	10 A	10 A	10 A
Blow-out fuse, slow	6 A	6 A	6 A
Blow-out fuse, gG	10 A	10 A	10 A
Circuit breaker 24V AC/DC, characteristic			
B/C	6 A	6 A	6 A
External contact fuse protection, auxiliary contacts			
Max. melting integral	240 A <sup>2</sup> s	240 A <sup>2</sup> s	240 A <sup>2</sup> s
Blow-out fuse, quick	10 A	10 A	10 A
Blow-out fuse, slow	6 A	6 A	6 A
Blow-out fuse, gG	10 A	10 A	10 A
Circuit breaker 24 V AC/DC, characteristic			
B/C	6 A	6 A	6 A
Contact material	AgSnO2 + 0,2 µm Au	AgSnO2 + 0,2 μm Au	AgSnO2 + 0,2 μm Au
Conventional thermal	774000	774002	774003
current while loading			
several contacts			
Ith per contact at UB AC; AC1: 240 V, DC1: 24 V			
Conv. therm. current with 1 contact	8 A	8 A	8 A
Conv. therm. current with 2 contacts	7 A	7 A	7 A
Conv. therm. current with 3 contacts	5,6 A	5,6 A	5,6 A
Conv. therm. current with 4 contacts	4,9 A	4,9 A	4,9 A
Conv. therm. current with 5 contacts	4,4 A	4,4 A	4,4 A
Conv. therm. current with 6 contacts	4 A	4 A	4 A

Times	774000	774002	774003
Switch-on delay			
With automatic start			
typ.	180 ms	180 ms	180 ms
With automatic start			
max.	250 ms	250 ms	250 ms
With automatic start	200 ms	200 ms	200 ms
after power on typ.	200 1115	200 IIIS	200 IIIS
With automatic start after power on max.	300 ms	300 ms	300 ms
With manual start typ.	200 ms	200 ms	200 ms
With manual start max.		250 ms	250 ms
With monitored start	200 1110	200 1110	200 1110
with rising edge typ.	150 ms	150 ms	150 ms
With monitored start			
with rising edge max.	200 ms	200 ms	200 ms
Delay-on de-energisation			
With E-STOP typ.	20 ms	20 ms	20 ms
With E-STOP max.	30 ms	30 ms	30 ms
With power failure typ.	170 ms	170 ms	170 ms
With power failure max	. 250 ms	250 ms	250 ms
Recovery time at max.			
switching frequency 1/s			
After E-STOP	50 ms	50 ms	50 ms
After power failure	300 ms	300 ms	300 ms
Min. start pulse duration			
with a monitored start	<b>50</b>	<b>FO</b>	<b>50</b>
With rising edge	50 ms	50 ms	50 ms
Supply interruption before de-energisation	35 ms	35 ms	35 ms
Simultaneity, channel 1	33 1113	33 1113	33 1119
and 2 max.	150 ms	150 ms	150 ms
Environmental data	774000	774002	774003
Climatic suitability	EN 60068-2-78	EN 60068-2-78	EN 60068-2-78
Ambient temperature			
Temperature range	-10 - 55 °C	-10 - 55 °C	-10 - 55 °C
Storage temperature			
Temperature range	-40 - 85 °C	-40 - 85 °C	-40 - 85 °C
Climatic suitability			
Humidity	93 % r. h. at 40 °C	93 % r. h. at 40 °C	93 % r. h. at 40 °C
Condensation during op-			
eration	Not permitted	Not permitted	Not permitted
EMC	EN 60947-5-1, EN 61000-6-2, EN 61326-3-1	EN 60947-5-1, EN 61000-6-2, EN 61326-3-1	EN 60947-5-1, EN 61000-6-2, EN 61326-3-1

Environmental data	774000	774002	774003
Vibration			
In accordance with the			
standard	EN 60068-2-6	EN 60068-2-6	EN 60068-2-6
Frequency	10 - 55 Hz	10 - 55 Hz	10 - 55 Hz
Amplitude	0,35 mm	0,35 mm	0,35 mm
Airgap creepage			
In accordance with the standard	EN 60947-1	EN 60947-1	EN 60947-1
Overvoltage category	III / II	III / II	III / II
Pollution degree	2	2	2
Rated insulation voltage	400 V	400 V	400 V
Rated impulse withstand voltage	4 kV	4 kV	4 kV
Protection type			
Housing	IP40	IP40	IP40
Terminals	IP20	IP20	IP20
Mounting area (e.g. control cabinet)	IP54	IP54	IP54
Mechanical data	774000	774002	774003
Mounting position	Any	Any	Any
Mechanical life	10,000,000 cycles	10,000,000 cycles	10,000,000 cycles
Material		- 10,000,000 o <b>j</b> 0.00	
Bottom	PPO UL 94 V0	PPO UL 94 V0	PPO UL 94 V0
Front	ABS UL 94 V0	ABS UL 94 V0	ABS UL 94 V0
Тор	PPO UL 94 V0	PPO UL 94 V0	PPO UL 94 V0
Connection type	Screw terminal	Screw terminal	Screw terminal
Mounting type	Fixed	Fixed	Fixed
Conductor cross section with screw terminals			
1 core flexible	0 2 - 4 mm <sup>2</sup> 24 - 10 ΔWG	. 0 2 - 4 mm <sup>2</sup> 24 - 10 ΔWG	0,2 - 4 mm², 24 - 10 AWG
2 core with the same cross section, flexible with crimp connectors, no plastic sleeve		0,2 - 2,5 mm², 24 - 14 AWG	0,2 - 2,5 mm <sup>2</sup> , 24 - 14 AWG
2 core with the same cross section, flexible without crimp connect- ors or with TWIN crimp connectors	0,2 - 2,5 mm², 24 - 14 AWG	0,2 - 2,5 mm², 24 - 14 AWG	0,2 - 2,5 mm², 24 - 14 AWG
Torque setting with screw terminals	0,6 Nm	0,6 Nm	0,6 Nm
Stripping length with screw terminals	8 mm	8 mm	8 mm
Dimensions			
Height	87 mm	87 mm	87 mm
Width	90 mm	90 mm	90 mm
Depth	121 mm	121 mm	121 mm
Weight	720 g	720 g	720 g

Where standards are undated, the 2020-07 latest editions shall apply.

Order no. 774006 -774009

General	774006	774009
Certifications	CCC, CE, EAC (Eurasian), TÜV, cULus Listed	CCC, CE, EAC (Eurasian), TÜV, cULus Listed
Electrical data	774006	774009
Supply voltage		
Voltage	230 - 240 V	24 V
Kind	AC	DC
Voltage tolerance	-15 %/+10 %	-15 %/+10 %
Output of external power supply (AC)	10 VA	_
Output of external power supply (DC)	_	5,5 W
Frequency range AC	50 - 60 Hz	_
Residual ripple DC	_	160 %
Duty cycle	100 %	100 %
Inputs	774006	774009
Number	2	2
Voltage at		
Input circuit DC	24 V	24 V
Start circuit DC	24 V	24 V
Feedback loop DC	24 V	24 V
Current at		
Input circuit DC	50 mA	50 mA
Start circuit DC	100 mA	100 mA
Feedback loop DC	100 mA	100 mA
Max. overall cable resistance Rl- max		
Single-channel at UB DC	_	45 Ohm
Single-channel at UB AC	45 Ohm	_
Dual-channel without detection of shorts across contacts at UB DC	_	90 Ohm
Dual-channel without detection of shorts across contacts at UB AC	90 Ohm	_
Dual-channel with detection of shorts across contacts at UB DC	;_	15 Ohm
Dual-channel with detection of shorts across contacts at UB AC	15 Ohm	_
Relay outputs	774006	774009
Number of output contacts		
Safety contacts (N/O), instant-		
aneous	6	6
Auxiliary contacts (N/C)	4	4

Max. short circuit current IK         1 kA         1 kA           Utilisation category         In accordance with the standard EN 60947-4-1         EN 60947-4-1           Utilisation category of safety contacts         EN 60947-4-1           AC1 at         400 V         400 V           Min. current         0,01 A         0,01 A           Max. current         5 A         5 A           Max. power         2000 VA         2000 VA           AC1 at         240 V         240 V           Min. current         0,01 A         0,01 A           Max. current         8 A         8 A           Max. power         2000 VA         2000 VA	
In accordance with the standard         EN 60947-4-1           Utilisation category of safety contacts         400 V           AC1 at         400 V           Min. current         0,01 A           Max. current         5 A           Max. power         2000 VA           AC1 at         240 V           Min. current         0,01 A           Max. current         0,01 A           Max. current         8 A	
Utilisation category of safety contacts         AC1 at       400 V       400 V         Min. current       0,01 A       0,01 A         Max. current       5 A       5 A         Max. power       2000 VA       2000 VA         AC1 at       240 V       240 V         Min. current       0,01 A       0,01 A         Max. current       8 A       8 A	
tacts         AC1 at       400 V       400 V         Min. current       0,01 A       0,01 A         Max. current       5 A       5 A         Max. power       2000 VA       2000 VA         AC1 at       240 V       240 V         Min. current       0,01 A       0,01 A         Max. current       8 A       8 A	
AC1 at       400 V       400 V         Min. current       0,01 A       0,01 A         Max. current       5 A       5 A         Max. power       2000 VA       2000 VA         AC1 at       240 V       240 V         Min. current       0,01 A       0,01 A         Max. current       8 A       8 A	
Min. current       0,01 A       0,01 A         Max. current       5 A       5 A         Max. power       2000 VA       2000 VA         AC1 at       240 V       240 V         Min. current       0,01 A       0,01 A         Max. current       8 A       8 A	
Max. current       5 A       5 A         Max. power       2000 VA       2000 VA         AC1 at       240 V       240 V         Min. current       0,01 A       0,01 A         Max. current       8 A       8 A	
Max. power       2000 VA         AC1 at       240 V         Min. current       0,01 A         Max. current       8 A	
AC1 at 240 V 240 V Min. current 0,01 A 0,01 A Max. current 8 A 8 A	
Min. current         0,01 A         0,01 A           Max. current         8 A         8 A	
Max. current 8 A 8 A	
Max. power 2000 VA 2000 VA	
DC1 at <b>24 V 24 V</b>	
Min. current 0,01 A 0,01 A	
Max. current 8 A 8 A	
Max. power 200 W 200 W	
Utilisation category of auxiliary con-	
tacts	
AC1 at <b>240 V 240 V</b>	
Min. current 0,01 A 0,01 A	
Max. current 8 A 8 A	
Max. power 2000 VA 2000 VA	
DC1 at <b>24 V 24 V</b>	
Min. current 0,01 A 0,01 A	
Max. current 8 A 8 A	
Max. power 200 W 200 W	
Utilisation category	
In accordance with the standard EN 60947-5-1 EN 60947-5-1	
Utilisation category of safety con-	
tacts	
AC15 at 230 V 230 V	
Max. current 5 A 5 A	
DC13 (6 cycles/min) at <b>24 V 24 V</b>	
Max. current 7 A 7 A	
Utilisation category of auxiliary contacts	
AC15 at <b>230 V 230 V</b>	
Max. current 5 A 5 A	
DC13 (6 cycles/min) at <b>24 V 24 V</b>	
Max. current 7 A 7 A	

Relay outputs	774006	774009
Utilisation category in accordance with UL		
Voltage	240 V AC G.U. (same polarity)	240 V AC G.U. (same polarity)
With current	8 A	8 A
Voltage	24 V DC Resistive	24 V DC Resistive
With current	5 A	5 A
Pilot Duty	B300, R300	B300, R300
External contact fuse protection, safety contacts		
In accordance with the standard	EN 60947-5-1	EN 60947-5-1
Max. melting integral	240 A <sup>2</sup> s	240 A <sup>2</sup> s
Blow-out fuse, quick	10 A	10 A
Blow-out fuse, slow	6 A	6 A
Blow-out fuse, gG	10 A	10 A
Circuit breaker 24V AC/DC, characteristic B/C	6 A	6 A
External contact fuse protection, auxiliary contacts		
Max. melting integral	240 A²s	240 A²s
Blow-out fuse, quick	10 A	10 A
Blow-out fuse, slow	6 A	6 A
Blow-out fuse, gG	10 A	10 A
Circuit breaker 24 V AC/DC,		
characteristic B/C	6 A	6 A
Contact material	AgSnO2 + 0,2 μm Au	AgSnO2 + 0,2 μm Au
Conventional thermal current	774006	774009
while loading several contacts		
Ith per contact at UB AC; AC1: 240 V, DC1: 24 V		
Conv. therm. current with 1 contact	8 A	_
Conv. therm. current with 2 contacts	7 A	_
Conv. therm. current with 3 contacts	5,6 A	_
Conv. therm. current with 4 contacts	4,9 A	_
Conv. therm. current with 5 contacts	4,4 A	_
Conv. therm. current with 6 contacts	4 A	_

Conventional thermal current	774006	774009
while loading several contacts		
Ith per contact at UB DC; AC1: 240 V, DC1: 24 V		
Conv. therm. current with 1 contact	_	8 A
Conv. therm. current with 2 contacts	_	8 A
Conv. therm. current with 3 contacts	_	7 A
Conv. therm. current with 4 contacts	_	6,1 A
Conv. therm. current with 5 contacts	_	5,4 A
Conv. therm. current with 6 contacts	_	5 A
Times	774006	774009
Switch-on delay		
With automatic start typ.	180 ms	190 ms
With automatic start max.	250 ms	250 ms
With automatic start after power on typ.	200 ms	200 ms
With automatic start after power		
on max.	300 ms	300 ms
With manual start typ.	200 ms	200 ms
With manual start max.	250 ms	250 ms
With monitored start with rising	4	
edge typ.	150 ms	165 ms
With monitored start with rising edge max.	200 ms	220 ms
Delay-on de-energisation	200 1113	
With E-STOP typ.	20 ms	20 ms
With E-STOP max.	30 ms	30 ms
With power failure typ.	170 ms	170 ms
With power failure max.	250 ms	250 ms
Recovery time at max. switching frequency 1/s		
After E-STOP	50 ms	50 ms
After power failure	300 ms	300 ms
Min. start pulse duration with a monitored start		
With rising edge	50 ms	50 ms
Supply interruption before de-energisation	35 ms	35 ms
Simultaneity, channel 1 and 2 max.	150 ms	150 ms
Environmental data	774006	774009
Climatic suitability	EN 60068-2-78	EN 60068-2-78
Ambient temperature		-
Temperature range	-10 - 55 °C	-10 - 55 °C

Environmental data	774006	774009
Storage temperature		
Temperature range	-40 - 85 °C	-40 - 85 °C
Climatic suitability		
Humidity	93 % r. h. at 40 °C	93 % r. h. at 40 °C
Condensation during operation	Not permitted	Not permitted
EMC	EN 60947-5-1, EN 61000-6-2, EN 61326-3-1	EN 60947-5-1, EN 61000-6-2, EN 61326-3-1
Vibration		
In accordance with the standard	EN 60068-2-6	EN 60068-2-6
Frequency	10 - 55 Hz	10 - 55 Hz
Amplitude	0,35 mm	0,35 mm
Airgap creepage		
In accordance with the standard	EN 60947-1	EN 60947-1
Overvoltage category	III / II	III / II
Pollution degree	2	2
Rated insulation voltage	400 V	400 V
Rated impulse withstand voltage	4 kV	4 kV
Protection type		
Housing	IP40	IP40
Terminals	IP20	IP20
Mounting area (e.g. control cabinet)	IP54	IP54
iiiet)	IF 34	IF34
Mechanical data	774006	774009
,		
Mechanical data	774006	774009
Mechanical data  Mounting position	774006 Any	774009 Any
Mechanical data  Mounting position  Mechanical life	774006 Any	774009 Any
Mechanical data  Mounting position  Mechanical life  Material	774006 Any 10,000,000 cycles	774009 Any 10,000,000 cycles
Mechanical data  Mounting position  Mechanical life  Material  Bottom	774006 Any 10,000,000 cycles PPO UL 94 V0	774009 Any 10,000,000 cycles PPO UL 94 V0
Mechanical data  Mounting position  Mechanical life  Material  Bottom  Front	774006  Any 10,000,000 cycles  PPO UL 94 V0 ABS UL 94 V0	774009  Any 10,000,000 cycles  PPO UL 94 V0 ABS UL 94 V0
Mechanical data  Mounting position  Mechanical life  Material  Bottom  Front  Top	774006  Any 10,000,000 cycles  PPO UL 94 V0 ABS UL 94 V0 PPO UL 94 V0	774009  Any 10,000,000 cycles  PPO UL 94 V0 ABS UL 94 V0 PPO UL 94 V0
Mechanical data  Mounting position  Mechanical life  Material  Bottom  Front  Top  Connection type	774006 Any 10,000,000 cycles  PPO UL 94 V0 ABS UL 94 V0 PPO UL 94 V0 Screw terminal Fixed	774009  Any 10,000,000 cycles  PPO UL 94 V0 ABS UL 94 V0 PPO UL 94 V0 Screw terminal
Mechanical data  Mounting position  Mechanical life  Material  Bottom  Front  Top  Connection type  Mounting type  Conductor cross section with screw	774006 Any 10,000,000 cycles  PPO UL 94 V0 ABS UL 94 V0 PPO UL 94 V0 Screw terminal Fixed	774009  Any 10,000,000 cycles  PPO UL 94 V0 ABS UL 94 V0 PPO UL 94 V0 Screw terminal
Mechanical data  Mounting position  Mechanical life  Material  Bottom  Front  Top  Connection type  Mounting type  Conductor cross section with screw terminals	774006 Any 10,000,000 cycles  PPO UL 94 V0 ABS UL 94 V0 PPO UL 94 V0 Screw terminal Fixed	774009 Any 10,000,000 cycles  PPO UL 94 V0 ABS UL 94 V0 PPO UL 94 V0 Screw terminal Fixed
Mechanical data  Mounting position  Mechanical life  Material  Bottom  Front  Top  Connection type  Mounting type  Conductor cross section with screw terminals  1 core flexible  2 core with the same cross section, flexible with crimp connect-	774006  Any  10,000,000 cycles  PPO UL 94 V0  ABS UL 94 V0  PPO UL 94 V0  Screw terminal  Fixed  0,2 - 4 mm², 24 - 10 AWG  0,2 - 2,5 mm², 24 - 14 AWG	774009  Any 10,000,000 cycles  PPO UL 94 V0 ABS UL 94 V0 PPO UL 94 V0 Screw terminal Fixed  0,2 - 4 mm², 24 - 10 AWG
Mechanical data  Mounting position  Mechanical life  Material  Bottom  Front  Top  Connection type  Mounting type  Conductor cross section with screw terminals  1 core flexible  2 core with the same cross section, flexible with crimp connectors, no plastic sleeve  2 core with the same cross section, flexible without crimp connectors or with TWIN crimp connectors	774006 Any 10,000,000 cycles  PPO UL 94 V0 ABS UL 94 V0 PPO UL 94 V0 Screw terminal Fixed  0,2 - 4 mm², 24 - 10 AWG  0,2 - 2,5 mm², 24 - 14 AWG	774009  Any 10,000,000 cycles  PPO UL 94 V0 ABS UL 94 V0 PPO UL 94 V0 Screw terminal Fixed  0,2 - 4 mm², 24 - 10 AWG  0,2 - 2,5 mm², 24 - 14 AWG
Mechanical data  Mounting position  Mechanical life  Material  Bottom  Front  Top  Connection type  Mounting type  Conductor cross section with screw terminals  1 core flexible  2 core with the same cross section, flexible with crimp connectors, no plastic sleeve  2 core with the same cross section, flexible without crimp connectors or with TWIN crimp connectors or with TWIN crimp connectors	774006 Any 10,000,000 cycles  PPO UL 94 V0 ABS UL 94 V0 PPO UL 94 V0 Screw terminal Fixed  0,2 - 4 mm², 24 - 10 AWG  0,2 - 2,5 mm², 24 - 14 AWG	774009  Any 10,000,000 cycles  PPO UL 94 V0 ABS UL 94 V0 PPO UL 94 V0 Screw terminal  Fixed  0,2 - 4 mm², 24 - 10 AWG  0,2 - 2,5 mm², 24 - 14 AWG

Mechanical data	774006	774009	
Dimensions			
Height	87 mm	87 mm	
Width	90 mm	90 mm	
Depth	121 mm	121 mm	
Weight	720 g	560 g	

Where standards are undated, the 2020-07 latest editions shall apply.

### Safety characteristic data



#### **NOTICE**

You must comply with the safety characteristic data in order to achieve the required safety level for your plant/machine.

Operating mode	EN ISO 13849-1:	EN ISO 13849-1:	EN 62061	EN 62061	IEC 61511	IEC 61511	EN ISO 13849-1:
	2015	2015	SIL CL	PFH <sub>D</sub> [1/h]	SIL	PFD	2015
	PL	Category					T <sub>м</sub> [year]
_	PL e	Cat. 4	SIL CL 3	2,31E-09	SIL 3	2,03E-06	20

Explanatory notes for the safety-related characteristic data:

- ▶ The SIL CL value in accordance with EN 62061 corresponds to the SIL value in accordance with EN 61508.
- ▶ T<sub>M</sub> is the maximum mission time in accordance with EN ISO 13849-1. The value also applies as the retest interval in accordance with EN 61508-6 and IEC 61511 and as the proof test interval and mission time in accordance with EN 62061.

All the units used within a safety function must be considered when calculating the safety characteristic data.



#### **INFORMATION**

A safety function's SIL/PL values are **not** identical to the SIL/PL values of the units that are used and may be different. We recommend that you use the PAScal software tool to calculate the safety function's SIL/PL values.

# Supplementary data




#### **CAUTION!**

It is essential to consider the relay's service life graphs. The relay outputs' safety-related characteristic data is only valid if the values in the service life graphs are met.

The PFH value depends on the switch frequency and the load of the relay output. If the service life graphs are not accessible, the stated PFH value can be used irrespective of the switch frequency and the load, as the PFH value already considers the relay's B10d value as well as the failure rates of the other components.

### Service life graph

The service life graphs indicate the number of cycles from which failures due to wear must be expected. The wear is mainly caused by the electrical load; the mechanical load is negligible.



### Example

Inductive load: 0.2 A

▶ Utilisation category: AC15

▶ Contact service life: 4 000 000 cycles

Provided the application to be implemented requires fewer than 4 000 000 cycles, the PFH value (see Technical details) can be used in the calculation.

To increase the service life, sufficient spark suppression must be provided on all output contacts. With capacitive loads, any power surges that occur must be noted. With DC contactors, use flywheel diodes for spark suppression.

### Order reference

Product type	Features	Connection type	Order no.
PNOZ 10	24 V AC	Screw terminals	774000
PNOZ 10	48 V AC	Screw terminals	774002
PNOZ 10	110 – 120 VAC	Screw terminals	774003
PNOZ 10	230 – 240 VAC	Screw terminals	774006
PNOZ 10	24 V DC	Screw terminals	774009

# EC declaration of conformity

This product/these products meet the requirements of the directive 2006/42/EC for machinery of the European Parliament and of the Council. The complete EC Declaration of Conformity is available on the Internet at www.pilz.com/support/downloads. Representative: Norbert Fröhlich, Pilz GmbH & Co. KG, Felix-Wankel-Str. 2, 73760 Ostfildern, Germany



Technical support is available from Pilz round the clock.

Americas
Brazil
+55 11 97569-2804
Canada
+1 888 315 7459
Mexico
+52 55 5572 1300
USA (toll-free)
+1 877-PILZUSA (745-9872)

Asia
China
+86 21 60880878-216
Japan
+81 45 471-2281
South Korea
+82 31 778 3300

# +61 3 95600621 Europe Austria +43 1 7986263-0 Belgium, Luxembourg +32 9 3217570 France +33 3 88104003 Germany +49 711 3409-444 Ireland +353 21 4804983 Italy, Malta +39 0362 1826711

Australia

Scandinavia +45 74436332 Spain +34 938497433 Switzerland +41 62 88979-32 The Netherlands +31 347 320477 Turkey +90 216 5775552 **United Kingdom** +44 1536 462203

You can reach our international hotline on: +49 711 3409-444 support@pilz.com

Pilz develops environmentally-friendly products using ecological materials and energy-saving technologies. Offices and production facilities are ecologically designed, environmentally-aware and energy-saving. So Pilz offers sustainability, plus the security of using energy-efficient products and environmentally-friendly solutions.











CECE®, CHRE®, CMSE®, induraNET p®, Leansafe®, Master of Safety®, Master of Security®, PAS4000®, PAScoal®, PASconfig®, Pilz®, PIT®, PLID®, PMCprimo®, PMCprotego®, PMCprotego PMCprotego®, P

We are represented internationally. Please refer to our homepage www.pilz.com for further details or contact our headquarters.

